


**TECHNICAL MANUAL
ORGANIZATIONAL MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)**

This copy is a reprint which includes current pages from Changes 1 and 2.



EQUIPMENT DESCRIPTION AND DATA	1-2
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)	2-1
FUNCTIONAL TESTING	2-3
TROUBLESHOOTING	2-11
MAINTENANCE PROCEDURES FOR M10 PROTECTIVE ENTRANCE	2-56
MAINTENANCE PROCEDURES FOR M56 GAS-PARTICULATE FILTER UNIT	2-68
MAINTENANCE PROCEDURES FOR M262 INSTALLATION KIT	2-89
MAINTENANCE ALLOCATION CHART	B-1
REPAIR PARTS AND SPECIAL TOOLS LIST	C-1
EXPENDABLE SUPPLIES AND MATERIALS LIST	D-1
ILLUSTRATED LIST OF MANUFACTURED ITEMS	E-1
INDEX	Index 1

COLLECTIVE PROTECTION EQUIPMENT, FIRE DIRECTION SYSTEM,
ARTILLERY, (TACFIRE) AN/GSG-10(V)
CONSISTING OF
ENTRANCE, PROTECTIVE, PRESSURIZED, COLLAPSIBLE, M10
(NSN 4240-00-229-2610);
FILTER UNIT, GAS-PARTICULATE, 200 CFM, 208 V, 400 Hz, M56
(NSN 4240-00-237-0227);
AND
INSTALLATION KIT, CBR, PROTECTIVE EQUIPMENT, TACFIRE, M262
(NSN 4240-01-063-4655)

HEADQUARTERS, DEPARTMENT OF THE ARMY
DECEMBER 1981

WARNINGS

High voltage is used to power this equipment. Before removing or installing power cable, be sure that POWER switch on compartment control module is in OFF position and that the collective protection equipment power source is shut down to avoid personal injury or loss of life.

If filter unit is operating, high voltage is present at the 208V indicator lamp socket on the power distribution unit. Personal injury or loss of life may result if socket is contacted.

Do not remove covers to service components after toxic exposure without observing proper handling procedures.

Filter seals must be properly seated to prevent bypass of contaminated air:

- Torque access cover bolts 180 to 200 inch-pounds to seat gas filter.
- Tighten inner cover retaining bar until sleeve is flush with top surface to seat particulate filter.

CHANGE
NO. 2

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 23 December 1989

ORGANIZATIONAL MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)
FOR
COLLECTIVE PROTECTION EQUIPMENT
FIRE DIRECTION SYSTEM, ARTILLERY (TACFIRE) , AN/GSG-10 (V)

1. The purpose of this change is to update guidance for disposal, handling, and storage of filters.
2. New or changed material is indicated by a vertical bar in the margin of the page. RPSTL listing changes are indicated by an asterisk to the left of the item number column adjacent to the line item;
3. Remove old pages and insert new pages as follows:

Remove Pages

None
2-1 and 2-2
C-9 and C-10

Insert Pages

a/(b blank)
2-1 and 2-2
C-9 and C-10

4. File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN II
Brigadier General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-28 (block 40), maintenance requirements for TM 3-4240-284-20&P.

CHANGE }
No. 1 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC 30 August 1982

Organizational Maintenance Manual
(Including Repair Parts and Special Tools List)
**COLLECTIVE PROTECTION EQUIPMENT, FIRE DIRECTION SYSTEM,
ARTILLERY: (TACFIRE) AN/GSG-10(V)
CONSISTING OF
ENTRANCE, PROTECTIVE, PRESSURIZED, COLLAPSIBLE, M10
(NSN 4240-00-229-2610);
FILTER UNIT, GAS-PARTICULATE, 200 CFM, 208 V, 400 Hz, M56
(NSN 4240-00-237-0227);
AND
INSTALLATION KIT, CBR, PROTECTIVE EQUIPMENT, TACFIRE, M262
(NSN 4240-01-063-4655)**

This change provides procedures for preventing the spread of small cracks *in the* plastic top and bottom shells of protective entrances.

TM 3-4240-284-20&P, 16 December 1981, is changed as follows:

1. Remove old pages and insert new pages as indicated below

<i>Remove pages</i>	<i>Insert pages</i>
2-3/2-4	2-3/2-4
2-55/2-56	2-55/2-56
None	2-62.1/2-62.2
B-3/B-4	B-3/B-4

2. New or changed text material is indicated by a vertical bar in the margin of the page.
3. File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

E. C. MEYER
*General, United States Army
Chief of Staff.*

Official:

ROBERT M. JOYCE
*Major General, United States Army
The Adjutant General*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-28, Organizational Maintenance requirements for Collective Protection Equipment, Field and Shelters.

This Publication is a courtesy quick copy from the UNITED STATES ARMY PUBLICATIONS CENTER, ST. LOUIS MISSOURI, to meet your needs while we are replenishing our regular stock.

WARNING

HEALTH/ENVIRONMENTAL HAZARD

Filters use ASC Whetlerite Carbon which contains Chromium VI. Chromium VI is a known carcinogen if inhaled or swallowed. Damaged or unusable filters are classified as hazardous waste:

DO NOT throw away damaged or unusable filters as ordinary trash.

DO turn in damaged or unusable filters to your hazardous waste management office or Defense Reutilization and Marketing Office (DRMO).

Filters are completely safe to handle and use if they are not damaged in such a way that carbon leaks from them. In unlikely event that carbon should leak, use protection such as a dust respirator *to* cover nose and mouth and put carbon in container such as self-sealing plastic bag; turn in to hazardous waste management office or DRMO.

Disposal of hazardous waste is restricted by the Resource Conservation and Recovery Act as amended (42 U.S.C.A sec 6901 et seq). Violation of these laws is subject to severe criminal penalties.

TECHNICAL MANUAL }
 NO. 3-4240-284-20&P }

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 Washington, DC, 16 December 1981

Organizational Maintenance Manual
 (Including Repair Parts and Special Tools List)
**COLLECTIVE PROTECTION EQUIPMENT, FIRE DIRECTION SYSTEM,
 ARTILLERY: (TACFIRE) AN/GSG-10(V)**
CONSISTING OF
ENTRANCE, PROTECTIVE, PRESSURIZED, COLLAPSIBLE, M10
(NSN 4240-00-229-2610);
FILTER UNIT, GAS-PARTICULATE, 200 CFM, 208 V, 400 Hz, M56
(NSN 4240-00-237-0227);
AND
INSTALLATION KIT, CBR, PROTECTIVE EQUIPMENT, TACFIRE, M262
(NSN 4240-01-063-4655)

Current as of 18 August 1981


REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Armament Materiel Readiness Command, ATTN: DRSAR-MAS-C, Aberdeen Proving Ground, MD 21010. A reply will be furnished to you.

	Page
CHAPTER 1 INTRODUCTION	1-1
Chapter Overview	1-1
Section I General Information	1-1
Section II Equipment Description and Data	1-2
Section III Principles of Operation	1-8

CHAPTER 2	MAINTENANCE INSTRUCTIONS	2-1
	Chapter Overview	2-1
Section	Repair Parts, Special Tools, TMDE, and Support Equipment	2-1
Section II	Service Upon Receipt	2-1
Section III	Preventive Maintenance Checks and Services (PMCS)	2-1
Section IV	Functional Testing	2-3
Section V	Troubleshooting	2-11
Section VI	Maintenance Procedures for M10 Protective Entrance	2-56
Section VII	Maintenance Procedure for M56 Gas-Particulate Filter unit	2-68
Section VIII	Maintenance Procedures for M262 Installation	2-89
APPENDIX A	REFERENCES	A-1
APPENDIX B	MAINTENANCE ALLOCATION CHART (MAC)	B-1
APPENDIX C	REPAIR PARTS AND SPECIAL TOOLS LIST	C-1

		Page	Illus Figure
Section I	Introduction	C-1	
Section II	Repair Parts List	C-4	
Group 0100	M10 Protective Entrance (PE)	C-4	C-1
	0110 Protective Entrance Control Module	C-6	C-2
Group 0200	M56 Gas-Particulate Filter Unit	C-8	C-3
	0220 Airflow Valve	C-12	C-4
	0231 Power Distribution Panel	C-14	C-5
	0240 Compartment Control Module	C-16	C-6
Group 0300	M262 Installation Kit	C-18	C-7
	0310 Airflow Valve and Silencer	C-20	C-8
	0311 Airflow Valve	C-22	C-9
Group 0600	Bulk Supplies	C-24	
Section III	Special Tools and Equipment List (Not Applicable)		
Section IV	National Stock Number and Part Number Index	C-25	
APPENDIX D	Expendable SUPPLIES AND MATERIALS LIST		D-1
APPENDIX E	ILLUSTRATED LIST OF MANUFACTURED ITEMS		E-1
	ALPHABETICAL INDEX		Index1



**CHAPTER 1
INTRODUCTION**

CHAPTER OVERVIEW

This chapter contains general information and equipment data for your collective protection equipment for TACFIRE

Section I. GENERAL INFORMATION

1-1. SCOPE.

- a. *Type of Manual:* Organizational Maintenance, including the Repair Parts and Special Tools List.
- b. *Model Numbers and Equipment Names:* The Collective Protection Equipment, Fire Direction System, Artillery, (TACFIRE) AN/GSG-10(V) consists of:
M10 Protective Entrance
M56 Gas-Particulate Filter Unit
M262 Installation Kit
- c. *Purpose of Equipment:* Provides filtered air under positive pressure to the M10 Protective Entrance and to the TACFIRE shelter.

1-2. MAINTENANCE FORMS AND RECORDS.

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by TM 38-750, The Army Maintenance Management System .

1-3. DESTRUCTION OF MATERIAL TO PREVENT ENEMY USE. Refer to TM 43-0002-31, Destruction of Chemical Weapons and Defense Equipment to Prevent Enemy Use.

1-4. PREPARATION FOR STORAGE OR SHIPMENT. Refer to TM 11-7440-294-14 (to be published).

1-5. NOMENCLATURE CROSS-REFERENCE LIST. This listing including nomenclature cross-references used this manual.

<i>Common Number</i>	<i>Official Nomenclature</i>
M10 Protective Entrance	Entrance, Protective, Pressurized, Collapsible, M10
M56 Gas-Particulate Filter Unit	Filter Unit, Gas-Particulate, 200 CFM, 208 V, 400 Hz, M56
M262 Installation Kit	Installation Kit, M262
Cable C5-19-6170-40	Cable Assembly, Special Purpose Electrical, C5-19-6170-40
Cable C5-19-6162-10	Cable Assembly, Special Purpose Electrical, C5-19-6162-10
Cable C5-19-6170-10	Cable Assembly, Special Purpose Electrical, C5-19-6170-10
Cable C5-19-6691	Cable Assembly, Special Purpose Electrical, C5-19-6691
Cable C5-19-6693	Cable Assembly, Special Purpose Electrical, C5-19-6693
Silencer	Muffler, Intake

1-6. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATION (EIR). If your collective protection equipment needs improvement, let us know". Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Tell us why a procedure is hard to perform. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at Command US Army Armament Materiel Readiness Command, ATTN: DRSAR-MAP-A, Aberdeen Proving Ground. MD 21010. We'll send you a reply.

Section II. EQUIPMENT DESCRIPTION AND DATA

1-7. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES.

Characteristics

- The CPE is designed to operate in a chemicdbiological agent contaminated zone.
- The filter unit provides filtered air under positive pressure to the M10 Protective Entrance and to the TACFIRE shelter.
- Positive pressure prevents dangerous amounts of chemical and biological (CB) agents from entering the protected area.

The M10 Rotective Entrance, while under positrive pressure, allows personnel to enter or leave without loss of positive pressure protection in the TACFIRE shelter.

capabilities and' Features

- Control modules are provided for both the M10 Protective Entrance and the TACFIRE shelter.
- Major components of the collective protection equipment (CPE) may be attached or detached from the TACFIRE shelter without affecting the operation of the shelter.
- Modular design of CPE permits:
 - a. Easy access to the major components for servicing and maintenance.
 - b. Quick replacement of malfunctioning components.

and the floor of the shell assembly. The support assemblies are located at the rear of the protective entrance.

- An impermeable fabric assembly is attached to the two halves of the shell assembly. When the fabric is fully extended, it forms the walls of the protective entrance.

(B) PROTECTIVE ENTRANCE CONTROL MODULE. Mounted in the roof of the shell assembly, provides white/or black-out red light, purge timing and low pressure warning for the protective entrance.

(C) GAS-PARTICULATE FILTER UNIT. The filter unit housing contains the main fan, the gas filter, and the particulate filter. Inner and outer access covers permit changing the filters.

- The airflow valve, attached to the outside of the filter unit housing, controls the airflow between the filter unit, the shelter, and the protective entrance.

(D) COMPARTMENT CONTROL MODULE. Mounts inside the shelter and contains controls and indicators to operate the collective protection equipment.

(E) POWER DISTRIBUTION UNIT. Mounts on the outside of the shelter below the filter unit. It serves as the electrical power distribution center for the collective protection equipment.

(F) AIRDUCT HOSE. Large diameter (6") impermeable fabric hose, in 6 foot sections, connects filter unit, shelter, and protective entrance for filtered and return air circulation.


(G) AIRFLOW VALVE AND SILENCER. Adjusts and silences the flow of filtered air to the protective entrance. The valve is controlled by the protective entrance control module.

(H) SPECIAL PURPOSE ELECTRICAL CABLES. Six cables route electrical power and electrical operating signals between the filter unit, power distribution unit, compartment control module, protective entrance, and valve and silencer assembly. (Not all cables are shown.)

1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.


(A) PROTECTIVE ENTRANCE. Consists Of:


- Shell assembly, which is in two halves, forms the roof and floor.
- Door assembly, when fully extended, provides for entering and leaving the protective entrance. The door frame supports the front of the protective entrance.
- Two support assemblies, when fully extended, form rigid poles between the roof



MAJOR COMPONENTS

1-9. IDENTIFICATION, INSTRUCTION, AND WARNING PLATES





1-10. EQUIPMENT DATA.

DIMENSIONS AND WEIGHTS OF COLLECTIVE PROTECTION EQUIPMENT COMPONENTS

Component	Length		Width		Height		Weight	
	Inch	CM	Inch	CM	Inch	CM	LB	Kg
M10 Protective Entrance								
Packaged dimensions	49.3	125.22	43.3	109.98	12.5	31.75	145	65.77
Erected dimensions	49.3	125.22	43.3	109.98	85.4	216.91	145	65.77
Protective Entrance Control Module	16	40.64	6.75	17.14	5	12.70	7.5	3.40
M56 Gas-Particulate Filter Unit	31	78.74	36	91.24	32	81.28	123	55.79
PE Airflow Valve and Silencer	15	38.10	8	20.32	4	10.16	13	5.90
Power Distribution Unit	18.5	46.99	8.25	20.95	4.25	10.79	16	7.26
Compartment Control Module	7.7	19.55	11.75	29.84	6.5	16.51	9	4.09
Particulate Filter	Outer Dia		Inner Dia		10	25.40	7.8	3.54
	16.6	42.16	12	30.48				
	Outer Dia		Inner Dia					
Gas Filter	21.4	54.35	16.7	42.41	10	25.40	37.8	17.15

OPERATING POWER REQUIREMENTS AND CHARACTERISTICS OF COLLECTIVE PROTECTION EQUIPMENT COMPONENTS


Component	Power Requirements	Input Voltage	Maximum Capacity	Airflow (cfm)	
Protective Entrance Control Module	2 amp at 28 V dc	28 V dc	3.5 kW	200 maximum 40 minimum at 20.0 in. water gage	
M56 Gas-Particulate Filter Unit	800 Watts	200 V, 400 Hz, 3-phase			
Airflow Valve	1 amp max at 28 V dc				
Power Distribution Unit		208 V, 400 Hz, 3-phase			
Compartment Control Module	1 amp max at 28 V dc	28 V dc			
Particulate Filter					200
Gas Filter					200

Section III. PRINCIPLES OF OPERATION

1-11. AIR FILTERING AND PRESSUREIZATION SYSTEM.

a The M56 gas-particulate filter unit removes toxic gases and dust from air supplied to the M10 protective entrance and shelter. Outside air is drawn through the air inlet of the by the main fan. From the main fan, the air is pushed through the particulate and gas filter to the airflow valve. The filtered air passes through the airflow valve and is carried by airduct hoses to the protective entrance through the airflow valve and silencer and to the shelter through the air conditioner. Pressure sensing compo-

nents in compartment control module automatically adjust the airflow valve to maintain a positive pressure in the shelter. b. The M10 protective entrance provides a pressurized transition area between the shelter and the outside contaminated zone. Personnel entering from the outside must wait five minutes within the protective entrance before entering the shelter. Contamination is purged by the flow of the filtered air. The protective entrance control module automatically adjustS the airflow valve and silencer assembly to maintain the proper air pressure inside the protective entrance.



CHAPTER 2 MAINTENANCE INSTRUCTIONS

CHAPTER OVERVIEW

This chapter contains information on the following subjects:

- I. Repair Parts, Special Tools, TMDE, and Support Equipment
- II. Service Upon Receipt
- III. Preventive Maintenance Checks and Services (PMCS)
- IV. Functional Tests
- V. Troubleshooting
- VI. Maintenance Procedures for M11 Protective Entrance
- VII. Maintenance Procedures for M11a Protective Entrance
- VIII. Maintenance Procedures for M11b Protective Entrance

Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

- 2-1. COMMON TOOLS AND EQUIPMENT.** For authorized common tools and equipment refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.
- 2-2. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT.** Special tools, TMDE, and support equipment are listed in Appendix C, Section III of this manual.
- 2-3. REPAIR PARTS.** Repair parts are listed and illustrated in Appendix C of this manual.

Section II SERVICE UPON RECEIPT

- 2-4. SERVICE UPON RECEIPT.** Refer to TM 11-7440-294-14 (to be published).

Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

- 2-5. PMCS PROCEDURES.**
- a. *General.* The PMCS procedures are contained in table below. They are arranged in logical sequence requiring a minimum amount of time and motion on the part of the persons performing them and are arranged so that there will be a minimum interference between persons performing checks simultaneously on the same end item.
 - b. *Item Number Column.* Checks and services are numbered in chronological order regardless of interval. This column shall be used as a source of item numbers for the "TM Number" column on DA Form 2404, Equipment Inspection and Maintenance Worksheet, in recording results of PMCS.
 - c. *Item To Be Inspected Column.* The items listed in this column are divided into groups indicating the portion of the equipment of which they are a part, for example, "Filter Unit," "Protective Entrance." Under these groupings, the items to be inspected are identified by as few words, usually the common name, as will clearly identify the item, for example, "main fan assembly," "airflow valve."
 - d. *Procedures Column.* This column contains a brief description of the procedure by which the check is to be performed. It contains all the information required to accomplish the checks and services, including appropriate tolerances, adjustment limits, and instrument and gage readings.

PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) SEMIANNUAL SCHEDULE

NOTE

Perform these checks and services in the order listed before you perform functional testing.

Item No.	Item To Be Inspected	Procedures
1	Filter Housing	<p>Inspect identification and instruction plates. You must be able to read them. Replace plates if necessary (p 2-77 and p 2-78).</p> <p>Inspect outside surfaces for rust, chipped paint, or bare metal on painted surfaces. Repaint or touchup as necessary (p 2-78).</p> <p>Make sure that all parts are secure and that there is no loose or missing hardware. Tighten loose hardware. Replace missing hardware.</p>
2	Special Purpose Electrical Cable Assemblies	<p>Inspect cable assemblies for bare wires, broken insulation, broken or damaged connectors. Replace damaged cable assemblies (p 2-95 through 2-106).</p>
3	Main Fan Assembly Cable	<p>Inspect cable assembly for bare wire, broken insulation, broken or damaged connector. Replace damaged main fan assembly (p 2-79).</p>
4	Airflow Valve	<p>Inspect valve for damage and loose mounting hardware. Replace missing mounting hardware. Replace damaged airflow valve (p 2-82).</p>
5	Power Distribution unit	<p>Inspect unit for loose or missing mounting hardware. Tighten loose hardware. Replace missing hardware.</p> <p>Inspect for damaged or missing electrical covers. Replace power distribution unit if the covers are damaged or missing (p 2-85).</p>
6	Gas-Particulate Filters	<p style="text-align: center;">WARNING</p> <p style="text-align: center;">DO NOT throw away damaged or unusable filters as ordinary trash.</p> <p style="text-align: center;">DO turn in damaged or unusable filters to your hazardous waste management office or Defense Reutilization and Marketing Office (DRMO).</p> <p>Remove filters (p 2-70) and check for physical or water damage.</p> <p>Inspect housing seal and inner cover gasket for damage. Replace seal or gasket if unserviceable (p 2-71).</p> <p>Reinstall filters or install new filter (p 2-72).</p>


Item No.	Item To Be Inspected	Procedures
7	Air duct Hoses	Inspect air duct hoses for damage or missing clamps. Repair or replace air duct hoses if necessary (p 2-108). Replace missing clamps.
8	M10 Protective Entrance	<p>Inspect identification and instruction plates. You must be able to read them. Replace plates if necessary (p 2-57).</p> <p>Inspect protective entrances with plastic top and bottom shells for cracks (p 2-62.1).</p> <p>Inspect outside surface for chipped paint or bare metal on painted surfaces. Repaint or touch up as necessary (p 2-62).</p> <p>Make sure that all parts are secure and that there is no loose or missing hardware. Tighten loose hardware. Replace missing hardware.</p>
9	Valve and Silencer	<p>Inspect identification and instruction plates. You must be able to read them. Replace instruction plate (p 2-91).</p> <p>Inspect valve and silencer for damage and loose or missing hardware. Tighten loose hardware. Replace missing hardware. Replace damaged valve and silencer (p 2-89).</p>
10	Collective Protection Equipment	Perform functional testing (p 2-3 thru p 2-10).

Section IV. FUNCTIONAL TESTING

2-6. GENERAL. This section contains instructions for functional testing the collective protection equipment for shelter. These tests must be performed following installation of the equipment, and semiannually then after.


- & Preventive Maintenance *Checks and Services* (PMCS). Perform PMCS on page 2-1 before performing functional testing.
- b. *Troubleshooting Procedures.* Refer to troubleshooting on page 2-11 for malfunctions and corrections.

2-7. FUNCTION TEST

LOCATION	ITEM	ACTION	INDICATION/REMARKS
Power Circuit	Cables	Check that all connections are tight.	Connector J6 on power distribution unit is not used.
	Power source	Check that power is supplied to power distribution unit.	
Power Distribution Unit (PDU)	Circuit breakers	Check that circuit breakers (1, 2, 3 and 4) are set. Press to set.	Power distribution unit is actually installed on its side, but is shown rightside up for clarity.
Compartment Control Module (CCM)		 <p>Set POWER switch (14) to OFF.</p>	
	Circuit breakers	Check that circuit breakers (5, 6, 7, and 8) are set. Press to set.	
Compartment Control Module (CCM)	Indicator lights	Press to test lamps: MASK (9)	Light will flash and warning horn (10) will sound. Replace lamp if necessary (p 2-88).
		ENTRANCE LOW PRESSURE (11)	Light will light when pressed. Replace lamp if necessary (p 2-88).
		CHANGE FILTER (12)	Light will light when pressed. Replace lamp if necessary (p 2-88).
		OCCUPIED (13)	Light will light when pressed. Replace lamp if necessary (p 2-88).

LOCATION	ITEM	ACTION	indication/REMARKS
----------	------	--------	--------------------

Protective Entrance Control Module (PECM)	Indicator lights	Press to test lamps: LOW PRESSURE (15)	Light will light when pressed. Replace lamp if necessary (p 2-66).
		PURGE (16)	Light will light when pressed. Replace lamp if necessary (p 2-85).



Dome light (18) will show white light. Replace lamp if necessary (p 2-67).

Set switch (17) to RED.

Dome light (18) will show red light. Replace lamp if necessary (p 2-67).

Set switch (17) to OFF.

Dome light (18) will go off.

Timer

Rotate TIMER (19) fully clockwise.

PURGE light (16) will light.

OCCUPIED light in compartment control module will light.

Allow TIMER (19) to return to "O" (approximately five minutes).

PURGE and OCCUPIED light will go off.


2-7. FUNCTIONAL TEST (CONT).

LOCATION	ITEM	ACTION	INDICATION/REMARKS
----------	------	--------	--------------------

		Close shelter door and protective entrance door.	
Compartment Control Module	Pressure circuit	Set POWER switch (14) to ON.	Main fan must start and run. MASK indicator light (9) will flash. Warning horn(10) will sound until shelter is pressurized (approximately 30 seconds). MASK light (9) will go off and Warning horn (10) will silence. when Proper shelter pressure is reached.
		Allow horn to silence automatically. This will indicate proper system operation.	

ENTRANCE LOW PRESSURE light (11) will light twhen filter until is started and then go off when proper protective entrance pressure is reached.

When loss of power to the collective protection equipment occurs with the compartment control module POWER switch in the ON position, the MASK light (9) will flash and warning horn (10) will sound.



		open shelter door.	MASK light (9) will flash. warning horn (10) will sound.
		Press HORN OFF button (20).	Button will stay in pressed positbn. Warning horn willstop sounding MASK light (9) will light and etay on.

LOCATION	ITEM	ACTION	INDICATION/REMARKS
----------	------	--------	--------------------


Open protective entrance door.

Compartment Control Module

Pressure circuit

ENTRANCE LOW PRESSURE light (11) will light.

Protective Entrance control Module




LOW PRESSURE light (15) will light.

Close protective entrance and shelter doors.

Within 30 seconds:
ENTRANCE LOW PRESSURE light (11) will go off. Also, the LOW PRESSURE light (15) on the protective entrance control module will go off.

MASK light (9) will go Off. HORN OFF button (20) will reset.




Power Distribution Unit

CHANGE FILTER indicator light

Disconnect tubing (21) (green dot).

Fitter unit must be operating.




2-7. FUNCTIONAL TEST (CONT).

LOCATION	ITEM	ACTION	indication/REMARKS
----------	------	--------	--------------------

Compartment Control Module

CHANGE FILTER indicator light

CHANGE FILTER light (12) will light.




Power Distribution Unit

Fan and Airflow Valve Housing Unit

Airflow valve

Filter unit must be operating.



Close shelter door.

Turn off filter unit:
Set compartment control POWER switch (14) to OFF.


Replace airduct hose (23) on port marked TO PROT ENT. Tighten hose damp (22).

The sliding plate (24) in the airflow valve must move to completely close off the outlet marked TO PROT ENT.

The sliding plate (24) in the airflow valve will move toward the port marked TO SHELTER. This partly opens the port marked TO PROT ENT.

Observe that sliding plate (24) covers the port marked TO SHELTER.

LOCATION	ITEM	ACTION	INDICATION/REMARKS
Compartment Control Module	Loss of power warning system	Disconnect plug P1 (25).	
		Set POWER switch (14) to ON.	MASK light (9) will flash. Warning horn (10) will sound.
		Set POWER switch (14) to OFF.	
		Reconnect plug P1 (25).	



Set POWER switch (14) to ON.

Filter unit must be operating and the shelter and protective entrance must be pressurized.

2-7. FUNCTIONAL TEST (CONT).

LOCATION	ITEM	ACTION	INDICATION/REMARKS
----------	------	--------	--------------------

NOTE

Two technicians are needed for this checkout procedure: on the outside of the protective entrance and the other shelter at airflow valve and silencer.


Airflow Valve and Silencer
Airflow valve
VALVE AND SILENCER

Make sure that shelter and protective entrance doors are closed.

Loosen hose clamp(26) and remove cap (27)from outlet port.

Observe the sliding plate.


The sliding plate (28) will move in a direction to allow more airflow into the protective entrance.



Replace cap(27) on outlet port. Tighten hose damp (26).

Fan and Airflow Valve Housing unit
Airflow valve

Disconnect cable P15 (29).




Hold airduct hose (23) going to the protective entrance and loosen hose damp (22). Remove airduct hose.

Reconnect cable P15 (29).

Sliding plate (24) will move to reduce airflow into the protective

Replace airduct hose (23). Tighten entrance hose damp (22).



Compartment control Module
POWER Switch

Set POWER switch (14) to OFF.

Section V. TROUBLESHOOTING

2-8. GENERAL.

a. This section contains troubleshooting information for locating and correcting most of the operating troubles which may develop in your protective equipment. Each malfunction for an individual component, unit, or system is followed by a list of tests or inspections which will help you to determine corrective actions to take. You should perform the test/inspections and corrective actions in the order listed.

b. This manual cannot list all possible malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed (except when malfunction and cause are obvious) or is not corrected by listed corrective actions, notify your supervisor.

NOTE

When measuring voltage at the Power Distribution Unit (PDU), TP #10 is ground. PDU is actually installed on its side, but is shown rightside up for clarity.

2-9. TROUBLESHOOTING PROCEDURES.


a. Perform functional test first. Then use the symptom index for quick access to the troubleshooting procedures.

SYMPTOM INDEX



Troubleshooting
Procedure
Page

1. MASK light flashing and/or warning horn sounding	2-12
2. Protective entrance LOW PRESSURE lights on	2-22
3. No power indication (all indicator lights do not illuminate when pressed to test).	2-33
4. Protective entrance LOW PRESSURE lights will not come on	2-39
5. CHANGE FILTER lights with clean filter	2-45
6. CHANGE FILTER light does not illuminate	2-46
7. OCCUPIED AND PURGE lights do not operate properly	2-48
8. INDICATORS circuit breaker trips	2-51
9. Protective Entrance dome light does not come on	2-54

b. The following describes the use of the troubleshooting charts:



1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING.




LEGEND


CCM = Compartment Control Module

* = To Be Published


MAIN FAN CIRCUIT BREAKER



CCM




AIRFLOW VALVE



AIRFLOW VALVE

From page 2-12



LEGEND




CCM = Compartment Control Module

FU = Filter Unit

* = To Be Published


1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT)

Page 2-13




LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- TP = Test Point
- FU = Filter Unit
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published



PAGE 2-14



LEGEND

CCM = Compartment Control Module


PDU = Power Distribution Unit

Feed Thru = Elec/Pneu Feed Thru



* = To Be Published

1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT)


Page 2-13



MAIN FAN CIRCUIT BREAKER





MAIN FAN CIRCUIT BREAKER



LEGEND


- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

Page 2-16






LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published




1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT)
 Page 2-13 or Page 2-16




LEGEND



- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published



208V INDICATOR





POWER SWITCH



LEGEND


- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT)




LEGEND

- CCM = Compartment Control Module
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published







Page 2-20



LEGEND




- PDU = Power Distribution Unit
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON



LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- PE = Protective Entrance
- PECM = Protective Entrance Control Module
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published






LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON (CONT)




Page 2-23



LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

Page 2-23






LEGEND

- GRD = Ground
- PE = Protective Entrance
- PECM = Protective Entrance Control Module
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru

2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON (CONT)




Page 2-22

With the power on and both entrance doors closed, disconnect P15 at PE airflow valve and remove airduct to PE airflow valve and silencer



LEGEND

- CCM = Compartment Control Module
- PE = Protective Entrance
- Feed Thru = Elec/Pneu Feed Thru





LEGEND

- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON (CONT)

Page 2-27





LEGEND

CCM = Compartment Control Module


Feed Thru = Elec/Pneu Feed Thru

* = To Be Published






LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- PE = Protective Entrance
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published





2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON (CONT)

Page 2-29




LEGEND
 PDU = Power Distribution Unit
 PECM = Protective Entrance Control Module
 TP = Test Point
 Feed Thru = Elec/Pneu Feed Thru
 * = To Be Published





LEGEND

- PDU = Power Distribution Unit
- PE = Protective Entrance
- PECM = Protective Entrance Control Module
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru



2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON (CONT)


Page 2-31




LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published


3. NO POWER INDICATION (ALL INDICATOR LIGHTS DO NOT ILLUMINATE WHEN PRESSED TO TEST.)



CCM



PECM




PDU

AN/USM-223 MULTIMETER

LEGEND





CCM = Compartment Control Module
 PDU = Power Distribution Unit
 PE = Protective Entrance



PECM = Protective Entrance Control Module
 TP = Test Point
 * = To Be Published


3. NO POWER INDICATION (ALL INDICATOR LIGHTS DO NOT ILLUMINATE WHEN PRESSED TO TEST) (CONT)

Page 2-33





LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published



Page 2-34






LEGEND

- PDU = Power Distribution Unit
- PECM = Protective Entrance Control Module
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru




3. NO POWER INDICATION (ALL INDICATOR LIGHTS DO NOT ILLUMINATE WHEN PRESSED TO TEST) (CONT).

Page 2-35



LEGEND

- PDU = Power Distribution Unit
- PECM = Protective Entrance Control Module
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published





LEGEND

- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

3. NO POWER INDICATION (ALL INDICATOR LIGHTS DO NOT ILLUMINATE WHEN PRESSED TO TEST) (CONT).




Page 2-37



LEGEND

- PDU = Power Distribution Unit
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

4. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS WILL NOT COME ON.






LEGEND

- CCM = Compartment Control Module
- PE = Protective Entrance
- PECM = Protective Entrance Control Module



4. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS WILL NOT COME ON (CONT).

Page 2-39



LEGEND

- PDU = Power Distribution Unit
- PE = Protective Entrance
- PECM = Protective Entrance Control Module
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru



LEGEND

CCM = Compartment Control Module



PDU = Power Distribution Unit

Feed Thru = Elec/Pneu Feed Thru

* = To Be Published



4. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS WILL NOT COME ON (CONT).

Page 2-40



LEGEND


- PDU = Power Distribution Unit
- PECM = Protective Entrance Control Module
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published



LEGEND



- CCM = Compartment Control Module
- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

Page 2-39



4. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS WILL NOT COME ON (CONT).


Page 2-43




LEGEND

- PDU = Power Distribution Unit
- PECM = Protective Entrance Control Module
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published





5. CHANGE FILTER LIGHTS WITH CLEAN FILTER.




LEGEND
 CCM = Compartment Control Module
 PDU = Power Distribution Unit
 TP = Test Point
 Feed Thru = Elec/Pneu Feed Thru
 * = To Be Published




6. CHANGE FILTER LIGHT DOES NOT LIGHT.



LEGEND
 PDU = Power Distribution Unit
 TP = Test Point
 Feed Thru = Elec/Pneu Feed Thru
 * = To Be Published



Page 2-46








LEGEND

CCM = Compartment Control Module


Feed Thru = Elec/Pneu Feed Thru

* = To Be Published


7. OCCUPIED AND PURGE LIGHTS DO NOT OPERATE PROPERLY.



LEGEND
 PDU = Power Distribution Unit
 PECM = Protective Entrance Control Module
 TP = Test Point
 Feed Thru = Elec/Pneu Feed Thru



Page 2-48





LEGEND

CCM = Compartment Control Module
 Feed Thru = Elec/Pneu Feed Thru

* = To Be Published

7. OCCUPIED AND PURGE LIGHTS DO NOT OPERATE PROPERLY (CONT)




Page 2-48




LEGEND

- PDU = Power Distribution Unit
- PECM = Protective Entrance Control Module
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

INDICATORS CIRCUIT BREAKER






8. INDICATORS CIRCUIT BREAKER TRIPS.



LEGEND CCM = Compartment Control Module
 PDU = Power Distribution Unit
 TP = Test Point
 Feed Thru = Elec/Pneu Feed Thru
 * = To Be Published


8. INDICATOR CIRCUIT BREAKER TRIPS (CONT).

Page 2-51





LEGEND

- PDU = Power Distribution Unit
- PECM = Protective Entrance Control Module
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru





Page 2-52




LEGEND

- PDU = Power Distribution Unit
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

9. PROTECTIVE ENTRANCE DOME LIGHT DOES NOT COME ON




PE LIGHT CIRCUIT BREAKER




LEGEND


- PDU = Power Distribution Unit
- PE = Protective Entrance
- PECM = Protective Entrance Control Module
- TP = Test Point
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published



PE LIGHT CIRCUIT BREAKER



Page 2-54



LEGEND

- PDU = Power Distribution Unit
- PE = Protective Entrance
- PECM = Protective Entrance Control Module
- Feed Thru = Elec/Pneu Feed Thru
- * = To Be Published

Section VI. MAINTENANCE PROCEDURES FOR M10 PROTECTIVE ENTRANCE

2-10. GENERAL. These instructions are for use by organizational maintenance personnel. They apply to:
 M10 Protective entrance
 Protective entrance control module

2-11. M10 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS.

This task covers:

- | | | | |
|----------------|-----------------|----------------|----------------------|
| a. Replacement | c. Removal | e. Disassembly | g. Painting |
| b. Repair | d. Installation | f. Reassembly | h. Inspection/Repair |

INITIAL SETUP

Tools

- General Mechanics Tool Kit
 SC 5180-90-CL-N26
- Portable electric drill NSN 5130-00-889-8994
- Twist drill NSN 5133-00-227-9650

References

TM 11-7440-294-14 (to be published)

Personnel Required: 2


LOCATION	ITEM	ACTION
----------	------	--------

REPLACEMENT

TACFIRE	MI O Protective entrance	Refer to TM 11-7440-294-14 for protective entrance replacement instructions.
---------	--------------------------	--

REPAIR

M10 Protective Entrance (PE) Impermeable wall fabric



Repair tears or slits:

Clean damaged area using rags (Item 6, app D) and dry-cleaning solvent (item 4, app D).

Cut a piece of tape (item 7, app D) about four inches longer than the tear or slit. position tape over the tear or slit and press firmly in place.

Apply tape to the inside of the protective entrant" impermeable fabric wall. If necessary for added strength, crossed strips of tape may be used

LOCATION

ITEM

ACTION


REMOVAL

M10 Protective Entrance

Instruction plates (1, 2, and 4) and identification plate (3)

Lift edge of plate with a sharp tool.

Pull plate completely off the mounting surface.



OPENING PROCEDURES

1. REMOVE CAP AND ATTACH AIR HOSE.
2. DISENGAGE LATCHES - RAISE TOP TO FULL HEIGHT.
3. OPEN DOOR. INSERT DETENT PINS IN DOOR FRAME. (OPENING INSTRUCTIONS CONTINUED ON P.E. WALL)

CLOSING PROCEDURES

7. LOWER DOOR SIDE - TUCK IN ALL FABRIC - LOWER BACK SIDE.
8. CHECK FOR FABRIC AND SHELL ALIGNMENT - SECURE LATCHES.
9. REMOVE AIR HOSE - REPLACE CAP.

ENTRANCE, PROTECTIVE, PRESSURIZED
COLLAPSIBLE, M10

NSN
SERIAL NO.
CONT NO. US

CAUTION
DO NOT ENTER WHEN
PROTECTIVE ENTRANCE
IS OCCUPIED

INSTALLATION

Thoroughly dean mounting surface with dry-cleaning solvent (item 4, app D). Surface must be free of all contamination such as oil, grease, dirt, or any foreign matter.

NOTE

Identification and instndon plates are made of aluminum foil with a solvent-activated backing.

Activate the back of the plate with dry-cleaning solvent (item 4, app D).

Mount the plate and apply pressure to the plate surface.


Spray or- brush plate with aliphatic polyurethane coating (item 2, app D).

2-11. M10 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M10 Protective Entrance	Plug drain	<p>Remove cap plain nut (1) and washer (2).</p> <p>Remove screw (3) from protective entrance (4) and chain loop (5).</p> <p>Unscrew plug drain (6) and remove.</p>
-------------------------	------------	--



INSTALLATION

- Install screw (3) through chain loop (5) and hole in protective entrance (4).
- Install washer (2) and cap plain nut (1). Tighten securely.
- Install plug drain (6). Tighten finger tight.

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M10 Protective Entrance
Airduct Inlet


Dust and moisture seal
protective

Loosen hose clamps (1). Remove airduct hose (2) from inlet (3).

Reach through inlet and hold nut (4) with a wrench.

Remove screw (5) from nut (4), washer (6), and cable loop on cap (7) from inlet (3).

Remove cap (7) from protective entrance (8).



M10 Protective Entrance
Airduct Cutlet

Dust and moisture seal
protective cap


Loosen hose clamp (9) Remove airduct hose (10) from Outlet (11).

Reach through outlet hold screw (12) with a wrench.

Unscrew nut (13).

Remove washers (14 and 15) and screw (12).

Remove cap (16) from protective entrance (8).



2-11. M10 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS (CONT).


LOCATION	ITEM	ACTION
----------	------	--------

DISASSEMBLY

Dust and moisture seal protective cap

Unscrew nut (1). Remove washer (2), screw (3), support cable (4), and washer (5) from rubber cap (6).

Unscrew adjustment screw on hose clamp (7) and remove from rubber cap (6).



REPAIR

Support cable

Fabricate support cable (fig E-1, app E).

REASSEMBLY

Dust and moisture seal protective cap


Install hose clamp (7) in groove in rubber cap (6). Turn adjustment screw just enough to keep clamp in place.

Secure support cable (4) to rubber cap (6) with screw (3), washer (5), washer (2), and nut (1).

LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION

M10 Protective Entrance Airduct Inlet	Dust and moisture seal protective cap
--	--




Place screw (5) through support cable loop and screw hole at base of airduct inlet (3).

Reach through airduct inlet and install washer (6) and nut (4). Tighten security.

Place airduct hose (2) on air duct inlet.

Tighten hose clamps (1) securely.

M10 Protective Entrance Airduct outlet	Dust and moisture seal protective cap
---	--



Reach through airduct outlet and install screw (12).

Place support cable loop, washers (14 and 15), and nut (13) on screw (12). Tighten nut securely.

Place airduct hose (10) on airduct outlet (11).

Tighten hose clamp (9) securely.

2-11. M10 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL


M10 Protective Entrance (PE)

Static port adapter

Disconnect hose adapter (1).

Remove three nuts (2), screws (3), washers (4), and static port cover (5).

Remove nut (6) and static port adapter (7)



INSTALLATION

Install static port adapter (7) and nut (6). Tighten securely.

Install static port cover (5) using screws(3), washers (4), and nuts (2).

connect hose adapter (1) to static port adapter (7). Tighten security.

PAINTING

M0 Protective Entrance

Painted surfaces

Touch-up painting of metal surfaces is authorized:

Clean surfaces to be painted using rags (Item 6, app D) and dry-cleaning solvent (item 4, app D).

NOTE

Refer to TM 43-0139 for painting instructions for field use.

Paint surface with one coat of primer (item 5, app D).

Paint surfaces of equipment mounted outside of the protective entrance with aliphatic polyurethane coating (item 2, app D).

LOCATION	ITEM	ACTION
----------	------	--------

INSPECTION/REPAIR

M10 Protective Entrance

Top and bottom shells


NOTE

Two technicians are needed for this procedure: one on the inside of the entrance and one on the outside.

Lay erected entrance on its side with door up.

Remove screws (1), pads (2), and retainer assemblies (3).

Examine top (4) and bottom (5) shells for cracks, particularly in the area of A.



2-11. M10 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

INSPECTION/REPAIR (CONT)


M10 Protective Entrance

Top and bottom shells
 DRILLED STOP HOLES


Press suspect crack areas on outside of shell with a block of wood to expose end point of cracks for technician inside entrance.

Drill a 1/8-inch diameter stop hole through shell from inside entrance at endpoint of each crack. See detail A.

Reinstall screws (1), pads (2), and retainer assemblies (3).



DETAIL A



2-12. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Repair
- c. Installation
- d. Disassembly
- e. Reassembly

INITIAL SETUP

Tools

General Mechanics Tool Kit
SC 5180-90-CL-N26

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M10 Protective Entrance


Protective entrance control module

Set POWER switch (1) on compartment control module to OFF.

Shut down collective protection equipment power source.

Disconnect electrical cable plugs P20 (2) and P21 (3) from outside of protective entrance and remove nuts (4 and 5).


Remove electrical connector covers (6 and 7) with chains and loops. Withdraw electrical cable connectors (8 and 9). Remove and retain preformed packings (10 and 11) on connectors (8 and 9).



2-12. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL (CONT)



Disconnect adapter (12) on hose (13) from coupling (14).

Remove screws (15) and washers (16).

Remove protective entrance control module (17) from inside the protective entrance.

CAUTION

Pressure circuit may be damaged. Hold coupling on protective entrance control module with a wrench to prevent it from turning.

Disconnect adapter (18) on hose (13) from adapter(19) on protective entrance control module.


REPAIR

Hose

Fabricate replacement hose (13) (fig E-4A, app E). Cut adapters (12 and 18) from hose and insert adapters in new hose.

INSTALLATION

M10 Protective Entrance	Protective entrance control module
-------------------------	------------------------------------



Install hose on protective entrance control module. Hold adapter (19) with a wrench and tighten adapter (18).

Position protective entrance control module (17) against brackets (20) in protective entrance.

Install screws (15) through washers (16) and into brackets (20). Tighten securely.

Install adapter (12) on coupling (14) and tighten.

Install electrical cable connectors J21 (9) and J20 (8) with prefrned packings (10 and 11) in protective entrance from the inside.


LOCATION	ITEM	ACTION
		From the outside, install loop of connector cover (7) and nut (5) on cable connector J21 (9). Tighten nuts securely. From the outside, install loop of connector cover (6) and nut (4) on cable connector J20 (8). Tighten nut securely.
		Reconnect electrical cable plugs P20 (2) and P21 (3).

REMOVAL

Protective Entrance Control Module

Knob

Pull knob (1) from timer shaft (2).



INSTALLATION

Align knob pointer with 0 on panel. Push knob (1) on timer shaft (2).


REMOVAL

Protective Entrance Control Module

PURGE indicator lamp

Unscrew indicator light (3) from indicator light base (4).

Pull out lamp (5) from indicator light (3).



INSTALLATION

Insert indicator lamp (5) in indicator light (3).

Install indicator light (3) in light base (4).


2-12. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Protective Entrance Control Module LOW PRESSURE lamp

Using two screwdrivers, gently pry lens (1) from panel (2)



Remove lamps (3) from lens (1).



INSTALLATION



Insert lamps (3) in lens (1). Insert lens (1) into panel (2) as shown in detail A. Press lens into panel until it snaps into place.

REMOVAL

Protective Entrance Control Module Identification plate

Lift edge of plate (4) with a sharp tool.

Pull plate completely off the mounting surface.



INSTALLATION

Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt, or any foreign matter.

Activate the back of the plate with dry-cleaning solvent

Mount the plate and apply pressure to the plate surface.


Spray or brush plate with aliphatic Polyurethane coating (item 2, app D).

LOCATION	ITEM	ACTION
----------	------	--------

DISASSEMBLY

Protective Entrance Control Module Dome light

Remove screws (1), retainer (2), light lens (3), and dome light gasket (4).



Remove red lamp (5) by pressing in on the bulb and rotating it counterclockwise. Pull red lamp from socket (6).

Remove clear lamp (7) by pressing in on the bulb and rotating it counterclockwise. Pull clear lamp from socket (8).

REPAIR

Lamps, screws, lens, and dome light gasket

Replace if unserviceable.

REASSEMBLY

Protective Entrance Control Module Dome light

Insert red lamp (5) in socket(6). Aline studs in lamp base with slot in socket. Press in and turn red lamp clockwise until it locks in place.

Insert clear lamp (7) in socket (8). Aline studs in lamp base with slot in Socket. Press in and turn clear lamp clockwise until it locks in place.

Place gasket (4) on dome light lens (3).

Place retainer (2) on gasket and aline screw haies.

Position assembly in place and install screws (1). Tighten securely.

Section VII. MAINTENANCE PROCEDURES FOR M56 GAS-PARTICULATE FILTER UNIT

2-13. GENERAL. These instructions are for use by organizational maintenance personnel. They apply to:

- M56 Gas-particulate filter unit
- Main fan
- Airflow valve
- Power distribution unit
- Compartment control module

2-14. M56 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS.

This task covers:

- | | |
|-----------------|---------------|
| a. Replacement | e. Reassembly |
| b. Removal | f. Repair |
| c. Installation | g. Painting |
| d. Disassembly | |

INITIAL SETUP

Tools

- General Mechanics Tool Kit
- SC 5180-90-CL-N26
- Torque wrench 0-500 inch-pounds

References

TM 11-7440-294-14 (to be published)

General Safety Instructions

The unit commander or senior officer in charge of maintenance personnel assigned to remove and dispose of the contaminated gas and particulate filters must prescribe the necessary protective clothing (TM 10-277) to be worn during this operation. He must also prescribe the necessary safety measures to be followed including the decontamination operation (TM 3-220) that must be performed before the new filters are installed.

LOCATION

ITEM

ACTION

REPLACEMENT

TACFIRE

M56 Gas-particulate filter unit

Refer to TM 11-7440-294-14 for M58 gas-particulate filter unit removal and installation instructions.

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

NOTE

The unit commander or senior officer in charge of maintenance personnel assigned to remove and dispose of the contaminated gas and particulate filters must prescribe the necessary protective clothing (TM 10-277) to be worn during this operation. He must also prescribe the necessary safety measures to be followed including the decontamination operation (TM 3-220) that must be performed before the new filters are installed.

M56 Gas-Particulate Filter Unit Particulate filter




Set POWER switch (1) on the compartment control module to OFF.

Loosen screw (2).


Pull catch (3) outward and swing retaining bar (4) away from inner cover (5).

Using handles, pull inner cover (5) from access cover (6).

Pull particulate filter (7) from filter housing (8).



INSTALLATION



Place particulate filter (7) in filter housing (8), either end first.

Grasp inner cover by the handle and place it in the access cover (6).

Swing retaining bar (4) up across inner cover and engage end of bar with catch (3).

WARNING

Filter seals must be properly seated to prevent bypass of contaminated air.

Tighten screw (2) until sleeve (9) is flush with top surface (A) of retaining bar (4).

2-14. M56 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL



NOTE

The unit commander or senior officer in charge of maintenance personnel assigned to remove and dispose of the contaminated gas and particulate filters must prescribe the necessary protective clothing (TM 10-277) to be worn during this operation. He must also prescribe the necessary safety measures to be followed including the decontamination operation (TM 3-220) that must be performed before the new filters are installed.

M56 Gas-Particulate Filter Unit

Particulate and gas filters

Set POWER switch (1) on the compartment control module to OFF.



Loosen screw (2).

Pull catch (3) outward and swing retaining bar (4) away from inner cover (5).

Using handles, pull inner cover (5) from access cover (6).

Pull particulate filter (7) from filter housing (8).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL (CONT)


M56 Gas-Particulate Filter Unit

Particulate and gas filters

Remove screws (9), aluminum washer (10), and washer (11).

Pull access cover (6) from filter housing (8).

Pull gas filter (12) from filter housing (8).




Filter Housing/
Inner Cover

Seal or
Gasket

Replace access cover seal(13)on filter housing, or gasket (14) on inner cover (5) if unserviceable.

- a. Remove seal or gasket from groove.
- b. Clean groove using solvent (item 4, app D).
- c. Apply adhesive (item 1 appd D)in groove
- d. Install seal or gasket.



2-14. M56 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION

M56 Gas-Particulate Filter Unit Gas filter

Place gas filter (12) in filter housing (8), either end first.

Position access cover (6) on filter housing, align guide pin with guide hole (15). Push access cover (6) into place.

NOTE

To prevent binding of outer access cover against filter housing rim, screws must be tightened alternately, in a criss-cross pattern.


Install washers (11), aluminum washers (10), and screws (9) finger tight.

WARNING

Filter seals must be properly seated to prevent bypass of contaminated air.

CAUTION

Be sure to observe torque values for the torque wrench being used.



Preliminary torque. In a crisscross pattern, torque screws to 8-10 foot-pounds (100-125 inch-pounds).

Final torque. In a crisscross pattern, torque screws to 15-16 foot-pounds (180-200 inch-pounds).

Particulate filter

Place particulate filter (7) in gas filter (16), either end first.


Grasp inner cover by the handles and place it in the access cover (6).

Swing retaining bar (4) up across inner cover and engage end of bar with catch (3).

WARNING

Filter seals must be properly seated to prevent bypass of contaminated air.

Tighten screw (2) until sleeve (17) is flush with top surface (A) of retaining bar (4).



LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M56 Gas-Particulate Filter Unit


Dust and moisture seal protective cap

Unscrew hose clamp adjusting screw (1) and remove airduct hose (2) from inlet tee (3).


Unscrew hose clamp adjusting screw (4) and remove shelter airduct hose (5).

Remove nut (6) and washer (7) from screw (8).

Remove screw (8) from inlet tee (3), loop of support cable (9) with dust and moisture seal protective cap (10), and washer (11).



DISASSEMBLY



Remove nut (12) and washer (13) from screw (14).

Remove screw (14) from rubber cap (10), loop of support cable (9), and washer (15).

Remove hose clamp (16) from rubber cap (10).

REPAIR


Support cable

Fabricate support cable (fig E-1, app E).

2-14. M56 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REASSEMBLY



Insert screw (14) in washer (15), loop of support cable (9) and hole in rubber cap (10).

Install washer (13) and nut (12). Tighten securely.

Install hose clamp (16) in groove in rubber cap (10).

INSTALLATION


M56 Gas-Particulate Filter Unit Dust and moisture seal protective cap

Insert screw (8) in washer (11), loop of support cable (9), and hole in inlet tee (3).

Install washer (7) and nut (6). Tighten securely.

Place airduct hose (2) on inlet tee. Tighten hose clamp adjusting screw (1).

Install airduct hose (5) on airflow valve (17). Tighten hose clamp adjusting screw (4).



LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M56 Gas-Particulate Filter
Unit/power Distribution
unit

Unscrew tube (green) coupling nut (1) from connector (2).



Unscrew tube (green) coupling nut (3) from connector (4).

Pull tube coupling nuts with sleeves (1 and 3) off tube (5). See detail A.

Unscrew tube (red) coupling nut (6) from connector (7).

Unscrew tube (red) coupling nut (8) from connector (9).

Pull tube coupling nuts with sleeves (6 and 8) off tube (10).



REPAIR

Tubing (nonmetallic)

Fabricate tubing (fig E-2, app E).

2-14. M56 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION


M56 Gas-Particulate Filter Unit/Power Distribution Unit

Red tubing (nonmetallic)

Push tube coupling nuts (6 and 8) with sleeves on red tube (10). See detail A.

TUBE COUPLING NUT

Push one end of tube (10) into connector (7) and one end into connector (9). RED dot on power distribution unit indicates connector (9).




DETAIL A

Push tube coupling nut (6) with sleeve onto connector (7) and handtighten.

Push tube coupling nut (8) with sleeve onto connector (9) and handtighten.

Green tubing (nonmetallic)

Push tube coupling nuts (1 and 3) with sleeves on green tube (5). See detail A.



Push one end of tube (5) into connector (2) and one end into connector (4). GREEN dot on power distribution unit indicates connector (4).

Push tube coupling nut (1) with sleeve onto connector (2) and handtighten,

Push tube coupling nut (3) with sleeve onto connector (4) and handtighten.

LOCATION	ITEM	ACTION
----------	------	--------


REMOVAL

Access Cover

Instruction plates

Lift edge of plate (1,2,or 3) with a sharp tool.

Pull plate completely off the mounting surface.



INSTALLATION

Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter.

Activate the back of the mounting plate with dry-cleaning solvent (Item 4, app D).

Mount the plate (1, 2, or 3) and pressure to the plate surface.

Sprayer brush plate with aliphatic polyurethane coating (item 2, app D).


2-14. M56 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M56 Gas-Particulate Filter Unit	Identification plate	Lift edge of plate with a sharp tool. Pull plate completely off the mounting surface.
---------------------------------	----------------------	--

INSTALLATION



Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter.

Activate the back of the mounting plate with dry-cleaning solvent (item 4, app D).

Mount the plate (1) and apply pressure to the plate surface.

Spray or brush plate with aliphatic polyurethane coating (item 2, app D).

PAINTING

Filter housing, compartment control module, and power distribution unit

Touch-up painting is authorized.

Thoroughly clean the surfaces to be repainted. Use rags (item 6, app D) and dry-cleaning solvent (item 4, app D).

NOTE

Refer to TM 43-0139 for painting instructions for field use.

Paint surfaces with one coat of primer (item 5, app D).

Paint primed surfaces with aliphatic polyurethane coating (item 2, app D).

2-15. MAIN FAN - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Installation

INITIAL SETUP

Tools

- General Mechanics Tool Kit
- SC 5160-90-CL-N26

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M56 Gas-Particulate Filter Unit


Main fan/inlet tee

Set POWER switch (1) on compartment control module to OFF.

Loosen hose damp adjusting screws (2) and remove inlet tee airduct hose (3) and airflow valve airduct hoses (4).

Disconnect electrical cable plug P15 (5) from airflow valve.

Disconnect electrical cable P4 (6) from power distribution panel connector J4 (7).



2-15. MAIN FAN - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL (CONT)


M56 Gas-Particulate Filter Unit

Main fan/inlet tee

Remove screws (8) and washers (9).

Pull inlet tee (10) with main fan attached from filter housing (11). Remove cable from bushing (12).

Remove main fan electrical cable bushing (12) from filter housing. Retain.




Inlet Tee

Main fan

Remove screws (13) and washers (14).

Separate main fan (15) from inlet tee (10).



INSTALLATION

Inlet Tee

Main fan


Position main fan (15) up to inlet tee (10). Aline guide pins (16) on inlet tee with guide pin holes in main fan. Push main fan against inlet tee.

Install washers (14) and screws (13). Tighten securely.

LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION (CONT)

M56 Gas-Particulate Filter unit Main fan/inlet tee unit



Install bushing (12) on cable (17) about 10 inches from motor.

Position inlet tee (10) up to filter housing (11).

Install bushing (12) in slot in face of filter housing (11) with slit away from housing.

Align guide pin hole (18) with guide pin (19). Push inlet tee against filter housing.


Install washers (9) and screws (8). Tighten securely.

Connect electrical cable plug P4 (6) to power distribution panel connector J4 (7).

Connect electrical cable plug P15 (5) to airflow valve.

Install airduct hoses (3 and 4).

Tighten hose damp adjusting screws (2).



2-16 AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS.

This task covers:
 a. Removal
 b. Disassembly
 c. Repair

d Reassembly
 e. Installation

INITIAL SETUP

Tools

General Mechanics Tool Kit
 SC 5180-90-CL-N26

References



TM 11-7440-294-14 (to be published)

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M56 Gas-Particulate Filter Unit Airflow valve

Set POWER switch (1) on compartment control module to OFF.



Gasket

Loosen hose damp adjusting screws (2) and remove airt duct hoses (3).

Disconnect electrical plug P15 (4) from airflow valve connector J15 (5).

Remove nuts (6), screws (7), and washers (8).

Separate airflow valve (9) from fitter unit (10).

Replace airflow valve gasket (11) if unserviceable. Remove gasket from flange on airflow valve. Clean flange using dry-cleaning solvent (item 4, app D). Apply adhesive (item 1, app D) to flange. Install gasket.

LOCATION	ITEM	ACTION
----------	------	--------

DISASSEMBLY

Airflow Valve


Dust and moisture seal protective cap

Remove nut (12) from screw (13). Remove screw (13) from airflow valve, supportable (14), washer (15), support cable (16), and washer (17).

Remove nut (18) and washer (19) from screw (20).

Remove screw (20) from rubber cap (21), support cable (22), and washer (23).

Remove hose damp (24) from rubber cap (21).



REPAIR

Support cable

Fabricate support cable (fig E-1, app E).

REASSEMBLY

Airflow Valve

Dust and moisture seal protective

Install screw (20) in washer (23), loop of support cable (22), hole in rubber cap (21), washer, and nut (18). Tighten nut securely.

Install hose damp (24) in groove in rubber cap (21). Do not tighten adjusting screw.

Install screw (13) in washer (17), loop of support cable (16), washer (15), supportable (14), hole in airflow valve, and nut (12). Tighten nut securely.

2-16. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION

M56 Gas-Particulate Filter Unit


Airflow valve

Place airflow valve (9) against filter housing (10). Align screw holes.

Install washers (8), screws (7), and nuts (6). Tighten securely.

Connect electrical plug PI 5 (4) to airflow valve connector J15 (5).

Install airduct hoses (3) on airflow valve. Tighten hose clamp adjusting screws (2).



REMOVAL


Airflow Valve

Identification plate and instruction plates

Lift edge of plate (1,2,or 3) with a sharp tool.

Pull plate completely off the mounting surface.

INSTALLATION



Thoroughly dean mounting surface with dry-cleaning solvent (Item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter.

Activate the back of the plate (1, 2, or 3) with dry-cleaning solvent (Item 4, app D),

Mount the plate and apply pressure to the phlate surface.

Spray of brush plate with allphetic polyurethane coating (Item 2, app D).

2-17. POWER DISTRIBUTION UNIT - MAINTENANCE INSTRUCTIONS.

This task covers:

a. Replacement

b. Removal

c. Installation

INITIAL SETUP

Tools

General Mechanics Tool Kit
SC 5160-90-CL-N26

General Safety Instructions

If filter is operating, 208 V is present at the indicator lamp socket.

References

TM 11-7440-294-14 (to be published)


LOCATION	ITEM	ACTION
----------	------	--------

REPLACEMENT

TACFIRE	Power distribution unit	Refer to TM 11-7440-294-14 for power distribution unit removal and installation instructions.
---------	-------------------------	---

REMOVAL

Power Distribution Panel 206 V lamp



Loosen screws (1).

Open access cover (2) on power distribution panel (3).

Unscrew lens (4).

WARNING

If filter unit is operating, high voltage is present at the indicator lamp socket. Personal injury or loss of life may result if socket is contacted.

Remove 206 V lamp (5) from indicator lamp socket (6).

INSTALLATION

Insert 206 V lamp (5) in lens (4).

Screw lens (4) into indicator lamp socket (6).


Close access cover (2) against panel (3) and secure with screws (1).

2-17. POWER DISTRIBUTION UNIT - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Power Distribution Unit Identificatio plate



Lift edge of plate (1) with a sharp tool.

Pull plate completely off the mounting surface.

INSTALLATION

Thoroughly dean mounting surface with dry-cleaning solvent (item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter.

Activate the back of the plate with dry-cleaning solvent (item 4, app D).

Mount plate (1) and apply pressure to the plate surface.

Spray or brush plate with aliphatic polyurethane coating (item 2, app D).

2-18. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Replacement
- b. Repair
- c. Removal
- d. Installation

INITIAL SETUP

Tools

General Mechanics Tool Kit
SC 5180-90-CL-N26

References

TM 11-7440-294-14 (to be published)

LOCATION	ITEM	ACTION
REPLACEMENT		
TACFIRE	Compartment control module	Refer to TM 11-7440-294-14 for compartment control module removal and installation instructions.

REPAIR


Compartment Control Module and Feed-Thru* Connector

Hose

Pull off hose (1).

Fabricate replacement hose (fig E-4B, app E).

Install new hose.



INTERIOR VIEW OF FEED-THRU*

I ELEC/PNEU FEED THRU

2-18. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (CONT).


LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Compartment Control Module

MASK lamp

Using two screwdrivers, gently pry lens (1) module from control panel (2).



NOTE

Observe the location of the lamps in the lens module. Lamps must be reinstalled in the same sockets.

Pull lamps (3) from lens (1).

LOW PRESSURE lamp

Same as MASK lamp.


OCCUPIED lamp

Same as MASK lamp.

CHANGE FILTER lamp

Unscrew lens (4). Remove lamp (5).

INSTALLATION



DETAIL A

MASK lamp

Insert lamps (3) into lens (1). Use the same lamp sockets that lamps were removed from.

Insert lens (1) into control panel (2), as shown in detail A. Press lens into panel until it snaps into place.

LOW PRESSURE lamp

Same as MASK lamp.

OCCUPIED lamp

Same as MASK lamp.

CHANGE FILTER lamp

Insert lamp (5) into lens (4).

Screw lens (4) into control panel (2).

**Section VIII. MAINTENANCE PROCEDURES
FOR M262 INSTALLATION KIT**

2-19. GENERAL. These instructions are for use by organizational maintenance personnel. They apply to:
Airflow valve and silencer
Cables
Air duct hoses

2-20. AIRFLOW VALVE AND SILENCER - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Installation
- b. Removal
- c. Repair
- d. Installation

INITIAL SETUP

Tools

General Mechanics Tool Kit
SC 5180-90-CL-N26

References

TM 11-7440-294-14 (to be published)

LOCATION	ITEM	ACTION
----------	------	--------


INSTALLATION

TACFIRE	Airflow Valve and Silencer	Refer to TM 11-7440-294-14 for airflow valve and silencer installation instructions.
---------	----------------------------	--

REMOVAL

Airflow Valve and Silencer Silencer

Loosen hose clamp adjusting screw (1) and remove air duct hose (2) from silencer (3).



Remove nuts (4) and screws (5).

Remove retaining strap (6).

Loosen adjusting screws on hose clamps (7).

Remove silencer (3), nonmetallic hose (8), and hose clamps (7).


2-20. AIRFLOW VALVE AND SILENCER - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL (CONT)

Airflow Valve and Silencer Airflow valve

Disconnect electrical cable plug P15 (9) from airflow valve connector J15 (10).



Remove nuts (11) and screw (12).

Remove airflow valve (13) from mounting bracket (14).

REPAIR

Nonmetallic hose

Fabricate replacement nonmetallic hose (fig E-3, app E).

Gasket

Replace airflow valve gasket (15) if unserviceable. Remove gasket from flange. Clean flange using dry-cleaning solvent (item 4, app D). Apply adhesive (item 1, app D) to flange. Install gasket.

INSTALLATION

Airflow Valve and Silencer Airflow valve

Position airflow valve (13) against bracket (14) and aline screw holes.

Install screws (12) and nuts (11). Ttghten securely.


Connect electrical cable plug P15 (9) to airflow valve connector J15 (10).

LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION (CONT)

Airflow Valve and Silencer Silencer

Place hose dampers (7) on nonmetallic hose (8) and install on airflow valve (13).



Install silencer (3) in nonmetallic hose (8) and tighten adjusting screw on hose dampers (7)

Place retaining strap (6) over silencer (3), and align screw holes in strap and mounting bracket (14).

Install screws (5) and nuts (4). Tighten securely.

Install airduct hose (2) on silencer (3) and tighten hose clamp adjusting screw (1).


REMOVAL

Airflow Valve and Silencer Instruction plate

Lift edge of plate (16) with a sharp tool.

Pull plate completely off the mounting surface.

INSTALLATION



Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter.

Activate the back of the plate with dry-cleaning solvent (item 4, app D).

Mount the plate and apply pressure to the plate surface.

Spray or brush plate with aliphatic polyurethane coating (item 2, app D).

2-21. CABLE C5-19-6170-40 - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Test
- c. Replace
- d. Installation


INITIAL SETUP

Test Equipment
Multimeter AN/USM223

LOCATION	ITEM	ACTION
----------	------	--------

NOTE

Use the cable routing diagram below to locate each of the six cables.



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM

*ELEC/PNEU FEED THRU

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M10 Protective Entrance and Airflow Valve and Silencer


Cable C5-19-6170-40

Set compartment control module POWER switch (1) to OFF.

Shut down collective protection equipment power source.

Disconnect cable plug P21 (2) from protective enclosure connector J21 (3).

Disconnect cable plug P15 (4) from airflow valve and silencer connector J15 (5).




2-21. CABLE C5-19-6170-40 - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

TEST

Cable C5-19-6170-40

Check continuity of each wire between P21 and p15



**C5-19-6170-40
CABLE ASSEMBLY WIRING DIAGRAM**


NOTE

Use multimeter and cable C5-19-6170-40 wiring diagram.

REPLACE

Cable C5-19-6170-40

Replace cable if it fails continuity check.



LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION


M10 Protective Entrance and Airflow Valve and Silencer

Cable C5-19-6170-40

Set POWER switch (1) on compartment control module to OFF.

Connect cable plug PI 5 (4) to airflow valve connector J15 (5).

Connect cable plug P21 (2) to protective entrance connector J21 (3).



2-22. CABLE CS-19-6162-10 - MAINTENANCE INSTRUCTIONS.

This task covers:

a. Removal

b. Test

c. Installation

INITIAL SETUP

Test Equipment
Multimeter AN/USM223

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

M10 Protective Entrance
and Power Distribution Unit


Cable C5-19-6162-10

Set compartment control module POWER switch (1)
to OFF.

Shut down collective protection equipment
power source.

Disconnect electrical cable plug P20 (2) from protective
entrance enclosure connector J20 (3).

Disconnect electrical cable plug P5 (4) from power
distribution unit connector J5 (5).




LOCATION	ITEM	ACTION
----------	------	--------

TEST


Cable C5-19-6162-10 Check continuity of each wire between P5 and P20.

NOTE

Use multimeter and cable C5-19-6162-10 wiring diagram.



Cable C5-19-6162-10 Replace cable if it fails continuity check.



2-22. CABLE CS-16-6162-10 - MAINTENANCE INSTRUCTIONS (CONT)

LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION


M10 Protective Entrance
and Power Distribution Unit

Cable C5-19-6162-10

Set POWER switch (1) on compartment control module to OFF.

Connect electrical cable plug P5 (4) to power distribution unit connector J5 (5).

Connect electrical cable plug P20 (2) to protective entrance enclosure connector J20 (3).



2-23. CABLE C5-19-6170-10 - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Test
- c. Replace
- d. Installation

INITIAL SETUP

Test Equipment
Multimeter AN/USM223

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Power Distribution Unit and Airflow Valve on Fitter Unit


Cable C5-19-6170-10

Set compartment control module POWER switch (1) to OFF.

Shut down collective protection equipment power source.

Disconnect cable assembly plug P2 (2) from PDU connector J2 (3).

Disconnect cable assembly plug PI 5 (4) from airflow valve connector J15 (5).



2-23. CABLE C5-19-6170-10 - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION	ITEM	ACTION
----------	------	--------

TEST


Power Distribution unit
and Airflow Valve on
Filter unit

Cable C5-19-6170-10

Check continuity of each wire between P2 and P15.

NOTE

use multimeter and cable C5-19-6170-10
wiring diagram.




C5-19-6170-10
CABLE WIRING DIAGRAM

REPLACE

Power Distribution Unit
and Airflow Valve on
Filter Unit

cabl e C5-19-6170-10

Replace cable if it fails continuity check



LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION


Power Distribution Unit
and Airflow Valve on
Filter Unit

Cable C5-19-6170-10

Set POWER switch (1) on compartment control module to OFF.

Connect cable assembly plug P15 (4) to airflow valve connector J15 (5).

Connect cable assembly plug P2 (2) to power distribution unit connector J2 (3).



2-24. CABLE C5-19-6693 - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Test
- c. Replace
- d. Installation

INITIAL SETUP

Test Equipment
Multimeter AN/USM223

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Compartment Control
Module and Feed-Thru*
Connector


Cable C5-19-6693

Set compartment control module POWER switch (1) to OFF.

Shut down collective protection equipment power source.

Disconnect cable assembly plug P1 (2) from compartment control module connector J1 (3).

Disconnect cable assembly plug P3 (4) from feed-thru* connector J3 (5).




INTERIOR VIEW OF FEED-THRU*

TEST

Cable C5-19-6693

Check continuity of each wire between P1 and P3.



NOTE

Use multimeter and cable C519-6693 wiring diagram.

***ELEC/PNEU FEED THRU**


LOCATION	ITEM	ACTION
----------	------	--------

REPLACE

Compartment Control
Module and Feed-Thru*
Connector

Cable C5-19-6693

Replace cable if it fails continuity check.



INSTALLATION


Compartment Control
Module and Feed-Thru*
Connector

cablc C5-19-6693

Set compartment control module POWER switch (1)
to OFF.

Connect cable assembly plug P3 (4) to feed-thru"
connector J3 (5).

Connect cable assembly plug P1 (2) to compartment
control module connector J1 (3).



ELEQPNEU FEED THRU

2-25. CABLE C5-19-6693 - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Test
- c. Replace
- d. Installation

INITIAL SETUP

Test Equipment
Multimeter AN/USM223

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Power Distribution Unit and Feed-Thru" Connector



cable C5-19-6693

Set compartment control module POWER switch (1) to OFF.

Shut down collective protection equipment power source.

Disconnect cable assembly plug P1 (2) from feed-thru* connector J1 (3).

Disconnect cable assembly plug P3 (4) from power distribution unit connector J3 (5).



EXTERIOR VIEW OF FEED-THRU*


***ELEC/PNEU FEED THRU**

LOCATION	ITEM	ACTION
----------	------	--------

TEST

Cable C5-19-6693

Check continuity of each wire between P1 and P3.




**C5-19-6693
CABLE ASSEMBLY WIRING DIAGRAM**

R E P A I R

Power Distribution Unit and Feed-Thru* Connector

 cable c5-19-6693

 Replace cable if it fails continuity check.



INSTALLATION

Power Distribution Unit and Feed-Thru* Connector

 cable C5-19-6693

 Set compartment control module POWER switch (1) to OFF.

 Connect cable assembly plug P3 (4) to power distribution unit connector J3 (5).

 Connect cable assembly plug P1 (2) to feed-thru* connector J1 (3).

ELEC/PNEU FEED THRU

2-26. CABLE C5-19-6691 - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Test
- c. Replace
- d. Installation

INITIAL SETUP

Test Equipment
Multimeter AN/USM223

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

WARNING

High voltage is used to power this equipment. Before removing power cable, be sure that POWER switch on compartment control module is in the OFF position and that the collective protection equipment power source is shut down to avoid personal injury or loss of life.

Power Distribution Unit and Power Source Connector



Cable C5-19-6691

Set compartment control module POWER switch (1) to OFF.

Shut down collective protection equipment power source.

Disconnect cable assembly plug P7 (2) from power distribution unit connector J7 (3).

Disconnect cable assembly plug PI 2 (4) from power source connector (5).



*ELEC/PNEU FEED THRU

LOCATION	ITEM	ACTION
----------	------	--------

T E S T


Power Distribution Unit
and Power Source
Connector

able C5-19-6691

Check continuity of each wire between P7 and P12.

NOTE

Use multimeter and cable
C5-19-6691 wiring diagram.




**C5-19-6691
CABLE WIRING DIAGRAM**

R E P L A C E

Power Distribution Unit
and Power Source
Connector

able C5-19-6691

Replace cable if it fails continuity check.



I N S T A L L A T I O N

WARNING

High voltage is used to power this equipment. Before installing power cable, be sure that POWER switch on compartment control module is in the OFF position and that the collective protection equipment power source is shut down to avoid personal injury or loss of life.

Power Distribution unit and cable C5-19-6691
Power source connector

Set compartment control module POWER switch (1) to OFF.

Connect cable assembly plug P9 (4) to power source connect J9 (5) at feed thru.

connect cable assembly plug P7 (2) to power distribution unit connector J7 (3).

2-27. AIRDUCT HOSES - MAINTENANCE INSTRUCTIONS.

This task covers:

a. Removal

b. Replace/Repair

c. Installation

INITIAL SETUP

Tools

SC5180-90-CL-N26

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

TACFIRE


Airduct hoses

NOTE

Airduct hoses **(A)** are 6 ft long. Airduct hose **(B)** is 3 ft long. Each airduct hose section can be removed or installed as explained below.

Loosen hose clamp adjusting screws (1).

Pull airduct hose (2) from adapters (3 and 4).



LOCATION	ITEM	ACTION
----------	------	--------

REPLACE/REPAIR

TACPIRE

Airduet hoses

Replace if not repairable.


Repair:

Clean damaged areas using rags (item 6, app D) and dry-cleaning solvent (item 4, app D).

Cut a piece of tape (item 7, app D) 4 inches longer than the slit or tear.

Apply the tape over the damaged area leaving 2 inches of tape beyond the tear or slit at each end.

Press tape firmly in place.



INSTALLATION


TACFIRE

Airduet hoses

Push each end of airduet hose (2) over adapters (3 and 4).

Check that edge of hose is pushed against the bead on the adapter.

Tighten hose damp adjusting screws (1) securely.



APPENDIX A REFERENCES

The following publications are related to information contained in this manual.

A-1. TECHNICAL MANUALS.

TM 3-220	Chemical, Biological and Radiological (CBR) Decontamination
TM 10-277	Protective Clothing Chemical Operations
*TM 11-7440-294-14	Installation and Operation Instructions for Installation of Modular Collective Protection Equipment (MCPE) in Tacfire Display and Computer Shelters (S-280)
TM 38-750	The Army Maintenance Management System (TAMMS)
TM 43-0002-31	Destruction of Chemical Weapons and Defense Equipment to Prevent Enemy Use
TM 43-0139	Painting Instructions for Field Use
TM 740-90-1	Administrative Storage of Equipment

A-2. COMMON TABLE OF ALLOWANCES.

CTA 50-970	Expendable Items (Except: Medical ,Class V, Repair Parts and Heraldic Items)
----------------------	--

A-3. SUPPLY BULLETIN.

SB 708-41/42	Federal Supply Code for Manufacturers; United States and Canada- Name to Code and Code to Name
------------------------	--

A-4. SUPPLY CATALOG.

SC 5180-90-CL-N26	Tool Kit, General Mechanic's; Automotive
-----------------------------	--

*To be published

APPENDIX B MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

B-1. GENERAL.

- a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance categories.
- b. The Maintenance Allocation Chart (MAC) in section II designates overall responsibility for the performance of maintenance functions on the identified end item or Component. The implementation of the maintenance functions upon the end item or component will be consistent with the assigned maintenance functions.
- c. Section III lists the special tools and test equipment required for each maintenance function as referenced from section II.
- d. Section IV contains supplemental instructions and explanatory notes for a particular maintenance function.

B-2. MAINTENANCE FUNCTIONS. Maintenance functions will be limited to and defined as follows:

- a. *Inspect.* To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination.
- b. *Test.* To verify serviceability by measuring the mechanical or electrical characteristics of an item and comparing those characteristics with prescribed standards.
- c. *Service.* Operations required periodically to keep an item in proper operating condition, i.e., to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases.

- d. *Adjust.* To maintain, within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.
- e. *Aline.* To adjust specified variable elements of an item to bring about optimum or desired performance.
- f. *Calibrate.* To determine and cause corrections to be made or to be adjusted on instruments or test, measuring, and diagnostic equipments used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.
- g. *Install* The act of emplacing, seating, or fixing into position an item, part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.
- h. *Replace.* The act of substituting a serviceable like type part, subassembly, or module (component or assembly) for an unserviceable counterpart.
- i. *Repair.* The application of maintenance services¹ or other maintenance actions² to restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.
- j. *Overhaul.* That maintenance effort (service/action) necessary to restore an item to a completely serviceable/operational condition as prescribed by maintenance standards in appropriate technical publications (i.e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

¹Services - inspect, test, service, adjust, aline, calibrate, or replace.

²Actions - welding, grinding, riveting, straightening, facing, remachining, or resurfacing.

- k. *Rebuild.* Consists of those serviced actions necessary for the restoration of un-serviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of materiel maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc) considered in classifying Army equipment components.

B-3. EXPLANATION OF COLUMNS IN THE MAC, SECTION II.

- a. *Column 1, Group Number.* Column 1 lists fictional group code numbers, the purpose of which is to identify components, assemblies, subassemblies, and modules with the next higher assembly.
- b. *Column 2, Component/Assembly.* Column 2 contains the names of components, assemblies, subassemblies, and modules for which maintenance is authorized.
- c. *Column 3, Maintenance Function.* Column 3 lists the functions to be performed on the item listed in Column 2. (For detailed explanation of these functions, see paragraph B-2.)
- d. *Column 4, Maintenance Category.* Column 4 specifies, by the listing of a work time figure in the appropriate subcolumn(s), the category of maintenance authorized to perform the function listed in Column 3. *This figure* represents the active time required to perform that maintenance function at the indicated category of maintenance. If the number or complexity of the tasks within the listed maintenance function vary at different maintenance categories, appropriate work time figures will be shown for each category. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time, troubleshooting time, and quality assurance/quality control time in addition to the time required to perform the specific

tasks identified for the maintenance functions authorized in the maintenance allocation chart. The symbol designations for the various maintenance categories are as follows

- C Operator or crew.
- O Organizational maintenance.
- F Direct support maintenance.
- H General support maintenance.
- D Depot maintenance.
- e. *Column 5, Tools and Equipment.* Column 5 specifies, by code, those common tool sets (not individual tools) and special tools, TMDE, and support equipment required to perform the designated function.
- f. *Column 6, Remarks.* This column shall, when applicable, contain a letter code, in alphabetic order, which shall be keyed to the remarks contained in Section IV.

B-4. EXPLANATION OF COLUMNS IN TOOL AND TEST EQUIPMENT REQUIREMENTS, SECTION III.

- a. *Column 1, Reference Code.* The tool and test equipment reference code correlates with a code used in the MAC, Section II, Column 5.
- b. *Column 2, Maintenance Category.* The lowest category of maintenance authorized to use the tool or test equipment.
- c. *Column 8, Nomenclature.* Name or identification of the tool or test equipment.
- d. *Column b, National Stock Number.* The National stock number of the tool or test equipment.
- e. *Column 5, Tool Number.* The manufacturer's part number.

B-5. EXPLANATION OF COLUMNS IN REMARKS, SECTION IV.

- a. *Column 1, Reference Code.* The code recorded in column 6, Section II.
- b. *Column 2, Remarks.* This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

Section II. MAINTENANCE ALLOCATION CHART

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) TOOLS AND EQPT.	(6) REMARKS
			C	O	F	H	D		
0100	M10 PROTECTIVE ENTRANCE	Inspect	0.2						
		Test		0.2				4	
		Install	0.3						
		Replace		0.5					
		Repair		0.3				1, 15, 16	
0110	PROTECTIVE ENTRANCE CONTROL MODULE	Test			0.5			4, 5, 6, 8, 9, 10, 11	
		Replace		0.4				1	
		Repair		0.1	4.0			2	
0200	M56 GAS- PARTICULATE FILTER UNIT	Inspect	0.2						
		Test		0.5				4	
		Replace		0.3				1	
		Repair		1.0				1, 3	
0210	MAIN FAN	Test			0.5			4	
		Replace		0.8				1	
		Repair			4.0			2, 12, 13, 14	
0220	AIRFLOW VALVE	Test			0.3			4	
		Replace		0.3				1	
		Repair		0.5	2.0			2	
0230	POWER DISTRIBUTION UNIT	Replace		0.2				1	
		Repair			0.1			2	
0231	POWER DISTRIBUTION PANEL	Test			0.5			4, 5, 6, 7, 9, 10, 11	
		Repair		0.1	2.0			2	
0240	COMPARTMENT CONTROL MODULE	Test			1.0			4, 5, 6, 8, 9, 10, 11	
		Replace		0.2				1	
		Repair		0.1	4.0			2	
0300	M262 INSTALLATION KIT	Test			0.3			4	
		Inspect	0.5						
		Install	0.7						
		Repair	0.1	0.7					
0310	AIRFLOW VALVE AND SILENCER	Test			0.2			4	
		Install	0.1						
		Repair		1.0				1	
0311	AIRFLOW VALVE	Test			0.3			4	
		Replace		0.3				1	
		Repair		0.5	2.0			2	

Section III. TOOL AND TEST EQUIPMENT REQUIREMENTS

TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
1	o	TOOL KIT, GENERAL MECHANICS	5180-00-177-7033	SC 5180-90-CL-N26
2	F	TOOL KIT, ELECTRONIC EQUIPMENT	5180-00-610-8177	SC 5180-91-CL-R07
3	o	WRENCH, TORQUE	5120-00-247-2536	AN/USM223
4	0	MULTIMETER	6625-00-999-7465	
5	F	POWER SUPPLY DIRECT CURRENT	6130-00-408-4962 (or equivalent)	
6	F	GAGE, DIFFERENTIAL, DIAL INDICATING, 06 inches (H ₂ O)	6685-00-087-6331	
7	F	RESISTOR, 680 OHM, ±50/o, 2 WATT	5905-00-256-0390	
8	F	RESISTOR, 100 OHM ± 10 ⁰ /o, 10 WATT	5905-00752-6460	
9	F	SYRINGE, HYPODERMIC	651\$00-754-0412	
10	F	TEE, HOSE	4730-00082-5402	
11	F	TUBING, NONMETALLIC	4720-00-059-5819	
12	F	PULLER KIT	5120-00289-9597	
13	F	GAGE, DEPTH, MICROMETER	5210-00-619-4045	
14	F	PRESS, ARBOR	344440-243-2655 (or equivalent)	
15	0	DRILL, ELECTRIC, PORTABLE	5130-00-889-8994	
16	0	DRILL, TWIST 1/8 INCH	5133-00-227-9650	

Section IV. REMARKS

REFERENCE CODE	REMARKS
	<i>None</i>

APPENDIX C

REPAIR PARTS AND SPECIAL TOOLS LIST

Section I. INTRODUCTION

C-1. SCOPE. This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the collective protection equipment. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

C-2. GENERAL. This Repair Parts and Special Tools List is divided into the following sections:

- a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence.
- b. *Section III. Special Tools List.* Not applicable.
- c. *Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list in alphameric sequence of all parts numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

C-3. EXPLANATION OF COLUMNS.

- a. *Illustration.* This column is divided as follows:
 - (1) *Figure Number.* Indicates the figure number of the illustration on which the item is shown.

- (2) *Item Number.* The number used to identify item called out in the illustration.

- b. *Source, Maintenance, and Recoverability (SMR) Codes.*

- (1) *Source Code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA	Item procured and stocked for anticipated or known usage.
MO	Item to be manufactured or fabricated at organizational level.
AO	Item to be assembled at organizational level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and aircraft support items as restricted by AR 700-42.

- (2) *Maintenance Code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

code	<i>Application/Explanation</i>
O	Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes.

<i>Code</i>	<i>Application/Explanation</i>
O	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
Z	Nonreparable. No repair is authorized.

(3) *Recoverability Code*. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows

<i>Recoverability Codes</i>	<i>Definition</i>
Z	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
O	Reparable item. When uneconomically repairable, condemn and dispose at organizational level.
F	Reparable item. When uneconomically repairable, condemn and dispose at the direct support level.

Recoverability Codes

Definition

- | | |
|----|--|
| A | Item requires special handling or condemnation procedures because of specific reasons (i. e., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions. |
| c. | <i>National Stock Number</i> . Indicates the National stock number assigned to the item and which will be used for requisitioning. |
| d. | <i>Federal Supply Code for Manufacturer (FSCM)</i> . The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc. |
| e. | <i>Part Number</i> . Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items. |

NOTE

When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.

- | | |
|----|--|
| f. | <i>Description</i> . Indicates the Federal item name and, if required, a minimum description to identify the item. |
| g. | <i>Unit of Measure (UIM)</i> . Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned. |

- h. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, (e. g., shims, spacers, etc).

C-4. SPECIAL INFORMATION.

- a. Detailed manufacturing instructions for items source coded to be manufactured or fabricated are found in appendix E of this manual. Bulk materials required to manufacture items are listed in the Bulk Material Group of this manual.
- b. Action change codes indicated in the lefthand margin of the listing page denote the following

- N Indicates an added item.
- C Indicates a change in data.
- R Indicates a change in NSN only.

C-5. HOW TO LOCATE REPAIR PARTS.


- a. When National Stock Number or Part Number is Unknown:
 - (1) *First.* Using the table of contents determine the functional group within which the item belongs. This is necessary since illustrations are prepared for fictional groups, and listings are divided into the same groups.
 - (2) *Second.* Find the illustration covering the fictional group to which the item belongs.
 - (3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.

- (4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.
- b. *When National Stock Number or Part Number is Known:*
 - (1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.
 - (2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

C-6. ABBREVIATIONS.

<i>Abbreviation</i>	<i>Explanation</i>
CFM	cubic feet per minute
dia	diameter
hd	head
hex	hexagon
in.	inch
id	inside diameter
lg	long
MFD	manufactured
mtg	mounting
NPS	National Pipe Standard
nom	nominal
no	number
oa	overall
od	outside diameter
porm	plus or minus
PSI	pounds per square inch
thk	thick
thd	thread
UNC	United National Course
UNF	United National Fine
W/	with


Section II. REPAIR PARTS LIST



AR 920794

Figure C-1. M10 Protective Entrance


(1)	(2)	(3)	(4)	(5)	TM3-4240-284-20&P (6) DESCRIPTION	(7)	(8)
ILLUSTRATION (a) FIG NO	(b) ITEM NO	SMR CODE	NATIONAL STOCK NUMBER	PSCM	PART NUMBER	USABLE ON CODE	QTY INC IN UNIT
					GROUP 0100 PROTECTIVE ENTRANCE		
					E5-19-6201-40		
C-1	1	PAOFF	4240-00-229-2610	81361	E5-19-6201-40	ENTRANCE, PROTECTIVE, PRESSURIZED: M10	EA 1
C-1	2	PAOZZ	5305-00-179-8946	96906	MS51849-66	SCREW,MACHINE HEX HD, NO. 10-32UNF-2A, 3/4 IN LG	EA 3
C-1	3	PAOZZ	5310-00-045-3296	96906	MS35338-43	WASHER,LOCK SPRING, NO. 10 NOM SIZE	EA 3
C-1	4	PAOFF	4240-01-048-2803	81361	E5-19-6357	CONTROL MODULE, PROTECTIVE ENTRANCE	EA 1
C-1	5	PAOZZ	4730-01-050-7540	30327	KF03-04RV	ADAPTER,STRAIGHT	EA 1
C-1	6	MOOZZ		81361	E5-19-6357-111	HOME,NONMETALLIC LOW PRESSURE: MFD FROM 4720-00-065-5682,	EA 1
C-1	7	PAOZZ	4730-01-017-5119	30327	KF03-02PS	ADAPTER,STRAIGHT	EA 1
C-1	8	PAOZZ	5330-00-250-0236	96906	MS29513-24	PACKING,PREFORMED	EA 1
C-1	9	PAOZZ	5330-00-248-3849	96906	MS29513-019	PACKING,PREFORMED	EA 1
C-1	10	PAOOO	5340-01-048-6327	81361	C5-19-6145	CAP,PROTECTIVE,DUST DUST AND MOISTURE SEAL	EA 2
C-1	11	PAOZZ	5305-00-115-9934	96906	MS51849-55	SCREW,MACHINE HEX HD, NO. 8-32UNC-2A, 5/8 IN LG	EA 3
C-1	12	PAOZZ	5310-00-765-3197	96906	MS27183-41	WASHER,FLAT .186 IN ID, .438 IN OD. .049 IN THK	EA 5
C-1	13	A0000		99862	CL-2-FANDCL-2-C 8.0	CABLE	EA 2
C-1	14	PAOZZ	4030-00-878-8693	99862	CL2F	FERRULE,WIRE ROPE	EA 4
C-1	15	MOOZZ		99862	CL-2-C-8.0	CABLE, NYLON: 8IN. LG MFD FROM 4010-00-069-5180	EA 2
C-1	16	XAOZZ		81361	C5-19-6309	CAP, RUBBER	EA 2
C-1	17	PAOZZ	4730-00-908-6294	96906	MS35842-16	CLAMP, HOSE 4-1/8 TO 7 IN DIA RANGE	EA 2
C-1	18	PAOZZ	5310-00-811-3494	96906	MS21044N08	NUT,SELF-LOCKING, HEXAGON: 9-32 UNJC-38	EA 3
C-1	19	PAOZZ	9905-01-068-2368	81361	5-19-6657	PLATE, INSTRUCTION NO STEP	EA 1
C-1	20	PAOZZ	9905-01-049-1385	81361	C5-19-6175	PLATE, INSTRUCTION	EA 1
C-1	21	PAOZZ	5305-00-211-8193	96906	MS51849-54	SCREW,MACHINE HEX HD, NO. 8-32UNC-2A, 1/2 IN LG	EA 1
C-1	22	PAOZZ	5305-00-157-5621	96906	MS51849-56	SCREW,MACHINE HEX. HD, NO. 8-32UNC-2A, 3/4 IN LG	EA 1
C-1	23	PAOZZ	5310-00-928-9821	96906	MS24679-2	NUT,PLAIN,CAP NO. 8-32UNC-28	EA 2
C-1	24	PAOZZ	5310-00-045-3299	96906	MS35338-42	WASHER,LOCK SPRING, NO. 8 NOM SIZE	EA 2
C-1	25	PAOZZ	9905-01-062-0672	81361	C5-19-6316-12	PLATE, IDENTIFICATION: ENTRANCE, PROTECTIVE, PRESSURIZED, M10	EA 1
C-1	26	PAOZZ	9905-01-048-2790	81361	B5-19-6238	PLATE,INSTRUCTION CAUTION, DO NOT ENTER WHEN PROTECTIVE ENTRANCE IS OCCUPIED	EA 1
C-1	27	PAOZZ	5410-00-981-8701	01943	8173	CAP,FILLER OPENING W/CHAIN	EA 1
C-1	28	PAOZZ	5310-01-054-4643	96906	MS3186-34	NUT,PLAIN,HEXAGON 11/16-24UNEF-2B	EA 1
C-1	29	PAOZZ	5935-00-912-9599	96906	MS3181-10N	COVER,ELECTRICAL CONNECTOR	EA 1
C-1	30	PAOZZ	5935-00-990-5580	96906	MS3181-14N	COVER,ELECTRICAL CONNECTOR	EA 1
C-1	31	PAOZZ	5310-00-435-8983	96906	MS3186-43	NUT,PLAIN,HEXAGON 1-20UNEF-2B	EA 1
C-1	32	PAOZZ	5305-00-115-9406	96906	MS51849-53	SCREW,MACHINE HEX HD, NO. 6-32UNC-2A, .38 IN LG	EA 3
C-1	33	PAOZZ	5310-00-045-3299	96906	MS35338-42	WASHER,LOCK SPRING NO. 9 NOM SIZE	EA 3
C-1	34	PAOZZ	4240-01-049-0804	81361	C5-19-6236	COVER,PROTECTIVE	EA 1
C-1	35	PAOZZ	5310-00-897-6081	96906	MS35691-32	NUT,PLAIN,HEXAGON JAM. 7/16-20 UNF-2B	EA 1
C-1	36	PAOZZ	4730-01-067-9232	81361	C5-19-6654	ADAPTER,PIPE TO TUBE 1/4NPS, 7/16-20UNF-2A	EA 1
C-1	37	PAOZZ	5310-00-928-9821	96906	MS24679-2	NUT,PLAIN,CAP NO.8-32UNC-2B	EA 3



AR 920795


Figure C-2. Protective entrance control module

TM3-4240-284-20&P									
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)		
ILLUSTRATION						DESCRIPTION			
(a)	(b)		NATIONAL				QTY		
FIG	ITEM	SMR	STOCK	PART			INC		
NO	NO	CODE	NUMBER	FSCM	NUMBER	USABLE ON CODE	IN		
							U/M	UNIT	
GROUP 0110 PROTECTIVE ENTRANCE									
CONTROL MODULE									
E-5-19-6357									
C-2	1	PAOZZ	5355-00-821-5225	79919	K35B1	KNOB	EA	1	
C-2	2	PAOZZ	6240-00-763-7744	96906	MS25237-387	LAMP, INCANDESCENT	EA	3	
C-2	3	XAOZZ		96906	MS25041-8 LENS ONLY	LENS	EA	1	
C-2	4	XAOZZ		04426	44-601	LIGHT MODULE	EA	1	
C-2	5	PAOZZ	6240-00-155-7784	96906	MS35478-307	LAMP, INCANDESCENT	EA	1	
C-2	6	PAOZZ	6240-00-155-7932	96906	MS25235R311	LAMP, INCANDESCENT RED	EA	1	
C-2	7	PAOZZ	5330-00-143-8571	96906	MS25358-6	GASKET DOME LIGHT	EA	1	
C-2	8	PAOZZ	6220-00-283-9732	96906	MS25358-4	LENS, LIGHT	EA	1	
C-2	9	XAOZZ		96906	MS25358-5	RETAINER LIGHT	EA	1	
C-2	10	PAOZZ	5305-00-889-2999	96906	MS35206-217	SCREW, MACHINE PAN HD, NO. 4-40UNC-2A, 1/2 IN LG	EA	6	
C-2	11	PAOZZ	9905-01-053-3006	81361	C5-19-6316-4	PLATE, IDENTIFICATION: CONTROL MODULE, PROTECTIVE ENTRANCE	EA	1	



ARA80-0123

Figure C-3. M56 gas-particulate filter unit (1 of 2)




ARA80-0130

Figure C-3. M56 gas-particulate filter unit (2 of 2)

TM 3-4240-284-20&P

(1) ILLUSTRATION		(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) FSCM	(5) PART NUMBER	(6) DESCRIPTION	(7) U/M	(8) QTY INC IN UNIT
(a) FIG NO	(B) ITEM NO							
						GROUP 0200 GAS PARTICULATE FILTER UNIT		
						ES-19-6402		
C-3	1	PAOFF	4240-00-237-0227	81361	E5-19-6402	FILTER UNIT, GAS-PARTICULATE: 1 FILTER, M56	EA	1
C-3	2	PAOZZ	9905-01-071-5711	81361	5-19-6316-9	PLATE, IDENTIFICATION: FILTER UNIT, GAS-PARTICULATE, 1 FILTER, M56	EA	1
C-3	3	PAOFF	4240-01-057-3378	81361	E5-19-6376	CONTROL MODULE COMPARTMENT	EA	1
C-3	4	PAOZA	4240-01-067-5605	81361	5-19-6718	FILTER BET, GAS AND PARTICULATE	EA	1
C-3	5	PAOZA	4240-01-066-3266	81361	D5-19-6262	FILTER, PARTICULATE	EA	1
C-3	6	XAOZA		81361	D5-19-6368	FILTER, GAS	EA	1
C-3	7	PAOFF	4240-01-068-8645	81361	E5-19-6387	POWER DISTRIBUTION UNIT	EA	1
C-3	8	MOOZZ		81361	E5-19-6402-8	TUBING, NOMETALLIC ¼ IN. DD. GREEN, MFD FROM 4720-01-053 0316-	EA	1
C-3	9	MOOZZ		81361	E5-19-6402-7	TUBING, NOMETALLIC ¼ IN. DD, RED MFD FROM 4720-00-996-0381	EA	1
C-3	10	XBOFF	4240-01-054-7020	81361	E5-19-6314-20	HOUSING UNIT, FAN AND AIRFLOW VALVE	EA	1
C-3	11	PAOOO	5340-01-048-6327	81361	C5-19-6145	CAP, PROTECTIVE, DUST DUST AND MOISTURE SEAL	EA	1
C-3	12	PAOZZ	5305-00-115-9934	96906	M851849-55	SCREW, MACHINE HEX HD, NO. 8-32UNC-2A, 5/8 IN LG	EA	2
C-3	13	PAOZZ	5310-00-765-3197	96906	MS27183-41	WASHER, FLAT .100 IN ID. .430 IN OD. .049 IN THK	EA	4
C-3	14	AOOOO			CL-2-FANDCL-2-C-	CABLE	EA	1
C-3	15	PAOZZ	4030-00-878-8693	99862	8.0			
C-3	16	MOOZZ		99862	CL2F	FERRULE, WIRE ROPE	EA	2
C-3	17	XAOZZ		99862	CL-2-C-B.0	CABLE, NYLON: B IN. LG, MFD FROM 4010-00-069-5180	EA	1
C-3	18	PAOZZ	4730-00-908-6294	81361	C5-19-6309	CAP, RUBBER	EA	1
C-3	19	PAOZZ	5310-00-811-3494	96906	MS35842-16	CAP,HOSE 4-1/8 TO 7 IN DIA RANGE	EA	1
C-3	20	PAOZZ	5310-00-809-4058	96906	MS21044N08	NUT, SELF-LOCKING, HEXAGON: ND. 6-32UNC-38	EA	2
C-3	21	PAOFF	4140-01-059-2095	81361	E5-19-6240	FAN, TUBEAXIAL 200 CFM	EA	1
C-3	22	PAOZZ	5310-00-809-4058	96906	MS27183-10	WASHER, FLAT .281 IN ID. .625 IN OD. .065 IN THK	EA	6
C-3	23	PAOZZ	5305-00-068-0513	96906	MS90727-6	SCREW, CAP, HEXAGON HEAD: ¼-28UNF-2A. ¾ IN LG	EA	6
C-3	24	XBOZZ	4240-01-107-2433	81361	E5-19-6120	HOUSING, GAS PARTICULATE 1 FILTER	EA	1
C-3	25	PAOZZ	5330-01-069-9824	81361	C5-19-5687-2	SEAL, RUBBER	EA	1


TM3-4240-284-20&P		(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION		(a)	(b)	NATIONAL		PART	DESCRIPTION		QTY	
FIG	ITEM	SMR	STOCK		FSCM	NUMBER		USABLE ON CODE	INC	
NO	NO	CODE	NUMBER						IN	
									UNIT	
C-3	25	XBOZZ			81361	E5-19-6128	COVER, ACCESS		EA	1
C-3	26	PAOZZ	5310-00-080-6004		96906	MS27183-14	WASHER,FLAT .406 IN ID, .812 IN OD, .065 IN THK		EA	6
C-3	27	PAOZZ	5310-00-187-2400		88044	AN960PD616	WASHER,FLAT 0.390 IN. ID, 0.625 IN. OD, 0.063 IN. THK		EA	6
C-3	28	PAOZZ	5305-00-269-3240		96906	MS90727-64	SCREW,CAP,HEXAGON HEAD: 3/8-24UNF-2A, 1-1/2 IN LG		EA	6
C-3	29	XBOZZ			81361	D5-19-6260	COVER, INNER		EA	1
C-3	30	PAOZZ	5330-01-068-0515		81361	C5-19-5687-1	SEAL, RUBBER		EA	1
C-3	31	PAOZZ	9905-01-067-8634		81361	B5-19-6134	PLATE,INSTRUCTION WARNING TORQUE OUTER COVER BOLTS 180 TO 200 INCH POUNDS		EA	1
C-3	32	PAOZZ	9905-01-066-3084		81361	5-19-6135	PLATE,INSTRUCTION WARNING- DO NOT REMOVE COVERS TO SERVICE COMPONENTS AFTERTOXIC EXPOSURE, WITHOUT OBSERVING PROPER HANDLING PROCESDURES		EA	1
C-3	33	PAOZZ	9905-01-050-7557		81361	B5-19-6133	PLATE,INSTRUCTION WARNING- TIGHTEN UNTIL SLEEVE IS FLUSH WITH TOP SURFACE		EA	1
C-3	34	PAOZZ	5310-00-877-5797		96906	MS21044N3	NUT, SELF-LOCKING, HEAXGON: NO. 10-32UNJF-3B		EA	8
C-3	35	PAOZZ	5330-01-088-4442		81361	5-19-6348	GASKET AIRFLOW VALVE		EA	1
C-3	36	PAOPF	4240-01-055-1493		81361	E5-19-6136	VALVE,AIRFLOW		EA	1
C-3	37	PAOZZ	5310-00-014-5850		96906	MS27183-42	WASHER,FLAT .219 IN ID, .500 IN OD, .049 IN THK		EA	8
C-3	38	PAOZZ	5305-00-824-7363		80205	NAS1096-3-12	SCREW,MAHCINE HEX HD, NO. 10-32NF-3A, 3/4 IN LG		EA	8
C-3	39	PAOZZ	5305-00-180-4966		96906	MS51849-64	SCREW,MACHINE HEX, NO. 10-32UNF-2A, 1/2 IN LG		EA	1
C-3	40	PAOZZ	5340-00-119-4705		96906	MS9352-05	CLAMP,LOOP CUSHIONED, 3/8 IN NOM TUBE OD		EA	1
C-3	41	PAOZZ	4730-00-817-1891		30327	261P1-4	NUT,TUBE COUPLING 1/4 IN TUBE OD, 3/8 THD SIZE, W/SLEEVE.		EA	2
C-3	42	PAOZZ	5365-01-057-7379		81361	B5-19-6347	BUSHING,RUBBER		EA	1
C-3	43	PAOZZ	5310-00-081-4219		96906	MS27183-12	WASHER,FLAT .344 IN ID, .685 IN OD, .065 IN THK		EA	9
C-3	44	PAOZZ	5305-00-051-4075		96906	MS90727-33	SCREW,CAP,HEXAGON HEAD: 5/16-24UNF-2A, 7/8 IN LG		EA	8
C-3	45	PAOZZ	4520-01-057-7010		81361	D5-19-6401-10	TEE,AIR INLET		EA	1



AR 920798

Figure C-4. Airflow valve

TM3-4240-284-20&P									
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)		
ILLUSTRATION						DESCRIPTION		QTY	
(a)	(b)		NATIONAL					INC	
FIG	ITEM	SMR	STOCK	PART				IN	
NO	NO	CODE	NUMBER	FSCM	NUMBER		USABLE ON CODE	U/M	UNIT
							GROUP 0220 AIRFLOW VALVE		
							E-5-19-6136		
C-4	1	PAOZZ	9905-01-065-9382	81361	C5-19-6149		PLATE, IDENTIFICATION: AIRFLOW VALVE	EA	1
C-4	2	PAOZZ	9905-01-051-0186	81361	B5-19-6147		PLATE, INSTRUCTION TO SHELTER	EA	1
C-4	3	PAOZZ	9905-01-050-7556	81361	B5-19-6148		PLATE, INSTRUCTION TO PROT ENT	EA	1
C-4	4	PAOZZ	4730-00-908-6294	96906	MS35842-16		CLAMP, HOME 4-1/8 TO 7 IN. DIA RANGE	EA	2
C-4	5	PAOZZ	5310-00-811-3494	96906	MS21044N08		NUT, SELF-LOCKING, HEXAGON: NO. 8-32UNC-38	EA	3
C-4	6	PAOZZ	5310-00-765-3197	96906	MS27183-41		WASHER, FLAT .188 IN ID, .438 IN OD, .49 IN THK	EA	6
C-4	7	XAOZZ		81361	C5-19-6309		CAP, RUBBER	EA	2
C-4	8	AOOOO		99862	CL-2-FANDCL-2-C-8.0		CABLE	EA	2
C-4	9	PAOZZ	4030-00-878-8693	99862	CL2F		FERRULE, WIRE ROPE	EA	4
C-4	10	MOOZZ		99862	CL-2-C-8.0		CABLE, NYLON: 8 IN LG, MFD FROM 4010-00-069-5180	EA	2
C-4	11	PAOZZ	5305-00-115-9934	96906	MS51849-55		SCREW, MACHINE HEX HD, NO. 8-32UNC-2A, 5/8 IN LG	EA	2
C-4	12	PAOOO	5340-01-048-6327	81361	C5-19-6145		CAP, PROTECTIVE, DUST DUST AND MOISTURE SEAL	EA	2
C-4	13	PAOZZ	5305-00-157-5621	96906	MS51849-56		SCREW, MACHINE HEX HD, NO. 8-32UNC-2A, 3/4 IN LG	EA	1



AR 920799

Figure C-5. Power distribution panel

TM3-4240-284-20&P							
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION						DESCRIPTION	
(a)	(b)		NATIONAL				QTY
FIG	ITEM	SMR	STOCK	PART			INC
NO	NO	CODE	NUMBER	FSCM	NUMBER	USABLE ON CODE	IN
						U/M	UNIT
GROUP 0231 POWER DISTRIBUTION PANEL							
E5-19-6391							
C-5	1	PAOZZ	6240-00-892-4420	81349	M15098/11-001	LAMP,GLOW	EA 1
C-5	2	XAOZZ		07137	PTL-A1 (3-C7A) LENS ONLY	LENS	EA 1
C-5	3	PAOZZ	9905-01-065-3065	81361	C5-19-6316-6	PLATE, IDENTIFICATION: POWER DISTRIBUTION UNIT	EA 1
C-5	4	PAOZZ	4730-00-817-1891	30327	261P1-4	NUT,TUBE COUPLING 1/4 IN TUBE OD, 3/8-24 THD SIZE, W/SLEEVE	EA 2




Figure C-6. Compartment control module

TM3-4240-284-20&P							
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION						DESCRIPTION	
(a)	(b)		NATIONAL				QTY
FIG	ITEM	SMR	STOCK	PART			INC
NO	NO	CODE	NUMBER	FSCM	NUMBER	USABLE ON CODE	IN
							U/M
							UNIT
GROUP 0240 COMPARTMENT CONTROL MODULE							
E5-19-6376							
C-6	1	PAOZZ	6240-00-763-7744	96906	MS25237-387	LAMP, INCANDESCENT	EA 8
C-6	2	XAOZZ		04426	44-601	LIGHT MODULE	EA 3
C-6	3	XAOZZ		96906	MS25041-8 LENS ONLY	LENS	EA 2





Figure C-7. M262. Installation kit.

AR 920848

TM3-4240-284-20&P			(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION			(a)	(b)	NATIONAL	FSCM	PART	DESCRIPTION	USABLE ON CODE	QTY
FIG	ITEM	SMR	STOCK							INC
NO	NO	CODE	NUMBER							IN
										U/M
										UNIT
								GROUP 0300 M262 INSTALLATION KIT		
								PL5-19-6704		
C-7	1	PAOZZ	4730-01-049-0805	81361	C5-19-6182			COUPLING,AIR DUCT		EA 5
C-7	2	PAOZZ	4240-01-052-3783	81361	C5-19-6180			HOLDER,STORAGE,AIR		EA 9
C-7	3	PAOZZ	4240-01-061-7233	81361	E5-19-5908			FRAME,INTERFACE ENTRANCE		EA 1
C-7	4	PAOZZ	4730-01-050-7540	30327	KF03-04RV			ADAPTER,STRAIGHT, TUBE TO HOBE		EA 1
C-7	5	PAOZZ	4730-01-067-9232	81361	C5-19-6654			ADAPTER,PIPE TO TUBE 1/4 NPS, 7/16-20 UNF-2A		EA 1
C-7	6	PAOZZ	5310-00-897-6081	96906	MS35691-32			NUT,PLAIN,HEXAGON		EA 1
C-7	7	MOOZZ		81361	PL5-19-6704-19			HOBE,NONMETALLIC 3/16 IN. NOM ID MFD FROM 4720-00-065-5682		EA 1
C-7	8	PAOZZ	5330-01-054-0857	96906	MS90484-20-1			GASKET MOUNT,ELECTRICAL CONNECTOR		EA 1
C-7	9	PAOZZ	5935-00-994-0294	96906	MS3119E20-16			ADAPTER,CONNECTOR ELECTRICAL: THRU-BULKHEAD MTO		EA 1
C-7	10	PAOZZ	5935-00-762-1392	96906	MS3181-20C			COVER,ELECTRICAL CONNECTOR		EA 1
C-7	11	PAOOO	4720-01-074-9220	81361	C5-19-6181-10			HOBE,AIR DUCT 6 IN. ID, 72 IN LG O/A		EA 6
C-7	12	PAOOO	4720-01-063-4567	81361	C5-19-6181-20			HOBE,AIR DUCT 6 IN. ID, 36 IN LG O/A		EA 2
C-7	13	PAOZZ	4240-01-068-2354	81361	5-19-6693			CABLE ASSEMBLY, SPECIAL PURPOSE, ELECTRICAL: 72 IN NOM LG EXCLUDING TERMINATIONS		EA 2
C-7	14	PAOZZ	4240-01-069-9827	81361	5-19-6691			CABLE ASSEMBLY, SPECIAL PURPOSE, ELECTRICAL: 33 IN. NOM LG EXCLUDING TERMINATIONS		EA 1
C-7	15	PAOZZ	4240-01-073-3439	81361	5-19-6162-10			CABLE ASSEMBLY, SPECIAL PURPOSE, ELECTRICAL: 240 IN. NOM LG EXCLUDING TERMINATIONS		EA 1
C-7	16	PAOZZ	4240-01-067-8376	81361	5-19-6170-10			CABLE ASSEMBLY, SPEICAL PURPOSE, ELECTRICAL: 54 IN NOM LG EXCLUDING TERMINATIONS		EA 1
C-7	17	PAOZZ	4240-01-068-2355	81361	5-19-6170-40			CABLE ASSEMBLY, SPEICAL PURPOSE, ELECTRICAL 76 IN. NOM LG		EA 1
C-7	18	XBOOO		81361	D5-19-6628			AIRFLOW VALVE AND SILENCER		EA 1




▲ FURNISHED WITH BASIC ITEM

AR 920801

Figure C-8. Airflow valve and silencer

TM3-4240-284-20&P			(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION			(a)	(b)	NATIONAL			DESCRIPTION		QTY
FIG	ITEM	SMR	STOCK		PART				USABLE ON CODE	INC
NO	NO	CODE	NUMBER	FSCM	NUMBER					IN
										U/M
										UNIT
								GROUP 0310 AIRFLOW VALVE AND SILENCER		
								D5-19-6628		
C-8	1	PAOZZ	2990-01-057-3475	81361	C5-19-6627			MUFFLER, INTAKE		EA 1
C-8	2	PAOZZ	4730-00-908-6294	96906	MS35842-16			CLAMP, HOSE 4-1/8 TO 7 IN DIA RANGE		EA 2
C-8	3	PAOZZ	5305-00-179-8946	96906	MS51849-66			SCREW, MACHINE HEX HD, NO. 10-32UNF-2A, 3/4 IN LG		EA 8
C-8	4	PAOFF	4240-01-055-1493	81361	E5-19-6136			VALVE, AIRFLOW		EA 1
C-8	5	PAOZZ	5330-01-088-4442	81361	5-19-6348			GASKET AIRFLOW VALVE		EA 1
C-8	6	PAOZZ	9905-01-051-0187	81361	B5-19-6656			PLATE, INSTRUCTION PROTECTIVE ENTRANCE		EA 1
C-8	7	XBOZZ		81361	C5-19-6626			STRAP, RETAINING		EA 1
C-8	8	PAOZZ	5305-00-157-5621	96906	MS51849-56			SCREW, MACHINE HEX HD, NO. 8-32UNC-2A, 3/4 IN LG		EA 2
C-8	9	PAOZZ	5310-00-877-5797	96906	MS21044N3			NUT, SELF-LOCKING, HEXAGON: NO. 10-32UNJF-3B		EA 8
C-8	10	XBOZZ		81361	D5-19-6625			BRACKET, MOUNTING		EA 1
C-8	11	PAOZZ	5310-00-811-3494	96906	MS21044N08			NUT, SELF-LOCKING, HEXAGON: NO. 8-32UNJC-3B		EA 2
C-8	12	MOOZZ		81361	D5-19-6716			HOSE, NONMETALLIC-3-1/2 IN LG MFD FROM 4720-01-106-4602		EA 1



AR 920798

Figure C-9. Airflow valve

TM3-4240-284-20&P									
(1)	(2)		(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION									
(a)	(b)	SMR	NATIONAL	FSCM	PART	DESCRIPTION	USABLE ON CODE	QTY	INC
NO	NO	CODE	STOCK	NUMBER	NUMBER			IN	UNIT
GROUP 0311 AIRFLOW VALVE									
E5-19-6136									
E5-19-6136									
C-9	1	PAOZZ	9905-01-065-9382	81361	C5-19-6149	PLATE, IDENTIFICATION: AIRFLOW VALVE		EA	1
C-9	2	PAOZZ	9905-01-051-0186	81361	B5-19-6147	PLATE, INSTRUCTION TO SHELTER		EA	1
C-9	3	PAOZZ	9905-01-050-7556	81361	B5-19-6148	PLATE, INSTRUCTION		EA	1
C-9	4	PAOZZ	4730-00-908-6294	96906	MS35842-16	CLAMP, HOSE 4-1/8 TO 7 IN DIA RANGE		EA	2
C-9	5	PAOZZ	5310-00-811-3494	96906	MS21044N08	NUT, SELF-LOCKING, HEXAGON: NO. 8-32UNC-3B		EA	3
C-9	6	PAOZZ	5310-00-765-3197	96906	MS27183-41	WASHER, FLAT .198 IN ID, .438 OD, .049 IN THK		EA	6
C-9	7	XAOZZ		81361	C5-19-6309	CAP, RUBBER		EA	2
C-9	8	AOOOO		99862	CL-2-FANDCL-2-C 8.0	CABLE		EA	2
C-9	9	PAOZZ	4030-00-878-8693	99862	CL2F	FERRULE, WIRE ROPE		EA	4
C-9	10	MOOZZ		99862	CL-2-C-8.0	CABLE, NYLON: 9 IN. LG. MFD FROM 4010-00-069-5180		EA	2
C-9	11	PAOZZ	5305-00-115-9934	96906	MS51849-55	SCREW, MACHINE HEX HD, NO. 9-32UNC-2A, 5/8 IN LG		EA	2
C-9	12	PAOOO	5340-01-048-6327	81361	C5-19-6145	CAP, PROTECTIVE, DUST DUST AND MOISTURE SEAL		EA	2
C-9	13	PAOZZ	5305-00-157-5621	96906	MS51849-56	SCREW, MACHINE HEX HD, NO. 8-32UNC-2A, 3/4 IN LG		EA	1

TM3-4240-284-20&P									
(1)		(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION			NATIONAL		PART	DESCRIPTION		QTY	
(a)	(b)	SMR	STOCK		NUMBER		USABLE ON CODE	INC	
FIG	ITEM	CODE	NUMBER	FSCM	NUMBER			IN	
NO	NO							U/M	UNIT
GROUP 0500 BULK MATERIALS									
BULK	PAOZZ		4010-00-069-5180	99862	CL2C	CABLE, NYLON COVERE NYLON COVERED		FT	7
BULK	PAOZZ		4720-00-065-8682	30327	C403	HOBE, NONMETALLIC RUBBER 3/16 IN NOM ID		FT	3
BULK	PAOZZ		4720-00-996-0381	30327	44P RED	TUBING, NONMETALLIC 1/4 IN OD, .040 IN. WALL THM RED.		FT	5
BULK	PAOZZ		4720-01-053-0316	30327	44P GREEN	TUBING, NONMETALLIC 1/4 IN. OD, .040 IN. WALL THK GREEN		FT	5
BULK	PAOZZ		4720-01-106-4602	96906	MS521301B225360	HOSE, PREFORMED RUBBER, RADIATOR, 6.00 FORM .03 ID X .10 FORMWALL (3 PLY) 50 PSI PRESSURE		FT	1

SECTION III. SPECIAL TOOLS AND EQUIPMENT LIST
 Not applicable

SECTION IV. NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5310-00-014-5850	C-3	37	4730-00-908-6294	C-8	2
5310-00-045-3296	C-1	3	4730-00-908-6294	C-9	4
5310-00-045-3299	C-1	24	5935-00-912-9599	C-1	29
5310-00-045-3299	C-1	33	5310-00-928-9821	C-1	23
5305-00-051-4075	C-3	44	5310-00-928-9821	C-1	37
4720-00-065-8682	BULK		5410-00-981-8701	C-1	27
5305-00-068-0513	C-3	22	5935-00-990-5580	C-1	30
4010-00-069-5180	BULK		5935-00-994-0294	C-7	9
5310-00-080-6004	C-3	26	4720-00-996-0381	BULK	
5310-00-081-4219	C-3	43	4730-01-017-5119	C-1	7
5305-00-115-9406	C-1	32	9905-01-048-2790	C-1	26
5305-00-115-9934	C-1	11	4240-01-048-2803	C-1	4
5305-00-115-9934	C-3	12	5340-01-048-6327	C-1	10
5305-00-115-9934	C-4	11	5340-01-048-6327	C-3	11
5305-00-115-9934	C-9	11	5340-01-048-6327	C-4	12
5340-00-119-4705	C-3	40	5340-01-048-6327	C-9	12
5330-00-143-8571	C-2	7	4240-01-049-0804	C-1	34
6240-00-155-7784	C-2	5	4730-01-049-0805	C-7	1
6240-00-155-7932	C-2	6	9905-01-049-1385	C-1	20
5305-00-157-5621	C-1	22	4730-01-050-7540	C-1	5
5305-00-157-5621	C-4	13	4730-01-050-7540	C-7	4
5305-00-157-5621	C-8	8	9905-01-050-7556	C-4	3
5305-00-157-5621	C-9	13	9905-01-050-7556	C-9	3
5305-00-179-8946	C-1	2	9905-01-050-7557	C-3	33
5305-00-179-8946	C-8	3	9905-01-051-0186	C-4	2
5305-00-180-4966	C-3	39	9905-01-051-0186	C-9	2
5310-00-187-2400	C-3	27	9905-01-051-0187	C-8	6
5305-00-211-8193	C-1	21	4240-01-052-3783	C-7	2
4240-00-229-2610	C-1	1	4720-01-053-0316	BULK	
4240-00-237-0227	C-3	1	9905-01-053-3006	C-2	11
5330-00-248-3849	C-1	9	5330-01-054-0857	C-7	8
5330-00-250-0236	C-1	8	5310-01-054-4643	C-1	28
5305-00-269-3240	C-3	28	4240-01-054-7020	C-3	10
6220-00-283-9732	C	8	4240-01-055-1493	C-3	36
5310-00-435-8983	C-1	31	4240-01-055-1493	C-8	4
5935-00-762-1392	C-7	10	4240-01-057-3378	C-3	3
6240-00-763-7744	C-2	2	2990-01-057-3475	C-8	1
6240-00-763-7744	C-6	1	4520-01-057-7010	C-3	45
5310-00-765-3197	C-1	12	5365-01-057-7379	C-3	42
5310-00-765-3197	C-3	13	4140-01-059-2095	C-3	20
5310-00-765-3197	C-4	6	4240-01-061-7233	C-7	3
5310-00-765-3197	C-9	6	9905-01-062-0672	C-1	25
5310-00-809-4058	C-3	21	4720-01-063-4567	C-7	12
5310-00-811-3494	C-1	18	9905-01-065-3065	C-5	3
5310-00-811-3494	C-3	19	9905-01-065-9382	C-4	1
5310-00-811-3494	C-4	5	9905-01-065-9382	C-9	1
5310-00-811-3494	C-8	11	9905-01-066-3084	C-3	32
5310-00-811-3494	C-9	5	4240-01-066-3266	C-3	5
4730-00-817-1891	C-3	41	4240-01-067-5605	C-3	4
4730-00-817-1891	C-5	4	4240-01-067-8376	C-7	16
5355-00-821-5225	C-2	1	9905-01-067-8634	C-3	31
5305-00-824-7363	C-3	38	4730-01-067-9232	C-1	36
5310-00-877-5797	C-3	34	4730-01-067-9232	C-7	5
5310-00-877-5797	C-8	9	5330-01-068-0515	C-3	30
4030-00-878-8693	C-1	14	4240-01-068-2354	C-7	13
4030-00-878-8693	C-3	15	4240-01-068-2355	C-7	17
4030-00-878-8693	C-4	9	9905-01-068-2368	C-1	19
4030-00-878-8693	C-9	9	4240-01-068-8645	C-3	7
5305-00-889-2999	C-2	10	5330-01-069-9824	C-3	24
6240-00-892-4420	C-5	1	4240-01-069-9827	C-7	14
5310-00-897-6081	C-1	35	9905-01-071-5711	C-3	2
5310-00-897-6081	C-7	6	4240-01-073-3439	C-7	15
4730-00-908-6294	C-1	17	4720-01-074-9220	C-7	11
4730-00-908-6294	C-3	18	5330-01-088-4442	C-3	35
4730-00-908-6294	C-4	4	5330-01-088-4442	C-8	5
			4720-01-106-4602	BULK	
			4240-01-107-2433	C-3	23

FSCM	PART NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
88044	AN960PD616	C-3	27	96906	MS21044N3	C-3	34
81361	B5-19-6133	C-3	33	96906	MS21044N3	C-8	9
81361	B5-19-6134	C-3	31	96906	MS24679-2	C-1	23
81361	B5-19-6147	C-4	2	96906	MS24679-2	C-1	37
81361	B5-19-6147	C-9	2	96906	MS25041-8 LENS ONLY	C-2	3
81361	B5-19-6148	C-4	3	96906	MS25041-8 LENS ONLY	C-6	3
81361	B5-19-6148	C-9	3	96906	MS25235R311	C-2	6
81361	B5-19-6238	C-1	26	96906	MS25237-387	C-2	2
81361	B5-19-6347	C-3	42	96906	MS25237-387	C-6	1
81361	B5-19-6656	C-8	6	96906	MS25358-4	C-2	8
81361	B5-19-6716	C-8	12	96906	MS25358-5	C-2	9
99862	CL-2-C-8.0	C-1	15	96906	MS25358-6	C-2	7
99862	CL-2-C-8.0	C-3	16	96906	MS27183-10	C-3	21
99862	CL-2-C-8.0	C-4	10	96906	MS27183-12	C-3	43
99862	CL-2-C-8.0	C-9	10	96906	MS27183-14	C-3	26
99862	CL-2-FANDCL-2-C-8.0	C-1	13	96906	MS27183-41	C-1	12
99862	CL-2-FANDCL-2-C-8.0	C-3	14	96906	MS27183-41	C-3	13
99862	CL-2-FANDCL-2-C-8.0	C-4	8	96906	MS27183-41	C-4	6
99862	CL-2-FANDCL-2-C-8.0	C-9	8	96906	MS27183-41	C-9	6
99862	CL2C	BULK		96906	MS27183-42	C-3	37
99862	CL2F	C-1	14	96906	MS29513-019	C-1	9
99862	CL2F	C-3	15	96906	MS29513-24	C-1	8
99862	CL2F	C-4	9	96906	MS3119E20-16	C-7	9
99862	CL2F	C-9	9	96906	MS3181-10N	C-1	29
30327	C403	BULK		96906	MS3181-14N	C-1	30
81361	C5-19-5687-1	C-3	30	96906	MS3181-20C	C-7	10
81361	C5-19-5687-2	C-3	24	96906	MS3186-34	C-1	28
81361	C5-19-6145	C-1	10	96906	MS3186-43	C-1	31
81361	C5-19-6145	C-3	11	96906	MS35206-217	C-2	10
81361	C5-19-6145	C-4	12	96906	MS35338-42	C-1	24
81361	C5-19-6145	C-9	12	96906	MS35338-42	C-1	33
81361	C5-19-6149	C-4	1	96906	MS35338-43	C-1	3
81361	C5-19-6149	C-9	1	96906	MS35478-307	C-2	5
81361	C5-19-6175	C-1	20	96906	MS35691-32	C-1	35
81361	C5-19-6180	C-7	2	96906	MS35691-32	C-7	6
81361	C5-19-6181-10	C-7	11	96906	MS35842-16	C-1	17
81361	C5-19-6181-20	C-7	12	96906	MS35842-16	C-3	18
81361	C5-19-6182	C-7	1	96906	MS35842-16	C-4	4
81361	C5-19-6236	C-1	34	96906	MS35842-16	C-8	2
81361	C5-19-6309	C-1	16	96906	MS35842-16	C-9	4
81361	C5-19-6309	C-3	17	96906	MS51849-53	C-1	32
81361	C5-19-6309	C-4	7	96906	MS51849-54	C-1	21
81361	C5-19-6309	C-9	7	96906	MS51849-55	C-1	11
81361	C5-19-6316-12	C-1	25	96906	MS51849-55	C-3	12
81361	C5-19-6316-4	C-2	11	96906	MS51849-55	C-4	11
81361	C5-19-6316-6	C-5	3	96906	MS51849-55	C-9	11
81361	C5-19-6626	C-8	7	96906	MS51849-56	C-1	22
81361	C5-19-6627	C-8	1	96906	MS51849-56	C-4	13
81361	C5-19-6654	C-1	36	96906	MS51849-56	C-8	8
81361	C5-19-6654	C-7	5	96906	MS51849-56	C-9	13
81361	D5-19-6260	C-3	29	96906	MS51849-64	C-3	39
81361	D5-19-6262	C-3	5	96906	MS51849-66	C-1	2
81361	D5-19-6368	C-3	6	96906	MS51849-66	C-8	3
81361	D5-19-6401-10	C-3	45	96906	MS521301B225360	BULK	
81361	D5-19-6625	C-8	10	96906	MS90484-20-1	C-7	8
81361	D5-19-6628	C-7	18	96906	MS90727-33	C-3	44
81361	E5-19-5908	C-7	3	96906	MS90727-6	C-3	22
81361	E5-19-6120	C-3	23	96906	MS90727-64	C-3	28
81361	E5-19-6128	C-3	25	96906	MS9352-05	C-3	40
81361	E5-19-6136	C-3	36	81349	M15098/11-001	C-5	1
81361	E5-19-6136	C-8	4	80205	NAS1096-3-12	C-3	38
81361	E5-19-6201-40	C-1	1	81361	PL5-19-6704-19	C-7	7
81361	E5-19-6240	C-3	20	07137	PTL-A1 (3-C7A) LENS ONLY	C-5	2
81361	E5-19-6314-20	C-3	10	30327	261P1-4	C-3	41
81361	E5-19-6357	C-1	4	30327	261P1-4	C-5	4
81361	E5-19-6357-111	C-1	6	04426	44-601	C-2	4
81361	E5-19-6376	C-3	3	04426	44-601	C-6	2
81361	E5-19-6387	C-3	7	30327	44P RED	BULK	
81361	E5-19-6402	C-3	1	30327	44P GREEN	BULK	
81361	E5-19-6402-7	C-3	9	81361	5-19-6135	C-3	32
81361	E5-19-6402-8	C-3	8	81361	5-19-6162-10	C-7	15
30327	KF03-02PS	C-1	7	81361	5-19-6170-10	C-7	16
30327	KF03-04RV	C-1	5	81361	5-19-6170-40	C-7	17
30327	KF03-04RV	C-7	4	81361	5-19-6316-9	C-3	2
79919	K35B1	C-2	1	81361	5-19-6348	C-3	35
96906	MS21044N08	C-1	18	81361	5-19-6348	C-8	5
96906	MS21044N08	C-3	19	81361	5-19-6657	C-1	19
96906	MS21044N08	C-4	5	81361	5-19-6691	C-7	14
96906	MS21044N08	C-8	11	81361	5-19-6693	C-7	13
96906	MS21044N08	C-9	5	81361	5-19-6718	C-3	4
				01943	8173	C-1	27

APPENDIX D EXPENDABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

D-1. SCOPE. This appendix lists expendable supplies and materials you will need to operate and maintain the collective protection equipment. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts and Heraldic Items).

D-2. EXPLANATION OF COLUMNS.

- a. *Column 1- Item Number.* This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., "Use dry-cleaning solvent, item 4, app D").
- b. *Column 2- Level.* This column identifies the lowest level of maintenance that requires the listed item.
O - Organizational Maintenance
F - Direct Support Maintenance
- c. *Column 3- National Stock Number.* This is the National stock number assigned to the item; use it to request or requisition the item.
- d. *Column 4- Description.* Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the part number followed by the Federal Supply Code for Manufacturer (FSCM) in parentheses, if applicable.
- e. *Column 5- Unit of Measure (U/M).* Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST


(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION	(5) U/M
1	O	8040-00-165-8614	ADHESIVE, BONDING VULCANIZED: MMM-A-121 (81348) 1 qt can	QT
2	O	8010-01-055-2319	ALIPHATIC POLYURETHANE COATING low reflective, chemical agent resistant MIL-C-46168 (MR) 1gal cntnr	EA
	O	7920-00-223-8002	BRUSH, ACID SWABBING horsehair bristle, 5.750 length HR643	EA

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION (FSCM)	(5) U/M
4	0		DRY-CLEANING SOLVENT: P-D-680	
		6850-00-664-5685	1 QT CNTNR	EA
		6850-00-281-1985	1 GAL CNTNR	EA
5	0		PRIMER: CLASS 2 MIL-P-23377	
		8010-00-142-9279	KIT	EA
6	0		RAG,WIPING: COTTON DESIGNED FOR GENERAL PURPOSE USE DDD-R-30 (81348)	
		7920-00-205-1711	50 IL BALE	EA
7	0		TAPE: OLIVE DRAB, CLASS 1,3 WIDE PP-T-60	
		7510-00-663-3738	ROLL	EA

APPENDIX E ILLUSTRATED LIST OF MANUFACTURED ITEMS

E-1. INTRODUCTION.


- a. This appendix includes complete instructions for making items authorized to be manufactured or fabricated at organizational maintenance level.
- b. All bulk materials needed for manufacture of an item are listed by National Stock Number in a tabular list on the illustration.



NOTES:

1. FABRICATE SUPPORT CABLE FROM NSN 4010-00-069-5180 STOCK.
2. CRIMP WIRE ROPE FERRULES (NSN 4030-00-878-8693) ON CABLE AS SHOWN.
3. ALL DIMENSIONS ARE IN INCHES.



Figure E-1. Support cable



NOTES:

1. FABRICATE GREEN NONMETALLIC TUBING FROM NSN 4720-01-053-0316 STOCK.
2. FABRICATE RED NONMETALLIC TUBING FROM NSN 4720-00-996-0381 STOCK.
3. ALL DIMENSIONS ARE IN INCHES.



Figure E-2. Nonmetallic tubing



NOTES:

1. FABRICATE FROM NSN
4720-01-106-4602 STOCK
2. ALL DIMENSIONS ARE IN INCHES

Figure E-3. Nonmetallic hose



NOTES:

1. FABRICATE FROM NSN
4720-00-065-8682 STOCK.
2. ALL DIMENSIONS ARE IN INCHES.

	LENGTH
A	12
B	22

Figure E-4. Rubber hose

ALPHABETICAL INDEX

<i>Subject</i>	<i>Page</i>	<i>Subject</i>	<i>Page</i>
A		G	
Airduct Hose	2-108	Gas-Particulate Filter Unit, M56	
Airflow Valve	2-82	Dust and Moisture Seal Protective Cap	
Disassembly	2-83	Disassembly	2-73
Installation	2-84	Installation	2-74
Reassembly	2-83	Reassembly	2-74
Removal	2-82	Repair	2-73
Replace/Repair	2-83	Gas and Particulate Filters,	
Airflow Valve and Silencer	2-89	Removal	2-71
Installation	2-90	Installation	2-72
Removal	2-89	Gas Filter,	
Replace/Repair	2-90	Installation	2-72
C		Green Tubing (Nonmetallic),	
Checks and Services, Preventive		Installation	2-76
Maintenance	2-1	Identification Plate,	
Common Tools and Equipment	2-1	Installation	2-78
Compartment Control Unit	2-87	Removal	2-78
Installation	2-87	Instruction Plates,	
Removal	2-87	Installation	2-77
Lamps		Removal	2-77
Installation	2-88	Particulate Filter,	
Removal	2-88	Installation	2-69
D		Removal	2-69
Data, Equipment	1-6	Red Tubing (Nonmetallic),	
Description of Major Components,		Installation	2-76
Location and	1-2	Tubing (Nonmetallic),	
Destruction of Materiel to Prevent		Removal	2-75
Enemy Use	1-1	Repair	2-75
Dust and Moisture Seal Protective Cap	2-59	Painting	2-78
Disassembly	2-60	Replace	2-68
Reassembly	2-60	H	
Repair	2-60	Hoses, Airduct	2-108
E		Installation	2-109
Enemy Use, Destruction of		Removal	2-108
Materiel to Prevent	1-1	Replace/Repair	2-109
Equipment Characteristics, Capabilities,		I	
and Features	1-2	Identification Plate,	
Equipment Data	1-6	Installation	2-78
Equipment Improvement Recommendation		Removal	2-78
(EIR), Reporting	1-1	Instruction Plates,	
Expendable Supplies and Materials List	D-1	Installation	2-77
F		Removal	2-77
Functional Testing	2-3	Identification, Instruction, and	
		warning Plates	1-4
		Illustrated List of Manufactured Items	E-1

TM 3-4240-284-20&P

<i>Subject</i>	<i>Page</i>
L	
Location and Description of Major Components	1-2
M	
Main Fan,	
Installation	2-80
Removal	2-79
Maintenance Allocation Chart	B-1
Maintenance Forms and Records	1-1
Maintenance Instructions	2-1
Air duct Hoses	2-108
Airflow Valve	2-82
Cable C5-19-6693	2-102
Cable C5-19-6162-10	2-96
Cable C5-10-6170-10	2-99
Cable C5-10-6170-40	2-92
Cable C5-19-6691	2-106
Compartment Control Unit	2-87
Dust and Moisture Seal Protective Cap	2-59
Gas-Particulate Filter Unit M56	2-68
Hoses, Air duct	2-108
Identification and Instruction Plates	2-57
Main Fan	2-79
Plug Drain With Chain	2-58
Power Distribution Unit	2-85
Protective Entrance Control Module	2-63
Protective Entrance M10	2-56
Manual, Type of	1-1
Materials List, Expendable Supplies and	D-1
Model Numbers and Equipment Names	1-1
O	
Operation, Principles of	1-8
Organizational Maintenance Repair Parts and Special Tools List	C-1
P	
Plug Drain with Chain	2-58
Removal	2-58
Installation	2-58
Power Distribution Unit	2-85
Identification Plate	
Installation	2-86
Removal	2-86
208V Lamp	
Installation	2-85
Removal	2-85
Replace	2-85
Preparation for Storage or Shipment	1-1

<i>Subject</i>	<i>Page</i>
Preventive Maintenance Checks and Services	2-1
Principles of Operation	1-8
Procedures, Troubleshooting	2-11
Protective Entrance Control Module	2-63
Disassembly	2-67
Installation	2-64
Reassembly	2-67
Removal	2-63
Repair	2-64
Protective Entrance, M10	
Dust and Moisture Seal Protective Cap	
Disassembly	2-60
Installation	2-61
Reassembly	2-60
Removal	2-59
Repair	2-60
Impermeable Wall Fabric	
Repair	2-66
Instruction Plates and Identification Plate	
Installation	2-57
Removal	2-57
Plug Drain	2-58
Installation	2-58
Removal	2-58
Static Port Adapter	
Installation	2-62
Removal	2-62
Painting	2-62
Replace	2-56
Purpose of Equipment	1-1

R

References	A-1
Repair Parts	2-1
Repair Parts List	C-6
Reporting Equipment Improvement Recommendations (EIR)	1-1

S

Special Tools, TMDE, and Support Equipment	2-1
---	-----

T

Tools and Equipment, Common	2-1
Tools, TMDE, and Support Equipment, special	2-1
Troubleshooting procedures	2-11
Type of Manual	1-1

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

Your mailing address

DATE SENT Date you send this form

PUBLICATION NUMBER
TM 3-4240-284-20&P

PUBLICATION DATE
Date of TM

ORGANIZATIONAL MAINTENANCE
PROTECTION EQUIPMENT, FIRE
MANUAL COLLECTIVE PROTECTION EQUIPMENT, FIRE
DIRECTION SYSTEM, ARTILLERY, (TACFIRE) ANVGS-10(V).

BE EXACT...PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
1-6	1-7		
2-7	2-7		
2-74	2-17		

ITEM 1. LINE 13. Change "Rock Island, IL 61299" to read, "Aberdeen Proving Ground, Md 21010."
REASON: Wrong Address.

ITEM 2. IN REMARKS column add, "Do not use a wrench." Place remark in line with, "Tighten finger tight."
REASON: Incomplete information.

ITEM 3. Add callout "33" to the hose clamp in the illustration.
REASON: Call out missing from illustration.

SAMPLE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SSG I. M. DeSpirito 999-1776

SIGN HERE

I. M. DeSpirito

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE.

P.S. --IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

TEAR ALONG DOTTED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 3-4240-284-20&P

PUBLICATION DATE

16 Dec 81

ORGANIZATIONAL MAINTENANCE
MANUAL COLLECTIVE PROTECTION EQUIPMENT, FIRE
DIRECTION SYSTEM, ARTILLERY, (TACFIRE) ANGS9-10(V).

BE EXACT...PIN-POINT WHERE IT IS

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

Large empty space for writing the recommendation and details.

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

TEAR ALONG DOTTED LINE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE.

P.S. -IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Armament Materiel Readiness Command
ATTN: DRSAR-MAS-C
Aberdeen Proving Ground, MD 21010

TEAR ALONG DOTTED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 3-4240-284-20&P

PUBLICATION DATE

16 Dec 81

ORGANIZATIONAL MAINTENANCE
MANUAL COLLECTIVE PROTECTION EQUIPMENT, FIRE
DIRECTION SYSTEM, ARTILLERY, (TACFIRE) ANKGS-10(V).

BE EXACT...PIN-POINT WHERE IT IS

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

(This area is currently blank for user input.)

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S. --IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

TEAR ALONG DOTTED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Armament Materiel Readiness Command
ATTN: DRSAR-MAS-C
Aberdeen Proving Ground, MD 21010

TEAR ALONG DOTTED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH THIS PUBLICATION?

THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER
TM 3-4240-284-20&P

PUBLICATION DATE
16 Dec 81

ORGANIZATIONAL MAINTENANCE
MANUAL COLLECTIVE PROTECTION EQUIPMENT, FIRE
DIRECTION SYSTEM, ARTILLERY, (TACFIRE) ANVGSQ-10(V).

BE EXACT...PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.

TEAR ALONG DOTTED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 **2028-2**

PREVIOUS EDITIONS ARE OBSOLETE.

P.S. -IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Armament Materiel Readiness Command
ATTN: DRSAR-MAS-C
Aberdeen Proving Ground, MD 21010

TEAR ALONG DOTTED LINE

By Order of the Secretary of the Army:

E. C. MEYER
General, United States Army
Chief of Staff

Official:

ROBERT M. JOYCE
Brigadier General United States Army
The Adjutant General

DISTRIBUTION :

To be distributed in accordance with DA Form 12-28, Organizational maintenance requirements for Collective Protection Equipment Vehicular.

