


TECHNICAL MANUAL

DIRECT SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)



INTRODUCTION	1-1
TROUBLESHOOTING	2-1
MAINTENANCE PROCEDURES FOR M12 PROTECTIVE ENTRANCE	2-137
MAINTENANCE PROCEDURES FOR M56 GAS-PARTICULATE FILTER UNIT	2-144
REPAIR PARTS AND SPECIAL TOOLS LIST	B-1
EXPENDABLE SUPPLIES AND MATERIALS LIST	C-1
INDEX	INDEX-1

COLLECTIVE PROTECTION EQUIPMENT, GUIDED MISSILE AIR
DEFENSE SYSTEM, AN/TSQ-73
CONSISTING OF
ENTRANCE, PROTECTIVE, PRESSURIZED: COLLAPSIBLE, M12
(NSN 4240-01-048-2923);
FILTER UNIT, GAS-PARTICULATE: 200 CFM, 208 V, 400 HZ, M56
(NSN 4240-00-237-0227)
AND
INSTALLATION KIT: CBR, PROTECTIVE EQUIPMENT, AN/TSQ-73, M263
(NSN 4240-01-063-7679)

HEADQUARTERS, DEPARTMENT OF THE ARMY
24 AUGUST 1982

CHANGE
NO. 1

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 21 December 1989

DIRECT SUPPORT MAINTENANCE MANUAL
FOR
COLLECTIVE PROTECTION EQUIPMENT
GUIDED MISSILE AIR DEFENSE SYSTEM, AN/TSQ-73

1. The purpose of this change is to update guidance for disposal, handling, and storage of filters.
2. New or changed material is indicated by a vertical bar in the margin of the page. RPSTL listing changes are indicated by an asterisk to the left of the item number column adjacent to the line item.
3. Remove old pages and insert new pages as follows:

Remove Pages

Insert Pages

None
B-17 and B-18

a/(b blank)
B-17 and B-18

4. File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN II
Brigadier General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with DA Form 12-28-R, quantity required block 56,
TM 3-4240-286-30&P.

WARNING

HEALTH/ENVIRONMENTAL HAZARD

Filters use ASC Whetlerite Carbon which contains Chromium VI. Chromium VI is a known carcinogen if inhaled or swallowed. Damaged or unusable filters are classified as hazardous waste:

DO NOT throw away damaged or unusable filters as ordinary trash.

DO turn in damaged or unusable filters to your hazardous waste management office or Defense Reutilization and Marketing Office (DRMO).

Filters are completely safe to handle and use if they are not damaged in such a way that carbon leaks from them. In unlikely event that carbon should leak, use protection such as a dust respirator to cover nose and mouth and put carbon in container such as self-sealing plastic bag; turn in to hazardous waste management office or DRMO.

Disposal of hazardous waste is restricted by the Resource Conservation and Recovery Act as amended (42 U.S.C.A sec 6901 et seq). Violation of these laws is subject to severe criminal penalties.

Direct Support Maintenance Manual
(Including Repair Parts And Special Tools List)
COLLECTIVE PROTECTION EQUIPMENT, GUIDED MISSILE AIR
DEFENSE SYSTEM, AN/TSG-73
CONSISTING OF
ENTRANCE, PROTECTIVE, PRESSURIZED: COLLAPSIBLE, M12
(NSN 4240-01-048-2923);
FILTER UNIT, GAS-PARTICULATE:
200 CFM, 208 V, 400 HZ, M56
(NSN 4240-00-237-0227)
AND
INSTALLATION KIT: CBR, PROTECTIVE EQUIPMENT, AN/TSG-73, M283
(NSN 4240-01-063-7679)






Current as of 3 March 1982 for Appendix B.

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Armament Materiel Readiness Command, ATTN: DRSAR-MAS-C, Aberdeen Proving Ground, MD21010. A reply will be furnished to you.

		Page
CHAPTER	1 INTRODUCTION	1-1
Section	I General Information	1-1
	II Equipment Description and Data	1-2
	III Repair Parts, Special Tools, TMDE, and Support Equipment	1-2
	IV Principles of Operation	1-2

		Page	
CHAPTER	2	MAINTENANCE INSTRUCTIONS	2-1
Section	I	Troubleshooting	2-1
	II	Maintenance Procedures for M12 Protective Entrance	2-137
	III	Maintenance Procedures for M56 Gas-Particulate Filter Unit	2-144
APPENDIX	A	REFERENCES	A-1
	B	REPAIR PARTS AND SPECIAL TOOLS LIST	B-1
Section	I	Introduction	B-1
	II	Repair Parts List	B-6
			Page
			Illus Figure
Group	0100	M12 Protective Entrance	B-7
		0110 Protective Entrance Control Module	B-11
	0200	M56 Gas-Particulate Filter Unit	B-14
		0210 Main Fan	B-21
		0220 Airflow Valve	B-23
		0230 Power Distribution Unit	B-25
		0231 Power Distribution Panel	B-29
		0240 Compartment Control Module	B-35
	0300	M263 Installation Kit	B-39
		0310 Airflow Valve and Silencer	B-41
		0311 Airflow Valve	B-43
	0500	Bulk Material	B-44
Section	III	Special Tools List (Not Applicable)	B-45
	Iv	NSN, Part No. index	B-45
APPENDIX	C	EXPENDABLE SUPPLIES AND MATERIALS LIST	C-1
	D	ILLUSTRATED LIST OF MANUFACTURED ITEMS	D-1
		INDEX	Index 1



CHAPTER 1

INTRODUCTION

Section I. GENERAL INFORMATION

1-1. SCOPE.

a. Type of *Manua/*. Direct Support Maintenance, including the Repair Parts and Special Tools List.

b. *Model Numbers and Equipment Names*.

M12 protective entrance:

Protective entrance control module

M56 gas-particulate filter unit:

Main fan

Airflow valve

Power distribution unit

Compartment control module

M263 installation kit:

Airflow valve

c. *Purpose of Equipment*. Provides filtered air under positive pressure to field shelters.

1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS. Department of the Army forms and procedures used for equipment maintenance will be those prescribed by TM 38-750, The Army Maintenance Management System (TAMMS).

1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE. Refer to TM 43-0002-31, Destruction of Chemical Weapons and Defense Equipment to Prevent Enemy Use.

1-4. NOMENCLATURE CROSS-REFERENCE LIST. This listing includes nomenclature cross-references used in this manual.

<i>Common Name</i>	<i>Official Nomenclature</i>
Compartment control module (CCM)	Control module, compartment

Common Name

Differential pressure gage

M56 gas-particulate filter unit

M12 protective entrance

M263 installation kit

Power card

Protective entrance control module (PECM)

Switching card

Official Nomenclature

Gage, differential, dial indicating

Filter unit, gas-particulate, M56

Entrance, protective, pressurized, M12

Installation kit, M263

Printed circuit board: power

Control module, protective entrance

Printed circuit board: switching

1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR). If your collective protection equipment needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Tell us why a procedure is hard to perform. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at Commander, US Army Armament Materiel Readiness Command, ATTN: DRSAR-MAP-A, Aberdeen Proving Ground, MD21010. A reply will be furnished directly to you.

Section II. EQUIPMENT DESCRIPTION AND DATA

1-6. DESCRIPTION AND TABULATED DATA. Refer to TM 3-4240-286-20&P.

Section III. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

1-7. COMMON TOOLS AND EQUIPMENT. For authorized common tools and equipment refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

1-8. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT. No special tools, TMDE, or support equipment are required.

1-9. REPAIR PARTS. Repair parts are listed and illustrated in appendix B of this manual.


Section IV. PRINCIPLES OF OPERATION

1-10. PRESSURE CONTROL SYSTEM.

a. The basic function of the pressure control system is to control the air pressure in a protected compartment within the prescribed limits by controlling the opening of an airflow valve from the pressurized air supply, the filter unit. The prescribed limits are 1.2 to 1.7 inches water gage (hereafter referred to as in. wg) for the compartment or compartment control module and 0.4 to 0.8 in. wg for the protective entrance and protective entrance control module. The control system operates from 28 vdc power.

b. The compartment pressure is sensed by the pressure transducer which provides an output voltage of 2 volts/in. wg to pin 1 of the switching card. When the air pressure in the compartment drops below the desired low limit, 1.2 in. wg for switching card A2 or 0.4 in. wg for

switching card A3, the pressure transducer output voltage drops below the low limit reference voltage. An operational amplifier (op amp) on the switching card compares pressure transducer output voltage to the low limit reference voltage (2.6 volts for the compartment control module low limit side) provided by potentiometer R11, resistor R13 and the voltage reference diode VR1 and multiplies the voltage difference by 26 times and provides this as the output voltage at TP-D. The op amp output voltage is at a low power level of only a few milliamps (mA). The transistor Q1 amplifies the power level to about 50 mA while providing no voltage amplification. The power level is further amplified by Q4 of the power card A1. This transistor brings the power level up to about 500 mA to drive the airflow valve motor.



Pressure Control System, Switching and Power Card, Interconnection Schematic

c. Direct current power and ground are provided at output terminals 3 and 4 of the power card to the reversible 28 vdc motor. As the output of Q4 on the power card starts to rise, it provides current via R10 to the base of Q2 on the power card. When this happens, Q2 turns on and provides a ground at terminal 4 of the power card whenever a voltage greater than a few volts is provided at terminal 3 of the power card. The airflow valve motor is connected such that when this happens the airflow valve motor will start and open the valve until the compartment pressure has risen to within the prescribed limits.

d. The description so far has been only for a low pressure condition or low limit side. There is an equivalent high pressure or high limit side circuitry which provides opposite polarity voltage to terminals 3 and 4 of the power card and hence the airflow valve motor. This circuitry consists of U2, Q3 on the switching card, and Q3 and Q1 on the power card. Whenever one pressure side is on, the other side is off. In the dead band (i.e., when the pressure is within the proper limits), both sides are off. The greater the pressure is outside the dead band, the greater the dc voltage to the airflow valve

motor. The voltage increases at the rate of 5.1 volts/.1 in. wg and saturates or reaches a maximum of about 25 volts when the pressure is 0.35 in. wg or more outside of the dead band.

e. The switching card also contains the low pressure alarm circuitry consisting basically of Q2, CR1, VR3, and the voltage divider resistors R8 and R25. This circuit is set to fire when the pressure falls below a preset level, 1.0 in. wg for the compartment control module and 0.33 in. wg for the protective entrance control module. When the pressure reaches the levels described above, the voltage across the four layer diode goes down to about 1 volt and allows base current to flow into the transistor Q2. The transistor is, therefore, "on" and provides a ground at terminal 9 of the switching card. In the system when this ground is provided, the MASK light/horn alarm or PE LOW PRESSURE light comes on. The circuit turns off when the voltage level of the low limit side falls within the proper limits.

f. The circuit consisting of R14, VR2, and Q4 is a series voltage regulator for the op amps and the pressure transducer. The circuit limits the voltage of these components to 28 vdc during high voltage transients.

1-11, LOSS OF POWER/PRESSURE WARNING SYSTEM.


a. The loss of power warning system provides an alarm, mask light and warning horn whenever the power switch on the compartment control module is turned on in the absence of input power to the compartment control module. An alarm is also provided when power is lost during normal operation.

b. When the compartment control module power switch is ON and the power is provided to the modular collective protection equipment, the batteries are charged through normal power distribution in the compartment control module through charging resistor R8. With the compartment control module power switch ON and a loss of power, battery power is provided to the loss of power warning system through terminals 5 and 6 of the compartment control module power switch of terminals 7 of A4 (printed circuit assembly switching auxiliary). Power is provided to the warning devices from terminal 8 of A4, Diodes A4 CR4 and CR5 prevent

power feedback into the rest of the 28 vdc power system, Diode CR3 provides power for the MASK indicator press-to-test. Diode A4 CR6 blocks power to the loss of power warning system when the system is off; however, press-to-test power is being provided through CR5.


c. During normal operation, 28 vdc power is provided through the closed contacts of pressure switch S6 and diode A4CR7 to keep A4Q3 turned off. Whenever there is a loss of pressure or a loss of power, 28 vdc is removed from the base of A4 Q3 and battery current provided by A4R5, A4VR1, and A4R7 turns A4Q3 on. Current provided by A4 Q3 and A4 R3 is directed to the base of A4 Q2 turning A4 Q2 on. When A4 Q2 is on, a ground is provided at terminals 1, 2, and 6 of A4 which activates the warning circuit.

d. Current will be supplied by A4 Q3 as long as the battery voltage is greater than 16 volts. In the range of 14-16 volts the transistor A4 Q3 will be turned off by A4 VR1 thus removing base drive for A4 Q2 and hence turning off the warning circuit and preventing deep discharge of the batteries.





Loss of Power/Pressure Warning System Schematic Diagram

1-12. OVERALL SYSTEM. Refer to system schematic diagram below for component operation with other collective protection equipment.



Collective Protection System Schematic Diagram



Collective Protection System Schematic Diagram (Sheet 2 of 2)


CHAPTER 2 MAINTENANCE INSTRUCTIONS

Section I. TROUBLESHOOTING

2-1. SCOPE. This section provides information for locating and correcting malfunctions in the modular collective protection equipment. Flow charts are used to

isolate malfunctions and prescribe the required corrective action.

2-2. FLOW CHART PROCEDURES. The following describes the use of the troubleshooting charts:






INDEX	
TROUBLESHOOTING PROCEDURE	Page
PECM	2-2
Main Fan	2-32
Airflow Valve	2-33
Power Distribution Panel	2-39
CCM	2-63
TEST EQUIPMENT	
Multimeter AN/USM223	●
Power Supply 6130-00-408-4962 (or equiv)	●
Differential Pressure Gage 6685-00-087-6331	●
Hypodermic Syringe 6515-00-754-0412	●
Hose Tee 4730-00-082-5402	●
Tubing 4720-00-059-5819	●
Resistor (680 OHM, 2W) 5905-00-256-0390	●
Resistor (100 OHM, 10W) 5905-00-752-6460	●


2-3. PECM TROUBLESHOOTING PROCEDURES.

NOTE


All voltages are dc and are measured with respect to dc return (TB1-1) unless otherwise specified.




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).



2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont)




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).

CAUTION




Be careful not to touch other pins in J20 as it may short out components on XA3 switching card.





From page 2-10.




2-3 PECM TROUBLESHOOTING PROCEDURES (Cont).





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).





2-3. PECM TROUBLESHOOTING PROCEDURES





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).






2-3. PECM TROUBLESHOOTING PROCEDURES





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).



2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).







From page 2-20.

Remove power. Measure diodes on switching card A3 to verify that they are not shorted. Measure resistance between:


Diode	(+)	(-)
A3CR2	TP-J	TP-H
A3CR3	TP-J	A3-B(3)
A3CR4	TP-K	A3-B(3)
A3CR5	TP-K	TP-L



2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).



From page 2-22.

Apply vacuum to the PECM as indicated below and measure test point (TP) voltage on switching card A3 with respect to TB1-1 as indicated:

Vacuum (in. wg)	Volts	
	TP-M	TP-G
0	25 ± 2	< 1
0.4	9.3 ± 3.5	< 1
0.6	< 1	< 1
0.8	< 1	9.3 ± 3.5
1.3	< 1	25.3 ± 2



Was the specified voltage obtained in all cases?

Remove power. Replace the switching card A3 (p 2-140). Repeat test on page 2-3.

Remove power. Remove XA1 jumper. Install the power card A1. Apply power.

Is the current less than 1/2 amp?




Remove power. Replace power card A1 (p 2-141). Repeat test on page 2-3.

Repeat test on page 2-3.

2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).

● = TP (TEST POINT)

From page 2-3 and page 2-4.



Remove power. Remove screws from PECM panel and lift up for access to components. Apply power. Measure voltage between:
 (+) A3-TP-J (-) A3-TP-K

Was 22.5 to 26.5 vdc obtained?

Remove power. Repair wiring (p 2-142) for continuity between:
 Wire No. From (+) To (-)
 20 XA3-S(15) XA1-B(2)
 21 XA3-R(14) XA1-E(5)
 31 XA1-C(3) J21-A
 32 XA1-D(4) J21-B
 Repeat test on page 2-3.

Measure voltage between:
 (+) A2-TP-B (-) TB1-1

Was 28 ± 2 vdc obtained?

Remove power. Repair wire (3) between J20-C and XA1-10 (p 2-142). Apply power. Repeat test on page 2-3.



Measure voltage between:
 (+) A3-TP-B (-) XA3-C(3)

Was 28 ± 2 vdc obtained?


Remove power. Repair wires to TB1-1 from XA1-H(7) and XA3-C(3). Refer to page 2-142. Apply power and repeat test on page 2-3.

Proceed to page 2-25.


2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).





2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).



2-3. PECM TROUBLESHOOTING PROCEDURES



2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).




From page 2-28.

Remove power printed circuit card A1. Connect jumpers as follows:

(From) XA1-L(10) (To) XA1-K(9)

This connection completes the power to the switching card A3 which is normally provided when the power card A1 is removed so that the switching card A3 is not electrically loaded by a defective power card. Apply 28 vdc power and vacuum to the PECM as indicated below and measure test point (TP) voltage on switching card A3 with respect to ground TB1-1 as indicated:

Vacuum (in. wg)	Voltage at test point (volts)	
	A3-TP-M	A3-TP-G
0	25 ± 2	< 1
0.4	9.3 ± 3.5	< 1
0.6	1	< 1
0.8	1	9.3 ± 3.5
1.3	1	25.3 ± 2





No





Yes

Remove power. Remove jumper. Replace the switching card A3 (p 2-140). Repeat test on page 2-3.



Proceed to page 2-30. Remove jumper.




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).




2-3. PECM TROUBLESHOOTING PROCEDURES (Cont).





2-4. MAIN FAN TROUBLESHOOTING PROCEDURES.





WARNING
 Keep hands away from fan impeller area when main fan is running.




2-5. AIRFLOW VALVE TROUBLESHOOTING PROCEDURES.




2-5. AIRFLOW VALVE TROUBLESHOOTING PROCEDURES (Cont).




2-5. AIRFLOW VALVE TROUBLESHOOTING PROCEDURES (Cont).




2-5. AIRFLOW VALVE TROUBLESHOOTING PROCEDURES (Cont).





2-5. AIRFLOW VALVE TROUBLESHOOTING PROCEDURES (Cont).





2-5. AIRFLOW VALVE TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES.




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).



2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).



2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).



From page 2-42.

Connect the high pressure side of a differential pressure gage (6 in. wg) to a pressure source (syringe, aspirator, etc.) and to the hose fitting marked with a red dot on the PDU panel.

Connect one end of a 680 ohm, 2 watt resistor to J3-F. Apply 28 vdc to:


(+)	(-)
680 resistor	J3-A

Slowly increase pressure to 6 in. wg and measure voltage across resistor connected to power source (+) and J3-F (-). Voltmeter should indicate 28 ± 2 vdc when pressure is greater than 5.5 in. wg; 0 vdc when less than 4.5 in. wg.

```


    graph TD
        Start[From page 2-42.] --> Q1{Was the voltage 0 vdc at pressure less than 4.5 in. wg?}
        Q1 -- No --> P254[Proceed to page 2-54.]
        Q1 -- Yes --> Q2{Was the voltage 28 ± 2 vdc at pressure greater than 5.5 in. wg?}
        Q2 -- No --> P254
        Q2 -- Yes --> P244[Proceed to page 2-44.]
        P244 --> Q3{Did the voltage switch to 28 ± 2 vdc at a pressure less than 4.5 in. wg?}
        Q3 -- No --> P253[Proceed to page 2-53.]
        Q3 -- Yes --> P2165[Replace pressure switch S7 (p 2-165). Repeat test on this page.]
    
```

2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).





CB3


Protective entrance light circuit breaker




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).





2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).





2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).





2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (cont)





2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).





2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).







2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).




2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING PROCEDURES (Cont).



2-6. POWER DISTRIBUTION PANEL TROUBLESHOOTING (PROCEDURES Cont).






2-7. CCM TROUBLESHOOTING PROCEDURES.




NOTE


All voltages are dc and are measured with respect to dc return (TB1-2 thru 8) unless otherwise specified.



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



From page 2-63.




With the POWER switch S9 OFF, open (pull out) all circuit breakers until white shows on shaft. Connect a 100 ohm, 10 watt resistor across terminals J1-P and J1-N. Apply 28 vdc to J1 connector:
 Pin B - positive
 Pin A - negative
 Measure the voltage across resistor:
 (+) J1-P (-) J1-N

Power application or removal on the following pages is accomplished by making or breaking connections to pins A and B of J1 or by setting the power source on or off.

```

    graph TD
        A{Was 0 vdc obtained?} -- No --> B[Proceed to page 2-103.]
        A -- Yes --> C{Is the warning horn and/or MASK indicator light off?}
        C -- No --> B
        C -- Yes --> D[Proceed to page 2-65.]
    
```



Remove screws on CCM panel and lift up for access to components. Remove power. Disconnect wires (11 and 12) from S9-8 and S9-11. Apply power.

```

    graph TD
        A{Was 0 vdc obtained?} -- No --> B[Remove power. Repair wires between S9-8 or S9-11 to J1-N or J1-P (p 2-184). Apply power. Repeat test on this page.]
        A -- Yes --> C[Remove power. Disconnect wires from CB5-2. Measure voltage at CB5-2.]
    
```


Remove power. Repair wires between S9-8 or S9-11 to J1-N or J1-P (p 2-184). Apply power. Repeat test on this page.

Remove power. Disconnect wires from CB5-2. Measure voltage at CB5-2.
 (+) CB5-2 (-) TB1-2
 Apply power.


```

    graph TD
        A{Was 0 vdc obtained?} -- No --> B[Remove power. CB5 should not have voltage at terminal 2 when it is tripped. Replace INDICATORS circuit breaker CB5 (p 2-178). Reconnect wires 11 and 12 at S9. Apply power. Repeat test on this page.]
        A -- Yes --> C[Remove power. Repair wiring from CB5-2 to S9-7 (p 2-184). Reconnect wires 11 and 12 at S9. Apply power. Repeat test on this page.]
    
```




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).






2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).

NOTE


Reapplying power on the following pages will probably cause the horn to sound. Press the HORN OFF button to silence horn.





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont.)


From page 2-77.




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).







2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).






2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



From page 2-107.




Pressure circuit breaker CB8 provides a dc return signal on its auxiliary contacts to actuate the warning horn LS1 when CB8 is open or tripped. Measure the voltage at the auxiliary terminal CB8-3 (soldered terminal) with respect to dc return.

(+) CB8-3 (-) TB1-2



```

    graph TD
        Start([From page 2-107]) --> Test1{Was the voltage less than 1 vdc?}
        Test1 -- No --> Test2{Was the voltage less than 1 vdc?}
        Test1 -- Yes --> Test2
        Test2 --> Measure1[/Measure the voltage between:  
(+) K2-C on B side of switch  
(-) TB1-2/]
        Measure1 --> Test3{Was the voltage less than 1 vdc?}
        Test3 -- No --> Repair1[Remove power. Set POWER switch OFF. Repair wiring between K2-B-C and CB8-3 (p 2-184). Apply power. Repeat test on page 2-65.]
        Test3 -- Yes --> Measure2[/Measure the voltage between:  
(+) K2-N.C. on B side of switch  
(-) TB1-2/]
        Measure2 --> Test4{Was the voltage 0 ± 0 vdc?}
        Test4 -- No --> Repair2[Remove power. Set POWER switch OFF. Replace HORN OFF switch (p 2-182). Apply power. Repeat test on page 2-65.]
        Test4 -- Yes --> Repair3[Remove power. Set POWER switch OFF. Repair wiring (p 2-184) between K2-B-N.C. and LS1-(-). Apply power. Repeat test on page 2-65.]
        Repair1 --> Test5[/Remove power. Measure for continuity to ground:  
(+) CB8-4  
(-) TB1-2/]
        Repair2 --> Test5
        Repair3 --> Test5
        Test5 --> Test6{Was continuity obtained?}
        Test6 -- No --> Repair4[Set POWER switch OFF. Repair wire to TB1-5. Apply power. Repeat test on page 2-65.]
        Test6 -- Yes --> Repair5[Set POWER switch OFF. Replace COMPARTMENT PRESSURE circuit breaker CB8 (p 2-179). Apply power. Repeat test on page 2-65.]
    
```



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont)




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




CB8




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont)





From page 2-112. Mask light remains on even when switching card A2 has been removed. Remove power. Disconnect (unsolder) wire 34 on A4-2. Leave wire which goes to A4-6 connected. Apply power.




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont)





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7 CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



● = TP (TEST POINT)



Was resistance greater than 1 K ohm obtained?

Measure resistance at the output of A2 between:

(+)	(-)
A2-TP-M	A2-B(2), C(3), or D(4)
A2-TP-G	A2-B(2), C(3), or D(4)



Replace switching card A2 (p 2-176). Reinstall power card A1. Apply power. Repeat test on page 2-68.

Was resistance greater than 1 K ohm obtained?


Replace switching card A2 (p 2-176). Reinstall power card A1. Apply power. Repeat test on page 2-68.

Proceed to page 2-121.

2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




From page 2-121.

Apply vacuum to CCM as indicated below and measure test point (TP) voltage on switching card A2 with respect to TB1-2 as indicated.


Pressure (in. wg)	Voltage at test points TP-M	TP-G
0	25 ± 2	< 1
1.2	9.3 ± 3.5	< 1
1.45	< 1	< 1
1.7	< 1	9.3 ± 3.5
2.5	< 1	25.3 ± 2





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).







2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



From page 2-126.

Set POWER switch OFF. Remove power. Remove switching card A2 (p 2-176). Measure diodes on switching card to verify that they are not shorted. Measure resistance between:

Diode	(+)	(-)
CR2	TP-J	TP-H
CR3	TP-J	A2-B(2), C(3), or D(4)
CR4	TP-K	A2-B(2), C(3), or D(4)
CR5	TP-K	TP-L

Was resistance greater than 1 K for all measurements?

Measure resistance at the output of the switching card A2 between:

(+)	(-)
A2-TP-M	A2-B(2), C(3), or D(4)
A2-TP-G	A2-B(2), C(3), or D(4)



Replace switching card A2. Apply power. Set POWER switch ON. Repeat test on page 2-68.

Was resistance greater than 1 K obtained?

Replace switching card A2. Apply power. Set POWER switch ON. Repeat test on page 2-68.


Proceed to page 2-129.

2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).

From page 2-129.




Remove power card A1 (p 2-174). Connect jumpers as indicated:

(From)	(To)
XA1-L(10)	XA1-K(9)
XA1-H(7)	XA1-J(8)

This connection completes the power to the switching card A2 which is normally provided when the power card is installed. The power card A1 is removed so that the switching card is not electrically loaded by a defective power card. Apply power. Set POWER switch ON and apply vacuum to CCM as indicated below and measure test point (TP) voltage on switching card A2 with respect to TB1-2 as indicated:

Vacuum (in. wg)	Voltage at test points	
	TP-M	TP-G
0	25 ± 2	< 1
1.2	9.3 ± 3.5	< 1
1.45	< 1	< 1
1.70	< 1	9.3 ± 3.5
2.5	< 1	25.3 ± 2

● = TP (TEST POINT)




Was the specified voltage obtained in all cases?

No



Set POWER switch OFF. Replace the switching card A2 (p 2-176). Remove jumpers. Reinstall power card A1. Set POWER switch ON. Repeat test on page 2-68.

Yes


Proceed to page 2-131.




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).




2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).





2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



2-7. CCM TROUBLESHOOTING PROCEDURES (Cont).



Section II. MAINTENANCE PROCEDURES FOR M12 PROTECTIVE ENTRANCE

2-8. Scope.

a. This section contains repair procedures for component parts of the M 12 protective entrance.

b. Disassemble only as necessary to gain access to desired components.

c. Illustrations are configured to show access to the specific components being addressed and may not show the true position of the item or items being maintained or disassembled.

d. Identify wiring prior to unsoldering connection to simplify reassembly.

2-9. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Disassembly
- b. Repair
- c. Reassembly

- d. Removal
- e. Installation

Tools

Electronic Equipment Tool
Kit TK-105/G (SC 5180-91-CL-R07)

Troubleshooting References
Refer to page 2-2.

References

TB SIG 222

Equipment Condition


PECM removed from the protective entrance.

LOCATION	ITEM	ACTION
----------	------	--------

DISASSEMBLY

Protective entrance control module

1. Remove twelve screws (1) from panel (2).
2. Carefully pull panel (2) away from housing (3).



REPAIR

Gasket

Replace gasket (4) if defective.

REASSEMBLY


Protective entrance control module

1. Place panel (2) on housing (3) and secure with twelve screws (1).

2-9. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION




REMOVAL

1. Disassemble PECM (page 2-137).
2. Remove three screws (1) and wires (2) from toggle switch (3).
3. Remove nut (4) and washer (5).
4. Remove toggle switch (3) and keying washer (6).

INSTALLATION

1. Install keying washer (6) on toggle switch (3).
2. Insert toggle switch in panel and secure with washer (5) and nut (4).
3. Attach wires (2) to toggle switch using three screws (1). Refer to page 2-142.
4. Reassemble PECM (page 2-137).

REMOVAL/INSTALLATION



REMOVAL

1. Disassemble PECM (page 2-137).
2. Unsolder wires from LOW PRESSURE switch/indicator light (1).
3. Pry out lamp module (2).
4. Remove two screws (3) and two lamps (4).
5. Remove sleeve (5) from back of panel (6) and pull LOW PRESSURE switch/indicator light (1) from front of panel (6).

INSTALLATION

1. Insert LOW PRESSURE switch/indicator light (1) in panel.
2. Place sleeve (5) over LOW PRESSURE switch/indicator light and secure with screws (3). Install lamps (4).
3. Press lamp module (2) into LOW PRESSURE switch/indicator light.
4. Connect and solder wires to LOW PRESSURE switch/indicator light. Refer to page 2-142.
5. Reassemble PECM (page 2-137).


2-9. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Panel

PURGE indicator light



REMOVAL

1. Disassemble PECM (page 2-137).
2. Remove insulating tubing and unsolder wires from PURGE indicator light (1).
3. Unscrew knurled lens (2) and nut (3),
4. Remove washer (4) and PURGE indicator light (1).
5. Remove lamp (5) from PURGE indicator light.


INSTALLATION

1. Install lamp (5) in PURGE indicator light (1).
2. Insert PURGE indicator light in panel and install washer (4) and nut (3).
3. Install knurled lens (2).
4. Place insulating tubing over wires.
5. Connect and solder wires to PURGE indicator light. Refer to page 2-142.
6. Reassemble PECM (page 2-137).

REMOVAL/INSTALLATION

Panel

TIMER switch



REMOVAL

1. Disassemble PECM (page 2-137).
2. Remove two screws (1) and two washers (2) from TIMER switch (3). Remove wires (4).
3. Loosen setscrew and remove knob (5).
4. Remove nut (6) and washer (7) from TIMER switch (3).
5. Remove TIMER switch (3).

INSTALLATION


1. Install TIMER switch (3) in panel using washer (7) and nut (6).
2. Position knob (5) on shaft of TIMER switch with pointer at the zero mark on panel.
3. Tighten setscrew in knob.
4. Install wire leads (4) on TIMER switch using washers (2) and screws (1). Refer to page 2-142.
5. Reassemble PECM (page 2-137).

2-9. Protective ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Panel



1. Disassemble PECM (page 2-137).
2. Remove two screws (1) from toggle switch (2) and - release wires (3).
3. Remove three screws (4), nonmetallic washers (5), and nuts (6).
4. Remove one screw (7), washers (8 and 9), nuts (10 and 11), and wire (12).
5. Remove dome light (13) and gasket (14).

REPAIR

Gasket

Fabricate gasket (fig D-1, app D).

INSTALLATION


Dome light

1. Install gasket (14) and dome light (13) in panel using three screws (4), washers (5) and nuts (6).
2. Install wire lead (12) on one screw (7) and secure with washers (8 and 9) and nuts (10 and 11). Install wire leads (3) on toggle switch (2) using two screws (1). Refer to page 2-142.
3. Reassemble PECM (page 2-137).

REMOVAL/INSTALLATION

Housing

Switching card



REMOVAL

1. Disassemble PECM (page 2-137).
2. Remove screw (1) and washers (2 and 3).
3. Lift switching card (4) slightly and pull from socket.

INSTALLATION

1. Insert switching card (4) into socket in housing.
2. Secure switching card with screw (1) and washers (2 and 3).
3. Reassemble PECM (page 2-137).


2-9. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cent).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Housing

Power card



REMOVAL

1. Disassemble PECM (page 2-137).
2. Remove screw (1) and washers (2 and 3).
3. Lift power card (4) slightly and pull from socket.


INSTALLATION

1. Insert power card (4) into socket in housing.
2. Secure power card (4) with screw (1) and washers (2 and 3).
3. Reassemble PECM (page 2-137).

REMOVAL

Housing

Pressure transducer



1. Disassemble PECM (page 2-137).
2. Remove connector plug (1) from pressure transducer (2).
3. Remove tubing (3).
4. Remove two screws (4), washers (5), and nuts (6).
5. Remove pressure transducer (2).

REPAIR

Nonmetallic tubing

Fabricate replacement tubing (3) from NSN 9330-01-073-1011 stock. Cut to same length as tubing being replaced.

INSTALLATION

Pressure transducer


1. Place transducer (2) in housing and secure with two screws (4), washers (5), and nuts (6).
2. Install tubing (3).
3. Connect plug (1) to transducer.
4. Reassemble PECM (page 2-137).

2-9. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).


LOCATION	ITEM	ACTION
----------	------	--------

REPAIR

Protective entrance control Wiring module



CONT. ON PAGE 2-143.



CONT. ON PAGE 2-143.


- LEGEND**
- DS2 - LIGHT
 - DS3 - INDICATOR LIGHT
 - DS4 - INDICATOR LIGHT
 - S3 - SWITCH
 - S4 - TIMER
 - S5 - SWITCH
 - P13 - CONNECTOR
 - J20 - CONNECTOR
 - J21 - CONNECTOR
 - XA1 - CONNECTOR
 - XA3 - CONNECTOR
 - TB1 - TERMINAL BOARD
 - GRD - GROUND

2-9. PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REPAIR (Cont)

Protective entrance control Wiring module



Section III. MAINTENANCE PROCEDURE FOR M56 GAS-PARTICULATE FILTER UNIT

2-10. General.

- a. This section contains repair procedures for component parts of the M56 Gas-particulate Filter Unit,
- b. Disassemble only as necessary to gain access to desired components.

c. Illustrations are configured to show access to the specific components being addressed and may not show the true position of the item or items being maintained or disassembled.

2-11. MAIN FAN - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Disassembly
- c. Installation
- d. Reassembly

INITIAL SETUP

Troubleshooting References
Refer to page 2-32.

Equipment Condition
Main fan removed from filter unit.

Tools
General mechanics tool kit SC 5180-90-CL-N26
Puller kit 5120-00-289-9597

Torque wrench 5120-00-247-2536
Micrometer depth gage 5210-00-619-4045
Arbor press 3444-00-243-2655
(or equivalent)


Materials
Coating, aliphatic polyurethane (item 3, app C)
Dry cleaning solvent (item 4, app C)
Grease (item 5, app C)

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Main Fan

Identification plate



REMOVAL

1. Lift edge of plate (1) with a sharp tool.
2. Pull plate completely off the mounting surface.

INSTALLATION

1. Thoroughly clean mounting surface with dry cleaning solvent (item 4, app C). Mounting surface must be free of all contamination such as oil, grease, dirt, or any foreign matter.
2. Activate the back of the plate with dry cleaning solvent (item 4, app C).
3. Mount plate (1) and apply pressure to the plate surface.
4. Spray or brush plate with aliphatic polyurethane coating (item 3, app C).

2-11. MAIN FAN - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------


REMOVAL

Main Fan

Bearings

I Disassemble main fan.

DISASSEMBLY



1. Remove six screws (1) and washers (2).
2. Remove impeller cover (3) from fan housing (4).

3. Remove impeller nut (5) and washer (6).
4. Remove impeller (8).
5. Remove woodruff key (7).
6. Remove shim (9).
7. Remove four screws (10), bearing retainer plate (11), and bushing (12).

CAUTION

When removing the motor cover (15) from the fan housing (4), use care not to pull the stator electrical wires from ground.

8. Remove six screws (13) and washers (14).
9. Carefully remove motor cover (15) from fan housing (4). Slide the motor cover (15) back onto the electrical cable.

NOTE

Use care not to lose loading spring washer (16), as it will fall free when the motor cover is removed from the fan housing.

2-11. MAIN FAN - MAINTENANCE INSTRUCTIONS (Cont).


LOCATION	ITEM	ACTION
----------	------	--------

DISASSEMBLY (Cont)

Main fan

CAUTION

Use care not to damage the rotor or nick rotor shaft journals when pressing rotor from bearing.



- Using an arbor press, press rotor (17) from bearing (18) and out of fan housing (4).
- Press bearing (18) from fan housing (4).

CAUTION

Use care not to damage the rotor or nick shaft journals when removing the bearing.

- Remove bearing (19) from rotor (17) shaft using a standard bearing puller,


NOTE

Use care not to lose deflector (20). It will fall free when bearing is removed.

INSTALLATION

Rotor shaft

Bearing




- Install deflector (20) on rotor shaft. Press a new bearing (19) on the rotor (17) shaft (use an arbor press). Make sure the bearing is flush against the deflector and shaft shoulder.

2-11. MAIN FAN - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

INSTALLATION (Cont)


Rotor shaft



2. Install the rotor (17) in the fan housing (4).
3. Stand the fan housing on end with rotor shaft supported, and press a new bearing (18) on the input end of the rotor shaft, flush against the shaft shoulder.
4. Fill cavity of bearings (18 and 19) half full of grease (item 5, app C).

REASSEMBLY

Main fan



1. Install loading spring washer (16) on the end of rotor shaft and press against the bearing with the fingers.
2. Position the motor cover in place on the fan housing (4). Work stator cable through rubber gromment (21) to remove slack while positioning. Seat bearing and loading spring washer in motor cover,

CAUTION

Make sure loading spring washer remains in place on the rotor shaft and bearing is fully seated before tightening screws.

3. Install six screws (13) and washers (14) in motor cover.
4. Install bearing retainer plate (11) with four screws (10) and torque to 20-23 inch-pounds,


2-11. MAIN FAN - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REASSEMBLY (Cont)

Main fan

5. Check the contour fit between the fan impeller and the impeller cover.



6. Position the fan housing (4) vertically with input end up.
7. Install bushing (12) on rotor shaft.
8. Install the fan impeller (8) on the rotor shaft without the woodruff key. Do not install self locking nut.
9. Install the impeller cover (3) on the fan housing and secure with two screws (1) and two washers (2) 180 degrees apart.


NOTE

The fan impeller must be firmly seated against the bushing on the rotor shaft in order to obtain an accurate reading for dimension "A".

DI MENS I ON " A "
FAN I MPELLER
F I R M L Y
S E A T E D
A G A I N S T
S P A C E R .

DI MENS I ON " B "
FAN I MPELLER
S E A T E D
A G A I N S T
I MPELLER
C O V E R .

10. With the fan impeller against bushing, use a 2 inch depth micrometer with two parallel bars (1/2 inch by 1 inch by 8 inches). Measure the distance from the top of the parallel bars to the machined surface on the fan impeller as shown. Record as dimension "A".



NOTE

The fan impeller must be firmly seated against the impeller cover to obtain an accurate reading for dimension "B".

I MPELLER GAGE DIAMETER. (ADD SHIMS BETWEEN I MPELLER AND S P A C E R TO OBTAIN 0.007 TO 0.012 I NCH AXIAL C L E A R A N C E BETWEEN FAN I MPELLER AND I MPELLER C O V E R .)

11. Pull up on the fan impeller to seat against the impeller cover and take a second measurement using the same technique as in step 10 and record as dimension "B".

2-11. MAIN FAN - MAINTENANCE INSTRUCTIONS (Cont).



LOCATION	ITEM	ACTION
----------	------	--------

REASSEMBLY (Cont)

Main Fan

Example

1.152 inches	(Dimension "A")
-1.086 inches	(Dimension "B")
<hr/>	
0.066 inch	(Dimension "C")
-0.010 inch	(Nominal)
<hr/>	
0.056 inch	(Dimension "D")



LOCATION OF INSTALLATION HOLES (WITH STATOR CABLE ON OUTPUT END AT 6 O' CLOCK POSITION)

IMPELLER COVER VIEWED FROM INPUT END

12. Subtract dimension "B" from dimension "A" as recorded in steps 10 and 11, the difference being dimension "C". (See example below.)
13. Subtract a nominal 0.010 inch from dimension "C" and record as dimension "D". Dimension "D" is the required shim thickness for shim to obtain 0.007 to 0.012 inch axial clearance between the fan impeller and the impeller cover.
14. Remove impeller cover and impeller.
15. Peel laminated shims (9) to required thickness determined by dimension "D" to obtain the proper spacing.
16. Install shims (9) on rotor shaft.
17. Install woodruff key (7) in rotor shaft and install fan impeller (8).
18. Install washer (6) and lock nut (5).
19. Torque lock nut (5) to 95 to 110 inch-pounds.
20. Turn rotor counterclockwise to check that bearings are free.
21. With the stator electric cable positioned in the 6 o'clock position, install the impeller cover (3) with the installation locating holes located in the 3 o'clock and 9:30 positions.
22. Install six washers (2) and screws (1).

2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Installation

INITIAL SETUP

Tools

Electronic Equipment Tool
Kit TK-105/G (SC 5180-91-CL-R07)

Equipment Condition

Airflow valve removed from filter unit or airflow valve removed from airflow valve and silencer.

References

TB SIG 222

NOTE

Perform all electrical connections in accordance with wiring diagram on page 2-160.

Troubleshooting References

Refer to page 2-33.

LOCATION	ITEM	ACTION
----------	------	--------


REMOVAL/INSTALLATION

REMOVAL

Airflow Valve

Motor with radio noise filter

1. Remove nut (1) and screw (2) from GRD 4 terminal lug (3)
2. Tag and unsolder wires (4 and 5) from FL2 radio noise filter (6).
3. Cut cable strap (7). Remove nut (8), screw (9) and cable strap (7).
4. Remove two nuts (10) and screws (11).




2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION (Cont)


Airflow Valve

Motor with radio noise filter



5. Loosen setscrew (12) and remove gear (13).
6. Remove four nuts (14) and screws (15).
7. Remove motor (16) and FL2 radio noise filter (6) as a unit.
8. Remove screw (17), washer (18), and grounding wire (19).

INSTALLATION



1. Install grounding wire (19) on motor (16) with washer (18) and screw (17).
2. Install motor (16) in airflow valve (20) using four screws (15) and nuts (14).
3. Install gear (13) on shaft of motor (16). Tighten setscrew (12).
4. Install FL2 radio noise filter (6) and grounding wire (19) in airflow valve (20) using screws (11) and nuts (10).


2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION (Cont)

Airflow Valve

Motor with radio noise filter




5. Install screw (2), GRD 4 terminal lug (3), and nut (1).
6. Observing the wiring diagram on page 2-160, solder the tagged wires (4 and 5) to lugs on FL2 radio noise filter (6).
7. Bring cabling between motor (16) and FL2 radio noise filter (6) together and install cable strap (7), screw (9), and nut (8).

REMOVAL/INSTALLATION

Airflow Valve

Radio noise filter



REMOVAL

1. Cut and remove cable ties (1 thru 5) and separate the wires.
2. Tag and unsolder one pair of wires (6) from FL1 radio noise filter (8) negative (-) terminal.
3. Tag and unsolder one pair of wires (7) from FL1 radio noise filter (8) positive (+) terminal.
4. Remove two screws (9) and nuts (10). Place FL1 radio noise filter (8) inside the airflow valve.



2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION (Cont)

Airflow Valve

Radio noise filter



5. Cut cable strap (11). Remove nut (12), screw (13), and cable strap (11).

6. Remove nut (14), screw (15), and two grounding terminal lugs (16 and 17) from GRD 2.

7. Tag and unsolder wire (18) from normally closed (NC) terminal on switch (S2).

8. Cut cable strap (19). Remove nut (20), screw (21), and cable strap (19).

9. Remove nut (22), screw (23), and grounding lug (24) from GRD 3.

10. Tag and unsolder wire (25) from normally closed (NC) terminal on switch (S1).

11. Remove FL1 radio noise filter (8) from airflow valve (26).

NOTE


Be sure to keep the old filter. It will be used as a pattern for installing a new filter.

2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------


REMOVAL/INSTALLATION (Cont)

Airflow Valve Radio noise filter



INSTALLATION

1. Using the old radio noise filter as a pattern, cut and tag wires on new filter and install ground terminal lugs on the shielding of both wires.
2. Mount radio noise filter (8) in airflow valve (26) using two screws (9) and nuts (10).



NOTE

Place FL1 radio noise filter wires over the flange of the airflow valve.

3. Observing the wiring diagram on page 2-160 solder the tagged wires (6 and 7) to lugs on FL1 radio noise filter (8).





2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATI ON	ITEM	ACTI ON
-----------	------	---------

REMOVAL/INSTALLATION (Cont)

Airflow Valve

Radio noise filter



4. Place wires (18 and 25) in position in the airflow valve (26),
5. Solder wire (18) to normally closed (NC) terminal on switch (S2).
6. Install grounding lugs (16 and 17), using screw (15) and nut (14).
7. Install cable strap (11) using screw (13) and nut (12). Secure the wires within the cable strap.

8. Solder wire (25) to normally closed (NC) terminal on switch (S1),
9. Install grounding lug (24) using screw (23) and nut (22).
10. Install cable strap (19) using screw (21) and nut (20). Secure the wires within the cable strap.


2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Airflow Valve

Diode and capacitor on switch (S1)



REMOVAL

1. Unsolder diode (1) from normally closed (NC) and from normally open (NO) terminals on switch (S1).
2. Unsolder capacitor (2) from normally closed (NC) and from common (C) terminals on switch (S1).

INSTALLATION

1. Cut and bend leads of diode (1) and capacitor (2) using the old parts as a pattern.
2. Solder diode (1) leads to normally closed (NC) and to normally open (NO) terminals on switch (S1).
3. Solder capacitor (2) leads to normally closed (NC) and common (C) terminals on switch (S1).


2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Airflow Valve

Switch (S1) and adapter

**REMOVAL**

1. Tag and unsolder wire (1) from normally closed (NC) terminal on switch (S1).
2. Tag and unsolder wire (2) from common (C) terminal on switch (S1).
3. Remove two nuts (3) and screws (4).
4. Remove switch (S1) and adapter (5).

INSTALLATION

1. Install switch (S1) and adapter (5) using two screws (4) and nuts (3).
2. Cut and bend leads of capacitor (6) to fit between normally closed (NC) and common (C) terminals of switch (S1).
3. Cut and bend leads of diode (7) to fit between normally closed (NC) and normally open (NO) terminals of switch (S1).
4. Solder wire (1), one end of capacitor (6), and one end of diode (7) to normally closed (NC) terminal of switch (S1).
5. Solder wire (2) and one end of capacitor (6) to common (C) terminal of switch (S1).
6. Solder one end of diode (7) to normally open (NO) terminal of switch (S1).


2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Airflow Valve

Diode and capacitor on switch (S2)



REMOVAL

1. Unsolder diode (1) from normally closed (NC) and from normally open (NO) terminals on switch (S2).
2. Unsolder capacitor (2) from normally closed (NC) and from common (C) terminals on switch (S2).

INSTALLATION

1. Cut and bend leads of diode (1) and capacitor (2) using the old parts as a pattern.
2. Solder diode (1) leads to normally closed (NC) and to normally open (NO) terminals on switch (S2).
3. Solder capacitor (2) leads to normally closed (NC) and to common (C) terminals on switch (S2).




2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Airflow Valve

Switch (S2) and adapter



REMOVAL

1. Tag and unsolder wire (1) from normally closed (NC) terminal on switch (S2).
2. Tag and unsolder wire (2) from common (C) terminal on switch (S2).
3. Remove two nuts (3) and screws (4).
4. Remove switch (S2) and adapter (5).

INSTALLATION

1. Install switch (S2) and adapter (5) using two screws (4) and nuts (3).
2. Cut and bend leads of capacitor (6) to fit between normally closed (NC) and common (C) terminals of switch (S2).
3. Cut and bend leads of diode (7) to fit between normally closed (NC) and normally open (NO) terminals of switch (S2).
4. Solder wire (1), one end of capacitor (6), and one end of diode (7) to normally closed (NC) terminal of switch (S2).
5. Solder wire (2) and one end of capacitor (6) to common (C) terminal of switch (S2).
6. Solder one end of diode (7) to normally open (NO) terminal of switch (S2).


2-12. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REPAIR

Airflow Valve

Wiring



LEGEND

- GRD1 - GROUND
- GRD2 - GROUND
- GRD3 - GROUND
- GRD4 - GROUND
- B1 - GEAR MOTOR
- C1 - CAPACITOR
- C2 - CAPACITOR
- CR1 - DIODE
- CR2 - DIODE
- FL1 - FILTER
- FL2 - FILTER
- J15 - CONNECTOR
- S1 - CLOSED LIMIT SWITCH
- S2 - OPEN LIMIT SWITCH
- TP12 - TEST POINT
- TP11 - TEST POINT

2-13. POWER DISTRIBUTION UNIT - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Installation

INITIAL SETUP

Troubleshooting References
Refer to page 2-39.

Equipment Condition
Power distribution unit removed from the filter unit.

Tools

Electronic Equipment Tool
Kit TK-105/G (SC 5180-91-CL-R07)

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION


Power Distribution Unit Panel

REMOVAL

1. Remove twelve screws (1) and separate panel (2) from housing (3).
2. Remove gasket (4) from housing (3).

INSTALLATION

1. Install gasket (4) on housing (3) with screw holes aligned.
2. Install panel (2) on housing using twelve screws (4).



2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Repair
- c. Installation

INITIAL SETUP

Materials

Insulation sleeving item 6, app C)

Troubleshooting References

Refer to page 2-39,

Tools

Electric Equipment Tool Kit TK-105/G (SC 5180-91-CL-R07)

Equipment Condition


Power distribution panel removed from distribution unit. Refer to page 2-161.

References

TB SIG 222

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION



REMOVAL

1. Remove six screws (1), washers (2), and wires (3) from circuit breaker (4).
2. Unsolder wires from C and NO contacts (5) on circuit breaker.
3. Remove four screws (6) and remove fan circuit breaker (5).

INSTALLATION


Observe the orientation of the numbers on the push button.

1. Insert fan circuit breaker (4) in panel and secure with four screws (6).
2. Solder wires to C and NO contacts of circuit breaker. Refer to page 2-169.
3. Install wires on six electrical terminal using six screws (1) and washers (2).

2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION



REMOVAL


1. Remove two screws (1), washers (2), and wires (3) from circuit breaker (4).
2. Unscrew waterproof boot (5).
3. Remove circuit breaker and keying washer (6).

INSTALLATION

1. Place keying washer (6) on circuit breaker (4).
2. Insert circuit breaker in panel and secure with waterproof boot (5).
3. Connect wires using screws (1) and washers (2). Refer to page 2-169.

REMOVAL/INSTALLATION

Power Distribution Panel 208 v indicator light



REMOVAL

1. Remove insulation and unsolder connections from indicator light (1).
2. Unscrew knurled ring (2) and remove indicator light.

INSTALLATION


1. Insert 208 v indicator light (1) in panel and secure with knurled nut (2).
2. Place insulation sleeving (item 6, app C) over wire leads.
3. Solder wire leads to 208 v indicator light. Refer to page 2-169.
4. Place insulation sleeving (item 6, app C) over connection and shrink.

2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Power Distribution Panel	RFI filter	<ol style="list-style-type: none"> 1. Remove five nuts (1), lockwashers (2), and washers (3) from filter terminals and release wiring (4). 2. Unscrew nut (5). 3. Unscrew four screws (6) and remove radio noise filter. 4. Remove preformed packing (7) from radio noise filter (8).
--------------------------	------------	---



REPAIR

Preformed packing

Replace preformed packing (7) if unserviceable.


INSTALLATION

Power Distribution Panel	RFI filter	<ol style="list-style-type: none"> 1. Place preformed packing (7) on radio noise filter (8). 2. Install radio noise filter in panel using four screws (6) and nut (5). 3. Connect electrical wiring to the seven connectors. Refer to page 2-169.
--------------------------	------------	--

2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

Power Distribution Panel Pressure switch



1. Pinch ears of hose clamps (1) and remove tubing (2 and 3) from pressure switch (4).
2. Loosen clamps (5) if necessary to remove tubes.
3. Disconnect electrical connector from pressure switch and remove switch.

REPAIR

Nonmetallic tubing

1. Fabricate replacement tubing (2 or 3) from NSN 9330-01-073-1011 stock. Cut to same length as tubing being replaced.

INSTALLATION

Pressure switch

1. Connect wire connector to pressure switch (4).
2. Position pressure switch between tubing (2 and 3) with switch terminals pointing toward transformer/rectifier and "LOW" and "HIGH" marking away from panel.
3. Install tube (3) on the "LOW" side of the switch and tube (2) on the "HIGH" side.
4. Position clamps (1) within 1/4 inch of switch body.

2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS (Cont).


LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Power Distribution Panel	Transformer/rectifier	
--------------------------	-----------------------	--

REMOVAL

1. Remove four screws (1) from transformer/rectifier (2) and remove wires.
2. Remove four screws (3), washers (4), and nuts (5) and remove transformer/rectifier.



INSTALLATION

1. Position transformer/rectifier (2) on panel.
2. Secure to panel using four screws (3), washers (4), and nuts (5).
3. Install wires using four screws (1). Refer to page 2-169,

2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS (Cont).


LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Power Relay	Diode (CR5)
Power Distribution Panel	Power relay

REMOVAL

1. Remove nuts (1) and washers (2).
2. Remove diode (3) from power relay (4).
3. Remove six nuts (5) and washers (6) from power relay and remove wires (7 and 8).
4. Remove four nuts (9), washers (10), and screws (11).
5. Remove power relay.



INSTALLATION

Power Distribution Panel	Power relay
Power Relay	Diode (CR5)


1. Position power relay (4) on panel.
2. Attach with four screws (11), washers (10), and nuts (9).
3. Install wires (7) on terminals XI and X2 of power relay. Refer to page 2-169.
4. Install diode (3) between terminal XI and X2 of the power relay. Ensure that the end is installed on terminal X2. Secure with washers (2) and nuts (1).
5. Install wires (8) and secure with washers (6) and nuts (5). Refer to page 2-169.

2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Power Distribution Panel Printed circuit assembly



REMOVAL

1. Unsolder wires from auxiliary switching printed circuit assembly (1).
2. Remove two nuts (2), washer (3), cable strap (4), and two screws (5).
3. Remove auxiliary switching printed circuit assembly.

INSTALLATION


1. Position printed circuit board (1) on bracket and install screws (5).
2. Install cable strap (4) and nut (2) on one screw. Install washer (3) and nut (2) on the other.
3. Connect and solder wires to printed circuit assembly. Refer to wiring diagram on page 2-169.

2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS (Cont).

LOCATOIN ITEM ACTION

REPAIR

Power Distribution Panel Wiring




2-14. POWER DISTRIBUTION PANEL - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REPAIR (Cont)

Power Distribution Panel Wiring



LEGEND

- | | |
|---------------------------|---------------------------|
| A5 - PRINTED CIRCUIT CARD | J4 - CONNECTOR |
| CB1 - CIRCUIT BREAKER | J5 - CONNECTOR |
| CB2 - CIRCUIT BREAKER | J6 - CONNECTOR |
| CB3 - CIRCUIT BREAKER | J7 - CONNECTOR |
| CB4 - CIRCUIT BREAKER | JUNC - INSULATED JUNCTION |
| CB5 - DIODE | K1 - FAN RELAY |
| DS1 - INDICATOR | R1 - RESISTOR |
| FL3 - FILTER | S7 - PRESSURE SWITCH |
| GRD - GROUND | T1 - TRANSFORMER |
| J2 - CONNECTOR | TB1 - TERMINAL BOARD |
| J3 - CONNECTOR | TP - TEST POINT |

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Disassembly
- b. Repair
- c. Reassembly
- d. Removal
- e. installation

INITIAL SETUP

Troubleshooting Reference
Refer to page 2-63.

Tools
Electronic Equipment Tool
Kit TK-105/G (SC 5180-91-CL-R07)

Equipment Condition
Compartment control module removed from shelter


References
TB SIG 222

LOCATION	ITEM	ACTION
----------	------	--------

DISASSEMBLY

Compartment control module

1. Remove eight screws (1).
2. Pull panel (2) away from housing (3).



REPAIR

Gasket

Replace gasket (4) if defective.

REASSEMBLY

Compartment control module

Position panel (2) on housing (3) and secure with eight screws (1).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------


REMOVAL/INSTALLATION

Housing

Pressure switch

REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove screw (1) and washer (2).
3. Pinch ears of clamps (3 and 4) and pull tubes from pressure switch (5).
4. Carefully remove connectors (6) from pressure switch (5).



INSTALLATION

1. connect pressure switch (5) (tap marked LOW) to tube (7).
2. connect pressure switch (5) (tap marked HIGH) to tube (8).
3. Install hose clamps (3 and 4) and electrical connectors (6).
4. Reassemble CCM (p 2-171).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).


LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL

Housing

Pressure transducer

1. Disassemble CCM (p 2-171).
2. Remove connector (1) from pressure transducer (2).
3. Pull tubing (3) from pressure transducer (2).
4. Remove two screws (4) and remove pressure transducer (2).



REPAIR

Nonmetallic tubing

Fabricate replacement tubing (3) from NSN 9330-01-073-1011 stock. Cut to same length as tubing being replaced.

INSTALLATION

Pressure transducer

1. Install pressure transducer (2) using two screws (4).

CAUTION


When installing rubber tubes, be sure that the tube from the pressure switch is connected to the hose connector marked Pr on the pressure transducer and that the other tube is connected to the hose connector marked Px on the pressure transducer.

2. Connect tubing (3) to pressure transducer (2).
3. Connect connector (1) to connector (5).
4. Reassemble CCM (p 2-171).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION




REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove screws (1) and washer (2).
3. Pull power card (3) from its socket.

INSTALLATION

1. Insert power card (3) into connector.
2. Secure power card (3) with screw (1) and washer (2).
3. Reassemble CCM (p 2-171).

REMOVAL/INSTALLATION



REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove four nuts (1) and screws (2).
3. Remove two battery retainers (3).
4. Unsolder and remove four batteries (4).

INSTALLATION

1. Solder connections on four warning system batteries (4), Refer to page 2-184.
2. Install and secure the four batteries (4) using two retainers (3), four screws (2), and four nuts (1).
3. Reassemble CCM (p 2-171).


2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Panel

Printed circuit assembly
(auxiliary switching)



REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove two screws (1), nuts (2), and washers (3).
3. Unsolder wires and remove auxiliary switching printed circuit assembly (4).

CAUTION

Apply needle-nose pliers to the leads of the diodes connected between terminals 1 and 2, 3 and 8, and 7 and 8 to form a heat sink during soldering of these terminals. This is done to prevent heat damage to the diodes. Use care to apply only enough heat as necessary to form a good solder joint. This applies to all terminals.


INSTALLATION

1. Connect and solder wires to auxiliary switching printed circuit assembly (4). Refer to page 2-184.
2. Place auxiliary switching printed circuit assembly (4) on bracket (5) and attach using screws (1), washers (3), cable bracket (6), and nuts (2).
3. Reassemble CCM (p 2-171).

REMOVAL/INSTALLATION

Housing

Flasher



REMOVAL

1. Disassemble CCM (p 2-171).
2. Unsolder wires from flasher (1).
3. Remove two screws (2), nuts (3), and washers (4).
4. Remove flasher (1).


INSTALLATION

1. Install flasher (1) using two screws (2), washers (4), and nuts (3).
2. Connect and solder wires. Refer to page 2-184.
3. Reassemble CCM (p 2-171).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION




REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove screw (1) and washer (2).
3. Pull out switching card (3).

INSTALLATION

1. Insert switching card (3) into connector.
2. Secure switching card (3) with screw (1) and washer (2).
3. Reassemble CCM (p 2-171).

REMOVAL



1. Disassemble CCM (p 2-171).
2. Remove wires from warning horn (1).
3. Unscrew bezel (2) and remove warning horn (1) and gasket (3).

REPAIR

Gasket

Fabricate gasket (fig D-2, app D).

INSTALLATION


Audible signal (warning horn)

1. Insert warning horn (1) with gasket (3) in panel (4), and secure with bezel (2).
2. Connect wire leads. Refer to page 2-184.
3. Reassemble CCM (p 2-171).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION




REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove insulation and unsolder wires from terminal on DUST FAN DEFECT indicator light (1).
3. Remove knurled ring (2), nuts (3), and washer (4) from light (1).

INSTALLATION

1. Insert DUST FAN DEFECT indicator light (1) in panel (5) and secure with washer (4) and nut (3).
2. Install knurled ring (2).
3. Connect and solder wire leads. Refer to page 2-184.
4. Reassemble CCM (p 2-171).

REMOVAL/INSTALLATION



REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove insulation and unsolder wires from terminals on CHANGE FILTER indicator light (1).
3. Remove knurled ring (2), nut (3), and washer (4) from light (1).

INSTALLATION

1. Insert CHANGE FILTER indicator light (1) in panel (5) and secure with washer (4) and nut (3).
2. Install knurled ring (2).
3. Connect and solder wire leads. Refer to page 2-184.
4. Reassemble CCM (p 2-171).


2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Panel

INDICATORS circuit breaker



REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove wire leads from INDICATORS circuit breaker (1).
3. Unscrew and remove waterproof boot (2).
4. Remove circuit breaker (1) and keying washer (3).


INSTALLATION

1. Insert INDICATORS circuit breaker (1) with keying washer (3) in panel (4) and secure with waterproof boot (2).
2. Connect wire leads. Refer to page 2-184,
3. Reassemble CCM (p 2-171).

REMOVAL/INSTALLATION

Panel

ENTRANCE PRESSURE circuit breaker



REMOVAL

1. Disassemble CCM (p 2-171),
2. Remove wire leads from ENTRANCE PRESSURE circuit breaker (1).
3. Unscrew and remove waterproof boot (2),
4. Remove circuit breaker (1) and keying washer (3).

INSTALLATION


1. Insert ENTRANCE PRESSURE circuit breaker (1) with keying washer (3) in panel (4) and secure with waterproof boot (2).
2. Connect wire leads. Refer to page 2-184.
3. Reassemble CCM (p 2-171).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Panel




REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove wire leads from COMPARTMENT PRES-SURE circuit breaker (1).
3. Unscrew and remove waterproof boot (2),
4. Remove circuit breaker (1) and keying washer (3).

INSTALLATION

1. Insert COMPARTMENT PRESSURE circuit breaker (1) with keying washer (3) in panel (4) and secure with waterproof boot (2),
2. Connect wire leads. Refer to page 2-184,
3. Reassemble CCM (p 2-171).

REMOVAL/INSTALLATION



REMOVAL

1. Disassemble CCM (p 2-171).
2. Remove wire leads from MAIN FAN circuit breaker (1).
3. Unscrew and remove waterproof boot (2).
4. Remove circuit breaker (1) and keying washer (3).

INSTALLATION


1. Insert MAIN FAN circuit breaker (1) with keying washer (3) in panel (4) and secure with waterproof boot (2).
2. Connect wire leads. Refer to page 2-184.
3. Reassemble CCM (p 2-171).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

Panel OCCUPIED switch/
indicator light



REMOVAL

1. Disassemble CCM (p 2-171).
2. Unsolder wire leads from OCCUPIED switch/indicator light (1),
3. Pry out and remove the lamp module (2).
4. Remove two screws (3).
5. Remove sleeve (4) and switch/indicator light (1).

INSTALLATION

NOTE

Lamp module is keyed to fit into light body at only one rotational position. It may be necessary to turn the lamp module within the light body to find the keyway.

1. Place module (2) in OCCUPIED switch/indicator light (1) and position in panel (5) with the word OCCUPIED right side up and level.
2. Remove module (2). Place sleeve (4) over switch/indicator light (1) and secure with screws (3).
3. Replace module (2) in switch/indicator light (1).
4. Connect and solder wires. Refer to page 2-184.
5. Reassemble CCM (p 2-171).

REMOVAL/INSTALLATION

LOW PRESSURE switch/
indicator light

REMOVAL


1. Disassemble CCM (p 2-171).
2. Unsolder wire leads from LOW PRESSURE switch/indicator light (1).
3. Pry out and remove the lamp module (2).
4. Remove two screws (3).
5. Remove sleeve (4) and switch/Indicator light (1).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION (Cont)

INSTALLATION



NOTE

Lamp module is keyed to fit into light body at only one rotational position. It may be necessary to turn the lamp module within the light body to find the keyway.


1. Place module (2) in LOW PRESSURE switch/indicator light (1) and position in panel (5) with the words LOW PRESSURE right side up and level.
2. Remove module (2). Place sleeve (4) over switch/indicator light (1) and secure with screws (3).
3. Replace module (2) in switch/indicator light (1).
4. Connect and solder wires. Refer to page 2-184.
5. Reassemble CCM (p 2-171).

REMOVAL/INSTALLATION

REMOVAL

Panel

MASK switch/Indicator light



1. Disassemble CCM (p 2-171).
2. Unsolder wire leads from MASK switch/indicator light (1).
3. Pry out and remove lamp module (2).
4. Remove two screws (3).
5. Remove sleeve (4) and switch/indicator light (1).

INSTALLATION

NOTE


Lamp module is keyed to fit into light body at only one rotational position. It may be necessary to turn the lamp module within the light body to find the keyway.

1. Place module (2) in MASK switch/indicator light (1) and position in panel (5) with the word MASK right side up and level.
2. Remove module (2). Place sleeve (4) over switch/indicator light (1) and secure with screws (3).
3. Replace module (2) in switch/indicator light (1).
4. Connect and solder wires. Refer to page 2-184.
5. Reassemble CCM (p 2-171).


2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION



REMOVAL/INSTALLATION



R E M O V A L

CAUTION

When unsoldering diodes (1) from the switch solenoid terminals, apply needle-nose pliers to the leads of the diode to form a heat sink. Excessive heat will damage the diode.

1. Disassemble CCM (p 2-171).
2. Unsolder diodes (1) from HORN OFF switch (2).

INSTALLATION

CAUTION

Diodes must be connected properly or damage will result. Observe the banded end of the diodes. Apply needle-nose pliers to leads of diodes to form a heat sink when soldering. Excessive heat will damage the diodes.

1. Solder diodes (1) to HORN OFF switch (2) in accordance with wiring diagram (p 2-184).
2. Reassemble CCM (p 2-171).

REMOVAL

1. Disassemble CCM (p 2-171).
2. Unsolder wire leads and diodes from HORN OFF switch (1).
3. Remove nut (2) and switch (1).

INSTALLATION

1. Insert HORN OFF switch (1) in panel (3) and secure with nut (2).
2. Connect and solder wires and diodes to HORN OFF switch. Refer to page 2-184,
3. Reassemble CCM (p 2-171).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).


LOCATION	ITEM	ACTION
----------	------	--------

REMOVAL/INSTALLATION

REMOVAL

POWER toggle switch.

1. Disassemble CCM (p 2-171).
2. Remove wire leads from **POWER** toggle switch (1).
3. Remove nut (2), washer (3), and **POWER** toggle switch.



INSTALLATION


1. Insert **POWER** toggle switch (1) in panel (4) and secure with washer (3) and nut (2).
2. Connect electrical wires. Refer to page 2-184.
3. Reassemble CCM (p 2-171).

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REPAIR

Compartment Control Module Wiring



LEGEND

- | | |
|-----------------------|----------------------|
| CB5 - CIRCUIT BREAKER | CR6 - DIODE |
| CB6 - CIRCUIT BREAKER | CR4 - DIODE |
| CB7 - CIRCUIT BREAKER | A4 - CIRCUIT BOARD |
| CB8 - CIRCUIT BREAKER | LS1 - HORN |
| DS5 - INDICATOR | J1 - CONNECTOR |
| | P19 - CONNECTOR |
| DS7 - INDICATOR | XA1 - CONNECTOR |
| DS8 - INDICATOR | XA2 - CONNECTOR |
| DS9 - INDICATOR | TB1 - TERMINAL BOARD |
| CR5 - DIODE | TB2 - TERMINAL BOARD |
| DS11 - INDICATOR | K2 - RELAY |
| DS12 - INDICATOR | GRD - GROUND |
| S6 - SWITCH | B1 - BATTERY |
| S8 - SWITCH | B2 - BATTERY |
| S9 - SWITCH | B3 - BATTERY |
| S10 - SWITCH | B4 - BATTERY |
| S11 - SWITCH | |


(A) CONT. ON PAGE 2-185.

2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REPAIR (Cont)

Compartment Control Module Wiring




2-15. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (Cont).

LOCATION	ITEM	ACTION
----------	------	--------

REPAIR (Cont)

Compartment Control Module

Wiring



APPENDIX A
REFERENCES

The following publications are related to information contained in this manual.

A-1. TECHNICAL MANUALS

- TM 3-4240-286-20&P Organizational Maintenance Manual (Including Repair Parts and Special Tools List) for Collective Protection Equipment, Guided Missile Air Defense System, AN/TSQ-73; Consisting of Entrance, Protective, Pressurized, Collapsible, MI 2 (NSN 4240-01-048-2923); Filter Unit, Gas-Particulate, 200 CFM, 208 V, 400 HZ, M56 (NSN 4240-00-237-0227); and Installation Kit, CBR, Protective Equipment, AN/TSQ-73, M263 (NSN 4240-01-063-7679)
- TM 9-1430-651-12 Operator's and Organizational Maintenance Manual, Emplacement and Preparation for Travel, Guided Missile Air Defense System, AN/TSQ-73
- TM 38-750 The Army Maintenance Management System (TAMMS)
- TM 43-0002-31 Destruction of Chemical Weapons and Defense Equipment to Prevent Enemy Use

A-2. COMMON TABLE OF ALLOWANCES

- CTA 50-970 Expendable Items (Except Medical, Class V, Repair Parts and Heraldic Items)

A-3. SUPPLY BULLETIN

- SB 708-42 Federal Supply Code for Manufacturers; United States and Canada-Code to Name (Cataloging Handbook H4-2)

A-4. SUPPLY CATALOGS

- SC 5180-91-CL-R07 Tool Kit, Electronic Equipment TK-105/G
- SC 5180-90-CL-N26 Tool Kit, General Mechanics

A-5. TECHNICAL BULLETIN

- TB SIG 222 Solder and Soldering

APPENDIX B REPAIR PARTS AND SPECIAL TOOLS LIST

Section 1. INTRODUCTION

B-1. Scope. This appendix lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for the performance of direct support maintenance of the Collective Protection Equipment for the AN/TSQ-73. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

B-2. General. This Repair Parts and Special Tools List is divided into the following sections:

a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in National stock number (NSN) sequence.

b. *Section III. Special Tools List.* Not applicable.

c. *Section IV. National Stock Number and Part Number Index.* A list in National item identification number (NIIN, the last nine figures of the NSN) sequence, of all National stock numbers (NSNs) appearing in the listings, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

B-3. Explanation of Columns.

a. *Illustration.* This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. *Source, Maintenance, and Recoverability (SMR) Codes.*

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	<i>Definition</i>
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply system.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.

<i>code</i>	<i>Definition</i>
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at the direct support maintenance level.
AO	Item to be assembled at organizational level.
AF	Item to be assembled at direct support maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.
XD	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above, except those coded XA.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance.

<i>Code</i>	<i>Application/explanation</i>
C	Crew or operator maintenance performed within organizational maintenance.
O	Support item is removed, replaced, used at the organizational level.
F	Support item is removed, replaced, used at the direct support level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

<i>Code</i>	<i>Application/explanation</i>
O	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F	The lowest maintenance level capable of complete repair of the support item is the direct support level.
L	Repair restricted to specialized repair activity. Not applicable.
Z	Nonreparable. No repair is authorized.
B	No repair is authorized. The item maybe reconditioned by adjusting, lubricating, etc, at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

<i>Recoverability Code</i>	<i>Definition</i>
Z	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
O	Reparable item. When uneconomically repairable, condemn and dispose at organizational level.
F	Reparable item. When uneconomically repairable, condemn and dispose at the direct support level.
L	Reparable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.
A	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. *National/ Stock Number.* Indicates the National stock number assigned to the item and which will be used for requisitioning purposes.

d. *Federal Supply Code for Manufacturer (FSCM)*. The FSCM is a five-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

e. *Part Number*. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.

f. *Description*. Indicates the Federal item name and, if required, a minimum description to identify the item.

g. *Unit of Measure (U/M)*. Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. *Quantity Incorporated in Unit*. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable (e.g., shims, spacers, etc).

B-4. Special Information.

a. Useable On Codes are shown in the description column. Uncoded items are applicable to all models.

b. Detailed manufacturing instructions for items source coded to be manufactured or fabricated are found in maintenance portions of this manual. Bulk materials required to manufacturer items are listed in the Bulk Material Group of this appendix.

c. Detailed assembly instructions for items source coded to be assembled are found in the maintenance portions of this manual. Assembly components are listed immediately following the item to be assembled.

B-5. How to Locate Repair Parts.

a. When National Stock Number or Part Number is Unknown:

(1) *First*. Using the table of contents, determine the functional group with which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second*. Find the illustration covering the functional group to which the item belongs.

(3) *Third*. Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth*. Using the repair parts listing, find the figure and item number noted on the illustration.

b. When National Stock Number or Part Number is Known:

(1) *First*. Using the index of National stock numbers and part numbers, find the pertinent NSN or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.

(2) *Second*. After finding the figure and item number, locate the figure and item number in the repair parts list.

B-6. ABBREVIATIONS.


<i>Abbreviation</i>	<i>Explanation</i>
amp	amperage
CBR	chemical, biological, radiological (warfare)
cfm	cubic feet per minute
cl.	class
cres	corrosion-resistant steel
deg	degree
dia	diameter
elec	electrical
ext	external
fil	fillister

<i>Abbreviation</i>	<i>Explanation</i>
ft	foot, feet
gr	grade
h	high
hex	hexagonal
hd	head
hz	hertz
id	inside diameter
in	inch
intl	internal
lg.	length, long
med	medium
mfd	manufactured
min	minimum
mtg	mounting

<i>Abbreviation</i>	<i>Explanation</i>
nom	nominal
oa	overall
od	outside diameter
plm	plus or minus
psi	pounds per square inch
pst	paste
RFI	radio frequency interference
spst	single-pole single-throw
thd	thread
thk	thick
v	volt
w/	with
w/o	without

THIS PAGE INTENTIONALLY LEFT BLANK

Section II. REPAIR PARTS LIST




ARA81-0019

Figure B-1. M12 protective entrance

TM3-4240-286-30&P		(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION								
(A)	(B)		NATIONAL		PART	DESCRIPTION		QTY
FIG	ITEM	SMR	STOCK	FSCM	NUMBER		U/M	INC
NO.	NO.	CODE	NUMBER			USABLE ON CODE		IN
						GROUP 0100 M12 PROTECTIVE ENTRANCE		
						ES-19-6201-20		
B-1	1	PAOOO	4240-01-048-2923	81361	ES-19-6201-20	ENTRANCE, PROTECTIVE, PRESSURIZED: M12	EA	1
B-1	2	PAOZZ	5305-00-179-8946	96906	MS51849-66	SCREW, MACHINE HEX HD, NO.10-32UNF-2A, 3/4 IN LG	EA	3
B-1	3	PAOZZ	5310-00-045-3296	96906	MS35338-43	WASHER, LOCK SPRING, NO.10 NOM SIZE	EA	3
B-1	4	PAOZZ	4240-01-048-2803	81361	E5-19-6357	CONTROL MODULE, PROTECTIVE ENTRANCE	EA	1
B-1	5	PAOZZ	4730-01-050-7540	30327	KF03-04RV	ADAPTER, STRAIGHT	EA	1
B-1	6	MOOZZ		81361	E5-19-6357-111	HOSE, NONMETALLIC LOW PRESSURE: MFD FROM 4720-00-065-8682	EA	1
B-1	7	PAOZZ	4730-01-017-5119	30327	KF03-02PS	ADAPTER, STRAIGHT	EA	1
B-1	8	PAOZZ	5330-00-250-0236	96906	MS29513-024	PACKING, PREFORMED	EA	1
B-1	9	PAOZZ	5330-00-248-3849	96906	MS29513-019	PACKING, PREFORMED	EA	1
B-1	10	PAOOO	5340-01-048-6327	81361	C5-19-6145	CAP, PROTECTIVE, DUST AND MOISTURE SEAL	EA	2
B-1	11	PAOZZ	5305-00-115-9934	96906	MS51849-55	SCREW, MACHINE HEX HD, NO.8-32UNC-2A, 5/8 IN LG	EA	3
B-1	12	PAOZZ	5310-00-765-3197	96906	MS27183-41	WASHER, FLAT .188 IU ID, .438 IN OD, .049 IN THK	EA	5
B-1	13	AOOOO			CL-2-FANDCL-2-C-8.0	CABLE	EA	2
B-1	14	PAOZZ	4030-00-878-8693	99862	CL2F	FERRULE, WIRE ROPE	EA	4
B-1	15	MOOZZ		99862	CL-2-C-8.0	CABLE, NYLON: 8IN. LG MFD FROM 4010-00-069-5180	EA	2
B-1	16	XAOZZ		81361	C5-19-6309	CAP, RUBBER	EA	2
B-1	17	PAOZZ	4730-00-908-6294	96906	MS35842-16	CLAMP, HOSE 4-1/8 TO 7 IN DIA RANGE	EA	2
B-1	18	PAOZZ	5310-00-811-3494	96906	MS21044N08	NUT, SELF-LOCKING, HEXAGON: 8-32 UNJC-3B	EA	3
B-1	19	PAOZZ	9905-01-068-2368	81361	5-19-6657	PLATE, INSTRUCTION NO STEP	EA	1
B-1	20	PAOZZ	9905-01-049-1385	81361	C5-19-6175	PLATE, INSTRUCTION	EA	1
B-1	21	PAOZZ	5305-00-211-8193	96906	MS51849-54	SCREW, MACHINE HEX HD, NO.8-32UNC-2A, 1/2 IN LG	EA	1
B-1	22	PAOZZ	5305-00-157-5621	96906	MS51849-56	SCREW, MACHINE HEX HD, NO.8-32UNC-2A, 3/4 IN LG	EA	1
B-1	23	PAOZZ	5310-00-928-9821	96906	MS24679-2	NUT, PLAIN, CAP NO. 8-32UNC-2B	EA	2
B-1	24	PAOZZ	5310-00-045-3299	96906	MS35338-42	WASHER, LOCK SPRING, NO.8 NOM SIZE	EA	2
B-1	25	PAOZZ	9905-01-061-7139	81361	C5-19-6316-10	PLATE, IDENTIFICATION: ENTRANCE, PROTECTIVE, PRESSURIZED M12	EA	1
B-1	26	PAOZZ	9905-01-048-2790	81361	B5-19-6238	PLATE, INSTRUCTION CAUTION, DO NOT ENTER WHEN PROTECTIVE ENTRANCE IS OCCUPIED	EA	1
B-1	27	PAOZZ	5410-00-981-8701	01943	8173	CAP, FILLER OPENING W/CHAIN	EA	1
B-1	28	PAOZZ	5310-01-054-4643	96906	MS3186-34	NUT, PLAIN, HEXAGON 11/16-24UNEF-2B	EA	1
B-1	29	PAOZZ	5935-00-912-9599	96906	MS3181-10N	COVER, ELECTRICAL CONNECTOR	EA	1
B-1	30	PAOZZ	5935-00-990-5580	96906	MS3181-14N	COVER, ELECTRICAL CONNECTOR	EA	1
B-1	31	PAOZZ	5310-00-435-8983	96906	MS3186-43	NUT, PLAIN, HEXAGON 1-20UNEF-2B	EA	1
B-1	32	PAOZZ	5305-00-115-9406	96906	MS51849-53	SCREW, MACHINE HEX HD, NO.6-32UNC-2A, .38IN LG	EA	3
B-1	33	PAOZZ	5310-00-045-3299	96906	MS35338-42	WASHER, LOCK SPRING NO.8 NOM SIZE	EA	3
B-1	34	PAOZZ	4240-01-049-0804	81361	C5-19-6236	COVER, PROTECTIVE	EA	1
B-1	35	PAOZZ	5310-00-897-6081	96906	MS35691-32	NUT, PLAIN, HEXAGON JAM, 7/16-20 UNF-2B	EA	1
B-1	36	PAOZZ	4730-01-067-9232	81361	C5-19-6654	ADAPTER, PIPE TO TUBE 1/4NDS, 7/16-20UNF-2A	EA	1
B-1	37	PAOZZ	5310-00-928-9821	96906	MS24679-2	NUT, PLAIN, CAP NO.8-32UNC-2B	EA	3


B-7



ARA80-2413

Figure B-2. Protective entrance control module (sheet 1 of 2)

THIS PAGE INTENTIONALLY LEFT BLANK



ARA81-0020


Figure B-2. Protective entrance control module (sheet 2 of 2)

TM3-4240-286-30&P		(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION		(A)	(B)	NATIONAL	FSCM	PART	DESCRIPTION	QTY	INC
FIG	ITEM	SMR	STOCK	NUMBER		NUMBER	USABLE ON CODE	IN	UNIT
NO.	NO.	CODE						U/M	
							GROUP 0110 PROTECTIVE ENTRANCE		
							CONTROL MODULE		
							ES-19-6357		
B-2	1	XAFZZ			81361	E5-19-6360	PLATE,LETTERED	EA	1
B-2	2	MFFZZ			81349	MS086/1-20-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7519	FT	V
B-2	3	PAFZZ	5940-00-143-4771		96906	MS25036-103	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO. 10 STUD SIZE	EA	1
B-2	4	PAFZZ	5310-00-877-5797		96906	MS21044N3	NUT,SELF-LOCKING,HEXAGON: NO.10-32UNJF-38	EA	1
B-2	5	PAFZZ	5940-00-825-3699		96906	MS17143-10	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO.5 STUD SIZE	EA	9
B-2	6	MFFZZ			81349	MS086/1-16-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7517	FT	V
B-2	7	PAFZZ	5930-00-057-5848		96906	MS24658-21M	SWITCH,TOGGLE	EA	1
B-2	8	PAFZZ	5940-00-204-8966		96906	MS25036-102	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO. 6 STUD SIZE	EA	1
B-2	9	PAFZZ	5310-00-575-5292		83330	2660	WASHER,SHOULDERED PLASTIC,.031 IN.SHOULDER H,.140 IN ID,.375	EA	4
B-2	10	PAFZZ	5310-00-934-9748		96906	MS35649-244	NUT,PLAIN,HEXAGON 4-40-UNC-2B	EA	1
B-2	11	PAFZZ	5940-00-615-6073		96906	MS25036-152	TERMINAL,LUG CRIMP STYLE,16-14 AWG WIRE SIZE,NO.4 STUD SIZE	EA	1
B-2	12	PAFZZ	5310-00-088-0551		96906	MS21044N04	NUT,SELF-LOCKING,HEXAGON: NO.4-40UNC-3B	EA	4
B-2	13	MFFZZ			81349	MS086/1-22-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7520	FT	V
B-2	14	PAFZZ	6645-01-113-2525		79919	71015	TIMER,INTERVAL TIME OFF TYPE,SPST,CENTER MTQ,SPLASHPROOF, 5 MIN AT 90DEG STOP,KNOB NO.K35B1	EA	1
B-2	15	PAFZZ	5310-00-559-0070		96906	MS35333-38	WASHER,LOCK INTL TOOTH,NO.8 NOM SIZE	EA	2
B-2	16	PAFZZ	5940-00-557-1629		96906	MS25036-149	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO.8 STUD SIZE	EA	4
B-2	17	PAFZZ	6210-00-635-4700		76854	VM911M8	LIGHT,INDICATOR	EA	1
B-2	18	PAFZZ	5330-00-954-6684		80205	NAS1598-6Y	PACKING WITH RETAINER: 3/8 IN. BOLT SIZE	EA	2
B-2	19	PAFZZ	5310-00-199-1056		96906	MS35650-3385	NUT,PLAIN,HEXAGON 3/8-24UNF-2B	EA	2
B-2	20	PAOZZ	5355-00-821-5225		79919	K35B1	KNOB	EA	1
B-2	21	PAFZZ	5305-00-148-1286		96906	MS3213-36	SCREW,MACHINE PAN HD,SELF-SEALING,NO.10-32UNF-2A,3/4 IN. LG	EA	13
B-2	22	PAOZZ	6240-00-763-7744		81348	W-L-00111/7	LAMP,INCANDESCENT	EA	3
B-2	23	PAFZZ	5930-01-052-7684		81361	E5-19-6376-155	SWITCH,PUSH HOUSING AND SWITCH: ENGRAVED "LOW PRESSURE"	EA	1
B-2	24	PAFZZ	5305-01-057-7206		96906	MS3213-5	SCREW,MACHINE PAN HD,SELF-SEALING,NO.4-40UNC-2A,1/2 IN LG	EA	3
B-2	25	PAFFF	6220-00-891-1491		96906	MS25358-7	LIGHT,DOME	EA	1
B-2	26	XAFZZ			96906	MS25358-3	HOUSING,DOME LIGHT	EA	1
B-2	27	PAOZZ	6240-00-155-7784		96906	MS35478-307	LAMP,INCANDESCENT	EA	1
B-2	28	PAOZZ	6240-00-155-7932		96906	MS25235R311	LAMP,INCANDESCENT RED	EA	1
B-2	29	PAOZZ	5330-00-143-8571		96906	MS25358-6	GASKET DOME LIGHT	EA	1
B-2	30	PAOZZ	6220-00-283-9732		96906	MS25358-4	LENS,LIGHT	EA	1
B-2	31	XAOZZ			96906	MS25358-5	RETAINER,LIGHT	EA	1
B-2	32	PAOZZ	5305-00-889-2999		96906	MS35206-217	SCREW,MACHINE PAN HD, NO.4-40UNC-2A,1/2 IN LG	EA	6

B-11

TM3-4240-286-30&P		(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION		(A)	(B)	NATIONAL	FSCM	PART	DESCRIPTION	USABLE ON CODE	QTY	
FIG	ITEM	SMR	STOCK	NUMBER	NUMBER	NUMBER			INC	
NO.	NO.	CODE	NUMBER						IN	
									UNIT	
B-2	33	PAFZZ	5305-00-984-4976	96906	MS35206-219		SCREW,MACHINE PAN HD,NO.4-40UNC-2A,3/4IN LG		EA	1
B-2	34	PAFZZ	5310-00-058-3599	96906	MS35335-57		WASHER,LOCK EXT TOOTH,NO 4 NOM SIZE		EA	1
B-2	35	PAFZZ	5940-00-113-8179	96906	MS25036-107		TERMINAL,LUG CRIMP STYLE,16-14 AWG WIRE SIZE,NO.6 STUD SIZE		EA	2
B-2	34	MFFZZ			81361	C5-19-5676	GASKET MFD FROM 9320007858171		EA	1
B-2	37	PAOZZ	9905-01-053-3006	81361	C5-19-6316-4		PLATE,IDENTIFICATION: CONTROL MODULE,PROTECTIVE ENTRANCE		EA	1
B-2	38	PAFZZ	4730-01-053-5923	81361	B5-19-6362		ADAPTER,STRAIGHT,HOSE		EA	1
B-2	39	PAFZZ	5330-00-954-6684	80205	NAS1598-6Y		PACKING WITH RETAINER: 3/8 IN BOLT SIZE		EA	1
B-2	40	XAFZZ			81361	E5-19-6358	HOUSING		EA	1
B-2	41	PAFZZ	5330-00-928-0290	80205	NAS1598-06Y		PACKING WITH RETAINER: NO 6 SCREW SIZE		EA	2
B-2	42	PAFZZ	5305-00-920-0327	12909	500881		SCREW,MACHINE PAN HD,SLOTTED,CRES,NO.6-32UNC-2A,2-1/2 IN LG		EA	2
B-2	43	PAFZZ	5999-01-050-4635	81361	C5-19-6197		PRINTED CIRCUIT BOARD: POWER		EA	1
B-2	44	PAFZZ	5305-00-227-1543	96906	MS51849-33		SCREW,MACHINE HEX HD,NO.6-32UNC-2A,.38 IN LG		EA	2
B-2	45	PAFZZ	5310-00-045-4007	96906	MS35338-41		WASHER,LOCK SPRING,NO 6 NOM SIZE		EA	2
B-2	46	PAFZZ	5310-00-983-8483	96906	MS27183-5		WASHER,FLAT .156 IN ID,.312 IN OD,.035 IN THK		EA	2
B-2	47	PAFZZ	5999-01-050-4636	81361	D5-19-6193-20		PRINTED CIRCUIT BOARD: SWITCHING		EA	1
B-2	48	PAFZZ	5330-01-085-3267	81361	5-19-6361		GASKET CONTROL MODULE		EA	1
B-2	49	PAFZZ	6685-01-056-5283	33107	P92-1020		TRANSMITTER,PRESSURE		EA	1
B-2	50	MFFZZ			81361	E5-19-6357-47	TUBING NONMETALLIC: 3/16 IN NOM ID,GREEN, MFD FROM 9330010731011		IN	13
B-2	51	PAFZZ	5310-00-081-8087	96906	MS21044N06		NUT,SELF-LOCKING,HEXAGON: NO 6-32UNJC-3B		EA	2


THIS PAGE INTENTIONALLY LEFT BLANK



ARA81-0021

Figure B-3. M56 gas-particulate filter unit (sheet 1 of 2)

THIS PAGE INTENTIONALLY LEFT BLANK




ARA81-0022

Figure B-3. M56 gas-particulate filter unit (sheet 2 of 2)

TM3-4240-286-30&P (1)		CHANGE 1 (2)		(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION (A)	ITEM (B)	SMR	NATIONAL STOCK	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	U/M	QTY INC IN UNIT
FIG NO.	NO.	CODE	NUMBER						
GROUP 0200 M56 GAS PARTICULATE FILTER UNIT									
E5-19-6402									
*	B-3	1	PAOFA	4240-00-237-0227	81361	E5-19-6402	FILTER UNIT, GAS-PARTICULATE: 1 FILTER,M56	EA	1
	B-3	2	PAOZZ	9905-01-071-5711	81361	5-19-6316-9	PLATE,IDENTIFICATION: FILTER UNIT,GAS-PARTICULATE,1 FILTER,M56	EA	1
	B-3	3	PAOFF	4240-01-057-3378	81361	E5-19-6376	CONTROL MODULE COMPARTMENT	EA	1
	B-3	4	PAOZA	4240-01-067-5605	81361	5-19-6718	FILTER SET,GAS AND PARTICULATE	SE	1
	B-3	5	PAOZA	4240-01-066-3266	81361	D5-19-6262	FILTER,PARTICULATE	EA	1
	B-3	6	XAOZA		81361	D5-19-6368	FILTER,GAS	EA	1
	B-3		PAOFF	4240-01-068-8645	81361	E5-19-6387	POWER DISTRIBUTION UNIT	EA	1
	B-3	8	MOOZZ		81361	E5-19-6402-8	TUBING,NONMETALLIC MFD FROM 4720-01-053-0316	EA	1
	B-3	9	MOOZZ		81361	E5-19-6402-7	TUBING,NONMETALLIC 1/4 IN OD,RED,MFD FROM 4720-00-996-0381	EA	1
	B-3	10	XBOFF	4240-01-054-7020	81361	E5-19-6314-20	HOUSING UNIT, FAN AND AIRFLOW VALVE	EA	1
	B-3	11	PAOOO	5340-01-048-6327	81361	C5-19-6145	CAP,PROTECTIVE,DUST AND MOISTURE SEAL	EA	1
	B-3	12	PAOZZ	5305-00-115-9934	96906	MS51849-55	SCREW,MACHINE HEX HD,NO 8-32UNC-2A,5/8 IN LG	EA	2
	B-3	13	PAOZZ	5310-00-765-3197	96906	MS27183-41	WASHER,FLAT .188 IN ID, .438 IN OD, .049 IN THK	EA	4
	B-3	14	AOOOO			CL-2-FANDCL-2-C- 8.0	CABLE	EA	1
	B-3	15	PAOZZ	4030-00-878-8693	99862	CL2F	FERRULE,WIRE ROPE	EA	2
	B-3	16	MOOZZ		99862	CL-2-C-8.0	CABLE,NYLON: 8 IN LG,MFD FROM 4010-00-069-5180	EA	1
	B-3	17	XAOZZ		81361	C5-19-6309	CAP,RUBBER	EA	1
	B-3	18	PAOZZ	4730-00-908-6294	96906	MS35842-16	CLAMP,HOSE 4-1/8 TO 7 IN DIA RANGE	EA	1
	B-3	19	PAOZZ	5310-00-811-3494	96906	MS21044N08	NUT,SELF-LOCKING,HEXAGON: NO 8-32UNJC-3B	EA	2
	B-3	20	PAOFF	4140-01-059-2095	81361	E5-19-6240	FAN,TUBEAXIAL MAIN: 200 CFM	EA	1
	B-3	21	PAOZZ	5310-00-809-4058	96906	MS27183-10	WASHER,FLAT .281 IN ID, .625 IN OD, .065 IN THK	EA	6
	B-3	22	PAOZZ	5305-00-068-0513	96906	MS90727-6	SCREW,CAP,HEXAGON HEAD: 1/4-28UNF-2A,3/4 IN LG	EA	6
	B-3	23	XBOZZ	4240-01-107-2433	81361	E5-19-6120	HOUSING,GAS-PARTICU 1 FILTER	EA	1
	B-3	24	PAOZZ	5330-01-069-9824	81361	C5-19-5687-2	SEAL,RUBBER	EA	1
	B-3	25	XBOZZ		81361	E5-19-6128	COVER,ACCESS	EA	1
	B-3	26	PAOZZ	5310-00-080-6004	96906	MS27183-14	WASHER,FLAT .406 IN ID,.812 IN OD, .065 IN THK	EA	6
	B-3	27	PAOZZ	5310-00-187-2400	88044	AN960PD616	WASHER,FLAT 0.390 IN ID, 0.625 IN OD, 0.063 IN THK	EA	6
	B-3	28	PAOZZ	5305-00-269-3240	96906	MS90727-64	SCREW,CAP,HEXAGON HEAD: 3/8-24UNF-2A,1-1/2 IN LG	EA	6
	B-3	29	XBOZZ		81361	D5-19-6260	COVER,INNER	EA	1
	B-3	30	PAOZZ	5330-01-068-0515	81361	C5-19-5687-1	SEAL,RUBBER	EA	1
	B-3	31	PAOZZ	9905-01-067-8634	81361	B5-19-6134	PLATE,INSTRUCTION WARNING TORQUE OUTER COVER BOLTS 180 TO 200 INCH POUNDS	EA	1
	B-3	32	PAOZZ	9905-01-066-3084	81361	5-19-6135	PLATE,INSTRUCTION WARNING-DO NOT REMOVE COVERS TO SERVICE COMPONENTS AFTERTOXIC EXPOSURE,WITHOUT OBSERVING PROPER HANDLING PROCEDURES	EA	1
	B-3	33	PAOZZ	9905-01-050-7557	81361	B5-19-6133	PLATE,INSTRUCTION WARNING-TIGHTEN UNTIL SLEEVE IS FLUSH WITH TOP SURFACE	EA	1
	B-3	34	PAOZZ	5310-00-877-5797	96906	MS21044N3	NUT,SELF-LOCKING,HEXAGON: NO 10-32UNJF-3B	EA	8

(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION							
(A)	(B)		NATIONAL				QTY
FIG	ITEM	SMR	STOCK	PART	DESCRIPTION		INC
NO.	NO.	CODE	NUMBER	NUMBER	USABLE ON CODE		IN
				FSCM		U/M	UNIT
B-3	35	PAOZZ	5330-01-088-4442	81361	5-19-6348		EA 1
B-3	36	PAOPF	4240-01-055-1493	81361	E5-19-6136		EA 1
B-3	37	PAOZZ	5310-00-014-5850	96906	MS27183-42		EA 8
B-3	38	PAOZZ	5305-00-824-7363	80205	NAS1096-3-12		EA 8
B-3	39	PAOZZ	5305-00-180-4966	96906	MS51849-64		EA 1
B-3	40	PAOZZ	5340-00-119-4705	96906	MS9352-05		EA 1
B-3	41	PAOZZ	4730-00-817-1891	30327	261P1-4		EA 2
B-3	42	PAOZZ	5365-01-057-7379	81361	B5-19-6347		EA 1
B-3	43	PAOZZ	5310-00-081-4219	96906	MS27183-12		EA 8
B-3	44	PAOZZ	5305-00-051-4075	96906	MS90727-33		EA 8
B-3	45	PAOZZ	4520-01-057-7010	81361	D5-19-6401		EA 1

THIS PAGE INTENTIONALLY LEFT BLANK



ARA81-0023

Figure B-4. Main fan

TM3-4240-286-30&P		(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION		(A)	(B)	NATIONAL		PART	DESCRIPTION		QTY
FIG	ITEM	SMR	STOCK		FSCM	NUMBER		USABLE ON CODE	INC
NO.	NO.	CODE	NUMBER						IN
									U/M
									UNIT
							GROUP 0210 MAIN FAN		
							E5-19-6240		
B-4	1	XAFZZ			81361	E5-19-6241	HOUSING, FAN		EA 1
B-4	2	PAFZZ	5315-00-616-5526		96906	MS35756-8	KEY, WOODRUFF		EA 1
B-4	3	XAFZZ			81361	C5-19-6247	ROTOR		EA 1
B-4	4	PAFZZ	4320-01-052-7999		81361	B5-19-6081	DEFLECTOR, DIRT AND SHAFT		EA 1
B-4	5	PAFZZ	3110-00-144-8882		38443	201SFP	BEARING, BALL, ANNULAR		EA 2
B-4	6	PAFZZ	5310-00-227-4882		92830	F1240-008	WASHER, SPRING LOADING		EA 1
B-4	7	PAFZZ	5310-00-167-0835		88044	AN960-416L	WASHER, FLAT .265 IN ID, .500 IN OD, .032 IN THK		EA 12
B-4	8	PAFZZ	5305-00-477-2713		80205	NAS1351-4-12	SCREW, CAP, SOCKET HEAD: 1/4-28UNF-3A, 3/4 IN LG		EA 12
B-4	9	XAFZZ			81361	D5-19-6242	COVER, MOTOR		EA 1
B-4	10	PAFZZ	3110-01-057-4653		81361	C5-19-6255	PLATE, RETAINING, BEARING		EA 1
B-4	11	PAFZZ	3120-01-053-5848		81361	B5-19-6254	BUSHING, SLEEVE IMPELLER		EA 1
B-4	12	PAFZZ	5305-00-978-9369		96906	MS16997-31	SCREW, CAP, SOCKET HEAD: NO 8-32UNC-3A, 3/8 IN. LG		EA 4
B-4	13	PAFZZ	5365-01-053-2593		81361	B5-19-6030-1	SHIM LAMINATED		EA 1
B-4	14	XAFZZ			81361	D5-19-6252	IMPELLER, FAN		EA 1
B-4	15	PAFZZ	5310-00-167-0821		88044	AN960-616	WASHER, FLAT .390 IN ID, .625 IN OD, .063 IN THK		EA 1
B-4	16	PAFZZ	5310-00-810-1786		96906	MS21042-6	NUT, SELF-LOCKING, EXTENDED WASHER, HEXAGON: 3/8-24UNJF-3B		EA 1
B-4	17	XAFZZ			81361	E5-19-6251	COVER, IMPELLER		EA 1
B-4	18	XAFZZ			96906	MS3116P16-8P	CONNECTOR, PLUG, ELECTRIC		EA 1
B-4	19	PAFZZ	9905-01-054-4263		81361	C5-19-6258-1	PLATE, IDENTIFICATION: MAIN FAN, 200 CFM		EA 1




Figure B-5. Airflow valve

TM3-4240-286-30&P		(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION								
(A)	(B)		NATIONAL		PART	DESCRIPTION		QTY
FIG	ITEM	SMR	STOCK	FSCM	NUMBER		U/M	INC
NO.	NO.	CODE	NUMBER			USABLE ON CODE		IN
						GROUP 0220 AIRFLOW VALVE		
						E9-19-6136		
B-5	1	PAFZZ	6105-01-056-9045	25140	5A3128	GEARCASE-MOTOR PLANETARY,GEAR REDUCED	EA	1
B-5	2	PAFZZ	5940-00-113-9828	96906	MS25036-148	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO.4 STUD SIZE	EA	2
B-5	3	MFFZZ		81349	M5086/1-20-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7519	FT	V
B-5	4	PAFZZ	5305-00-582-5808	96906	MS35265-31	SCREW,MACHINE FIL HCAD,NO 6-32UNC-2A,5/8 IN LG	EA	4
B-5	5	PAOZZ	5310-00-811-3494	96906	MS21044N08	NUT,SELF-LOCKING,HEXAGON: NO. 8-32UNJC-3B	EA	3
B-5	6	PAFZZ	5975-01-053-6294	09922	TF-5H	STRAP,TIEDOWN,CABLE	EA	3
B-5	7	PAFZZ	5310-00-088-0551	96906	MS21044N04	NUT,SELF-LOCKING,HEXAGON: NO 4-4OUNJC-3B	EA	8
B-5	8	XAFZZ		81361	D5-19-6138	MOUNT,MOTOR	EA	1
B-5	9	PAFZZ	5310-00-081-8087	96906	MS21044N06	NUT,SELF-LOCKING,HEXAGON	EA	12
B-5	10	MFFZZ		81349	M5086/1-22-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7520	FT	V
B-5	11	PAFZZ	5305-00-242-1264	96906	MS51849-13	SCREW,MACHINE HEXAGON HEAD,NO 4-4OUNC-2A, .38 IN LG	EA	8
B-5	12	PAOZZ	5305-00-115-9934	96906	MS51849-55	SCREW,MACHINE HEX HD,NO 8-32UNC-2A,5/8 IN LG	EA	2
B-5	13	PAOZZ	9905-01-065-9382	81361	C5-19-6149	PLATE,IDENTIFICATION: AIRFLOW VALVE	EA	1
B-5	14	PAFZZ	5940-00-557-1629	96906	MS25036-149	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE, NO 8 STUD SIZE	EA	6
B-5	15	PAOZZ	5310-00-765-3197	96906	MS27183-41	WASHER,FLAT .188 IN ID, .438 IN OD, .049 IN THK	EA	6
B-5	16	XAFZZ		81361	C5-19-6144	GEAR	EA	1
B-5	17	PAFZZ	5305-00-058-9362	96906	MS51977-19	SETSCREW HEX SOCKET, NO 6-32UNC-3A,3/16 IN LG	EA	1
B-5	18	PAFZZ	5305-00-984-6221	96906	MS35206-234	SCREW,MACHINE PAN HD,NO.6-32UNC-2A,1 IN LG	EA	8
B-5	19	PAOZZ	5305-00-157-5621	96906	MS51849-56	SCREW,MACHINE HEX HD,NO 8-32UNC-2A, 3/4 IN LG	EA	1
B-5	20	PAOOO	5340-01-048-6327	81361	C5-19-6145	CAP,PROTECTIVE,DUST AND MOISTURE SEAL	EA	2
B-5	21	PAOZZ	4730-00-908-6294	96906	MS35842-16	CLAMP,HOSE 4-1/8 TO 7 IN DIA RANGE	EA	2
B-5	22	XAOZZ		81361	C5-19-6309	CAP,RUBBER	EA	2
B-5	23	AOOOO		99862	CL-2-FANDCL-2-C-8.0	CABLE	EA	2
B-5	24	MOOZZ		99862	CL-2-C-8.0	CABLE,NYLON: 8IN LG, MFD FROM 4010-00-069-5180	EA	2
B-5	25	PAOZZ	4030-00-878-8693	99862	CL2F	FERRULE,WIRE ROPE	EA	4
B-5	26	XAFZZ		81361	E9-19-6137	HOUSING,VALVE	EA	1
B-5	27	PAOZZ	9905-01-051-0186	81361	B5-19-6147	PLATE,INSTRUCTION TO SHELTER	EA	1
B-5	28	PAOZZ	9905-01-050-7556	81361	B5-19-6148	PLATE,INSTRUCTION TO PROT ENT	EA	1
B-5	29	PAFZZ	5961-00-924-6981	81349	JAN1N4245	SEMICONDUCTOR DEVICE,DIODE	EA	2
B-5	30	PAFZZ	5930-00-913-7960	81349	MS25085-2	SWITCH,SENSITIVE	EA	2
B-5	31	PAFZZ	5910-00-114-0510	81349	M39014/01-1581	CAPACITOR,FIXED CERAMIC	EA	2
B-5	32	PAFZZ	5930-00-296-9610	94135	1227903-178	ADAPTER,SWITCH ACTU	EA	2
B-5	33	PAFZZ	5915-01-075-7240	81361	C5-19-6152	FILTER,RADIO FREQUENCY INTERFERENCE	EA	1
B-5	34	MFFZZ		81349	M7078-3-22-1	CABLE,SPECIAL PURPOSE,ELECTRICAL: MFD FROM 6145-00-608-5484	FT	V





Figure B-6. Power distribution unit.

ARA81-0025

(1)		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(8) FIG NO	(9) ITEM NO	S&P CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	QTY INC IN UNIT
						GROUP 0230 POWER DISTRIBUTION UNIT E5-19-6387		
B-6	1	PAFZZ	5999-01-074-8880	8136	D5-19-6392	SHIELDING GASKET, POWER DISTRIBUTION UNIT.....		EA 1
B-6	2	XAPZZ		81361	E5-19-6390	HOUSING		EA 1
B-6	3	PAFZZ	5305-01-031-5092	9690	MS3213-33	SCREW, MACHINE PAN HD, SELF-SEALING, NO. 10-32UNF-2A, 1/2 IN LG.....		EA 12
B-6	4	PAFFF	4240-01-057-3474	81361	E5-19-6391	PANEL, POWER DISTRIBUTION UNIT		EA 1


THIS PAGE INTENTIONALLY LEFT BLANK



ARA81-0026

Figure B-7. Power distribution panel (sheet 1 of 2)

THIS PAGE INTENTIONALLY LEFT BLANK




ARA81-0027

Figure B-7. Power distribution panel (sheet 2 of 2)

TM3-4240-286-30&P		(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION		(A)	(B)	NATIONAL		PART	DESCRIPTION		QTY
FIG	ITEM	SMR	STOCK		FSCM	NUMBER			INC
NO.	NO.	CODE	NUMBER				USABLE ON CODE	U/M	IN
									UNIT
							GROUP 0231 POWER DISTRIBUTION PANEL		
							E5-19-6391		
B-7	1	PAFZZ	5940-00-113-8179		96906	MS25036-107	TERMINAL,LUG CRIMP STYLE, 16-14 AWG WIRE SIZE,NO 6 STUD SIZE	EA	6
B-7	2	MFFZZ			81349	M5086/1-20-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7519	FT	V
B-7	3	PAFZZ	5940-00-204-8966		96906	MS25036-102	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO 6 STUD SIZE	EA	9
B-7	4	PAFZZ	5925-00-814-8428		18876	10231240	CIRCUIT BREAKER	EA	1
B-7	5	PAFZZ	5940-00-143-4774		96906	MS25036-153	TERMINAL,LUG CRIMP STYLE, 16-14 AWG WIRE SIZE, NO 8 STUD SIZE	EA	13
B-7	6	PAFZZ	5925-01-067-5437		82647	6752-320-20	CIRCUIT BREAKER	EA	1
B-7	7	PAFZZ	5925-00-045-1704		82647	7274-12-1	CIRCUIT BREAKER	EA	1
B-7	8	PAFZZ	5925-00-768-2035		82647	7274-12-1-1-2	CIRCUIT BREAKER	EA	1
B-7	9	PAFZZ	5310-00-877-5797		96906	MS21044N3	NUT,SELF-LOCKING,HEXAGON: NO 10-32UNJF-3B	EA	12
B-7	10	PAFZZ	5975-01-053-6294		09922	TF-5H	STRAP,TIEDOWN,CABLE	EA	4
B-7	11	PAFZZ	5310-00-809-8546		96906	MS27183-8	WASHER,FLAT .219 IN ID, .438 IN OD, .049 IN THK	EA	9
B-7	12	PAFZZ	5305-00-179-8946		96906	MS51849-66	SCREW,MACHINE HEX HD,NO. 10-32UNF-2A,3/4 IN LG	EA	8
B-7	13	PAFZZ	5310-00-088-0551		96906	MS21044N04	NUT,SELF-LOCKING,HEXAGON: NO 4-40UNJC-3B	EA	2
B-7	14	PAFZZ	5905-00-553-8100		81349	RER70F1100R	RESISTOR,FIXED,WIRE WOUND	EA	1
B-7	15	PAFZZ	5305-01-053-0958		96906	MS51849-14	SCREW,MACHINE HEX HD,NO 4-40UNC-2A, 1/2 IN LG	EA	2
B-7	16	XBFZZ			07137	PTL-A1(3-C7A)	LIGHT,INDICATOR	EA	1
B-7	17	PAFZZ	5975-00-958-6451		82647	14500-1	BOOT,DUST AND MOISTURE SEAL	EA	3
B-7	18	PAOZZ	6240-00-892-4420		81349	M15098/11-001	LAMP,GLOW	EA	1
B-7	19	PAFZZ	5305-01-053-0959		96906	MS3213-14	SCREW,MACHINE PAN HD,SELF-SEALING,NO 6-32UNC-2A,7/16 IN LG	EA	4
B-7	20	PAFZZ	5305-00-148-1286		96906	MS3213-36	SCREW,MACHINE PAN HD,SELF-SEALING,NO 10-32UNF-2A,3/4 IN LG	EA	4
B-7	21	PAFZZ	5945-00-201-9456		96906	MS24143D1	RELAY,ELECTROMAGNETIC 25 AMP,3PST, N O	EA	1
B-7	22	PAFZZ	5940-00-143-4780		96906	MS25036-108	TERMINAL,LUG CRIMP STYLE,16-14 AWG WIRE SIZE,NO 10 STUD SIZE	EA	10
B-7	23	PAFZZ	5940-00-681-8185		96906	MS35430-4	TERMINAL,LUG SOLDER TYPE,14-20 AWG WIRE SIZE,NO 6 STUD SIZE	EA	2
B-7	24	PAFZZ	5961-00-139-9812		81349	JAN1N5557	SEMICONDUCTOR DEVICE,DIODE	EA	1
B-7	25	PAFZZ	5940-00-143-4771		96906	MS25036-103	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE, NO 10 STUD SIZE	EA	1
B-7	26	PAFZZ	5999-01-048-9865		81361	C5-19-6415	PRINTED CIRCUIT ASSEMBLY	EA	1
B-7	27	PAOZZ	4730-00-817-1891		30327	261P1-4	NUT,TUBE COUPLING 1/4 IN TUBE OD,3/8-24 THD SIZE, W/SLEEVE	EA	2
B-7	28	PAOZZ	9905-01-065-3065		81361	C5-19-6316-6	PLATE,IDENTIFICATION: POWER DISTRIBUTION UNIT	EA	1
B-7	29	MFFZZ			81361	E5-19-6391-52	TUBING,NONMETALLIC: 3/16 IN NOM ID,GREEN,MFD FROM 9330-01-073-1011	IN	14
B-7	30	PAFZZ	5940-00-825-3697		96906	MS17143-11	TERMINAL,LUG CRIMP STYLE, 16-14 AWG WIRE SIZE,NO 5 STUD SIZE	EA	4
B-7	31	PAFZZ	5940-00-825-3699		96906	MS17143-10	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO 5 STUD SIZE 1.8	EA	16

TM3-4240-286-30&P								
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION								
(A)	(B)		NATIONAL		DESCRIPTION		QTY	
FIG	ITEM	SMR	STOCK	PART			INC	
NO.	NO.	CODE	NUMBER	NUMBER	USABLE ON CODE		IN	
				FSCM			U/M	
							UNIT	
B-7	32	PAFZZ	5305-01-006-8953	96906	MS3213-27	SCREW,MACHINE PAN HD,SELF-SEALING,NO 8-32UNC-2A,5/8 IN LG	EA	4
B-7	33	PAFZZ	5305-01-053-0960	96906	MS3213-24	SCREW,MACHINE PAN HD,SELF-SEALING,NO 8-32UNC-2A,7/16 IN LG	EA	4
B-7	34	PAFZZ	5330-00-542-1329	96906	MS28775-120	PACKING,PREFORMED	EA	1
B-7	35	PAFZZ	5915-01-096-8853	81361	D5-19-6353	FILTER,RADIO FREQUENCY INTERFERENCE	EA	1
B-7	36	MFFZZ		81349	M5086/1-16-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7517	FT	V
B-7	37	PAFZZ	5310-00-809-8544	96906	MS27183-7	WASHER,FLAT .188 IN ID, .375 IN OD .049 IN THK	EA	4
B-7	38	PAFZZ	5310-00-811-3494	96906	MS21044N08	NUT,SELF-LOCKING, HEXAGON: NO 8-32UNJC-3B	EA	4
B-7	39	PAFZZ	5950-01-091-8626	81361	D5-19-6397	TRANSFORMER,POWER RECTIFIER MODULE, 400 HZ	EA	1
B-7	40	MFFZZ		81349	M5086/1-22-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7520	FT	V
B-7	41	PAFZZ	5940-00-557-1629	96906	MS25036-149	TERMINAL,LUG CRIMP STYLE, 22-18 AWG WIRE SIZE, NO 8 STUD SIZE	EA	2
B-7	42	PAFZZ	5340-00-989-9224	96906	MS25281R6	CLAMP,LOOP PLASTIC WIRE SUPPORT,RIBBED INNER DIA, 3/8 IN BUNDLE DIADIA	EA	2
B-7	43	PAFZZ	4730-00-116-2969	70494	A5S	CLAMP,HOSE	EA	2
B-7	44	PAFZZ	5930-01-055-9249	81361	B5-19-6261-1	SWITCH,PRESSURE	EA	1

THIS PAGE INTENTIONALLY LEFT BLANK




▽ DISASSEMBLY TYPICAL FOR LIKE ITEMS
▲ FURNISHED WITH BASIC ITEM

ARA81-0028

Figure B-8. Compartment control module (sheet 1 of 2)

THIS PAGE INTENTIONALLY LEFT BLANK



▲ FURNISHED WITH BASIC ITEM


ARA81-0029

Figure B-8. Compartment control module (sheet 2 of 2)

TM3-4240-286-30&P		(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION		(A)	(B)	NATIONAL	FSCM	PART	DESCRIPTION	QTY	INC
FIG	ITEM	SMR	STOCK	NUMBER		NUMBER	USABLE ON CODE	IN	IN
NO.	NO.	CODE						U/M	UNIT
							GROUP 0240 COMPARTMENT CONTROL MODULE		
							E5-19-6376		
B-8	1	MFFZZ			81349	M5086/1-22-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7520	FT	V
B-8	2	PAFZZ	5310-00-014-5850		96906	MS27183-42	WASHER,FLAT .219 IN ID, .500 IN OD,.049 IN THK	EA	7
B-8	3	PAFZZ	5310-00-877-5797		96906	MS21044N3	NUT,SELF-LOCKING,HEXAGON:NO 10-32UNJF-38	EA	7
B-8	4	PAFZZ	5975-01-053-6294		09922	TF-5H	STRAP,TIEDOWN,CABLE	EA	4
B-8	5	PAFZZ	5305-00-179-8946		96906	MS51849-66	SCREW,MACHINE HEX HD,NO 10-32UNF-2A,3/4 IN LG	EA	4
B-8	6	XAFZZ			81361	D5-19-6378	PANEL,LETTERED	EA	1
B-8	7	PAFZZ	5930-01-052-7684		81361	E5-19-6376-155	SWITCH,PUSH HOUSING AND SWITCH: ENGRAVED "LOW PRESSURE"	EA	1
B-8	8	PAOZZ	6240-00-763-7744		81348	W-L-00111/7	LAMP,INCANDESCENT	EA	8
B-8	9	PAFZZ	5975-00-958-6451		82647	14500-1	BOOT,DUST AND AND MOISTURE SEAL	EA	4
B-8	10	PAFZZ	5925-01-054-3453		82647	7274-34-3/4	CIRCUIT BREAKER	EA	1
B-8	11	PAFZZ	5925-00-045-1704		82647	7274-12-1	CIRCUIT BREAKER	EA	1
B-8	12	PAFZZ	6210-00-635-4700		76854	VM911MS	LIGHT,INDICATOR	EA	2
B-8	13	PAFZZ	5999-01-048-9866		81361	C5-19-6688	PRINTED CIRCUIT ASSEMBLY,SWITCHING,AUXILIARY	EA	1
B-8	14	PAFZZ	5925-01-054-3452		82647	7274-34-1	CIRCUIT BREAKER	EA	2
B-8	15	PAFZZ	5940-00-813-0698		96906	MS25036-101	TERMINAL,LUG CRIMP STYLE, 22-18 AWG WIRE SIZE NO 6 STUD SIZE	EA	29
B-8	16	PAFZZ	5930-01-050-4362		04426	44-580151AAAA	SWITCH,PUSH ENGRAVED "OCCUPIED"	EA	1
B-8	17	PAFZZ	6350-00-267-0442		37942	SC628M	SIGNAL,ELECTRONIC, AUDIBLE	EA	1
B-8	18	PAFZZ	5310-00-579-0079		96906	MS35333-37	WASHER,LOCK INT TOOTH, NO 6 NOM SIZE	EA	2
B-8	19	MFFZZ			81361	B5-19-5710	GASKET MFD FROM 9320-00-785-8171	EA	1
B-8	20	PAFZZ	5961-00-924-6981		81349	JAN1N4245	SEMICONDUCTOR DEVICE,DIODE	EA	3
B-8	21	PAFZZ	5930-00-854-7864		18876	9745533	SWITCH,PUSH	EA	1
B-8	22	PAFZZ	5930-01-108-2588		81361	E5-19-6376-159	SWITCH,PUSH HOUSING AND SWITCH: ENGRAVED "MASK"	EA	1
B-8	23	PAFZZ	5930-00-847-2599		96906	MS24660-23D	SWITCH,TOGGLE	EA	1
B-8	24	PAFZZ	6685-01-056-5283		33107	P92-1020	TRANSMITTER,PRESSURE	EA	1
B-8	25	MFFZZ			81361	E5-19-6376-46	TUBING,NONMETALLIC: 3/16 IN NOM ID,GREEN,MFD FROM 9330-01-073-1011	IN	18
B-8	26	PAFZZ	6640-00-494-0527		05178	6152	CONNECTOR,ELASTIC TUBING,BRANCHED: Y SHAPE, .25 IN OD	EA	1
B-8	27	PAFZZ	5340-00-989-9224		96906	MS25281R6	CLAMP,LOOP PLASTIC SIRE SUPPORT,RIBBED INNER DIA, 3/8 IN BUNDLE DIA	EA	1
B-8	28	PAFZZ	5310-00-765-3197		96906	MS27183-41	WASHER,FLAT .188 IN ID, .438 IN OD, .049 IN THK	EA	1
B-8	29	PAFZZ	5305-00-211-8193		96906	MS51849-54	SCREW,MACHINE HEX HD, NO 8-32UNC-2A,1/2 IN LG	EA	1
B-8	30	PAFZZ	4730-00-116-2969		70494	A58	CLAMP,HOSE	EA	2
B-8	31	PAFZZ	5305-01-054-2488		96906	MS3213-11	SCREW,MACHINE PAN HD,SELF-SEALING, NO 6-32UNC-2A,1/4 IN LG	EA	2
B-8	32	PAFZZ	5930-01-068-8812		81361	5-19-6261-2	SWITCH,PRESSURE	EA	1
B-8	33	PAFZZ	5940-00-681-8185		96906	MS35430-4	TERMINAL,LUG SOLDER TYPE,14-20 AWG WIRE,NO 6 STUD SIZE	EA	2
B-8	34	PAFZZ	5961-00-139-9812		81349	JAN1N5557	SEMICONDUCTOR DEVICE,DIODE	EA	1

TM3-4240-286-30&P		(2)	(3)	(4)	(5)	(6)	(7)	(8)	
ILLUSTRATION									
(A)	(B)		NATIONAL		PART			QTY	
FIG	ITEM	SMR	STOCK	FSCM	NUMBER	DESCRIPTION	USABLE ON CODE	INC	
NO.	NO.	CODE	NUMBER					IN	
								UNIT	
B-8	35	XAFZZ		81349	37TB10	TERMINAL BOARD		EA	2
B-8	36	PAFZZ	6135-01-053-0564	09823	CS1004	BATTERY, DRY CELL TYPE 225SC		EA	2
B-8	37	PAFZZ	6135-01-055-9627	09823	CS1005	BATTERY, DRY CELL TYPE 225SC		EA	2
B-8	38	XAFZZ		81361	E5-19-6377	HOUSING, COMPARTMENT CONTROL		EA	1
B-8	39	PAFZZ	5310-00-199-1056	96906	MS35650-3385	NUT, PLAIN, HEXAGON 3/8-24UNF-2B		EA	1
B-8	40	PAFZZ	5305-01-031-5092	96906	MS3213-33	SCREW, MACHINE PAN HD, SELF-SEALING, NO 10-32UNF-2A, 1/2 IN LG		EA	10
B-8	41	PAFZZ	5330-00-954-6684	80205	NAS1598-6Y	PACKING WITH RETAINER: 3/8 IN BOLT SIZE		EA	1
B-8	42	PAFZZ	4730-01-053-5923	81361	B5-19-6362	ADAPTER, STRAIGHT, HOSE		EA	1
B-8	43	PAFZZ	4730-01-017-5119	30327	KF03-02PS	ADAPTER, STRAIGHT, PIPE TO HOSE		EA	1
B-8	44	PAFZZ	5310-00-014-5850	96906	MS27183-42	WASHER, FLAT .219 IN ID, .500 IN. OD, .049 IN THK		EA	1
B-8	45	PAFZZ	5975-01-053-6294	09922	TF-5H	STRAP, TIEDOWN, CABLE		EA	1
B-8	46	MFFZZ		81349	MS086/1-20-9	WIRE, ELECTRICAL MFD FROM 6145-00-578-7519		FT	V
B-8	47	PAFZZ	5940-00-143-4771	96906	MS25036-103	TERMINAL, LUG CRIMP STYLE, 22-18 AWG WIRE SIZE, NO 10 STUD SIZE		EA	1
B-8	48	PAFZZ	5945-01-059-7074	81361	C5-19-6383	FLASHER, THERMAL E11		EA	1
B-8	49	PAFZZ	5940-00-825-3699	96906	MS17143-10	TERMINAL, LUG CRIMP STYLE, 22-18 AWG WIRE SIZE, NO 5 STUD SIZE		EA	43
B-8	50	PAFZZ	5999-01-048-9867	81361	D5-19-6193-10	PRINTED CIRCUIT BOARD, SWITCHING		EA	1
B-8	51	PAFZZ	5305-00-227-1543	96906	MS51849-33	SCREW, MACHINE HEX HD, NO 6-32UNC-2A, .38 IN LG		EA	2
B-8	52	PAFZZ	5310-00-045-4007	96906	MS35338-41	WASHER, LOCK SPRING, NO 6 NOM SIZE		EA	2
B-8	53	PAFZZ	5310-00-983-8483	96906	MS27183-5	WASHER, FLAT .156 IN ID, .312 IN OD, .035 IN THK		EA	2
B-8	54	PAFZZ	5999-01-050-4635	81361	C5-19-6197	PRINTED CIRCUIT BOARD: POWER		EA	1
B-8	55	PAFZZ	5305-01-033-2636	96906	MS3213-13	SCREW, MACHINE PAN HD, SELF-SEALING, NO 6-32UNC-2A, 3/8 IN LG		EA	4
B-8	56	PAFZZ	9905-01-052-3766	81361	C5-19-6316-7	PLATE, IDENTIFICATION: CONTROL MODULE COMPARTMENT		EA	1
B-8	57	PAFZZ	5999-01-070-8434	81361	C5-19-6382	SHIELDING GASKET, RFI		EA	1
B-8	58	XBFZZ	5935-00-715-2756	96906	MS3126F10-68	CONNECTOR, PLUG, ELECTRICAL		EA	1
B-8	59	PAFZZ	6135-01-052-3744	81361	B5-19-6659	RETAINER, BATTERY		EA	2
B-8	60	PAFZZ	5310-00-081-8087	96906	MS21044N06	NUT, SELF-LOCKING, HEXAGON: NO 6-32UNJC-3B		EA	4


THIS PAGE INTENTIONALLY LEFT BLANK



ARA81-0030

Figure B-9. M263 installation kit

TM3-4240-286-30&P									
(1)	(2)	(3)	(4)	(5)	(6)		(7)	(8)	
ILLUSTRATION					DESCRIPTION			QTY	
(a)	(b)	NATIONAL		PART				INC	
FIG	ITEM	STOCK		NUMBER		USABLE ON CODE		IN	
NO	NO	CODE		FSCM	NUMBER			U/M	UNIT
						GROUP 0300 M263 INSTALLATION KIT			
						PL5-19-6705			
B-9	1	PAOZZ	4730-01-049-0805	81361	C5-19-6182	COUPLING,AIR DUCT		EA	5
B-9	2	PAOZZ	4240-01-052-3783	81361	C5-19-6180	HOLDER,STORAGE,AIR DUCT		EA	9
B-9	3	PAOZZ	4240-01-061-7233	81361	E5-19-5908	FRAME,INTERFACE		EA	1
B-9	4	PAOZZ	4730-01-050-7540	30327	KF03-04RV	ADAPTER,STRAIGHT,TUBE TO HOSE		EA	1
B-9	5	PAOZZ	4730-01-067-9232	81361	C5-19-6654	ADAPTER,PIPE TO 1/4 NPS,7/16-20UNF-2A		EA	1
B-9	6	PAOZZ	5310-00-897-6081	96906	MS35691-32	NUT,PLAIN,HEXAGON JAM,7/16-20UNF-2B		EA	1
B-9	7	MOOZZ		81361	PL5-19-6705-20	HOSE,NONMETALLIC RUBBER,3/16 IN NOM ID MFD FROM 4720-00-065-8682		EA	1
B-9	8	PAOZZ	5330-01-054-0857	96906	MS90484-20-1	GASKET FLANGE MOUNT,ELECTRICAL CONNECTOR		EA	1
B-9	9	PAOZZ	5935-00-994-0294	96906	MS3119E20-16	ADAPTER,CONNECTOR RECEPTACLE,ELECTRICAL: THRU-BULKHEAD MTG.		EA	1
B-9	10	PAOZZ	5935-00-762-1392	96906	MS3181-20C	COVER,ELECTRICAL		EA	1
B-9	11	PAOOO	4720-01-074-9220	30299	0120-0600-0109	HOSE,AIR DUCT 6 IN ID,72 IN LG O/A		EA	8
B-9	12	PAOOO	4720-01-063-4567	30299	0120-0600-0106	HOSE,AIR DUCT 6 IN ID,36 IN LG O/A		EA	1
B-9	13	PAOZZ	4240-01-069-3494	81361	5-19-6160-40	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL: 72 IN NOM,LG EXCLUDINGTERMINATIONS		EA	1
B-9	14	PAOZZ	4240-01-068-2356	81361	5-19-6160-50	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL: 144 IN NOM LG EXCLUDINGTERMINATIONS		EA	1
B-9	15	PAOZZ	4240-01-073-3439	81361	5-19-6162-10	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL: 240 IN NOM LG EXCLUDINGTERMINATIONS		EA	1
B-9	14	PAOZZ	4240-01-067-9826	81361	5-19-6684	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL: 72 IN NOM LG EXCLUDINGTERMINATIONS		EA	1
B-9	17	PAOZZ	4240-01-067-8376	81361	5-19-6170-10	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL: 54 IN NOM LG EXCLUDINGTERMINATIONS		EA	1
B-9	18	PAOZZ	4240-01-068-2355	81361	5-19-6170-40	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL 76 IN NOM LG		EA	1
B-9	19	XBOOO		81361	D5-19-6628	AIRFLOW VALVE AND SILENCER		EA	1



▲ FURNISHED WITH BASIC ITEM

ARA81-0031

Figure B-10. Airflow valve and silencer

TM3-4240-286-30&P			(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION			(a)	(b)	NATIONAL		PART	DESCRIPTION		QTY
FIG	ITEM	SMR	STOCK			FSCM	NUMBER		USABLE ON CODE	INC
NO	NO	CODE	NUMBER							IN
										U/M
										UNIT
								GROUP 0310 AIRFLOW VALVE AND SILENCER		
								D5-19-6628		
B-10	1	PAOZZ	2990-01-057-3475			81361	C5-19-6627	MUFFLER, INTAKE		EA 1
B-10	2	PAOZZ	4730-00-908-6294			96906	MS35842-16	CLAMP, HOSE 4-1/8 TO 7 IN DIA RANGE		EA 2
B-10	3	PAOZZ	5305-00-179-8946			96906	MS51849-66	SCREW, MACHINE HEX HD, NO 10-32UNF-2A, 3/4 IN LG		EA 8
B-10	4	PAOFF	4240-01-055-1493			81361	E5-19-6136	VALVE, AIRFLOW		EA 1
B-10	5	PAOZZ	5330-01-088-4442			81361	5-19-6348	GASKET AIRFLOW VALVE		EA 1
B-10	6	PAOZZ	9905-01-051-0187			81361	B5-19-6656	PLATE, INSTRUCTION PROTECTIVE ENTRANCE		EA 1
B-10	7	XBOZZ				81361	C5-19-6626	STRAP, RETAINING		EA 1
B-10	8	PAOZZ	5305-00-157-5621			96906	MS51849-56	SCREW, MACHINE HEX HD, NO 8-32UNC-2A, 3/4 IN LG		EA 2
B-10	9	PAOZZ	5310-00-877-5797			96906	MS21044N3	NUT, SELF-LOCKING, HEXAGON: NO 10-32UNJF-3B		EA 8
B-10	10	XBOZZ				81361	D5-19-6625	BRACKET, MOUNTING		EA 1
B-10	11	PAOZZ	5310-00-811-3494			96906	MS21044N08	NUT, SELF-LOCKING, HEXAGON: NO 8-32UNJC-3B		EA 2
B-10	12	MOOZZ				81361	D5-19-6628-14	HOSE, NONMETALLIC 3.50 IN LG, MFD FROM 4720-01-106-4602		EA 1




Figure B-11, Airflow valve.

TM3-4240-286-30&P		(2)	(3)	(4)	(5)	(6)	(7)	(8)
ILLUSTRATION						DESCRIPTION		QTY
(a)	(b)		NATIONAL		PART			INC
FIG	ITEM	SMR	STOCK	FSCM	NUMBER		USABLE ON CODE	IN
NO	NO	CODE	NUMBER					UNIT
						GROUP 0311 AIRFLOW VALVE		
						E5-19-6136		
B-11	1	PAFZZ	6105-01-056-9045	25140	5A3128	GEARCASE-MOTOR PLANETARY,GEAR REDUCED		EA 1
B-11	2	PAFZZ	5940-00-113-9828	96906	MS25036-148	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO 4 STUD SIZE		EA 2
B-11	3	MFFZZ		81349	M5086/1-20-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7519		FT V
B-11	4	PAFZZ	5305-00-582-5808	96906	MS35265-31	SCREW,MACHINE FIL HD,NO 6-32UNC-2A,5/8IN LG		EA 4
B-11	5	PAOZZ	5310-00-811-3494	96906	MS21044N08	NUT,SELF-LOCKING,HEXAGON: NO 8-32UNC-3B		EA 3
B-11	6	PAFZZ	5975-01-053-6294	09922	TF-5H	STRAP,TIEDOWN,CABLE		EA 3
B-11	7	PAFZZ	5310-00-088-0551	96906	MS21044N04	NUT,SELF-LOCKING,HEXAGON: NO 4-4OUNJC-3B		EA 8
B-11	8	XAFZZ		81361	D5-19-6138	MOUNT,MOTOR		EA 1
B-11	9	PAFZZ	5310-00-081-8087	96906	MS21044N06	NUT,SELF-LOCKING,HEXAGON		EA 12
B-11	10	MFFZZ		81349	M5086/1-22-9	WIRE,ELECTRICAL MFD FROM 6145-00-578-7520		FT V
B-11	11	PAFZZ	5305-00-242-1264	96906	MS51849-13	SCREW,MACHINE HEX HD,NO 4-4OUNC-2A,.38 IN LG		EA 8
B-11	12	PAOZZ	5305-00-115-9934	96906	MS51849-55	SCREW,MACHINE HEX HD,NO 8-32UNC-2A,5/8 IN LG		EA 2
B-11	13	PAOZZ	9905-01-065-9382	81361	C5-19-6149	PLATE,IDENTIFICATION: AIRFLOW VALVE		EA 1
B-11	14	PAFZZ	5940-00-557-1629	96906	MS25036-149	TERMINAL,LUG CRIMP STYLE,22-18 AWG WIRE SIZE,NO S STUD SIZE		EA 6
B-11	15	PAOZZ	5310-00-765-3197	96906	MS27183-41	WASHER,FLAT .188 IN ID, .438 OD, .049 IN THK		EA 6
B-11	16	XAFZZ		81361	C5-19-6144	GEAR		EA 1
B-11	17	PAFZZ	5305-00-058-9362	96906	MS51977-19	SETSCREW HEX SOCKET,NO 6-32UNC-3A,3/16 IN LG		EA 1
B-11	18	PAFZZ	5305-00-984-6221	96906	MS35206-234	SCREW,MACHINE PAN HD,NO 6-32UNC-2A,1 IN LG		EA 8
B-11	19	PAOZZ	5305-00-157-5621	96906	MS51849-56	SCREW,MACHINE HEX HD,NO 8-32UNC-2A,3/4 IN LG		EA 1
B-11	20	PAOOO	5340-01-048-6327	81361	C5-19-6145	CAP,PROTECTIVE,DUST AND MOISTURE SEAL		EA 2
B-11	21	PAOZZ	4730-00-908-6294	96906	MS35842-16	CLAMP,HOSE 4-1/8 TO 7 IN DIA RANGE		EA 2
B-11	22	XAOZZ		81361	C5-19-6309	CAP,RUBBER		EA 2
B-11	23	AOOOO		99862	CL-2-FANDCL-2-C-8.0	CABLE		EA 2
B-11	24	MOOZZ		99862	CL-2-C-8.0	CABLE,NYLON: 8 IN LG MFD FROM 4010-00-069-5180		EA 2
B-11	25	PAOZZ	4030-00-878-8693	99862	CL2F	FERRULE,WIRE ROPE		EA 4
B-11	26	XAFZZ		81361	E9-19-6137	HOUSING,VALVE		EA 1
B-11	27	PAOZZ	9905-01-051-0186	81361	B5-19-6147	PLATE,INSTRUCTION TO SHELTER		EA 1
B-11	28	PAOZZ	9905-01-050-7556	81361	B5-19-6148	PLATE,INSTRUCTION TO PROT		EA 1
B-11	29	PAFZZ	5961-00-924-6981	81349	JAN1N4245	SEMICONDUCTOR DEVICE,DIODE		EA 2
B-11	30	PAFZZ	5930-00-913-7960	81349	MS25085-2	SWITCH,SENSITIVE		EA 2
B-11	31	PAFZZ	5910-00-114-0510	81349	M39014/01-1581	CAPACITOR,FIXED,CERAMIC		EA 2
B-11	32	PAFZZ	5930-00-296-9610	94135	1227903-178	ADAPTER,SWITCH ACTU		EA 2
B-11	33	PAFZZ	5915-01-075-7240	81361	C5-19-6152	FILTER,RADIO FREQUENCY INTERFERENCE		EA 1
B-11	34	MFFZZ		81349	M7078-3-22-1	CABLE,SPECIAL PURPOSE,ELECTRICAL: MFD FROM 6145-00-608-5484		FT V

TM3-4240-286-30&P									
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)		
ILLUSTRATION						DESCRIPTION			
(a)	(b)		NATIONAL				QTY	INC	
FIG	ITEM	SMR	STOCK	PART			IN	IN	
NO	NO	CODE	NUMBER	FSCM	NUMBER	USABLE ON CODE	U/M	UNIT	
GROUP 0500 BULK MATERIAL									
BULK	1	PAOZZ	4010-00-069-5180	99862	CL2C	CABLE,NYLON COVERED	FT		7
BULK	2	PAOZZ	4720-00-065-8682	30327	C403	HOSE,NONMETALLIC RUBBER 3/16 IN NOM ID	FT		13
BULK	3	PAOZZ	4720-00-996-0381	30327	44PRED	TUBIN,NONMETALLIC 1/4 IN OD, .040 IN WALL THK RED	FT		5
BULK	4	PAFZZ	6145-00-578-7517	81349	M5086/1-16-9	WIRE,ELECTRICAL 600 V,16AWG,STRANDED SINGLE CONDUCTOR, WHITE	FT		47
BULK	5	PAFZZ	6145-00-578-7519	81349	M5086/1-20-9	WIRE,ELECTRICAL 600 V,20 AWG,STRANDED SINGLE CONDUCTOR, WHITE	FT		35
BULK	6	PAFZZ	6145-00-578-7520	81349	M5086/1-22-9	WIRE,ELECTRICAL 600 V,22 AWG,STRANDED SINGLE CONDUCTOR, WHITE	FT		278
BULK	7	PAFZZ	6145-00-608-5484	81349	M7078-3-22-1	CABLE,SPECIAL PURPOSE,ELECTRICAL: 600 V,22 AWG, STRANDED SINGLECONDUCTOR,SHIE DED	FT		5
BULK	8	PAFZZ	9320-00-785-8171	81349	MIL-R-3065	RUBBER STRIP 1/16 IN NOM THK, 2FT X 2FT, GR SC4158F2G	SH		1
BULK	9	PAOZZ	4720-01-053-0316	30327	44PGREEN	TUBING,NONMETALLIC 1/4 IN OD, .040 IN WAL THK GREEN	FT		5
BULK	10	PAFZZ	9330-01-073-1011	81348	ZZ-R-765	TUBING NONMETALLIC: SILICONE RUBBER,GREEN,.188 IN ID, .375 IN OD, CL2B,OR 50	FT		4
BULK	11	PAOZZ	4720-01-106-4602	81361	B5-19-6716	HOSE,NONMETALLIC 6.000 IN ID,4.000 IN LG,50 PSI BURST PRESSURE	EA		1

SECTION III. SPECIAL TOOLS LIST

(NOT APPLICABLE)

SECTION IV NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIG. NO.	ITEM NO.	STOCK NUMBER	FIG. NO.	ITEM NO.
5310-00-014-5850	B-3	37	5330-00-248-3849	B-1	9
5310-00-014-5850	B-8	2	5330-00-250-0236	B-1	8
5310-00-014-5850	B-8	44	6350-00-267-0442	B-8	17
5925-00-045-1704	B-7	7	5305-00-269-3240	B-3	28
5925-00-045-1704	B-8	11	6220-00-283-9732	B-2	30
5310-00-045-3296	B-1	3	4720-00-288-9757	BULK	
5310-00-045-3299	B-1	24	5930-00-296-9610	B-11	32
5310-00-045-3299	B-1	33	5930-00-296-9610	B-5	32
5310-00-045-4007	B-2	45	5310-00-435-8983	B-1	31
5310-00-045-4007	B-8	52	5305-00-477-2713	B-4	8
5305-00-051-4075	B-3	44	6640-00-494-0527	B-8	26
5930-00-057-5848	B-2	7	5330-00-542-1329	B-7	34
5310-00-058-3599	B-2	34	5905-00-553-8100	B-7	14
5305-00-058-9362	B-11	17	5940-00-557-1629	B-11	14
5305-00-058-9362	B-5	17	5940-00-557-1629	B-2	16
4720-00-065-8682	BULK		5940-00-557-1629	B-5	14
5305-00-068-0513	B-3	22	5940-00-557-1629	B-7	41
4010-00-069-5180	BULK		5310-00-559-0070	B-2	15
5310-00-080-6004	B-3	26	5310-00-575-5292	B-2	9
5310-00-081-4219	B-3	43	6145-00-578-7517	BULK	
5310-00-081-8087	B-11	9	6145-00-578-7519	BULK	
5310-00-081-8087	B-2	51	6145-00-578-7520	BULK	
5310-00-081-8087	B-5	9	5310-00-579-0079	B-8	18
5310-00-081-8087	B-8	60	5305-00-582-5808	B-11	4
5310-00-088-0551	B-11	7	5305-00-582-5808	B-5	4
5310-00-088-0551	B-2	12	6145-00-608-5484	BULK	
5310-00-088-0551	B-5	7	5940-00-615-6073	B-2	11
5310-00-088-0551	B-7	13	5315-00-616-5526	B-4	2
5940-00-113-8179	B-2	35	6210-00-635-4700	B-2	17
5940-00-113-8179	B-7	1	6210-00-635-4700	B-8	12
5940-00-113-9828	B-11	2	5940-00-681-8185	B-7	23
5940-00-113-9828	B-5	2	5940-00-681-8185	B-8	33
5910-00-114-0510	B-11	31	5935-00-715-2756	B-8	58
5910-00-114-0510	B-5	31	5935-00-762-1392	B-9	10
5305-00-115-9406	B-1	32	6240-00-763-7744	B-2	22
5305-00-115-9934	B-1	11	6240-00-763-7744	B-8	8
5305-00-115-9934	B-11	12	5310-00-765-3197	B-1	12
5305-00-115-9934	B-3	12	5310-00-765-3197	B-11	15
5305-00-115-9934	B-5	12	5310-00-765-3197	B-3	13
4730-00-116-2969	B-7	43	5310-00-765-3197	B-5	15
4730-00-116-2969	B-8	30	5310-00-765-3197	B-8	28
5340-00-119-4705	B-3	40	5925-00-768-2035	B-7	8
5961-00-139-9812	B-7	24	9320-00-785-8171	BULK	
5961-00-139-9812	B-8	34	5310-00-809-4058	B-3	21
5940-00-143-4771	B-2	3	5310-00-809-8544	B-7	37
5940-00-143-4771	B-7	25	5310-00-809-8546	B-7	11
5940-00-143-4771	B-8	47	5310-00-810-1786	B-4	16
5940-00-143-4774	B-7	5	5310-00-811-3494	B-1	18
5940-00-143-4780	B-7	22	5310-00-811-3494	B-10	11
5330-00-143-8571	B-2	29	5310-00-811-3494	B-11	5
3110-00-144-8882	B-4	5	5310-00-811-3494	B-3	19
5305-00-148-1286	B-2	21	5310-00-811-3494	B-5	5
5305-00-148-1286	B-7	20	5310-00-811-3494	B-7	38
6240-00-155-7784	B-2	27	5940-00-813-0698	B-8	15
6240-00-155-7932	B-2	28	5925-00-814-8428	B-7	4
5305-00-157-5621	B-1	22	4730-00-817-1891	B-3	41
5305-00-157-5621	B-10	8	4730-00-817-1891	B-7	27
5305-00-157-5621	B-11	19	5355-00-821-5225	B-2	20
5305-00-157-5621	B-5	19	5305-00-824-7363	B-3	38
5310-00-167-0821	B-4	15	5940-00-825-3697	B-7	30
5310-00-167-0835	B-4	7	5940-00-825-3699	2	5
5305-00-179-8946	B-1	2	5940-00-825-3699	B-7	31
5305-00-179-8946	B-10	3	5940-00-825-3699	B-8	49
5305-00-179-8946	B-7	12	5930-00-847-2599	B-8	23
5305-00-179-8946	B-8	5	5930-00-854-7864	B-8	21
5305-00-180-4966	B-3	39	5310-00-877-5797	B-10	9
5310-00-187-2400	B-3	27	5310-00-877-5797	B-2	4
5310-00-199-1056	B-2	19	5310-00-877-5797	B-3	34
5310-00-199-1056	B-8	39	5310-00-877-5797	B-7	9
5945-00-201-9456	B-7	21	5310-00-877-5797	B-8	3
5940-00-204-8966	B-2	8	4030-00-878-8693	B-1	14
5940-00-204-8966	B-7	3	4030-00-878-8693	B-11	25
5305-00-211-8193	B-1	21	4030-00-878-8693	B-3	15
5305-00-211-8193	B-8	29	4030-00-878-8693	B-5	25
5305-00-227-1543	B-2	44	5305-00-889-2999	B-2	32
5305-00-227-1543	B-8	51	6220-00-891-1491	B-2	25
5310-00-227-4882	B-4	6	6240-00-892-4420	B-7	18
4240-00-237-0227	B-3	1	5310-00-897-6081	B-1	35
5305-00-242-1264	B-11	11	5310-00-897-6081	B-9	6
5305-00-242-1264	B-5	11	4730-00-908-6294	B-1	17

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
4730-00-908-6294	B-10	2	5365-01-053-2593	B-4	13
4730-00-908-6294	B-113	21	9905-01-053-3006	B-2	37
4730-00-908-6294	B-3	18	3120-01-053-5848	B-4	11
4730-00-908-6294	B-5	21	4730-01-053-5923	B-2	38
5935-00-912-9599	B-1	29	4730-01-053-5923	B-8	42
5930-00-913-7960	B-11	30	5975-01-053-6294	B-11	6
5930-00-913-7960	B-5	30	5975-01-053-6294	B-5	6
5961-00-924-6981	B-11	29	5975-01-053-6294	B-7	10
5961-00-924-6981	B-5	29	5975-01-053-6294	B-8	4
5961-00-924-6981	B-8	20	5975-01-053-6294	B-8	45
5330-00-928-0290	B-2	41	5330-01-054-0857	B-9	8
5310-00-928-9821	B-1	23	5305-01-054-2488	B-8	31
5310-00-928-9821	B-1	37	5925-01-054-3452	B-8	14
5310-00-934-9748	B-2	10	5925-01-054-3453	B-8	10
5330-00-954-6684	B-2	18	9905-01-054-4263	B-4	19
5330-00-954-6684	B-2	39	5310-01-054-4643	B-1	28
5330-00-954-6684	B-8	41	4240-01-054-7020	B-3	10
5975-00-958-6451	B-7	17	4240-01-055-1493	B-10	4
5975-00-958-6451	B-8	9	4240-01-055-1493	B-3	36
5305-00-978-9369	B-4	12	5930-01-055-9249	B-7	44
5410-00-981-8701	B-1	27	6135-01-055-9627	B-8	37
5310-00-983-8483	B-2	46	6685-01-056-5283	B-2	49
5310-00-983-8483	B-8	53	6685-01-056-5283	B-8	24
5305-00-984-4976	B-2	33	6105-01-056-9045	B-11	1
5305-00-984-6221	B-11	18	6105-01-056-9045	B-5	1
5305-00-984-6221	B-5	18	4240-01-057-3378	B-3	3
5340-00-989-9224	B-7	42	4240-01-057-3474	B-6	4
5340-00-989-9224	B-8	27	2990-01-057-3475	B-10	1
5935-00-990-5580	B-1	30	3110-01-057-4653	B-4	10
5935-00-994-0294	B-9	9	4520-01-057-7010	B-3	45
4720-00-996-0381	BULK		5305-01-057-7206	B-2	24
5305-01-006-8953	B-7	32	5365-01-057-7379	B-3	42
4730-01-017-5119	B-1	7	4140-01-059-2095	B-3	20
4730-01-017-5119	B-8	43	5945-01-059-7074	B-8	48
5305-01-031-5092	B-6	3	9905-01-061-7139	B-1	25
5305-01-031-5092	B-8	40	4240-01-061-7233	B-9	3
5305-01-033-2636	B-8	55	4720-01-063-4567	B-9	12
9905-01-048-2790	B-1	26	9905-01-065-3065	B-7	28
4240-01-048-2803	B-1	4	9905-01-065-9382	B-11	13
4240-01-048-2923	B-1	1	9905-01-065-9382	B-5	13
5340-01-048-6327	B-1	10	9905-01-066-3084	B-3	32
5340-01-048-6327	B-11	20	4240-01-066-3266	B-3	5
5340-01-048-6327	B-3	11	5925-01-067-5437	B-7	6
5340-01-048-6327	B-5	20	4240-01-067-5605	B-3	4
5999-01-048-9865	B-7	26	4240-01-067-8376	B-9	17
5999-01-048-9866	B-8	13	9905-01-067-8634	B-3	31
5999-01-048-9867	B-8	50	4730-01-067-9232	B-1	36
4240-01-049-0804	B-1	34	4730-01-067-9232	B-9	5
4730-01-049-0805	B-9	1	5330-01-068-0515	B-3	30
9905-01-049-1385	B-1	20	4240-01-068-2355	B-9	18
5930-01-050-4362	B-8	16	4240-01-068-2356	B-9	14
5999-01-050-4635	B-2	43	9905-01-068-2368	B-1	19
5999-01-050-4635	B-8	54	4240-01-068-8645	B-3	7
5999-01-050-4636	B-2	47	5930-01-068-8812	B-8	32
4730-01-050-7540	B-1	5	4240-01-069-3494	B-9	13
4730-01-050-7540	B-9	4	5330-01-069-9824	B-3	24
9905-01-050-7556	B-11	28	4240-01-069-9826	B-9	16
9905-01-050-7556	B-5	28	5999-01-070-8434	B-8	57
9905-01-050-7557	B-3	33	9905-01-071-5711	B-3	2
9905-01-051-0186	B-11	27	9330-01-073-1011	BULK	
9905-01-051-0186	B-5	27	4240-01-073-3439	B-9	15
9905-01-051-0187	B-10	6	5999-01-074-8880	B-6	1
6135-01-052-3744	B-8	59	4720-01-074-9220	B-9	11
9905-01-052-3766	B-8	56	5915-01-075-7240	B-11	33
4240-01-052-3783	B-9	2	5915-01-075-7240	B-5	33
5930-01-052-7684	B-2	23	5330-01-085-3267	B-2	48
5930-01-052-7684	B-8	7	5330-01-088-4442	B-10	5
4320-01-052-7999	B-4	4	5330-01-088-4442	B-3	35
4720-01-053-0316	BULK		5950-01-091-8626	B-7	39
6135-01-053-0564	B-8	36	5915-01-096-8853	B-7	35
5305-01-053-0958	B-7	15	4240-01-107-2433	B-3	23
5305-01-053-0959	B-7	19	5930-01-108-2588	B-8	22
5305-01-053-0960	B-7	33	6645-01-113-2525	B-2	14

FSCM	PART NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
88044	AN960-416L	B-4	7	88044	AN960PD616	B-3	27
88044	AN960-616	B-4	15	70494	A5S	B-7	43

FSCM	PART NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
70494	A5S	B-8	30	81361	D5-19-6262	B-3	5
81361	B5-19-5710	B-8	19	81361	D5-19-6353	B-7	35
81361	B5-19-6030-1	B-4	13	81361	D5-19-6368	B-3	6
81361	B5-19-6081	B-4	4	81361	D5-19-6378	B-8	6
81361	B5-19-6133	B-3	33	81361	D5-19-6392	B-6	1
81361	B5-19-6134	B-3	31	81361	D5-19-6397	B-7	39
81361	B5-19-6147	B-11	27	81361	D5-19-6401	B-3	45
81361	B5-19-6147	B-5	27	81361	D5-19-6625	B-10	10
81361	B5-19-6148	B-11	28	81361	D5-19-6628	B-9	19
81361	B5-19-6148	B-5	28	81361	D5-19-6628-14	B-10	12
81361	B5-19-6238	B-1	26	81361	E5-19-5908	B-9	3
81361	B5-19-6254	B-4	11	81361	E5-19-6120	B-3	23
81361	B5-19-6261-1	B-7	44	81361	E5-19-6128	B-3	25
81361	B5-19-6347	B-3	42	81361	E5-19-6136	B-10	4
81361	B5-19-6362	B-2	38	81361	E5-19-6136	B-3	36
81361	B5-19-6362	B-8	42	81361	E5-19-6201-20	B-1	1
81361	B5-19-6656	B-10	6	81361	E5-19-6240	B-3	20
81361	B5-19-6659	B-8	59	81361	E5-19-6241	B-4	1
99862	CL-2-C-8.0	B-11	24	81361	E5-19-6251	B-4	17
99862	CL-2-C-8.0	B-1	15	81361	E5-19-6314-20	B-3	10
99862	CL-2-C-8.0	B-3	16	81361	E5-19-6357	B-1	4
99862	CL-2-C-8.0	B-5	24	81361	E5-19-6357-47	B-2	50
99862	CL-2-FANDCL-2-C-8.0	B-11	23	81361	E5-19-6358	B-2	40
99862	CL-2-FANDCL-2-C-8.0	B-1	13	81361	E5-19-6360	B-2	1
99862	CL-2-FANDCL-2-C-8.0	B-3	14	81361	E5-19-6376	B-3	3
99862	CL-2-FANDCL-2-C-8.0	B-5	23	81361	E5-19-6376-155	B-2	23
99862	CL2C	BULK		81361	E5-19-6376-155	B-8	7
99862	CL2F	B-11	25	81361	E5-19-6376-159	B-8	22
99862	CL2F	B-1	14	81361	E5-19-6376-46	B-8	25
99862	CL2F	B-3	15	81361	E5-19-6377	B-8	38
99862	CL2F	B-5	25	81361	E5-19-6387	B-3	7
9823	CS1004	B-8	36	81361	E5-19-6390	B-6	2
9823	CS1005	B-8	37	81361	E5-19-6391	B-6	4
30327	C403	B-1	6	81361	E5-19-6391-52	B-7	29
30327	C403	BULK		81361	E5-19-6402	B-3	1
81361	C5-19-5676	B-2	36	81361	E5-19-6402-7	B-3	9
81361	C5-19-5687-1	B-3	30	81361	E5-19-6402-8	B-3	8
81361	C5-19-5687-2	B-3	24	81361	E9-19-6137	B-11	26
81361	C5-19-6144	B-11	16	81361	E9-19-6137	B-5	26
81361	C5-19-6144	B-5	16	92830	F1240-008	B-4	6
81361	C5-19-6145	B-11	20	81349	JANIN4245	B-11	29
81361	C5-19-6145	B-1	10	81349	JANIN4245	B-5	29
81361	C5-19-6145	B-3	11	81349	JANIN4245	B-8	20
81361	C5-19-6145	B-5	20	81349	JANIN5557	B-7	24
81361	C5-19-6149	B-11	13	81349	JANIN5557	B-8	34
81361	C5-19-6149	B-5	13	30327	KF03-02PS	B-1	7
81361	C5-19-6152	B-11	33	30327	KF03-02PS	B-8	43
81361	C5-19-6152	B-5	33	30327	KF03-04RV	B-1	5
81361	C5-19-6175	B-1	20	30327	KF03-04RV	B-9	4
81361	C5-19-6180	B-9	2	79919	K35B1	B-2	20
81361	C5-19-6182	B-9	1	81349	MIL-R-3065	BULK	
81361	C5-19-6197	B-2	43	96906	MS16997-31	B-4	12
81361	C5-19-6197	B-8	54	96906	MS17143-10	B-2	5
81361	C5-19-6236	B-1	34	96906	MS17143-10	B-7	31
81361	C5-19-6247	B-4	3	96906	MS17143-10	B-8	49
81361	C5-19-6255	B-4	10	96906	MS17143-11	B-7	30
81361	C5-19-6258-1	B-4	19	96906	MS21042-6	B-4	16
81361	C5-19-6309	B-11	22	96906	MS21044N04	B-11	7
81361	C5-19-6309	B-1	16	96906	MS21044N04	B-2	12
81361	C5-19-6309	B-3	17	96906	MS21044N04	B-5	7
81361	C5-19-6309	B-5	22	96906	MS21044N04	B-7	13
81361	C5-19-6316-10	B-1	25	96906	MS21044N06	B-11	9
81361	C5-19-6316-4	B-2	37	96906	MS21044N06	B-2	51
81361	C5-19-6316-6	B-7	28	96906	MS21044N06	B-5	9
81361	C5-19-6316-7	B-8	56	96906	MS21044N06	B-8	60
81361	C5-19-6382	B-8	57	96906	MS21044N08	B-10	11
81361	C5-19-6383	B-8	48	96906	MS21044N08	B-11	5
81361	C5-19-6415	B-7	26	96906	MS21044N08	B-1	18
81361	C5-19-6626	B-10	7	96906	MS21044N08	B-3	19
81361	C5-19-6627	B-10	1	96906	MS21044N08	B-5	5
81361	C5-19-6654	B-1	36	96906	MS21044N08	B-7	38
81361	C5-19-6654	B-9	5	96906	MS21044N3	B-10	9
81361	C5-19-6688	B-8	13	96906	MS21044N3	B-2	4
81361	D5-19-6138	B-11	8	96906	MS21044N3	B-3	34
81361	D5-19-6138	B-5	8	96906	MS21044N3	B-7	9
81361	D5-19-6193-10	B-8	50	96906	MS21044N3	B-8	3
81361	D5-19-6193-20	B-2	47	96906	MS24143D1	B-7	21
81361	D5-19-6242	B-4	9	96906	MS24658-21M	B-2	7
81361	D5-19-6252	B-4	14	96906	MS24660-23D	B-8	23
81361	D5-19-6260	B-3	29	96906	MS24679-2	B-1	23

FSCM	PART NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
96906	MS24679-2	B-1	37	96906	MS35478-307	B-2	27
96906	MS25036-101	B-8	15	96906	MS35649-244	B-2	10
96906	MS25036-102	B-2	8	96906	MS35650-3385	B-2	19
96906	MS25036-102	B-7	3	96906	MS35650-3385	B-8	39
96906	MS25036-103	B-2	3	96906	MS35691-32	B-1	35
96906	MS25036-103	B-7	25	96906	MS35691-32	B-9	6
96906	MS25036-103	B-8	47	96906	MS35756-8	B-4	2
96906	MS25036-107	B-2	35	96906	MS35842-16	B-10	2
96906	MS25036-107	B-7	1	96906	MS35842-16	B-11	21
96906	MS25036-108	B-7	22	96906	MS35842-16	B-1	17
96906	MS25036-148	B-11	2	96906	MS35842-16	B-3	18
96906	MS25036-148	B-5	2	96906	MS35842-16	B-5	21
96906	MS25036-149	B-11	14	96906	MS51849-13	B-11	11
96906	MS25036-149	B-2	16	96906	MS51849-13	B-5	11
96906	MS25036-149	B-5	14	96906	MS51849-14	B-7	15
96906	MS25036-149	B-7	41	96906	MS51849-33	B-2	44
96906	MS25036-152	B-2	11	96906	MS51849-33	B-8	51
96906	MS25036-153	B-7	5	96906	MS51849-53	B-1	32
81349	MS25085-2	B-11	30	96906	MS51849-54	B-1	21
81349	MS25085-2	B-5	30	96906	MS51849-54	B-8	29
96906	MS25235R311	B-2	28	96906	MS51849-55	B-11	12
96906	MS25281R6	B-7	42	96906	MS51849-55	B-1	11
96906	MS25281R6	B-8	27	96906	MS51849-55	B-3	12
96906	MS25358-3	B-2	26	96906	MS51849-55	B-5	12
96906	MS25358-4	B-2	30	96906	MS51849-56	B-10	8
96906	MS25358-5	B-2	31	96906	MS51849-56	B-11	19
96906	MS25358-6	B-2	29	96906	MS51849-56	B-1	22
96906	MS25358-7	B-2	25	96906	MS51849-56	B-5	19
96906	MS27183-10	B-3	21	96906	MS51849-64	B-3	39
96906	MS27183-12	B-3	43	96906	MS51849-66	B-10	3
96906	MS27183-14	B-3	26	96906	MS51849-66	B-1	2
96906	MS27183-41	B-11	15	96906	MS51849-66	B-7	12
96906	MS27183-41	B-1	12	96906	MS51849-66	B-8	5
96906	MS27183-41	B-3	13	96906	MS51977-19	B-11	17
96906	MS27183-41	B-5	15	96906	MS51977-19	B-5	17
96906	MS27183-41	B-8	28	96906	MS521301B225360	BULK	
96906	MS27183-42	B-3	37		MS90484-20-1	B-9	8
96906	MS27183-42	B-8	2	96906	MS90727-33	B-3	44
96906	MS27183-42	B-8	44	96906	MS90727-6	B-3	22
96906	MS27183-5	B-2	46	96906	MS90727-64	B-3	28
96906	MS27183-5	B-8	53	96906	MS9352-05	B-3	40
96906	MS27183-7	B-7	37	81349	M15098/11-001	B-7	18
96906	MS27183-8	B-7	11	81349	M39014/01-1581	B-11	31
96906	MS28775-120	B-7	34	81349	M39014/01-1581	B-5	31
96906	MS29513-019	B-1	9	81349	M5086/1-16-9	B-2	6
96906	MS29513-024	B-1	8	81349	M5086/1-16-9	B-7	36
96906	MS3116P16-8P	B-4	18	81349	M5086/1-16-9	BULK	
96906	MS3119E20-16	B-9	9	81349	M5086/1-20-9	B-11	3
96906	MS3126F10-6S	B-8	58	81349	M5086/1-20-9	B-2	2
96906	MS3181-10N	B-1	29	81349	M5086/1-20-9	B-5	3
96906	MS3181-14N	B-1	30	81349	M5086/1-20-9	B-7	2
96906	MS3181-20C	B-9	10	81349	M5086/1-20-9	B-8	46
96906	MS3186-34	B-1	28	81349	M5086/1-20-9	BULK	
96906	MS3186-43	B-1	31	81349	M5086/1-22-9	B-11	10
96906	MS3213-11	B-8	31	81349	M5086/1-22-9	B-2	13
96906	MS3213-13	B-8	55	81349	M5086/1-22-9	B-5	10
96906	MS3213-14	B-7	19	81349	M5086/1-22-9	B-7	40
96906	MS3213-24	B-7	33	81349	M5086/1-22-9	B-8	1
96906	MS3213-27	B-7	32	81349	M5086/1-22-9	BULK	
96906	MS3213-33	B-6	3	81349	M7078-3-22-1	B-11	34
96906	MS3213-33	B-8	40	81349	M7078-3-22-1	B-5	34
96906	MS3213-36	B-2	21	81349	M7078-3-22-1	BULK	
96906	MS3213-36	B-7	20	80205	NAS1096-3-12	B-3	38
96906	MS3213-5	B-2	24	80205	NAS1351-4-12	B-4	8
96906	MS3213-5	B-2	24	80205	NAS1351-4-12	B-4	8
96906	MS35206-217	B-2	32	80205	NAS1598-06Y	B-2	41
96906	MS35206-219	B-2	33	80205	NAS1598-6Y	B-2	18
96906	MS35206-234	B-11	18	80205	NAS1598-6Y	B-2	39
96906	MS35206-234	B-5	18	80205	NAS1598-6Y	B-8	41
96906	MS35265-31	B-11	4	81361	PL5-19-6705-20	B-9	7
96906	MS35265-31	B-5	4	87137	PTL-A1(3-C7A)	B-7	16
96906	MS35333-37	B-8	18	33107	P92-1020	B-2	49
96906	MS35333-38	B-2	15	33107	P92-1020	B-8	24
96906	MS35335-57	B-2	34	81349	RER70F1100R	B-7	14
96906	MS35338-41	B-2	45	37942	SC628M	B-8	17
96906	MS35338-41	B-8	52	9922	TF-5H	B-11	6
96906	MS35338-42	B-1	24	9922	TF-5H	B-5	6
96906	MS35338-42	B-1	33	9922	TF-SH	B-7	10
96906	MS35338-43	B-1	3	9922	TF-5H	B-8	45
96906	MS35430-4	B-7	23	76854	VM911MB	B-2	17
96906	MS35430-4	B-8	33	76854	VM911M8	B-8	12

FSCM	PART NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
81348	W-L-00111/7	B-2	22	81361	5-19-6170-40	B-9	18
81348	W-L-00111/7	B-8	8	81361	5-19-6261-2	B-8	32
81348	ZZ-R-765	BULK		81361	5-19-6316-9	B-3	2
30299	0120-0600-0106	B-9	12	81361	5-19-6348	B-10	5
30299	0120-0600-0109	B-9	11	81361	5-19-6348	B-3	35
18876	10231240	B-7	4	81361	5-19-6361	B-2	48
94135	1227903-178	B-11	32	81361	5-19-6657	B-1	19
94135	1227903-178	B-5	32	81361	5-19-6684	B-9	16
82647	14500-1	B-7	17	81361	5-19-6718	B-3	4
82647	14500-1	B-8	9	25140	5A3128	B-11	1
38443	201SFP	B-4	5	25140	5A3128	B-5	1
30327	261P1-4	B-3	41	12909	500881	B-2	42
30327	261P1-4	B-7	27	5178	6152	B-8	26
83330	2660	B-2	9	82647	6752-320-20	B-7	6
81349	37TB10	B-8	35	79919	71015	B-2	14
4426	44-580151AAAA	B-8	16	82647	7274-12-1	B-7	7
30327	44PGREEN	BULK		82647	7274-12-1	B-8	11
30327	44PRED	BULK		82647	7274-12-1-1-2	B-7	8
81361	5-19-6135	B-3	32	82647	7274-34-1	B-8	14
81361	5-19-6160-40	B-9	13	82647	7274-34-3/4	B-8	10
81361	5-19-6160-50	B-9	14		8173	B-1	27
81361	5-19-6162-10	B-9	15		9745533	B-8	21
81361	5-19-6170-10	B-9	17				

APPENDIX C
EXPENDABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

C-1. SCOPE. This appendix lists expendable supplies and materials you will need to operate and maintain the collective protection equipment. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

C-2. EXPLANATION OF COLUMNS.

a. *Column 1, Item Number.* This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., *Use dry-cleaning solvent, item 4, app C*).

b. *Column 2, Level.* This column identifies the lowest level of maintenance that requires the listed item.

- O - Organizational Maintenance
- F - Direct Support Maintenance

c. *Column 3, National Stock Number.* This is the National stock number assigned to the item; use it to request or requisition the item.

d. *Column 4, Description.* Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.

e. *Column 5, Unit of Measure (U/M).* Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION	(5) U/M
1	O	8040-00-165-8614	ADHESIVE, BONDING VULCANIZED: (81348) MMM-A-121 1 qt can	QT
2	O	7920-00-543-7728	BRUSH, ACID SWABBING: bristle (81348) HB643	EA
3	O	8010-01-055-2319	COATING, ALIPHATIC POLYURETHANE: two part kit, 1 gal pigment and polyester, 1 qt catalyst (81349) MIL-C-46168	KT
4	O	6850-00-281-1985	DRY CLEANING SOLVENT: 1 gal can (81348) P-D-680	GL
5	F	9150-00-944-8953	GREASE, AIRCRAFT, GENERAL PURPOSE: wide temperature range (81349) MIL-G-81322 1 lb can	CN


(1)	(2)	(3)	(4)	(5)
Item Number	Level	National Stock Number	Description	U/M
6	F	5970-00-812-2969	INSULATION SLEEVING:BLACK,MF 100,1/8 X 1 FT LG (06090)	FT
7	0	8010-00-142-9279	PRIMER COATING: 1 QT,TWO PART KIT,CLASS 2 (81349)MIL-P-23377	KT
8	0	7920-00-205-1711	RAG,WIPING: COTTON DESIGNED FOR GENERAL PURPOSE USE (81348) DDD-R-30 5- LB BALE	EA
9	F	8030-00-889-3535	TAPE,ANTISEIZING: 1/2 IN WIDE, 260 IN LG (81349)MIL-T-27730	EA
10	0	7510-00-663-3738	TAPE: OLIVE DRAB,3 WIDE TYPE 3,CLASS 1 (80244)PPP-T-60 ROLL	EA

APPENDIX D
ILLUSTRATED LIST OF MANUFACTURED ITEMS

D-1. INTRODUCTION.

a. This appendix includes complete instruction for making items authorized to be manufactured or fabricated at direct support maintenance level.


b. All bulk materials needed for manufacture of an item are listed by National Stock Number in a tabular list on the illustration.



NOTES:

1. FABRICATE FROM NSN 9320-00-785-8171 STOCK.
2. ALL DIMENSIONS ARE IN INCHES.

Figure D-1. Gasket



NOTES:

1. FABRICATE FROM NSN 9320-00-785-8171 STOCK.
2. ALL DIMENSIONS ARE IN INCHES.

Figure D-2. Gasket

INDEX

Subject	Page	Subject	Page
A		M	
Airflow Valve		Main Fan	
Maintenance Instructions	2-150	Maintenance Instructions	2-144
Troubleshooting	2-33	Troubleshooting	2-32
Appendix A, References	A-1	Maintenance Forms and Records	1-1
Appendix B, Repair Parts and Special Tools		Maintenance Instructions	
List	B-1	Airflow Valve	2-150
Appendix C, Expendable Supplies and Materials		Compartment Control Module	2-171
List	C-1	Main Fan	2-144
Appendix D, Illustrated List of Manufactured		Power Distribution Unit	2-161
Items	D-1	Protective Entrance Control Module	2-137
C		P	
Compartment control Module		Power Distribution Unit	
Maintenance Instructions	2-171	Maintenance Instructions	2-162
Troubleshooting	2-63	Troubleshooting	2-39
D		Pressure Control System	1-2
Destruction of Material to Prevent		Principles of Operation	1-2
Enemy Use	1-1	Protective Entrance Control Module	
E		Maintenance Instructions	2-137
Expendable Supplies and Materials List,		Troubleshooting	2-2
Appendix C	C-1	R	
F		References, Appendix A	A-1
Flow Chart Procedures	2-1	Repair Parts and Special Tools List, Appendix B	B-1
L		Reporting Equipment Improvement Recommen-	1-1
Loss of Power/Pressure Warning System	1-4	dations	
		T	
		Troubleshooting	
		Airflow Valve	2-33
		Compartment Control Module	2-63
		Main Fan	2-32
		Power Distribution Panel	2-39
		Protective Entrance Control Module	2-2

By Order of the Secretary of the Army:

E. C. MEYER
General, *United States Army*
Chief of Staff

Official:

ROBERT M. JOYCE
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION :

To be distributed in accordance with DA Form 12-28, Direct and General Support Maintenance Requirements for Collective Protection Equipment and DA Form 12-32, Direct and General Support Maintenance Requirements for AN/TSQ-73 Missile System.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)
Your mailing address

DATE SENT
Date you fill out this form

PUBLICATION NUMBER
TM 3-4240-286-30&P

PUBLICATION DATE
24 Aug 82

PUBLICATION TITLE
COLLECTIVE PROTECTION EQUIPMENT, GUIDED MISSILE AIR DEFENSE SYSTEM, AN/TSQ-73

BE EXACT... PIN-POINT WHERE IT IS				IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:
PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.	
1-1	1-4			ITEM 1. LINE 12. Change "Rock Island, IL 61201" to read, "Aberdeen Proving Ground, MD 21010." REASON: Wrong address.
2-28	2-12			ITEM 2. Test equipment. Add, "28V dc power supply capable of delivery 2 amps" REASON: Incomplete information.
2-43	2-14			ITEM 3. Add callout "20" to the shaft slinger in the illustration. REASON: Callout missing from illustration.

SAMPLE

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER
JOHN SMITH, S.SGT. 793/XXXX

SIGN HERE
John Smith

TEAR ALONG DOTTED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



*THEN... JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM. CAREFULLY TEAR
IT OUT. FOLD IT AND DROP
IT IN THE MAIL!*

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER
TM 3-4240-286-30&P

PUBLICATION DATE
24 Aug 82

PUBLICATION TITLE COLLECTIVE PROTECTION EQUIPMENT, GUIDED MISSILE AIR DEFENSE SYSTEM, AN/TSQ-73

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.

TEAR ALONG DOTTED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE, \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD-314



TEAR ALONG DOTTED LINE

Commander
US Army Armament Materiel Readiness Command
ATTN: DRSAR-MAS-C
Aberdeen Proving Ground, MD 21010

THE METRIC SYSTEM AND EQUIVALENTS

WEIGHT MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 lb.
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

TEMPERATURE

$5/9(^{\circ}\text{F} - 32) = ^{\circ}\text{C}$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $9/5^{\circ}\text{C} + 32 = ^{\circ}\text{F}$

APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
its	Liters	0.473
arts	Liters	0.946
allons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
ers	Gallons	0.264
ms	Ounces	0.035
ograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pounds-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
ometers per Liter	Miles per Gallon	2.354
ometers per Hour	Miles per Hour	0.621



PIN: 051449-001