


TECHNICAL MANUAL

**OPERATOR'S UNIT AND DIRECT SUPPORT
MAINTENANCE MANUAL**

**CENTRIFUGAL PUMP UNIT
1 1/2" SUCTION & DISCHARGE
24 VOLT DC ELECTRIC MOTOR DRIVEN**



This copy is a reprint which includes current pages from Change 1.

CHANGE

NO. 1

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., 16 SEPTEMBER 1992

Operator's, Unit and Direct Support
Maintenance Manual

**CENTRIFUGAL PUMP UNIT
1-1/2" SUCTION & DISCHARGE
24 VOLT, DC, ELECTRIC MOTOR DRIVEN**

Distribution authorized to U.S. Government agencies only due to limited rights to data enclosed herein. This determination was made on 7 February 1989. Other requests for this document will be referred to AMCPM-PWL, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798.

DESTRUCTION NOTICE For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

TM 10-4320-314-13&P, 15 June 1990 is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

6-1 and 6-2


Insert pages

6-1 and 6-2

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:



MILTON H. HAMILTON
*Administrative Assistant to the
Secretary of the Army*

02448

GORDON R. SULLIVAN
*General, United States Army
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25E qty rqr block no. 4853, requirements for TM 10-4320-314-13&P.

Current as of 10 January 1990


REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in the back of this manual directly to: Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

This technical manual is an authentication of the manufacturer's commercial literature and does not conform with the format and the content requirements normally associated with Army technical manuals. This technical manual does, however, contain all essential information required to operate and maintain the equipment.

Distribution authorized to U.S. Government agencies only due to limited rights to data enclosed herein. This determination was made on 7 February 1989. Other requests for this document will be referred to AMCPM-PWL, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798.

DESTRUCTION NOTICE For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.



Returned Goods: Written permission must be obtained before returning any material. Material returned for credit will be subject to a factory inspection. Credit for products within the warranty period will be subject to a rehandling charge. Returns must be shipped with transportation charges prepaid. Special non-catalog items cannot be returned.

Freight F.O.B. shipping point. Examine shipment upon arrival to ascertain if in good order. Any shortages or damage should be noted on Bill of Lading before signing.

SAFETY PRECAUTIONS

The following are general safety precautions that are not related to any specific procedures and therefore do not appear elsewhere in this publication. These are recommended precautions that personnel must understand and apply during many phases of operation and maintenance of the equipment covered herein. Should situations arise that are not covered in the general or specific safety precautions, the Commanding Officer or other authority will issue orders deemed necessary to cover the situation.

KEEP AWAY FROM LIVE CIRCUITS

Operating personnel must at all times observe all safety regulations. Do not replace components or make adjustments inside the equipment with the voltage supply turned on. Under certain conditions, dangerous potentials may exist when the power control is in the off position. To avoid casualties, always remove power and discharge and ground a circuit before touching it, or connecting or disconnecting meters or test leads.

DO NOT SERVICE OR ADJUST ALONE

Under no circumstances should repair or adjustment of energized equipment be attempted alone.

RESUSCITATION

Personnel working with or near high voltages should be familiar with modern methods of resuscitation. Should someone be injured and stop breathing, initiate resuscitation immediately. A delay could cost the victim's life.

GENERAL PRECAUTIONS

All circuits not known to be dead must be considered alive at all times.

Do not wear loose clothing when working on rotating equipment.

When working near electricity, do not use metal rules, flashlights, metallic pencils or any other object having exposed conducting material.

Before making any test, repairs or adjustments, be sure to protect yourself against grounding and be sure the frame of the motor and the motor controller are securely grounded.

Priming and sample taking operations using the centrifugal pump unit results in fuel being discharged directly from the sample hose on the ground in the immediate vicinity of the pump. All precautions to prevent fuel ignition, explosion and fire must be taken.

Do not operate DC motor until motorpump case is full of fuel. Dry operation will harm the motorpump mechanical seal.

SECTION 1 INTRODUCTION

1-1. DESCRIPTION.

1-2. The centrifugal pump unit, hereinafter referred to as the unit, is a self-contained fueling system Consisting of the major Components illustrated in figure 1-1.

1-3. The motorpump is powered by a 1/2 Horsepower 24 Volt DC permanent magnet motor. Fuel enters through the suction strainer. The fuel flows through two 25 foot suction hoses to the motorpump. The motorpump discharges the fuel through two 25 foot discharge hoses. The fuel flows under pressure to the discharge nozzle and into vehicles or containers.

1-4. The unit contains a hand pump which is used to sample fuel and initially fill the motorpump case. This process of falling the motorpump case prior to operation is called priming.

1-5. The hand pump is a hand operated plunger piston pump. It is connected to the motorpump case by a hose. The hand pump is isolated from the motorpump by a ball valve.

1-6. The unit is connected to the 24 Volt DC power source by a 15 foot power cable. The cable terminates with a power plug.

1-7. The electrical controls include a circuit breaker for overload and short circuit protection, The motor contains an electrical thermal protection device which senses approaching overheat conditions in the motor housing and shuts the motor off before damage occurs.

1-8. The motorpump is a self priming centrifugal capable of transferring from 25 to 50 GPM of diesel fuel at 20 feet of head. The unit will operate at rated conditions when positioned at an angle up to 15 degrees from the horizontal. The unit primes within two minutes on a 10 foot static suction lift after initial filling of the pump case. Electrical power requirement is 24 VDC, 30 amps. The physical parameters of the unit are:

- a. Length — 26.5 inches
- b. Width — 12.5 inches
- c. Height — 17 inches
- d. Cube — 3.25 cubic feet
- e. Weight — 75 pounds

1-9. The unit is a self contained system and ships with all major Components listed above. Additional items required for operation are a grounding point, a fuel source and a 24 VDC power supply

1-10. To store the unit, drain all lines and pump case in accordance with operating procedures, Unit storage temperature conditions can range from + 155 °F to -65 °F.

1-11. Operating temperature conditions can be from +125 °F to -25 °F.

1-12. No special tools or test equipment are required for normal operation.

1-13. The unit is warranted in accordance with the limited warranty contained in this manual.

Figure 1-1. Centrifugal Pump Unit (Cradle removed for component visibility)
(Sheet 1 of 2)










Figure 1-1. Centrifugal Pump Unit (Sheet 2 of 2)



**SUCTION
HOSE**



**DISCHARGE
HOSE**

SECTION 2
SET-UP

2-1. **SET-UP.**

2-2. Set up the unit following these steps.

- a. Remove unit components from transportation vehicle. Locate on the ground near fuel source.
- b. Electrically ground unit using ground wire. Connect one ground clamp to unit cradle and other ground clamp to fueling ground point.
- c. Remove dust plug from inlet and dust cap from outlet.
- d. Connect two suction hoses (black stripe) together. Connect to motorpump inlet.
- e. Connect suction strainer to suction hose.
- f. Connect two discharge hoses together. Connect to motorpump outlet.
- g. Connect discharge nozzle to discharge hose.
- h. Place suction strainer end of suction hose below surface of fuel source. Strainer must be below surface of fuel source at all times or unit will not work.
- i. Uncoil power cable. Connect power plug to 24 volt DC power source.
- j. Unit is now ready for start-up.

WARNING

**Do not disconnect ground clamps or power plugs while unit is running.
Disconnection will generate sparks and cause fire or explosion.**

SECTION 3 OPERATION

3-1. PRIMING.

WARNING

Priming and sample taking operations using the unit results in fuel being discharged directly from the sample hose on the ground in the immediate vicinity of the pump. All precautions to prevent fuel ignition, explosion and fire must be taken.

3-2. Unit will not prime until the following conditions are met:

- a. Suction strainer must be under surface of fuel source. Any air entering the suction strainer will cause the unit to lose prime or cease pumping.
- b. There must be not air leaks in suction or discharge hoses. All hose camlock connections must be firmly seated before unit can be primed. Check to insure each camlock joint has its washer firmly seated prior to closing camlock joint.
- c. Motorpump case drain valve located below motorpump inlet connection must be closed.
- d. Discharge nozzle must be closed during hand pump operation and when motorpump is self-priming. Opening discharge nozzle will allow air into the hoses prior to priming being completed and will result in loss of prime and an inoperable unit.

3-3. START-UP SEQUENCE.

3-4. Start-up the unit in accordance with the following steps.

- a. Turn ball valve handle to vertical "PRIME/SAMPLE" (open) position. Close motorpump case drain valve.
- b. Operate hand pump using steady, short, up and down strokes. Time to prime motorpump will vary from 1 to 3 minutes.
- c. Pumping hand pump removes air from hoses and motorpump case. Steadily pump hand pump until a continuous stream of fuel discharges from sample hose.
- d. Take clean sample of fuel from sample hose end.
- e. Continue to operate hand pump until steady stream of fuel flows. Once steady stream of fuel flows from sample hose, close ball valve by moving handle from "PRIME/SAMPLE" (open) position to "RUN" (close) position.
- f. Turn power switch on electrical junction box to "ON" position.

- g. Unit is now running on DC motor and is ready to transfer fuel.
- h. Transfer fuel by opening fuel discharge nozzle. Initial operation may produce slugs of air and fuel prior to steady operation.

CAUTION

Do not operate DC motor until motorpump case is full of fuel. Dry operation will harm the motorpump mechanical seal.

3-5. NORMAL OPERATION.

3-6. The unit is now operation. The discharge nozzle can be opened and closed, as required to transfer fuel into containers or vehicles. With the discharge nozzle closed, the pump can run up to 5 minutes. If no fuel is to be transferred, turn the power switch to the “OFF” position. The motorpump will retain its prime as long as the discharge nozzle remains closed and no air is allowed into hoses. In a fuel lifting application, if the discharge nozzle is opened when the electric motor is turned off air will flow into the nozzle and fuel will flow (back siphon) through the hoses and motorpump back into the fuel tank and the unit will lose its prime.

3-7. LOSS OF PRIME.

3--8. If the liquid prime of the MOTORPUMP is lost, reprime MOTORPUMP by repeating START-UP sequence Steps a – h.

3-9. SHUT DOWN SEQUENCE.

3-10. Shut down the unit in accordance with the following steps:

- a. Turn power switch to “OFF” position.
- b. Disconnect power plug from power supply and coil power cable on cradle.
- c. Open discharge nozzle and allow fuel to drain from hoses and motorpump.
- d. Disconnect suction and discharge hoses from unit. Disassemble suction and discharge hose draining fuel from hoses.
- e. Open motorpump case drain valve and drain fuel from motorpump case.
- f. Turn ball valve handle to “PRIME/SAMPLE” position and stroke hand pump five or six times to remove fuel from hand pump.
- g. After fuel has drained from motorpump, close motorpump case drain valve, turn ball valve handle to “RUN” position. Replace inlet dust plug and outlet dust cap.
- h. Unit is now fully drained.

**SECTION 4
TROUBLESHOOTING GUIDE**

| <u>SYMPTOM</u> | <u>POSSIBLE CAUSE</u> | <u>CORRECTIVE ACTION</u> |
|-------------------------------|---|---|
| LOSS OF SUCTION | <ol style="list-style-type: none"> 1. Airleak in suction and discharge hose lines. 2. Suction lift is too high. 3. Suction strainer exposed. | <ol style="list-style-type: none"> 1. Check camlock connections for missing gaskets or open joints. 2. Lower unit closer to fuel level. 3. Push suction strainer below fuel surface to bottom of fuel tank. |
| PUMP LEAKS | <ol style="list-style-type: none"> 1. Worn mechanical seal. | <ol style="list-style-type: none"> 1. Replace mechanical seal. |
| LITTLE OR NO DISCHARGE | <ol style="list-style-type: none"> 1. Motorpump case not filled with fuel (not primed or loss of prime). 2. Discharge nozzle too high. 3. Suction strainer plugged. 4. Hole or leak in suction hose. 5. Discharge nozzle strainer plugged. 6. Suction strainer not submerged deep enough. 7. Suction or discharge hose kinked. 8. Suction hose collapsed. 9. Power supply insufficient. 10. Pump running backwards. | <ol style="list-style-type: none"> 1. Fill motorpump case using hand pump. Reprime using start-up sequence steps a through h. 2. Shorten suction lift and/or discharge nozzle level. 3. Remove suction strainer from hose. Clean, reassemble and reprime. 4. Repair or replace suction hose. 5. Remove discharge nozzle strainer, clean and replace. 6. Submerge strainer lower in fuel tank. 7. Straighten out hose. 8. Suction lift greater than hose suction rating. 9. Obtain correct 24 VDC power with 30 ampere capacity. 10. Check rotation arrow on motorpump case and confirm motorpump shaft is rotating in direction of arrow on case. Change power source polarity to change direction of transfer pump rotation. |

| <u>SYMPTOM</u> | <u>POSSIBLE CAUSE</u> | <u>CORRECTIVE ACTION</u> |
|---|--|---|
| CANNOT OBTAIN SAMPLE OR WILL NOT PRIME | 1. Air leaks in suction or discharge hose. | 1. Check hose joints for air leakage or missing gaskets. |
| | 2. Discharge nozzle open. | 2. Close discharge nozzle. |
| | 3. Suction strainer not fully submerged. | 3. Submerge suction strainer to tank bottom. |
| | 4. Fuel lift greater than 10 feet. | 4. Move unit closer to fuel source. |
| | 5. Motorpump case drain valve open. | 5. Close motorpump case drain valve. |
| | 6. Pump shaft seal leaking. | 6. Hand rotate pump shaft to dislodge any dirt on seal face. Replace worn seal. |
| MOTOR WILL NOT START | 1. Power supply not operating. | 1. Connect to live 24 VDC power supply. |
| | 2. Circuit breaker tripped. | 2. To reset circuit broker, turn power switch lever to "RESET" position then turn back to "ON". |
| | 3. Circuit breaker trips when turned to "ON" position. | 3. Electrical short in motor power cable or electrical box. Repair at maintenance location. |
| | 4. Motor overheated. | 4. Place unit in shade, let it cool, then restart. |
| MOTOR STOPS | 1. Circuit breaker tripped. | 1. Reset circuit broker. |
| | 2. Motor overheated. | 2. Allow motor to cool then restart. |
| | 3. Loss of electric. | 3. Find operable power supply power. |

SECTION 5 MAINTENANCE

5-1. CLEANING.

- a. Remove oil, dust and dirt from exterior of unit.
- b. Using fuel as a cleaning agent, brush lint and dirt from exterior of suction screen. Use a non-metallic bristle brush being careful not to distort screen wire structure.
- c. Remove, clean and replace discharge nozzle strainer.
- d. Pump and motor do not require periodic lubrication.
- e. Junction box contains supplier factory-sealed components and no lubrication, adjustment or cleaning is required.
- f. Clean dirt from power cable with dry cloth. Remove sand and fine grit from plug end prior to replacing cap.

5-2. MECHANICAL SEAL REPLACEMENT.

A. Disassembly.

1. Turn power switch to off. Disconnect power cable.
2. drain unit and disconnect hoses from motorpump.
3. Disconnect hose between motorpump case and hand pump.
4. Remove case cap screws.
5. Remove case from motorpump.
6. Insert 7/8" open end wrench between openings in adapter and place on flats of shaft. Hold shaft to stop rotation.
7. Leave the 7/8" open end wrench on flats of shaft and unscrew the impeller by turning counter clockwise when facing the impeller (see figure 5-1).
8. The impeller half of the seal can now be removed from the impeller (see figure 5-2).
9. Remove the four cap screws holding adapter to motor. Remove adapter.
10. Place adapter on flat surface and push out the adapter half of the mechanical seal (see figure 5-3).

B. Reassembly.

1. Clean the case and adapter flange gasket faces. Clean the adapter seal and bore. Clean the impeller seal cavity bore shaft. Clean the shaft shoulder fitting against impeller.



Figure 5-1. Removing Impeller




Figure 5-2. Removing Impeller
Half of Mechanical Seal




Figure 5-3. Mechanical Seal Parts

2. Lubricate the impeller seal cavity. Coat the impeller half rubber cup exterior with a soapy water solution. Press the rubber cap with impeller half of seal squarely and evenly into the impeller seal cavity. Use caution not to chip or scratch the lapped face of seal.
3. Apply pipe sealant on outside of the cup portion of the adapter seal to ease cup into adapter.
4. Install the cup by pressing on the cup lip (a 3" long piece of 1 1/4" PVC pipe or similar device will ease/aid in installation). Make certain that cup is fully seated.
5. Assemble adapter to motor and secure the four cap screws.
6. Hold shaft against rotation by inserting 7/8" open end wrench between openings in adapter and place on flats of shaft (see figure 5-1). Thread impeller on shaft until it is tight against the shaft shoulder.
7. Install O-ring gasket on adapter pump side flange shoulder.
8. Replace case on adapter.
9. Tighten case cap screws alternately and evenly.
10. Check for free rotation after assembly is completed.
11. Connect hand pump hose to case.
12. Fill case with fuel before restarting. Do not start unit until case is filled.

5-3. CABLE ASSEMBLY MAINTENANCE.

5-4. Inspection.

5-5. Inspection of the power cable assembly conforms generally to standard visual inspection procedures performed on electrical equipment. Be certain to perform the following visual checks and inspections on the power cable for the specific conditions noted.

- a. Check the connector for distortion, dents, corrosion and a broken insulator. Check that the center contact pin is not bent, misaligned or otherwise deformed.
- b. Check the power cable insulation for cuts, tears, abrasion and other similar damage.

5-6. Test.

5-7. Test the power cable for continuity to ascertain its integrity as follows:

- a. Remove junction box cover (2.14, figure 5-4) to gain access to power cable terminations and disconnect power cable from circuit breaker (2.3) and radio frequency interference filter (2.4).

TM 10-4320-314-13&P

b. Use a multimeter (Simpson Model 260 or equal) and check between each electrical lead lug terminal and appropriate connector termination (negative or positive) for continuity. There should be a zero resistance reading. If either reading is other than zero, replace a defective connector, electrical lead or lug terminal.

5-8. **Repair and Replacement.**

5-9. Connector.

a. No connector repair is possible other than the removal of corrosion and straightening of a slightly bent center contact pin. To replace the connector, remove the cover attaching screws.

b. Remove the attaching bolts and lock washers securing the electrical leads to the connector.

c. Reattach the electrical leads to the new connector and install the connector cover.

5-10. Electrical Lead(s).

a. Repair of the electrical leads is limited to replacement of damaged lug terminal(s). To replace a lug terminal(s), clip off the damaged terminal(s).

b. Strip off the electrical lead insulation, being careful not to cut the stranded conductors, just enough so that when the conductors are fully inserted into the lug terminal, the insulation almost makes contact with the lug terminal barrel. Clip off excess conductor length or strip off additional electrical lead insulation as required.

c. Insert conductors fully into leg terminal barrel and crimp terminal barrel to fully secure onto electrical lead.

5-11. **HAND PUMP MAINTENANCE.**

5-12. **Inspection.**

a. Inspection of the hand pump is limited to the detection of fuel leakage.

b. Inspection for the detection of fuel leakage is accomplished during the "PRIME/SAMPLE" function when the hand pump is operated with short up and down strokes. If leakage is detected during this function between the discharge end (3.3, figure 5-4) and tube (3.5) or elbow (32), the suction end (3.12) and tube (3.5) or nipple (38), or around rod (3.6), the hand pump must be removed from the unit for repair.

5-13. **Test.**

a. Testing of the hand pump is limited to the detection of wear of the seal cup (3.7, figure 5-4) and excessive scoring or damage of the tube (3.5).

b. Testing to detect wear of the seal cup (3.7) and excessive scoring of the tube (3.5) is accomplished during the "PRIME/SAMPLE" function. If the "PRIME SAMPLE" function

takes more than 4 minutes and the suction strainer is under the surface of the fuel source (no air leakage to the suction side of the hand pump), the seal cup is worn and/or the tube is excessively scored and the hand pump must be removed from the unit for repair.

5-14. **Repair and Replacement.**

WARNING

Do not disconnect the inlet or outlet hoses from the hand pump while the unit is hot. A fire or explosion could occur if spilled fuel contacts excessively hot components.

- a. To remove the hand pump from the unit, be certain all components are cool to the touch and then loosen hose clamps (28, figure 5-4) and pull hoses (26 and 29) off elbows (32). Fuel will be spilled as the hoses are disconnected. Take out four screws (24) and lock washers (25) securing the hand pump to the unit and remove the hand pump.
- b. If fuel leakage was observed between the discharge end (3.3) and tube (3.5) or elbow (32), the suction end (3.12) and tube (3.5) or nipple (38) check for a loose connection between the interconnecting parts where leakage was detected. Tighten the mating parts if possible to eliminate the leakage or replace both mating parts if the connection is tight and then reinstall the hand pump.
- c. If fuel leakage was observed around rod (3.6), unscrew handle (3.1) from rod (3.6) and discharge end (3.3) from tube (3.5). Remove and discard gaskets (3.2) and using new gaskets, reassemble and reinstall the hand pump being certain the hose clamps (28) are sufficiently tight to prevent fuel leakage from around elbows (32).
- d. If testing denotes wear of the seal cup (3.7) and/or excessive scoring of the tube (3.5) has occurred, proceed as follows:
 1. Remove the hand pump from the unit, being certain all components are cool to the touch, by loosening hose clamps (28) and pulling hoses (26 and 29) off elbows (32). Fuel will be spilled as the hoses are disconnected. Take out four screws (24) and lock washers (25) securing the hand pump to the unit and remove the hand pump.
 2. Unscrew discharge end (3.3) from tube (3.5) and pull tube off assembled internal components. Inspect internal bore of tube for excessive wear, scoring or distortion. Discard a damaged tube.
 3. Unscrew retaining nut (3.4) from rod (3.6) and remove seal retainer (3.10), spacer (3.9) and seal cup (3.7). Discard seal cup and reassemble disassembled parts. Apply a light coating of vaseline to seal cup and install the assembled internal components into tube (3.5). Reinstall the hand pump onto the unit being certain the hose clamps (28) are sufficiently tight to prevent fuel leakage from around elbows (32).

5-15. JUNCTION BOX MAINTENANCE.

5-16. Junction box maintenance is limited to the replacement of defective components and testing of the RFI filter (2.4, figure 5-4) and the power solenoid (2.2). Inspection of the junction box conforms

generally to standard visual inspection procedures performed on **electrical** equipment. Be certain to perform the following visual checks and inspections **on the junction box** components for the specific conditions noted:

5-17. Inspection.

- a. Remove cover (2.14, figure 5-4) and check electrical wiring insulation for cuts, tears, abrasion and overheating as evidenced by charred or brittle insulation.
- b. Check that all connections to the RI filter (2.4), power solenoid (2.2) and circuit breaker (2.3) are tight. Tighten any loose connection and spray interior of junction box (2.1) with anti-moisture /fungus resistant varnish per MIL-V-173C after tightening any loose hardware or replacing any parts.
- c. Check that gasket (2.15) is not torn or otherwise damaged.

5-18. Test.

- a. Disconnect the power supply leads from the 24 volt DC power supply.
- b. Connect a multimeter (Simpson Model 260 or equal) across circuit breaker (2.3, figure 5-4) terminals (LINE and LOAD) and check for proper operation as the circuit breaker operator is operated from the ON (0 ohms resistance) to the OFF/RESET (infinite ohms resistance) positions and back again to the ON position.
- c. Connect the multimeter across terminals B and C of the power solenoid (2.2) and check for 0 ohms resistance. Then check for 0 ohms resistance across terminals B and A. If an infinite resistance reading is observed, the motor thermal overload is open. If continuity (0 ohms resistance) is not noted with the thermal overload closed, replace a defective power solenoid.
- d. Remove screws (2.9) and washers (13) securing RFI filter (2.4), solenoid (2.2) and bracket (2.8) to junction box (2.1); remove RFI filter, solenoid and bracket from junction box. Remove cover from RFI filter.
- e. Connect the multimeter across terminals 1 and 4 of RFI filter (2.4) and check for 0 ohms resistance. Then check for 0 ohms resistance across terminals 2 and 5, and then 3 and 6. Check also for infinite ohms resistance with the multimeter connected between terminals 1 and 6, 2 and 6, 3 and 4, and 3 and S. Any reading other than 0 and infinity is cause for replacement of the RFI filter. Reverse procedure to reinstall.

5-19. Repair and Replacement.

5-20. No repair of individual components within the junction box is possible. Replacement of individual components necessitates disconnecting and tagging leads from the defective component(s), removal of the defective components attaching self-tapping screws and replacement of the defective component(s). A small amount of silicone rubber adhesive sealant should be applied to the attaching self locking screws before their installation to assure integrity of the explosion proof junction box. Also,

after installation of the tagged leads onto the appropriate component terminals, spray the interior of junction box (2.1, figure 5-4) with anti-moisture/fungus resistant varnish per MIL-V-173C and firmly tighten the cover (2.14).

5-21. **ELECTRIC MOTOR REPAIR.**

5-22. **Inspection.**

- a. During operation of the unit, observe the electric motor and inspect for excessive noise or vibration. Excessive noise or vibration necessitates removal of the pump from the unit in order to test the electric motor independently to determine whether the electric motor or pump is at fault.
- b. If during operation, the motor thermal protector or circuit breaker tripped (adequate 24 volt DC power supply with 30 ampere capacity), removal of the pump from the unit is required in order to test the electric motor independently to determine whether the electric motor or pump is at fault.
- c. At the completion of a transfer function, check that the electric motor does not feel uncomfortably hot to hand touch. An excessively hot electric motor (provided with an adequate 24 volt DC power supply) even though the motor thermal protector or circuit breaker did not trip, necessitates removal of the pump from the unit in order to test the electric motor independently to determine whether the electric motor or pump is at fault. Overheating is generally a result of undervoltage, binding of pump components or defective motor bearings.

5-23. **Test.**

5-24. In order to determine whether the electric motor or pump is at fault as a result of trouble found during inspection (excluding an insufficient power supply), be certain all components are cool to the touch and the pump is disconnected from its power source, and then disengage the pump from the electric motor and test the electric motor as follows:

- a. Remove two screws (1.18, figure 5-4), two screws (1.2), four lock washers (1.6) and four flat washers (1.17) securing pump case (1.12) to adapter (1.3) and cradle (4).
- b. Pull pump case (1.12) away from adapter (1.3) until pump case is clear of impeller (1.9)
- c. Move pump case (1.12) out of the way (to the side of cradle (4) with the prime pump). Pump case may be repositioned while attached to prime pump hose (29).
- d. Facing impeller (1.9), unscrew the impeller counterclockwise from shaft (1.5). The shaft may be prevented from rotating with a 7/8" open end wrench. Flats have been provided on the shaft for this purpose. Remove the ring portion of mechanical seal (1.8) with impeller.
- e. Try to turn shaft (1.5) by hand. If the shaft turns freely, connect an ammeter in series with the electric motor and apply the rated 24 volts DC. If the motor sounds normal and the ammeter reads 20% or less of the nameplate full load current, it can be assumed the deficiency is external

to the electric motor. If however, the motor **shaft** does not turn freely or the motor is noisy, it can be assumed the deficiency is internal to the electric motor. Remove and replace the electric motor in accordance with the following procedures.

5-25. Motor Assembly Removal.

5-26. Remove the motor as an assembly in accordance with the following procedure:

- a. Remove pump case (1.12, figure 5-4), impeller (1.9) and ring portion of mechanical seal (1.8) in accordance with paragraph 5-24, steps a through d.
- b. Remove two screws (16), two flat washers (48) and two lock washers (17) securing junction box (2.1) to cradle (4).
- c. Remove four screws (18), eight flat washers (19), four lock washers (20) and four nuts (21) securing motor (1. 1) to cradle (4), and remove motor and junction box from cradle.
- d. Remove four screws (1.2) and four lock washers (1.6) securing adapter (1.3) to motor (1.1). Remove adapter (1.3) from motor rabbet. O-ring (1.7) can remain with adapter.
- e. Loosen three setscrews (1.13) securing shaft (1.5) to motor shaft. Remove shaft (1.5), key (1.14) and flinger (1.4) from motor (1.1)
- f. Remove junction box cover (2.14). Remove screws (2.9) and washers (13) securing RFI filter (2.4), solenoid (2.2), and bracket (2.8) to junction box (2.1); remove RFI filter, solenoid, and bracket from junction box. Remove cover from RI filter and disconnect motor lead ring terminals from stud number 1, 2, and 3 on RI filter.
- g. Remove terminals of power cable (2.17) from circuit breaker (2.3) and RFI filter (2.4).
- h. Loosen locking rings connectors (2.11), unscrew connectors (2.11) from junction box (**2.1**), and remove power cable (2. 17) ends from junction box.
- i. Unscrew junction box (2. 1) from nipple on motor end cover.

5-27. Motor Assembly Replacement.

5-28. Install a replacement motor assembly in accordance with the following procedure.

- a. With defective motor removed, apply silicone sealant (27) to threads of nipple on rear cover of replacement motor (1.1).
- b. Screw junction box (2.1) onto nipple on motor (1.1) rear cover until hand tight and power cord connector openings are facing the pump end. Face of junction box (2.1) with 1/4-20 tapped holes must be perpendicular to motor (1.1) shaft in order to assure alignment with cradle (4) mounting plate.
- c. Insert power cable (2.17) ends into junction box (2.1) and screw connectors (2.11) into junction box. Tighten locking rings on connectors (2.1 1).

- d. Attach terminals on power cable (2.17) to circuit breaker (2.3) and RFI filter (2.4). Attach motor lead ring terminals to RFI filter stud number 1, 2, and 3 (see schematic on figure 5-5). Replace cover on RFI filter, and reattach to junction box (2.1, figure 5-4) at back of junction box, using screw (2.9) and washer (13).
- e. Place flange of solenoid (2.2) over remaining flange of RFI filter and fasten both to junction box with screw (2.9) and washer (13). Place flange of bracket (2.8) over remaining flange of solenoid positioning operating fork (2.6) over lever on circuit breaker (2.3), and fasten both to junction box with screw (2.9). Install screw (2.9) in remaining hole in bracket (2.8) and fasten to junction box.
- f. Apply silicone sealant (27, figure 5-4) to threads on cover (2.14) and install O-ring gasket (2.15) onto cover. Screw cover into junction box (2.1),
- g. Install flinger (1.4) over motor (1.1) shaft. Place key (1.14) in keyway of motor shaft and slide shaft (1.5) over motor shaft. Do not tighten setscrews (1.13).
- h. Attach adapter (1.3) with O-ring (1.7) to motor (1.1) using four screws (1.2) and four lock washers (1.6).
- i. Attach motor (1.1) to cradle (4) using four screws (18), eight flat washers (19), four lock washers (20) and four nuts (21). Do not fully tighten nuts.
- j. Attach junction box (2.1) to cradle (4) using two screws (16), two flat washers (48) and two lock washers (17). Tighten all fasteners attaching the junction box and motor to the cradle.
- k. With the ring portion of mechanical seal (1.8) pressed into impeller (1.9) and the spring portion of mechanical seal pressed into adapter (1.3), screw impeller (1.9) onto shaft (1.5). The mechanical seal spring will push the shaft away from the adapter.
- l. Place cradle end on a flat surface so that the motor shaft is vertical and the impeller is facing up.
- m. Place a 0.015" thick shim (approximately equal to 3-4 sheets of this technical manual) on the face of the impeller.
- n. Position case (1.12) over impeller (1.9) and press case down over adapter (1.3) rabbet. **Temporarily secure** case to adapter with two screws (1.18).
- o. Tighten setscrews (1.13) to secure shaft (1.5) to motor (1.1) shaft.
- p. Remove screws (1.18) and case (1.12). Remove shim from impeller. Reinstall case on adapter (1.3) and fasten case to adapter and cradle (4) with two screws (1.18), two screws (1.2), four lock washers (1.6) and four flat washers (1.17).

SECTION 6
PARTS LIST

TM10-4320-314-13&P

| ITEM | QTY | PART NO. | DESCRIPTION | ACTUAL MFG/CAGE | ACTUAL MFG PART NO. |
|------|-----|--------------|----------------------------------|--------------------|------------------------|
| 1.0 | 1 | 118 000 433 | CENTRIFUGAL PUMP UNIT, MODEL #85 | SCOT | 3200K1 |
| 1.1 | 1 | 113 000 290 | MOTOR, 112 HP 24 VDC | OHIO ELEC | C-481404X7879 |
| 1.2 | 6 | 105 000 155 | SCREW,CAP,HEX HEAD | 96906 | MS90725-59 |
| 1.3 | 1 | 132 000 386 | ADAPTER | SCOT | |
| 1.4 | 1 | 104 000 171 | FINGER | SCOT | |
| 1.5 | 1 | 135 000 266 | SHAFT | SCOT | |
| 1.6 | 8 | 104 000 124 | WASHER, LOCK | 96906 | MS35338-46 |
| 1.7 | 1 | 116 000 141 | GASKET, BUNA | PARKER | 2-246 |
| 1.8 | 1 | 101 000 169 | SEAL | JOHN CRANE | H-SP-9327-1 |
| 1.9 | 1 | 131 000 780 | IMPELLER | SCOT | |
| 1.10 | 1 | 107 000 233 | VALVE, DRAIN | KADDIS | 100-A |
| 1.11 | 1 | 116 000 206 | GASKET | PARKER | 2-112 |
| 1.12 | 1 | 130 000 347 | CASE | SCOT | |
| 1.13 | 3 | 105 000 477 | SETSCREW | 96906 | MS51021-56 |
| 1.14 | 1 | 102 000 280 | KEY | SCOT | |
| 1.15 | 1 | 106 000 371 | PLUG, PIPE, 1"NPT,CSK SQ HEAD | PITTSBURGH PLUG | 526-1 |
| 1.17 | 4 | 104 000 194 | WASHER, FLAT | 96906 | MS27183-15 |
| 1.18 | 2 | 105 000 156 | SCREW,CAP,HEX HEAD | 96906 | MS90725-60 |
| 2.0 | 1 | 118 000 435 | ELECTRICAL BOX | SCOT | |
| 2.1 | 1 | 110 000 408 | JUNCTION BOX-EXPL PROOF | SCOT | |
| 2.2 | 1 | 120 000 305 | SOLENOID | ESSEX | 120-114721 |
| 2.3 | 1 | 120 000 306 | BREAKER | CARLING SWITCH | AA1B0346405B1C |
| 2.4 | 1 | 120 000 257A | FILTER, RFI | OHMIC FILTER | NF-262A |
| 2.5 | 1 | 102 000 332 | HANDLE, OPERATING | DAVIES | 3090J |
| 2.6 | 1 | 110 000 409 | LEVER, OPERATING | CROUSE-HINDS | 0200247 |
| 2.7 | 1 | 105 000 581 | NUT, SELF-LOCKING, HEXAGON | 96906 | MS 17830-SC |
| 2.8 | 1 | 110 000 410 | BRACKET | SCOT | |
| 2.9 | 4 | 105 000 341 | SCREW, MACHINE | | MS51957-28 |
| 2.10 | 1 | 117 000 546 | TAG. ON-OFF/RESET | SCOT | |
| 2.11 | 1 | 107 000 270 | CONNECTORS, CABLE | PYLE NATIONAL | DB-338 |
| 2.12 | 10 | 120 000 308 | WIRES (SEE SCHEDULE) | SCOT | |
| 2.13 | 1 | 117 000 494 | NAME PLATE | SCOT | |

CHANGE 1

6-1

| ITEM | QTY | PART NO. | DESCRIPTION | ACTUAL MFG/CAGE | ACTUAL MFG PART NO. |
|------|-----|-------------|--|-----------------|---------------------|
| 2.14 | 1 | 110 000 342 | COVER | SCOT | |
| 2.15 | 1 | 116 000 252 | GASKET, BUNA | PARKER | 2-253 |
| 2.16 | 3 | 105 000 238 | SCREW, DRIVE | 96906 | MS21318-9 |
| 2.17 | 1 | 120 000 302 | CABLE, POWER | SCOT | |
| 2.18 | 1 | 105 000 116 | NUT, PLAIN, HEX | 96906 | MS51967-6 |
| 2.19 | 1 | 110 000 421 | STUD, HANDLE, OPERATING | SCOT | |
| 2.20 | 2 | 105 000 590 | SCREW, MACHINE | 96906 | MS35206-226 |
| 3.0 | 1 | 118 000 434 | HAND PUMP | SCOT | |
| 3.1 | 1 | 133 000 489 | HANDLE | DIMCO-GREY | 2-293-301 |
| 3.2 | 2 | 133 000 532 | GASKET | PARKER | 2-109 |
| 3.3 | 1 | 110 000 402 | DISCHARGE END | SCOT | |
| 3.4 | 1 | 105 000 116 | NUT, PLAIN, HEX | 96906 | MS51967-6 |
| 3.5 | 1 | 107 000 264 | TUBE, THREADED, BRASS | SCOT | |
| 3.6 | 1 | 133 000 530 | ROD (STEM) | SCOT | |
| 3.7 | 1 | 133 000 531 | SEAL CUP | SCOT | |
| 3.8 | 1 | 110 000 404 | SEAL RETAINER, TOP | SCOT | |
| 3.9 | 1 | 110 000 405 | SPACER | SCOT | |
| 3.10 | 1 | 110 000 406 | SEAL RETAINER | SCOT | |
| 3.11 | 1 | 108 000 374 | SPACER | SCOT | |
| 3.12 | 1 | 110 000 403 | SUCTION END | SCOT | |
| 4 | 1 | 119 000 469 | CRADLE | SCOT | |
| 5 | 1 | 118 000 432 | STRAINER, SUCTION | SCOT | |
| 6 | 2 | 118 000 429 | HOSE ASSEMBLY, DISCHARGE | 81349 | M11588-0307300 |
| 6.1 | 2 | 108 000 358 | HOSE, DISCHARGE, RUBBER, 1 1/2" X 25' | BUCKEYE RUBBER | MIL-H-11588 |
| 6.2 | 2 | 108 000 363 | ADAPTER, CAMLOCK | 96906 | MS27021-9 |
| 6.3 | 2 | 108 000 362 | COUPLER, CAMLOCK | 96906 | MS27025-9 |
| 6.4 | 8 | 106 000 293 | CLAMP, HOSE | BAND-IT | Q-208 |
| 7 | 1 | 107 000 272 | CHECK VALVE | FLOWMATIC | 5159 |
| 8 | 2 | 118 000 431 | HOSE ASSEMBLY, SUCTION | 81349 | M370A05B2A3000 |
| 8.1 | 2 | 108 000 359 | HOSE SUCTION RUBBER 1 1/2" X 25' | BUCKEYE RUBBER | MIL-H-370 |
| 8.2 | 2 | 108 000 363 | ADAPTER, CAMLOCK | 96906 | MS27021-9 |
| 8.3 | 2 | 108 000 362 | COUPLER, CAMLOCK | 96906 | MS27025-9 |

| ITEM | QTY | PART NO. | DESCRIPTION | ACTUAL MFG/CAGE | ACTUAL MFG PART NO. |
|------|-----|-------------|--|--------------------|---------------------|
| 8.4 | 8 | 106 000 293 | CLAMP, HOSE | BAND-IT | Q-208 |
| 9 | 1 | 108 000 368 | NOZZLE DISCHARGE | DOVER/OPW | 190G-5104 |
| 10 | 1 | 108 000 365 | ADAPTER, CAMLOCK | 96906 | MS27022-9 |
| 11 | 2 | 108 000 366 | COUPLER, CAMLOCK | 96906 | MS27024-9 |
| 12 | 1 | 120 000 307 | CABLE, GROUNDING | 97403 | 13220E1127 |
| 13 | 2 | 104 000 289 | WASHER, LOCK | 96906 | MS35335-31 |
| 14 | 2 | 107 000 266 | NIPPLE, CLOSE | NATIONAL EQPT | 99CNAL 150 |
| 15 | | NOT USED | | | |
| 16 | 2 | 105 000 147 | CAP SCREW 1/4-20UC X 5/8" | 96906 | MS90725-5 |
| 17 | 2 | 104 000 121 | WASHER LCOK | 96906 | MS35338-44 |
| 18 | 4 | 105 000 151 | CAP SCREW | 96906 | MS90725-34 |
| 19 | 8 | 104 000 111 | WASHRE FLAT | 96906 | MS27183-12 |
| 20 | 4 | 104 000 123 | WASHER LOCK | 96906 | MS35338-45 |
| 21 | 4 | 105 000 121 | NUT, HEX | 96906 | MS35649-2312 |
| 22 | AR | 121 000 393 | TAPE, TEFLON SEAL | GARLOCK | MIL-T-27730A |
| 23 | AR | 121 000 116 | PIPE JOINT COMPOUND | HERCULES | 15-427 |
| 24 | 4 | 105 000 586 | SCREW, CAP, HEX SOCKET HEAD | 96906 | MS16996-9 |
| 25 | 4 | 104 000 290 | WASHER, EXTERNAL TOOTH LOCK | 96906 | MS35335-32 |
| 26 | 1 | 108 000 371 | HOSE, BULK | DAYCO | 8L3 |
| 27 | AR | 121 000 376 | SEALANT, SILICONE | GE | G624 |
| 28 | 3 | 106 000 370 | CLAMP, HOSE | TRIDON | 620-006 |
| 29 | 1 | 108 000 371 | HOSE, BULK | DAYCO | 8L3 |
| 30 | 1 | 107 000 268 | HOSE BARB | PARKER | 125 HBL 8-8 |
| 31 | 2 | 107 000 269 | ELL, STREET | PARKER | 2202 P-8-8 |
| 32 | 2 | 107 000 271 | ELBOW | PARKER | 296 HB 8-6 |
| 33 | 1 | 108 000 370 | CAP, DUST | 96906 | MS27028-9 |
| 34 | 1 | 108 000 369 | PLUG, DUST | 96906 | MS27029-9 |
| 35 | 1 | 117 000 547 | NAMEPLATE | SCOT | |
| 36 | 4 | 105 000 238 | SCREW, DRIVE | 96906 | MS21318-20 |
| 37 | AR | 121 000 369 | SEALANT, PERMATEX | LOCTITE | 2C |
| 38 | 1 | 107 000 273 | NIPPLE, PIPE, 3/8" NPT X CLOSE, BRASS | MC MASTER -CARR | 4568K151 |
| 39 | 1 | 133 000 272 | VALVE, BALL | GRINNELL | 515-1/2 3500 |
| 40 | 1 | 107 000 274 | NIPPLE, PIPE, 1/2" NPT X 2 1/2", BRASS | MC MASTER -CARR | 4568K174 |

| ITEM | QTY | PART NO DESCRIPTION | ACTUAL MFG/CAGE | ACTUAL MFG PART NO. |
|------|-----|--|--------------------|---------------------|
| 41 | 2 | 105 000 RIVETS, POP, 1/8" DIA X 1 1/4", ALUM | MC MASTER -CARR | 97517A015 |
| 42 | 1 | 117 000 TAG PRIME/SAMPLE RUN | SCOT | |
| 43 | 10 | 108 000 CAP/PLUG | ALLLIANCE | TP 2 1/8 |
| 44 | AR | 121 000 SEALANT, THREAD LOCKING | PERMABOND | HH120 |
| 45 | 2 | 120 000 TERMINAL, RING (SEE 5-5) | ETC/MOLEX | C-830-14-R90 |
| 46 | 1 | 120 000 TERMINAL, RING (SEE 5-5) | ETC/MOLEX | AA-821-08-R90 |
| 47 | 1 | 120 000 TERMINAL,RING (SEE 5-5) | ETC/MOLEX | AA-822-14-R90 |
| 48 | 2 | 104 000 WASHER, FLAT | 96906 | MS 27183-10 |
| 49 | 7 | GASKET | 96906 | MS27030-5 |

LIST OF MANUFACTURERS

| NAME | ADDRESS |
|--|---|
| ALLIANCE PLASTICS, INC | 3100 STATION ROAD ERIE, PA 16510 |
| BAND-IT-IDEX, INC. | P. O. BOX 16307 DENVER, CO 80216 |
| BUCKEYE RUBBER PRODUCTS, INC. | P. O. BOX DRAWER 389 LIMA, OH 45802 |
| CARLINGSWITCH, INC CIRCUIT BREAKER DIVISION | 60 JOHNSON AVENUE PLAINVILLE, CT 06062 |
| CROUSE-HINDS ECM DIV. COOPER INDUSTRIES, INC. | SYRACUSE, NY 13221 |
| DAVIES MOLDING COMPANY | 4920 W BLOOMINGDALE AVENUE CHICAGO, IL 60639 |
| DAYCO CORP. | 333 WEST FIRST STREET DAYTON, OH 45401 |
| DIMCO-GREY | 8200 SOUTH SUBURBAN ROAD CENTERVILLE, OH 45458 |
| DOVER CORP. - OPW DIV. | 9393 PRINCETON GLENDALE ROAD P. O. BOX 40240 CINCINNATI, OH 45240 |
| ETC/MOLEX | 4820 PARK BLVD. PINELLAS PARK, FL 33565 |
| FLOWMATIC | NORTH HOOSICK, NY 12133 |
| ESSEX CONTROL DIV. UNITED TECHNOLOGIES | LOGANSPOUT, IN 46947 |
| GARLOCK DIV. COLT INDUSTRIES | FRIENDS LANE NEWTON, PA 18940 |
| GENERAL ELECTRIC SILICONE | 260 HUDSON RIVER ROAD WATERFORD, NY 12188 |
| HERCULES CHEMICAL co., INC | 29-T W. 38TH STREET NEW YORK, NY 10018 |
| GRINNELL CORP. | 260 WEST EXCHANGE STREET PROVIDENCE, RI 02901 |
| JOHN CRANE, INC. | 6400 OAKTON STREET MORTON GROVE, IL 60053 |
| KADDISMFG. | OLD BEAHAN & WEIDNERROAD ROCHESTER, NY 14962 |

LIST OF MANUFACTURERS (Continued)

| NAME | ADDRESS |
|---|---|
| LOCTITE CORP. | 999 N. MOUNTAIN ROAD NEWINGTON, CT 06111 |
| MC MASTER-CARR | P.O. BOX 4355 CHICAGO, IL 60680 |
| NATIONAL EQUIPMENT CORP. | P. O. BOX 2204 HOUSTON, TX 77252 |
| OHIO ELECTRIC MOTORS | P. O. BOX 168 PAINT FORK ROAD BARNADSVILLE, NC 28709 |
| OHMIC FILTER, INC. | 125 GRACE STREET, P. O. DRAWER 1080 ST. MICHAELS, MD 21663 |
| PARKER-HANNIFIN CORP. O-RING DIVISION | 2360 PALUMBO DRIVE LEXINGTON, KY 40509 |
| PARKER-HANNIFIN CORP. TUBE FITTINGS DIVISION | 3885 GATEWAY BLVD. COLUMBUS, OH 43228 |
| PERMABOND INTERNATIONAL | 480 SOUTH DEAN STREET ENGLEWOOD, NJ 07631 |
| PITTSBURGH PLUG AND PRODUCTS CORP. | P.O. BOX H EVANS CITY, PA 16033 |
| PYLE-NATIONAL DIV. BRINTEC CORP. | 1334 N. KOSTNER AVENUE CHICAGO, IL 60651 |
| TRIDON NORTH AMERICA | P. O. BOX I600-T NASHVILLE, TN 37202 |

APPENDIX A

MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

A-1. General

a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance categories.

b. The Maintenance Allocation Chart (MAC) in section II designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component will be consistent with the capacities and capabilities of the designated maintenance categories.

c. Section 111 lists the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from section

d. Section IV contains supplemental instructions and explanatory notes for a particular maintenance function.

A-2. Maintenance functions. Maintenance functions will be limited to and defined as follows:

a. Inspect. To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g., by sight, sound, or feel).

b. Test. To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards.

c. Service. Operations required periodically to keep an item in proper operating condition, i.e., to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases.

d. Adjust. To maintain or regulate, within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.

e. Aline. To adjust specified variable elements of an item to bring about optimum or desired performance.

f. Calibrate. To determine and cause corrections to be made or to be adjusted on instruments or test, measuring, and diagnostic equipments used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy to detect and adjust any discrepancy in the accuracy of the instrument being compared.

g. Remove/Install. To remove and install the same item when required to perform service or other maintenance functions. Install maybe the act of emplacing, seating, or fixing into position

APPENDIX A

a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

h. Replace. To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and is shown as the 3d position code of the SMR code.

i. Repair. The application of maintenance services, including fault location/troubleshooting removal/installation and disassembly/assembly and maintenance actions identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

j. Overhaul. That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications (i.e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

k. Rebuild. Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of materiel maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc.) considered in classifying Army equipment/components.

A-3. Explanation of Columns in the MAC, Section II

a. Column I, Group Number. Column I lists functional group code numbers, the purpose of which is to identify maintenance significant components, assemblies, subassemblies, and modules with the next higher assembly. End item group number shall be "00."

b. Column 2, Component/Assembly. Column 2 contains the names of components, assemblies, subassemblies, and modules for which maintenance is authorized.

c. Column 3, Maintenance Function. Column 3 lists the functions to be performed on the item listed in Column 2. (For detailed explanation of these functions, see paragraph 8-2.)

d. Column 4, Maintenance Category. Column 4 specifies, by the listing of a work time figure in the appropriate subcolumn(s), the category of maintenance authorized to perform the function listed in Column 3. This figure represents the active time required to perform that maintenance function at the indicated category of maintenance. If the number or complexity of the tasks within the listed maintenance function vary at different maintenance categories, appropriate work time figures will be shown for each category. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance/quality control time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the maintenance allocation chart. The symbol designations for the various maintenance categories are as follows:

APPENDIX A

| | | |
|---|--------|-----------------------------------|
| C | | Operator or Crew |
| O | | Unit Maintenance |
| F | | Direct Support Maintenance |
| H | | General Support Maintenance |
| L | | Specialized Repair Activity (SRA) |
| D |* | Depot Maintenance |

e. Column 5, Tools and Equipment. Column 5 specifies, by code, those common tool sets (not individual tools) and special tools, TMDE, and support equipment required to perform the designated function.

f. Column 6, Remarks. This column shall, when applicable, contain a letter code, in alphabetic order, which shall be keyed to the remarks contained in Section IV.

A-4. Explanation Of Columns in Tool and Test Equipment Requirements, Section 111

a. Column 1, Reference Code. The tool and test equipment reference code correlates with a code used in the MAC, Section Column S.

b. Column 2, Maintenance Category. The lowest category of maintenance authorized to use the tool or test equipment.

c. Column 3, Nomenclature. Name or identification of the tool or test equipment.

d. Column 4, National Stock Number. The National stock number of the tool or test equipment.

e. Column 5, Tool Number. The manufacturer's part number.

A-5. Explanation of Columns in Remarks, Section IV

a. column 1, Reference Code. The code recorded in column 6, Section

b. Column 2, Remarks. This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

APPENDIX A

Section II. MAINTENANCE ALLOCATION CHART

| (1) GROUP NUMBER | (2) COMPONENT/ ASSEMBLY | (3) MAINTENANCE FUNCTION | (4) MAINTENANCE LEVEL | | | | | (5) TOOLS AND EQUIPMENT | (6) REMARKS |
|------------------------|-----------------------------------|--------------------------------|--------------------------|-----|-----|-----|-------|-------------------------------|----------------|
| | | | UNIT | | D/S | G/S | DEPOT | | |
| | | | C | O | F | H | D | | |
| 00 | PUMPING UNIT | INSPECT | | | | | | 1 | * |
| 01 | HOSE ASSY, SUCTION & DISCHARGE | INSPECT | .2 | | | | | | A |
| | | REPAIR | .1 | | | | | | C |
| | | REPLACE | .1 | | | | | | H |
| | SUCTION STRAINER | INSPECT | .1 | | | | | | A |
| | | SERVICE | .2 | | | | | | I |
| | | REPLACE | .1 | | | | | | |
| | DISPENSING NOZZLE | INSPECT | .1 | | | | | | A, F |
| | | SERVICE | | .3 | | | | | I |
| | | REPLACE | | .1 | | | | | H |
| 02 | JUNCTION BOX | INSPECT | .1 | | | | | | A |
| | | | | .2 | | | | | B |
| | | TEST | | .5 | | | | | J |
| | | REPAIR | | 1.0 | | | | | E |
| | POWER CABLE & PLUG | INSPECT | .1 | | | | | | A |
| | | REPAIR | | .7 | | | | | E |
| | | REPLACE | | .5 | | | | H | |
| 03 | HAND PRIME ASSY | | | | | | | | |
| | HAND PUMP | INSPECT | .1 | | | | | | A |
| | | REPAIR | | .7 | | | | | D |
| | | REPLACE | | .4 | | | | | H |
| | CHECK VALVE | INSPECT | | .1 | | | | | A |
| | | REPLACE | | .3 | | | | | |
| | ISOLATION VALVE | INSPECT | | .1 | | | | | A |
| REPLACE | | | .3 | | | | | | |
| HOSE ASSY | INSPECT | .1 | | | | | | A | |
| | REPAIR | | .3 | | | | | E | |
| | REPLACE | | .2 | | | | | | |
| FITTINGS & JOINTS | INSPECT | .1 | | | | | | A | |
| | REPLACE | | .2 | | | | | | |
| 04 | PUMP ASSY | | | | | | | | |
| | FITTINGS | INSPECT | .1 | | | | | | A |
| | | REPLACE | | .3 | | | | | |

APPENDIX A

Section II. MAINTENANCE ALLOCATION CHART

| (1) GROUP NUMBER | (2) COMPONENT/ ASSEMBLY | (3) MAINTENANCE FUNCTION | (4) MAINTENANCE LEVEL | | | | | (5) TOOLS AND EQUIPMENT | (6) REMARKS |
|------------------------|-----------------------------------|--------------------------------|--------------------------|-----|-----|-----|-------|-------------------------------|----------------|
| | | | UNIT | | D/S | G/S | DEPOT | | |
| | | | C | O | F | H | D | | |
| 04 (Cont.) | CAM-LOCK FITTINGS & COMPONENTS | INSPECT | .1 | | | | | | A |
| | | REPAIR | .1 | | | | | | C |
| | | REPLACE | | .3 | | | | | |
| | PUMP HOUSING | INSPECT | .1 | | | | | | A |
| | | REPAIR | | | 2.0 | | | 2 | C, G |
| | | REPLACE | | | 1.0 | | | 2 | |
| | DRAIN COCK | INSPECT | .1 | | | | | | A |
| | | REPLACE | | .2 | | | | | |
| | IMPELLER | TEST | | .2 | | | | | F |
| | | INSPECT | | | 1.0 | | | | A |
| REPLACE | | | | 1.0 | | | 2 | | |
| ADAPTER | INSPECT | .1 | | | | | | A | |
| | REPLACE | | | 1.0 | | | 2 | | |
| SHAFT SEAL | INSPECT | .1 | | | | | | A | |
| | REPLACE | | | 1.0 | | | 2 | | |
| STUB SHAFT | INSPECT | | .2 | | | | | A, F | |
| | REPLACE | | | 1.0 | | | 2 | | |
| 05 | ELECTRIC MOTOR | INSPECT | .1 | | | | | | A |
| | | TEST | | .2 | | | | | J |
| | | REPLACE | | 1.0 | | | | | H |
| 06 | CRADLE (FRAME) | INSPECT | .1 | | | | | | A |
| | | REPAIR | | | 1.4 | | | | G |
| | | REPLACE | | 1.0 | | | | | |
| 07 | GROUND ASSY | INSPECT | .2 | | | | | | A |
| | | REPLACE | | .1 | | | | | |

APPENDIX A

Section II. TOOL AND TEST EQUIPMENT REQUIREMENTS
MAINTENANCE ALLOCATION CHART

| (1) TOOL/TEST EQUIP. REF CODE | (2) MAINTENANCE CATEGORY | (3) NOMENCLATURE | (4) NSN | (5) TOOL NUMBER |
|--|--------------------------------|--|------------------|-----------------------|
| 1 | O | Shop Equipment, Automotive Maintenance and Repair: Organizational Maintenance Common No. 1, Less Power | 491 | SC-4910-95-CL-A74 |
| 2 | F | Tool Kit, General Mechanics | 5180-00-699-5273 | SC-5 CL-NO5 |

Section IV. REMARKS FOR
MAINTENANCE ALLOCATION CHART

| REFERENCE CODE | REMARKS |
|-------------------|---|
| A | SECURELY ATTACHED, VISUAL DAMAGE, EXTERNAL LEAKAGE |
| B | SECURELY ATTACHED, VISUAL DAMAGE, INTERNAL LEAKAGE |
| C | REPLACE GASKETS |
| D | REPLACE SEAL ASSEMBLY |
| E | REPAIR BY REPLACING DEFECTIVE COMPONENTS |
| F | OPERATIONAL TEST |
| G | WELD |
| H | REPLACE ASSEMBLY |
| I | CLEAN STRAINER |
| J | REQUIRES USE OF MULTIMETER CONTAINED IN TOOL KIT, SC 4910-95-CL-A74 |
| * | ONLY TOOL KIT REQUIRED UNLESS OTHERWISE INDICATED |

APPENDIX B**COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LIST****Section I. INTRODUCTION****B-1. SCOPE**

This appendix lists components of end item and basic issue items for the Centrifugal Pump Unit to help you inventory items required for safe and efficient operation.

B-2. GENERAL

The Components of End Item and Basic Issue Items Lists are divided into the following sections:

a. Section II. Components of End Item. This listing is for informational purposes only, and is not authority to requisition replacements. These items are part of the end item, but are removed and separately packaged for transportation or shipment. As part of the end item, these items must be with the end item whenever it is issued or transferred between property accounts. Illustrations are furnished to assist you in identifying the items.

b. Section III. Basic Issue Items. These are the minimum essential items required to place the Centrifugal Pump Unit in operation, to operate it, and to perform emergency repairs. Although shipped separately packaged, BII must be with the Centrifugal Pump Unit during operation and whenever it is transferred between property accounts. The illustrations will assist you with hard-to-identify items. This manual is your authority to request/requisition replacement BII, based on TOE/MTOE authorization of the end item.

B-3. EXPLANATION OF COLUMNS

The following provides an explanation of columns found in the tabular listings.

a. Column (1) – Illustration Number (illus Number). This column indicates the number of the illustration in which the item is shown.

b. Column (2) – National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.


c. Column (3) – Description. Indicates the Federal item name and, if required, a minimum description to identify and locate the item. The last line for each item indicates the CAGE (in parentheses) following by the part number.

d. Column (4) – Unit of Measure (U/M). Indicates the measure used in performing the actual operational/maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in pr).

e. Column (5) – Quantity required (Qty rqr). Indicates the quantity of the item authorized to be used with/on the equipment.

APPENDIX B

Section II. COMPONENTS OF END ITEM



| (1) ILLUS/ ITEM NO. | (2) NATIONAL STOCK NUMBER | (3) DESCRIPTION CAGE AND PART NUMBER | (4) U/M | (5) QTY RQR |
|---------------------------|---------------------------------|--|---------------|-------------------|
| | | STRAINER, SUCTION 118.000, 432 | (13646) EA | 1 |
| 2 | | HOSE, SUCTION M370A05B2A3000 | (81349) EA | 2 |
| 3 | 4720-01-215-7956 | HOSE, DISCHARGE M11588-03-07-300 | (81349) EA | 2 |
| 4 | 6150-01-197-6335 | GROUND WIRE ASSY 13220E1 | (97403) EA | 1 |
| 5 | 4390-00-902-4642 | NOZZLE, FUEL DISPENSING 13217E2974 | (97403) EA | 1 |

SECTION III. BASIC ISSUE ITEMS LIST

| (1) ILLUS/ ITEM NO. | (2) NATIONAL STOCK NUMBER | (3) DESCRIPTION CAGE AND PART NUMBER | (4) U/M | (5) QTY RQR |
|---------------------------|---------------------------------|--|------------|-------------------|
| 1 | 4320-01-247-2633 | TM 5-4320-314-10 | EA | 1 |

**APPENDIX C
ADDITIONAL AUTHORIZATION LIST**

Section I. INTRODUCTION

C-1. SCOPE

This appendix lists additional items you are authorized for the support of the Centrifugal Pump Unit.

C-2. GENERAL

This list identifies items that do not have to accompany the Centrifugal Pump Unit and that do not have to be turned in with it. These items are all authorized to you by CTA, MTOE, TDA, or JTA.

C-3. EXPLANATION OF LISTING

National stock numbers, descriptions, and quantities are provided to help you identify and request the additional items you require to support this equipment. The items are listed in alphabetical sequence by item name under the type document (i.e., CTA, MTOE, TDA, or JTA) which authorizes the item(s) to you.

| (1) ILLUS/ ITEM NO. | (2) NATIONAL STOCK NUMBER | (3) DESCRIPTION CAGE AND PART NUMBER | USABLE ON CODE | (4) U/M | (5) QTY RQR |
|---------------------------|---------------------------------|--|-------------------|------------|-------------------|
| 1 | 5975-00-878-3791 | GROUNDING ROD ASSY | | EA | 1 |
| 2 | 5120-01-013-1676 | SLIP HAMMER, GROUND ROD | | EA | 1 |

APPENDIX D

EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

D-1. SCOPE

This appendix lists expendable/durable supplies and materials you will need to operate and maintain the Centrifugal Pump Unit.

D-2. EXPLANATION OF COLUMNS

a. Column (1) – Item number. This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., “Use cleaning compound, item 5. App. D”).

b. Column(2) –Level. This column identifies the lowest level of maintenance that requires the listed item.

(enter as applicable)

- C - Operator / Crew
- O - Unit Maintenance
- F - Direct Support Maintenance
- H - General Support Maintenance

c. Column (3) – National Stock Number. This is the National stock number assigned to the item, use it to request or requisition the item.

d. Column (4) –Description. Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the Commercial and Government Entity (CAGE) code in parentheses followed by the part number.

e. Column (5) – Unit of Measure (U/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea. in. pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

APPENDIX D

EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST
CENTRIFUGAL PUMP UNIT

| (1) ITEM NUMBER | (2) MAINT LEVEL | (3) NATIONAL STOCK NUMBER | (4) DESCRIPTION | (5) U/M |
|-----------------------|-----------------------|---------------------------------|---|------------|
| 1 | 0 | 7920-00-282-2470 | BRUSH, NON-METALLIC FIBER BRISTLE | EA |
| 2 | 0 | 7930-00-526-2919 | DETERGENT, GENERAL PURPOSE LIQUID 5 GAL PAIL | GAL |
| 3 | 0 | 7920-00-148-9666 | RAGS, WIPING | BALE |
| 4 | 0 | 6950-00-281-1985 | SOLVENT, DRY CLEANING P-D-680 | GAL |
| 5 | 0 | 5970-00-832-6950 | VARNISH (AEROSOL) | CAN |

By Order of the Secretary of the Army:

CARL E. VUONO
General United States Army
Chief of Staff

Official

WILLIAM J. MEEHAN, II
Brigadier General United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25E, Operator, Unit, Direct Support Maintenance requirements for Pump, Centrifugal, Portable Refueling System, Gas Driven, Base Mounted, 100 GPM, 1½ IN (114MX1A).

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN . . . JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

PFC JOHN DOE
COA, 3d ENGINEER BN
FT. LEONARDWOOD, MD 63108

DATE SENT

PUBLICATION NUMBER

TM 5-4320-314-13&P

PUBLICATION DATE

15 June 1990

PUBLICATION TITLE Pump Unit,
Centrifugal 1½" Suction &
Discharge 24 Volt DC

BE EXACT . . . PIN-POINT WHERE IT IS

| PAGE NO | PARA-GRAPH | FIGURE NO | TABLE NO |
|---------|------------|-----------|----------|
| 6 | 2-1 a | | |
| B1 | | 4-3 | |
| 125 | line 20 | | |

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

In line 6 of paragraph 2-1a the manual states the engine has 6 cylinders. The engine on my set only has 4 cylinders. Change the manual to show 4 cylinders.

Callout 16 on figure 4-3 is pointing at a bolt. In key to figure 4-3, item 16 is called a shim - Please correct one or the other.

I ordered a gasket, item 19 on figure B-16 by NSN 2 910-05-762-3001. I got a gasket but it doesn't fit. Supply says I got what I ordered, so the NSN is wrong. Please give me a good NSN

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

JOHN DOE, PFC (268) 317-7111

SIGN HERE:

JOHN DOE

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.
DRSTS-M Overprint 1, 1 Nov 80

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

COMMANDER
U.S. ARMY TROOP SUPPORT COMMAND
ATTN: AMSTR-MCTS
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

COMMANDER
U.S. ARMY TROOP SUPPORT COMMAND
ATTN: AMSTR-MCTS
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

REVERSE OF DA FORM 2028-2
REVERSE OF DRSTS-M OVERPRINT 1
1 NOV 80

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

COMMANDER
U.S. ARMY TROOP SUPPORT COMMAND
ATTN: AMSTR-MCTS
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK


DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

COMMANDER
U.S. ARMY TROOP SUPPORT COMMAND
ATTN: AMSTR-MCTS
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798


TEAR ALONG PERFORATED LINE

| REV. | DESCRIPTION |
|------|--|
| 1 | 17.0 FRAME HEIGHT WAS 14.5 (DRAWN 02/08/88) |
| 2 | ADDED WEIGHTS (CAMLOCK, BRUSHES PER PARTS LIST) |
| 3 | ADDED WEIGHT DIMENSIONS TABLE (AS PER 19-000-822) |
| 4 | CHANGED DIRECTION OF PUMP/ENGINE FROM 1/2 TO 1/4 (DRAWN 10/87) |



PUMP DATA
 SCOT MODEL # 85
 1/2 x 1/2 CENTRIFUGAL PUMP
 HORIZONTAL CLOSE COUPLED
 US ARMY SPEC. NO.: MIL-P-53063(ME)
 NSN 4320-01-247-2633
 CONTRACT NO: DAAK-01-88-D-0053
 CAPACITY: 30 GPM
 HEAD: 20 FT
 LIQUID PUMPED: 54 O.82
 HYDROSTATIC TEST PRESSURE: 30 PSIG
 IMPELLER DIAMETER: 4.48

MOTOR DATA
 1/2 HORSE POWER - 3000 RPM
 24 VOLT D.C. FLA 22
 TENV, WATER PROOF, EXPLOSION PROOF
 NEMA MG-1, NFPAND 70, CL I, DIV. I, GRP. D





GROUND CLAMP CONTACT AREA
 BEFORE PAINTING, MASK OFF
 1" STRIP AROUND (360°) PISTON
 PUMP BRACKET.

POWER SUPPLY: 24 VOLT D.C.

PAINT TREATMENT
 IN ACCORDANCE WITH MIL-T-704 TYPE
 F OR G - CAMOUFLAGE GREEN #383
 CONFORMING TO MIL-C-44168

WEIGHTS & DIMENSIONS

| ITEM | QTY | WEIGHT(LBS) | L | W | H | F.W. |
|------------------|-----|-------------|------|------|----|-------|
| PUMP/MOTOR ASSY. | 1 | 75 | 24.5 | 12.5 | 17 | 3.25 |
| SUCTION HOSE | 2 | 55 | 21 | 21 | 9 | 4.6 |
| DISCHARGE HOSE | 2 | 50 | 21 | 21 | 9 | 4.6 |
| TOTAL | 5 | 180 | | | | 12.45 |





CONTRACT: DAAK01-88-D-0053 DTD 29 FEB 88

| | | |
|-----------------------------|---|----------------------------|
| FSCM 13644 | SCOT DIV. ANDOX CORP. CEDARBURG, WISCONSIN 53012 | 85 |
| SCALE: 1/2 | DATE: 9-27-88 | REVISION: 4 |
| DATE: 9-27-88 | 9 MAR 89 | 10 AUG 89 |
| ASSEMBLY-CAPTURED FUEL PUMP | | DRAWN BY: TJS |
| SCOT # 8500K1 | | REVISION: 4 |
| NSN 4320-01-290-8401 | | DATE: 10 MAR 87 |
| | | DRAWING NUMBER: 19-000-822 |

Figure 5-4. Centrifugal Pump Unit (Sheet 1 of 3)
 5-11/(5-12 blank)

19-000-822



HAND PISTON PUMP HOSE DETAIL

- ASSEMBLY NOTES**
- 1) USE TERON TAPE P/N 121,000, 389 OR PIPE THREAD SEALANT P/N 121,000, 116 ON ALL PIPE JOINTS
 - 2) APPLY SILICONE SEALANT TO THREADS OF COVER ON EXPLOSION PROOF JUNCTION BOX (121,000, 376)

STENCIL NOTES:

- ①: LIFT HERE
- ②: TIE DOWN HERE
- ③: GROUND HERE
- ④: CARC - TO SIDE OF CASE


USE FLAT BLACK "CARC" SPRAY PAINT
STENCIL LETTERS TO BE 1/2" HIGH

EX. CARC $\frac{1}{2}$ "

| REV | DESCRIPTION |
|-----|--|
| 6 | 105,000, 151, 105,000, 149, 1, 1974/89, 2, 1, 1974/89 |
| 5 | 121,000, 376, 121,000, 389, 121,000, 116, 121,000, 116 |
| 4 | CHANGED DIMENSIONS TO DIMENSIONS SHOWN IN THIS DRAWING. APPROVED BY: [Signature] |
| 3 | ADDED DIMENSIONS TO DIMENSIONS SHOWN IN THIS DRAWING. APPROVED BY: [Signature] |
| 2 | ADDED DIMENSIONS TO DIMENSIONS SHOWN IN THIS DRAWING. APPROVED BY: [Signature] |
| 1 | ORIGINAL DIMENSIONS SHOWN IN THIS DRAWING. APPROVED BY: [Signature] |

| | | | |
|---|--|----------------------|--|
| CONTRACT: DAAGD1-88-D-0068 DATED: 28 FEB 88 | | | |
| FCM: 18648 | | SCOT DIV. ARMO CORP. | |
| DATE: 10-6-88 | | 28 AUG 89 | |
| SCALE: NTS | | REPLACES: 26 SEP 89 | |
| DRAWN BY: TJS | | | |
| REVIEWED BY: [Signature] | | | |
| ASSEMBLY CAPTURED FUEL PUMP | | | |
| SCOT # 282001 PUMP 82 | | | |
| NSN 4320-01-286-2461 | | | |
| 19,000,822 | | 19,000,822 | |

Figure 5-4. Centrifugal Pump Unit (Sheet 2 of 3)
5-13/(5-14 blank)



| REV. | DESCRIPTION |
|------|--|
| 1 | ITEM 11 IN MAPS ITEM 27. 135 8/2/89 ECM 132.09 |
| 2 | ADDED #49, #2, #2.11- SUCTION & DISCHARGE HOSE. TO 8/2/89 ECM 134.89 |

- NOTES:
- 1) APPLY TEFLON TAPE (22) OR PIPE JOINT COMPOUND (23) TO PIPE THREADS.
 - 2) APPLY SILICONE SEALANT (27) TO THREADS OF LOWER (24) AND MOTOR (11) BEFORE ASSEMBLY TO JUNCTION BOX.
 - 3) APPLY PERMATEX (27) TO THREADS OF BRASS TUBE (33) BEFORE ASSEMBLY TO (32) AND (34).
 - 4) APPLY THREAD LOCKING SEALANT (44) TO MOUNTING HARDWARE BEFORE ASSEMBLY.

CONTRACT: DAAR01-88-D-0058 DATED: 29 FEB 88


FSCM 13346 SCOT DIV. ARDOR CORP. 285
 CEDARBURG, WISCONSIN 53012

SCALE: N.T.S. DRAWN BY: TJS
 DATE: 12-6-88 2 AUG 89 28 AUG 89 REVISION: 1

ASSEMBLY CAPTURED FUEL PUMP
 PFR, MIL-D-8800-1 PMP 88
 NSN 4810-01-2 286-3461 2 DRAWING NUMBER
 17,400,872


Figure 5-4. Centrifugal Pump Unit (Sheet 3 of 3)
 5-15/(5-16 blank)

| ELECTRICAL CONTROL COMPONENTS | | | | | |
|-------------------------------|-----|--------------|-------------|----------------------------------|-----------------|
| ITEM | QTY | PART NUMBER | DRAWING NO. | DESCRIPTION | MATERIAL |
| 1 | 1 | 110.000.408 | 19.000.814 | JUNCTION BOX, EXPLOSION PROOF | ALUMINUM |
| 2 | 1 | 120.000.305 | 16.002.241 | SOLENOID, POWER | VARIOUS |
| 3 | 1 | 120.000.306 | 16.002.243 | BREAKER | VARIOUS |
| 4 | 1 | 120.000.257A | 18.001.437 | FILTER, RFI | ALUMINUM |
| 5 | 1 | 102.000.332 | 16.002.245 | HANDLE, OPERATING | PLASTIC/BRASS |
| 6 | 1 | 110.000.409 | 16.002.246 | LEVER, OPERATING | STEEL |
| 7 | 1 | 105.000.581 | | LOCK NUT 5/16-18 UNC | STEEL |
| 8 | 1 | 110.000.410 | 16.002.242 | BRACKET, BREAKER | ALUMINUM |
| 9 | 4 | 105.000.541 | | 1/8" B/S SCREW - SELF TAPPING | STAINLESS STEEL |
| 10 | 1 | 117.000.546 | 16.002.244 | TAG, ON-OFF/RESET | ALUMINUM |
| 11 | 2 | 107.000.270 | | CONNECTORS - POWER | ALUMINUM |
| 12 | 10 | 120.000.308 | 18.001.723 | WIRES - SEE WIRE SCHEDULE | VARIOUS |
| 13 | 1 | 117.000.494 | 16.001.860 | NAMEPLATE, JUNCTION BOX | ALUMINUM |
| 14 | 1 | 110.000.342 | 19.000.527 | COVER | ALUMINUM |
| 15 | 1 | 116.000.252 | | O-RING | BUNA |
| 16 | 3 | 105.000.238 | | DRIVE PINS | ZINC PLATED |
| 17 | 1 | 120.000.302 | 17.001.680 | CABLE, POWER SUPPLY | VARIOUS |
| 18 | 1 | 105.000.116 | | HEX NUT, 5/16-18 UNC | ZINC STEEL |
| 19 | 1 | 110.000.421 | 16.002.296 | STUD, HANDLE OPERATING | ZINC STEEL |
| 20 | 2 | 105.000.590 | | SCREW, #6-32x.25L6, BREAKER MTH. | ZINC STEEL |



| WIRE GAUGE | FROM | TERM. NO./SIZE | TO | TERM. NO./SIZE | LENGTH |
|------------|------|----------------|----------|----------------|------------------------------|
| W10 | S | POWER CABLE | - | FILTER | 6 1/4" 6" * |
| W9 | 10 | SOLENOID PWR. | A 2/16 | FILTER | 4 1/4" 6" 120.000.308-W9 (5) |
| WB | 18 | SOLENOID CAL | C #12 | FILTER | 5 #8 6" 120.000.308-W8 (5) |
| W7 | 18 | SOLENOID PWR. | B 5/16 | SOLENOID COIL | D #10 6" 120.000.308-W7 (5) |
| W6 | 10 | CIRCUIT BRKR. | LOAD #10 | SOLENOID PWR. | B 5/16 6" 120.000.308-W6 (5) |
| WS | 8 | POWER CABLE | + | CIRCUIT BRKR. | LINE #10 6" * |
| W4 | 12 | #MOTOR PWR. | A-1 | FILTER GRD | 3 1/4" 8" |
| W3 | 18 | #MOTOR TP | TH | FILTER GRD | 3 1/4" 8" |
| W2 | 18 | #MOTOR TP | TH | FILTER | 2 #8 8" |
| W1 | 12 | #MOTOR PWR. | A-2 | FILTER | 1 1/4" 8" |

WIRE SCHEDULE (* FROM MOTOR)



- NOTES**
- 1) SPRAY WIRE CONNECTIONS AND INSIDE OF HOUSING WITH ANTI-MOISTURE/FUNGUS RESISTANT VARNISH #111.000.165 PER MIL-V-173-C AT ASSEMBLY.
 - 2) ALL 1/8" HOLES FOR (9) SELF TAPPING SCREWS TO HAVE A SMALL AMOUNT OF SILICONE RUBBER ADHESIVE SEALANT #121.000.376 APPLIED BEFORE ASSEMBLY.
 - 3) ALL PIPE THREAD CONNECTIONS TO HAVE TEFLON TAPE PIPE THREAD SEALANT PART NUMBER 121.000.393 APPLIED TO THREADS AT ASSEMBLY.
 - 4) FOR ARRANGEMENT OF COMPONENTS, SEE DWG. 19.000.822 SHEET 3 ITEMS 2.1 THRU 2.18.
 - 5) WIRE RATING, UL TYPE MTW 600 VOLT

* WS & W10 HAVE 6" CABLE LENGTH INSIDE JUNCTION BOX FOR CONNECTION. EXTERIOR CABLE IS 15 FEET LONG.

P/N 118.000.435

| REV. | DESCRIPTION | REV. | DESCRIPTION |
|------|---|------|--|
| 4 | ADD DRIVE PIN, NAMEPLATE, COVER AND O-RING TO DRAWING. TJS 5/17/89 ECU 94.89 | 1 | DELETED RUBBER GROMMET, ADDED NOTE 1, DELETED VENT PLUG & THE BENCH MARKS. |
| 5 | ADDED ITEM 19, STUD, HANDLE ON TJS 7/5/89 ECU 120.89 | 2 | ADDED NOTES 2 & 3 TJS 11-9-88 ECU |
| 6 | ADDED 105.000.590 #10-32 SCREWS TJS 8/18/89 ECU 151.89 | 3 | ADDED #18 HEX NUT, TJS 4-14-88 ECU 340.88 |
| 7 | 121.000.376 WAS 121.000.375, 121.000.393 WAS 121.000.203 TJS 8/28/89 ECU 154.89 | | |

CONTRACT : DAAK01-88-D-DO53 DATED 29 FEB 88

SCOT DIV. ARDOX CORP. NAME: ELECTRICAL CONTROLS 85

MATL: FSCM 13646

UNLESS OTHERWISE SPECIFIED: 1- PLACE DEC 2 ANGULAR 2- PLACE DEC 2 3- PLACE DEC 2 MACHINED SURFACE TEXTURE

FOR TOLERANCES NOT SPECIFIED SEE 300-SERIES SHOP PRACTICE STANDARDS

DR TJS 9-22-88 SIMILAR TO REPLACES 14 AUG 89 28 AUG 89

CH _____ SCALE _____ SHEET _____ DWG. NO. 18.001.723

AP _____ NTS _____

Figure 5-5. Centrifugal Pump Unit Electrical Controls 5-17/(5-18 blank)

The Metric System and Equivalents

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimeter = 10 centimeters .394 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.06 feet
 1 kilometer = 10 hectometers = 3,260.8 feet

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram .10 decigram = .035 ounce
 1 dekagram = 10 grams = .35 ounce
 1 hectogram = 10 dekagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 liter = 10 deciliters = 33.81 fl. ounces
 1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches
 1 sq. meter (centers) = 100 sq. decimeters = 10.76 sq. feet
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

| To change | To | Multiply by | To change | To | Multiply by |
|---------------|--------------------|-------------|--------------------|---------------|-------------|
| inches | centimeters | 2.540 | ounce-inches | newton-meters | .007062 |
| feet | meters | .305 | centimeters | inches | .394 |
| yards | meters | .914 | meters | feet | 3.280 |
| miles | kilometers | 1.609 | meters | yards | 1.094 |
| square inches | square centimeters | 6.451 | kilometers | miles | .621 |
| square feet | square meters | .093 | square centimeters | square inches | .155 |
| square yards | square meters | .836 | square meters | square feet | 10.764 |
| square miles | square kilometers | 2.590 | square meters | square yards | 1.196 |
| acres | square hectometers | .406 | square kilometers | square miles | .386 |
| cubic feet | cubic meters | .028 | square hectometers | acres | 2.471 |
| cubic yards | cubic meters | .765 | cubic meters | cubic feet | 35.315 |
| fluid ounces | milliliters | 29,573 | cubic meters | cubic yards | 1.308 |
| pints | liters | .473 | milliliters | fluid ounces | .034 |
| quarts | liters | .946 | liters | pints | 2.113 |
| gallons | liters | 3.785 | liters | quarts | 1.057 |
| ounces | grams | 28,349 | liters | gallons | .264 |
| pounds | kilograms | .454 | grams | ounces | .035 |
| short tons | metric tons | .907 | kilograms | pounds | 2.205 |
| pound-feet | newton-meters | 1.356 | metric tons | short tons | 1.102 |
| pound-inches | newton-meters | .11296 | | | |

Temperature (Exact)

°F Fahrenheit temperature 5/9 (after subtracting 32) Celsius temperature °C

