


---

TECHNICAL MANUAL

**OPERATOR'S, ORGANIZATIONAL AND DIRECT  
SUPPORT MAINTENANCE  
MANUAL (INCLUDING REPAIR PARTS AND  
SPECIAL TOOLS LIST)**



**PUMP, CENTRIFUGAL  
FRAME MOUNTED, 1 1/2 IN.,  
GASOLINE ENGINE DRIVEN, LESS ENGINE,  
(BARNES MODEL 17570) NSN 4320-00-752-9466  
ELECTRICAL MOTOR DRIVEN,  
(SCHLEYER MODEL 4M-SE2000), NSN 4320-00-010-5888  
ELECTRICAL MOTOR DRIVEN  
(BARNES MODEL US4CCE), NSN 4320-00-937-8099**

INTRODUCTION
OPERATING INSTRUCTIONS
OPERATOR MAINTENANCE INSTRUCTIONS
ORGANIZATIONAL MAINTENANCE INSTRUCTIONS
DIRECT SUPPORT MAINTENANCE INSTRUCTIONS
APPENDIX A REFERENCES
APPENDIX B MAINTENANCE ALLOCATION CHART
APPENDIX C ADDITIONAL AUTHORIZED LIST
APPENDIX D REPAIR PARTS AND SPECIAL TOOLS LIST

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**17 SEPTEMBER 1982**



CHANGE  
NO. 5

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 28 MAY 1993

Operator's, Organizational, and Direct Support  
Maintenance Manual  
(Including Repair Parts and Special Tools List)

PUMP, CENTRIFUGAL FRAME MOUNTED, 1 1/2 IN.,  
GASOLINE ENGINE DRIVEN, LESS ENGINE,  
(BARNES MODEL 17570), NSN 4320-00-752-9466  
(SCHLEYER MODEL 4M-SG-2000) NSN 4320-00-752-9466  
ELECTRICAL MOTOR DRIVEN,  
(SCHLEYER MODEL 4M-SE2000), NSN 4320-01-010-5888  
(BARNES MODEL US4CCE), NSN 4320-00-937-8099

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 5-4320-200-13&P, 17 September 1982, is changed as follows:

1. The title is changed as shown above.
2. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

i and ii  
1-3 through 1-6  
2-3 through 2-8  
-----  
4-1 and 4-2  
-----  
  
4-11 through 4-14  
D-5 and D-6  
D-9 through D-16


Insert pages

i and ii  
1-3 through 1-6  
2-3 through 2-8  
2-8.1 through 2-8.4  
4-1 and 4-2  
4-2.1 through 4-2.7/  
(4-2.8 blank)  
4-11 through 4-14  
D-5 and D-6  
D-9 through D-18

3. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

  
MILTON H. HAMILTON  
*Administrative Assistant to the  
Secretary of the Army*  
04285

GORDON R. SULLIVAN  
*General, United States Army  
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 1366, requirements for TM 5-4320-200-13&P.

CHANGE

No. 4

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 25 April 1990

Operator's, Organizational and Direct Support  
Maintenance Manual  
(Including Repair Parts and Special Tools List)

PUMP, CENTRIFUGAL FRAME MOUNTED, 1½ IN.,  
GASOLINE ENGINE DRIVEN, LESS ENGINE,  
(BARNES MODEL 17570) NSN 4320-00-752-9466  
ELECTRICAL MOTOR DRIVEN,  
(SCHLEYER MODEL 4M-SE2000), NSN 4320-01-010-5888  
ELECTRICAL MOTOR DRIVEN  
(BARNES MODEL US4CCE) NSN 4320-00-937-8099

Approved for public release. Distribution is unlimited.

TM 5-4320-200-13&P, 17 September 1982, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

4-1 through 4-4  
4-7 and 4-8  
D-7 through D-10  
D-15 and D-16

Insert pages

4-1 through 4-4  
4-7 and 4-8  
D-7 through D-10  
D-15 and D-16

2. Retain this sheet in front of manual for reference purposes.

**By Order of the Secretary of the Army:**

**CARL E. VUONO**  
*General, United States Army*  
*Chief of Staff*

**Official:**

**WILLIAM J. MEEHAN, II**  
*Brigadier General United States Army*  
*The Adjutant General*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A, Operator, Unit, Direct Support and General Support Maintenance requirements for Pump, Centrifugal, Frame Mounted, 1½ IN, (GAS: 17570; Electric: 4M-SE2000, US4CCE).



CHANGE }  
No. 3 }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
Washington, D. C., 21 August 1989

Operator's, Organizational and Direct Support  
Maintenance Manual  
(Including Repair Parts and Special Tools List)

PUMP, CENTRIFUGAL FRAME MOUNTED, 1½ IN.,  
GASOLINE ENGINE DRIVEN, LESS ENGINE,  
(BARNES MODEL 17570) NSN 4320-00-752-9466  
ELECTRICAL MOTOR DRIVEN,  
(SCHLEYER MODEL 4M-SE2000), NSN 4320-01-010-5888  
ELECTRICAL MOTOR DRIVEN  
(BARNES MODEL US4CCE) NSN 4320-00-937-8099

Approved for public release. Distribution is unlimited.

TM 5-4320-200-13&P, 17 September 1982, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

1-3 and 1-4  
2-3 and 2-4

Insert pages

1-3 and 1-4  
2-3 and 2-4

2. Retain this sheet in front of manual for reference purposes.

**By Order of the Secretary of the Army:**

**CARL E.VUONO**  
*General, United States Army*  
*Chief of Staff*

**Official:**

**WILLIAM J. MEEHAN, II**  
*Brigadier General United States Army*  
*The Adjutant General*

**DISTRIBUTION:**

To be distributed in accordance with DA Form 12-25A, Operator, Unit, Direct Support and General Support Maintenance requirements for Pump, Centrifugal, Frame Mounted, 1½ IN, (Gas: 17570; Electric: 4M-SE2000, US4CCE).





CHANGE

NO 2

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 30 November 1987

Operator's Organizational and Direct Support  
Maintenance Manual  
(Including Repair Parts and Special Tools List)

PUMP, CENTRIFUGAL  
FRAME MOUNTED, 1½ IN.,  
GASOLINE ENGINE DRIVEN, LESS ENGINE,  
(BARNES MODEL 17570) NSN 4320-00-752-9466  
ELECTRICAL MOTOR DRIVEN,  
(SCHEYLER MODEL 4M-SE2000), NSN 4320-01-010-5888  
ELECTRICAL MOTOR DRIVEN  
(BARNES MODEL US4CCE) NSN 4320-00-937-8099

TM 5-4320-200-13&P, 17 SEPTEMBER 1982, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

i and ii  
1-3 and 1-4  
2-5 through 2-8  
2-15 through 2-18  
D-7 through D-12  
D-15 and D-16

Insert pages

i and ii  
1.-3 and 1-4  
2-5 through 2-8  
2-15 through 2-18  
D-7 through D-12  
D-15 and D-16

2. Retain this sheet in front of manual for reference purposes.

**By Order of the Secretary of the Army:**

**CARL E. VUONO**  
*General, United States Army*  
*Chief of Staff*

**Official**

**R. L. DILWORTH**  
*Brigadier General, United States Army*  
*The Adjutant General*

**DISTRIBUTION:**

To be distributed in accordance with DA Form 12-25A, Operator, Unit, and Direct support and General Support Maintenance Requirements for Pump, Centrifugal, Frame Mounted, 1½ In. (Gas: 17570; Electric; 4M-SE2000, US4CCE).



CHANGE }  
No. 1 }HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C. 30 June 1986Operator's, Organizational and Direct Support  
Maintenance Manual  
(Including Repair Parts and Special Tools List)PUMP, CENTRIFUGAL  
FRAME MOUNTED, 1 1/2 IN.,  
GASOLINE ENGINE DRIVEN, LESS ENGINE,  
(BARNES MODEL 17570) NSN 4320-00-752-9466  
ELECTRICAL MOTOR DRIVEN,  
(SCHLEYER MODEL 4M-SE2000), NSN 4320-01-010-5888  
ELECTRICAL MOTOR DRIVEN  
(BARNES MODEL US4CCE), NSN 4320-00-937-8099

TM 5-4320-200-13&amp;P, 17 SEPTEMBER 1982, is changed as follows:

1. The title is changed as shown above. Remove and insert pages as indicated below.

***Remove pages***2-3 thru 2-8  
2-15 and 2-16  
C-1/( C-2 Blank)  
D-13 thru D-16***Insert pages***2-3 thru 2-8  
2-15 and 2-16  
C-1/( C-2 Blank)  
D-13 thru D-16

2. *New* or changed material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

3. Retain these sheets in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

R. L. DILWORTH  
*Brigadier General, United States Army*  
*The Adjutant General*JOHN A. WICKHAM, JR.  
*General, United States Army*  
*Chief of Staff*

## DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A Operator, Organizational, Direct Support and General Support Maintenance requirements for Pump, Centrifugal, Frame Mounted, 1 1/2 In, (Gas: 17570; Electric: 4M-SE-2000, US4CCE).



**WARNING**

o When filling the fuel tank, do not smoke or use open flame in the area. Always make metal-to-metal contact between the container and the fuel tank. This will prevent a spark as fuel flows over metallic surfaces. Failure to observe this warning may result in death to personnel.

o Never operate the centrifugal pump in an enclosed area unless the exhaust gases are piped to the outside. Exhaust gases contain carbon monoxide which is a colorless, odorless, and poisonous gas.

o Make sure spark plug leads are disconnected before performing maintenance on the pump.

o Avoid breathing smoke when using a fire extinguisher.

o Do not fill the fuel tank while the engine is running. Gasoline spilled on a hot engine may explode and cause serious injury to personnel.

o Do not attempt to perform any maintenance on the pump while the engine is running.

o Make sure all gasoline fumes are removed from tank before starting welding operations. Fumes in tank can cause a severe explosion if ignited.

o Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is 100°F (38°C).

**CAUTION**

o Do not operate pump without priming. Running pump dry will damage pump seals and make pump inoperative. Do not operate pump for long periods of time without fluid flowing through it.

o When tying centrifugal pump to carrier, install bands through frame. Do not secure by banding across channels.



TECHNICAL MANUAL

No. 5-4320-200-13&P

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 17 September 1982

OPERATOR'S, ORGANIZATIONAL, AND DIRECT SUPPORT MAINTENANCE MANUAL  
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)  
PUMP, CENTRIFUGAL FRAME MOUNTED, 1 1/2 IN.,  
GASOLINE ENGINE DRIVEN, LESS ENGINE,  
(BARNES MODEL 17570), NSN 4320-00-752-9466  
(SCHLEYER MODEL 4M-SE-2000) NSN 4320-00-752-9466  
ELECTRICAL MOTOR DRIVEN,  
(SCHLEYER MODEL 4M-SE2000), NSN 4320-01-010-5888  
(BARNES MODEL US4CCE), NSN 4320-00-937-8099

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in the back of this manual direct@ Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you.

**Distribution Statement A:** Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	Page
CHAPTER 1. INTRODUCTION . . . . .	1-1
Section I. General Information . . . . .	1-1
Section II. Equipment Description and Data . . . . .	1-1
Section III. Principles of Operation . . . . .	1-8
CHAPTER 2. OPERATING INSTRUCTIONS . . . . .	2-1
Section I. Description and Use of Operator's Controls and Indicators . . . . .	2-1
Section II. Preventive Maintenance Checks and services . . . . .	2-3
Section III. Operation Under Usual Conditions . . . . .	2-10
Section IV. Operation Under Unusual Conditions . . . . .	2-19
CHAPTER 3. OPERATOR MAINTENANCE INSTRUCTIONS . . . . .	3-1
Section I. Lubrication . . . . .	3-1
Section II. Troubleshooting . . . . .	3-2
CHAPTER 4. UNIT MAINTENANCE INSTRUCTIONS . . . . .	4-1
CHAPTER 5. DIRECT SUPPORT MAINTENANCE INSTRUCTIONS . . . . .	5-1

This manual supersedes TM 5-4320-200-15, 27 November 1968, including all changes.

TABLE OF CONTENTS (Continued)

APPENDIX A.	REFERENCES	A-1
	B. MAINTENANCE ALLOCATION CHART	B-1
	C. ADDITIONAL AUTHORIZED LIST	C-1
	D. REPAIR PARTS AND SPECIAL TOOLS LIST	D-1

LIST OF ILLUSTRATIONS

Figure	Title	Page
1-1	Centrifugal Pump(Gasoline Engine Powered) . . . . .	1-2
1-2	Centrifugal Pump (Electric Motor Powered Typical) . . . . .	1-2
1-3	Location and Description of Major Components (Gasoline Engine Powered) . . . . .	1-4
1-4	Location and Description of Major Components (Electric Motor Powered) . . . . .	1-5
2-1	Operating Controls (Gasoline Engine Driven Pump) . . . . .	2-1
2-2	Operating Controls (Electric Motor Driven Pump) . . . . .	2-2
2-3	Equipment Inspection and Maintenance Worksheet . . . . .	2-9
2-4	Priming the Pump . . . . .	2-12
2-5	Pump Draining Instructions . . . . .	2-20
4-1	FuelTankRemoval . . . . .	4-2
4-2	Fuel Line andFilterRemoval . . . . .	4-4
4-3	Channel Removal . . . . .	4-6
4-4	Fuel Tank Replacement . . . . .	4-7
4-5	Power Cable Replacement (Electric Motor Driven Pump) . . . . .	4-9
4-6	Electric Motor Removal . . . . .	4-10
4-7	Centrifugal Pump Assembly, Disassembly and Replacement . . . . .	4-14
5-1	Electric Motor . . . . .	5-3
D-1	Engine, Support andCarryingFrame . . . . .	D-6
D-2	Fuel Tank, LinesandFittings . . . . .	D-8
D-3	Frame, Motorand Cable . . . . .	D-10
D-4	Electric Motor . . . . .	D-12
D-5	pump . . . . .	D-14

LIST OF TABLES

Table	Title	Page
2-1	Operator Preventive Maintenance Checks and Services	
3-1	Operator Troubleshooting . . . . .	3-2
4-1	Unit Preventive Maintenance Checksand Services . . . . .	4-1
4-2	Unit Maintenance Troubleshooting . . . . .	4-12



CHAPTER 1  
INTRODUCTION

---

Section I. GENERAL INFORMATION

**1-1. SCOPE.**

a. This manual covers three Centrifugal Pumps. These pumps output water at the rate of 65 gallons per minute. One pump is gasoline engine powered and the other two are electric motor powered.

This manual contains operating instructions, and maintenance instructions for Operator's, Organizational and Direct Support Maintenance. The pump (figure 1-1, 1-2) is used to pump fresh water.

b. The gasoline engine is covered in TM 5-2805-256-14.





Figure 1-1. Centrifugal Pump (Gasoline Engine Powered)



**Figure 1-2. Centrifugal Pump (Electric Motor Powered Typical)**

**1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS.**

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750. The Army Maintenance Management System (TAMMS).

**1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE.**

Procedures for destroying Army materiel to prevent enemy use are listed in TM 750-224-1-4.

**1-4. PREPARATION FOR STORAGE OR SHIPMENT.**

a. Placement of equipment in administrative storage should be for short periods of time when a shortage of maintenance effort exists. Items should be in mission readiness within 24 hours or within the time factors as determined by the directing authority. During the storage period appropriate maintenance records will be kept.

b. Before placing equipment in administrative storage, current preventive maintenance checks and services (PMCS) should be completed, shortcomings and deficiencies should be corrected, and all modification work orders (MWO's) should be applied.

c. Storage site selection. Inside storage is preferred for items selected for administrative storage. If inside storage is not available, trucks, vans, conex containers and other containers may be used.

**Section H. EQUIPMENT DESCRIPTION AND DATA****1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR).**

If your pump needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Tell us why a procedure is hard to perform. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MDO, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798, We'll send you a reply.

**1-6. DESCRIPTION AND DATA.**

The pump is:

**CENTRIFUGAL.** Uses a high speed rotating motion that forces water away from the center.

**SELF CONTAINED.** Pump and gasoline engine or electric motor are coupled together as one unit. No additional equipment is needed to run the pump.

**FRAME MOUNTED.** For ease of handling.


The pump can:

Pump 50 gallons (Gasoline Engine Powered) of fresh water per minute at 70 foot head, or 65 gallons at 50 foot head.

Operate in all weather conditions.


**1-7. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.**

Major components are shown and described in figure 1-3 and 1-4.



- A. GASOLINE ENGINE. Supplies operating power to pump.
- B. CENTRIFUGAL PUMP. (Direct coupled to engine), used for pumping water.
- C. FUEL TANK. Contains fuel to operate engine.
- D. INLET HOSE ADAPTER. Water inlet to pump.
- E. OUTLET HOSE ADAPTER. Water outlet from pump.

Figure 1-3. Location and Description of Major Components  
(Gasoline Engine Powered).



- A. MOTOR. Supplies operating power to pump.
- B. CENTRIFUGAL PUMP. (Direct coupled to motor), used for pumping water.
- C. CABLE. Supplies power to motor.
- D. INLET HOSE ADAPTER. Water inlet to pump.
- E. OUTLET HOSE ADAPTER. Water outlet from pump.

Figure 1-4. Location and Description of Major Components  
(Electric Motor Powered).

L

**1-8. DIFFERENCES BETWEEN MODELS.**

This manual covers only the Barnes pump Models 17570, US4CCE, and the Schleyer pump Model 4M-SE2000. Model 17570 pumps with Military Standard Engine 1A08-1 were furnished with engine and fuel tank brackets which differ from those currently used with the 1A08-3 engine. Engine supports, brackets, and the fuel tanks now supplied can be adapted to the 1A08-1 engine or to mount a 1A08-3 engine as replacement. Refer to Organizational Maintenance Instructions for replacement procedures.

**1-9. EQUIPMENT DATA**

Barnes Model 17570 and Schleyer Model 4M-SG-2000

NOMENCLATURE .....	Pump Centrifugal, Fresh Water self-priming frame mounted, 1-1/2 inch, Type II.
STOCK NUMBER .....	NSN 4320-00-752-9466
MODEL .....	BARNES 17570 SCHLEYER 4M-SG-2000
GASOLINE ENGINE MODEL .....	Military Standard 1A08-1 or 1A08-3
WEIGHTS AND DIMENSIONS	
Shipping Weight .....	110 lbs (49.5 kg)
Length .....	18 in
Width .....	16 in
Height .....	22 in
Cube .....	3.7ft
CAPACITIES	
Fuel Tank .....	2 quarts
Crankcase .....	1/2 quart
PERFORMANCE	
Engine	
Pump .....	65 gallon per minute

Barnes Model US4CCE

NOMENCLATURE .....	Pump, Centrifugal, 1-1/2 in. frame mounted, fresh water, 65gpm, 50ft hd.
STOCK NUMBER .....	NSN 4320-00-937-8099
MODEL .....	US4CCE
ELECTRIC MOTOR MODEL .....	Baldor Electric 617M

WEIGHTS AND DIMENSIONS

Shipping Weight-----110 lbs (49.5 kg)  
 Length -----21 inches (53.3 cm)  
 Width -----13 inches (33 cm)  
 Height -----22 inches (55.8 cm)  
 Cube -----4 feet (0.112 cubic meters)

POWER REQUIREMENTS

Horse Power-----2  
 Vol ts-----208  
 AMPS-----5.7  
 Hertz -----60  
 Phase-----3

PERFORMANCE

Motor -----3450 revolutions per minute  
 Pump -----65 gallons per minute

Schleyer Model 4M-SE2000

NOMENCLATURE -----Pump, Centrifugal, 1-1/2 in., frame  
 mounted, fresh water, 65gpm 50ft.  
 head

STOCK NUMBER--- -----NSN 4320-01-010-5888

MODEL-----4M-SE2000

ELECTRIC MOTOR MODEL -----Bal dar Electric 617M

WEIGHTS AND DIMENSIONS

Shipping Weight-----110 lbs (49.5 kg)  
 Length -----21 inches (53.3 cm)  
 Width -----13 inches (33 cm)  
 Height -----22 inches (55.8 cm)  
 Cube -----4 feet (0.112 cubic meters)

POWER REQUIREMENTS

Horsepower-----2  
 vol ts-----208  
 AMPS-----5.7  
 Hertz-----60  
 Phase-----3


PERFORMANCE

Motor -----3450 revolutions per minute  
 Pump -----65 gallons per minute

Section III. PRINCIPLES OF OPERATION

**1-10.** HOW IT WORKS.

When the engine is running a shaft with attached fins (impeller) turns inside the pump water chamber. This causes water to be drawn into the chamber thru an inlet opening (port). Water then is discharged thru an outlet opening (port). A check valve located in the suction port keeps water from running back out of the pump when it is stopped.





CHAPTER 2  
OPERATING INSTRUCTIONS

Section I. DESCRIPTION AND USE OF OPERATOR'S  
CONTROLS AND INDICATORS

2-1. GENERAL.

Figure 2-1 shows the location of the operator's controls on the gasoline engine driven pump, and figure 2-2 shows the location of the operator's controls on the electric motor driven pump. Before you operate the pump make sure you know the location and operation of all controls.




Figure 2-1. Operating Controls  
(Gasoline Engine Driven Pump)




Figure 2-2. Operating Controls (Electric Motor Driven Pump).

## Section 11. OPERATOR'S PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

**2-1.GENERAL.** Preventive Maintenance Checks and Services (PMCS) means systematic caring, inspecting, and servicing of equipment to keep it in good condition and to prevent breakdowns. As the pump's operator, your mission is to:

Be sure to perform your PMCS each time you operate the pump. Always do your PMCS in the same order, so it gets to be a habit. Once you've had some practice, you 'll quickly spot anything wrong.

Do your BEFORE (B) PMCS just before you operate the pump. Pay attention to WARNINGS, CAUTIONS, and NOTES.

Do your DURING (D) PMCS while you operate the pump. During operation means to monitor the pump and its related components while it is actually being operated. Pay attention to WARNINGS, CAUTIONS, and NOTES.

Do your AFTER (A) PMCS right after operating the pump. Pay attention to WARNINGS, CAUTIONS, and NOTES.

Do your WEEKLY (W) PMCS once a week.

Do your MONTHLY (M) PMCS once a month.

Use DA Form 2404 (Equipment Inspection and Maintenance Worksheet) to record any faults that you discover before, during, or after operation, unless you can fix them. You DO NOT need to record faults that you find.

Be prepared to assist unit maintenance when they lubricate the pump. Perform any other services when required by unit maintenance.

### **2-2.PMCS PROCEDURES.**

Your Preventive Maintenance Checks and Services, Table 2-1, lists inspections and care required to keep your pump in good operating condition. It is set up so you can make your BEFORE (B) OPERATION checks as you walk around the pump.

The "INTERVAL" column of Table 2-1 tells you when to do a certain check or service.

The "PROCEDURE" column of Table 2-1 tells you how to do required checks and services. Carefully follow these instructions. If you do not have tools, or if the procedure tells you to, notify your supervisor.

#### **NOTE**

Terms "ready/available" and "mission capable" refer to same status: Equipment is on hand and ready to perform its combat missions. (See DA Pam 738-750)

The "EQUIPMENT IS NOT READY/AVAILABLE IF:" column in Table 2-1 tells you when your pump is nonmission capable and why the pump cannot be used.

If the pump does not perform as required, refer to Chapter 3, Section II, Troubleshooting.

If anything looks wrong and you can't fix it, write it on your DA Form 2404. IMMEDIATELY, report it to your supervisor.

When you do your PMCS, you will always need a rag or two. Following are checks that are common to the entire pump:

**Keep It Clean.** Dirt, grease, oil, and debris only get in the way and may cover up a serious problem. Clean as you work and as needed. Use dry cleaning solvent (SD-2) on all metal surfaces. Use soap and water when you clean rubber or plastic material. Upholstery can be cleaned with soap and water and a clean, damp cloth.

**Rust and Corrosion.** Check pump body and frame for rust and corrosion. If any bare metal or corrosion exists, clean, and apply a thin coat of oil. Report it to your supervisor.

**Bolts, Nuts, and Screws.** Check them all for obvious looseness, missing, bent, or broken condition. You can't try them all with a tool, but look for chipped paint, bare metal, or rust around bolt heads. If you find a bolt, nut, or screw you think is loose, tighten it or report it to your supervisor.

**Welds.** Look for loose or chipped paint, rust, or gaps where parts are welded together. If you find a bad weld, report it to your supervisor.

**Electric Wires and Connectors,** Look for cracked, frayed, or broken insulation, bare wires, and loose or broken connectors. Tighten loose connectors. Report any damaged wires to your supervisor.

**Hoses and Fluid Lines.** Look for wear, damage, and leaks, and make sure clamps and fittings are tight. Wet spots show leaks, but a stain around a fitting or connector can also mean a leak. If a leak comes from a loose fitting or connector, tighten it. If something is broken or worn out, report it to your supervisor.

When you check for "operating condition," you look at the component to see if it's serviceable.

## **2-3. CLEANING AGENTS.**



- DO NOT use diesel fuel, gasoline, or benzene (benzol) for cleaning.
- DO NOT SMOKE when using cleaning solvent. NEVER USE IT NEAR AN OPEN FLAME. Be sure there is a fire extinguisher nearby and use cleaning solvent only in well-ventilated places. Flash point of solvent is 138°F (60°C).
- USE CAUTION when using cleaning solvents. Cleaning solvents evaporate quickly and can irritate exposed skin if solvents contact skin. In cold weather, contact of exposed skin with cleaning solvents can cause frostbite.

**CAUTION**

When cleaning, engine must be COLD (same temperature as outside air). DO NOT point water or steam directly at any electrical connection. DO NOT point water stream directly at radiator fins. DO NOT use high pressure water supply system. Damage to engine, electrical system, and other components may result.

**NOTE**

Only use those authorized cleaning solvents or agents listed in Appendix D.

**Cleaning Engine.**

When using water to clean the engine use water pressure and volume similar to a standard household type water supply system (45-70psi, 6.5-10.2 kPa).

After cleaning, allow engine to air dry. Do not use compressed air to dry engine. Do not run engine to decrease drying time.

Remove all component covers before starting engine.

**CAUTION**

When cleaning, engine must be COLD (same temperature as outside air). DO NOT point water or steam directly at any electrical connection. DO NOT point water stream directly at radiator fins. DO NOT use high pressure water supply system. Damage to engine, electrical system, and other components may result.

Keep cleaning solvents, gasoline, and lubricants away from rubber or soft plastic parts. They will deteriorate material.

**Cleaning Rust or Grease.** When cleaning grease buildup or rusty places, use a cleaning solvent. Then apply a thin coat of light oil to affected area.

**2-4. LEAKAGE DEFINITIONS FOR OPERATOR PMCS.** It is necessary for you to know how fluid leakage affects the status of the pump. Following are types/classes of leakage an operator needs to know to be able to determine the status of the pump. Learn these leakage definitions and remember - when in doubt, notify your supervisor.

**CAUTION**

When cleaning, engine must be COLD (same temperature as outside air). DO NOT point water or stem directly at any electrical connection. DO NOT point water stream directly at radiator fins. DO NOT use high pressure water supply system. Damage to engine, electrical system, and other components may result.

- Equipment operation is allowable with minor leakages (Class I or II). Of course, consideration must be given to fluid capacity in the item/system being checked/inspected. When in doubt, notify your supervisor.
- When operating with Class I or II leaks, continue to check fluid levels as required in your PMCS.
- Class III leaks should be reported immediately to your supervisor,

CLASS I - Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

CLASS II - Leakage of fluid great enough to form drops but not enough to cause drops to drip from item being checked/inspected.

CLASS III Leakage of fluid great enough to form drops that fall from item being checked/inspected.

--

Table 2-1 Operator Preventive Maintenance Checks and Semites




Item No.	Interval	Location		Procedure	Not Fully Mission Capable
		Item to Check/ Service			
1	Before	FUEL TANK		<p align="center"><b>-NOTE-</b></p> <p>Items 1 through 8 are for Gasoline Engine Driven (GED) pumps. Items 9 through 14 are for Electric Motor Driven (EMD) pumps.</p> <p align="center"><b>-FRONT-</b></p> <p>Remove Cap (1) and check cap, strainer (2) and gasket (3).</p>  <p align="center"><b>-LEFT SIDE-</b></p> <p>Loosen ball nut (4) and swing bail (5) to remove bowl (6). Clean bowl and remove strainer or gasket (7) as required.</p> 	Leaks, cap missing, trainer clogged, gasket broken or missing.
2	Before	SEDIMENT STRAINER		<p align="center"><b>-LEFT SIDE-</b></p> <p>Loosen ball nut (4) and swing bail (5) to remove bowl (6). Clean bowl and remove strainer or gasket (7) as required.</p> 	Strainer leaking or loose connection.

Table 2-1 Operator Preventive Maintenance Checks and Services (Cont.)



Item No.	Interval	Location	Procedure	Not Fully Mission Capable
		Item to Check Service		
3	Before	OIL LEVEL DIP STICK	<p>Remove oil level dip stick (8) and check for oil level. Add oil if needed.</p> 	No oil, oil level low or no dip stick.
4	Before	AIR CLEANER	<p>Inspect air cleaner visual signal (9) to determine if red SERVICE LEVEL signal is visible. If the signal is visible proceed as follows. Turn wing bolts (10) one quarter turn to loosen. Wipe out inside of element housings (11). To clean filter element (12) blow off element with compressed air from clean to dirty side of element. To reassemble insert cleaned element (12). Turn wing bolts (10) one quarter turn to tighten DO NOT USE WRENCH.</p> <p><b>EMERGENCY - To clean gently tap element against hand. Do not tap against hard objects. Filter element (12) can be washed in soap and water. Do not use gasoline or other solvents.</b></p> 	



Table 2-1 Operator Preventive Maintenance Checks and Services


Item No.	Interval	Location Item to Check/ Service	Procedure	Not Fully Mission Capable
5	Before	ENGINE	<p><b>Caution use care when cleaning. do not puncture filter element. Press button (14) in SERVICE LEVEL signal.</b></p>  <p><b>Perform lubrication to or in conjunction with with PMCS. Refer to LO 5-2805-256-16.</b></p> <p>Make the following walk around checks;</p> <ul style="list-style-type: none"> <li>a. Check for fuel leakage on around and under pump assembly.</li> <li>b. Check air cleaner restriction indicator if red <b>RED SERVICE</b> signal is visible, clean or replace filter element.</li> <li>c. Check for broken, cracked, and damaged motor mounts and components. Check for loose and missing hardware. Check frame and shock mounts for deterioration, cracks, and damage.</li> </ul>	<p>Class III oil leaks or any fuel leaks found.</p> <p>Motor mounts, shock mounts, components, or hardware missing, damaged cracked or deteriorated.</p>

Table 2-1 Operator Preventive Maintenance Checks and Services (Cont.)



Item No.	Interval	Location	Procedure	Not Fully Mission Capable
		Item to Check/Service		
6	Before	PUMP	Inspect pump (1) for Class III leaks, cracks, or other damage.	Pump has cracks, Class III leaks, or other damage.
7	Before	SUCTION VALVE	Check suction valve(2) for proper operation and leaks.	Suction valve leaks, has cracks or is loose.
				
8	During	ENGINE/PUMP	During starting and operation, check pump for fuel and oil leakage. Check for excessive vibration unusual noise, and any indication of failing or defective components.	Excessive vibration, unusual noise or failing or defective components.
9	Before	ELECTRIC CORD AND CONNECTORS	Inspect for breaks, frayed insulation and loose connections.	Loose connections, frayed, or broken wires.
10	Before	ELECTRIC MOTOR	Inspect electric motor (1) for proper mounting, dirt, and loose connections (2).	Electric motor has loose mountings or connections.
				

Table 2-1 Operator Preventive Maintenance Checks and Services (Cont.)




Item No.	Interval	Location		Procedure	Not Fully Mission Capable
		Item to Check/Service			
11	Before	ELECTRIC MOTOR FAN		inspect electric motor fan guard (3) for dirt, foreign matter, and damage.	Fan motor has loose fan guard
					
12	Before	ELECTRIC MOTOR AND PUMP		<p>Make the following walk around checks;</p> <p>a. Check the electric motor and cable for loose connections, evidence of over heating, and damaged insulation.</p> <p>b. Check for broken, cracked, and damaged motor mounts and components. Check for loose and missing hardware. Check shock mounts for deterioration, cracks , and damage.</p>	<p>Motro or pump has loose connection or evidence of overheating.</p> <p>Motor or pump haa loose, missing, damaged, or deteriorating motor mounts, shock mounts or components.</p>
13	During	ELECTRIC MOTOR AND PUMP		During starting and operation, check for excessive vibration, unusual noise, and indication of a failling or defective component. If suspected, notify your supervisor.	Motor or pump has excessive vibration, unusual noise or indication of failling component.
14	During	PUMP		Inspect pump (1) for Class III leaks, cracks, or other damage.	Pump has cracks, Class III leaks or other damage.
					

Table 2-1 Operator Preventive Maintenance Checks and Services (Cont.)

Item No.	Interval	Location	Procedure	Not Fully Mission Capable
		Item to Check/Service		
15	During	SUCTION VALVE	<p>Check suction valve (2) for proper operation and leaks.</p> 	Suction valve inoperable or has class III leaks.

EQUIPMENT INSPECTION AND MAINTENANCE WORKSHEET										
For use of this form, see TM 58-750, the pertinent agency is the Office of the Deputy Chief of Staff for Logistics										
1. ORGANIZATION					2. DESCRIPTION AND MODEL					
3. EQUIPMENT/SERIAL NO.		4. MILES	5. HOURS	6. HOURS FIRED	7. HOY STARTS	8. DATE	9. TYPE INSPECTION			
APPLICABLE REFERENCE										
TM NUMBER				TM DATE		TM NUMBER		TM DATE		
<p><b>INSTRUCTIONS</b> - Perform each check listed in the TM applicable to the inspection performed. Following the sequence listed in pertinent TM, complete form as follows:</p> <p><b>COLUMN a</b> - Enter TM item number.</p> <p><b>COLUMN b</b> - Enter the applicable condition status symbol.</p> <p><b>COLUMN c</b> - Enter deficiencies and shortcomings.</p> <p><b>COLUMN d</b> - Show corrective action for deficiency or shortcoming listed in Column c.</p> <p><b>COLUMN e</b> - Individual ascertaining completed corrective action initial in this column.</p>										
ALL INSPECTIONS AND EQUIPMENT CONDITIONS RECORDED ON THIS FORM HAVE BEEN DETERMINED IN ACCORDANCE WITH DIAGNOSTIC PROCEDURES AND STANDARDS IN THE TM CITED HEREON.										
10. SIGNATURE (Person performing inspection)				11. TIME		12. SIGNATURE (Maintenance Supervisor)		13. TIME		14. MANHOURS REQUIRED
TM ITEM NO.	STATUS	DEFICIENCIES AND SHORTCOMINGS			CORRECTIVE ACTION			INITIAL WHEN CORRECTED		

**DA FORM 2404**  
1 JAN 66

160-10-7000-1

Figure 2-3. Equipment Inspection and Maintenance Worksheet.

### Section III. OPERATION UNDER USUAL CONDITIONS

#### 2-3. GENERAL.

The instructions in this section are for personnel who operate the pump. It describes how the pump is started and stopped in normal weather conditions.

#### 2-4. ASSEMBLY AND PREPARATION FOR USE.

##### 2-4.1. Unloading the Equipment.

The total weight of the crated centrifugal pump is 110 pounds. A handtruck, forklift, or manpower may be used to unload the crated unit. The crate must be kept in an upright position as shown on the crate while unloading.

##### 2-4.2. Unpacking the Equipment.

a. General. For domestic shipping, the centrifugal pump is packed in a cardboard box.

b. Unpacking. Cut and remove all retaining straps from cardboard box. Remove centrifugal pump from its container.

**CAUTION**

Be careful while unpacking to avoid damaging equipment.

c. Removal of Protective Materials and Preservatives. Remove protective tape and coverings from inlet and outlet ends of centrifugal pump. Prepare engine for inspection and operation as outlined on DA Form 2258 (Depreservation Guide).

##### 2-4.3. Inspecting and Servicing Equipment.

a. Check identification plate against packing bill for positive identification of equipment.

b. Visually inspect equipment for any damage which may have occurred during shipment. Make certain that all nuts and bolts are in place and secure.

For inspection and servicing of new or used engine, refer to TM 5-2805-256-14.

d. Perform daily preventive maintenance services listed in paragraph 2-2.

## 2-4.4. Installation or Setting-Up Instructions.

- a. General. The pump is shipped assembled for operation.
- b. Installation.

(1) Place pump on a base that is solid and strong enough to support weight of unit. Refer to paragraph 1-9 for dimensions of base.

(2) Select a level site where there will be enough space on all sides for servicing and operation of the unit.

(3) Place pump as close as possible to source of water. Avoid long suction lifts which reduce pumping efficiency.

(4) Connect hoses to inlet and outlet adapters. Make sure intake end of inlet hose is connected.

(5) If pump is operated in enclosed area, make certain that there is proper ventilation and exhaust gases are piped outside.

**WARNING**

Never operate pump in enclosed areas unless exhaust gases are piped outside. Exhaust gases contain carbon monoxide, a colorless, odorless, and poisonous gas, which can cause serious illness or death.

## 2-5. STARTING THE EQUIPMENT.

Before you operate. Always keep in mind the *CAUTIONS AND WARNINGS*.

- a. Preparation for Starting.

(1) Do the before operation preventive maintenance services (para 2-2).

(2) Prime pump as described in figure 2-4, if pump *is not* full of water.

**CAUTION**

Do not operate pump without priming. Running pump dry will damage pump seals and the pump will not operate. Do not operate pump for long periods of time without water flowing through it.





Figure 2-4. Priming the pump.

- b. Starting the Gasoline Engine Driven Pump. Start pump as shown below:

NOTE


Allow engine sufficient warmup time before starting pumping operations.

- 1 - Move choke control to CLOSE.







2 - Turn Fuel Shut Off Valve to OPEN.




3 - Move throttle control to half throttle and tighten throttle nut.




4 - Set ignition switch to Run.




- 5 - Place the Inlet Air Temperature Control in the SUMMER position.




- 6 - Wind starter rope as shown around starter pulley and pull rope sharply.



- 7 - When engine starts and warms up, slowly open choke. Maintain smooth operation until choke is fully open.




- 8 - Let engine run at about one-half throttle until it reaches operating temperature.
- 9 - When operating temperature is reached, move throttle control to full throttle for maximum pumping rate. If less than maximum pumping rate is desired, adjust throttle control position to the required speed setting.




- 10 - To stop pumping without stopping engine, move throttle control to idle position and allow engine to idle.
- 11 - To resume pumping operation move throttle control to desired speed setting.

**C. Starting the Electric Motor Driven Pump. Start pump as shown below:**

- 1 - Using the Ground Rod and Attachments, ground unit as follows. (Required on Electrical Powered Pump only.) Drive the rod into the ground at least 8 feet. Attach one end of 6 AWG wire to the generator's ground terminal and tighten the nut. Slip the other end between the clamp and the rod and tighten the screw. If there is a wire hole in the clamp, use it.




- 2 - Connect the power connector to a power source.



The pump will be pumping.

- 3 - Check fan to see if it rotates as shown:




4 - If rotation is not correct check incoming power source.


**2-6. STOPPING THE EQUIPMENT.**

**a. Stopping Gasoline Engine Driven Pump.**

1 - Place the throttle control in the idle position, and let the engine idle for 3 to 5 minutes. This will allow the engine to cool.



2 - Set the Ignition Switch to OFF.



**b. Stopping Electric Motor Driven Pump.**

Disconnect connector on cable from power source.

## 2-7. DISMANTLING FOR MOVEMENT.

The pump is completely self-contained and can be moved over short distances manually by lifting at the ends of the pump frame. If the pump is to be transported by carrier, block or tie it to the carrier to prevent it from shifting while being transported.

**CAUTION**

When tying pump to carrier, install bands through frame, Do not secure by banding across channels.

- a. Disconnect inlet and outlet hoses from inlet and outlet adapters.
- b. Cover openings of inlet and outlet adapters to protect adapter threads and prevent foreign matter from entering pump. If the pump is gasoline driven proceed as follows:
  - c. Disconnect exhaust pipe extension if used.
  - d. Drain fuel from fuel tank into suitable container.

## 2-8. REINSTALLATION AFTER MOVEMENT.

Refer to paragraph 2-4.4 for installation and setting up procedures.

## Section IV. OPERATION UNDER UNUSUAL CONDITIONS

### 2-9. GENERAL.

This section contains instructions for operation of the equipment in the following conditions: extreme cold, extreme heat, dusty or sandy areas, rainy or humid conditions, salt water areas, and high altitudes.

### 2-10. OPERATION IN EXTREME COLD.

#### a. Gasoline Engine Driven Pump.

(1) Keep fuel tank full to prevent condensation. Drain and service fuel filter more frequently than under normal conditions (paragraph 3-5.2).

(2) Before starting engine, remove any accumulated ice or snow from spark plugs and wiring.

(3) Make sure Inlet Air Temperature shutter on engine is set for winter operation.

(4) Run engine at low speed to warm to operating temperature before applying full load.

(5) Lubricate engine in accordance with current lubrication order LO 5-2805-256-14.

(6) Fill pump with warm water to prevent freezing at starting.

(7) Drain pump immediately after operation as shown in figure 2-5.

#### b. Electric Motor Driven Pump.

(1) Fill pump with warm water to prevent freezing at starting.

(2) Drain pump immediately after operation as shown in figure 2-5.




Figure 2-5. Pump Draining Instructions.

## 2-11. OPERATION IN EXTREME HEAT.

### a. Gasoline Engine Driven Pump.

(1) Make sure Inlet Air Temperature shutter is set for summer operation.

(2) Keep pump clean and free of dust. If pump is operated indoors, allow sufficient room around unit for air circulation. Make sure exhaust is vented outside.

(3) Inspect shrouding and cooling fins of engine for dust or foreign matter which might stop flow of air.

(4) Lubricate engine in accordance with current lubrication order LO 5-2805-256-14 and TM 5-2805-256-14.

### b. Electric Motor Driven Pump.

(1) Keep pump clean and free of dust. If pump is operated indoors, allow sufficient room around unit for air circulation. Make sure exhaust is vented outside.

(2) Inspect cooling fins of motor for dust or foreign matter that might stop flow of air.



**2-12. OPERATION IN DUSTY OR SANDY AREAS.****a. Gasoline Engine Driven Pump.**

(1) If installation is permanent, erect protective shield for pump. If installation is temporary, take advantage of natural barriers which offer protection from dust and sand.

(2) Service air cleaner daily to keep fuel system free from sand and dirt (TM 5-2805-256-14).

(3) Strain all fuel before adding to fuel tank. Drain and service fuel filter more frequently than under normal conditions (paragraph 4-2.2).

(4) Clean pump frequently. Wipe it with a cloth dampened in approved cleaning solvent.

(5) Lubricate engine in accordance with current lubrication order LO 5-2805-256-14 and TM 5-2805-256-14.

**b. Electric Motor Driven Pump.**

(1) If installation is permanent, erect protective shield for pump. If installation is temporary, take advantage of natural barriers which offer protection from dust and sand.

(2) Clean pump frequently. Wipe it with cloth dampened in approved cleaning solvent.

**2-13. OPERATION UNDER RAINY OR HUMID CONDITIONS.****a. Gasoline Engine Driven Pump.**

(1) If unit is outside and not operating, cover unit with canvas or other waterproof material during damp, rainy weather. Remove cover during dry weather to allow unit to dry out.

(2) Keep fuel tank full at all times to prevent condensation. Drain and service fuel filter frequently (paragraph 4-2.2).

(3) Humid conditions can cause corrosion and deterioration of electrical components. Keep electrical components clean and dry.

(4) Lubricate engine in accordance with current lubrication order LO 5-2805-256-14 and TM 2805-256-14.

**b. Electric Motor Driven Pump.**

(1) If unit is outside and not operating, cover unit with canvas or other waterproof material during damp, rainy weather. Remove cover during dry weather to allow unit to dry out.

(2) Humid conditions can cause corrosion and deterioration of electrical components. Keep electrical components clean and dry.

## 2-14. OPERATION IN SALT WATER AREAS.

### a. Gasoline Engine Driven Pump.

(1) Salt water causes corrosive action on metal. Care must be taken to avoid contact with salt water. After contact with salt water, wash unit with clean, fresh water.

(2) Coat exposed metal with rustproofing material. Remove any rust immediately and cover exposed surface with a coat of paint.

(3) Clean lubrication surfaces prior to lubricating. Lubricate engine in accordance with current lubrication order LO 5-2805-256-14 and TM 4-2805-256-14.

### b. Electric Motor Driven Pump.

(1) Salt water causes corrosive action on metal. Care must be taken to avoid contact with salt water. After contact with salt water, wash unit with clean, fresh water.

(2) Coat exposed metal with rustproofing material. Remove any rust immediately and cover exposed surface with a coat of paint.

## **WARNING**

Disconnect pump from **source** of electric power, to eliminate electric shock.

## 2-15. OPERATION AT HIGH ALTITUDES.

### a. Gasoline Engine Driven Pump.

Because of thinner air at higher altitudes, the carburetor may require an adjustment providing a leaner mixture. **If** this condition exists, refer to TM 5-2805-256-14.

### b. Electric Motor Driven Pump.

There are no special requirements.

CHAPTER 3  
OPERATOR MAINTENANCE INSTRUCTIONS

---

Section I. LUBRICATION INSTRUCTIONS

3-1. GENERAL LUBRICATION INFORMATION.

The gasoline engine is the only component of the centrifugal pump that requires lubrication. The pump and electric motor uses prelubricated, sealed ball bearings that require no further lubrication.

3-2. DETAILED LUBRICATION INFORMATION.

Refer to the current lubrication order LO 5-2805-256-14 and to TM 5-2805-256-14 for engine lubrication instructions.

**CAUTION**

When OES oil is used, it will be checked more often.

Section II. TROUBLESHOOTING

3-3. GENERAL.

The table lists the common malfunctions which you may find during the operation or maintenance of the pump or it's components. should perform the test/inspections and corrective actions in the order listed.

This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. **If** a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor. Refer to TM 5-2805-256-14 for engine troubleshooting.

Table 3-1. OPERATOR TROUBLESHOOTING

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. GASOLINE ENGINE DRIVEN PUMP FAILS TO PUMP TO RATED CAPACITY.		
	Step 1 - Check for low engine speed.	Adjust engine speed.
	Step 2 - Check for sufficient fuel.	Adjust fuel control valve.
	Step 3 - Check position of Choke Control	Readjust.
	Step 4 - Check position of Inlet Air Temperature Control.	Readjust.
	Step 5 - Check that pump is located close to source of supply.	Relocate pump.
	Step 6 - Check pump for leaks, cracks, or other damage.	Notify maintenance activity.
2. ELECTRIC MOTOR DRIVEN PUMP.		
	a. INTERMITTENT OPERATION	
	Step 1 - Check for bad connections or power cable.	Notify maintenance activity.
	Step 2 - Suction line clogged.	Clean

Table 3-1. OPERATOR TROUBLESHOOTING (Continued)

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
	Step 3 - Suction line too long.	Move pump closer to water.
	Step 4 - Air leak.	Notify maintenance activity.
	Step 5 - Pump impeller clogged.	Clean.
	b. MOTOR FAILS TO RUN PROPERLY.	Notify maintenance activity.
	c. MOTOR OVERHEATS	
	Step 1 - Defective motor.	Notify maintenance activity.
	Step 2 - Incorrect power source (voltage too high or low).	Check power source.
3. PUMP FAILS TO PRIME.		
	Step 1 - Check pump for leaks, cracks, or other damage.	Notify maintenance activity.
	Step 2 - Check pump for sufficient prime.	Reprime pump.
	Step 3 - Check drain pet cock.	Clean or notify maintenance activity.



CHAPTER 4  
UNIT MAINTENANCE INSTRUCTIONS

---

#### 4-1. GENERAL .

This chapter contains the removal, cleaning, inspection, and installation procedures for Organizational Maintenance.

*Before maintenance always keep in mind  
the WARNINGS and CAUTIONS located on the  
inside front cover*

Preventive Maintenance Checks and Services (PMCS) means systematic care, inspection, and service of equipment to keep it in good condition and to prevent breakdowns. As the pump's operator, your mission is to:

Be sure to perform your PMCS regularly. Always do your PMCS in the same order, so it gets to be a habit. Once you've had some practice, you'll quickly spot anything wrong. Pay attention to WARNINGS, CAUTIONS, and NOTES.

#### 4-1.1 PMCS PROCEDURES.

a. Your Preventive Maintenance Checks and Services, Table 4-1, lists inspections and care required to keep your pump in good operating condition.

b. The "INTERVAL" column of Table 4-1 tells you when to do a certain check or service.

c. The "PROCEDURE" column of Table 4-1 tells you how to do required checks and services. Carefully follow these instructions.

#### NOTE

Terms "ready/available" and "mission capable" refer to same status:  
Equipment is on hand and ready to perform its combat missions. (See  
DA Pam 738-750)

d. The "EQUIPMENT IS NOT READY/AVAILABLE IF:" column in Table 4-1 tells you when your pump is nonmission capable and why the pump cannot be used,

e. If the pump does not perform as required, refer to Paragraph 4-4.1 Unit Troubleshooting.

f. When you do your PMCS, you will always need a rag or two. Following are checks that are common to the entire pump:

(1) Keep It Clean. Dirt, grease, oil, and debris only get in the way and may cover up a serious problem. Clean as you work and as needed. Use dry cleaning solvent (SD-2) on all metal surfaces. Use soap and water when you clean rubber or plastic material. Upholstery can be cleaned with soap and water and a clean, damp cloth.

(a) Rust and Corrosion. Check pump body and frame for rust and corrosion, If any bare metal or corrosion exists, clean, and apply a thin coat of oil.

(b) Bolts, Nuts, and Screws. Check them all for obvious looseness, missing, bent, or broken condition. You can't try them all with a tool, but look for chipped paint, bare metal, or rust around bolt heads. If you find a bolt, nut, or screw you think is loose, tighten it.

(c) Welds. Look for loose or chipped paint, rust, or gaps where parts are welded together.

(d) Electric Wires and Connectors, Look for cracked, frayed, or broken insulation, bare wires, and loose or broken connectors. Tighten loose connectors.

(e) Hoses and Fluid Lines. Look for wear, damage, and leaks, and make sure clamps and fittings are tight. Wet spots show leaks, but a stain around a fitting or connector can also mean a leak. If a leak comes from a loose fitting or connector, tighten it.

g. When you check for "operating condition," you look at the component to see if it's serviceable.

#### 4-1.2 CLEANING AGENTS.



- DO NOT use diesel fuel, gasoline, or benzene (benzol) for cleaning.
- DO NOT SMOKE when using cleaning solvent. NEVER USE IT NEAR AN OPEN FLAME. Be sure there is a fire extinguisher nearby and use cleaning solvent only in well-ventilated places. Flash point of solvent is 138°F (60°C).
- USE CAUTION when using cleaning solvents. Cleaning solvents evaporate quickly and can irritate exposed skin if solvents contact skin. In cold weather, contact of exposed skin with cleaning solvents can cause frostbite.



#### NOTE

Only use those authorized cleaning solvents or agents listed in Appendix D.

h. Cleaning Engine.

(1) When using water to clean the engine use water pressure and volume similar to a standard household type water supply system (45-70psi, 6.5-10.2 kpa).

(a) After cleaning, allow engine to air dry. Do not use compressed air to dry engine. Do not run engine to decrease drying time.



Remove all component covers before starting engine.

**CAUTION**

Keep cleaning solvents, gasoline, and lubricants away from rubber or soft plastic parts. They will deteriorate material.

Cleaning Rust or Grease. When cleaning grease buildup or rusty places, use a cleaning solvent. Then apply a thin coat of light oil to affected area.

**4-1.3 LEAKAGE DEFINITIONS FOR UNIT PMCS,** It is necessary for you to know how fluid leakage affects the status of the pump. Following are types/classes of leakage the maintainer needs to know to be able to determine the status of the pump.

**CAUTION**

Equipment operation is allowable with minor leakages (Class I or II). Of course, consideration must be given to fluid capacity in the hem/system being checked/inspected.

CLASS I-Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

CLASS II - Leakage of fluid great enough to form drops but not enough to cause drops to drip from item being checked/inspected.

CLASS III - Leakage of fluid great enough to form drops that fall from item being checked/inspected.

Table 4-1 Unit Preventive Maintenance Checks and Services

Item No.	Interval	Item To Be Checked Or Serviced	Procedure	Not Fully Mission Capable If:
1	Quarterly	<b>SHOCK MOUNTS</b>	Inspect shocks mounts for cracks or deterioration.	Shock mounts are cracked or deteriorated.
2	Quarterly	<b>FRAME</b>	Inspect frame for cracks, breaks or deterioration.	Frame cracked, broken, or deteriorated.
3	Quarterly	<b>SEDIMENT STRAINER</b>	Loosen ball nut (1) and swing bail (2) to remove bowl (3). Clean bowl and remove strainer or gasket (4) as required.	Strainer leaking or loose connection.
4	Quarterly	<b>FUEL LINE</b>	Inspect fuel line (5) for leaks, kinks, breaks, and loose connections.	Fuel line leaks or has kinks, breaks or loose connections.





Table 4-1 Unit Preventive Maintenance Checks and Services (Cont.)

Item No.	Interval	Item To Be Checked Or Serviced	Procedure	Not Fully Mission Capable If:
5	Quarterly	MUFFLER	Inspect muffler for cracks, holes, and faulty connections.	Muffler has cracks, holes, or loose connections.
6	Quarterly	ADJUSTMENTS	During operational test listen for any unusual noises or vibration. Make all necessary adjustments during operational test.	
7	Quarterly	PUMP	Inspect pump (1) for Class III leaks, cracks, or other damage.	Pump has cracks, Class III leaks, or other damage.
8	Quarterly	ADAPTERS	Inspect inlet and outlet adapters (2) for class III leaks or damage.	Adapters are cracked, loose or have class III leaks.
9	Quarterly	SUCTION VALVE	Check suction valve (3) for proper operation and leaks.	Suction valve leaks, has cracks or is loose.




Table 4-1 Unit Preventive Maintenance Checks and Services (Cont.)

Item No.	Interval	Item To Be Checked Or Serviced	Procedure	Not Fully Mission Capable If:
10	Quarterly	ELECTRIC CORD AND CONNECTORS	Inspect cord and connectors for breaks, frayed insulation or loose connections.	Cord or connector are loose or cracked.
11	Quarterly	ELECTRIC MOTOR	Inspect Electric motor (1) and connections (2) for proper mounting, and dirt.	Motor mounts or connections are loose.
12	Quarterly	ELECTRIC MOTOR FAN	Inspect electric motor fan guard (3) for dirt, foreign matter and damage.	Fan guard loose or is damaged.




Table 4-1 Unit Preventive Maintenance Checks and Services (Cont.)


Item No.	Interval	Item To Be Checked Or Serviced	Procedure	Not Fully Mission Capable If
13	Semiannually	SUCTION VALVE	<p>Check suction valve(1) for proper operation and leaks.</p> 	suction valve leaks, has cracks or is loose.
14	Semiannually	SPARKPLUG AND CABLE	<p>a. Check spark plug for cracked insulation or burned electrodes. Clean and set plug gap (para 4-22).</p> <p>b. Check spark plug cable for loose connections and damaged insulation.</p>	<p>Spark plug has burned electrodes or cracked insulation.</p> <p>Spark plug cable is loose or insulation is damaged.</p>
15	Semiannually	CONTACT POINTS AND CONDENSER	Check for pitted or burned points. Clean and set point gap (para 4.31)	Point or burned or pitted. Condenser defective.
16	Semiannually	CRANKCASE	Check vent assembly for dirt or damage.	Vent assembly damaged or dirty.

Table 4-1 Unit Preventive Maintenance Checks and Services (Cont.)

Item No.	Interval	Item To Be Checked Or Serviced	Procedure	Not Fully Mission Capable If:
17	Semiannually	FUEL FILTER	Remove and clean sediment bowl and filter.	Filter defective or damaged.

**4-2. GASOLINE ENGINE DRIVEN PUMP.**

This section contains the maintenance instructions for the engine, and fuel system components which are not described in TM 5-2850-256-14. It includes coverage of the fuel tank, fuel filter, fuel lines and fittings, and engine. Also included is information on the fuel tank, mounting hardware, and fuel line changes necessary to change from engine Model 1A08-1 to engine Model 1A08-3.

**4-2.1. Fuel Tank**

a. Removal

- (1) Refer to figure 4-1. Drain fuel tank (1) into a suitable container.
- (2) Disconnect fuel line (2) at fuel filter (3).
- (3) Remove screws (4) that attach fuel tank to bracket.
- (4) Remove fuel tank cap and strainer (5).




Figure 4-1. Fuel Tank Removal.





Table 4-1 Unit Preventive Maintenance Checks and Services (Cont.)


Item No.	Interval	Item To Be Checked Or Serviced	Procedure	Not Fully Mission Capable If:
13	Semiannually	SUCTION VALVE	<p>Check suction valve ( 1) for roper operation and leaks.</p> 	Suction valve leaks, has racks or is loose.
14	Semiannually	SPARKPLUG AND CABLE	<p>a. Check spark plug for cracked insulation or burned electrodes. Clean and set plug gap (para 4-22).</p> <p>b. Check spark plug cable for loose connections and damaged insulation.</p>	<p>Spark plug has burned electrodes or cracked insulation.</p> <p>Spark plug cable is loose or insulation is damaged.</p>
15	Semiannually	CONTACT POINTS AND CONDENSER	Check for pitted or burned points. Clean and set point gap (para 4.31)	Point or burned or pitted. Condenser defective.
16	Semiannually	CRANKCASE	Check vent assembly for dirt or damage.	Vent assembly damaged or dirty.

Table 4-1 Unit Preventive Maintenance Checks and Services (Cont.)

Item No.	Interval	Item To Be Checked Or Serviced	Procedure	Not Fully Mission Capable If:
17	Semiannually	FUEL FILTER	Remove and clean sediment bowl and filter.	Filter defective or damaged.

**4-2. GASOLINE ENGINE DRIVEN PUMP.**

This section contains the maintenance instructions for the engine, and fuel system components which are not described in TM 5-2850-256-14. It includes coverage of the fuel tank, fuel filter, fuel lines and fittings, and engine. Also included is information on the fuel tank, mounting hardware, and fuel line changes necessary to change from engine Model 1A08-1 to engine Model 1A08-3.

**4-2.1. Fuel Tank**

a. Removal

- (1) Refer to figure 4-1. Drain fuel tank (1) into a suitable container.
- (2) Disconnect fuel line (2) at fuel filter (3).
- (3) Remove screws (4) that attach fuel tank to bracket.
- (4) Remove fuel tank cap and strainer (5).




Figure 4-1. Fuel Tank Removal.



b. Cleaning and Inspection.

- (1) Thoroughly clean fuel tank.

**WARNING**

Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is 100°F (38°C).

(2) Clean fuel strainer and cap with approved cleaning solvent; shake dry.

- (3) Inspect for cracks, breaks, or other damage.

(4) Repair cracks and breaks, using approved arc welding methods.

**WARNING**

Make sure all gasoline fumes are removed from tank before starting welding operations. Fumes in tank can cause a severe explosion if ignited.

c. Installation.

Repeat the removal procedure in reverse sequence.

## 4-2.2. Fuel Lines, Filter.

a. Removal.

(1) Refer to figure 4-2. Loosen finger nut (1) on yoke (2) of fuel filter. Swing yoke upward and remove fuel bowl (3) and unscrew filter (4).

(2) Disconnect fuel line (5) from tank and fuel filter.

(3) Disconnect fuel filter from engine fuel pump.




Figure 4-2. Fuel Line and Filter Removal,

b. Cleaning and Inspection.



Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is **100°F (38°C)**.

(1) Clean fuel filter, bowl assembly and fuel lines with approved cleaning solvent and dry thoroughly.

(2) Inspect fuel filter, connector threads, bowl, and bowl gasket for cracks, breaks, and other damage.

(3) Inspect fuel lines for cracks, distortion, or other damage.

(4) Replace all damaged or defective parts.

c. Installation.

Using figure 4-2 repeat the removal procedure in reverse sequence.

## 4-2.3. Exhaust System.

The exhaust system maintenance and inspection procedures, are listed and illustrated in TM 5-2805-256-14.

## 4-2.4. Engine.

This section contains the engine removal procedures. All engine maintenance procedures and instructions are described and illustrated in TM 5-2805-256-14.

a. Removal.

(1) Remove fuel lines and filter as per paragraph 4-2.2.

(2) Remove centrifugal pump as per paragraph 4-4.

b. Cleaning and Inspection.

Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is 100°F (38°C).

(1) Clean exterior of engine with approved cleaning solvent and dry thoroughly.

(2) Inspect engine for any external damage, tag engine, noting any defects or damage, and return it to depot maintenance.

c. Installation.

Repeat the removal procedure (para 4-2.4) in reverse sequence.

## 4-2.5. Frame.

Two channels mounted on the frame with shock mounts support the engine and pump and absorb the shock and vibration of the pump while in operation. The tubular frame supports and protects the pump and engine.

a. Removal.

(1) Remove fuel lines and filter as per paragraph 4-2.2.

(2) Remove centrifugal pump as per paragraph 4-4.

- (3) Remove engine as per paragraph 4-2.4.
- (4) Remove fuel tank as per paragraph 4-2.1.
- (5) Refer to figure 4-3. Remove capscrews (1), lock washers (2), and nut (3).
- (6) Remove channels (4).




Figure 4-3. Channel Removal.


b. Cleaning and Inspection.




Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is 100°F (38°C).

- (1) Clean channels and frame with approved cleaning solvent or wire brush as required.
- (2) Inspect channels and frame for cracks or bends.
- (3) Inspect shock mounts for cracks, wear, and deterioration.





ENGINE 1A08-1



ENGINE 1A08-3

Figure 4-4. Fuel Tank Replacement

**c.** Repair.

Refer to Direct Support Maintenance.

**d.** Installation.

(1) Refer to figure 4-3. Repeat the removal procedures in reverse sequence.

4-2.6. Conversion Engine Model 1A08-1 to Model 1A08-3.

When the Model 1A08-1 engine is replaced with a Model 1A08-3 engine the following changes are required.

**a.** Engine mounting. The rails used to mount the 1A08-1 engine are made with the brackets as an assembly. The rails used to mount the 1A08-3 engine are separate from the brackets. When replacing the 1A08-1 with a 1A08-3 model, requisition the rails and brackets for installation. The brackets used for mounting the 1A08 engine will fit any Military Standard engine.

**b.** Fuel System. When the engine is replaced the fuel system must also be replaced. The items to be replaced are as shown in figure 4-4 and are as follows:

- 1 - Bracket
- 2 - Fuel line
- 3 - Fuel tank

NOTE

The existing fuel tank can be used with a possible modification of the bracket.

- 4 - Fuel filter.

Refer to Appendix D for part numbers.

4-3. ELECTRIC MOTOR DRIVE in PUMP.

4-3.1. Power Cord.

**a.** Removal.

(1) Refer to figure 4-5. Remove screws (1) that attach connection box cover (2) to motor (3).

(2) Disconnect power cable (4) from wires (5) inside connection box.

(3) Loosen connector (7) and remove cable (4).




Figure 4-5. Power Cable Replacement (Electric Motor Driven Pump).

b. Cleaning and Inspection.



Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is 100°F (38° C).

Clean the metal parts with an approved solvent and dry thoroughly.

c. Installation.

(1) Repeat the removal procedure in reverse sequence.

(2) Connect wires as follows:

<u>MOTOR WIRE</u>	<u>CABLE WIRE</u>
1	Black
2	White
3	Red
Ground	Green

(3) Insulate cable connections in accordance with standard practices.

4-3.2. Electric Motor.

This section contains the motor removal procedures.

a. Removal.

(1) Remove the centrifugal pump as per paragraph 4-4.

(2) Remove the power cable as per paragraph 4-3.1.

(3) Refer to figure 4-6. Remove nuts (1), washers (2) and screws (3) that attach motor (4) to frame (5).




Figure 4-6. Electric Motor Removal.

b. Cleaning and Inspection.



Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is 100 F (38°C).

- (1) Clean the metal parts with an approved solvent and dry thoroughly.
- (2) Inspect for damage and defects, replace as necessary.

c. Installation.

Refer to figure 4-6. Repeat the removal procedure in reverse sequence.

4-3.3. Frame.

Two channels welded to the frame support the electric motor and pump. The tubular frame supports and protects the motor and pump.

a. Removal.

- (1) Remove power card as per paragraph 4-3.1.
- (2) Remove centrifugal pump as per paragraph 4-4.
- (3) Remove electric motor as per paragraph 4-3.2.

b. Cleaning and Inspection.

**WARNING**

Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is 100° F (38° C).

- (1) Clean the frame with an approved drycleaning solvent.
- (2) Inspect frame for cracks or other damage.

c. Repair.

Refer to Direct Support Maintenance.

d. Installation.

Repeat the removal procedure in reverse sequence.

**4-4. CENTRIFUGAL PUMP.**

The centrifugal pump is coupled to the gasoline engine or electric motor. The pump case houses the impeller, wear plate, and seal and serves as a water chamber with suction and discharge ports. The volute, which bolts to the front of the pump case, completely encircles the impeller. A check valve prevents water backflow through the pump.

4-4.1. Troubleshooting.

Table 4-2 is used for organizational maintenance activity troubleshooting. This table is to be used in conduction with the preventive maintenance table contained in paragraph 2-2.

Table 4-2. Maintenance Activity Troubleshooting.

---

MALFUNCTION

TEST OR INSPECTION

CORRECTIVE ACTION

---

1. PUMP FAILS TO PUMP TO RATED CAPACITY.

Step 1- Check if check valve is defective.

Replace check valve. (Refer to para 4-4.3)

Step 2- Check if impeller is clogged or broken.

Flush pump case or replace impeller. (Refer to para 4-4.2)

Step 3- Check pump case for leaks, cracks, or damage.

Repair or replace case. (Refer to para 4-4.2)

Step 4- Check if packing seals are worn or defective.

Replace packing seals. (Refer to para 4-4.2)

Step 5- Check if clearance between wear plate and impeller is excessive,

Install shims as required. (Refer to para 4-4.2)

2. PUMP FAILS TO PRIME.

Step 1- Check if check valve is defective

Replace check valve. (Refer to para 4-4.3)

Step 2- Check if suction flange is loose or defective,

Tighten mounting nuts or replace suction flange. (Refer to para 4-4.3)

Step 3- Check if packing seals are worn or defective.

Replace impeller. (Refer to para 4-4.2)

Table 4-2. Maintenance Activity Troubleshooting (Continued).

## MALFUNCTION

## TEST OR INSPECTION

## CORRECTIVE ACTION

---

Step 4- Check if impeller is damaged.

Replace impeller. (Refer to para 4-4.2)

## 3. PUMP NOISY.

Step 1- Check if pump mounting hardware is loose.

Tighten pump mounting hardware. (Refer to para 4-4.2)

Step 2- Check if impeller is broken.

Replace impeller shaft. (Refer to para 4-4.2)

Step 3- Check if impeller shaft is defective.

Replace impeller shaft (Refer to para 4-4.2)

---

## 4-4.2. Pump.

a. Removal.

(1) Gasoline engine disconnect one spark plug lead (1). Electric motor disconnect power cord (l).

(2) Disassemble pump in numerical sequence as shown in figure 4-7.

## 4-4.3. Check Valve.

a. Removal.

(1) Refer to figure 4-7. Remove nuts (23) and washers (24), then suction flange (25).

(2) Remove gasket (28), consisting of small weight (27) and large weight (29).

(3) Remove screw (26) separating items (29), (28), and (27).

b. Installation.

Reverse the above procedure.




Figure 4-7. Centrifugal Pump Assembly, Disassembly and Reassembly.



Figure 4-7 Legend.

1. Shoulder bolt	19. Nut
2. Cover plate	20. Washer
3. O-ring	21. Diverter
4. Cap Screw	22. Adapter, suction flange
5. Lockwasher	23. Nut
6. Washer	24. Lockwasher
7. Impeller	25. Suction flange
8. Screw	26. Screw
9. Wear plate	27. Weight (small)
10. Shim	28. Gasket, check valve
11. Key	29. Weight (large)
12. Adapter shaft	30. Stud
13. Seal assembly	31. Plug
14. Gasket, adapter	32. Draincock
15. Adapter, discharge	33. Body
16. Elbow, discharge	34. Drive screw
17. Nipple, discharge	35. Serial plate
18. Setscrew	

b. Cleaning and Inspection.



Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid inhalation of fumes and repeated or prolonged skin exposure. Wash exposed skin thoroughly with soap and water. Use in well ventilated area away from open flame or excessive heat. Flash point is **100°F (38°C)**.

(1) Clean all parts with approved cleaning solvent and dry thoroughly.

(2) Inspect housings, impeller, wear plate, seals, and shaft, and shaft coupling for cracks, breaks, wear, leaky seals, and other damage.

(3) Repair cracks and breaks in housings using approved arc welding methods, provided repair does not upset critical pump tolerances.

.... (4) Replace all damaged or defective parts.

c. Installation.

(1) Refer to figure 4-7, reassembly pump in reverse sequence.

(2) Reassemble shaft/impeller assembly using sufficient shims (10) to result in an impeller-face to wear plate-face clearance of 0.010" to 0.015".

(3) Reassemble peeler and adjust to result in peeler-to-impeller clearance of 0.005" to 0.0015".

(4) Lightly oil O-ring (3) and reassemble cover (2) in place on body (33).

## CHAPTER 5

DIRECT SUPPORT MAINTENANCE INSTRUCTIONS

---

## 5-1. GENERAL.

This chapter contains maintenance instructions for Direct Support personnel. Reference to TM 5-2805-265-14 for engine maintenance.

## 5-2. FRAME .

## 5-2.1. Gasoline Driven Pump.

a. Removal.

Remove all components from frame (para 4-2.5 a).

b. Cleaning and Inspection.

Clean and inspect frame (para 4-2.5 b).

c. Repair.

(1) Repair cracks and broken welds using approved arc welding methods.

(2) Straighten bends with hammer, anvil or vise.

(3) Replace shock mounts if required.

d. Installation.

Refer to paragraph 4-2.5. Repeat removal procedure in reverse sequence.

## 5-2.2. Electric Motor Drive Pump.

a. Removal.

Remove all components from frame (para 4-3.3 a).

b. Cleaning and Inspection.

Clean and inspect frame (para 4-3.3 b).

c. Repair.

(1) Repair cracks and broken welds using approved arc welding methods.

(2) Straighten bends with hammer, anvil or vise.

(3) Replace shock mounts if required.

d. Installation.

Refer to paragraph 4-3.3. Repeat removal procedure in reverse sequence.

5.3. ELECTRIC MOTOR.

This section contains testing and repair procedures for the electric motor.

a. Removal.

Remove all components from frame (para 4-3.3 a).

b. Cleaning and Inspection.


Clean and inspect motor (para 4-3.3 b).

c. Testing.

Using a suitable test lamp circuit, test for continuity between each of the motor wires. Replace the motor if lamp does not light. Test for grounds between one motor (any one) wire and frame. If lamp does light, replace the motor.

d. Repair.

Disassemble the motor and replace components as needed. Refer to figure 5-1 for electric motor component breakdown.



- |     |           |     |           |
|-----|-----------|-----|-----------|
| 1.  | Cover     | 15. | Bearing   |
| 2.  | Fan       | 16. | Sleeve    |
| 3.  | End Plate | 17. | Gasket    |
| 4.  | Washer    | 18. | Box       |
| 5.  | Stator    | 19. | Screw     |
| 6.  | End Plate | 20. | Gasket    |
| 7.  | Washer    | 21. | Lid       |
| 8.  | Screw     | 22. | Screw     |
| 9.  | Nut       | 23. | Screw     |
| 10. | Bearing   | 24. | Fitting   |
| 11. | Rotor     | 25. | Wire      |
| 12. | Shaft     | 26. | Bolt      |
| 13. | Fan       | 27. | Set Screw |
| 14. | Retainer  | 28. | Set Screw |

Figure 5-1. Electric Motor.



## APPENDIX A

## REFERENCES

## A-1. Fire Protection

TB 5-4200-200-10 Hand Portable Fire Extinguishers Approved for Army Users.

## A-2. Lubrication

C9100-12 Fuels, Lubricants, Oils and **Waxes**  
 TB703-1 Specification List of Standard Liquid Fuels, Lubricants, Preservatives and Related Products Authorized by U.S. Army

LO 5-2805-256-12 Lubrication Orders: Engine, Gasoline, 1-1/2 HP Military Standard Models (Model 1A08-1) Models A108-2 (Model 1A08-3) to 38G2-102-2LC-1 L103520A-10/1

## A-3. Painting

AR746-1 Color, Marking and Preparation for Equipment for Shipment

AR746-5 Marking and Packing of Supplies and Equipment Color and Marking of Army Materiel.

## A-4. Maintenance

TM 5-764 Electric Motor and Generator Repair  
 TM 5-2805-256-24P Organizational, Direct and General Support Maintenance Repair Parts: Engine, Gasoline 1-1/2 HP Military Standard Models 1A08-1 FSN 2805-601-5181, Model 1A08-2, FSN 2805-714-8552; Model 1A08-3 FSN 2805-068-7510 (SL-4-03620A; T038G2-102-4)

TM 38-750 The Army Maintenance Management System (TAMMS) Field Command Procedures

TM 9-207 Operation and Maintenance of Ordnance Materiel in Cold Weather (0 to -65°F).

## A-5. Shipment and Storage

TB 740-93-2 Preservation of USAMECOM Mechanical Equipment for Shipment and Storage

TM 740-90-1 Administrative Storage Equipment

## A-6. Demolition

TM 750-244-3 Procedures for Destruction of Equipment to Prevent Enemy Use

## A-7. Radio Suppression

TM 11-483 Radio Interference Suppression





## APPENDIX B

## MAINTENANCE ALLOCATION CHART

## Section I. INTRODUCTION

## B-1. GENERAL.

a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance levels.

b. The Maintenance Allocation Chart (MAC) in section II designates overall responsibility for the performance of maintenance functions on the identified end item or component. The implementation of the maintenance functions upon the end item or component will be consistent with the assigned maintenance functions.

c. Section III lists the special tools and test equipment required for each maintenance function as referenced from section II.

d. Section IV contains supplemental instructions on explanatory notes for a particular maintenance function.

## B-2. MAINTENANCE FUNCTIONS.

a. Inspect. To determine the serviceability of an item by comparing its physical, mechanical and/or electrical characteristics with established standards through examination.

b. Test. To verify serviceability and detect incipient failure by measuring the mechanical or electrical characteristics of an item and comparing those characteristics with prescribed standards.

c. Service. Operations required periodically to keep an item in proper operating condition, i.e., to clean (decontaminate), to preserve, to drain, to paint, or to replenish fuel, lubricants, hydraulic fluids, or compressed air supplies.

d. Adjust. To maintain, within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.

e. Align. To adjust specified variable elements of an item to bring about optimum or desired performance.

f. Calibrate. To determine and cause corrections to be made or to be adjusted on instruments or test measuring and diagnostic equipments used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

g. Install. The act of emplacing, seating, or fixing into position an item, part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

h. Replace. The act of substituting a serviceable like type part, subassembly, or module (component or assembly) for an unserviceable counterpart.

i. Repair. The application of maintenance services or other maintenance actions to restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

j. Overhaul. The maintenance effort (service/actions) necessary to restore an item to a completely serviceable/operational condition as prescribed by maintenance standards (i.e., DMWR) in appropriate technical publications. Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

Section II. MAINTENANCE ALLOCATION CHART

(1) Group Number	(2) Component/Assembly	(3) Maintenance function	(4) Maintenance level					(5) Tools and equipment	(6) Remarks
			C	O	F	H	D		
01 0100	Engine Assembly	Inspect	0.2					1	A
	Engine Gasoline	Service		1.0			**		
	Mount Shock	Replace		2.0					
02 0200	Fuel System Tank, Lines and Fittings	Replace		1.0					
		Inspect	0.1						
03 0300	Frame Frame Assembly	Service	0.2					1	
		Replace		0.5					
04 0400	Accessory Items Cable Assembly	Inspect	0.1	1.0					
		Replace			2.0			4	
0401	Data Plates	Repair							
		Inspect	0.1						
05 0500	Electric Motors Motor	Replace		0.5				2	
		Inspect	0.1	0.5				1	
		Replace							2
0501	Ventilating System	Inspect							
		Test		0.1	2.5		**	3	
		Repair		2.0	2.8			3	
06 0600	Pump Pump Assembly	Replace	0.1						
		Inspect							
		Service	0.4				**		
0601	Impeller	Replace		2.0				1	
		Inspect		2.0				2	
0602	Seal Assembly	Inspect		0.2				1	
		Replace		0.3				1	
		Inspect	0.1						
0602	Discharge and Suction Valve, Check	Replace		0.5				1	
		Inspect	0.1						
		Replace		0.3				1	
0602	Adaptors Gasket, Flange	Replace		0.3				2	
		Inspect	0.1						

\*\* Indicates WT/MH Required

Section III. TOOL AND TEST EQUIPMENT REQUIREMENTS.

(1) Reference Code	(2) Maintenance Level	(3) Nomenclature	(4) National /NATO Stock Number	(5) Tool Number
1	O, F	Tool Kit, General Mechanics Automotive (W33004) or equivalent	5180-00-177-7033	
2	0	Shop Equipment Auto- motive maintenance and repair; organizational maintenance or equi- valent (W32593)	4910-00-754-0654	
3		Shop Set, Fuel and Electrical System: Fuel Maintenance, Basic (T30414) or equivalent	4910-00-390-7774	
4	F	Welding Shop, trailer mounted (Y48323) or equivalent	3431-00-935-7821	

Section IV. REMARKS  
Maintenance Allocation Chart

Reference Code	Remarks
A	Maintenance allocation chart for engine is in TM 5-2805-256-14.



APPENDIX C

ADDITIONAL AUTHORIZATION LIST

Section I. INTRODUCTION

C-1. SCOPE.

This appendix lists additional items you are authorized for the support of the Centrifugal Pump.

C-2. GENERAL.

This list identifies items that do not have to accompany the Centrifugal Pump and that do not have to be turned in with it.

C-3. EXPLANATION OF LISTING.

National stock numbers, descriptions, and quantities are provided to help you identify and request the additional items you require to support this equipment.

(1) NATIONAL STOCK NUMBER	(2) DESCRIPTION FSCM & PART NUMBER USABLE ON CODE	(3) U/M	(4) QTY. AUTH
7520-00-559-9618 5975-00-243-5861 4210-00-555-8837 5975-00-642-8937 2990-00-972-7950 6145-00-189.6695	CASE: Operator Maintenance ..BYZ CTH BZB CLAMP: Wire ..... CTH BZB EXTINGUISHER:Fire ..... BYZ CTH BZB ROD: Ground .....CTH BZB ROPE: Starting .....BYZ WIRE: Electrical .....CTH BZB	ea ea ea ea ea ft	1 1 1 1 1 10





## APPENDIX D

## REPAIR PARTS AND SPECIAL TOOLS LIST

## Section I. INTRODUCTION

## D-1. Scope.

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of operator's organizational, and direct support maintenance of the Centrifugal Pump. It authorizes the requisitioning and issue of repair parts as indicated by the source and maintenance codes.

## D-2. General.

This Repair Parts and Special Tools List is divided into the following sections:

- a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence,
- b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized for the performance of maintenance (Not Applicable. )
- c. Section IV. National Stock Number and Part Number Index. A list, in National Item Identification Number (NIIN) sequence, of all National Stock Numbers (NSN) appearing in the listings, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance. This index is followed by a cross-reference list of reference designators to figure and item numbers.

## D-3. Explanation of Columns.

- a. Illustration. This column is divided as follows:

- (1) Figure Number. Indicates the figure number of the illustration of which the item is shown.

- (2) Item Number. The number used to identify item called out in the illustration.

- b. Source, Maintenance, and Recoverability (SMR) Codes.

- (1) Source Code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items.

Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply system.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later date.
KD	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at the direct support maintenance level.
MH	Item to be manufactured or fabricated at general maintenance support level.
MD	Item to be manufactured or fabricated at depot maintenance level.
AO	Item to be assembled at organizational level.
AF	Item to be assembled at direct support maintenance level.
AH	Item to be assembled at general support maintenance level.
AD	Item to be assembled at depot maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in replacement of the next higher assembly.
XB	Item not procured or stocked. <b>If</b> not available through salvage, requisition.
XD	A support item that is not stocked. When required, item will be procure through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and support items restricted by AR **700-42**.

(2) Maintenance Code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The Maintenance Code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance.

Code	Appl i cati on/Expl anati on
C -	Crew or operator maintenance performed within organizational maintenance
O -	Support item is removed, replaced, used at the organizational level.
I -	Support item is removed , replaced, used by the direct support element of integrated direct support maintenance.
F -	Support item is removed, replaced, used at the direct support level.
H -	Support item is removed, replaced, used at the general support level.
D -	Support items that are removed, replaced, used at depot, mobile depot, or specialized repair activity only.

NOTE

Codes I and F will be considered the same by direct support units.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes.

Code	Appl i cati on/Expl anati on
O -	The lowest maintenance level capable of complete repair of the support item is the organization level.
F -	The lowest maintenance level capable of complete repair of the support item is the direct support level.
H -	The lowest maintenance level capable of complete repair of the support item is the general support level.
D -	The lowest maintenance level capable of complete repair of the support item is the depot level.
L -	Repair restricted to designated, Specialized Repair Activity.
Z -	Nonreparable. No repair is authorized.

- B - No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) Recoverability Code. Recoverability code are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability Code	Definition
z -	Non-repairable item. When unserviceable, condemn and dispose at the level indicated in position three (3).
o -	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F -	Repairable item. When uneconomically repairable, condemn and dispose at direct support level.
H -	Repairable item. When uneconomically repairable, condemn and dispose at general support level.
D -	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L -	Repairable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.
A -	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. National Stock Number. Indicates the National stock number assigned to the item and which will be used for requisitioning.

d. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which control the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.

e. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42; which is used to identify the manufacturer, distributor, or Government agency, etc.

f. Description. Indicates the Federal item name and, if required, a minimum description to identify the items. Items that are included in kits and sets are listed below the name of the kit or set with the quantity of each item in the kit or set indicated in the quantity incorporated in unit column.

g. Unit of Measure (U/M), Indicates the standard or basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g.: ea, in, pr, etc.). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for functional group, subfunctional group, or an assembly. A “V” appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, (e.g., shims spacers, etc).

D-4. Special Information.

a. Usable on codes are shown in the description column. Uncoded items are applicable to all models. Identifications of the usable codes used in this publication are:

Code	Used On
BYZ	Barnes Model 17570
BYZ	Schleyer Model 4M-SG-2000
CTH	Schleyer Model 4M-SE2000
BZB	Barnes Model US4CCE

D-5. How to Locate Repair Parts.

a. When National Stock Number or Part Number is Unknown:

(1) Using the table of contents determine the assembly group within which the repair part belongs. This is necessary since illustrations are prepared for assembly groups, and listings are divided into the same group.

(2) Find the illustration covering the assembly group to which the repair part belongs.

(3) Identify the repair part on the illustration and note the illustration figure number and item number of the repair part.

(4) Using the repair parts listing, find the assembly group to which the repair part belongs and locate the illustration figure and item number noted on the illustration.

b. When National Stock Number of Part Number is Known:

(1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphanumeric sequence, cross-referenced to the illustration figure number and item number.

(2) Second. After finding the figure and item number, locate the figure and item number in the repair parts list.




Figure D-1. Engine, Support and Carrying Frame.

(1) ILLUSTRATION (a) FIG NO	(2) (b) ITEM NO	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) FSCM	(6) PART NUMBER	TMS-4320-200-13&P (6) DESCRIPTION	USABLE ON CODE	(7) USABLE ON U/M	(8) QTY INC IN UNIT
						GROUP 01 ENGINE ASSEMBLY			
D-1	1	PAOZZ	5305-00-068-0502	96906	MS90725-6	SCREW, CAP, HEXAGON HEAD		BYZ EA	8
D-1	2	PAOZZ	5310-00-012-0380	96906	MS35338-25	WASHER LOCK		BYZ EA	8
D-1	3	PBOZZ	4320-00-717-1380	97403	13200E7202	PUMP, BODY		EA	1
D-1	4	PBOZZ	5315-00-043-1787	96906	MS35756-34	KEY, MACHINE		EA	8
D-1	5	PBOZZ	2805-00-068-7510	96906	A1A08-3	ENGINE, GASOLINE USE ON SERIAL NO. 27139-121 AND UP		BYZ EA	1
D-1	6	PBOZZ	5306-00-225-9093	96906	MS90726-38	BOLT, MACHINE		BYZ EA	8
D-1	7	PBOZZ	5310-00-582-5615	96906	MS35690-522	NUT, PLAIN, HEXAGON		BYZ EA	8
D-1	8	PBOZZ	5310-00-012-0214	96906	MS35338-26	WASHER, LOCK		BYZ EA	8
D-1	9	XOZZ		97403	13200E7229	BRACKET, ENGINE		BYZ EA	2
D-1	10	PBOZZ	5306-00-225-9093	96906	MS90726-38	BOLT, MACHINE		BYZ EA	8
D-1	11	PBOZZ	5310-00-880-7746	96906	MS51968-5	NUT, PLAIN, HEXAGON		EA	8
D-1	12	XBOZZ		97403	13200E7230	SUPPORT, ENGINE		BYZ EA	2
D-1	13	XBOZZ		97403	13200E7217	FRAME ASSEMBLY		BYZ EA	1
D-1	14	XBOZZ		08288	MSS5305-3	SCREW, DRIVE		BYZ, BZB EA	8
D-1	15	XBOZZ		08288	MSS9905-3	PLATE, IDENTIFICATION		BZB EA	1




Figure D-2. Fuel Tank Lines and Fittings



(1) ILLUSTRATION (a) FIG NO		(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) FSCM	(5) PART NUMBER	TMS-4320-200-13&P (6) DESCRIPTION	USABLE ON CODE	(7) USABLE ON U/M	(8) QTY INC IN UNIT
						GROUP 02 FUEL SYSTEM			
D-2	1	PAOFF	5310-00-584-5005	96906	MS36890-408	NUT, PLAIN, HEXAGON	BYZ	EA	5
D-2	2	PAOFF	5310-00-012-0380	96906	MS35338-05	WASHER, LOCK	BYZ	EA	5
D-2	3	PAOZZ	5305-00-068-0502	96906	MS35927-6	SCREW, CAP, HEXAGON HEAD	BYZ	EA	4
D-2	4	PAOZZ	2910-00-735-2526	05748	17838SA	TANK, FUEL	BYZ	EA	1
D-2	5	MOOZZ				LINE ASSEMBLY, MAKE FROM NSN 4710-00-277-5525	BYZ	EA	1
D-2	5A		4730-00-011-8537	96906	MS39166-3L	NUT, TUBE, COUPLING, 45° FLARE TYPE		EA	1
D-2	5B		4730-00-011-4627	96906	MS39176-3	NUT, TUBE, COUPLING, TAPERED SLEEVE TYPE		EA	1
D-2	5C		4730-00-278-8763	96906	MS39177-3	SLEEVE, COMPRESSION		EA	1
D-2	5D		4710-00-277-5525			TUBING (BULK)		EA	1
D-2	6	PBOZZ	4730-00-270-4615	97403	13215E5883	ADAPTER, STRAIGHT, PIPE TO TUBE	BYZ	EA	1
D-2	7	PBOZZ	4730-00-263-4963	08288	MSS4730-13	ELBOW, PIPE TO TUBE	BYZ	EA	1
D-2	8	PAOZZ	2910-00-905-9792	96906	MS51086-1	STRAINER, SEDIMENT	BYZ	EA	1
D-2	8A	XAOZZ		80463	100-7	VALVE, FUEL SHUTOFF		EA	1
D-2	8B			70040	854-254	BAIL ASSY, STRAINER		EA	1
D-2	8C	PAOZZ	5330-00-594-2293	70040	854-389	GASKET		EA	1
D-2	8D	XAOZZ		80463	854187	STRAINER, FUEL		EA	1
D-2	8E	XAOZZ		70040	1522092	BOWL, SEDIMENT		EA	1
D-2	9	PBOZZ	4730-00-921-3628	96906	MS51953-1	NIPPLE, PIPE	BYZ	EA	1
D-2	10	XBOZZ		05748	18021	SPACER, BRACKET	BYZ	EA	2
D-2	11	PBOZZ	5306-00-071-2242	96906	MS90725-9	SCREW, CAP, HEXAGON HEAD	BYZ	EA	1
D-2	12	XBOZZ		97403	13215E5883	BRACKET, FUEL TANK	BYZ	EA	1
D-2	13	PBOZZ	2910-00-294-1579	78252	17900	CAP, ASSEMBLY	BYZ	EA	1
D-2	14	PAOZZ	4320-00-111-5163	78252	23438051	STRAINER, FUEL TANK	BYZ	EA	1




Figure D-3. Frame

(1)		(2)	(3)	(4)	(5)	TMS-4320-200-13&P (6)	(7)	(8)
ILLUSTRATION (a)	ITEM (b)	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	QTY INC IN UNIT
D-3	1	PAOZZ	5310-00-732-0558	96906	MS51967-8	GROUP 03 FRAME NUT, PLAIN, HEXAGON	CTH, BZB EA	4
D-3	2	PAOZZ	5310-00-543-5101	96906	MS35338-46	WASHER, LOCK	CTH, BZB EA	4
D-3	3	PAOZZ	5310-00-269-3214	96906	MS90725-64	SCREW, CAP, HEXAGON HEAD	CTH, BZB EA	4
D-3	4	XBOZZ		97403	13200E7218	FRAME ASSEMBLY	CTH, BZB EA	1
D-3	5	PAOZZ	5305-00-269-3209	96906	MS51967-2	NUT, PLAIN, HEXAGON	CTH, BZB EA	1
D-3	6	PAOZZ	5305-00-269-3209	96906	MS90725-6	SCREW, CAP, HEXAGON HEAD	CTH, BZB EA	1
D-3	7	PAOZZ	5310-00-543-5101	96906	MS35338-44	WASHER, LOCK	CTH, BZB EA	1
D-3	8	PAOZZ	5940-00-143-4794	96906	MS20659-109	THERMINAL, LUG	CTH, BZB EA	1
D-3	9	XBOZZ		08288	MSS5305-3	SCREW, DRIVE	BZB EA	2
D-3	10	XBOZZ		08288	MSS9905-3	PLATE, IDENTIFICATION	BYZ, BZB EA	1




Figure D-4 Cable Assembly

(1)		(2)	(3)	(4)	(5)	TMS-4320-200-13&P (6) DESCRIPTION	(7)	(8)
ILLUSTRATION (a) FIG NO	ITEM (b) NO	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER		USABLE ON U/M	QTY INC IN UNIT
						GROUP 04 ACCESSORY ITEMS		
D-4	1	PAOZZ	6150-00-971-2116	81336	13200E7222	CABLE ASSEMBLY	BZB EA	1
D-4	2	PAOZZ	5310-00-732-0558	96906	MS21083N3	NUT,PLAIN,HEXAGON	CTH,BZB EA	3
D-4	3	PAOZZ	5305-00-957-6652	96906	MS35207-264	SCREW,MACHINE	BZB EA	3
						(USED TO SECURE POWER CABLE TO MOTOR)		
D-4	4	PAOZZ	5310-00-903-8282	96906	MS210683N4	NUT,SELF-LOCKING,HEXAGON	CTH,BZB EA	1
						(USED TO SECURE POWER CABLE TO MOTOR)		
D-4	5	PAOZZ	5305-00-993-2641	96906	MS35207-281	SCREW,MACHINE	CTH,BZB EA	1
						(USED TO SECURE POWER CABLE TO MOTOR)		




Figure D-5. Electric Motor.

(1) ILLUSTRATION (a) FIG NO	(2) (b) ITEM NO	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) FSCM PART NUMBER	(6) TMS-4320-200-13&P DESCRIPTION	(7) USABLE ON U/M	(8) QTY INC IN UNIT
					GROUP 05 ELECTRIC MOTOR		
D-5		PBOFZ	4320-00-932-9705	97403 13200E7211	ELECTRIC MOTOR AND PUMP ASSEMBLY  (SEE FIGURE D-6 FOR PUMP BREAKDOWN)	CTH,BZB EA	1
D-5	1	XBFZZ		05472 36-696	COVER,FAN	CTH,BZB EA	1
D-5	2	XDFZZ		05472 36-100A	FAN,COOLING	CTH,BZB EA	1
D-5	3	XBFZZ		05472 36-2120	ENDPLATE	CTH,BZB EA	1
D-5	4	XBFZZ		96906 MS35338-5	WASHER,FLAT	CTH,BZB EA	2
D-5	5	XDFZZ		05472 36-2118	STATOR,WITH BASE	CTH,BZB EA	1
D-5	6	XBFZZ		05472 36-694	ENDPLATE	CTH,BZB EA	1
D-5	7	XBOZZ		05472 52WEB	WASHER,WAVY	CTH,BZB EA	1
D-5	8	PAFZZ	5305-00-995-3441	96906 MS35207-269	SCREW,CAP,HEXAGON HEAD	CTH,BZB EA	2
D-5	9	XBFZZ		96906 MS35690-401	NUT,PLAIN,HEXAGON	CTH,BZB EA	1
D-5	10	PBFZZ	6105-00-876-6356	38443 205SZZ	BEARING,BALL,ANNULAR	BZB EA	1
D-5	11	XDOZZ		05472 36-271	ROTOR	CTH,BZB EA	1
D-5	12	PBOZZ	5315-00-043-1787	96906 MS357565-34	KEY,MACHINE	EA	1
D-5	13	XBFZZ		05472 36-2119	SHAFT	CTH,BZB EA	1
D-5	14	XDFZZ		05472 36-136	PLATE,RETAINING	CTH,BZB EA	1
D-5	15	XBOZZ		05472 36417	RETAINER,BEARING	CTH,BZB EA	1
D-5	16	PBFZZ	3110-00-109-1157	38443 205SZZ	BEARING,BALL,ANNULAR	CTH,BZB EA	2
D-5	17	XBFZZ		05472 6-31	SPACER,SLEEVE	CTH,BZB EA	1
D-5	18	XBFZZ		05472 36-48	GASKET	CTH,BZB EA	1
D-5	19	XBFZZ		05472 36-213	BOX,CONDUCT	CTH,BZB EA	1
D-5	20	XBFZZ		96906 MS24641-49	SCREW,MACHINE	CTH,BZB EA	2
D-5	21	XBFZZ		05472 36-49	GASKET	CTH,BZB EA	1
D-5	22	XBOZZ		05472 36-40	LID,BOX	CTH,BZB EA	1
D-5	23	XBFZZ		96096 MS2464945	SCREW,MACHINE	CTH,BZB EA	3
D-5	24	XBFZZ		96906 MS35230-61	SCREW,MACHINE	CTH,BZB EA	1
D-5	25	XBOZZ		05472 22549	GLAND,CABLE	BZB EA	1
D-5	26	PAFZZ	5940-00-143-4794	96906 MS25036-12	TERMINAL,LUG	CTH,BZB EA	3
D-5	27	XBFZZ		05472 36-37A	SCREW,CAP,HEXAGON HEAD	CTH,BZB EA	1
D-5	28	PAFZZ	5305-00-579-2972	96906 02781	SCREW,FAN MOUNTING	BZB EA	1
D-5	29	PAOZZ	5305-00-723-9305	96906 MS51963-65	SETScrew	CTH,BZB EA	2
D-5	30	XBOZZ		08288 MSS5305-3	SCREW,DRIVE	BZB EA	8
D-5	31	XBOZZ		08288 MSS9905-3	PLATE,IDENTIFICATION	BZB EA	1




Figure D-6. Pump



(1) ILLUSTRATION (a) FIG NO	(2) (b) ITEM NO	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	(5) FSCM	(6) PART NUMBER	TMS-4320-200-13&P (6) DESCRIPTION	USABLE ON CODE	(7) USABLE ON U/M	(8) QTY INC IN UNIT
						GROUP 06 PUMP			
D-6		XBOZZ		97403	13200E7211	PUMP,CENTRIFUGAL		CTH,BZB EA	1
D-6	1	XBOZZ	5306-00-686-5722	97403	13200E7212	BOLT,SHOULDER		EA	2
D-6	2	XBOZZ		97403	13200E7203	COVER,PLATE		EA	1
D-6	3	PBOZZ	5330-00-527-8116	96906	MS29513-252	PACKING,PREFORMED		EA	1
D-6	4	PAOZZ	5300-00-225-9089	96906	MS90726-34	SCREW,MACHINE		BYZ EA	1
D-6	4	PAOZZ	5306-00-225-9089	96906	MS90726-33	BOLT,MACHINE		CTH,BZB EA	3
D-6	5	XDOZZ		96906	MS35338 45	WASHER,LOCK		BYZ EA	2
D-6	5	XDOZZ	5310-00-407-9566	96906	MS35336-45	WASHER,LOCK		CTH,BZB EA	3
D-6	6	XBOZZ		97403	13214E9380-5	WASHER,FLAT		BZB EA	1
D-6	7	PBOZZ	4320-00-784-6797	97403	13200E7204	IMPELLER,PUMP		EA	1
D-6	8	PAOZZ	5305-00-957-6652	96906	MS35198-67	SCREW,MACHINE		EA	3
D-6	9	PAOZZ	4320-00-790-6358	97403	13200E7214	PLATE WEAR		EA	1
D-6	10	XBOZZ		81349	MIL-S-22499	SHIM		EA	1
D-6	11	PBOZZ	5315-00-054-3207	80205	NAS558-606-10	KEY,MACHINE		BZB EA	1
D-6	12	PBOZZ	4320-00-784-6799	97403	13200E7205	ADAPTER,SHAFT		EA	1
D-6	13	PAOZZ	4320-00-790-6357	97403	13200E8806	SEAL ASSEMBLY		EA	1
D-6	14	PAOZZ	5330-00-202-4645	05748	18451	SEALPUMP		BYZ,BZB EA	1
D-6	15	PAOZZ	4730-01-043-7867	97403	13218E0479-17	ADAPTER,STRAIGHT		EA	1
D-6	16	XBOZZ		96906	MS39230-8	ELBOW,PIPE		BZB EA	1
D-6	17	PAOZZ	4730-00-196-1531	96906	MS51953-172	NIPPLEPIPE		EA	1
D-6	18	PAOZZ	5305-00-054-9261	96906	MS51054-6	SETSCREW		BYZ EA	1
D-6	19	XBOZZ		96906	MS35691-402	NUT,PLAIN,HEXAGON		EA	1
D-6	20	XBOZZ		80205	NAS1515H4	WASHER,FLAT		EA	1
D-6	21	XBOZZ		97403	13200E7213	DIVERTER,PUMP		EA	1
D-6	22	PAOZZ	5310-00-012-0368	97403	13200E7201-22	NUT,PLAIN,HEXAGON		EA	2
D-6	23	PBOZZ	4320-00-103-8199	97403	13200E7224	FLANGE ASSEMBLY		EA	1
D-6	24	XBOZZ		97403	13200E7225	FLANGE,SUCTION		BYZ,BZB EA	1
D-6	25	PAOZZ	5305-00-984-6210	96906	MS35206-263	SCREW,MACHINE		EA	1
D-6	26	XAOZZ		97403	13200E7227	WEIGHT,SMALL		EA	
D-6	27	XBOZZ		97403	13200E7226	GASKET		EA	1
D-6	28	XAOZZ		97403	13200E7228	WEIGHT,LARGE		EA	
D-6	29	PAOZZ	5307-01-078-2425	80205	NAS183-5-13A	STUD,PLAIN		EA	2
D-6	30	PAOZZ	4730-00-555-1355	96906	MS20913 60R	PLUG,PIPE		EA	1
D-6	31	PAOZZ	4820-00-272-3346	96906	MS35784 3	COCK,DRAIN		BYZ EA	1
D-6	32	PBOZZ	4320-00-717-1380	97403	13200E7202	BODY,PUMP		EA	1
D-6	33	PAOZZ	5305-00-253-5625	96906	MS21318-46	SCREW,DRIVE		EA	2
D-6	34	XDOZZ		97403	13219E2404	PLATE,PUMP		CTH,BZB EA	1
D-6	35	PAOZZ	4730-00-277-6844	81349	MIL-C-52404	ADAPTER,STRAIGHT		EA	1



By Order of the Secretary of the Army:

E. C. MEYER  
*General, United States Army*  
*Chief of Staff*

Official:

ROBERT M. JOYCE  
*Major General, United States Army*  
*The Adjutant General*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A, operator Maintenance requirements for Pumps, Fresh Water.





THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)  
**PFC JOHN DOE**  
**COA, 3d ENGINEER BN**  
**FT. L. HOWARDWOOD, MO 63108**  
 DATE SENT

PUBLICATION NUMBER: **TM 5-4320-200-13EP**  
 PUBLICATION DATE  
 PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS				IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:
PAGE NO	PARA-GRAPH	FIGURE NO	TABLE NO	
6	2-1 a			In line 6 of paragraph 2-1a the manual states the engine has <u>6</u> cylinders. The engine on my set only has <u>4</u> cylinders. Change the manual to show <u>4</u> cylinders.
B1		4-3		Callout 16 on figure 4-3 is pointing at a <u>bolt</u> . In key to figure 4-3, item 16 is called a <u>shim</u> - Please correct one or the other.
125	line 20			I ordered a gasket, item 19 on figure B-16 by NSN 2 910-05-762-3001. I got a gasket but it doesn't fit. Supply says I got what I ordered, so the NSN is wrong. Please give me a <u>good NSN</u>

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER  
**JOHN DOE, PFC (268) 317-7111**

SIGN HERE **JOHN DOE**  
**JOHN DOE**

1 Nov 80


I  
I

FILL IN YOUR  
UNITS ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY



OFFICIAL BUSINESS

TEAR ALONG PERFORATED LINE

**COMMANDER**

U.S. ARMY AVIATION AND TROOP COMMAND

Am: AMSAT-I-MP

4300 GOODFELLOW BOULEVARD

ST. LOUIS, MO 63120-1798

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

**SOMETHING WRONG WITH THIS PUBLICATION?**

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

PAGE NO

PARA-GRAPH

FIGURE NO

TABLE NO

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2  
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.  
DRSTS-M Overprint 2, 1 Nov 80.

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

1 Nov 80

FILL IN YOUR  
UNITS ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

---

---

OFFICIAL BUSINESS

COMMANDER  
U.S. ARMY AVIATION AND TROOP COMMAND  
ATTN: AMSAT-I-MP  
4300 GOODFELLOW BOULEVARD  
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE



RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

# SOMETHING WRONG WITH THIS PUBLICATION?



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

PAGE NO

PARA-GRAPH

FIGURE NO

TABLE NO

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

**DA** FORM **2028-2**  
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.  
DRSTS-M Overprint 2, 1 Nov 80.

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

1 Nov 80

FILL IN YOUR  
UNITS ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

---

---

OFFICIAL BUSINESS

COMMANDER  
U.S. ARMY AVIATION AND TROOP COMMAND  
ATTN: AMSAT-I-MP  
4300 GOODFELLOW BOULEVARD  
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



# SOMETHING WRONG WITH THIS PUBLICATION?

THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PARA-GRAPH	FIGURE NO	TABLE NO
---------	------------	-----------	----------

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2  
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.  
DRSTS-M Overprint 2, 1 Nov 80.

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNITS ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

---

---

OFFICIAL BUSINESS

COMMANDER  
U.S. ARMY AVIATION AND TROOP COMMAND  
ATTN: AMSAT-I-MP  
4300 GOODFELLOW BOULEVARD  
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

# The Metric System and Equivalents

## Linear Measure

1 centimeter = 10 millimeters = .39 inch  
 1 decimeter = 10 centimeters = 3.94 inches  
 1 meter = 10 decimeters = 39.37 inches  
 1 dekameter = 10 meters = 32.8 feet  
 1 hectometer = 10 dekameters = 328.08 feet  
 1 kilometer = 10 hectometers = 3,280.8 feet

## Weights

1 centigram = 10 milligrams = .15 grain  
 1 decigram = 10 centigrams = 1.54 grains  
 1 gram = 10 decigrams = .035 ounce  
 1 dekagram = 10 grams = .35 ounce  
 1 hectogram = 10 dekagrams = 3.52 ounces  
 1 kilogram = 10 hectograms = 2.2 pounds  
 1 quintal = 100 kilograms = 220.46 pounds  
 1 metric ton = 10 quintals = 1.1 short tons

## Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce  
 1 deciliter = 10 centiliters = 3.38 fl. ounces  
 1 liter = 10 deciliters = 33.81 fl. ounces  
 1 dekaliter = 10 liters = 2.64 gallons  
 1 hectoliter = 10 dekaliters = 26.42 gallons  
 1 kiloliter = 10 hectoliters = 264.18 gallons

## Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch  
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches  
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet  
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet  
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres  
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

## Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch  
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches  
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

## Approximate Conversion Factors

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	2.540	ounce-inches	newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29.573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	newton-meters	1.356	metric tons	short tons	1.102
pound-inches	newton-meters	.11296			

## Temperature (Exact)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
----	------------------------	----------------------------	---------------------	----

