


**U.S. ARMY TM 5-4320-304-14
U.S. MARINE CORPS TM 08922A-14/1**

TECHNICAL MANUAL

OPERATOR, UNIT, INTERMEDIATE DIRECT SUPPORT AND
INTERMEDIATE GENERAL SUPPORT MAINTENANCE MANUAL



**PUMP UNIT, CENTRIFUGAL,
SELF-PRIMING, 125 GPM,
CLASS 3, DIESEL DRIVEN
NSN 4320-01-190-0417**

Approved for public release;
distribution is unlimited

INTRODUCTION	1-1
OPERATING INSTRUCTIONS	2-1
OPERATOR'S MAINTENANCE INSTRUCTIONS	3-1
UNIT MAINTENANCE INSTRUCTIONS	4-1
INTERMEDIATE DIRECT SUPPORT MAINTENANCE INSTRUCTIONS	5-1
INTERMEDIATE GENERAL SUPPORT MAINTENANCE INSTRUCTIONS	6-1
MAINTENANCE ALLOCATION CHART	B-1
TORQUE LIMITS	F-1
GLOSSARY	
ALPHABETICAL INDEX	

**HEADQUARTERS, DEPARTMENT OF THE ARMY
AND HEADQUARTERS, U.S. MARINE CORPS**

16 SEPTEMBER 1987

C1

CHANGE

HEADQUARTERS,
DEPARTMENTS OF THE ARMY AND NAVY
AND HEADQUARTERS, U.S. MARINE CORPS
WASHINGTON, D. C., 5 March 1991

NO. 1

Operator's, Unit, Intermediate Direct Support
and Intermediate General Support Maintenance Manual
for

PUMP UNIT, CENTRIFUGAL, SELF-PRIMING, 125 GPM
CLASS 3, DIESEL-DRIVEN
NSN 4320-01-190-0417

Approved for public release; distribution is unlimited

TM 5-4320-304-14/TM 08922A-14/1, 16 September 1987, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

3-1 and 3-2

3-1 and 3-2

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretaries of the Army and Navy, including the Marine Corps:

CARL E. VUONO

*General, United States Army
Chief of Staff*

Official:

THOMAS F. SIKORA

*Brigadier General, United States Army
The Adjutant General*

DAVID E. BUTTORFF

*Rear Admiral, CEC, US Navy
Commander
Navy Facilities Engineering Command*

H.E. REESE

*Executive Director
Marine Corps Research, Development and
Acquisition Command*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25E, (qty rqr block no. 2455)

WARNING

SERIOUS INJURY

may result if the engine is not turned off during service or maintenance.

DEATH OR SERIOUS INJURY

to personnel or damage to equipment could occur if engine lifting strap is used to lift the centrifugal pump unit. The lifting strap shall be used to lift only the engine.

DEATH OR SERIOUS INJURY

could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

SEVERE BURNS

Muffler and related components get hot enough during pump operation to cause severe burns. Avoid contact with muffler and related components during checks described in this text.

CARBON MONOXIDE (EXHAUST GAS) CAN KILL YOU

Exposure to exhaust gases produces symptoms of headache, dizziness, loss of muscular control, drowsiness, or coma. Brain damage or death can result from severe exposure.

Fumes from engines become concentrated with poor ventilation. Operate engine in a ventilated area only.

While running engine, be alert for fumes. Keep area ventilated. If someone is overcome, expose to fresh air; keep warm and still; give artificial respiration if needed. Seek medical attention. Administer oxygen, if available.

GOOD VENTILATION IS THE BEST DEFENSE AGAINST EXHAUST POISONING.

SERIOUS INJURY

Before starting the engine and after making repairs or adjustments on the fuel system, a 17 mm wrench must be available to allow rapid removal of the steel fuel line at the injection pump in case of a runaway condition. Failure to heed this warning can result in injury to personnel and equipment damage.

WARNING

DEATH OR SERIOUS INJURY

could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

DEATH OR SERIOUS INJURY

could occur if unauthorized or unnecessary personnel are in the hoisting area. Permit only personnel actually engaged in the hoisting operation to be near the unit and hoisting equipment. All instructions for the hoisting operations must come from one authorized person.

DEATH OR SERIOUS INJURY

to personnel or damage to equipment could occur from improper hoisting. Hoist the load slowly to avoid tearing out lifting strap, slipping slings, or load shift. Do not jerk the load or swing it from side-to-side when hoisting. This places additional stress on hoisting components which can cause failure and loss of load. Be sure hoisting equipment is on solid footing and is suitable for the size of the load. Watch boom angle and overhead clearance when hoisting.

HEALTH AND SAFETY HAZARD

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138° F (38° to 59°C).

SERIOUS INJURY

could result from injector fuel spray. Keep hands away from fuel spray.

SEVERE BURNS

could result from handling heated parts. Use proper equipment to handle heated parts.

LIVE STEAM

used for cleaning shall not exceed 100 psi (6.9 bar). Use goggles or face shield for eye protection. Do not direct live steam against skin.

TECHNICAL MANUAL

TM 5-4320-304-14
 TM 08922A-14/1

HEADQUARTERS
 DEPARTMENT OF THE ARMY AND
 HEADQUARTERS, U. S. MARINE CORPS
 WASHINGTON, D. C., 16 September 1987

**Operator's, Unit, Intermediate Direct Support
 and Intermediate General Support Maintenance Manual**

for

PUMP UNIT, CENTRIFUGAL, SELF-PRIMING, 125 GPM,
 CLASS 3, DIESEL-DRIVEN
 NSN 4320-01-190-0417

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. A reply will be furnished directly to you. USMC users will submit Form NAVMC 10772 to CG MCLB (Code 850), Albany, GA 31704-5000.

Approved for public release; distribution is unlimited.

	Page
CHAPTER 1	1-1
INTRODUCTION	
Section I	1-1
Section II	1-2
Section III	1-6
CHAPTER 2	2-1
OPERATING INSTRUCTIONS	
Section I	2-1
Section II	2-3
Section III	2-24
Section IV	2-31
CHAPTER 3	3-1
OPERATOR MAINTENANCE INSTRUCTIONS	
Section I	3-1
Section II	3-2
Section III	3-7
CHAPTER 4	4-1
UNIT MAINTENANCE INSTRUCTIONS	
Section I	4-1
Section II	4-1
Section III	4-5
Section IV	4-8
Section V	4-13
Section VI	4-42

	Page
CHAPTER 5	5-1
INTERMEDIATE DIRECT SUPPORT MAINTENANCE INSTRUCTIONS	5-1
Section I Troubleshooting	5-1
Section II Maintenance Procedures	5-3
CHAPTER 6	6-1
INTERMEDIATE GENERAL SUPPORT MAINTENANCE INSTRUCTIONS	6-1
Section I Troubleshooting	6-1
Section II Maintenance Procedures	6-1
APPENDIX A.	A-1
REFERENCES	A-1
APPENDIX B.	B-1
MAINTENANCE ALLOCATION CHART	B-1
APPENDIX C.	C-1
COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LIST	C-1
APPENDIX D.	D-1
ADDITIONAL AUTHORIZATION LIST	D-1
APPENDIX E.	E-1
EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST	E-1
APPENDIX F.	F-1
TORQUE LIMITS	F-1
GLOSSARY	Glossary 1
ALPHABETICAL INDEX	Index 1

CHAPTER 1 INTRODUCTION

Section I. GENERAL INFORMATION

1-1. SCOPE

Type of Manual: Operator's, Unit, Intermediate Direct Support and Intermediate General Support Maintenance

Model Number and Equipment Name: A52109H Pump Unit, Centrifugal, Self-Priming, 125 GPM, Class 3, Diesel-Driven

Purpose of Equipment: Pumps Water

1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, The Army Maintenance Management System (TAMMS), USMC forms and records will be maintained in accordance with TM 4700-15/1.

1-3. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR'S)

If your centrifugal pump unit needs improvement, let us know. Send us an EIR/PIP. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at U.S. Army Troop Support Command, ATTN: AMSTR-QX, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. We'll send you a reply. USMC personnel are encouraged to submit PIP MCL 1650.17.

1-4. LIMITED WARRANTY

a. The centrifugal pump units are warranted by Peabody Barnes, Inc. against defective workmanship and materials for 9 months after date of installation or 36 months from the date of manufacture, whichever date occurs first. The installation date may be found in block 23, DA form 2408-9. The date manufactured appears on the identification plate.

b. Report all defects in material or workmanship to your supervisor who will take appropriate action through your organizational maintenance shop.

c. Peabody Barnes limits its obligation under this warranty to furnishing or replacing any product found to be defective as a result of workmanship or materials. They reserve the right to have the defective product returned at the expense of the user in order to establish the claim. If the responsibility for the failure is that of Peabody Barnes, they will absorb the transportation charges. The costs of labor, such as for removal and reinstallation of the product, are not covered under this warranty.

d. Peabody Barnes does not guarantee to maintain this product in order when its capacity is too small for the requirements, or where the system is subject to extraordinary use.

e. Peabody Barnes assumes no liability for incidental and consequential damages which may result from the use or misuse of its products. Some states do not allow the exclusion or limitation of incidental or consequential damages, however, so this limitation or exclusion may not apply.

1-4. LIMITED WARRANTY (Continued)

f. This warranty provides specific legal rights, and you may also have other rights which vary from state to state.

1-5. NOMENCLATURE CROSS-REFERENCE

For precise identification, simplified nomenclature has been established for clarity and is shown in the nomenclature cross-reference list.

NOMENCLATURE CROSS-REFERENCE LIST

This listing includes nomenclature cross-references used in this manual.

<u>Common Name</u>	<u>Official Nomenclature</u>
Centrifugal Pump Unit	Pump Unit, Centrifugal, Self-Priming, 125 GPM, Class 3, Diesel-Driven
Engine	Diesel Engine
Pump	Centrifugal Pump

1-6. ABBREVIATIONS

Abbreviations used in the manual are in accordance with requirements of MIL-STD-12.

Section II. EQUIPMENT DESCRIPTION

1-7. PURPOSE OF CENTRIFUGAL PUMP UNIT

General purpose water pumping applications.

1-8. CHARACTERISTICS

- Variable speed operation
- Frame-mounted
- Self-priming

1-9. CAPABILITIES AND FEATURES

- Pumps at a rate of 125 gpm
- Integral check valve retains fluid in the pump body when the pump is shut down

1-9. CAPABILITIES AND FEATURES (Continued)

- Hand crank start
- Variable speed governor
- ◆ Throttle control
- ◆ Dry-type air cleaner and rain hood
- Vertical mount muffler with protective screen

1-10. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

ENGINE (1). Power source.

MUFFLER (2). Mounts vertically on engine.

PROTECTIVE SCREEN (3). Metal safety cover for muffler.

AIR CLEANER (4). Dry-type, mounts on engine.

FUEL TANK ASSEMBLY (5). Mounts on engine.

CHECK VALVE ASSEMBLY (6). Mounts to pump suction (inlet) port.

PUMP (7). Mounts to engine.

FUEL FILTER (8). Filters fuel to engine.

INJECTION PUMP (9). Pumps fuel to injection nozzle.

FRAME (10). Supports engine and pump.

FUEL LIFT PUMP (11). Pumps fuel from the fuel tank to the injection pump.

OIL DIPSTICK (12). Measures engine oil level.

OIL FILLER CAP (13). Provides access to engine crankcase.

THROTTLE CONTROL HAND LEVER (14). Controls engine speed.

EXTRA FUEL BUTTON (15). Provides more fuel to engine during cold starting.


GOVERNOR (16). Maintains engine speed regardless of load.

SUCTION (INTAKE) COUPLING (17). Fuel inlet to pump.

DISCHARGE COUPLING (18). Fuel outlet from pump.

RESTRICTION INDICATOR (19). Shows when air cleaner is restricted and needs cleaning.

PRIMING PORT (20). Provides access to pump volute for priming.



1-11. DIFFERENCES BETWEEN MODELS

This technical manual covers only Centrifugal Pump Unit, Peabody Barnes Model A5210914H. No known differences exist for this model number.

1-12. EQUIPMENT DATA

a. Pump.

Manufacturer	Peabody Barnes, Inc.
Part number	70895SA
Type	Self-priming centrifugal
Service	Water
Duty cycle	Continuous
Rated output	125 gpm at 50 feet total head
Suction (intake) port	2-inch NPT
Discharge port	2-inch NPT
Priming port	2-inch NPT (bushed to 1-1/2-inch NPT)
Priming method	Self-priming system
Drain port	1/2-inch NPT (bushed to 3/8-inch NPT)
Rotation	counterclockwise (facing pump end)

b. Engine.

Manufacturer	Hatz Diesel
Model	E673LHK-241
Horsepower	6 hp at 3600 rpm
Type	Four-stroke air-cooled diesel
Number of cylinders	1
Bore	2.8740 in. (73.0 mm)
Stroke	2.6378 in. (67.0 mm)
Compression ratio (nominal)	19 to 1
Total displacement	17.09 cu in. (280 cm ³)
Direction of rotation (facing throttle control)	Clockwise
Number of main bearings	2

c. Engine accessories.

Air cleaner	
Manufacturer	Air - Maze
Part number	204-302
Type	Dry
Filter number	1DM-007


d. Capacities.

Fuel tank	1.04 gal (4.0 liters)
Engine crankcase	1.1 qt (1 liter)

e. Dimensions and weight.

Overall width	19 in. (0.48 meter)
Overall length	22.0 in. (0.559 meter)
Overall height	26.0 in. (0.660 meter)
Gross weight	175 lb (80 kg)
Shipping volume	6.3 cu ft (0.18 m ³)

Section III. TECHNICAL PRINCIPLES OF OPERATION



1-13. CENTRIFUGAL PUMP UNIT

ENGINE - bolted to frame. Provides the power necessary to drive the pump. Includes:

LUBRICATION SYSTEM - pressure lubricates the entire drive and governor mechanisms.

COOLING SYSTEM - includes a blower ring, mounted to the flywheel, which blows cool air through crankcase housing ports onto the cylinder.

FUEL SYSTEM - includes a fuel lift pump, fuel injection pump, venting pipe, fuel tank, filter, and fuel pressure pipe. The fuel lift pump pumps fuel from the fuel tank, through its filter, to the fuel injection pump, then to the injector through the fuel pressure pipe.

EXHAUST SYSTEM - includes a muffler and protective screen. The exhaust system transfers exhaust gases from the engine to the muffler. The muffler quiets the sound and reduces the temperature of the exhaust.

1-13. CENTRIFUGAL PUMP UNIT (Continued)

PUMP - bolted to the frame assembly. Uses power from the engine to pump water from the suction (intake) port to the discharge port. Includes a volute, impeller, check valve, and pump case with suction (intake) and discharge ports. The volute houses the impeller which draws water in through the suction (intake) port and forces it out of the pump through the discharge port. The check valve prevents discharged water from running back through the suction (intake) port.

FRAME - provides a movable mounting platform for the engine and pump assemblies.

CHAPTER 2 OPERATING INSTRUCTIONS

Section I. DESCRIPTION AND USE OF OPERATOR'S CONTROLS AND INDICATORS

WARNING

Personal injury may result if the engine is not turned off during service or maintenance.




Table 2-1. Operator's Controls and Indicators

Key	Control or Indicator	Function
1	Restriction indicator	Indicates blockage of air filter. A red band appears in window to indicate the need for cleaning or replacement. Indicator is threaded into air cleaner adapter, and is actuated by high negative pressure. Indicator can be reset.
2	Throttle control hand lever	Controls engine speed. With the hand lever in START position, the engine is at highest operating speed. By moving the lever between START and STOP, the desired engine speed can be obtained.




Table 2-1. Operator's Controls and Indicators - Continued

Key	Control or Indicator	Function
3	Fuel primer lever	Mechanically connected to fuel lift pump. Used to prime engine by forcing fuel from fuel tank into fuel system.
4	Extra fuel button	Provides more fuel to engine during starting. Pulling button out allows more fuel to engine. Button returns to normal position when engine reaches operating speed.
5	Decompression lever	Controls engine compression. Lever is placed in de-compression position during engine starting and returns to compression when engine reaches operating speed.

Section II. OPERATOR'S PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

2-1. GENERAL

a. *Before you operate.* Always keep in mind the CAUTIONS and WARNINGS. Perform your before (B) PMCS.

b. *While you operate.* Always keep in mind the CAUTIONS and WARNINGS. Perform your during (D) PMCS.

c. *After you operate.* Be sure to perform your after (A) PMCS.

d. *If your equipment fails to operate.* Troubleshoot with proper equipment. Report any deficiencies using the proper forms; see DA PAM 738-750; USMC personnel refer to TM 4700-15/1 for proper forms and record procedures.

2-2. PMCS PROCEDURES

a. Table 2-2 lists the preventive maintenance checks and services which shall be performed at specified intervals by the operator.

b. Item numbers are assigned to each check or service task. These numbers are to be used as a source of item numbers for the TM Number column on DA Form 2404, Equipment Inspection and Maintenance Worksheet, in recording results of PMCS.

c. The service intervals are divided into five categories; B - Before Operation; D - During Operation; A - After Operation; W - Weekly; and M - Monthly. A dot (•) is placed in the interval column for each check or service. If the same check or service is made in two or more intervals, a dot is placed in each applicable column.

d. The ITEM TO BE INSPECTED column lists the item to be checked or serviced. This column is combined with the PROCEDURE column.


e. The PROCEDURE column describes the procedure by which the check or service is to be performed. Illustrations are included to assist in locating that part of the equipment requiring the check or service.

f. The Equipment is Not Ready/Available If: column contains the basis for classifying the equipment as not ready/available because it is unable to perform its primary mission. An entry in this column will:

- (1) Identify conditions that make the equipment not ready/available for readiness reporting purposes.
- (2) Deny use of the equipment until corrective maintenance has been performed.

2-2. PMCS PROCEDURES (Continued)

g. The designations left, right, front, and rear as used in the preventive maintenance checks and services (PMCS) indicate the side or end of the centrifugal pump as viewed when facing the throttle control.



h. Leakage definitions for PMCS shall be classified as follows:

Class I Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

Class II Leakage of fluid great enough to form drops but not enough to cause drops to drip from item being checked/inspected.

Class III Leakage of fluid great enough to form drops that fall from the item being checked/inspected.

CAUTION

Equipment operation is allowable with minor leakages (Class I or II). Of course, you must consider the fluid capacity in the item/system being checked/inspected. When in doubt, notify your supervisor.

When operating with Class I or Class II leaks, continue to check fluid levels as required in your PMCS.

Class III leaks should be reported to your supervisor or organizational maintenance.

Table 2-2. Operator's Preventive Maintenance Checks and Services

NOTE

If the equipment must be kept in continuous operation, check and service only those items that can be checked and serviced without disturbing operation. Make the complete checks and services when the equipment can be shut down.

Perform weekly as well as before operation PMCS if:

- (1) You are the assigned operator and have not operated the item since the last weekly.
- (2) You are operating the item for the first time.

Within designated interval, these checks are to be performed in the order listed.

B - Before Operation
 D - During Operation

A - After Operation
 W - Weekly

M - Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
1					•	<p><i>Frame Assembly and Warning Plates.</i></p> <p>Check attaching hardware used to mount components of centrifugal pump unit. Attaching hardware shall be tight and free of corrosion and damage. Components of pump attached directly to frame (1) are:</p> <p style="margin-left: 40px;">Warning plates (2) Engine brackets (3) Identification plate (4)</p>	Cracks are detected, or engine is loose.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
1						<p><i>Frame Assembly and Warning Plates - Continued.</i></p> <ul style="list-style-type: none"> • Visually inspect all frame welds for cracks. Inspect only those welds that can be seen without dis-assembly. • Check that warning plates (2), identification plate (4), and throttle plate (5) can be read. • Check visible areas of rails (6 and 7) for corrosion and damage. • Check shock mounts (8) for splitting. • Check that cranking handle (9) is securely attached to the frame. Check cranking handle (9) for corrosion or damage. • Check for indications of corrosion in areas between all mated parts. • Check condition of paint. Paint shall be in good condition with no bare metal or corrosion. 	





Table 2-2. Operator's Preventive Maintenance Checks and Services - Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
2						<p><i>Lifting Strap (1).</i></p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px 0;"> <p>WARNING</p> </div> <p>Death or serious injury to personnel or damage to equipment could occur if engine lifting strap is used to lift the centrifugal pump unit. The lifting strap shall be used to lift only the engine.</p> <ul style="list-style-type: none"> • Check for cracks in base metal and/or welds. • Check eye (2) for wear and cracks. • Check for corrosion, especially at mating areas. • Check condition of paint. Paint shall be in good condition with no bare metal or corrosion. 	

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
3						<p><i>Oil Level.</i></p> <p>With engine level, remove oil dipstick (1). Wipe with lintless cloth.</p> <p>Insert oil dipstick all, the way into engine, then withdraw. Engine oil should coat oil dipstick to top mark.</p> <p>If oil coating is below top mark, remove cap (2) and add oil to bring level up to top mark. Again check oil level. Be sure oil coats dipstick to top mark.</p> <p>Check that cap (2) is tightly closed.</p> 	Oil level is low or Class III oil leak present.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M - Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available if:
	B	D	A	w	M		
4						<p><i>Timing Cover and Gear Housing.</i></p> <ul style="list-style-type: none"> • Check for oil leak at joint between timing cover (1) and crankcase (2). • Check for grease leak at joint between timing cover (1) and gear housing (3).  <ul style="list-style-type: none"> • Check condition of paint. Paint shall be in good condition with no bare metal or corrosion. 	Class III oil leakage is present.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
5		•				<p><i>Breather Pipe.</i></p> <ul style="list-style-type: none"> • Check for damaged or restricted breather pipe (1). Be sure bottom of breather pipe is not clogged. • Check that pipe clip (2) is tight. 	

Table 2-2. Operator's Preventive Maintenance Checks and services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
6	•		•			<p><i>Air Filter Assembly.</i></p> <p>Check for red band in window of restriction indicator (1).</p>  <p>Check rain hood (2) for damage that could prevent the replacement of air filter, allow dirt to enter air flow after the air filter, cause restriction indicator (1) to provide inaccurate readings, or obstruct air flow to the engine.</p>	<p>Dirt in air filter blocks air flow enough to cause red band to appear in window of restriction indicator.</p> <p>Damage or blockage prevents air flow to engine and trips restriction indicator.</p>

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D - During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
7						<p><i>Fuel System.</i></p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px 0;">WARNING</div> <p>Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.</p> <p>Check for leaks in fuel pressure pipe (1) and in fittings (2 and 3) at injector and at injection pump.</p> 	Leakage is present.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A - After Operation
 W - Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
7	•	•	•			<p><i>Fuel System - Continued.</i></p> <p>Check for fuel leakage at fittings (1) securing hoses (2) to injection pump (3).</p> 	Injection pump hose connection leaks.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
7		•				<p><i>Fuel System - Continued.</i></p> <ul style="list-style-type: none"> • Check fuel hoses (1) for leaks at ring pieces (2) and banjo bolts (3). • Check for fuel leaks at mating parts of fuel lift pump (4). • Check for fuel leaks at fuel filter (5). 	Class III leakage is present or fire hazard exists.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M - Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
7						<p><i>Fuel System - Continued.</i></p> <ul style="list-style-type: none"> • Check fuel hoses (1) for leaks, cracks, holes, and abrasions, and for leaks at ring pieces (2) and banjo bolts (3). • Check for oil leak between fuel lift pump (4) and crankcase (6). • Check fuel lift pump (4) for cracks, and for loose nuts (7) securing pump to crankcase (6). <p>Check operation of fuel primer-lever (8) at next startup. Fuel primer lever shall operate without binding to make sure fuel system is properly primed.</p> 	Class III leakage is present or fire hazard exists.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M - Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available if:
	B	D	A	W	M		
7						<p><i>Fuel System - Continued.</i></p> <div style="text-align: center; border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>WARNING</p> </div> <p>Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. DO NOT SMOKE.</p> <p>Remove fuel tank cap (1). Check for adequate fuel level. Add fuel to fuel tank (2) as required.</p> 	Fuel cannot be supplied to engine.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
7						<p><i>Fuel System - Continued.</i></p> <ul style="list-style-type: none"> Visually check fuel tank (2) for physical damage that could cause leaks or contamination of fuel supply.  <ul style="list-style-type: none"> Check fuel tank for deterioration. Check condition of paint. Paint shall be in good condition. 	Fuel cannot be supplied to engine; Class III leakage is present.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B - Before Operation
 D - During Operation

A - After Operation
 W - Weekly

M - Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
7		•				<p><i>Fuel System - Continued.</i></p> <p>Check fuel hoses (1) for leaks at banjo bolt (2) and double ring piece (3).</p> 	Class III fuel leaks or fire hazard resulting from leakage present.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B - Before Operation
 D - During Operation

A - After Operation
 W - Weekly

M - Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
8						<p><i>Muffler and Protective Screen.</i></p> <div style="border: 1px solid black; padding: 5px; text-align: center; width: fit-content; margin: 10px auto;">WARNING</div> <p>Muffler and related components get hot enough during pump operation to cause severe burns. Avoid contact with muffler and related components during checks described in this text.</p> <ul style="list-style-type: none"> • Visually check protective screen (1) on muffler (2) for excessive vibration during operation. • Listen for leaking exhaust gases. Locate leaking components. 	<p>Personnel hazard exists as a result of escaping exhaust gases or engine exhaust is restricted causing excessive back pressure.</p>

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B - Before Operation
 D - During Operation

A - After Operation
 W - Weekly

M - Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
8						<p><i>Muffler and Protective Screen - Continued.</i></p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px 0;"> <p>WARNING</p> </div> <p>Prior to touching portions of exhaust system, make sure that equipment has cooled.</p> <ul style="list-style-type: none"> • Check that protective screen (1) and heat shield (3) are mounted securely to engine. • Visually inspect muffler (2) for exhaust leaks caused by damage or corrosion. • Check condition of paint. Paint shall be in good condition with no bare metal or corrosion. 	<p>Personnel hazard exists as a result of escaping exhaust gases, or engine exhaust is restricted causing excessive back pressure.</p>

Table 2-2. Operator's Preventive Maintenance Checks and Services - Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
9					•	<p><i>Oil Drain Plug.</i></p> <p>Check oil drain plug (1) for oil leaks.</p> 	Class III oil leak is found.
10	•		•			<p><i>Pump Case Assembly, Volute, and Suction (Intake) Flange.</i></p> <p>Check that volute (1) is securely mounted to pump case (2) with studs (3) and nuts (4).</p> <p>Check that pipe plugs (5 and 6) are securely installed in pump case.</p> <p>Check that suction (intake) flange (7) and check valve (8) are securely mounted to pump case assembly with studs (9) and nuts (10). Check for damaged threads on studs (9).</p>	Pump case assembly and volute nuts or studs loose or broken. Foreign material, capable of damaging pump, found in suction (intake) flange or check valve.

Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W – Weekly

M – Monthly


Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
10	•		•			<p><i>Pump Case Assembly, Volute, and Suction (Intake) Flange - Continued.</i></p> <p>Visually check interior of suction (intake) flange (7) for foreign matter that could enter into pump case (2) and volute (1) during operation.</p>  <p>Listen for unusual noise during pump operation.</p>	<p>Unusual noise indicates damage to pump case assembly and volute.</p>


Table 2-2. Operator's Preventive Maintenance Checks and Services – Continued

B – Before Operation
 D – During Operation

A – After Operation
 W - Weekly

M – Monthly

Item No.	Interval					ITEM TO BE INSPECTED PROCEDURE	Equipment is Not Ready/ Available If:
	B	D	A	W	M		
10						<p><i>Pump Case Assembly, Volute, and Suction (Intake) Flange - Continued.</i></p> <ul style="list-style-type: none"> • Check volute (1), pump case assembly (2), and suction (intake) flange (3) for cracks and corrosion. Check studs (4 and 5) for damaged or corroded threads. Check condition of paint. Paint shall be in good condition with no bare metal or corrosion. 	<p>Pump case assembly components are cracked or damaged severely enough to prevent safe use. Inspection indicates pump may bind during operation.</p>



Section III. OPERATION UNDER USUAL CONDITIONS


2-3. ASSEMBLY AND PREPARATION FOR USE

a. The centrifugal pump unit comes fully assembled, ready for use after attaching suction (intake) and discharge hoses (not supplied with unit).

(1) Connect suction hose to hose adapter (1) on suction (intake) flange (2). Highest point in the suction hose should be at the pump.

(2) Connect discharge hose to hose adapter (3) in discharge port (4).

(3) Make sure that connections are tight.



b. Perform category B (before operation) PMCS contained in Table 2-2 or verify that category B PMCS was performed. Report any problems to organizational maintenance.

c. The following paragraphs contain instructions for starting, operating, and stopping the unit.

2-4. OPERATING PROCEDURE

WARNING

CARBON MONOXIDE (EXHAUST GAS) CAN KILL YOU

Exposure to exhaust gases produces symptoms of headache, dizziness, loss of muscular control, drowsiness, or coma. Brain damage or death can result from severe exposure.


Fumes from engines become concentrated with poor ventilation. Operate engine in a ventilated area only.

While running engine, be alert for fumes. Keep area ventilated. If someone is overcome, expose to fresh air; keep warm and still; give artificial respiration if needed. Seek medical attention. Administer oxygen, if available.

GOOD VENTILATION IS THE BEST DEFENSE AGAINST EXHAUST POISONING.

a. Preparation for Starting.

- (1) Move throttle control hand lever (1) to HIGH position on throttle plate (2).
- (2) Pull out extra fuel device button (3) until fully extended.
- (3) Turn decompression lever (4) clockwise to 12 o'clock position (position 2).



2-4. OPERATING PROCEDURE (Continued)

b. Priming Centrifugal Pump.

WARNING

CARBON MONOXIDE (EXHAUST GAS) CAN KILL YOU


Exposure to exhaust gases produces symptoms of headache, dizziness, loss of muscular control, drowsiness, or coma. Brain damage or death can result from severe exposure.

Fumes from engines become concentrated with poor ventilation. Operate engine in a ventilated area only.

While running engine, be alert for fumes. Keep area ventilated. If someone is overcome, expose to fresh air; keep warm and still; give artificial respiration if needed. Seek medical attention. Administer oxygen, if available.

GOOD VENTILATION IS THE BEST DEFENSE AGAINST EXHAUST POISONING.

- (1) Remove pipe plug (1) from priming port (2).
- (2) Pour water into priming port to fill volute (3).



2-4. OPERATING PROCEDURE (Continued)

CAUTION

If volute does not fill with liquid, check suction hose and suction hose connection at suction (intake) flange hose adapter for leaks. Be sure that suction hose end is completely immersed in water.

NOTE

As water fills volute, air is removed through discharge port. As the air is removed, water from the suction side of the pump is drawn into the volute and the pump will then draw on its own.

- (3) Install pipe plug (1) in priming port and tighten securely.


c. Starting.

CAUTION

If engine does not start on initial attempt, allow engine rotation to stop completely before again engaging crank handle.

Prime the pump. Rotation of pump impeller without liquid in volute can reduce service life of pump.

- (1) Engage crank handle (1) in gear housing (2).
- (2) With both hands, turn crank handle (1) clockwise with increasing speed.
- (3) When decompression lever (3) reaches 0 position, the highest possible speed must be obtained. Engine will start and go to maximum operating speed. Extra fuel device button (4) will return to normal position by itself.
- (4) Adjust throttle control hand lever (5) to desired speed.



2-4. OPERATING PROCEDURE (Continued)

d. *Stopping.*



CAUTION

Immediate shutdown of the engine without a 5-minute idle time may cause damage to engine. Do so only when made necessary by overriding system requirements or emergency conditions.

- (1) Slowly move throttle control hand lever toward LOW position to idle speed. Allow engine to idle for 5 minutes to allow engine operating temperature to stabilize.


NOTE

If centrifugal pump unit is to be reused in its present placement and alignment, be prepared to close suction and discharge valves on hoses attached to the pump. This will retain liquid in pump volute and reduce or eliminate priming requirements.

- (2) Move throttle control hand lever to extreme right (LOW) position.
- (3) Close any suction and discharge valves that are installed in hoses.

2-4. OPERATING PROCEDURE (Continued)

- (4) If pump is to be removed from system, remove pipe plug (1) and drain pump.
- (5) Remove suction hose from suction (intake) flange (2).
- (6) Remove discharge hose from discharge port (3).



2-5. IDENTIFICATION AND WARNING PLATES


The centrifugal pump has the following identification and instruction plates:

- a. *Identification plate.* Located on the frame assembly. Provides the pump identification number, serial number, dimensions, weight, and shipping information.


US			
MODEL		CONTR NR	
SER NR		CAPACITY	
REG NR	GVW	LB	LG IN
NSN	DATE MFD		HGT IN
ENG SER	SHIP WT	LB	W IN
WARRANTY	MO	MI	CU FT
DATE SHIPPED	DATE INSP	INSP STAMP	
BARNES PUMP			
MFR BY PEABODY BARNES INC MANSFIELD OHIO USA			

2-5. IDENTIFICATION AND WARNING PLATES (Continued)

b. *Throttle plate.* Located on top of gear housing. Indicates throttle lever position for high and low engine speed.



c. *Engine nameplate.* Located on the flywheel end, left side of the engine. Provides engine identification.



d. *Warning plates.* Located on both sides of the pump unit. Provide Information for the safety of personnel operating the centrifugal pump unit.



Section IV. OPERATION UNDER UNUSUAL CONDITIONS

2-6. OPERATION IN COLD

- a. Use proper engine oil for cold weather. See lubrication instructions in Chapter 3.

WARNING


Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

- b. Keep fuel tank full to prevent condensation. Condensation can freeze and clog lines, filters, and injectors.
- c. Cold weather starting can be improved by the addition of engine oil to the cold start assist.
- (1) With engine stopped, remove closing plug (1) from cold start assist (2).

CAUTION

Engine lockup could occur if oil is poured into center of cold start assist. Take care to fill cold start assist cup from the side.


- (2) Fill cold start assist cup with clean engine oil. To prevent engine lockup, carefully pour oil in the side of the cup.
- (3) Replace closing plug (1) into cold start assist (2) and press it in firmly.
- (4) Start engine immediately using instructions in paragraph 2-4.




2-7. OPERATION IN EXTREME HEAT

The engine of the centrifugal pump unit is air cooled. Heat can be removed from an engine in three ways: engine exhaust, engine oil, and the passage of air across and through cylinder cooling fins. Therefore, when operating in high ambient temperatures, observe the following:

- a. With engine stopped, inspect frequently to be sure that cylinder cooling fins are clean and free of dirt that inhibits cooling.
- b. With engine stopped, inspect frequently to be sure that blower ring is clean and free of dirt.
- c. With engine stopped, inspect frequently to be sure that engine oil is to top mark on dipstick (1). Add oil, if necessary, at oil filler cap (2) to bring level up to top mark.



- d. Check the air cleaner restriction indicator (1). If red band appears in window of restriction indicator, change the air filter in the air cleaner (2). Refer to paragraph 3-4.



2-8. OPERATION IN HIGH ALTITUDES

The operating efficiency of the engine diminishes at higher altitudes. Be sure that engine is operating at peak efficiency.

2-9. OPERATION IN SANDY OR DUSTY AREAS



CAUTION

Monitor air cleaner intake restriction indicator more closely in sandy or dusty locations. At first sign of restriction, change air filter.


- a. If red band appears in window of air cleaner restriction indicator and rain hood is not blocked and no damage to system components is found, replace air filter. Refer to paragraph 3-4.
- b. With engine stopped, inspect frequently to be sure that cylinder cooling fins are clean and free of dirt that inhibits cooling.
- c. With engine stopped, inspect frequently to be sure that blower ring is clean and free of dirt.
- d. With engine stopped, inspect frequently to be sure that engine oil is to top mark on dipstick. Add oil, if necessary, to bring level up to top mark.
- e. During fueling and PMCS, be sure that sand or dust is not allowed to enter fuel or lubrication system.
- f. If centrifugal pump unit is not in use and suction and/or discharge hoses are not installed, be sure that suction (intake) flange and discharge ports are covered.
- g. Be sure that frequency of PMCS is increased in accordance with local conditions and requirements.

2-10. OPERATION UNDER RAINY OR HUMID CONDITIONS

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper marked containers. **DO NOT SMOKE.**

Check that fuel tank cap (1) is tight. Fill fuel tank (2) immediately after every operating period to prevent condensation.



2-11. OPERATION IN SALT WATER AREAS

Salt water causes corrosion. Use fresh water to wash off any salt water that comes in contact with to equipment.

CHAPTER 3 OPERATOR MAINTENANCE INSTRUCTIONS


3-1. GENERAL.

Paint in accordance with MIL-T-704, Type A, color as specified (Appendix A).

Section I. LUBRICATION INSTRUCTIONS

3-2. LUBRICATION

a. With engine level, check oil level. Remove oil dipstick (1) and wipe with a lintless cloth. Insert oil dipstick all the way into engine. Withdraw dipstick. Engine oil should coat oil dipstick to top mark (2).




3-2. LUBRICATION (Continued)



Do not overfill. Engine damage could result. If overfilled, notify organizational maintenance.

b. If oil coating is below top mark (2), remove oil cap (3) and add oil of proper viscosity required by ambient temperature. See following chart.



Intervals of lubricating oil change	
first change (with new engine) after	further changes after every
25 h	150 h

c. Again check oil level to be sure oil coats dipstick (1) to top mark (2). Check that cap (3) is tightly closed.

Section II. TROUBLESHOOTING PROCEDURES

3-3. TROUBLESHOOTING

a. Table 3-1 lists common malfunctions which you may find during operation or maintenance of the centrifugal pump unit or its components. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

Table 3-1. Operator Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. ENGINE FAILS TO CRANK OR CRANKS AT LOW SPEED		Notify organizational maintenance.
2. ENGINE CRANKS BUT FAILS TO START		
		WARNING
		Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. DO NOT SMOKE.
Step 1.	Check for insufficient fuel supply.	Fill fuel tank.
Step 2.	Check starting procedures under prevailing conditions.	If starting procedures have been performed correctly, but engine still fails to start, notify organizational maintenance.
Step 3.	Check air cleaner restriction indicator.	If red band appears in window of restriction indicator, and rain hood is not blocked and no damage to system components is found, replace air filter (para 3-4).

Table 3-1. Operator Troubleshooting - Continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

3. UNEVEN RUNNING OR FREQUENT STALLING

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

CAUTION

A high temperature condition may cause abnormal engine operation.

- Step 1. Check for insufficient fuel supply.
Fill fuel tank.

4. LACK OF POWER

- Step 1. Check for low engine speed.
Adjust throttle lever to increase engine speed.

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

- Step 2. Check for insufficient fuel supply.
Fill fuel tank.

Table 3-1. Operator Troubleshooting-Continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
	Step 3. Check air cleaner restriction indicator.	If red band appears in window of restriction indicator, and rain hood is not blocked and no damage to system components is found, replace air filter (para 3-4).
	Step 4. Check for loose connections or a restricted or damaged line between fuel lift pump and tank, between fuel lift pump and injection pump, and between injection pump and injector.	Tighten loose connections. Report damaged lines to organizational maintenance.
	Step 5. Check for restrictions in suction or discharge hoses or hose end.	Clean away debris. If hoses are severely damaged or restricted, replace.

5. ENGINE STOPS RUNNING

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. DO NOT SMOKE.

Step 1. Check for Insufficient fuel supply.

Fill fuel tank.

Step 2. Check air cleaner restriction indicator for indication of restrictions or excessive dirt in air filter.

If red band appears in window of restriction indicator, and rain hood is not blocked and no damage to system components is found, replace air filter (para 3-4).

Table 3-1. Operator Troubleshooting - Continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
--------------------	---------------------------	--------------------------

6. EXCESSIVE LUBRICATING OIL CONSUMPTION

Step 1. Check for leakage at oil drain plug or oil filler cap.

If drain plug or oil filler cap is leaking, try to tighten. If leak continues, notify organizational maintenance.

Step 2. Check for leakage at joint between timing cover and crankcase.

Notify organizational maintenance.

Step 3. Check for leakage around cylinder head.

Notify organizational maintenance.

Step 4. Check for smoky exhaust. If exhaust discharge contains oil, excessive oil is being burned in engine cylinder or around cylinder valve stems.

Notify organizational maintenance.

7. PUMP FAILS TO PRIME

Step 1. Check for low engine speed.

Adjust throttle lever to increase engine speed.

Step 2. Check for air-locked pump.

Vent the pump volute and fill with water (para 2-4.b.).

Step 3. Check for leaks at the suction (intake) flange and gasket.

Tighten nuts on suction (intake) flange at pump case.

8. NOISY PUMP OPERATION

Notify organizational maintenance.

9. LOW DISCHARGE PRESSURE

Step 1. Check for low engine speed.

Adjust throttle lever to increase engine speed.

Step 2. Check suction (intake) line for leaking connections.

Tighten loose connections.

Section III. MAINTENANCE PROCEDURES

3-4. CLEANING OR REPLACING AIR FILTER

REMOVAL:

- 1 Remove wing nut (1) and sealing washer (2).
- 2 Remove air filter top (3) and rain hood (4).
- 3 Wipe rain hood and top with a clean, dry cloth.
- 4 Remove air filter (5).

CLEANING:

WARNING

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

CAUTION


Air pressure of greater than 30 psi (2.06 bar) will damage the air filter.

The use of cleaning fluids will damage the air filter.

- 1 Clean air filter (5) with air and/or warm water [70° to 100°F (21° to 38°C)]; or with a warm water/mild detergent solution.
- 2 Rinse and allow filter to dry.
- 3 If air filter cannot be cleaned, replace it.

INSTALLATION:

- 1 Install air filter (5) into rain hood (4) and place top (3) over air filter.
- 2 Aline hole in rain hood and top with threaded rod on base connector (6).




3-4. CLEANING OR REPLACING AIR FILTER (Continued)

CAUTION

Overtightening the wing nut will deform the element.

- 3 Install sealing washer (2) and wing nut (1).
- 4 Hand tighten wing nut as necessary to make sure the air filter assembly is secure and vibration free.
- 5 Reset restriction indicator (1).



CHAPTER 4 UNIT MAINTENANCE INSTRUCTIONS

Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

4-1. COMMON TOOLS AND EQUIPMENT

For authorized common tools (standard and metric) and equipment, refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

4-2. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

The special tools required to service the centrifugal pump unit are listed and illustrated in TM 5-4320-304-24P, Repair Parts and Special Tools List (RPSTL). USMC personnel refer to SL-4 08922A.

4-3. REPAIR PARTS

Repair parts are listed and illustrated in TM 5-4320-304-24P and SL-4 08922A

Section II. SERVICE UPON RECEIPT OF EQUIPMENT

4-4. UNLOADING EQUIPMENT

- a. Before attempting to unload the centrifugal pump unit, make sure that the unloading facility is capable of handling 175 pounds (80 kilograms).
- b. Remove shipping tiedowns.

WARNING

Death or serious injury could occur if unauthorized or unnecessary personnel are in the hoisting area. Permit only personnel actually engaged in the hoisting operation to be near the unit and hoisting equipment. All instructions for the hoisting operations must come from one authorized person.

Injury to personnel or damage to equipment could occur from improper hoisting. Hoist the load slowly to avoid slipping slings or load shift. Do not jerk the load or swing it from side-to-side when hoisting. This places additional stress on hoisting components which can cause failure and loss of load. Be sure hoisting equipment is on solid footing and is suitable for the size of the load. Watch boom angle and overhead clearance when hoisting.

Death or serious injury to personnel or damage to equipment could occur if engine lifting strap is used to lift the centrifugal pump unit. The lifting strap shall be used to lift only the engine.


- c. Unload the centrifugal pump unit with a lifting device secured to the frame assembly.

4-5. INSPECTING EQUIPMENT

- a. Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on (A) DD Form 6, Packaging Improvement Report, or (MC) MCO 4430.3.
- b. Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with the instructions of DA PAM 738-750.
- c. Check to see whether the equipment has been modified.

4-6. SETUP INSTRUCTIONS

- a. Locate unit as close as possible to the water to be pumped. Keep the suction hose and the amount of lift as short as possible.
- b. The operating site should be as level as possible (no more than 20 degrees slope) or the engine lubrication system may not work properly.
- c. Keep the suction and discharge hoses as short and straight as possible.
- d. Allow adequate space to permit support of the suction and discharge hoses where they enter the pump.
- e. Connect the suction hose to hose adapter on suction (intake) flange (1). Highest point in the suction hose should be at the pump.
- f. Connect discharge hose to hose adapter in discharge port (2).
- g. Make sure that connections are tight.




4-7. PRELIMINARY SERVICING AND ADJUSTMENT OF EQUIPMENT SETUP

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

- a. Be sure fuel tank has sufficient fuel.
- b. With engine level, check oil level. Remove oil dipstick (1) and wipe with a lintless cloth. Insert oil dipstick all the way into engine. Withdraw dipstick. Engine oil should coat oil dipstick to top mark (2).




4-7. PRELIMINARY SERVICING AND ADJUSTMENT OF EQUIPMENT SETUP (Continued)




Do not overfill. Engine damage could result.

If oil coating is below top mark (2), remove oil cap (3) and add oil of proper viscosity required by ambient temperature. See following chart.



Again check oil level to be sure oil coats dipstick (1) to top mark (2). Check that cap is tightly closed.

If oil coating extends above top mark, loosen drain plug (1), drain enough oil to lower oil level to top mark on dipstick, then tighten drain plug securely.



c. Refer to table 4-1 and perform preventive maintenance checks and services.

Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES

4-8. PREVENTIVE MAINTENANCE CHECKS AND SERVICES

Table 4-1 lists preventive maintenance checks and services (PMCS) which shall be performed at specified intervals by organizational maintenance personnel. It expands upon the preventive maintenance services performed by operator maintenance and includes additional services which are allocated to organizational maintenance. The columns, codes, and location designations used in the table are as follows:

a. Item numbers are assigned to each check or service task. The numbers are to be used as a source of item numbers for the TM Number column on (A) DA Form 2404, Equipment Inspection and Maintenance Worksheet, in recording results of PMCS. USMC personnel maintain forms and records described by TM 4700-15/1.

b. The service intervals are divided into four categories: W - Weekly; M - Monthly; Q - Quarterly; S - Semiannually. A dot (•) is placed in the interval column for each check or service. If the same check or service is made in two or more intervals, a dot is placed in each applicable column.

c. The Item To Be Inspected column lists the item to be checked or serviced.

d. The Procedures column describes the procedure by which the check or service is to be performed. Illustrations are included to assist in locating that part of the equipment requiring the check or service.

e. The designations left, right, front, and rear as used in PMCS indicate the side or end of the centrifugal pump as viewed when facing the throttle control.




Table 4-1. Organizational Preventive Maintenance Checks and Services

CAUTION

During PMCS it maybe necessary to run the engine. Since the pump is directly coupled to the engine, the pump will run when the engine runs. Running the pump for longer than a few seconds without liquid in the volute will damage the pump. When necessary to run the pump for longer than a few seconds, make sure that suction and discharge hoses are installed and a source of water is available. Prime pump, start engine to duplicate normal operation and prevent pump from overheating.

W-Weekly
 M-Monthly

Q-Quarterly
 S-Semiannually


Item No.	Interval				Item To Be Inspected	Procedures	Equipment is Not Ready/ Available If:
	W	M	Q	S			
1				●	Fuel Lift Pump	<div style="border: 1px solid black; padding: 5px; text-align: center; margin-bottom: 10px;">WARNING</div> <p>Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.</p> <p>Check fuel lift pump (1) for leakage. Check operation of primer lever (2).</p> <div style="text-align: center; margin-top: 10px;">  </div>	Fuel pump leaks.

Table 4-1. Organizational Preventive Maintenance Checks and Services – Continued

Item No.	Interval				Item To Be Inspected	Procedures	Equipment is Not Ready/ Available If:
	W	M	Q	S			
2		•			Check Valve Assembly	<p>Inspect suction (intake) flange (1) for cracks, damaged threads, or studs. Check that nuts (2) are tight and free of corrosion.</p> <p>Inspect check valve assembly (3) for evidence of leakage or gasket (4) damage, and presence of outer check valve weight (5). Screw (6) should be tight. All components shall be free of corrosion. When in closed position, gasket shall appear to make an airtight seal on pump outlet. Gasket shall be free to open with pump flow.</p>	Check valve assembly is cracked or not airtight.

Section IV. TROUBLESHOOTING

4-9. TROUBLESHOOTING

a. Table 4-2 contains troubleshooting information for locating and correcting most of the operating troubles which are the responsibility of organizational maintenance. Each malfunction for an individual component, unit, or system is followed by a list of tests or inspections which will help you to determine probable causes and corrective actions to take. Perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Only those functions within the scope of organizational maintenance are listed. For troubleshooting procedures within the scope of operator maintenance, refer to table 3-1.

4-10. SYMPTOM INDEX

Refer to the Symptom Index below. Locate the malfunction which is the same, or most nearly the same, as the trouble you are having with the pump. The Symptom Index lists the first page of troubleshooting information for that malfunction. Follow the steps one by one, and perform the corrective actions listed.

Malfunction Number	Description	Page
1	Engine hard to crank	4-8
2	Engine cranks but fails to start	4-8
3	Engine runs unsteadily and power output is low	4-10
4	Dense smoke from exhaust after warmup	4-10
5	Engine overheats	4-11
6	Pump makes excessive noise	4-12
7	Pump output low	4-12

Table 4-2. Organizational Maintenance Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

1. ENGINE HARD TO CRANK

Step 1. Check for proper oil viscosity.

Refer to chart in paragraph 4-7.

2. ENGINE CRANKS BUT FAILS TO START

Step 1. Check that extra fuel button has been pulled out prior to starting.

Pull out extra fuel button and attempt to start engine (para 2-4.c.).




Table 4-2. Organizational Maintenance Troubleshooting - Continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
	Step 2. Check window of air cleaner restriction indicator for red band indicating blocked air cleaner.	If red band appears in window of air cleaner restriction indicator and rain hood is not blocked and no damage to system components is found, replace air filter (para 3-4).
	Step 3. Check for empty fuel tank.	WARNING
		Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. DO NOT SMOKE.
		If fuel tank is empty, fill with fuel.
	Step 4. Check non-return valve for proper function.	WARNING
		Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.
		a. Disconnect hose from double ring piece at fuel tank. Turn engine with crank handle.

Table 4-2. Organizational Maintenance Troubleshooting - Continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

- b. If fuel does not flow from hose, remove non-return valve. Check valve by shaking for free movement of internal valve ball.



- c. If necessary, clean with fuel. If unserviceable, replace non-return valve (para 4-17).

3. ENGINE RUNS UNSTEADILY AND POWER OUTPUT IS LOW

- Step 1. Check window of air cleaner restriction indicator for red band indicating blocked air cleaner.

If red band appears in window of air cleaner restriction indicator and rain hood is not blocked and no damage to system components is found, replace air filter (para 3-4).

- Step 2. See Malfunction 2, step 4.
 Step 3. Notify direct support maintenance.

4. DENSE SMOKE FROM EXHAUST AFTER WARMUP

- Step 1. Shut down engine. With engine level, check oil level (para 4-7.b.).
 Add oil if necessary.

- Step 2. Check window of air cleaner restriction indicator for red band indicating blocked air cleaner.

If red band appears in window of air cleaner restriction indicator and rain hood is not blocked and no damage to system components is found, replace air filter (para 3-4).

- Step 3. Notify direct support maintenance.

Table 4-2. Organizational Maintenance Troubleshooting - Continued



MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
5. ENGINE OVERHEATS		
Step 1.	Check cooling air ducting for damage and dirt.	a. Check cylinder cooling fins for damage or dirt. b. Check blower ring blades for damage or dirt. Remove accumulated dust and dirt with a stiff-bristled brush. Start engine after cleaning. Allow engine to run until all indications of moisture have evaporated.
Step 2.	Shut down engine. With engine level, check oil level (para 4-7.b.).	Add oil if necessary.
Step 3.	Check muffler for obstruction.	Remove obstruction.
		
MUFFLER		
Step 4.	Notify direct support maintenance.	

Table 4-2. Organizational Maintenance Troubleshooting - Continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
6. PUMP MAKES EXCESSIVE NOISE		
	Step 1. Check volute for foreign material.	
		With engine stopped and suction hose removed, inspect interior of suction (intake) flange for foreign material or obstruction.
		<div style="text-align: center;"><p>CAUTION</p><p>Excessive pump noise can indicate that pump is running dry. This condition can cause serious pump damage.</p></div>
	Step 2. Check that suction hose is immersed in water or properly connected to container from which water is being pumped. Water level in container shall be above suction hose connection.	
		Relocate suction hose connection below surface of water.
	Step 3. Check suction hoses, connections, or parting surface of suction flange for leaks. Check pipe plugs are not leaking.	
	Step 4. Check that pump has been properly primed.	
		If necessary, prime the pump (para 2-4.b.).
	Step 5. Inspect check valve assembly for proper operation. Perform the checks and services of table 4-1, item 2.	
		Replace check valve assembly (para 4-12).
	Step 6. Notify direct support maintenance.	
7. PUMP OUTPUT LOW		
	Step 1. Check that engine speed is properly adjusted.	
		Adjust throttle lever to increase engine speed (para 2-4.d.).
	Step 2. See Malfunction 6, steps 1 thru 5.	

Section V. MAINTENANCE PROCEDURES

INDEX

	Para		Para
Adapter shaft	4-13	Fuel tank	4-19
Air cleaner	4-15	Impeller	4-13
Air filter assembly	4-15	Muffler	4-20
Check valve	4-12	Pump case assembly	4-14
Cold start assist	4-16	Restriction indicator	4-15
Cylinder head and valve assembly	4-22	Shaft seal	4-13
Fuel filter	4-17	Throttle control	4-21
Fuel lift pump	4-18	Volute	4-13
Fuel lines, hoses, and fittings	4-17	Wear plate	4-13

4-11. GENERAL INSTRUCTIONS

Maintenance instructions in this section will list resources required, personnel required, and equipment condition for the start of the procedure. Note the following:

- Resources required are not listed unless they apply to the procedure.
- Personnel required are listed only if the task requires more than one. If PERSONNEL is not listed, it means one person can do the task.
- The normal standard equipment condition to start a maintenance task is engine stopped. EQUIPMENT CONDITION is not listed unless some other condition is required.
- Refer to Appendix F to determine torque requirements when tightening threaded fasteners, unless a specific torque value is given in procedure. Standard torque values given in Appendix F are determined by thread size.

4-12. REPLACE/REPAIR CHECK VALVE ASSEMBLY

This task covers: a. Removal c. Repair e. Installation
 b. Disassembly d. Assembly


INITIAL SETUP

Tools

- (A) Tool kit, general mechanics automotive
- (USMC) Tool kit, general mechanics

Equipment Condition

Engine shut down, discharge hose removed, and water drained from pump via drain port at bottom of pump assembly.



REMOVAL:

- 1 Remove nuts (1).
- 2 Remove suction (intake) flange (2) and check valve assembly (3).
- 3 Remove check valve assembly (3) from suction (intake) flange (2).

DISASSEMBLY:

- 1 Remove screw (4) from check valve assembly (3).
- 2 Remove small weight (5), large weight (6), and gasket (7).

REPAIR:

- 1 Inspect nuts (1), flange (2), screw (4), small weight (5), large weight (6), and gasket (7) for wear, damage, rust, or corrosion.
- 2 Replace any worn or damaged parts.

ASSEMBLY:

- 1 Assemble large weight (6), gasket (7), and small weight (5),
- 2 Secure assembled parts with screw (4).

INSTALLATION:

- 1 Install check valve (3) on suction (intake) flange (2).
 - 2 Install check valve (3) and suction (intake) flange on studs (8).
 - 3 Secure with nuts (1).
-

4-13. REPLACE VOLUTE, IMPELLER, WEAR PLATE, SHAFT SEAL, AND ADAPTER SHAFT (Continued)

- 4 Unscrew impeller (9) counterclockwise and remove shims (10 and 11).
- 5 Remove screws (12). Remove wear plate (13) and packing (14). Discard packing.
- 6 Remove shaft seal (15) from pump case assembly (4). Discard shaft seal.
- 7 Remove adapter shaft (6) from pump case assembly (4). Remove key (16).

CLEANING:

WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138° F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

Clean volute (3), adapter shaft (6), impeller (9), and wear plate (13) with P-D-680 dry cleaning solvent and dry with compressed air.


INSPECTION:

- 1 Inspect volute (3), impeller (9), and wear plate (13) for excessive wear, rust, corrosion, or other damage. Replace any worn or damaged parts.
- 2 Inspect adapter shaft (6) for excessive wear, rust, corrosion, or other damage. Replace shaft if damaged in any way.

4-13. REPLACE VOLUTE, IMPELLER, WEAR PLATE, SHAFT SEAL, AND ADAPTER SHAFT (Continued)

INSTALLATION:

- 1 Install new shaft seal (15) on adapter shaft (6). Install key (16).
- 2 Install adapter shaft with shaft seal into pump case assembly (4).
- 3 Install new packing (14) in pump case assembly (4).
- 4 Install wear plate (13) and screws (12). Tighten screws securely.



NOTE

If the same impeller and wear plate are reassembled and no clearance change is indicated, make sure that the same thickness of shims is used.

- 5 If a new impeller and/or wear plate is to be installed, or if the impeller clearance is to be changed, determine the shim thickness required to obtain a clearance of 0.010 to 0.020 inch (0.254 to 0.508 mm) between the impeller and wear plate as follows:
 - a. Screw impeller (9) clockwise on shaft (6) without shims. Be sure that it is seated firmly against the shaft shoulder. Secure impeller with lock washer (8) and screw (7).
 - b. Measure from the face of the impeller (9) to the face of the wear plate (13) using a feeler gage.
 - c. Select shims (10 and 11) to equal the dimension obtained less 0.010 to 0.020 inch (0.254 to 0.508 mm) for clearance.
- 6 Install impeller (9) lock washer (8), and screw (7). Tighten screw securely.
- 7 Install new packing (5) on volute (3). Install volute on pump case assembly (4).
- 8 Install washers (2) and nuts (1). Tighten nuts securely.

4-14. REPLACE PUMP CASE ASSEMBLY

This task covers: a. Removal c. Inspection
 b. Cleaning d. Installation

INITIAL SETUP

Tools

- (A) Tool kit, general mechanics automotive
- (USMC) Tool kit, general mechanics

Equipment Condition

Para
4-13

Equipment Condition


Volute, impeller, wear plate, shaft seal, and adapter shaft removed.

Materials/Parts

Dry cleaning solvent (Item 10, Appendix E)

General Safety Instructions

Well-ventilated area required during cleaning.



REMOVAL:

Remove screws (1) securing pump case assembly (2).

4-14. REPLACE PUMP CASE ASSEMBLY (Continued)

CLEANING:

WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138°F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

Clean with solvent and dry with compressed air.

INSPECTION:

- 1 Inspect pump case assembly (2) for rust, corrosion, cracks, or other damage. Replace pump case assembly if damaged.
- 2 Inspect threaded holes for damage to threaded inserts (3, 4, and 5). If threads are damaged, notify direct support maintenance.

INSTALLATION:

Install screws (1) with insert in pump case assembly (2). Tighten evenly in an alternating pattern. Torque to 32 to 35 foot-pounds (4.43 to 4.84 m•kg).

4-15. REPLACE AIR FILTER ASSEMBLY

This task covers: a. Removal c. Repair e. Installation
 b. Disassembly d. Assembly f. Operational Check


INITIAL SETUP

Tools

- (A) Tool kit, general mechanics automotive
- (USMC) Tool kit, general mechanics

General Safety Instructions

Unit must be cool. Well-ventilated area required during operational check.



REMOVAL:

- 1 Unscrew restriction indicator (1) from nipple (2).
- 2 Unscrew air cleaner assembly (3) from engine.

DISASSEMBLY:

- 1 Unscrew street elbow (4) from air cleaner (5).
- 2 Remove wing nut (6) and sealing washer (7). Remove top (8) and air filter (9).
- 3 Separate base connector (10), gasket (11), and rain hood (12).

4-15. REPLACE AIR FILTER ASSEMBLY (Continued)

REPAIR:


Replace all damaged parts.

ASSEMBLY:

- 1 Place gasket (11) on rain hood (12). Insert base connector (10) into rain hood.
- 2 Insert air filter (9) into rain hood. Place top (8) over air filter.
- 3 Install sealing washer (7) and secure with wing nut (6).

INSTALLATION:

- 1 Install street elbow (4) on air cleaner (5).
- 2 Install restriction indicator (1).
- 2 Install restriction indicator (1).



4-15. REPLACE AIR FILTER ASSEMBLY (Continued)

OPERATIONAL CHECK:

WARNING

Muffler and related components get hot enough during pump operation to cause severe burns. Avoid contact with muffler and related components during checks described in this text.

Exposure to exhaust gases produces symptoms of headache, dizziness, loss of muscular control, drowsiness, or coma. Brain damage or death can result from severe exposure.

Fumes from engines become concentrated with poor ventilation. Operate engine in a ventilated area only.

While running engine, be alert for fumes. Keep area ventilated. If someone is overcome, expose to fresh air; keep warm and still; give artificial respiration if needed. Seek medical attention. Administer oxygen, if available.

GOOD VENTILATION IS THE BEST DEFENSE AGAINST EXHAUST POISONING.

- 1 Start engine and observe air cleaner assembly and restriction indicator for looseness, rattles, or leaks. Tighten.
 - 2 If red band is visible in window of restriction indicator, shut down engine.
 - 3 Recheck installation and air filter. Reset indicator.
 - 4 Restart engine. If red band is still visible, replace indicator.
 - 5 Restart engine and check indicator. If indicator still shows red band, refer to direct support.
-

4-17. REPLACE FUEL FILTER, FUEL PRESSURE LINE, HOSES, AND FITTINGS

This task covers: a. Removal c. Installation
 b. Inspection

INITIAL SETUP

Tools

(A) Tool kit, general mechanics automotive
(USMC) Tool kit, general mechanics

General Safety Instructions

Unit must be cool. Fuel tank must be empty.
Well-ventilated area required.

Materials/Parts

Diesel fuel oil (Item 2, Appendix E)

REMOVAL:


WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engine near open fuel containers. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

CAUTION


As each fuel hose, connection, or connection port is removed, be sure to tape over or plug each open connection to prevent contaminants from entering fuel system.

- 1 Remove screw (1), spacers (2), and clamp (3).
- 2 Remove fuel filter (4) from fuel hose (5) (lift pump to fuel filter).
- 3 Remove fuel filter (4) from fuel hose (6) (fuel filter to injection pump).
- 4 Discard fuel filter (4) and tape or plug fuel hoses (5 and 6).
- 5 Remove fuel hose (5) from lift pump discharge fitting.




4-17. REPLACE FUEL FILTER, FUEL PRESSURE LINE, HOSES, AND FITTINGS (Continued)


- 6 Remove screw (1) and clamps (2).
- 7 Remove fuel hose (3) from injection pump.
- 8 Remove fuel hose (4) from lift pump (5).
- 9 Remove screw (6) and clamp (7).
- 10 Remove hose clamp (8) and fuel hose (4) from fuel tank.



- 11 Remove fuel hose (1) (injection pump to double ring piece) from double ring piece (2). Tape or plug injection pump fitting.




- 12 Remove fuel hose (1) (double ring piece to injector) from double ring piece (2). Tape or plug injector fitting.




4-17. REPLACE FUEL FILTER, FUEL PRESSURE LINE, HOSES, AND FITTINGS (Continued)

- 13 Remove fuel pressure line (1) from injector (2) and injection pump (3).
Tape or plug fittings.



- 14 Remove non-return valve (1) and gasket (2).
Discard gasket (2).



INSPECTION:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

- 1 Inspect all fuel hoses for cracks, abrasions, or restrictions. Replace as necessary.
- 2 Inspect fuel pressure line for damage, rust, corrosion, or restrictions. Replace if necessary.

4-17. REPLACE FUEL FILTER, FUEL PRESSURE LINE, HOSES, AND FITTINGS (Continued)


- 3 Check non-return valve by shaking for free movement of internal valve ball. If necessary, clean with fuel. If internal valve ball does not have free movement, replace non-return valve.

INSTALLATION:


WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**


- 1 Install fuel pressure line (1) on injection pump (3) and injector (2).



- 2 Install fuel hose (1) (double ring piece to injector) on double ring piece (2).




- 3 Install fuel hose (1) (injection pump to double ring piece) on double ring piece (2).




4-17. REPLACE FUEL FILTER, FUEL PRESSURE LINE, HOSES, AND FITTINGS (Continued)

- 4 Install clamp (1) on fuel hose (2) (fuel tank to lift pump).
- 5 Install one clamp (3 and 4) with screws (5 and 6).
- 6 Install fuel hose (2) on lift pump (7).
- 7 Install fuel hose (8) on injection pump.
- 8 Install one clamp (4) on fuel hose (8).




- 9 Install fuel hose (1) (fuel filter to lift pump) and fuel hose (2) (injection pump to fuel filter) on a new fuel filter (3). Secure hoses with spacers (6), clamp (5), and screw (4).



4-17. REPLACE FUEL FILTER, FUEL PRESSURE LINE, HOSES, AND FITTINGS (Continued)

10 Install new gasket (2) and non-return vent valve (1).



4-18. REPLACE FUEL LIFT PUMP

This task covers: a. Removal c. Operational Check
 b. Installation

INITIAL SETUP

Tools

(A) Tool kit, general mechanics automotive
(USMC) Tool kit, general mechanics

General Safety Instructions

Well-ventilated area required.

Equipment

Condition


Para	Condition Description
4-17	Fuel hoses removed from fuel lift pump.

REMOVAL:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

- 1 Remove two hex nuts (1).
- 2 Remove fuel lift pump (2) and gasket (3). Discard gasket.
- 3 Remove inlet and outlet ring pieces (5).



4-18. REPLACE FUEL LIFT PUMP (Continued)

INSTALLATION:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

- 1 Install new gasket (3) and fuel lift pump (2).
- 2 Install two hex nuts (1).
- 3 Install inlet and outlet ring pieces (5).

OPERATIONAL CHECK:

- 1 Check that fuel lift pump is operational by operating primer lever (4).

NOTE

The fuel lift pump is cam driven. If high point of camshaft cam is in contact with fuel lift pump cam lever, fuel system cannot be primed using fuel lift pump.

- 2 Engage crank handle in gear housing and rotate clockwise to change camshaft position.
 - 3 Operate primer lever (4) on fuel lift pump and check for pumping action. If pumping action is not felt, continue to rotate hand crank until cam position allows hand priming.
-

4-19. REPLACE FUEL TANK

This task covers: a. Removal
b. Installation

INITIAL SETUP

Tools

(A) Tool kit, general mechanics automotive
(USMC) Tool kit, general mechanics

General Safety instructions

Well-ventilated area required.

Equipment

Condition Para

Condition Description


4-17 Fuel hoses removed from fuel tank.

REMOVAL:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

- 1 Remove two Allen screws (1), two Allen screws (2), four spacers (3), and two tube spacers (4).
- 2 Remove fuel tank (5) from engine.



4-19. REPLACE FUEL TANK (Continued)

INSTALLATION:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

- 1 Position fuel tank (5) on engine.
 - 2 Install two tube spacers (4) between fuel tank (5) and engine. Install four spacers (3), two Allen screws (2), and two Allen screws (1). Tighten screws securely.
-

4-20. REPLACE MUFFLER

This task covers: a. Removal c. Operational Check
 b. Installation

INITIAL SETUP**Tools**

- (A) Tool kit, general mechanics automotive
- (USMC) Tool kit, general mechanics

General Safety Instructions


Unit must be cool.

REMOVAL:

WARNING

Handling a hot muffler can cause severe burns. Allow unit to cool before handling.

- 1 Remove two screws (1) and washers (2).
- 2 Remove heat shield (3).
- 3 Remove three screws (4) and washers (5).
- 4 Remove protective screen (6).
- 5 Remove two nuts (7).
- 6 Remove muffler (8) and gasket (9). Discard gasket (9).

**INSPECTION:**

Inspect screws, nuts, washers, heat shield, protective screen, and muffler for rust, corrosion, or other damage. Replace if necessary.

INSTALLATION:

- 1 Install new gasket (9) and muffler (8).
- 2 Install two nuts (7). Tighten nuts (7) securely.
- 3 Install protective screen (6).

4-20. REPLACE MUFFLER (Continued)

- 4 Install three washers (5) and screws (4).
- 5 Install heat shield (3).
- 6 Install two washers (2) and screws (1).

OPERATIONAL CHECK:

WARNING

Touching exhaust system during test can cause severe burns.

Exposure to exhaust gases produces symptoms of headache, dizziness, loss of muscular control, drowsiness, or coma. Brain damage or death can result from severe exposure.

Fumes from engines become concentrated with poor ventilation. Operate engine in a ventilated area only.

While running engine, be alert for fumes. Keep area ventilated. If someone is overcome, expose to fresh air; keep warm and still; give artificial respiration if needed. Seek medical attention. Administer oxygen, if available.

GOOD VENTILATION IS THE BEST DEFENSE AGAINST EXHAUST POISONING.

Start engine and observe muffler (8) for leaks and/or rattles. Tighten screws (1 and 4) and nuts (7) as necessary to prevent rattles. If muffler leaks, replace it.

4-21. REPLACE/ADJUST THROTTLE CONTROL

This task covers: a. Removal c. Adjustments
 b. Installation

INITIAL SETUP

Tools


(A) Tool kit, general mechanics automotive
(USMC) Tool kit, general mechanics

Equipment Condition

Engine shut down.

REMOVAL:

- 1 Remove nut (1), disc (2), and nut (3).
Remove lever (4).
- 2 Loosen nuts (5 and 6). Unscrew
angular joint (7) from adjusting
screw (10).
- 3 Remove nut (8). Unscrew angular joint
(9) from adjusting screw (10).
- 4 Remove nut (11), disc (12), and spring
washer (13).
- 5 Remove hand lever (14), lever (15), and
screw (16).
- 6 Remove two screws (17), two discs
(18), two nuts (19), and two fixing
flaps (20).
- 7 Remove two screws (21). Remove con-
sole (22) and two discs (23).



INSTALLATION:

- 1 Install two discs (23) and console (22).
- 2 Install two screws (21). Tighten securely.
- 3 Install two screws (17), two discs (18), two nuts (19), and two fixing flaps (20).
- 4 Install screw (16) into console (22).
- 5 Install lever (15) on screw (16).
- 6 Install hand lever (14) on screw (16) and engage tang on hand lever (14) with notch on lever (15).

4-21. REPLACE/ADJUST THROTTLE CONTROL (Continued)

- 7 Install washer (13), disc (12), and nut (11). Tighten nut (11) securely.
- 8 Install nuts (5 and 6), if they were removed from the adjusting screw (10).
- 9 Install angular joints (7 and 9) on adjusting screw (10).
- 10 Install angular joint (9) on lever (15). Secure with nut (8).
- 11 Install angular joint (7) on lever (4). Secure with nut (3).
- 12 Tighten nuts (5 and 6).
- 13 Install lever (4) on engine. Secure with disc (2) and nut (1).

ADJUSTMENTS:

- 1 **IDLE ADJUSTMENT.** With engine running, loosen screw (17) and slide fixing flap (20) toward fuel lift pump side of engine. Move hand lever (14) to desired idle speed. Slide fixing flap (20) against hand lever (14) and tighten screw (17).
 - 2 **TOP SPEED ADJUSTMENT.** With engine running, loosen second screw (17) located closest to injection pump. Slide second fixing flap (20) toward injection pump side of engine. Move hand lever (14) to engine top speed. Slide fixing flap (20) against hand lever (14) and tighten screw (17).
 - 3 If idle or top speed of engine cannot be obtained, loosen nuts (5 and 6) and turn adjusting screw to increase or decrease travel of hand lever (14). Tighten nuts (5 and 6) after adjusting.
-

4-22. ADJUST CYLINDER HEAD AND VALVE ASSEMBLY

This task covers: Adjustments

INITIAL SETUP

Tools

- (A) Tool kit, general mechanics automotive
- (USMC) Tool kit, general mechanics
- Torque wrench
612 088 00
- Allen socket, 8 mm
612 095 00
- Box wrench, 10 mm
618 306 00

Equipment Condition

Engine shut down and cool.



General Safety Instructions

Well-ventilated area required.

ADJUSTMENT:


- 1 Remove screw (1) and pipe clip (2).
- 2 Remove two nuts (3) and two spring washers (4).
- 3 Lift cylinder head cover (5) from cylinder head.
- 4 Remove and discard gasket (6).

- 5 Adjust tappet clearance and decompression mechanism.
 - a. Put decompression lever (1) in position 0.
 - b. Crank engine clockwise when viewed from throttle control lever until compression resistance can be felt.




4-22. ADJUST CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

- c. Check clearance between rocker and valve stem with a feeler gage. Tappet clearance cold should be 0.004 inch (0.10 mm). To correct clearance loosen nut (2).
- d. Adjust screw (3) with screwdriver until feeler gage can be pulled between rocker and valve stem with very slight resistance after nut (2) has been tightened.




6 The adjustment of decompression adjustment screw is required if the engine does not decompress when the decompression lever is in position 1.

- a. Crank engine in same direction as for adjusting tappet clearance (see step 5b).
- b. Put decompression lever (1) in position 1.
- c. Loosen nut (2) using special 10 mm box wrench and turn adjustment screw (3) clockwise until rocker touches valve stem.
- d. Turn adjustment screw (3) another half turn and secure by tightening nut (2).



4-22. ADJUST CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

- 7 Check clearance of complete pushrod (1) and pinion (2).
 - a. Use a feeler gage to check that clearance (3) between socket of complete push rod (1) and pinion (2) is 0.039 inch (1.0 mm).
 - b. Check that clearance (4) is 0.039 inch (1.0 mm).
 - c. Clearances can be adjusted by adjusting complete pushrod (1) for clearance (3), and adjusting rocker shaft for clearance (4).



NOTE


During engine operation decompression shaft must not move. Assured clearances will prevent movement.

- 8 Install new gasket (6) on cylinder head.
- 9 Install cylinder head cover (5) on gasket (6).
- 10 Install two spring washers (4) and nuts (3). Tighten securely.

NOTE

Insure that copper washers are installed on both sides of the pipe clip to prevent oil leaks.

- 11 Install pipe clip (2) and screw (1).



Section VI. PREPARATION FOR STORAGE OR SHIPMENT

4-23. GENERAL

This section provides instructions for preparing the centrifugal pump unit for short term and intermediate storage or shipment.

4-24. ADMINISTRATIVE STORAGE

Administrative storage shall be in accordance with (A) AR 750-1 or (USMC) MCOP 4450.7.

NOTE

When centrifugal pump unit is taken out of service, take special precautions to protect the interior and exterior of the unit from rust accumulation and corrosion.

4-25. SHORT TERM STORAGE (30 days or less)

WARNING


Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Engines must be turned off and cool before refueling. Use proper refueling procedures and equipment to avoid spillage. Do not run engines near open fuel containers. Always store fuel in proper, marked containers. DO NOT SMOKE.

- a. Fill fuel tank with VV-F-800 diesel fuel oil. Connect centrifugal pump unit to a water supply. Prime pump and operate the engine for 2 minutes.

NOTE

Do not drain the fuel system after this run. Remove water supply after this run.

4-25. SHORT TERM STORAGE (30 days or less) (Continued)



- b. Remove suction hose from hose adapter (3) (intake).
- c. Remove discharge hose from hose adapter (4) (discharge).
- d. Remove pipe plug (1) and drain pump case (2). Replace pipe plug (1).
- e. Clean intake and discharge port threads using a wet cloth.
- f. Cover intake and discharge hose adapters.
- g. Seal all engine openings with moistureproof, vaporproof tape, strong enough to resist puncture and damage from the expansion of entrapped air.

4-26. INTERMEDIATE TERM STORAGE (more than 30 days)

- a. Connect centrifugal pump to a water supply. Prime pump, start engine, and allow to operate for 10 to 12 minutes or until normal operating temperature is reached. Shut down engine.
- b. Drain crankcase oil. Then fill crankcase to proper level using MIL-L-21260 preservative lubricating oil, Grade 2, or equivalent.

4-26. INTERMEDIATE TERM STORAGE (more than 30 days) (Continued)

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

c. Remove fuel tank cap (1) and hose connected to bottom of fuel tank (2). Collect fuel in a suitable metal container.

d. Replace fuel filter.

e. Replace hose to bottom of tank (2) and pour approximately one pint of MIL-L-46002 preservative oil, Grade 1, in fuel tank.

f. Start engine and allow to operate for not less than 5 to 7 minutes. Shut down engine.

g. Service air cleaner in accordance with paragraph 3-4.



h. Remove pipe plug (1) and drain pump case (2). Replace pipe plug (1).

i. Remove suction hose from hose adapter (3) (intake).

j. Remove discharge hose from hose adapter (4).

k. Coat all accessible surfaces with MIL-L-21260 preservative oil, Type I, Grade 30. Wipe excess oil from intake and discharge threads and cover adapters.

l. Remove pipe plug (5) and pour approximately one quart of MIL-P-116 preservative oil, Type P-14, into pump case (2). Replace pipe plug (5).



4-26. INTERMEDIATE TERM STORAGE (more than 30 days) (Continued)

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

- l. Drain engine crankcase and fuel tank into suitable metal containers.
- m. Service air cleaner in accordance with paragraph 3-4.

4-27. SHIPMENT

- a. Use shipping plugs, closures, or sealing tape to cover all openings in the pump and engine.
- b. Attach to the centrifugal pump unit all forms, tags, and records applicable to the unit.

CHAPTER 5
INTERMEDIATE DIRECT SUPPORT MAINTENANCE INSTRUCTIONS

Section I. TROUBLESHOOTING

5-1. TROUBLESHOOTING

a. Table 5-1 contains troubleshooting information for locating and correcting most of the operating troubles which are the responsibility of direct support maintenance. Each malfunction for an individual component, unit, or system is followed by a list of tests or inspections which will help you to determine probable causes and corrective actions to take. Perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Only those functions within the scope of direct support maintenance are listed. For troubleshooting procedures within the scope of operator/crew maintenance, refer to table 3-1. For troubleshooting procedures within the scope of organizational maintenance, refer to table 4-2.

5-2. SYMPTOM INDEX

Refer to the Symptom Index below. Locate the malfunction which is the same, or most nearly the same, as the trouble you are having with the centrifugal pump unit. The Symptom Index lists the first page of troubleshooting information for that malfunction. Follow the steps one by one, and perform the corrective actions listed.

Malfunction Number	Description	Page
1	Engine cranks but fails to start	5-2
2	Engine starts but runs unevenly, stalls, or surges	5-2
3	Engine stops running or produces black, white, or grey smoke	5-2
4	Engine consumes excessive lube oil	5-2

Table 5-1. Intermediate Direct Support Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. ENGINE CRANKS BUT FAILS TO START		
	Step 1. Check for loose cylinder head.	If loose, tighten nuts.
	Step 2. Check for faulty lift pump.	Repair lift pump (para 5-6).
	Step 3. Check for faulty injector. Remove and test injector (para 5-7).	Repair or replace faulty injector (para 5-7).
2. ENGINE STARTS BUT RUNS UNEVENLY, STALLS, OR SURGES		
	Step 1. Check for faulty injector. Remove and test injector (para 5-7).	Repair or replace faulty injector (para 5-7).
	Step 2. Check for air in the fuel system.	Service injector (para 5-7).
3. ENGINE STOPS RUNNING OR PRODUCES BLACK, WHITE, OR GREY SMOKE		
	Step 1. Check for faulty injector. Remove and test injector (para 5-7).	Repair or replace faulty injector (para 5-7).
	Step 2. Check for faulty lift pump.	Repair lift pump (para 5-6).
4. ENGINE CONSUMES EXCESSIVE LUBE OIL		
	Step 1. Check for oil leaks on bottom of engine.	Tighten screws on cover located on bottom of engine.

Section II. MAINTENANCE PROCEDURES

INDEX

	Para		Para
Crank assembly gears	5-9	Frame assembly	5-14
Cylinder	5-11	Injection pump	5-8
Cylinder head and valve assembly	5-10	Injector	5-7
Engine assembly	5-5	Lift pump	5-6
Flywheel	5-13	Piston	5-12
		Pump case	5-4

5-3. GENERAL INSTRUCTIONS

Most maintenance instructions in this section will list resources required, personnel required, and equipment condition for the start of the procedure. Note the following:

- Resources required are not listed unless they apply to the procedure.
- Personnel required are listed only if the task requires more than one. If PERSONNEL is not listed, it means one person can do the task.
- The normal standard equipment condition to start a maintenance task is engine stopped. EQUIPMENT CONDITION is not listed unless some other condition is required.
- Refer to Appendix F to determine torque requirements when tightening threaded fasteners, unless a specific torque value is given in procedure. Standard torque values given in Appendix F are determined by thread size.

5-4. REPAIR PUMP CASE

This task covers: Repair/Cleaning

INITIAL SETUP

Tools

Shop set, automotive repair, field maintenance, basic

Equipment Condition Para

4-14

Condition Description

Pump case assembly removed.

Materials/Parts


Dry, cleaning solvent (Item 10, Appendix E)
Zinc chromate primer coating (Item 9, Appendix E)

General Safety Instructions

Well-ventilated area required.

REPAIR/CLEANING:

- 1 Remove each insert (1, 2, or 3) from pump case (4) by using a scribe or other pointed instrument. Pry the last thread of insert into center of tapped hole. Grasp thread with needle-nosed pliers and remove damaged insert by threading out of hole.



5-4. REPAIR PUMP CASE (Continued)

- 2 Chase threaded hole using appropriate size tap.

WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138°F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 3 Using dry cleaning solvent and a stiff-bristled brush, clean threaded hole thoroughly.
 - 4 Using clean compressed air at 30 psi (2.06 bar) maximum discharge pressure, blow out threaded hole to make sure that all solvent has been removed and no particles are left in the hole.
 - 5 Coat new insert (1, 2, or 3) with zinc chromate primer coating.
 - 6 Insert each insert to a depth of 1 to 1.5 pitches below the top surface of the tapped hole in pump case (4). Wipe off excess primer.
 - 7 Remove drive tang from installed insert.
-

5-5. REPLACE ENGINE ASSEMBLY

This task covers: a. Removal b. Installation

INITIAL SETUP

Tools

Shop equipment, automotive maintenance and repair, common no. 1

General Safety Instructions

Hoisting equipment shall be used only by authorized personnel.

Equipment Condition

Para	Condition Description
4-14	Pump case assembly removed.
4-15	Air filter assembly removed.

REMOVAL:

WARNING


Death or serious injury could occur if unauthorized or unnecessary personnel are in the hoisting area. Permit only personnel actually engaged in the hoisting operation to be near the unit and hoisting equipment. All instructions for the hoisting operations must come from one authorized person.

Death or serious injury to personnel or damage to equipment could occur from improper hoisting. Hoist the load slowly to avoid tearing out lifting strap, slipping slings, or load shift. Do not jerk the load or swing it from side-to-side when hoisting. This places additional stress on hoisting components which can cause failure and loss of load. Be sure hoisting equipment is on solid footing and is suitable for the size of the load. Watch boom angle and overhead clearance when hoisting.

CAUTION

Engine will be damaged if set on cover at bottom of engine. Provide adequate blocking to support engine after removal.

- 1 Position a suitable lifting device over engine assembly. Attach to lifting strap (1).
- 2 Put tension on slings. Make sure engine is properly supported.
- 3 Remove four hex screws (2) and four spring washers (3) from each engine bracket (4). Remove engine assembly (5).
- 4 Lift engine assembly (5) and lower onto blocks on a stable, level work platform.



5-5. REPLACE ENGINE ASSEMBLY (Continued)

INSTALLATION:

WARNING

Death or serious injury could occur if unauthorized or unnecessary personnel are in the hoisting area. Permit only personnel actually engaged in the hoisting operation to be near the unit and hoisting equipment. All instructions for the hoisting operations must come from one authorized person.

Death or serious injury to personnel or damage to equipment could occur from improper hoisting. Hoist the load slowly to avoid tearing out lifting strap, slipping slings, or load shift. Do not jerk the load or swing it from side-to-side when hoisting. This places additional stress on hoisting components which can cause failure and loss of load. Be sure hoisting equipment is on solid footing and is suitable for the size of the load. Watch boom angle and overhead clearance when hoisting.

- 1 Attach lifting equipment. Lift and carefully lower engine assembly (5). Aline mounting holes on engine and engine brackets.
 - 2 Install four hex screws (2) and four spring washers (3) on each engine bracket (4). Tighten securely.
-

5-6. REPAIR LIFT PUMP

This task covers: a. Disassembly c. Assembly
 b. Repair

INITIAL SETUP

Tools

Shop set, automotive repair, field maintenance, basic

Materials/Parts

Diesel fuel oil (Item 2, Appendix E)

Lubricating oil (Item 6, Appendix E)

Equipment Condition Para

4-18

Condition Description

Fuel lift pump removed from engine.

General Safety Instructions


Well-ventilated area required.

DISASSEMBLY:

CAUTION

Do not scratch or mar mating surfaces of pump body or cover. The pump may leak or otherwise malfunction after reassembly.

- 1 Remove screw (1), gasket (2), and cover (3).
- 2 Remove and discard gasket (4).
- 3 Remove fuel filter (5).
- 4 Remove six Allen screws (6).
- 5 Remove upper pump chamber (7).
- 6 Remove diaphragm (8) from pump body (9) and discard.



5-6. REPAIR LIFT PUMP (Continued)

REPAIR:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean all parts except gasket (4) with clean diesel fuel and dry with low-pressure compressed air.
- 2 Inspect mating surface of cover (3) and pump body (9) parts for roughness or other damage. Scratches or other damage may result in pressure leaks.
- 3 Check for wear at contact areas. Replace pump body (9) or cover (3) if worn.
- 4 Inspect all parts for score marks and burrs. Parts must fit together tightly.
- 5 If parts are not repairable, replace.

ASSEMBLY:

CAUTION

Do not scratch or mar mating surfaces of pump body or cover. The pump may leak or otherwise malfunction after reassembly.

- 1 Install new diaphragm (8) into pump body (9).
 - 2 Install upper pump chamber (7) on diaphragm (8).
 - 3 Install six Allen screws (6) finger tight. Move fuel primer lever on pump body (9) to compress diaphragm spring. Tighten Allen screws.
 - 4 Install fuel filter (5).
 - 5 Lubricate gasket (4) with lubricating oil and install.
 - 6 Install screw (1), gasket (2), and cover (3).
-

5-7. REPLACE INJECTOR

This task covers:

- a. Removal
- b. Testing
- c. Installation

INITIAL SETUP

Tools

Shop set, automotive repair, field maintenance, basic

Testing device for injection equipment
604 628 00

Equipment Condition

Para

Condition Description

4-17

Fuel pressure line removed.

Materials/Parts

Diesel fuel (Item 2, Appendix E)

Grease (Item 3, Appendix E)

General Safety Instructions

Well-ventilated area required.

REMOVAL:


WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

CAUTION


The fuel injection system is extremely intricate and complex. All possible care should be taken in the removal, inspection, testing, and re-assembly of these components. While handling the fuel injector, be extremely careful not to touch the nozzle or the pin assembly on the nozzle end.

- 1 Remove injector (1) from cylinder head.
- 2 Remove joint washer (2).



5-7. REPLACE INJECTOR (Continued)

TESTING:



- 1 Visually inspect injector (1) for scoring or burning. Inspect to see if injector is bent, cracked, or damaged. If injector is damaged, replace it.

NOTE

Loosen the pressure gage connection, and crank the engine until trapped air is removed from the system.

- 2 Connect testing device 604 628 00 (3) to injector pump (4) and injector (1). Make sure side connection (5) is tightly locked.

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

Serious injury could result from injector fuel spray. Keep hands away from fuel spray.

NOTE

Prior to testing injector, make sure throttle control hand lever is in the **HIGH** position.

- 3 Crank engine by hand. As the engine is cranked, read fuel injection pressure on the gage and check fuel spray pattern from injector. Injection pressure should be 1958 to 2074 psi (135 to 143 bar). Fuel should spray out in an even spray pattern. If spray pattern does not conform to above, replace injector. If injector nozzle drips fuel before or after it has reached recommended injection pressure, replace injector.


5-7. REPLACE INJECTOR (Continued)

INSTALLATION:

CAUTION

The fuel injection system is extremely intricate and complex. All possible care should be taken in the removal, inspection, testing, and reassembly of these components. While handling the fuel injector, be extremely careful not to touch the nozzle or the pin assembly on the nozzle end.

- 1 Be certain injector seat in cylinder head is clean. Lightly coat joint washer (2) with grease and install on nozzle end of injector (1). Make sure outside beveled edge of new joint washer points toward cylinder head.
- 2 Carefully install injector (1) into injector bore in cylinder head. Make sure not to damage nozzle needle. Tighten injector to 7 foot-pounds (10 N·m) using torque wrench.



5-8. TEST/REPLACE/ADJUST INJECTION PUMP

This task covers: a. Test c. Installation
b. Removal d. Adjustment

INITIAL SETUP

Tools

Shop set, automotive repair, field maintenance, basic
Testing device for injection equipment 604 628 00
Dial gage 612 087 00
Fuel shutoff clamp 668 383 00
Socket wrench, 30 mm 668 335 00
Special wrench 606 000 00
Spill device 604 837 00

Materials/Parts

Diesel fuel oil (Item 2, Appendix E)
Lubricating oil (Item 6, Appendix E)

Equipment Condition

Para	Condition Description
4-14	Pump case assembly removed.
4-17	Fuel hose and fuel pressure line removed.
4-17	Non-return valve removed from injection pump.

General Safety Instructions

Well-ventilated area required.

TEST:


NOTE

Perform this test before removal of injection pump and after installation.

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

- 1 Connect fuel hose (1) from lift pump to injection pump (4).
- 2 Make sure the extra fuel device button is not pulled to the extended position. If the button is extended, move the throttle control hand lever to the LOW position and then return the lever to the HIGH position to reset the extra fuel button.



5-8. TEST/REPLACE/ADJUST INJECTION PUMP (Continued)

- 3 Connect testing device 60462800 (3) to injection pump (4). Make sure side connections (2) are tightly locked.
- 4 Loosen the pressure gage connection, and crank the engine until trapped air is removed from the system.
- 5 Tighten pressure gage connections.

CAUTION

The pressure gage can be damaged if the engine is cranked beyond the gage limits. Failure to heed this caution can damage equipment.

- 6 Slowly crank engine by hand. As the engine is cranked, read fuel injection pressure on the gage. Injection pressure should be 4351 to 5076 psi (300 to 350 bar). Stop cranking engine and observe whether pressure is maintained. If pressure drops below 3650 psi (250 bar) within 10 to 15 seconds, then injection pump is not in working order. Notify rear intermediate maintenance.
- 7 Remove testing device 604 628 00 (3).


REMOVAL:

- 1 Move throttle control hand lever to HIGH position and pull extra fuel button.

CAUTION

Do not scratch or mar mating surfaces of injection pump or mounting surface. The pump may leak or otherwise malfunction after reassembly.

- 2 Remove two hexagon nuts (1) and remove injection pump (2).
- 3 Remove shim(s) (3), plate (4), and tappet (5).



5-8. TEST/REPLACE/ADJUST INJECTION PUMP (Continued)

WARNING


Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

- 4 Clean all parts with clean diesel fuel and dry with low-pressure compressed air.
- 5 Inspect mating surface of injection pump for roughness or other damage. Scratches or other damage may result in pressure leaks. Check for wear at contact areas. Replace injection pump if worn.

INSTALLATION:

- 1 Install tappet (1) into crankcase (2).
- 2 Turn engine by hand until tappet (1) reaches the lowest point of cam (3).
- 3 Position throttle control hand lever so that governor lever slot (4) lies exactly in the center of the tappet bore.
- 4 Install plate (5), with the flat surface toward the injection pump (7).
- 5 Place shim pack (6) on crankcase (2) studs.
- 6 Position control sleeve on injection pump (7) so that control sleeve pin enters slot in governor lever.
- 7 Insert injection pump (7) carefully without moving the control sleeve out of its proper position.



NOTE

No resistance should be felt until the pump is within 0.160 inch (4 mm) of the crankcase, then a resistance due to initial load of plunger spring can be felt.

CAUTION

Do not tighten pump if not seated properly. Damage to pump, governor lever, or engine could result if improperly installed.

- 8 Using hand pressure, insert injection pump (7) fully into crankcase (2) and install two hexagon nuts (8). If the pump does not seat properly, governor sleeve pin of injection pump has not entered slot (4) in governor lever.

5-8. TEST/REPLACE/ADJUST INJECTION PUMP (Continued)

ADJUSTMENTS:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

CAUTION

When adjusting timing, pay special attention to rotation of engine. Timing can be accomplished only when engine is rotated correctly. Correct rotation is clockwise when facing throttle control hand lever.


Preparation:

- 1 Remove engine adapter housing to expose engine flywheel.
- 2 Block fuel hose (fuel tank to lift pump) with fuel shutoff clamp 668 383 00.
- 3 Remove the fuel filter, fuel hoses, and clamps using REMOVAL steps 1 to 7 in paragraph 4-17.
- 4 Disconnect fuel hose (fuel tank to lift pump) from lift pump connection using REMOVAL step 8 in paragraph 4-17.

NOTE


Use the existing fuel filter for testing.

- 5 Install fuel hose (5) (see REMOVAL step 2 in paragraph 4-17) on injection pump.
- 6 Install fuel filter (2).
- 7 Connect fuel hose (3) (fuel tank to lift pump) to fuel filter (2) inlet.



5-8. TEST/REPLACE/ADJUST INJECTION PUMP (Continued)

- 8 Unscrew delivery valve holder (1) and remove spring (2) filling piece with three shims (3), copper washer (4), delivery valve (5), and valve body (6).
- 9 Insert copper washer (4) and delivery valve body (6) only into spill device 604 83 700.
- 10 Thread spill device into injection pump with spill pipe in up position, and then secure in place.



NOTE

Additional copper washers may be necessary to attain the spill pipe in the up position when the spill pipe is tightened.

- 11 Install dial indicator 612 08 700 with adapter pin 1.64-inch (41 mm) long attached, into spill device, and pre-tension approximately 1 mm (one rotation of dial indicator hand).
- 12 Remove fuel shutoff clamp 668 383 00 from fuel hose.

NOTE

Fuel emerging from the spill pipe on spill device 604 837 00 must be bubble free.

- 13 Move the throttle control hand lever to the HIGH position.

Adjustment of Delivery End:

NOTE

The position of TDC (2) and end of delivery (3) and marked on the flywheel. The corresponding (alignment) mark (4) is on the right upper side of the crankcase.


- 1 Slowly rotate flywheel counterclockwise (when facing flywheel) until no fuel emerges from spill pipe on spill device 604 837 00.
- 2 Continue to very slowly rotate flywheel, while frequently blotting spill pipe with rag to absorb fuel, until fuel just begins to weep from spill pipe.

5-8. TEST/REPLACE/ADJUST INJECTION PUMP (Continued)

NOTE

The position achieved above is the end of delivery. If the shim pack is of the correct thickness, the timing marks on flywheel (1) (11.5 to 12.5 degrees) should align with reference mark (4).

- 3 Block fuel hose (from fuel tank) using fuel shutoff clamp 668 383 00.
- 4 If timing marks do not align with reference mark (4), rotate outer face of dial gage 612 087 00 until "0" mark aligns with needle.
- 5 Slowly rotate flywheel (1) in either direction to align timing marks of 11.5 to 12.5 degrees with reference mark (4). Gage reading will indicate amount of reshimming (as necessary).




NOTE

The end of delivery is delayed or advanced by adding or removing shims (1) to injection pump (2). The general rule for shimming is as follows:

More shims = end of delivery later (lower number of degrees)

Less shims = end of delivery earlier (higher number of degrees)

- 6 Remove fuel shutoff clamp 668 383 00 from fuel hose.
- 7 After correction of shimming, repeat steps 1 and 2 for checking purposes.




5-8. TEST/REPLACE/ADJUST INJECTION PUMP (Continued)

Adjustment of Delivery Lift:

NOTE

Delivery lift controls the quantity of fuel which is injected at full throttle (full load).

- 1 With flywheel timing marks (2) (11.5 to 12.5 degrees) aligned with reference mark (3), rotate dial gage 612 087 00 face to zero.
- 2 Slowly rotate flywheel (1) in a clockwise direction when facing flywheel until dial gage indicates 0.052 inch (1.34 mm).
- 3 Stop flywheel at position indicated in step 2.




WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers, DO NOT SMOKE.

- 4 At this point, fuel should emerge again from spill pipe (1) of spill device (2).

NOTE

If fuel does not emerge, turn the extra fuel device. If results are not obtained, turn the extra fuel device in the opposite direction.



5-8. TEST/REPLACE/ADJUST INJECTION PUMP (Continued)

5 Loosen extra fuel button jam nut (2) with socket wrench, 30 mm, 668 335 00.

6 Using special wrench 606 000 00, slightly rotate eccentric (1) until fuel drips at desired rate.

7 Tighten extra fuel button jam nut (2).

8 Block fuel hose (from fuel tank) using fuel shutoff clamp 668 383 00.

9 Remove dial gage, with spill device attached.

10 Remove delivery valve body (1) and copper washer (2).



11 Install filling piece with three shims (3) in delivery valve holder (4).

12 Insert spring (5) in delivery valve holder (4).

13 Insert copper washer (2) in delivery valve holder (4).

14 Insert delivery valve (6) in valve body (1).

15 Insert delivery valve (6) and valve body (1) into delivery valve holder (4).



NOTE

Verify that grooved end in the valve body enters the injection pump opening first.

16 Install new preformed packing (7), and then tighten delivery valve holder assembly into injection pump.

5-8. TEST/REPLACE/ADJUST INJECTION PUMP (Continued)

WARNING

Before starting the engine and after making repairs or adjustments on the fuel system, a 17 mm wrench must be available to allow rapid removal of the steel fuel line at the injection pump in case of a runaway condition. Failure to heed this warning can result in injury to personnel and equipment damage.

- 17 Install fuel filter, fuel hoses, and hose clamps as described in INSTALLATION steps 5, 6, 7, 8, and 9 of paragraph 4-17.
- 18 Remove fuel shutoff clamp 668 383 00 from fuel hose.
- 19 Install engine adapter housing.
-

5-9. REPLACE CRANK ASSEMBLY GEARS (Continued)

CLEANING:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean housing (2), gear wheel (6), and pinion (11) with diesel fuel and dry with compressed air.
- 2 Inspect all components for damage or excessive wear. Replace any components severely damaged or worn.

ASSEMBLY:

CAUTION

If either the gear wheel or pinion needs to be replaced, replace both. Timing marks on the small pinion must be aligned with the keyway on the tapered shaft. The timing marks on the gear wheel must be aligned with the mark on the small pinion. Failure to heed this caution can damage equipment.

- 1 Slide pinion (11) onto camshaft. Install spring washer (10) and hexagon nut (9) and tighten securely.
 - 2 Install disc (8) into timing cover housing with the graphite side of disc (8) facing outward.
 - 3 Lubricate dry bushing in timing cover housing with MIL-G-10924 grease.
 - 4 Install gear wheel (6) into dry bushing and secure gear wheel (6) with stud (7).
 - 5 Install oil seal (5) and needle shell (4) onto gear wheel (6).
 - 6 Fill housing (2) with 3-1/2 ounces (100 g) of warm MIL-G-10789 grease. Mount gasket (3) and housing (2) onto timing cover with four Allen screws (1).
-

5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY

This task covers:

a. Removal	d. Assembly/Adjustment
b. Disassembly	e. Installation/Adjustment
c. Cleaning/Inspection	

INITIAL SETUP

Tools

Shop set, automotive repair,
field maintenance, basic

Dial gage
612 087 00

Measuring device
603 114 00

Allen socket, 8 mm
612 095 00

Retainer bracket for cylinder
612 752 00

Box wrench
618 306 00

Materials/Parts

Diesel fuel oil (Item 2, Appendix E)


Equipment Condition

Para	Condition Description
4-14	Pump case assembly removed.
4-19	Fuel tank removed.
4-20	Muffler removed.
5-7	Injector removed from cylinder head.

General Safety Instructions

Well-ventilated area required.


REMOVAL:




- 1 Remove screw (1) and hex nut (2) from cowling (3).
- 2 Remove cowling (3) from engine.

5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

- 3 Remove screw (1) and pipe clip (2).
- 4 Remove two nuts (3) and two spring washers (4).
- 5 Lift cylinder head cover (5) off cylinder head.
- 6 Remove and discard gasket (6).




- 7 Remove four nuts (1) from four studs (2) and remove rocker shaft (3) with rockers, lifting eye, fuel tank bracket, and two air shields. Remove deflector (4).



NOTE

Record thickness of gasket (2) to aid in selection of new gasket during installation.

- 8 Remove cylinder head (1) and gasket (2). Discard gasket.




5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

9 Remove pushrod (1) and complete pushrod (2) from protection tubes (3).

10 Remove protection tubes (3), preformed packings (4), shims (5), and pressure springs (6).

NOTE

Complete pushrod (2) belongs to injection pump side of engine.



DISASSEMBLY:


CAUTION

Do not scratch the cylinder head sealing face. Scratches could cause poor sealing of cylinder head and cylinder.

1 Press down cup (1) and remove collets (2).


2 Remove valve spring (3), washer (4), and cap (5).

3 Remove valve (6) from cylinder head (7).



5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

- 4 Remove nut (1) from threaded pin (2).
- 5 Use needlenose pliers to remove pin (3) with 10 spring plates (4), and preformed packing (5) attached.
- 6 Remove and discard preformed packing (5).
- 7 Knock out pin (6) and remove decompression shaft (7) and pinion (8) from cylinder head (9).



CLEANING/INSPECTION:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.


Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean all parts with a clean cloth dampened with diesel fuel oil. Use wire brush where necessary. Dry with compressed air.
- 2 Inspect all parts for cracks, rust, corrosion, and excessive heat damage.
- 3 Inspect for accumulated carbon around injector seat in cylinder head.
- 4 Replace cylinder head if it is damaged.

5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

5 Measure rocker shaft (1) diameter. If rocker shaft diameter is smaller than 0.7074 inch (17.967 mm), it must be replaced.

6 Measure rocker bore bushing (2) inside diameter. If rocker bore bushing inside diameter is greater than 0.7076 inch (17.974 mm), replace bushing (2).



7 Measure rocker (3) radius. The radius must be 0.315 inch (8 mm). No flattening or brinelling is permitted on the rocker radius. If there is any evidence of flattening the rocker must be replaced.

NOTE

When replacing rocker (3) you must also replace bushing (2). They are replaced as an assembly. Bushing (2), however, can be replaced separately.

8 Inspect valve seats in cylinder head. If there is any evidence of damage, replace cylinder head.

9 Inspect valves. If there is any evidence of damage or distortion, replace valve.

ASSEMBLY/ADJUSTMENT:


1 Install pinion (8) in cylinder head (9).

2 Insert decompression shaft (7) through cylinder head (9) and into pinion (8).

3 Aline holes in pinion (8) and decompression shaft (7).

4 Install pin (6).

5 Install new preformed packing (5) on pin (3).



6 Install 10 spring plates (4) on pin (3). The spring plates (4) must be installed in five sets with concave sides together to create a spring action.

7 Install pin (3) with assembled preformed packing (5) and spring plate (4) into cylinder head (9).

8 Rotate decompression shaft (7) to horizontal position.

9 Install threaded pin (2) and tighten until snug.


10 Secure nut (1).

5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

CAUTION

Do not scratch the cylinder head sealing face. Scratches could cause poor sealing of cylinder head and cylinder.

- 11 Insert valve (6) into cylinder head (7).
- 12 Install cap (5), washer (4), valve spring (3), and cup (1).
- 13 Press down on cup (1) and install collets (2).




INSTALLATION/ADJUSTMENT:

CAUTION

Too small a clearance will damage piston, cylinder head, and valves.
Too large a clearance will result in difficult starting.

- 1 Adjust cylinder head clearance.
 - a. Insert dial gage 612 087 00 into measure device 603 114 00.
 - b. Put dial gage 612 087 00 with measuring device 603 114 00 on a flat surface.
 - c. Pre-tension dial gage 612 087 00 (1) to 1 mm and lightly tighten in position.
 - d. Set the dial gage to zero.
 - e. Install retaining bracket 612 752 00 (3) to retain cylinder (4).
 - f. Bring the piston to TDC position.
 - g. Carefully lower dial gage 612 087 00 (1) with measuring device 603 114 00 (2) on cylinder (4).
 - h. Measure the distance between the top of the cylinder and the top of the piston. Record reading on dial gage (1).



5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)


- i. Subtract reading on dial gage that was recorded from the required clearance of 0.0217/0.0256 inch (0.55/0.65 mm). This difference is the thickness of the gasket needed for proper cylinder head clearance.

NOTE


Gaskets come in various thicknesses. If you have a choice between two gaskets, it is best to use the thickest one.

- j. Remove dial gage 612 087 00 with measuring device 603 114 00, and retaining bracket 612 752 00.

- 2 Adjust complete push rod (1) so dimension A equals 5.8189/5.8268 inches (147.8/148.0 mm). This adjustment is required for proper engagement of complete pushrod with pinion on decompression shaft.




- 3 Install preformed packings (4), shims (5), pressure springs (6), and protection tubes (3).
- 4 Install complete pushrod (2) closest to injection pump side of engine.
- 5 Install pushrod (1).




5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

- 6 Install new gasket (2) and cylinder head (1) on cylinder.




- 7 Install rocker shaft (3) with rockers, two air shields, fuel tank bracket, and lifting eye. Install deflector (4).

- 8 Install four nuts (1) on four studs (2) and tighten nuts equally and crosswise to a torque of 47 foot-pounds (6.5 m-kg).




- 9 Adjust tappet clearance and decompression mechanism.

- a. Put decompression lever (1) in position 0.
- b. Turn engine clockwise when facing throttle control level until compression resistance can be felt.




5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)




- c. Check clearance between rocker and valve stem with a feeler gage. Tappet clearance cold should be 0.004 inch (0.10 mm). To correct clearance loosen nut (2).
 - d. Adjust screw (3) with screwdriver until feeler gage can be pulled between rocker and valve stem with very slight resistance after nut (2) has been tightened.
- 10 The adjustment of decompression adjustment screw (3) is required if the engine does not decompress when the decompression lever is in position 1.
- a. Turn engine in same direction as for adjusting tappet clearance.
 - b. Put decompression lever in position 1.

5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

- c. Loosen nut (2) using box wrench 618 306 00 and turn adjustment screw (1) clockwise until rocker touches valve stem.
- d. Turn adjustment screw (1) another half turn and secure by tightening nut (2).



- 11 Check clearance of complete pushrod (1) and pinion (2).
- a. Use a feeler gage to check that clearance (3) between socket of complete pushrod (1) and pinion (2) is 0.039 inch (1.0 mm).
 - b. Check that clearance (4) is 0.039 inch (1.0 mm).
 - c. Clearances can be adjusted by adjusting complete pushrod (1) for clearance (3), and adjusting rocker shaft for clearance (4).



NOTE

During engine operation decompression shaft must not move. Assured clearances will prevent movement.



5-10. INSPECT/REPLACE CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

12 Install gasket (6) on cylinder head.

13 Install cylinder head cover (5) on gasket (6).

14 Install two spring washers (4) and nuts (3). Tighten securely.

15 Install pipe clip (2) and screw (1).



16 Install cowling (3) to engine.

17 Install screw (1) and hex nut (2).

5-11. INSPECT/REPLACE CYLINDER (Continued)

CLEANING/INSPECTION:

WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138°F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean cylinder seats in crankcase (2) with dry cleaning solvent and dry with compressed air. Check that cylinder seats are smooth and flat.
- 2 Clean cylinder thoroughly with dry cleaning solvent. Dry with compressed air. Inspect for damage, warpage, rust, or corrosion. If severely damaged or warped, replace with new cylinder and piston.


NOTE

For piston replacement instructions refer to paragraph 5-12.

- 3 Inspect cylinder for cracks. Inspect for scoring, glazing, or a ridge on the upper portion of inner surface. Inspect for metal particles (fretting) on outer surface. Replace damaged cylinder with new cylinder and piston.

5-11. INSPECT/REPLACE CYLINDER (Continued)

- 4 Measure cylinder bore at levels 1 to 4 of engine centerline axis A and crossline axis B. A normal or new bore diameter should be 2.8740 to 2.8774 inches (73.00 to 73.01 mm). If wear limits for a normal bore cylinder have been reached or exceeded, replace cylinder and piston. If measurements on axis A and axis B are different, cylinder is out-of-round or has high spots. Replace cylinder and piston.
- 5 Check that the top and bottom joint faces are smooth and flat. If damaged, replace cylinder and piston.



REPAIR:

- 1 Remove slight ridges, score marks, and glaze with a hone equipped with 20-grit stones. Work hone up and down rapidly the full length of the cylinder bore several times in a criss-cross pattern. Criss-cross pattern produces hone marks on a 45-degree axis, which aids piston movement and helps prevent formation of ridges.

WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138° F (38° to 59°C).


Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

- 2 Clean cylinder with dry cleaning solvent and dry with compressed air. Remove any burrs.
- 3 Recheck cylinder bore and out-of-round on repaired cylinder as described above. Replace if out of tolerance.

5-11. INSPECT/REPLACE CYLINDER (Continued)

INSTALLATION:

- 1 Install piston (1) in accordance with paragraph 5-12. Apply lubricating oil to piston rings.
- 2 Check that piston rings are offset by 120 degrees.
- 3 Compress piston rings with piston ring clamp 666 346 00 (2).



CAUTION

When installing cylinder, make sure piston or connecting rod does not knock against crankcase. This could result in serious damage to piston or connecting rod.

Use care when installing cylinder to prevent damage to piston rings.

- 4 Apply lubricating oil to inside of cylinder (3) and slowly mount cylinder on studs (4).
 - 5 Remove piston ring clamp 666 346 00 (2).
-

5-12. INSPECT/REPAIR/REPLACE PISTON

This task covers: a. Removal c. Cleaning e. Repair
 b. Disassembly d. Inspection f. Assembly

INITIAL SETUP

Tools

Gudgeon pin extractor
614 957 00

Piston ring pliers
612 090 00

Equipment
Condition
Para

5-11

Condition Description

Cylinder removed from engine.

Materials/Parts

Diesel fuel oil (Item 2, Appendix E)

Dry cleaning solvent (Item 10, Appendix E)

General Safety Instructions


Well-ventilated area required.

REMOVAL:

CAUTION

When removing piston, make sure piston or connecting rod does not knock against crankcase. This could result in serious damage to piston or connecting rod.

- 1 Remove and discard circlip (1).
- 2 Press out gudgeon pin (2) far enough to remove gudgeon pin and piston (3) from connecting rod (4).
- 3 Remove piston (3) and gudgeon pin (2).
- 4 Remove and discard circlip (5).



5-12. INSPECT/REPAIR/REPLACE PISTON (Continued)


DISASSEMBLY:

- 1 Remove gudgeon pin (2) from piston (3) using gudgeon pin extractor 614 957 00 if necessary.



Piston ring breakage may occur if rings are opened more than necessary when removing or installing them. Do not strain rings.

- 2 Remove piston ring set (6) from piston (3) with piston ring pliers 612 090 00.



CLEANING:

WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138°F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean piston (3) and gudgeon pin (2) with dry cleaning solvent and dry with compressed air.
- 2 Remove carbon from piston ring lands and grooves.
- 3 Clean inside surface of piston and piston skirt.
- 4 Clean gudgeon pin bore.

5-12. INSPECT/REPAIR/REPLACE PISTON (Continued)



INSPECTION:

- 1 Inspect piston, piston skirt, and piston grooves for excessive wear and damage. Replace damaged piston.

NOTE

Excessively worn pistons, rings, or cylinders may be an indication of abnormal maintenance procedures or operating conditions. Check for and correct any abnormalities.

- 2 Examine piston (1) for scoring, fretting, pitting, cracks (especially on the interior surfaces), damaged ring grooves (2) or lands (3), or for indications of overheating. Repair slight scoring according to repair procedure. Replace damaged piston.
- 3 If piston is badly worn or damaged, check cylinder for excessive out-of-round, high spots, or other damage in accordance with paragraph 5-11.
- 4 Measure piston diameter (1) along axes A and B. A normal or new piston diameter should be 2.8724 inches (72.96 mm). If piston is out-of-round, replace piston.




5-12. INSPECT/REPAIR/REPLACE PISTON (Continued)

5 Measure piston compression ring groove (1) width. Measurement should be 0.0826 to 0.0843 inch (2.100 to 2.143 mm). If measurement is greater than 0.0843 inch (2.143 mm), replace piston.

6 Measure piston ring groove (2) width. Measurement should be 0.0811 to 0.0908 inch (2.060 to 2.310 mm). If measurement is greater than 0.0908 inch (2.310 mm), replace piston.

7 Measure piston oil control ring groove (3) width. Measurement should be 0.1582 to 0.1599 inch (4.020 to 4.060 mm). If measurement is greater than 0.1599 inch (4.060 mm), replace piston.



WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138° F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

- 8 If any ring groove width measurements are smaller than the minimum values given above, piston ring grooves may be clogged with carbon deposits. Clean piston with dry cleaning solvent. Dry with compressed air. Take measurements again.
- 9 Inspect gudgeon pin for scoring, fretting, pitting, or indications of overheating. If severely damaged, replace gudgeon pin.

REPAIR:

Remove slight scoring or fretting on piston. Clean and repeat procedure if necessary.

5-12. INSPECT/REPAIR/REPLACE PISTON (Continued)


ASSEMBLY:

- 1 If cylinder has been replaced, piston must also be replaced.



Piston rings are marked TOP and should be installed as marked. Piston ring breakage may occur if rings are opened more than necessary when removing or installing them. Do not strain rings.

- 2 If piston replacement is necessary, piston rings must also be replaced.
- 3 Install piston rings with piston ring pliers 612 090 00. Install oil control ring (1), cast iron compression ring (2), and chrome compression ring (3) in order. Be careful not to strain rings by opening them too wide during installation. Make sure that the piston ring gaps are equally spaced around the piston 120 degrees from each other.




- 4 Install new circlip (1) in lip groove of piston (3) gudgeon bore.



When installing piston, make sure piston or connecting rod do not knock against crankcase. This could result in serious damage to piston or connecting rod.

- 5 Insert connecting rod (4) into bottom of piston (3). Make sure that opening of combustion chamber is on the flywheel side.
- 6 Insert gudgeon pin (2) into piston (3) gudgeon bore and through rod bushing of connecting rod (4). Push in gudgeon pin until it contacts installed circlip (1) and stops.
- 7 Install new circlip (5).



5-13. INSPECT/REPLACE/REPAIR FLYWHEEL (Continued)

CLEANING/INSPECTION:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean flywheel thoroughly with diesel fuel oil. Use wire brush if necessary.
- 2 Dry flywheel with compressed air.
- 3 Inspect flywheel for cracks, rust, corrosion, or other damage.
- 4 Replace damaged or cracked flywheel.
- 5 Clean blower ring thoroughly with diesel fuel oil. Use a soft-bristle brush to clean blower ring blades.
- 6 Dry blower ring with compressed air.
- 7 Inspect blower ring for cracks, rust, corrosion, or other damage.
- 8 Check for damaged, chipped, or broken blower blades.
- 9 If blades are damaged, cracked, or chipped, replace blower ring.

5-13. INSPECT/REPLACE/REPAIR FLYWHEEL (Continued)

REPAIR:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

- 1 Smooth out nicks or burrs on flywheel and blower ring. Remove rust or corrosion, then clean with diesel fuel oil.
- 2 Dry with compressed air.

INSTALLATION:

- 1 Align blower ring (9) holes with mounting holes on flywheel (1).
 - 2 Install three spring washers (8) and three screws (7).
 - 3 Using socket 612 099 00, tighten screws to 22.13 foot-pounds (30 N·m).
 - 4 Install four screws (5) and spring washers (6) through flywheel (1) and into engine crankshaft.
 - 5 Restrain flywheel.
 - 6 Tighten screws to 51.6 foot-pounds (70 N·m).
 - 7 Take restraint off flywheel. Make sure flywheel turns freely.
 - 8 Install stub shaft (4), with three spring washers (3) and three screws (2).
 - 9 Install engine adapter housing.
-

5-14. INSPECT/REPLACE/REPAIR FRAME ASSEMBLY (FRAME, RAILS, AND SHOCK MOUNTS)

This task covers: a. Removal c. Repair
 b. Inspection d. Installation

INITIAL SETUP

Tools

Shop set, automotive repair,
field maintenance, basic

Materials/Parts

Dry cleaning solvent (Item 10, Appendix E)
Zinc chromate primer coating (Item 9,
Appendix E)

Equipment Condition

Para	Condition Description
4-12, 4-13	Pump assembly removed from pump case.
4-14	Pump case removed from engine.
5-5	Engine removed from frame.

General Safety Instructions


Well-ventilated area required.

REMOVAL:

- 1 Remove two cap screws (1), lock washers (2), and washers (3).
- 2 Remove left rail (5) from frame (7).
Remove two shock mounts (4).
- 3 Remove two cap screws (1), lock washers (2), and washers (3).
- 4 Remove right rail (6) from frame (7).
Remove two shock mounts (4).

INSPECTION:


- 1 Inspect left rail (5), right rail (6), and frame (7) for dents, rust, corrosion, structural damage, broken welds, or warpage.
- 2 If damaged or warped, or if welds are broken, repair.



5-14. INSPECT/REPLACE/REPAIR FRAME ASSEMBLY (FRAME, RAILS, AND SHOCK MOUNTS) (Continued)

REPAIR:

- 1 Remove helicoil insert (8) from frame (7) by using a scribe or other pointed instrument. Pry the last thread of helicoil insert in toward center of tapped hole. Grasp thread with needlenosed pliers. Remove damaged helicoil insert by threading out of hole.
- 2 Chase threaded hole using appropriate size tap.



WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138°F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.


- 3 Using dry cleaning solvent and a stiff-bristled brush, clean threaded hole thoroughly.
- 4 Using clean compressed air at 30 psi (2.06 bar) maximum discharge pressure, blow out threaded hole to make sure that all solvent has been removed and no particles are left in the hole.
- 5 If frame has broken welds, chip away all loose material before reworking welds.
- 6 Coat new helicoil insert (1) with zinc chromate primer.

5-14. INSPECT/REPLACE/REPAIR FRAME ASSEMBLY (FRAME, RAILS, AND SHOCK MOUNTS) (Continued)

- 7 Install helicoil insert to a depth of 1 to 1.5 pitches below the surface of the tapped hole in the frame (7). Wipe off excess primer.
- 8 Remove drive tang from installed helicoil insert (8).

INSTALLATION:

- 1 Install two shock mounts (4) in right rail (6).
- 2 Install two washers (3), lock washers (2), and cap screws (1) through right rail (6) and into frame (7).
- 3 Tighten cap screws (1) securely.
- 4 Install two shock mounts (4) in left rail (5).
- 5 Install two washers (3), lock washers (2), and cap screws (1) through left rail (5) and into frame (7).
- 6 Tighten cap screws (1) securely.



CHAPTER 6 INTERMEDIATE GENERAL SUPPORT MAINTENANCE INSTRUCTIONS

Section I. TROUBLESHOOTING

No troubleshooting procedures are required.

Section II. MAINTENANCE PROCEDURES

INDEX

	Para		Para
Camshaft	6-4	Governor	6-5
Connecting rod	6-3	Oil seal	6-6
Crankcase	6-8	Timing cover	6-4
Crankshaft	6-7	Valves	6-2
Cylinder head and valve assembly	6-2		

6-1. GENERAL INSTRUCTIONS

Most maintenance instructions in this section will list resources required, personnel required, and equipment condition for the start of the procedure. Note the following:

- Resources required are not listed unless they apply to the procedure.
- Personnel required are listed only if the task requires more than one. If PERSONNEL is not listed, it means one person can do the task.
- The normal standard equipment condition to start a maintenance task is engine stopped. EQUIPMENT CONDITION is not listed unless some other condition is required.
- Refer to Appendix F to determine torque requirements when tightening threaded fasteners, unless a specific torque value is given in procedure. Standard torque values given in Appendix F are determined by thread size.

6-2. REPAIR CYLINDER HEAD AND VALVE ASSEMBLY

This task covers: a. Cleaning/Inspection c. Test
 b. Repair

INITIAL SETUP

Tools

- Shop set, automotive repair, field maintenance, basic
- Clamping holder to grind valve-valve seat
604 581 00
- Valve reseating tool, 42.5 mm dia
612 103 00
- Guiding pin, 7 mm dia (valve reseating tool)
612 104 00
- Hand reamer, 7 mm dia (valve guide)
612 107 00
- Press-in mandrel, 7 mm dia (valve guide)
669 347 00
- Handle for valve reseating tool
670 323 00

Materials/Parts

- Diesel fuel oil (Item 2, Appendix E)
- Lapping and grinding compound, 600 grit (Item 5, Appendix E)

Equipment Condition

Para	Equipment Condition
5-5	Injector removed from cylinder head.
5-7	Cylinder head removed from engine. Rocker and valves removed from cylinder head.

General Safety Instructions

Well-ventilated area required.

CLEANING/INSPECTION:




Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean cylinder head with a clean cloth dampened with diesel fuel oil. Use wire brush where necessary. Dry with compressed air.
- 2 Inspect cylinder head for cracks, rust, corrosion, and excessive heat damage. Inspect for accumulated carbon.

6-2. REPAIR CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

3 Replace cylinder head if any of the following conditions exist: if the cylinder contact surface is roughened, not level, and cannot be repaired; if the valve seats are so worn that recutting is no longer possible; if contact surface for cylinder head cover is rough or damaged; or if there are cracks between the valve seats.



4 Check that the inside diameter of each valve guide does not exceed 0.2780 inch (7.059 mm).

5 Check that valve seat angle does not exceed 45 degrees.


6 Clean valves with diesel fuel oil and dry with compressed air.

7 Inspect valves for warpage, burning, or other damage.

8 Inspect valve stems for scratches, scuff marks, or other damage.

9 Inspect valve tulips, faces, and heads for pitting, ridges, or cracks.

10 Check that each valve stem diameter is not less than 0.2716 inch (6.95 mm).



11 Check that each valve head diameter is not less than 1.200 inches (30.5 mm).


REPAIR:

1 If the inside diameter of a cylinder head valve guide (1) exceeds 0.2780 inch (7.059 mm), replace valve guide. Press out valve guide using mandrel 669 347 00.

2 From cylinder head bottom, push valve guide (1) out of cylinder head (2). Insert new valve guide (1) into cylinder head (2). Install new valve guide by pressing in with mandrel 669 347 00. Minimum inserting pressure is 220 inch-pounds (245 cm·kg).


3 Ream the inside diameter of the valve guide to 0.2756/0.2759 inch (7.000/7.009 mm) using hand reamer 612 107 00.

4 Repair defective cylinder head valve seats by recutting with a 45 degree valve seat cutter. Recut valve seats with valve reseating tool 612 103 00, guiding pin 612 104 00, and handle for valve reseating tool 670 323 00. Cut until valve seat is absolutely clean.



6-2. REPAIR CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

- 5 The cylinder contact surface of the cylinder head can be repaired by machining. Remove up to a maximum of 0.0196 inch (0.5 mm) of metal provided the minimum valve recession is maintained.
- 6 Replace any valves that show head warping, burning, or other damage.
- 7 Replace valves that have seriously scratched or scuffed stems, or pitted, ridged, or cracked tulips faces, or heads.
- 8 Replace valves that have a valve head diameter of less than 1.200 inch (30.5 mm).
- 9 Remove slight scratches or scuff marks.
- 10 If the cylinder head valve seats were recut, lap the valves by using tool 604 581 00 and 600 grit lapping and grinding compound.



- 11 After lapping valves check valve recession.




The valve recession must not be less than 0.018 inch (0.45 mm), otherwise valve head may touch piston.

The valve recession shall be a maximum of 0.0275 inch (0.70 mm) and a minimum of 0.0180 inch (0.45 mm).

TEST:

- 1 Insert valve (1) into cylinder head (2).
- 2 Install cap (3) over valve (1) stem.
- 3 Install washer (4) on cap (3).
- 4 Install spring (5) on washer (4).
- 5 Insert cup (6) into spring (5).
- 6 Install two collets (7) into cup (6) and over valve (1) stem.
- 7 Press down on collets (7) and cup (6) until spring (5) compresses and collets (7) are locked in slot in valve (1) stem.



6-2. REPAIR CYLINDER HEAD AND VALVE ASSEMBLY (Continued)

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

- 8 Check proper fit of valves by pouring fuel into intake and exhaust ports. Observe for leakage at valve seats. A valve fits properly if no fuel trickles through.
-

6-3. REPAIR/REPLACE CONNECTING ROD

This task covers: a. Removal c. Repair
 b. Inspection d. Installation

INITIAL SETUP

Tools

Shop set, automotive repair,
field maintenance, basic
Allen socket, 6 mm
612 091 00

Materials/Parts

Diesel fuel oil (Item 2, Appendix E)
Dry cleaning solvent (Item 10, Appendix E)
Lubricating oil (Item 6, Appendix E)

References

Para 5-11 Cylinder
Para 6-7 Crankshaft Assembly
MIL-I-6868 Magnetic Particle Inspection

Equipment Condition

Para	Condition Description
5-12	Piston removed from engine.

General Safety Instructions

Well-ventilated area required.


REMOVAL:

- 1 Using Allen wrench, remove cover (1) with four caps (2) and Allen screws (3).
- 2 Remove and discard preformed packing (4).

CAUTION

When removing connecting rod, make sure it does not knock against crankcase. This could result in serious damage to connecting rod.

- 3 Using Allen socket 612 091 00, remove two Allen screws (5) and remove bottom half of connecting rod (6).
- 4 Remove top half of connecting rod (7) from top of crankcase.
- 5 Remove two bearing halves (8) from both halves of connecting rod (6 and 7).



6-3. REPAIR/REPLACE CONNECTING ROD (Continued)

INSPECTION:


WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138°F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean connecting rod components with dry cleaning solvent. Remove any carbon deposits with a wire brush. Clean inside surface of rod bushing (9), both connecting rod halves (6 and 7), and bearing (8). Blow compressed air through the drilled oil passage in connecting rod to clean connecting rod and rod bushing.


- 2 Visually inspect connecting rod for bending, warping, cracking, rust, or other damage. Check for cracks using MIL-I-6868 magnetic particle inspection. Replace if twisted or bent. Grind or replace if indications of cracks are revealed by magnetic particle inspection.



- 3 Measure and record rod bushing (9) inside diameter. Measure at points 1 and 2 along axes A and B. Measurements should be 0.9951 to 0.9858 inch (25.225 to 25.040 mm). If any measurement is outside these limits, replace rod bushing.
- 4 Inspect upper and lower bearing halves (8) for excessive wear, scoring, pitting, flaking, etching, and signs of overheating. Inspect bearing backs for bright spots (bearing moving in supports).
- 5 Temporarily assemble connecting rod with two new Allen screws and without bearings. Using a torque wrench, tighten screws to 29.50 foot pounds (40 N-m). Apply some oil to threads and contact surfaces.
- 6 Measure inside diameter of connecting rod, bearing bore. Measurement should be 1.8114 to 1.8107 inches (46.010 to 45.994 mm). If measurement is outside specified limits, replace connecting rod.

6-3. REPAIR/REPLACE CONNECTING ROD (Continued)

- 7 Disassemble connecting rod and carefully insert bearing halves (8). The bottom half has a hole which fits into connecting rod cup. Reassemble connecting rod with two Allen screws. Tighten screws following procedures described in preceding step 5.
- 8 Measure inside diameter of bearing. Measure at points 1 and 2 along axes A and B. Measurements should be 1.6541 to 1.6525 inches (42.016 to 41.974 mm).
- 9 If any measurement is outside the tolerance limits, replace the bearing. Make sure that measurements at points 1 and 2 are not different nor outside the tolerance limits, indicating that bearing is wearing in a conical shape.
- 10 Make sure measurements along axes A and B are not different nor outside the tolerance limits, indicating the bearing is wearing in an oval shape.
- 11 If bearing is out-of-round, replace it. Follow procedure described in paragraph 6-8. Also check cylinder and piston for unusual wear. Follow procedures described in paragraphs 5-11 and 5-12.




REPAIR:

WARNING

Dry cleaning solvent P-D-680 (safety or Stoddard's Solvent) is potentially dangerous. Avoid repeated and prolonged breathing of vapors and skin contact with the liquid. Do not use near open flame, arcing equipment, or other ignition sources. Always wear eye protection and protective clothing. The flash point of P-D-680 is 100° to 138°F (38° to 59°C).

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.



- 1 Clean rod bushing (9) and connecting rod (7) bore with dry cleaning solvent and dry with compressed air.

6-3. REPAIR/REPLACE CONNECTING ROD (Continued)

- 2 Inspect rod bushing for scoring, overheating, or other damage. Replace if damaged.
- 3 Measure outside diameter of rod bushing. Measurement should be 1.1042 to 1.1037 inches (28.048 to 28.035 mm). If measurement is outside specified limits, replace rod bushing.
- 4 Measure inside diameter of connecting rod bushing bore. Measurement should be 1.1028 to 1.1024 inches (28.013 to 28.000 mm). If measurement is outside specified limits, replace connecting rod.

CAUTION

Be certain that the numbers on both halves of the connecting rod match.

NOTE

Clean rust preventive from replacement connecting rod. Also make sure bearing bore is thoroughly cleaned to prevent trapped contaminants from adversely affecting bearings.

- 5 If required, clamp connecting rod in a padded vise and install new rod bushing (9) into connecting rod bushing bore.

INSTALLATION:

CAUTION

Be certain that bearing halves are installed correctly. The bottom bearing half (8) has a hole which fits into lower connecting rod half (6).

- 1 Carefully insert bearing halves (8) into connecting rod.

CAUTION

Be certain that the numbers on both halves of the connecting rod match.

When installing connecting rod, make sure it does not knock against crankcase. This could result in serious damage to connecting rod.

- 2 Install top half of connecting rod (7) on crankshaft.
 - 3 Install bottom half of connecting rod (6) (with dipper opening to dipstick side) and Allen screws (5). Using a torque wrench and Allen socket, tighten screws to 29.50 foot-pounds (40 N·m).
 - 4 Lubricate preformed packing (4) with lubricating oil and install into cover (1).
 - 5 Install cover (1) with four caps (2) and Allen screws (3).
-

6-4. REPAIR/REPLACE TIMING COVER AND CAMSHAFT

This task covers: a. Removal c. Disassembly e. Assembly
 b. Cleaning d. Repair f. Installation

INITIAL SETUP

Tools

Shop set, automotive repair,
field maintenance, basic

Auxiliary bush, timing cover oil seal
(30 x 47 mm)
666 075 00

Extractor, cam follower spindle
666 324 00

Mounting device, camshaft needle bearing
666 418 00

Punch, camshaft needle bearing
666 425 00

Materials/Parts

Diesel fuel oil (Item 2, Appendix E)

Equipment

Condition

Para

Condition Description

4-18

Lift pump removed.

5-8

Injection pump removed.

5-9

Crank handle and gears removed.

6-3

Connecting rod removed from
engine.

General Safety Instructions

Well-ventilated area required.

REMOVAL:



CAUTION

**Lift both cam followers from camshaft when removing
timing cover to prevent bending by cam points.**


- 1 Remove six screws (1) and joints (2) and remove timing cover (3) and camshaft (13).

NOTE

**Insertion of Allen screws in timing cover holes may aid in
removal of timing cover.**

- 2 Matchmark two teeth of camshaft gear and one tooth of crankshaft gear to make sure of proper alignment of gearing when reinstalling timing cover.

6-4. REPAIR/REPLACE TIMING COVER AND CAMSHAFT (Continued)



- 3 Remove and discard gasket (4).
- 4 Remove plastic plug above injection pump, and remove Allen setscrew from crankcase.
- 5 Remove spindle (5), cam followers (6 and 7), and shim (8) from crankcase using cam follower spindle extractor 666 324 00.

6-4. REPAIR/REPLACE TIMING COVER AND CAMSHAFT (Continued)

CLEANING:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean timing cover with diesel fuel and dry with compressed air.
- 2 Inspect all components for damage or excessive wear. Replace any components severely damaged or worn.
- 3 Inspect surface of cam followers. If damaged, replace cam followers.
- 4 Inspect needle bearing (20). If damaged, replace in accordance with repair procedures.

DISASSEMBLY:

- 1 Remove oil seal (9) from timing cover (3).
- 2 Collapse dry bushing (10) and remove.

WARNING

Handling heated parts can cause severe burns. Use proper equipment to handle heated parts.

- 3 Using an oven, heat timing cover to 120° to 160°F (50° to 70°C). Remove intermediate ring (11) and drive out ball bearing (12).
- 4 While timing cover is still hot, drive out camshaft (13).
- 5 Remove hexagon nut (14), spring washer (15), circlip (16), flanged wheel (17), roller bearing (18), and spacer (19).

6-4. REPAIR/REPLACE TIMING COVER AND CAMSHAFT (Continued)

REPAIR:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. **DO NOT SMOKE.**

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Reclean with diesel fuel and dry with compressed air.
- 2 Repair any minor damage, nicks, burrs, rust, or corrosion.
- 3 If needle bearing (20) is damaged, remove using camshaft needle bearing punch 666 425 00.
- 4 Replace new needle bearing (20) using camshaft needle bearing mounting device 666 418 00.

ASSEMBLY:


- 1 Assemble spacer (19), roller bearing (18), flanged wheel (17), circlip (16), spring washer (15), and hexagon nut (14) onto camshaft (13).

WARNING

Handling heated parts can cause severe burns. Use proper equipment to handle heated parts.

- 2 Using an oven, heat timing cover (3) to 120° to 160° F (50° to 70° C). Drive in new ball bearing (12) and install new intermediate ring (11).
- 3 While timing cover is still hot, drive in camshaft (13).
- 4 Drive in new dry bushing (10).
- 5 Using timing cover oil seal auxiliary bush 666 075 00, install new oil seal (9).

6-4. REPAIR/REPLACE TIMING COVER AND CAMSHAFT (Continued)



INSTALLATION:

- 1 Install timing cover (3).

NOTE

Make sure matchmarks on camshaft gear and crankshaft gear are aligned.

- 2 Install six screws (1) and joints (2).

6-5. REPAIR/REPLACE GOVERNOR

This task covers: a. Removal c. Installation
 b. Cleaning

INITIAL SETUP

Tools

Shop set, automotive repair,
field maintenance, basic

Extractor for gear, crankshaft
603 823 00

Impact mandrel, gear on crankshaft
666 069 00

Special tool for governor spring
618 305 00

References

Para 6-7 Crankshaft

Equipment Condition

Para	Condition Description
------	-----------------------

6-4	Timing cover and camshaft re- moved from engine.
-----	---

General safety Instructions

Well-ventilated area required.

Materials/Parts

Diesel fuel oil (Item 2, Appendix E)


Grease (Item 3, Appendix E)

Lubricating oil (Item 6, Appendix E)

REMOVAL:

- 1 Remove gearwheel (1) from crankshaft using crankshaft gear extractor 603 823 00.
- 2 Remove pins (2 and 3) from shaft (16).
- 3 Remove threaded pin (4) and hex nut (5) from governor lever (6).
- 4 Remove two hexagon nuts (7) and lever (8).
- 5 Remove hexagon nut (9) and friction disc (10).
- 6 Remove capsule (11), hex nut (12), plate (13), and eccentric pin 14). Discard preformed packing (15).
- 7 Press out shaft (16) from crankcase.

6-5. REPAIR/REPLACE GOVERNOR (Continued)



6-5. REPAIR/REPLACE GOVERNOR (Continued)

- 8 Remove spring washer (17) and discard two preformed packings (18).
- 9 Remove governor lever (6) and governor spring (19) from crankcase.
- 10 Pull sliding disc (20) and ball shell (21) from crankshaft.

NOTE

Ball hub disc (23), ball hub (24), and spacer (25) are removed when the crankshaft is removed. Refer to paragraph 6-7 for instructions.

CLEANING:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean all parts with diesel fuel oil and dry with compressed air.
- 2 Inspect all components for damage or excessive wear. Replace any components severely damaged or worn.

INSTALLATION:

- 1 If any of the four balls (22) were removed during disassembly, apply grease to four balls (22) and install balls in ball hub (24).

CAUTION

Ball shell (21) must slide easily over the crankshaft. Damage to crankshaft and governor could result from improper fitting of governor parts.

- 2 Slide ball shell (21) and sliding disc (20) onto crankshaft.
- 3 Lubricate preformed packing (15) with lubricating oil and install in preformed packing groove on eccentric pin (14).

6-5. REPAIR/REPLACE GOVERNOR (Continued)

- 4 Install eccentric pin (14), plate (13), hex nut (12), and capsule (11) into crankcase.
- 5 Mount governor spring (19) on governor lever (6) and install both parts into crankcase.

NOTE

The loop hole of the governor spring should point upward.

- 6 Lubricate two preformed packings (18) with lubricating oil and install in preformed packing grooves on shaft (16).
- 7 Slide spring washer (17) on shaft (16) and install shaft into crankcase.

CAUTION

Governor lever and shaft should move freely. Do not overtighten threaded pin and lock lever on shaft. (Snug pin to bottom and unscrew 1/2 turn.)

- 8 Drive pins (2 and 3) through shaft until approximately 0.125 inch (3.21 mm) of roll pins protrude through reverse side of shaft (16). Using special tool 618 305 00, loop ends of governor spring over drive pins (2 and 3).
- 9 Drive pins (2 and 3) in shaft (16) until flush with shaft.
- 10 Screw threaded pin (4) into governor lever (6) and tighten hexagon nut (5).
- 11 Install friction disc (10), hex nut (9), lever (8), and two hexagon nuts (7) on shaft (16).

WARNING

Handling heated parts can cause severe burns. Use proper equipment to handle heated parts.

- 12 Using an oven, heat gearwheel (1) to 160° to 175°F (70° to 80°C). Install gearwheel onto crankshaft using impact mandrel 666 069 00.
-

6-6. REPLACE OIL SEAL (FLYWHEEL SIDE) (Continued)

CLEANING/INSPECTION:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.


Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean oil seal components with diesel fuel and dry with compressed air.
- 2 Inspect all components for damage or excessive wear. Replace any components severely damaged or worn.

INSTALLATION:

- 1 Install auxiliary bush 666 068 00 in crankshaft.
 - 2 Install oil seal (5) into support (1).
 - 3 Fill groove of oil seal (5) with grease.
 - 4 Lubricate new preformed packing (4) with grease and install it in preformed packing groove in support (1).
 - 5 Install support (1) onto crankshaft with two security plates (2) and four hex screws (3).
 - 6 Remove auxiliary bush 666 068 00.
-

6-7. REPLACE CRANKSHAFT (Continued)



6-7. REPLACE CRANKSHAFT (Continued)

- 3 Remove counterweight (13) by removing two Allen screws (14).

WARNING

Handling heated parts can cause severe burns. Use proper equipment to handle heated parts.

- 4 Using a torch, heat roller bearing inner races (15 and 16) and remove them from crankshaft (1).

CLEANING/INSPECTION:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air always use chip guards, eye protection, and other personal protective equipment.

- 1 Clean crankshaft components with diesel fuel and dry with compressed air. Clean oil passages with a stiff wire brush.
- 2 Inspect all components for damage or excessive wear. Replace any components severely damaged or worn.

ASSEMBLY:

- 1 Install new cover (12).
- 2 Apply lubricating oil to the threads of two Allen screws (14) and contact surface of counterweight (13). Install counterweight and two Allen screws. Torque Allen screws to 16.23 foot-pounds (22 N·m).

WARNING

Handling heated parts can cause severe burns. Use proper equipment to handle heated parts.

3. Using an oven, heat the inner races of roller bearings (15 and 16) to 160° to 175°F (70° to 80°C) and press them onto crankshaft (1).

6-7. REPLACE CRANKSHAFT (Continued)

INSTALLATION:

- 1 Install circlip (4) into roller bearing outer race (5) and, press bearing race into crankcase until it comes to a stop at the circlip.
- 2 Push roller bearing outer race (3) onto crankshaft (1).
- 3 Install crankcase end play mounting device 666 074 00 on crankshaft.

WARNING


Handling heated parts can cause severe burns. Use proper equipment to handle heated parts.

- 4 Using an oven, heat crankcase (1) to 175° to 210°F (80° to 100°C).
- 5 Push in crankshaft (1) and crankcase end play mounting device 666 074 00 until mounting device stops. Allow crankcase to cool. Remove mounting device.
- 6 Using an oven, heat ball hub disc (6), ball hub (7), and spacer (8) to 160° to 175°F (70° to 80°C).
- 7 Install spacer (8), ball hub (7), and ball hub disc (6) onto crankshaft using ball hub impact mandrel 666 067 00.

NOTE

Balls (9), ball shell (10), and sliding disc (11) are governor components. Refer to paragraph 6-5 for instructions on installation of these parts.

6-8. REPAIR/REPLACE CRANKCASE (Continued)



6-8. REPAIR/REPLACE CRANKCASE (Continued)

CLEANING/INSPECTION:

WARNING

Death or serious injury could occur if fuel is not handled carefully. Use in a well-ventilated area away from open flame, arcing equipment, ignition sources, heaters, or excessive heat. Always store fuel in proper, marked containers. DO NOT SMOKE.

Death or serious injury could occur if compressed air is directed against the skin. Do not use compressed air for cleaning or drying unless the pressure is/has been reduced to 30 psi (2.06 bar) or less. When working with compressed air, always use chip guards, eye protection, and other personal protective equipment.

Live steam used for cleaning shall not exceed 100 psi (6.9 bar). Use goggles or face shield for eye protection. Do not direct live steam against skin.

- 1 Clean crankcase thoroughly with live steam. Clean all exterior openings and surfaces. Be especially sure to clean all oil passages to make sure they are clear. Use a small and/or large wire bristle brush where necessary to remove carbon or other deposits from openings and surfaces. Use diesel fuel as necessary to soften and remove carbon or hardened oil deposits. Dry with compressed air.
- 2 Inspect crankcase for any cracks, discoloration, distortion, rust, corrosion, or other damage. Use MIL-I-6868 magnetic particle inspection to detect cracks. If crankcase is cracked, distorted, overheated, seriously rusted or corroded on machined surfaces, or exhibits other serious damage, replace crankcase.
- 3 Inspect two studs (9), two studs (10), and two studs (11) for thread damage. If damaged, replace studs.

REPAIR/ASSEMBLY:

- 1 Lubricate joint (8) with lubricating oil and install on oil drain plug (7). Install oil drain plug.
 - 2 Install cylinder pin (6).
 - 3 If damaged, remove two studs (10) and two studs (11) and install new studs.
 - 4 If damaged, remove two studs (9) and install new studs.
 - 5 Lubricate preformed packing (5) with lubricating oil and install on cap screw (4). Install cap screw.
 - 6 Lubricate preformed packing (3) with lubricating oil and install on oil dipstick (1). Install oil dipstick into crankcase (2).
-

APPENDIX A REFERENCES

A-1. PUBLICATIONS INDEX

The following index should be consulted frequently for latest changes or revisions of references given in this appendix and for new publications relating to material covered in this manual.

Index of Administrative Publications DA PAM 310-1

A-2. FORMS AND RECORDS

Recommended Changes to Publications and Blank Forms DA 2028-2
Equipment Inspection and Maintenance Worksheet DA Form 2404
Equipment Control Record DA Form 2408-9
Packaging Improvement Report DD Form 6
Quality Deficiency Report SF 368

A-3. FIELD MANUALS

Operation and Maintenance of Ordnance Materiel in Cold Weather (0° to -65°F) FM 9-207

A-4. TECHNICAL MANUALS

The Army Maintenance Management System (TAMMS) DA PAM 738-750
Stock List 4 SL-4-08922A
Equipment Records and Procedures TM 4700
Hand Portable Fire Extinguishers for Army Users TM 5-4320-200-10
Organizational, Direct Support and General Support
Maintenance Repair Parts and Special Tools List,
Centrifugal Pump Unit, 125 GPM TM 5-4320-304-24P

A-5. OTHER PUBLICATIONS

Marine Corps Incentive Awards Program MCO 1650.17
Report of Item and Package Discrepancies MCO 4430.3
Marine Corps Warehousing MCO 4450.7

A-6. MILITARY SPECIFICATIONS

Treatment and Painting of Materiel MIL-T-704

APPENDIX B MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

B-1. MAINTENANCE ALLOCATION CHART (MAC)

a. *General.* This MAC assigns maintenance functions in accordance with the Three Level Maintenance concept. The three levels are depicted on the MAC as:

UNIT level - corresponds to an O code in the Repair Parts and Special Tools List (RPSTL). A C code entry under UNIT denotes maintenance performed by the crew or operator within UNIT maintenance.

INTERMEDIATE level - corresponds to an F code in the RPSTL.

DEPOT level - corresponds to a D code in the RPSTL.

b. *Unit Maintenance.* Maintenance to be performed in the Unit level is described as follows:

(1) Unit Maintenance activities are staffed and equipped to perform high frequency on-equipment maintenance tasks required to retain or return equipment to a serviceable condition. These tasks include preventive maintenance and repair and replace functions associated with a high level of mission capability.

(2) Unit Maintenance inspection and servicing include daily (usually performed by operator or crew), periodic, and special inspections, as authorized by the MAC or higher headquarters.

(3) Unit level maintains a Combat Prescribed Load List (PLL) which consists of items on the Mandatory Parts List (MPL) and items which are demand supported.

(4) Unit level performs troubleshooting, replace, and limited repair functions as authorized by the MAC, RPSTL, and applicable technical manuals.

c. *Intermediate Maintenance.* Maintenance to be performed in the Intermediate level is described as follows:

(1) One stop maintenance support through use of mobile weapon system oriented maintenance teams to perform authorized maintenance (that exceeds Unit level capability) to effect quick repair and return to user capabilities.

(2) Maintains a Combat Authorized Stockage List (ASL), Mandatory Parts List (MPL), Direct Exchange (DX), and provides limited Operational Readiness Float (ORF) for supported units.

(3) Provides collection, classification, and recovery services for serviceable and unserviceable materiel and maintains a Battle Damage Assessment (BDA) capability.

(4) Provides maintenance support for the theater supply system through repair of components and DX items.

(5) Provides maintenance units composed of commodity oriented platoons which may be augmented by support teams that deploy forward if the tactical situation permits.

(6) Maintains Operational Readiness Float (ORF) stocks in support of the theater.

d. *Depot Maintenance*. Depot level functions are authorized as indicated by entries in the Depot (D) Maintenance level column (4) in the MAC.

B-2. USE OF THE MAINTENANCE ALLOCATION CHART, SECTION II

a. The MAC assigns maintenance functions based on the following considerations:

- (1) Skills available.
- (2) Work time required.
- (3) Tools and test equipment required and/or available.

b. If a lower level of maintenance identified in column (4) of the MAC cannot perform all tasks of a single maintenance function (e.g., test, repair), then the higher level that can perform other tasks of that function is also indicated.

c. Higher maintenance levels are automatically authorized to perform maintenance functions assigned to a lower maintenance level.

d. Higher maintenance levels will perform the maintenance functions of lower maintenance levels when required or directed by the Commander who has authority to direct such tasking.

e. Assignment of a maintenance function in the MAC does not carry automatic authorization to carry the related spare or repair parts in stock. Information to requisition or secure parts will be as specified in the associated RPSTL.

f. Normally, there will be no deviation from the assigned level of maintenance. However, in cases of operational necessity, maintenance functions assigned a higher level may, at the request of the lower level, be assigned to the lower level on a one-time basis, if specifically authorized by the maintenance officer of the higher level to which the function is assigned. In such a case, the special tools, equipment, etc., required by the lower level to perform this function will be furnished by the higher level assigned the function. Also, transfer of a function to a lower level does not relieve the higher level of responsibility for the function, so the higher level will provide technical supervision and inspection of the function being performed at the lower level.

B-3. MAINTENANCE FUNCTIONS

Maintenance functions will be limited to and defined as follows:

a. *Inspect*. Two levels of inspect are covered in the MAC.

(1) When prescribed at the C or O element of Unit Maintenance level, inspect means to determine serviceability by comparing an item's physical, mechanical, and/or electrical characteristics with established standards through examination (i.e., by sight, sound, or feel). These inspections are included in preventive maintenance (PM) checks and services, such as PMCS, PMD.

(2) When prescribed at the Intermediate (F) or Depot (D) maintenance level, inspect refers to an initial inspection which is conducted prior to scheduling any repair on repairable items evacuated to this level. This inspection is made to determine whether an item qualifies for repair or discard.

b. *Test*. To verify serviceability and detect incipient failure by measuring the mechanical or electrical characteristics of an item and comparing those characteristics with prescribed standards.

c. *Service*. Operations required periodically to keep an item in proper operating condition, i.e., to clean (includes decontaminate), to preserve, to drain, or to replenish fuel, lubricants, hydraulic fluids, or compressed air supplies.

d. *Adjust*. To maintain within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to the specified parameters.

e. *Align*. To adjust specified variable elements of an item to bring about optimum or desired performance.

f. *Calibrate*. To determine and cause corrections to be made or to be adjusted on instruments or test measuring and diagnostic equipment used in precision measurement. Consists of comparison of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

g. *Install*. The act of emplacing, seating, or fixing into position an item, part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

h. *Replace*. The act of substituting a serviceable like type part, a subassembly, or module (component or assembly) for an unserviceable counterpart.

i. *Repair*. The application of maintenance services (inspect, test, service, adjust, align, calibrate, or replace) or other maintenance actions (welding, grinding, riveting, straightening, facing, remachining, or resurfacing) to restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

j. *Overhaul*. That maintenance effort (service/action) necessary to restore an item to a completely serviceable operational condition as prescribed by maintenance standards in appropriate technical publications (i.e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to a like new condition.

k. *Rebuild*. Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of materiel maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc.) considered in classifying Army equipment/components.

B-4. EXPLANATION OF COLUMNS IN THE MAC, SECTION II

a. *Column (1), Group Number*. Column 1 lists functional group code numbers which are assigned to identify maintenance significant components, assemblies, subassemblies, and modules to their next higher assembly.

b. *Column (2), Component/Assembly*. Column 2 contains the item names of components, assemblies, subassemblies, and modules for which group numbers (column 1) are assigned and for which maintenance is authorized.

c. *Column (3), Maintenance Function*. Column 3 lists the functions to be performed on items listed in column 2. (Function definitions are contained in paragraph B-3.)

d. *Column (4), Maintenance level*. The maintenance levels. Unit, Intermediate, and Depot, are allotted separate subcolumns within column 4. Entry of a work time figure (such as 1.0, 0.2) in a subcolumn indicates that that level is authorized to perform the function listed in column 3, and the

average time required to do the function is the work time figure. If the number or complexity of tasks within a maintenance function varies from one maintenance level to another, the applicable work time figure for each level will be entered for that function. The work time figure represents the average time it takes to restore a component/assembly to a serviceable condition under a typical field operating environment.

e. *Column (5), Tools and Equipment.* Column 5 specifies, by code, common tool sets (not individual tools from those sets), common TMDE, and special tools, TMDE, and support equipment required to perform a designated function. The code in Column 5 keys to the listing in Section III of the MAC.

f. *Column (6), Remarks.* This column, when applicable, contains a letter code which is keyed to an explanation of the code contained in Section IV of the MAC.

B-5. EXPLANATION OF COLUMNS IN THE MAC, SECTION III

a. *Column (1), Tool or Test Equipment Reference Code.* The tool or test equipment reference code correlates with a code used in the MAC, Section II, Column 5.

b. *Column (2), Maintenance Category.* The lowest category of maintenance authorized to use the tool or test equipment.

c. *Column (3), Nomenclature.* Name or identification of the tool or test equipment.

d. *Column (4), National/NATO Stock Number.* The national stock number of the tool or test equipment.

e. *Column (5), Tool Number.* The manufacturer's part number.

B-6. EXPLANATION OF COLUMNS IN THE MAC, SECTION IV

a. *Column (1), Reference Code.* The code recorded in Column 6, Section II.

b. *Column (2), Remarks.* This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

Section II. MAINTENANCE ALLOCATION CHART
CENTRIFUGAL PUMP UNIT (WATER) 125 GPM - Continued

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Eqpt	(6) Remarks
			Unit		Intermediate	Depot			
			C	O	F	H	D		
00	Centrifugal Pump Unit								
01	Pump Assembly								
	Check Valve	Inspect Replace Repair		0.1 1.0 0.5				1 1	
	Volute	Inspect Replace	0.1	1.0				1	
	Impeller	Inspect Replace		0.5 1.0				1,2	
	Wear Plate	Inspect Replace		0.5 1.0				1	
	Shaft Seal	Inspect Replace		1.0 1.0				1,2	
	Adapter Shaft	Inspect Replace		1.0 1.5				2,3	B
02	Pump Case Assembly								
	Pump Case	Inspect Replace Repair	0.1	1.0	3.0			2	
03	Air Filter Assembly	Inspect Service Replace Repair	0.1 0.5	.5 .5				1	C,F
04	Engine Assembly	Inspect Service Replace	0.2 0.2		2.0			2	

Subcolumns are as follows:
 F – DIRECT SUPPORT;

C – OPERATOR/CREW;
 H – GENERAL SUPPORT;

O – ORGANIZATIONAL;
 D – DEPOT

CENTRIFUGAL PUMP UNIT (WATER) 125 GPM - Continued

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Eqpt	(6) Remarks
			Unit		Intermediate	Depot			
			C	O	F	H	D		
05	Fuel System								
	Fuel Filter	Inspect Replace	0.1	0.5				1, 2	C, E
	Fuel Lines, Hoses, and Fittings	Inspect Replace	0.1	0.5				1, 2	
	Fuel Lift Pump	Replace Repair		0.5	1.5			1, 2	B
	Fuel Tank	Inspect Service Replace	0.2 0.2	1.0				4	B
	Injector	Inspect Test Replace		1.0	1.0 1.0			4, 8	B, G
	Injection Pump	Inspect Adjust Test Replace		0.1	0.1 2.0 1.0			4, 35	B, E
06	Exhaust System								
	Muffler	Inspect Replace	0.1	0.3				1, 2	
07	Crank Assembly								
	Gears	Inspect Replace			0.5 1.0				
	Handle	Inspect Replace	0.1	0.1					
08	Throttle								
	Throttle Control Hand Lever	Inspect Adjust Replace	0.1	0.5 0.5				1, 2	A

Subcolumns are as follows:
 F – DIRECT SUPPORT;

C – OPERATOR/CREW;
 H – GENERAL SUPPORT;

O – ORGANIZATIONAL;
 D – DEPOT

CENTRIFUGAL PUMP UNIT (WATER) 125 GPM - Continued

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Eqpt	(6) Remarks
			Unit		Intermediate	Depot			
			C	O	F	H	D		
09	Cylinder Head and Cylinder Assembly								
	Cylinder Head and Valve Assembly	Inspect Adjust Replace Repair		1.0	0.1 3.0		3.0	4, 7, 14, 16, 17, 18, 23, 36, 37	A, B, H, I
	Cylinder	Inspect Replace			0.1 3.0			7	B
	Piston	Inspect Repair Replace			1.0 3.0 3.0			5, 11, 12, 19, 20, 31	B, J
10	Crankcase Assembly								
	Connecting Rod	Inspect Repair Replace				1.0 3.0 3.0		13, 23	B, J
	Timing Cover	Inspect Repair Replace				0.2 1.0 3.0		28	B
	Camshaft	Inspect Repair Replace				1.0 4.0 4.0		6, 14, 21, 29, 32, 33	
	Governor	Inspect Repair Replace				1.0 4.5 4.5		22, 24	
	Flywheel	Inspect Replace Repair			1.0 2.0 0.5			15	B
	Oil Seal (Flywheel Side)	Inspect Replace				1.0 2.0		25	B

Subcolumns are as follows:
F – DIRECT SUPPORT;

C – OPERATOR/CREW;
H – GENERAL SUPPORT;

O – ORGANIZATIONAL;
D – DEPOT

CENTRIFUGAL PUMP UNIT (WATER) 125 GPM - Continued

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Eqpt	(6) Remarks
			Unit		Intermediate	Depot			
			C	O	F	H	D		
11	Crankshaft	Inspect Replace				1.0 5.0		6, 26, 27, 28	
	Crankcase	Inspect Replace Repair				1.0 5.0 2.0			
	Frame Assembly								
	Frame	Inspect Replace Repair	0.2		2.5 1.0			1, 2 4	D
	Rails	Inspect Replace	0.2		0.5			1, 2	
	Shock Mount	Inspect Replace	0.2		0.5			3	

Subcolumns are as follows:
 F – DIRECT SUPPORT;

C – OPERATOR/CREW;
 H – GENERAL SUPPORT;

O – ORGANIZATIONAL;
 D – DEPOT

Section III. TOOL AND TEST EQUIPMENT REQUIREMENTS

(1) Tool or Test Equipment Ref Code	(2) Maintenance Category	(3) Nomenclature	(4) National/ NATO Stock Number	(5) Tool Number
1	O	Tool Kit, General Mechanics Automotive	5180-00-177-7033	
2	O, F, H	Tool Kit, General Mechanics (USMC)	4910-00-754-0654	
3	O	Shop Equipment, Automotive Maintenance and Repair, Common No. 1	4910-00-754-0654	
4	F, H	Shop Set, Automotive Repair, Field Maintenance, Basic	4910-00-754-0705	
5	F	Measuring device for bumping clearance		603 114 00
6	H	Extractor for gear - crankshaft		603 823 00
7	H	Clamping holder to grind valve - valve seat		604 581 00
8	F	Testing device for injection equipment		604 628 00
9	F, H	Spill device		604 837 00
10	F, H	Special wrench		606 000 00
11	F, H	Dial gage (1/100 - 58 mm dia)		612 087 00
12	F	Piston ring pliers		612 090 00
13	H	Allen socket, 6 mm		612 091 00
14	O, F, H	Allen socket, 8 mm		612 095 00
15	F, H	Socket for screw with internal serrations		612 099 00
16	H	Valve reseating tool, 42,5 mm dia		612 103 00
17	H	Guiding pin, 7 mm dia (valve reseating tool)		612 104 00

(1) Tool or Test Equipment Ref Code	(2) Maintenance Category	(3) Nomenclature	(4) National/ NATO Stock Number	(5) Tool Number
18	H	Hand reamer, 7 mm dia H 7 (valve guide)		612 107 00
19	F	Retaining bracket for cylinder		612 752 00
20	F	Gudgeon pin extractor		614 957 00
21	H	Extractor for gear - crankshaft		618 168 00
22	H	Special tool for governor spring		618 305 00
23	O	Box wrench, 10 mm		618 306 00
24	H	Impact mandrel - ball hub		666 067 00
25	H	Auxiliary bush - oil seal (60 x 75 mm dia) support flywheel side		666 068 00
26	H	Impact mandrel - gear on crankshaft		666 069 00
27	H	Mounting device - crankshaft end play		666 074 00
28	H	Auxiliary bush - oil seal (30 x 47 mm dia) timing cover		666 075 00
29	H	Extractor - cam follower spindle		666 324 00
30	H	Crankshaft removing device		666 327 01
31	F	Piston ring clamp		666 346 00
32	H	Mounting device - needle bear- ing camshaft		666 418 00
33	H	Punch - needle bearing camshaft		666 425 00
34	F	Socket wrench, 30 mm		668 335 00
35	F, H	Fuel shutoff clamp		668 383 00
36	H	Press-in mandrel - valve guide, 7 mm dia		669 347 00
37	H	Handle for valve reseating tool		670 323 00

(1) Reference Code	(2) Remarks
A	Adjust to specifications
B	Repair by replacing defective components
C	Replace element
D	Weld
E	Repair by bleeding air from fuel system
F	Service by cleaning filter
G	Test timing and pressure output
H	Includes replacing valve seats, guides, and main bearings
I	Includes replacing bearing, valves, and gears
J	Includes replacing rings and rod bearings
K	Includes crankshaft grinding

APPENDIX C COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS

Section I. INTRODUCTION

C-1 . SCOPE

This appendix lists components of end item and basic issue items for the centrifugal pump unit to help you inventory items required for safe and efficient operation.

C-2. GENERAL

The Components of End Item and Basic Issue Items Lists are divided into the following sections:

a. *Section II. Components of End Item.* This listing is for informational purposes only, and is not authority to requisition replacements. These items are part of the end item, but are removed and separately packaged for transportation or shipment. As part of the end item, these items must be with the end item whenever it is issued or transferred between property accounts. Illustrations are furnished to assist you in identifying the items.

b. *Section III. Basic Issue Items.* These are the minimum essential items required to place the centrifugal pump unit in operation, to operate it, and to perform emergency repairs. Although shipped separately packaged, BII must be with the centrifugal pump unit during operation and whenever it is transferred between property accounts. The illustrations will assist you with hard-to-identify items. This manual is your authority to request/requisition replacement BII, based on TOE/MTOE authorization of the end item.

C-3. EXPLANATION OF COLUMNS

The following provides an explanation of columns found in the tabular listings.

a. *Column (1) – Illustration Number (Illus Number).* This column indicates the number of the illustration in which the item is shown.

b. *Column (2) – National Stock Number.* Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

c. *Column (3) – Description.* Indicates the Federal item name and, if required, a minimum description to identify and locate the item. The last line for each item indicates the FSCM (in parentheses) followed by the part number.


d. *Column (4) – Unit of Measure (U/M).* Indicates the measure used in performing the actual operational/maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr).

e. *Column (5) – Quantity Required (Qty Rqr).* Indicates the quantity of the item authorized to be used with/on the equipment.

Section II. COMPONENTS OF END ITEM

NOT APPLICABLE

Section III. BASIC ISSUE ITEMS



(1) Illus Number	(2) National Stock Number	(3) Description FSCM and Part Number	Usable On Code	(4) U/M	(5) Qty Rqr
1		TM 5-4320-304-14 HANDLE, STARTING (61080) 003 150 00		1	1

APPENDIX D
ADDITIONAL AUTHORIZATION LIST

NOT APPLICABLE

APPENDIX E
EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

E-1. SCOPE

This appendix lists expendable/durable supplies and materials you will need to operate and maintain the centrifugal pump unit. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

E-2. EXPLANATION OF COLUMNS

a. *Column (1) – Item Number.* This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., Dry Cleaning Solvent, item 11, Appendix E).

b. *Column (2) – Level.* This column identifies the lowest level of maintenance that requires the listed item.

- C – Operator/Crew
- O – Organizational Maintenance
- F – Direct Support Maintenance
- H – General Support Maintenance

c. *Column (3) – National Stock Number.* This is the National stock number assigned to the item; use it to request or requisition the item.

d. *Column (4) – Description.* Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the part number followed by Federal Supply Code for Manufacturer (FSCM) in parentheses.

e. *Column (5) – Unit of Measure (U/M).* Indicates the measure used in performing the actual maintenance function. If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
1	F		Color, Marking (Dykem)	
2	C, O, F, H		Fuel Oil, Diesel, VV-F-800	gal
3	H	9150-00-190-0907	Grease, Automotive and Artillery, MIL-G-10924	5 gal can
4	O	9150-00-754-2595	Grease, Ball and Roller Bearing, MIL-G-18709	1 gal can
5	H		Lapping and Grinding Compound (Valve), 600 grit, A-A-1203	
6	O, F, H	9150-00-186-6681	Oil, Lubricating, Internal Combustion Engine, MIL-L-2104	qt
7	O		Oil, Lubricating, Preservative, MIL-L-21260	qt
8			Preservative Oil, MIL-P-116, Type P-14	qt
9	F		Primer Coating, Zinc Chromate, TT-P-1757	
10	O, F, H	6850-00-274-5421	Solvent, Dry Cleaning, P-D-680	5 gal can

**APPENDIX F
 TORQUE LIMITS**

Self-Locking Nut Breakaway Torque Values

Thread Size	Minimum Breakaway Torque (In. Lbs.)	Thread Size	Minimum Breakaway Torque (In. Lbs.)
10-32	2.0	5/8-18	32.0
1/4-28	3.5	3/4-16	50.0
5/16-24	6.5	7/8-14	70.0
3/8-24	9.5	1-12	90.0
7/16-20	14.0	1-1/8-12	117.0
1/2-20	18.0	1-1/4-12	143.0
9/16-18	24.0		

NOTE

To determine breakaway torque, thread nut onto screw or bolt until at least two threads stick out. Nut shall not make contact with a mating part. Stop the nut. Torque necessary to begin turning nut again is the breakaway torque. Do not reuse self-locking nuts that do not meet minimum breakaway torque.

GLOSSARY

Section I. ABBREVIATIONS

°c	Degree Celsius
cm·kg	Centimeter-kilogram
cu	Cubic
ea	Each
EIR	Equipment Improvement Recommendations
°F	Degree Fahrenheit
ft	Foot; feet
ft-lb	Foot pound
gal	Gallon
gpm	Gallons per minute
hp	Horsepower
in.	Inch
kg	Kilogram
lb	Pound
m ³	Cubic meter
m·kg	Meter-kilogram
mm	Millimeter
N·m	Newton-meter
NPT	National pipe thread
oz	Ounce
PMCS	Preventive maintenance checks and services
psi	Pounds per square inch
q t	Quart
rpm	Revolutions per minute
TDC	Top dead center
TMDE	Test, measurement, and diagnostic equipment

Section II. DEFINITION OF UNUSUAL TERMS

A

ABRASION – A scraped or scuffed area. A hose may become abraded if an unshielded portion of it rubs against a piece of bracket or another hose.

ALIGN – To arrange in a line vertically and/or horizontally.

APPROVED – Permitted to be used for a specific purpose by the person or group who is authorized to grant approval.

ARC – A discharge of electric current crossing a gap between two electrodes.

ASSEMBLY – A combination of parts that may be taken apart without destruction, which has no application or use of its own but is needed for the completeness of a more complex item with which it is combined, or to which it is attached.

B

BRINNELLED – A deformation of a bearing by an impact.

BUMPING CLEARANCE – Clearance between cylinder head and top of piston. Measured with piston at TDC (top dead center).

C

CAPACITY – The volume, amount, or quantity that can be held or contained.

CARBON MONOXIDE – A poisonous gas that is made while a fuel is burning, especially if there is not quite enough air. The gas is colorless, odorless, and tasteless, but it can cause illness or death. See the warnings on the Warning page at front of manual.

CAVITATION - Condition caused when engine speed is increased beyond point of maximum suction vacuum. Cavitation is indicated by loud cracking noise in pump housing and is harmful to the pump unit.

CHAMFER – A beveled edge.

COMBUSTION – A chemical change, especially oxidation, accompanied by the production of heat and light. A combustion engine functions by burning fuel to produce heat, i.e., energy.

COMPONENT – A part or a combination of parts which together accomplish a function.

COMPRESSED AIR – Air that is under pressure. When the compressed air in a hose or pipe is allowed to escape (such as when you use an air gun), the air moves very fast and is used to blow away dirt and chips for cleaning.

CONDENSATION – A liquid formed from a vapor. Moisture carried in warm air will condense when it reaches a cold area, such as the surface of a fuel tank in subzero weather.

CORROSION – A gradual wearing away caused by chemical action. Metals exposed to salt water are likely to corrode.

D

DEBRIS – The scattered remains of something broken or destroyed.

DEFLECT – To bend or move from a straight line.

DETER 10 RATE – A worsening of condition usually as a result of age or hostile environment, as opposed to mechanical damage.

DIAMETRIC – Measurement across the center.

DISPLACEMENT – The volume displaced by a piston in a single stroke.

DISTORTION – The bending, twisting, or any other dynamic change of a surface.

E

EXHAUST – The gases that leave the engine through the tailpipe while the engine is running.

EXPENDABLE – An item that is not repairable and is discarded if damaged.

EXPOSURE - Being in the presence of something, or in contact with something. Skin is exposed to cleaning solvent when the solvent contacts the skin during cleaning operations.

F

FILTER – A device which removes dirt from the air or a fluid.

FLASH POINT – The lowest temperature at which the vapors of a solvent will ignite and burn.

FLUID – A substance that can flow; that is, either a gas or a liquid.

FRAYED – Something which has been worn away or unravelled, usually by rubbing.

FRETTING - A wearing away or corroding of an area.

G

GASKET – A seal or packing used between matched machine parts or around pipe joints to prevent the escape of gas or fluid.

GOGGLES – A device used to protect the eyes from dust, dirt, flying chips, etc.

GUDGEON PIN –A pivot pin.

I

IMMERSE – To completely cover by fluid.

INHALATION – The act of breathing in. The breathing in or inhalation of carbon monoxide can cause illness or death.

INITIAL – The first or starting condition.

L

LEGIBLE – Capable of being read. A legible nameplate can be read; an illegible plate cannot.

M

MALFUNCTION – Occurs when a unit fails to operate normally.

MANUFACTURER - The company which makes an item or piece of equipment for sale.

MATERIEL – Equipment, apparatus, and supplies of an organization such as an army.

O

OBSTRUCTION – An obstacle.

P

PIVOT – A short rod or shaft about which a related part rotates; the act of turning on or as if on a pivot.

PORT – A threaded hole through which fluid may pass, or pressure may be measured. Ports on the pump are used to connect hoses, and to measure pressure.

PRIME - The act of introducing a liquid into a pump to increase the pump's ability to overcome negative head pressure.

R

RACE – A grooved part of a component, such as a bearing, in which a moving part slides or rolls

RECOMMENDATIONS – Suggestions for change; advice given usually to make an improvement.

REQUIRE – To demand or need.

RESPIRATION – The process of breathing; inhaling and exhaling.

S

SATURATED – Soaked or drenched with a liquid.

SCOPE – The extent of an activity or concept; the amount of information covered as in a book.

SCRIBE – Sharp pointed tool.

SEDIMENT – Matter that settles to the bottom of a liquid.

SOLVENT – A liquid that can dissolve another substance.

SYMPTOM – The external sign or indication of a condition.

T

TIEDOWN – Strap or fastening device used to hold an object in position.

TORQUE – Force around an axis. It produces a rotary or twisting motion, and is measured in foot-pounds (ft-lb) or meter-kilograms (m·kg).

V

VALVE – A device used to control the flow of a fluid.

VAPOR – The gaseous form of any substance which is usually a liquid; vapors are present in the air around the substance.

VENTILATE – To provide with a source of fresh or uncontaminated air.

VISUAL – Visible; detected by the unaided eye.

VOLUTE – Housing into which impeller discharges water.

- (A) OPERATOR/CREW same as (USMC) 1st Echelon
- (A) ORGANIZATIONAL same as (USMC) 2nd Echelon
- (A) DIRECT SUPPORT same as (USMC) 3rd Echelon
- (A) GENERAL SUPPORT same as (USMC) 4th Echelon
- (A) DEPOT same as (USMC) 5th Echelon

ALPHABETICAL INDEX

Subject, Para

A

Abbreviations, 1-6
Adapter Shaft, 4-13
Adjustments
 Cylinder Head Clearance, 5-10
 Decompression Mechanism, 4-22, 5-10
 Fuel Injection Timing, 5-8
 Speed, 2-4
 Tappet Clearance, 4-22, 5-10
Administrative Storage, 4-24
Air Cleaner, 4-15
Air Filter, 3-4, 4-15
Assembly and Preparation for Use, 2-3

C

Camshaft, 6-4
Capabilities and Features, Centrifugal
 Pump Unit, 1-9
Capacities, Equipment Data, 1-12
Centrifugal Pump Unit
 Capabilities, 1-9
 Characteristics, 1-8
 Features, 1-9
 Principles of Operation, 1-13
 Purpose, 1-7
Characteristics, Centrifugal Pump Unit, 1-8
Check Valve Assembly, 4-12
Checking Engine Oil, 3-2
Checks and Services, Preventive Maintenance
 Operator's, 2-2
 Organizational, 4-8
Clearance, Cylinder Head, 5-10
Clearance, Tappet, 4-22, 5-10
Cold, Operation in, 2-6
Common Tools and Equipment, 4-1
Connecting Rod, 6-3
Controls and Indicators, Operator's, T2-1
Cover, Timing, 6-4
Crank Assembly, 5-9
Crankcase, 6-8
Crankcase Breather, 4-33
Crankshaft, 6-7
Cross-Reference List, Nomenclature, 1-5
Cylinder, 5-11
Cylinder Head and Valve Assembly, 4-22, 5-10, 6-2
Cylinder Head Clearance, 5-10

Subject, Para

D

Data, Equipment, 1-12
Decompression Mechanism, Adjustment of,
 4-22, 5-10
Description of Major Components, 1-10
Differences Between Models, 1-11
Dimensions and Weight, 1-13
Direct Support Maintenance
 Maintenance Procedures, 5-3
 Troubleshooting, 5-1
Disassembly
 (See Specific Items)
Dusty Areas, Operation in, 2-9

E

Electrical System Assembly, 4-15
Engine Accessories, Equipment Data, 1-12
Engine Assembly, 5-5
Engine, Equipment Data, 1-12
Engine Shutdown Valve, 4-35
Equipment
 Common, 4-1
 Data, 1-12
 Improvement Recommendations, 1-3
 Inspecting, 4-5
 Preliminary Servicing and Adjustment of, 4-7
 Support, 4-2
 Unloading, 4-4
Extreme Heat, Operation in, 2-7

F

Filter, Fuel, 4-17
Fittings, Fuel, 4-17
Flywheel, 5-13
Forms, Maintenance, 1-2
Frame Assembly, 5-14
Fuel
 Filter, 4-17
 Injection Pump, 5-8
 Injectors, 5-7
 Lift Pump, 4-18, 5-6
 Lines, Hoses, and Fittings, 4-17
 Tank, 4-19
Fuel Injection Timing, Adjustment of, 5-8

Subject, Para

G

Gears, Crank Assembly, 5-9
General Support Maintenance Procedures, 6-1
Governor, 6-5

H

High Altitudes, Operation in, 2-8
Humid Conditions, Operation Under, 2-10

I

Identification Plates, 2-5
impeller, 4-13
Index, Symptom
 Direct Support Maintenance, 5-2
 Organizational Maintenance, 4-10
Injection Pump, 5-8
Injectors, Fuel, 5-7
Inspecting Equipment, 4-5
Inspection
 (See Specific Items)
Installation
 (See Specific Items)
Instructions, Setup, 4-6
Intermediate Term Storage, 4-26

L

Lift Pump, Fuel, 4-18,5-6
Limited Warranty, 1-4
Lines, Fuel, 4-17
Location of Major Components, 1-10
Lubrication, 3-2

M

Maintenance Forms, Records, and Reports, 1-2
Maintenance, Preventive
 Operator's, 2-2
 Organizational, 4-8
Maintenance Procedures
 Direct Support, 5-3
 General Support, 6-1
 Operator, 3-4
 Organizational, 4-11
Major Components, Location and
 Description of, 1-10
Muffler, 4-20

N

Nomenclature Cross-Reference List, 1-5

Index 2

Subject, Para

O

Oil
 Filler, 4-16
 Seal, 6-6
Operating Procedure, 2-4
Operation
 in Cold, 2-6
 in Extreme Heat, 2-7
 in High Altitudes, 2-8
 in Salt Water Areas, 2-11
 in Sandy or Dusty Areas, 2-9
 Technical Principles of, 1-13
 Under Rainy or Humid Conditions, 2-10
 Under Usual Conditions, 2-3
Operator
 Controls and Indicators, T2-1
 Maintenance Procedures, 3-4
 Preventive Maintenance Checks and
 Services, 2-2
 Troubleshooting, 3-3
Organizational Maintenance
 Maintenance Procedures, 4-11
 Preventive Maintenance Checks and
 Services, 4-8
 Troubleshooting, 4-9

P

Painting, 3-1
Piston, 5-12
Preliminary Servicing and Adjustment of
 Equipment Setup, 4-7
Preparation for
 Starting, 2-4
 Storage and Shipment, 4-23
 Use, 2-3
Preventive Maintenance Checks and Services
 Operator's, 2-2
 Organizational, 4-8
Priming Centrifugal Pump, 2-4
Principles of Operation, 1-13
Procedures, Maintenance
 Direct Support, 5-3
 General Support, 6-1
 Operator, 3-4
 Organizational, 4-11
Pump
 Case Assembly, 4-14, 5-4
 Equipment Data, 1-12
 Fuel Injection, 5-8
 Fuel Lift Pump, 4-18, 5-6
Pumping Rate, Adjusting, 2-4

Subject, Para

Subject, Para

R

Rainy Conditions, Operation Under, 2-10
Records, Maintenance, 1-2
Removal
 (See Specific Items)
Repair
 (See Specific Items)
Repair Parts, 4-3
Reporting Equipment Improvement
 Recommendations, 1-3
Reports, Maintenance, 1-2

S

Salt Water Areas, Operation in, 2-11
Sandy Areas, Operation in, 2-9
Scope, 1-1
Seal, Oil, 6-6
Setup Instructions, 4-6
Shipment, 4-27
Short Term Storage, 4-25
Special Tools, 4-2
Speed, Adjusting, 2-4
Starting, 2-4
 Preparation for, 2-4
Stopping, 2-4
Storage
 Administrative, 4-24
 Intermediate Term, 4-26
 Preparation for, 4-23
 Short Term, 4-25
Support Equipment, 4-2
Symptom Index
 Direct Support Maintenance, 5-2
 Organizational Maintenance, 4-10

T

Tank, Fuel, 4-19
Tappet Clearance, Adjustment of, 4-22, 5-10
Test
 (See Specific Items)
Throttle Control, 4-21
Timing
 Cover, 6-4
 Fuel Injection, 5-8
Tools
 Common, 4-1
 Special, 4-2
Troubleshooting
 Direct Support, 5-1
 Operator, 3-3
 Organizational Maintenance, 4-9

U

Unloading Equipment, 4-4

V

Valve Assembly, Check, 4-12
Valves, 5-10, 6-2
Volute, 4-13

W

Warning Plates, 2-5
Warranty, Limited, 1-4
Wear Plate, 4-13
Weight and Dimensions, 1-12

By Order of the Secretaries of the Army and the Navy

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

R. L. DILWORTH
Brigadier General, United States Army
The Adjutant General

J. J. WENT
Lieutenant General, USMC
Deputy Chief of Staff for Installations and Logistics

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A, Operator, Unit, and Direct Support and General Support Maintenance. Requirements for Pump Unit, Centrifugal (A52109H).

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)
PFC JOHN DOE
COA, 3d ENGINEER BN
FT. LEONARDWOOD, MD 63108
 DATE SENT

PUBLICATION NUMBER: **TM 5-4320-304-14** PUBLICATION DATE: **16 Sep 87** PUBLICATION TITLE: **Pump Unit, Centrifugal, NSN 4320-01-190-0417**

BE EXACT... PIN-POINT WHERE IT IS				IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:
PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.	
6	2-1 a			<i>In line 6 of paragraph 2-1a the manual states the engine has <u>6</u> cylinders. The engine on my set only has <u>4</u> cylinders. Change the manual to show <u>4</u> cylinders.</i>
B1		4-3		<i>Callout 16 on figure 4-3 is pointing at a <u>bolt</u>. In key to figure 4-3, item 16 is called a <u>shim</u>. Please correct one or the other.</i>
125	line 20			<i>I ordered a gasket, item 19 on figure B-16 by NSN 2 910-00-762-3001. I got a gasket but it doesn't fit. Supply says I got what I ordered, so the NSN is wrong. Please give me a good NSN</i>

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER: **JOHN DOE, PFC (268) 317-7111** SIGN HERE: **JOHN DOE**

DA FORM 2028-2 1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE. DRSTS-M Overprint 1, 1 Nov 80

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



TEAR ALONG PERFORATED LINE

COMMANDER
U S ARMY TROOP SUPPORT COMMAND
ATTN: AMSTR-MCTS
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

COMMANDER
U S ARMY TROOP SUPPORT COMMAND
ATTN: AMSTR-MCTS
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



TEAR ALONG PERFORATED LINE

COMMANDER
U S ARMY TROOP SUPPORT COMMAND
ATTN: AMSTR-MCTS
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



TEAR ALONG PERFORATED LINE

COMMANDER
U S ARMY TROOP SUPPORT COMMAND
ATTN: AMSTR-MCTS
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

The Metric System and Equivalents

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimeter = 10 centimeters = 3.94 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.08 feet
 1 kilometer = 10 hectometers = 3,280.8 feet

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram = 10 decigrams = .035 ounce
 1 dekagram = 10 grams = .35 ounce
 1 hectogram = 10 dekagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 liter = 10 deciliters = 33.81 fl. ounces
 1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	2.540	ounce-inches	newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29.573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	grams	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	newton-meters	1.356	metric tons	short tons	1.102
pound-inches	newton-meters	.11296			

Temperature (Exact)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
----	------------------------	----------------------------	---------------------	----

