

TM 55-4920-226-15

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

**ORGANIZATIONAL, DIRECT SUPPORT,
GENERAL SUPPORT, AND DEPOT MAINTENANCE
MANUAL WITH REPAIR PARTS AND SPECIAL**

TOOL LISTS

TEST STAND, AIRCRAFT, HYDRAULIC

MODEL AHT-5A-1 , TYPE D-5A

FSN 4920-710-6669

**This copy is a reprint which includes current
pages from Change 4**

HEADQUARTERS, DEPARTMENT OF THE ARMY

SEPTEMBER 1964

SAFETY PRECAUTIONS

When handling gasoline, always provide a metal-to-metal contact between the container and tank. This will prevent a spark from being generated as gasoline flows over the metal surfaces.

Do not operate the hydraulic test stand in an inclosed building unless the exhaust gases are piped outside. The exhaust gases contain carbon monoxide, which is a colorless, odorless, and poisonous gas.

Maximum towing speed is 20 mph (miles per hour) over smooth paved surfaces.

When using the handcrank, keep the thumb on the same side of the crank handle as the fingers to avoid injury should the engine kickback. Never attempt to spin the engine with the handcrank.

CHANGE }
No. 4 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., 7 February 1972

Organizational, Direct Support, General Support, and
Depot Maintenance Manual With Repair Parts and Special Tool Lists

TEST STAND, AIRCRAFT, HYDRAULIC
MODEL AHT-5A-1, TYPE D-5A
FSN 4920-710-6669

TM 55-4920-226-15, 8 September 1964, is changed as follows:

Page 2, Table of Content 8. So much of Chapter 11, Section II, as reads "paragraph 215-219" is rescinded.

Page 14. (As added by C3, 17 Jul 67.) Caution is added after paragraph 40.

caution: If CH-47 aircraft are to be serviced, a three-micron filter kit, shall be installed on the test stand, if not already part of the integral test stand system. Reference TM 55-1520-209-20P and -35P manuals for part number of micron filter kit.

Pages 119 and 120. Paragraphs 215 thru 219, including figure 40, are superseded as follows:

(Refer TM 750-244-1-4 for demolition instructions.)

By Order of the Secretary of the Army:

W. C. WESTMORELAND,
General, United States Army,
Chief of Staff.

Official:

VERNE L. BOWERS,
Major General, United States Army,
The Adjutant General.

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31 (qty rqr block no. 94) requirements for Organizational Maintenance Instructions for all Fixed and Rotor Wing Aircraft.

*This change supersedes C3, 17 July 1967.

TECHNICAL MANUAL }
 No. 55-4920-226-15 }

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 WASHINGTON, D. C., 8 September 1964

ORGANIZATIONAL, DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE
 MANUAL WITH REPAIR PARTS AND SPECIAL TOOL LISTS
 TEST STAND, AIRCRAFT HYDRAULIC,
 (MODEL AHT-5A-1, TYPE D-5A)
 FSN 4920-710-6669

	Paragraph	Page
CHAPTER 1. INTRODUCTION		
Section I. General	1,2	3
II. Description and data ..	3-6	3
CHAPTER 2. OPERATING INSTRUCTIONS		
Section I. Service upon receipt of equipment	7-11	9
II. Controls and instruments ..	21-39	11
III. Operation under usual conditions...	40-44	14
IV. Operation under unusual conditions -	45-50	16
CHAPTER 3. OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS		
Section I. Special organizational tools and equipment	-----	17
II. Lubrication	51, 52	17
III. Preventive maintenance services	53,54	19
IV. Troubleshooting	55-68	20
V. Hydraulic system	69-73	22
VI. Running gear assembly	74-76	26
CHAPTER 4. DIRECT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS		
Section I. Special direct and general support maintenance tools and equipment	-----	31
II. Preventive maintenance services	77,78	31
III. Troubleshooting	79-98	33
IV. Radio interference suppression	99-105	35
V. Removal and installation of major components	106-108	38
CHAPTER 5. ENGINE MAINTENANCE INSTRUCTIONS		
Section I. Engine accessories	109-116	42
II. Air shrouding group	117-119	51
III. Manifold and cylinder block group	120-125	54
IV. Oil filler and filter mounting group.....	126-128	61
V. Fuel pump, fuel strainer and fuel tank	129-132	62
VI. Governor and control assembly	133-135	66
VII. Engine controls and instruments	136-138	70

	Paragraph	Page
CHAPTER 6. HYDRAULIC SYSTEM MAINTENANCE INSTRUCTIONS		
Section I. Reservoir and support	139, 140	72
II. Filters and manifold assembly	141-143	74
III. Hydraulic system instruments	144-147	76
IV. Control valves and panel	148-151	77
V. Hydraulic pump	152-157	80
CHAPTER 7. HOUSING AND RUNNING GEAR MAINTENANCE INSTRUCTIONS		
Section I. Housing assembly	158-161	82
II. Wheel and axle assemblies	162-164	84
III. Handbrake assembly	165-167	87
IV. Frame assembly	168-169	88
CHAPTER 8. DEPOT MAINTENANCE INSTRUCTIONS		
Section I. Depot maintenance special tools and equipment.		
II. Troubleshooting	170-181	90
CHAPTER 9. ENGINE MAINTENANCE, INSTRUCTIONS		
Section I. Engine accessories	182-185	92
II. Cylinder block group	186,187	99
III. Gear cover and timing gears	188-190	101
IV. Crankcase bottom plate and oil pump	191-193	103
V. Crankshaft and camshaft group	194-197	105
VI. Cylinder blocks and crankcase	198-200	109
CHAPTER 10. HYDRAULIC SYSTEM AND RUNNING GEAR MAINTENANCE INSTRUCTIONS.		
Section I. Pressure compensator control	201-206	111
II. Hydraulic pump	207-209	115
III. Frame assembly	210-212	118
CHAPTER 11. SHIPMENT AND LIMITED STORAGE AND DEMOLITION OF MATERIAL TO PREVENT ENEMY USE.		
Section I. Shipment and limited storage	213-214	119
II. Demolition of test stand to prevent enemy use.....	215-219	119
APPENDIX I. REFERENCES		121
II. MAINTENANCE ALLOCATION CHART		122
III. REPAIR PARTS LIST		128
INDEX		226

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1. Scope

a. These instructions are published for the information and guidance of operating and maintenance personnel to whom the aircraft hydraulic test stand is assigned. They contain information on operation, lubrication, detailed preventive maintenance services, and maintenance of the equipment, its accessories and auxiliaries; also packing, preservation, storing, and shipping procedures.

b. Supply manuals, technical manuals, lubrication orders, and other publications applicable to the hydraulic test stand are listed in appendix I. Appendix II contains the Maintenance Allocation Chart. Appendix III contains the repair parts lists.

c. The direct reporting by the individual user of errors, omissions, and recommendations for improving this manual is authorized and encouraged. DA Form 2028 will be used for reporting these improvements. This form will be completed in triplicate using pencil, pen, or typewriter. The original and one copy will be forwarded direct to the Commanding General, U. S. Army Aviation Materiel Command, P. O. Box 209, Main Office, St. Louis, Me., 63166.

2. Equipment Records

The Army equipment record system and procedures established in TM 38-750 apply to this equipment. The applicable forms as required by TM 38-750 will be used.

Section II. DESCRIPTION AND DATA

3. Description

a. Hydraulic Test Stand. The aircraft hydraulic test stand consists of a gasoline engine driven, variable volume, variable pressure, axial piston-type hydraulic pump. The necessary controls and instruments are included to select and control the desired phase of operation. The entire unit is trailer mounted for mobility and protected from weather by a housing assembly fitted with hinged doors and access panel. The purpose of the aircraft hydraulic test stand is to perform the following test operations on aircraft hydraulic systems: flush or fill the system with micronically filtered hydraulic fluid, provide a source of hydraulic pressure for testing aircraft hydraulic systems without the necessity of operating the aircraft engine; and test all components of the aircraft hydraulic system, including aircraft with pressurized reservoir systems.


b. Trailer and Running Gear Assembly. The frame assembly (7, fig. 1) is of a welded steel construction furnished with a hinged drawbar assembly (3) suitable for vehicle towing. Individual springs (11) are provided to insure good riding qualities without materially increasing height. A knuckle-type steering apparatus, incorporating tie rods (14, fig. 2) and king pins, is used to provide positive steering. Rear wheels are equipped with mechanical-type parking brakes, set by the brake lever assembly (8, fig. 1) to hold the test stand in a fixed position during test operations. The trailer rolls on pneumatic tires (9). Provisions are made for attaching lifting or tie-down fittings to the frame assembly (7).

c. Engine. The engine is a V-type, 4 cylinder, 4 stroke cycle, air cooled unit. A 6 volt battery is employed to power the starter. Engine speed is held automatically at the selected rpm (revo-

lutions per minute) by a centrifugal fly-weight governor which adjusts the throttle to compensate for changes in engine load. A handcrank, for manually cranking the engine, is secured to the frame in the engine compartment of the test stand. Controls for operating the engine are made accessible by opening the control panel door assembly (1, fig. 1). The front top


door assembly (2), front right door assembly (10), and left front door assembly (1, fig. 2) are opened to gain access to the engine compartment.

d. Hydraulic Reservoir. The hydraulic reservoir is mounted in the upper left rear corner of the housing assembly with the reservoir fill cap (4, fig. 2) extending through the rear top



- | | | |
|-------------------------------|------------------------|------------------------------|
| 1 Control panel door assembly | 5 Front panel assembly | 9 Pneumatic tire |
| 2 Front top door assembly | 6 Thumbscrew | 10 Right front door assembly |
| 3 Drawbar assembly | 7 Frame assembly | 11 Spring |
| 4 Housing assembly | 8 Brake lever assembly | |

Figure 1. Aircraft hydraulic test stand, three-quarter, right front view.



- | | | |
|----------------------------|---|---|
| 1 Left front door assembly | 6 Hose support hook | 11 Dust protective cap, $\frac{3}{4}$ in. |
| 2 Front top door assembly | 7 Coupling half, $\frac{1}{2}$ in. | 12 Dust protective cap, 1 in. |
| 3 Rear top door assembly | 8 Coupling half, $\frac{3}{4}$ in. | 13 Left rear door assembly |
| 4 Reservoir fill cap | 9 Coupling half, 1 in. | 14 Tie rod |
| 5 Rear door assembly | 10 Dust protective cap, $\frac{1}{2}$ in. | |

Figure 2. Aircraft hydraulic test stand, three-quarter, left rear view.

door assembly (3). A reservoir shutoff valve is provided for isolating the test stand reservoir from the hydraulic system when using fluid from the aircraft reservoir or when the test stand is utilized to drain the hydraulic system of the aircraft. Door assemblies (3 and 13) provide access to the reservoir for service and maintenance.

e. Hydraulic Pump. The hydraulic pump incorporates the following features: a pump

volume control providing regulation of pump delivery from 0 to 10 gpm (gallons per minute) at operating pressures ranging from 200 to 5000 psi (pounds per square inch) output, and to 100 psi maximum input: an adjustable compensating control mounted on the control panel, which at the predetermined pressure, reduces pump delivery to the minimum requirement to maintain pressure in the system.




Figure 3. Aircraft hydraulic test stand identification plate.




Figure 4. Engine identification plate.

4. Identification

a. The manufacturer's identification plate (fig. 3), is located in the lower right rear corner of the housing assembly and specifies type, specification, contract number, Federal stock number, manufacturer's part number, serial number, weight, towing speed, and rating of the hydraulic test stand.

b. The engine identification plate (fig. 4), mounted on the engine air shroud inside the engine compartment, specifies the make, model, serial number, and operating instructions of the engine.

5. Deviations in Models

This manual covers only the Sun Electric Corporation, Model AHT-5A-1, Type D5-A. No known unit differences exist for the model covered by this manual.

6. Tabulated Data

a. Aircraft Hydraulic Test Stand.

Manufacturer-----Sun Electric Corporation
Model-----AHT-5A-1

Operating range:

Altitude. ----- Sea level to 6000 ft.
Ambient temperature -----20° F. to 130° F.
Humidity -----95 to 100 percent
Deflection ----- 8½° in any plane from horizontal.

b. Engine.

Manufacturer-----Wisconsin Motor Corp.
Model-----MVG4D
Cycle-----4 stroke
Cylinders-----4
Cooling-----Air
Cylinder bore-----3¼ in. (inch)
Stroke-----4 in.
Piston displacement-----154 cu in (cubic inch)
Horsepower-----36 at 2200 rpm
Firing order-----1-3-4-2

c. Hydraulic Pump.

Manufacturer-----Denisen Engineering Company
Model-----PA072-564X201J
Type-----Axial piston, variable volume
Pressure output-----0 to 6000 psi
Volume output-----0 to 10 gpm

d. Capacities.

Engine crankcase-----5 qt (quart)
Engine fuel tank-----13 gal. (gallon)
Hydraulic reservoir-----26.8 gal.

e. Dimensions and weight.

Overall length -----76 in.
Overall width-----57 in.
Overall height-----53 in.
Weight-----2200 lb. (pound)




Figure 5. Shipping dimensions.

f. *Schematic Hydraulic Diagrams.* The schematic hydraulic diagram covers the complete hydraulic system of the test stand. It is included to aid in diagnosing and correcting malfunctions of the hydraulic system.

g. *Schematic Wiring Diagram.* The schematic wiring diagram illustrated in figure 7 covers the engine electrical system. It is included to aid in the maintenance and repair of the engine electrical system.




Figure 6. Schematic hydraulic diagram.




Figure 7. Schematic wiring diagram.

CHAPTER 2

OPERATING INSTRUCTIONS

Section 1. SERVICE UPON RECEIPT OF EQUIPMENT

7. Unloading and Unpacking of Equipment

a. Unloading.

- (1) Disconnect tie-down straps.
- (2) Where a lifting device of suitable capacity (over 3000 lb.) is available, install lifting eyebolts in the tapped holes provided in the frame, connect cable slings and lift the test stand from the carrier.
- (3) When a lifting device is not available, build a ramp with suitable lumber and tow the test stand off the carrier.

b. Unpacking.

- (1) Remove pressure sensitive tape from seams, doors, panels, screen, and ventilation ducts.
- (2) Remove barrier material from ventilation ducts and screens.
- (3) Remove bags of desiccant from inside test stand housing.
- (4) Remove pressure sensitive tape from all sealed openings.
- (5) Use solvent specification PP-S-661 for removal of preservatives from exterior surfaces of the equipment.

8. Inspection of New Equipment

a. Perform the before-operation services described in paragraph 54.

b. Make a complete visual inspection of the test stand for dents, cracks, breaks, and loose or missing parts. Make sure all components are securely mounted.

c. Inspect control panels for cracked or broken glass and damaged parts.

d. Inspect the tires for cuts, fabric breaks, and excessively worn treads.

e. Correct all deficiencies or report them to organizational maintenance.

9. Servicing New Equipment

a. General. Perform the before-operation services as described in paragraph 54.

b. Lubrication. Lubricate the test stand in accordance with the lubrication chart table I.

c. Fuel System.

- (1) *Filling Fuel Tank.* Remove the fuel tank cap (23, fig. 8) and fill the fuel tank to capacity with the proper grade fuel, specification MIL-G-3056. Use a clean container.


Warning: Always provide a metal-to-metal contact between the container and fuel tank when filling the tank with fuel. This will prevent a spark from being generated as gasoline flows over the metal surfaces.

- (2) *Fuel Strainer.*

- (a) Close the shutoff cock of the fuel strainer (1, fig. 27) by turning its handle fully clockwise.
- (b) Loosen the thumbnut and cup, swing the clamp wire and stud to one side and remove the glass bowl, gasket, and filter screen from the bowl cover.
- (c) Wash the bowl and screen in an approved cleaning solvent and wipe the bowl dry with a lint-free cloth.
- (d) Install the screen, gasket, and bowl in the cover and secure with the clamp wire and the thumbnut.
- (e) Open the shutoff cock and check the fuel strainer for leaks.

d. Battery.

- (1) *General.* The battery (14, fig. 8) of a new test stand is shipped dry charged and must be filled with electrolyte before use. Fill each cell to the level indicator or $\frac{3}{8}$ inch over the plates.



- | | | |
|------------------------------|----------------------------|---------------------------------------|
| 1 Pipe nipple | 9 Reservoir fill cap | 17 V-belting |
| 2 Left front door assembly | 10 Left rear door assembly | 18 Generator adjusting arm |
| 3 Elbow | 11 Low pressure filter | 19 Battery terminal adapter, negative |
| 4 Pipe nipple | 12 Manifold | 20 Battery fill cap |
| 5 Engine accessory generator | 13 Battery tray | 21 Bolt |
| 6 Generator mounting plate | 14 Battery | 22 Battery terminal adapter, positive |
| 7 Shielded cable | 15 Cover assembly | 23 Fuel tank cap |
| 8 Reservoir | 16 Nut (2 rqr) | |

Figure 8. Aircraft hydraulic test stand, left side view.

Warning: Battery electrolyte contains sulfuric acid and can cause severe skin burns. If the electrolyte comes in contact with the body, clothing, or painted surfaces, rinse immediately with clean water.

(2) Removal.

- (a) Disconnect the two battery terminal adapters (19 and 33, fig. 8) from the terminals of the battery (14).
- (b) Remove the 2 hex nuts (16), 2

lockwashers, and 2 flat washers that secure the cover assembly (15) and battery to the battery tray (13) and remove the battery.

(3) Installation.

- (a) Place the battery in the battery tray, mount the cover assembly on the battery and secure with the 2 flat washers, and 2 lockwashers, and 2 hex nuts.
- (b) Clean all corrosion from the battery

terminal adapters and terminals. Apply a thin film of grease to the terminals and adapters and connect the cables to the battery.

e. Tires. Check the tire inflation. Correct tire pressure is 30 psi.

f. Hydraulic System.

(1) Drain the preservative fluid from the system by removing the drain plug from the bottom of the low pressure filter (11, fig. 8).

(2) Install the drain plug. Remove the reservoir fill cap (9) and fill the reservoir with 20 gallons of hydraulic fluid, Specification MIL-O-5606.

Note. Do not overfill the hydraulic reservoir. The expansion space in the reservoir is necessary for satisfactory test stand operation.

(3) Bleed air from the hydraulic system as described in paragraph 70.

10. Inspection of Used Equipment

Inspect a used test stand, following the instructions contained in paragraph 8. Observe carefully the component parts that might be worn through use, such as connecting hose assemblies, tires, brakes, and drawbar assembly. Correct all deficiencies or report them to field maintenance.

11. Servicing Used Equipment

Service a used test stand as outlined in paragraph 9. Pay particular attention to the air cleaner, oil filter, fuel strainer, battery, and tires. Report all deficiencies, found during servicing, to field maintenance for correction.

Section II. CONTROLS AND INSTRUMENTS

12. General

This section describes, locates, illustrates and furnishes the operator with sufficient information pertaining to the various controls and instruments provided for proper operation of the aircraft hydraulic test stand.

13. Brake Lever Assembly

The brake lever assembly (8, fig. 1), mounted on the front of the frame assembly (7), sets the brake shoes in the rear wheels to secure the test stand in position for operation.

14. Reservoir Level Indicator

The reservoir level indicator (2, fig. 9) is located in the upper left-hand corner of the test stand control panel. It indicates the liquid level in the reservoir, reading from 0 to 27 gallons.

15. Reservoir Shutoff Valve

The reservoir shutoff valve (12, fig. 9) located in the lower right-hand corner of the test stand control panel is a gate valve, provided to control the flow of hydraulic fluid from the reservoir to the hydraulic system of the test stand. This valve must be closed when the reservoir of the hydraulic system under test is to be utilized.

16. Fluid Bypass Valve

The fluid bypass valve (27, fig. 9) is located directly below the filter pressure gage (6). It provides a means of directing the fluid discharge from the hydraulic pump into the reservoir. This valve must be open, creating a zero pressure condition, while starting the engine, connecting the test stand to the aircraft under test, and while setting the outlet selector valve.

17. Choke Control


The choke control (5, fig. 10), located on the engine control panel, is a manually operated control that closes the butterfly in the carburetor, enriching the fuel mixture for starting a cold engine.

18. Throttle Control

The throttle control (4, fig. 10), located on the engine control panel, left of the choke control (5), is a push-pull, twist lock control used to set the governor for the desired engine rpm.


19. Ignition Switch

The ignition switch (1, fig. 10) is a double pole throw switch mounted in the upper left-hand corner of the engine control panel. When placed in the OFF position, the ignition switch grounds the magneto and interrupts power to



- | | | |
|-----------------------------|-----------------------------------|-----------------------------|
| 1 Panel | 12 Reservoir shutoff valve | 23 Gage snubber valve |
| 2 Reservoir level indicator | 13 Ammeter | 24 Fluid pressure gage tap |
| 3 Fluid pressure gage | 14 Screw (4 rqr) | 25 Compensator control |
| 4 Fluid temperature gage | 15 Fluid flow indicator | 26 Filter pressure gage tap |
| 5 Screw (3 rqr) | 16 Outlet selector valve | 27 Fluid bypass valve |
| 6 Filter pressure gage | 17 High pressure relief valve | 28 Head temperature gage |
| 7 Screw (2 rqr) | 18 Flat washer (8 rqr) | 29 Fluid volume control |
| 8 Pressure selector valve | 19 Screw (8 rqr) | 30 Screw (4 rqr) |
| 9 Tachometer | 20 Flow control valve, 1/2 in. | 31 Bolt |
| 10 Hourmeter | 21 Flow control valve, 3/4 in. | 32 Bolt (8 rqr) |
| 11 Oil pressure gage | 22 Gage dampener pre-charge valve | |

Figure 9. Controls and instruments, removal points.



- | | |
|-------------------|--------------------|
| 1 Ignition switch | 4 Throttle control |
| 2 Starter switch | 5 Choke control |
| 3 Fuse holder | |

Figure 10. Engine control panel.

the hourmeter, armature relay, and the reservoir level indicator.

20. Starter Switch

The starter switch (2, fig. 10), mounted on the engine control panel, is a spring loaded, push-type switch. When pressed inward, it energizes the armature relay which in turn completes the electrical circuit between the battery and the starter.

21. Tachometer

The tachometer (9, fig. 9), mounted on the test stand control panel, is a needle-indicating, direct-reading instrument graduated from 0 to 3500 rpm in increments of 100 rpm. The tachometer

meter indicates the engine rpm. The normal operating speed is approximately 2200 rpm.

22. Oil Pressure Gage

The oil pressure gage (11, fig. 9), located on the test stand control panel, is a needle-indicating, direct-reading, pressure-actuated gage with the dial marked OFF, XX, and ON. Normal oil pressure is indicated when the needle is between XX and ON ranges.

23. Ammeter

The ammeter (13, fig. 9), mounted on the test stand control panel, is a needle-indicating, direct-reading, electrically actuated instrument. The dial is graduated in a 30-0-30 ampere scale. The ammeter indicates the amount of current flowing to or from the battery. With the engine in operation, the normal reading should be on the charge side of the 0.

24. Head Temperature Gage

The head temperature gage (28, fig. 9), located on the test stand control panel, is a needle-indicating, direct-reading, heat-actuated gage graduated from 0 to 600 degrees fahrenheit. With the engine in operation the needle should be approximately mid-scale.

25. Hourmeter

The hourmeter (10, fig. 9), mounted on the test stand control panel to the right of the head temperature gage (28), is an electrically driven, direct-reading indicator with five numbered wheels, which record engine operating time in hours and tenths of hours. The time recorded is a guide for making operating checks, periodic inspections, and filter cartridge replacements.

26. Flow Control Valves

The ½ in. and ¾ in. flow control valves (20 and 21, fig. 9), located on the left side of the test stand control panel, control the flow of hydraulic fluid to and from the hydraulic test stand. In addition to the valve handles, locking devices are provided to secure the valves in their closed or open position.

27. Fluid Volume Control

The fluid volume control (29, fig. 9), centrally located on the test stand control panel, positions

the cam plate of the pump to obtain the desired volume output. The adjusted output is indicated by the fluid flow indicator (15). A locknut is provided to secure the fluid volume control in its adjusted setting.

28. Fluid Flow Indicator

The fluid flow indicator (15, fig. 9), mounted on the test stand control panel, indicates hydraulic pump delivery. The indicator is calibrated from 0 to 10 gpm.

29. High Pressure Relief Valve

The high pressure relief valve (17, fig. 9), located in the lower left-hand corner of the test stand control panel, is an adjustable, bypass-type relief valve with an operating range from 200 to 5000 psi. This valve serves as a safety device, protecting the hydraulic system under test from excessive pressure. A knurled locknut is provided to secure the valve in adjustment.

30. Compensator Control

The compensator control (25, fig. 9), located directly below the fluid temperature gage (4) on the test stand control panel, is adjusted for the desired discharge pressure of the test stand. A locknut is provided to secure the control in adjustment.

31. Fluid Pressure Gage

The fluid pressure gage (3, fig. 9), mounted on the test stand control panel, is a needle-indicating, direct-reading, pressure actuated gage. The dial is graduated from 0 to 6000 psi in increments of 50 psi. When the test stand is in operation the fluid pressure gage indicates the discharge pressure selected by the compensator control (25).

32. Gage Snubber Valve

The gage snubber valve (23, fig. 9), located below the fluid pressure gage (3) on the test stand control panel, is a needle-type valve provided to admit pressure to the fluid pressure gage.

33. Fluid Pressure Gage Tap

The fluid pressure gage tap (24, fig. 9), extending through the test stand control panel, is provided for the connection of a test pressure

gage to check the accuracy of the fluid pressure gage (3).

34. Filter Pressure Gage

The filter pressure gage (6, fig. 9), mounted on the test stand control panel, is a needle-indicating, direct-reading, pressure and vacuum actuated, compound-type gage. When used in conjunction with the pressure selector valve, the filter pressure gage indicates pressure drop through the low pressure filter. An indicated pressure drop of 20 psi necessitates replacement of the low pressure filter element.

35. Filter Pressure Gage Tap

The filter pressure gage tap (26, fig. 9), extending through the test stand control panel, provides a means of connecting a test gage to check the accuracy of the filter pressure gage (6).

36. Pressure Selector Valve

The pressure selector valve (8, fig. 9), located in the upper right-hand corner of the test stand control panel, is a two-way, plug-type valve utilized to switch the filter pressure gage con-

nection from the inlet to the outlet side of the low pressure filter, thereby determining the condition of the filter element.

37. Gage Dampener Precharge Valve

The gage dampener precharge valve (22, fig. 9), extending through the test stand control panel, is provided to precharge the gage dampener with air to serve as a cushion in the hydraulic system, dampening pulsations.

38. Outlet Selector Valve

The outlet selector valve (16, fig. 9), mounted on the test stand control panel, is a 4-way, plug-type valve, providing a means of selecting either the ½ in. or ¾ in. outlet connections of the test stand.

39. Fluid Temperature Gage

The fluid temperature gage (4, fig. 9), centrally located at the top of the test stand control panel, is a needle-indicating, direct-reading temperature gage graduated from -20 to 240 degrees Fahrenheit in increments of 5 degrees. During operation the indicated fluid temperature should never exceed 160°.

Section III. OPERATION UNDER USUAL CONDITIONS

40. General

Instructions in this section are published for the information and guidance of personnel responsible for operation of the aircraft hydraulic test stand. It is essential that the operator knows how to perform every operation for which the equipment is capable.

41. Starting the Test Stand

a. Preparation for Starting.

- (1) Set the brake lever assembly (8, fig. 1) securing the test stand in position.
- (2) Open the engine compartment and control panel door assemblies.
Caution: Always keep engine compartment top and side doors open during operation.
- (3) Perform the before-operation services outlined in paragraph 54.
- (4) Connect the coupling halves (7, 8, and 9, fig. 2) of the test stand to the cor-

responding outlets of the aircraft to be tested. Keep unused couplings capped with the dust protective caps (10, 11, and 12).

b. Electrical Starting.

- (1) Open the fluid bypass valve (27, fig. 9) by turning the handle fully counterclockwise.
- (2) Pull the choke control (5, fig. 10) out.
- (3) Pull the throttle control (4) to one-quarter open position.
- (4) Place the ignition switch (1) in the ON position.
- (5) Push the starter switch (2) until engine starts.
- (6) Open the choke control until the engine operates smoothly.
- (7) Operate the engine at 1000 to 1400 rpm for approximately 10 minutes to warm engine up to normal operating temperature.

- (8) Set the throttle control (4) for an engine speed of 1800 rpm indicated by the tachometer (9, fig. 9). Rotate the throttle clockwise to lock it in adjustment.

c. Manual Starting.

- (1) Perform procedures in *b* (1) through (4) above.
- (2) Insert the starting crank in the access hole in the front panel assembly (5, fig. 1). Engage the starting crank with the pin provided in the crank shaft and pull up on the crank.

Warning: When using the starting crank, keep the thumb on the same side of the crank handle as the fingers to avoid injury should the engine kickback. Never attempt to spin the engine with the starting crank.

- (3) Open the choke control until the engine operates smoothly.
- (4) After sufficient warm up, set the throttle for an engine speed of 1800 rpm.

42. Stopping the Test Stand

a. Open the fluid bypass valve (27, fig. 9) by turning handle of the valve fully counterclockwise.

b. Close the flow control valves (20 and 21).

c. Idle the engine for 5 minutes to normalize engine temperature.

d. Place the ignition switch (1, fig. 10) in the OFF position and close the reservoir shutoff valve (12, fig. 9).

43. Operating Details

a. Close the two flow control valves (20 and 21, fig. 9).

b. Open the gage snubber valve (23).

c. Adjust the pump delivery to requirements of the aircraft under test with the fluid volume control (29) as indicated by the fluid flow indicator (15). Turn the hand wheel clockwise to

increase delivery, counterclockwise to decrease delivery. Tighten the knurled locknut to secure the fluid volume control in position.

d. Set the outlet selector valve (16) for the desired size outlet.

e. Slowly close the fluid bypass valve (27).

Warning: Do not connect or disconnect any hoses with the fluid bypass valve closed and the test stand in operation.

Caution: Do not reposition the outlet selector valve with the fluid bypass valve closed and the test stand in operation.

f. Adjust the high pressure relief valve (17) to relieve pressure at approximately 200 psi above the system pressure of the unit under test. Clockwise rotation of the relief valve knob increases pressure setting, counterclockwise rotation decreases pressure setting.

g. Adjust the compensator control (25) until the fluid pressure gage (3) indicates pressure slightly higher than the maximum pressure of the system being tested.

Caution: Adjust the compensator control for a zero reading on the fluid pressure gage when the compensator is not in use.

h. Open the flow control valves (20 and 21) and proceed with the test operation as directed by the manufacturer's specifications for the system under test.

44. Movement to a New Work Site

a. Shut down and disconnect the test stand from the system being tested (par. 42). Coil the hose assemblies and stow them in the rear compartment of the test stand.

b. Close and secure all doors and release the brake lever assembly (8, fig. 1).

c. Attach the drawbar assembly (3, fig. 1) to the prime mover and tow the test stand to the new work site.

Caution: Maximum allowable towing speed is 20 mph over smooth paved surfaces.

d. Set up the test stand for operation in accordance with instructions in paragraph 41.

Section IV. OPERATION UNDER UNUSUAL CONDITIONS

45. Operation in Extreme Cold

a. Lubricate the test stand in accordance with the lubrication chart.

b. Keep the electrolyte at the proper level in the battery, and the battery fully charged. If water is added to the battery, run the engine long enough to thoroughly charge the battery.

c. Close engine compartment doors as required to maintain satisfactory engine operating temperature.

d. Remove oil from the air cleaner (par. 52) and replace with the proper grade of oil.

46. Operation in Extreme Heat

a. Locate the test stand in a well ventilated area and keep all door assemblies open during operation.

b. Lubricate the test stand in accordance with the lubrication chart.

c. Keep the engine shrouding, cylinder heads, fins, and the air opening in the housing free of dirt and obstructions.

47. Operation in Dusty or Sandy Areas

a. Lubricate the test stand in accordance with the lubrication chart. Keep lubricants, grease gun, oil containers and fittings clean.

b. Protect the test stand from dust and sand as much as possible. Keep the unit clean and free of foreign matter.

c. Cover the unit with a tarpaulin when not in use.

d. If possible, wet down the area surrounding the operating site to keep down dust and sand.

e. Clean the engine air cleaner every 2 to 4 hours.

48. Operation Under Rainy or Humid Conditions

a. Lubricate the test stand in accordance with the lubrication chart.

b. Keep the fuel tank full to prevent accumulation of condensation.

c. Keep electrical components clean and dry. Watch closely for evidence of fungus growth and remove promptly.

d. Cover the test stand with a tarpaulin or similar protection when not in use.

49. Operation on Salt Water Areas

a. Lubricate the test stand in accordance with the lubrication chart.

b. Wipe all exposed areas frequently. Clean off salt water deposits with clear water and wipe dry.

c. Coat all exposed machined metal surfaces with a thin film of oil.

d. Retouch or repaint damaged paint surfaces to prevent corrosion of exposed metal.

e. Cover the test stand with a tarpaulin or similar protection when not in use.

50. Operation at High Altitude

a. The amount of oxygen delivered to the carburetor is reduced when operating at high altitudes. Reduce the amount of fuel admitted by the carburetor by adjusting the fuel mixture (par. 122).

b. Keep air cleaner clean to assure maximum air passage to the carburetor.

CHAPTER 3
OPERATOR AND ORGANIZATIONAL
MAINTENANCE INSTRUCTIONS

Section I. SPECIAL ORGANIZATIONAL TOOLS AND EQUIPMENT

No special tools or equipment are required to perform organizational maintenance of this aircraft hydraulic test stand.

Section II. LUBRICATION

51. General

This section contains lubrication instructions which are supplemental to and are not specifically covered in the lubrication chart.

52. Detailed Lubrication Information

a. Care of Lubricants. Replace covers on lubricant containers after use and store in a clean, dry place. Keep all containers, used in handling lubricating oil or gasoline, clean and ready for use.

b. Cleaning. Use an approved cleaning solvent to wipe all surfaces clean surrounding the point of application before applying the lubricant.

c. Points of Application. Follow the detailed lubrication instructions given in the applicable maintenance paragraphs and refer to the lubrication chart for type of lubricant and interval of application.


d. Operation After Lubrication. Operate the test stand for 5 minutes immediately after lubrication. Inspect the oil filter for leaks and correct as necessary. Stop the unit, wait 5 minutes, and check the oil level. Add oil to bring the oil level up to the FULL mark if necessary.

e. Oil Filter.

- (1) Loosen the bolt (27, fig. 11) and remove the cover (26) from oil filter (24).

Table 1. Lubrication Chart

Lubricants	Expected Temperatures			Intervals
	Above +32° F.	+40° F to -10° F.	0° F. to -65° F.	
OE—OIL, Engine, Heavy Duty Engine Crankcase Air Cleaner OES—OIL, Engine, Subzero	OE30	OE10	OES	50 hours 50 hours
2190—LUBRICATING OIL, General Purpose Flow Indicator Drawbar Assembly Door Hinges and Latches Engine Generator	2190	2110	2075	50 hours 100 hours 100 hours 100 hours
GAA—GREASE, Automotive and Artillery Wheel Bearings Tie Rod Ends Spindles	All Temperatures			100 hours 100 hours 100 hours



- | | | |
|--|---------------------------|---------------------|
| 1 Breather cap | 11 Carburetor | 21 Ignition magneto |
| 2 Engine control panel | 12 Clamp (4 rqr) | 22 Pipe nipple |
| 3 Nut | 13 Cylinder head shroud | 23 Elbow |
| 4 Nut | 14 Air cleaner assembly | 24 Oil filter |
| 5 Choke control | 15 Thumbscrew | 25 Bolt |
| 6 Throttle control | 16 Ground strap | 26 Cover |
| 7 Spark plug (4 rqr) | 17 Oil cup | 27 Bolt |
| 8 Ignition cable (4 rqr) | 18 Timing hole plug | 28 Oil sabre |
| 9 Screw, machine, 1/4-20 x 3/8 in. (4 rqr) | 19 Gear cover | 29 Screw |
| 10 Air intake cap | 20 Crankcase bottom plate | |

Figure 11. Oil filter, air cleaner, and ignition magneto, installed view.

- (2) Remove the cartridge from inside the filter and discard.
- (3) Wipe the inside of the filter with a lint-free cloth making sure all dirt and sludge are removed.
- (4) Insert a new cartridge in the filter body. Be sure the correct end of the cartridge is up.
- (5) Install a new gasket in the cover (26). Place the cover on the oil filter (24) and tighten the bolt (27).
- (6) Add one quart of oil to the engine crankcase to compensate for oil lost in servicing the oil filter. Refer to lubrication chart table 1 for the proper grade oil.
- (7) Operate the unit immediately after servicing (*d* above).

f. Air Cleaner.

- (1) Remove the air intake cap (10, fig. 11).
- (2) Loosen the thumbscrew (15) and remove the oil cup (17) from the air cleaner assembly (14).
- (3) Discard the oil in the oil cup. Wash the oil cup and air intake in an approved cleaning solvent and dry thoroughly.
- (4) Fill the oil cup to the level mark with clean oil of the proper grade. Refer to the lubrication chart table 1. Install the oil cup on the air cleaner body and tighten the thumbscrew (15) to secure.
- (5) Install the air intake cap on the top of the air cleaner assembly.

Section III. PREVENTIVE MAINTENANCE SERVICES

53. General

To insure that the equipment is ready for operation at all times, it must be inspected systematically before operation, during operation, and after operation, so that defects may be discovered and corrected before they result in serious damage or failure. The necessary preventive maintenance services will be performed before operation. Defects discovered during operation of the unit will be noted for future correction, to be made as soon as operation has ceased. Stop operation immediately if a deficiency is noticed during operation which would damage the equipment if operation were con-

tinued. After-operation services will be performed by the operator after every operating period. After-operation services will be performed at intervals based on the normal operations of the equipment. Reduce interval to compensate for abnormal conditions. Defects or unsatisfactory operating characteristics beyond the scope of the operator to correct must be reported at the earliest opportunity to organizational maintenance. Responsibility for performance of preventive maintenance services rests not only with the operator, but with the entire chain of command from section chief to commanding officer (AR 750-5).

54. Operator's Daily Services

Intervals			Procedures
Before Operation	During Operation	After Operation	
X	-----	X	<i>Visual inspection.</i> Make a general inspection of the entire unit for obvious deficiencies, such as oil or fuel leaks, loose or missing bolts, nuts, screws, loose connections, broken wires, and any damage that may have occurred since the equipment was last operated. Correct or report any deficiencies to field maintenance.
X	-----	-----	<i>Tampering.</i> Inspect the test stand for evidence of tampering or damage. Do not operate the unit until all defects are corrected or reported to direct and general support maintenance.
X	-----	X	<i>Fuel.</i> Check the fuel supply. See that the fuel tank is full.
X	-----	X	<i>Leaks.</i> Inspect for leaks, paying particular attention to the fuel line and connections. Correct all deficiencies noticed or report to direct and general support maintenance.

Intervals			Procedures
Before Operation	During Operation	After Operation	
X		X	<i>Oil.</i> Check the oil level in the engine crankcase. Add oil if the oil is not at the proper level.
X			<i>Air Cleaner.</i> Inspect the air cleaner for accumulated dirt. Clean if necessary.
X		X	<i>Battery.</i> Clean the battery and see that the terminal connections are tight. Check the level of the electrolyte. Add water as necessary to bring the level to three-eighths of an inch above the plates.
X		X	<i>Tires.</i> Inspect the tires for cuts, leaks, fabric breaks, and uneven wear. Check the tires for proper inflation. Correct tire pressure is 30 psi. Report a defective tire to direct and general support maintenance.
X		X	<i>Cooling System.</i> Inspect the condition of the fins on the engine. See that they are clean and free from dust and dirt. Inspect the engine shrouding for correct installation and loose or missing mounting bolts. Correct all deficiencies <i>or</i> report them to direct and general support maintenance.
X			<i>Fuel Strainer.</i> Inspect the bowl of the strainer for accumulation of water, dirt, and foreign matter. Clean the fuel strainer if necessary.
X			<i>Instruments.</i> Inspect all instruments for broken glass, improper operation, and insecure mounting. Report all deficiencies to direct and general support maintenance.

Section IV. TROUBLESHOOTING

55. General

This section provides information useful in diagnosis and correction, inspection, operation, or failure of the hydraulic test stand, or any of its components. Each trouble symptom stated

is followed by a list of probable causes of the trouble. The possible remedy recommended is described opposite the probable cause.

56. Engine Hard to Start or Fails to Start

<i>Probable cause</i>	<i>Possible remedy</i>
Carburetor not choked sufficiently -----	Pull choke control further out.
Carburetor flooded. -----	Push in choke control and crank until engine fires.
Water or dirt in fuel strainer -----	Clean the fuel strainer (par. 9).
Battery cables loose or terminals corroded -----	Tighten battery cable connections or remove and clean cables as required (par. 9).

57. Engine Misses or Runs Erratically

<i>Probable cause</i>	<i>Possible remedy</i>
Water, dirt, or gum in the fuel -----	Clean the fuel strainer and drain fuel tank and fill with clean fuel (par. 9).
Air cleaner clogged -----	Service air cleaner (par. 52).
Carburetor out of adjustment -----	Report to direct and general support maintenance.

58. Engine Stops Suddenly

<i>Probable cause</i>	<i>Possible remedy</i>
Water or dirt in fuel strainer -----	Clean the fuel strainer and drain the fuel tank and fill with clean fuel (par. 9).
Air cleaner clogged -----	Service the air cleaner (par. 52).

59. Engine Overheats

<i>Probable cause</i>	<i>Possible remedy</i>
Crankcase oil level too low -----	Stop engine and add oil to proper level.

<i>Probable cause</i>	<i>Possible remedy</i>
Air shroud loose or damaged -----	Tighten air shroud. Report damaged shroud to direct and general support maintenance.
Cylinder cooling fins clogged with dirt -----	Report malfunction to direct and general support maintenance.

60. Engine Knocks or Develops Excessive Noise

<i>Probable cause</i>	<i>Possible remedy</i>
Crankcase oil level too low -----	Stop engine and add oil to proper level. Refer to lubrication chart.

61. Engine Oil Pressure Low

<i>Probable cause</i>	<i>Possible remedy</i>
Crankcase oil level too low -----	Stop engine and add oil to proper level. Refer to lubrication chart.
Oil pressure gage defective -----	Report malfunction to direct and general support maintenance.

62. Engine Exhaust Smoky

<i>Probable cause</i>	<i>Possible remedy</i>
Crankcase oil level too high -----	Drain off excess oil to correct level.
Carburetor choked excessively -----	Push in choke control.
Engine cold causing poor combustion -----	Allow sufficient time for engine warm up before operating the hydraulic system.

63. Fuel Consumption Excessive

<i>Probable cause</i>	<i>Possible remedy</i>
Choke control partially closed -----	Open choke control.
Dirty air cleaner -----	Service the air cleaner (par. 52).
Fuel leaks -----	Report to direct and general support maintenance.

64. Battery Needs Frequent Recharging

<i>Probable cause</i>	<i>Possible remedy</i>
Battery electrolyte level low -----	Add battery water to correct level (par. 9).
Battery defective -----	Replace defective battery (par. 9).

65. Hydraulic Pump Fails to Deliver Sufficient Pressure

<i>Probable cause</i>	<i>Possible remedy</i>
High pressure relief valve out of adjustment -----	Adjust the high pressure relief valve (par. 43).
Compensator control incorrectly adjusted -----	Adjust the compensator control (par. 43).
Fluid bypass valve open -----	Close the fluid bypass valve.
Defective fluid pressure gage -----	Report to direct and general support maintenance.

66. Hydraulic Pump Fails to Deliver Sufficient Volume

<i>Probable cause</i>	<i>Possible remedy</i>
Fluid volume control incorrectly adjusted -----	Adjust the fluid volume control (par. 43).
Engine speed incorrect -----	Set throttle for an indicated 1800 rpm.

67. Hydraulic System Pressure too High

<i>Probable cause</i>	<i>Possible remedy</i>
High pressure relief valve set too high -----	Adjust high pressure relief valve (par. 43).
High pressure relief valve defective -----	Refer the malfunction to direct and general support maintenance.

68. Hydraulic Fluid Temperature too High

<i>Probable cause</i>	<i>Possible remedy</i>
Low pressure filter dirty -----	Report deficiency to direct and general support maintenance.
Reservoir fluid level low -----	Fill reservoir to correct level (par. 9).

Section V. HYDRAULIC SYSTEM

69. General

The hydraulic system of the test stand is comprised of the hydraulic pump, high and low pressure filters, pressure gages, flow indicator, and control valves. The necessary interconnect-

ing hose assemblies and tubing are included for the hydraulic system to perform its intended function of delivering filtered hydraulic fluid, at the desired volume and pressure, to the aircraft hydraulic system under test.




Figure 12. Hydraulic system installation.

1	Axial piston pump	25	Flared tube elbow
2	Pump mount	26	Reservoir shutoff valve-to-manifold tubing
3	Shaft coupling	27	Flared tube elbow
4	Pump-to-low pressure filter hose assembly	28	Pressure selector valve-to-pump tubing
5	Pump-to-manifold tubing	29	Flared tube elbow
6	Low pressure filter-to-bleed valve tubing	30	Outlet selector valve-to-outlet tubing, ½ in.
7	Bleed valve	31	Outlet selector valve-to-outlet tubing, ¾ in.
8	Pump-to-high pressure filter hose assembly	32	High pressure relief valve-to-snobber valve tubing
9	High pressure filter assembly	33	Flared tube tee
10	Flared tube tee	34	Flared tube tee
11	High pressure filter-to-relief valve tubing	35	Damper valve-to-snobber valve tubing
12	High pressure relief valve-to-manifold tubing	36	Snubber valve-to-gage top tubing
13	High pressure filter-to-outlet selector valve tubing	37	Fluid pressure gage-to-dampener hose assembly
14	Suction tubing	38	Relief valve-to-bypass valve tubing
15	Coupling half, 1 in.	39	Flared tube tee
16	Dust protective cap, 1 in.	40	Pressure selector valve-to-bypass valve tubing
17	Flow control valve-to-outlet tubing	41	Flared tube tee
18	Dust protective cap, ¾ in.	42	Pressure selector valve-to-gage tubing
19	Flow control valve-to-outlet tubing	43	Flared tube elbow
20	Dust protective cap	44	Pressure selector valve-to-gage hose assembly
21	Outlet selector valve-to-reservoir tubing	45	Bypass valve-to-reservoir shutoff valve tubing
22	Relief valve-to-reservoir tubing	46	Reservoir-to-shutoff valve tubing
23	Relief valve	47	Filter and manifold assembly
24	Tee		

Figure 12—Continued.

70. Bleeding Air From the Hydraulic System

a. Fill the reservoir as outlined in paragraph 9.

b. Open the bleed valve (7, fig. 12) and allow air to escape from the low pressure filter. Close the valve when air bubbles no longer appear.

c. Connect the ½ inch hose assembly to the coupling half (7, fig. 2).

d. Set the outlet selector valve (16, fig. 9) in the ½ inch outlet position.

e. Open the flow control valve (20).

f. Remove the reservoir fill cap (9, fig. 8). Remove the coupling half from the opposite end of the attached ½ inch hose assembly and insert the open end into the reservoir being careful not to damage the screen in the filler neck of the reservoir.

g. Set the fluid voume control (29, fig. 9) at 2 gpm as registered on the fluid flow indicator (15).

h. Start the test stand (par. 41) and circulate hydraulic fluid through the system and back into the reservoir until all traces of air bubbles are gone from the fluid flowing into the reservoir.

i. Stop the test stand (par. 42) and disconnect the hose assembly. Cap both ends of the hose assembly and the coupling half of the test stand.

71. Filter Element Replacement

a. *Inspecting Low Pressure Filters.*

(1) Start the test stand (par. 41) and adjust the fluid volume control (29, fig. 9) for maximum pump delivery.

(2) Set the pressure selector valve (8) at FILTER INLET position and note the reading on the filter pressure gage (6).

(3) Set the pressure selector valve (8) at FILTER OUTLET position and note the reading on the filter pressure gage (6).

(4) The difference between the readings (2) and (3) above, represents the pressure drop across the low pressure filter. Replace the filter element, *b* below, should the pressure drop be 20 psi or greater.

b. *Low Pressure Filter Element Replacement.*

(1) Close the reservoir shutoff valve (12, fig. 9).

(2) Remove plug (28, fig. 13) from the bottom cover (26) and drain the hydraulic fluid from the low pressure filter.

(3) Disconnect the low-pressure filter-to-bleed valve tubing (6, fig. 12) and the pump-to-low pressure filter hose as-




Figure 13. Filter and manifold assembly, exploded view.

1 Locknut	12 Plate assembly	22 Lockwasher (10 rqr)
2 Flared tube elbow	13 Bolt (2 rqr)	23 Thermoswitch
3 Preformed packing	14 Lockwasher (2 rqr)	24 Preformed packing
4 Flared tube union	15 Spacer (2 rqr)	25 Preformed packing
5 Preformed packing	16 Top cover	26 Bottom cover
6 Bolt (6 rqr)	17 Locknut	27 Bolt (6 rqr)
7 Preformed packing	18 Flared tube elbow	28 Plug
8 Wingnut	19 Preformed packing	29 Preformed packing
9 Filter element cover	20 Manifold	30 Preformed packing
10 Gasket (2 rqr)	21 Bolt (10 rqr)	31 Filter housing
11 Filter element		

Figure 13—Continued.

sembly (4) from the top cover of the low pressure filter.

- (4) Remove the six bolts (6, fig. 13) that secure the top cover (16) to the filter housing (31) and remove the cover with attached parts from the housing.
- (5) Remove the wing nut (8) that secures the filter element cover (9), gasket (10), and the filter element (11) in place and remove the cover, gasket, and element.
- (6) Wash all metal parts with an approved cleaning solvent and dry thoroughly.
- (7) Place a new filter element (11) on the plate assembly (12) and secure with the gasket (10), filter element cover (9), and the wing nut (8).
- (8) Position the preformed packing (7) and the top cover (16) on the filter housing (31) and secure with the six bolts (6).
- (9) Connect the pump-to-low pressure filter hose assembly (4, fig. 12) and the low pressure filter-to-bleed valve tubing. (6) to the installed top cover.
- (10) Install the plug (28, fig. 13) in the bottom cover (26).
- (11) Open the reservoir shutoff valve (12, fig. 9) and bleed air from the low pressure filter (par. 70).
- (12) Fill reservoir as prescribed in paragraph 9.

c. High Pressure Filter Element Replacement. If the high pressure filter assembly (9, fig. 12) is clogged or dirty, replace the element as follows:

- (1) Cut the safety wire and unscrew the element case from the filter head.

- (2) Remove the old element and replace it with a new element.
- (3) Reassemble the high pressure filter and secure with a safety wire.
- (4) Fill reservoir as prescribed in paragraph 9.

72. Hose Assemblies

a. Removal.

- (1) Remove the drain assembly from the bottom of the reservoir and drain the hydraulic system.
- (2) Disconnect and remove the pressure selector valve-to-gage hose assembly (44, fig. 12), fluid pressure gage-to-dampener hose assembly (37), pump-to-high pressure filter hose assembly (8), and the pump-to-low pressure filter hose assembly (4).
- (3) Remove the 3 hose assemblies attached to the 3 coupling halves (7, 8, and 9, fig. 2). These hose assemblies are stored in the compartment at the rear of the test stand when not in use.

b. Cleaning and Inspection.

- (1) Clean the hose assemblies in an approved cleaning solvent and dry thoroughly.
- (2) Inspect the hose assemblies for frayed or worn hose. Inspect the fittings of the hose assemblies and the drain assembly for damaged threads. Replace a defective hose assembly or drain assembly.

c. Installation.

- (1) Install the 3 hose assemblies on the 3 coupling halves (7, 8, and 9, fig. 2) or store them in the compartment at the rear of the test stand.

- (2) Install the pump-to-low pressure filter hose assembly (4, fig. 12), pump-to-high pressure hose assembly (8), fluid pressure gage-to-dampener hose assembly (37), and the pressure selector valve-to-filter gage hose assembly (44).
- (3) Install the drain assembly in the bottom of the reservoir and fill the reservoir (par. 9).

73. Pressure Gages

a. Testing Pressure Gages.

- (1) Connect a pressure gage of known accuracy to the filter pressure gage tap (26, fig. 9).
- (2) Start the test stand (par. 41) and compare the readings of both the test gage and the filter pressure gage (6). Replace a defective gage as outlined below.

b. Pressure Gage Replacement.

(1) Removal.

- (a) Close the reservoir shutoff valve (12, fig. 9).
- (b) Disconnect the hose from the back of the filter pressure gage (6).
- (c) Remove the 3 nuts and 3 screws that secure the filter pressure gage to the panel and remove the gage.
- (d) Remove the fluid pressure gage (3) in a similar manner.

(2) Installation.

- (a) Position the filter pressure gage (6) in the panel (1) and secure with the 3 screws and 3 nuts.
- (b) Connect the hose to the back of the filter pressure gage.
- (c) Open the reservoir shutoff valve (12).
- (d) Install the fluid pressure gage in a similar manner.

Section VI. RUNNING GEAR ASSEMBLY

74. Wheels

a. Removal.

- (1) Remove the 5 hex nuts (30, fig. 14) and 5 lockwashers (31) that secure

the wheel to the hub (51) and remove the wheel.

- (2) Remove the remaining wheels in a similar manner.

1 Cotter pin (4 rqr)	30 Nut, plain, hex (20 rqr)	59 Thrush washer (2 rqr)
2 Nut (4 rqr)	31 Lockwasher (20 rqr)	60 Spindle assembly
3 Lubrication fitting (4 rqr)	32 Nut, plain, hex (32 rqr)	61 Sleeve bearing (2 rqr)
4 Tie rod end (2 rqr)	33 Lockwasher (32 rqr)	62 Sleeve bearing (2 rqr)
5 Tie rod end (2 rqr)	34 Bolt (32 rqr)	63 Axle bracket
6 Nut (4 rqr)	35 Wheel half (4 rqr)	64 Bolt (8 rqr)
7 Lockwasher (4 rqr)	36 Wheel half (4 rqr)	65 Lockwasher (8 rqr)
8 Bolt (4 rqr)	37 Pneumatic tire (4 rqr)	66 Brake assembly (2 rqr)
9 Loop clamp (4 rqr)	38 Inner tube	67 Nut (8 rqr)
10 Tie rod	39 Tire valve cap (4 rqr)	68 Lockwasher (8 rqr)
11 Drawbar assembly	40 Check valve (4 rqr)	69 Axle assembly
12 Headed grooved pin	41 Grease cap (4 rqr)	70 Support and arm assembly
13 Retaining ring	42 Cotter pin (4 rqr)	71 Nut (12 rqr)
14 Steering arm assembly	43 Nut (4 rqr)	72 Lockwasher (12 rqr)
15 Cotter pin	44 Key washer (4 rqr)	73 Flat washer (12 rqr)
16 Nut	45 Roller bearing cone (4 rqr)	74 Bolt (12 rqr)
17 Thrust washer (2 rqr)	46 Roller bearing cup (4 rqr)	75 Retaining ring (16 rqr)
18 Shear bolt	47 Grease seal (4 rqr)	76 Headless grooved pin (8 rqr)
19 Latch	48 Roller bearing cone (4 rqr)	77 Arm assembly
20 Nut	49 Roller bearing cup (4 rqr)	78 Sleeve bearing (8 rqr)
21 Bolt	50 Ribbed neck bolt (10 rqr)	79 Rubber bumper (4 rqr)
22 Cable assembly	51 Hub (4 rqr)	80 Nut (4 rqr)
23 Cable assembly	52 Brake drum (2 rqr)	81 Lockwasher (4 rqr)
24 Elastic grommet (2 rqr)	53 Spring (4 rqr)	82 Flat washer (4 rqr)
25 Brake lever assembly	54 Axle assembly	83 Bolt
26 Stop bracket, right-hand (2 rqr)	55 Bolt (8 rqr)	84 Support assembly
27 Stop bracket, left-hand (2 rqr)	56 Lockwasher (8 rqr)	85 Sleeve bearing
28 Bolt (8 rqr)	57 Kingpin (2 rqr)	86 Clamp
29 Lockwasher (8 rqr)	58 Thrust washer (2 rqr)	87 Frame assembly

Figure 14. Running gear and brake assembly, exploded view.




Figure 14—Continued.




Figure 15. Brake lever assembly, exploded view.

1 Cable assembly, right-hand	7 Spacer (2 rqr)	13 Flat washer (3 rqr)
2 Cable assembly, left-hand	8 Washer (3 rqr)	14 Cotter pin
3 Nut (3 rqr)	9 Bolt (3 rqr)	15 Flat washer
4 Lever assembly	10 Cotter pin (2 rqr)	16 Lever (2 rqr)
5 Spacer (3 rqr)	11 Headed straight pin (2 rqr)	17 Spacer (2 rqr)
6 Spacer	12 Rod end clevis (2 rqr)	18 Headed straight pin

Figure 15—Continued.

b. Installation.

- (1) Position the wheel on the hub (51) and secure with the 5 lockwashers (31) and 5 hex nuts (30).
- (2) Install the remaining wheels in a similar manner.

75. Drawbar and Steering Arm Assemblies

a. Removal.

- (1) Remove the hex nut (20, fig. 14) and bolt (21) that secure the latch (19) to the steering arm assembly (14) and remove the latch.
- (2) Remove the retaining ring (13) and headed grooved pin (12) that secure the drawbar assembly (11) to the steering arm assembly and remove the drawbar.
- (3) Remove the 2 cotter pins (1), and nuts (2) that secure the 2 tie rod ends (5) to the steering arm assembly and lift the tie rod ends out of the arm.
- (4) Remove the cotter pin (15), nut (16), two thrust washers (17), and shear bolt (18) from the steering arm assembly and remove the steering arm from the support and arm assembly (70).
- (5) Remove the sleeve bearing (85) from the support and arm assembly.

b. Cleaning and Inspection.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Inspect the drawbar and steering arm assembly for cracks, breaks, and distortion.
- (3) Inspect the thrust washer and sleeve bearing for nicks, burrs, distortion, and excessive wear.
- (4) Inspect all attaching hardware for distortion and damaged threads.
- (5) Replace all defective parts.

c. Installation.

- (1) Install the sleeve bearing (85, fig. 14) in the support and arm assembly (70).
- (2) Position the steering arm assembly (14) on the support and arm assembly and insert the shear bolt (18) in the aligned holes of the arm and sleeve bearing. Install the two thrust washers (17), nut (16) and insert cotter pin (15) in the shear bolt.
- (3) Insert the 2 tie rod ends (5) in the steering arm assembly and secure with the 2 nuts (2) and 2 cotter pins (1).
- (4) Position the drawbar assembly (11) in the steering arm assembly and install the headed grooved pin (12) and the retaining ring (13).
- (5) Place the latch (19) on the steering arm and install the bolt (21) and hex nut (20).

76. Brake Lever Assembly

a. Removal.

- (1) Remove the 2 hex nuts (3, fig. 15) that secure the 2 cable assemblies (1 and 2) to the 2 rod end clevises (12) and pull cable ends out of the clevises.
- (2) Remove the 3 bolts (9), 3 spacers (5), 2 spacers (7), the spacer (6) and 3 lockwashers (8) that secure the lever assembly (4) to the frame and remove the lever assembly.

b. Cleaning and Inspection.

- (1) Clean the brake lever assembly with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the brake lever assembly for cracks, breaks, and distortion. Check to see that the lever operates free without binding. Replace a defective brake lever assembly.

c. Installation.

- (1) Position the 3 spacers (5, fig. 15) and the lever assembly (4) on the frame and secure with the 2 spacers (7), spacer (6), 3 lockwashers (8) and 3 bolts (9) .
- (2) Insert the cable assemblies (1 and 2)

in the rod end clevises (12) and secure with the 2 hex nuts (3).

d. Brake Adjustment. The brakes of the test stand are adjusted by rotating the knurled portion of the lever assembly (4, fig. 15). Clockwise rotation will set the brakes tighter while counter clockwise rotation will reduce set pressure.

CHAPTER 4

DIRECT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS

Section I. SPECIAL DIRECT AND GENERAL SUPPORT MAINTENANCE TOOLS AND EQUIPMENT

No special tools are required to perform direct and general support maintenance of this hydraulic test stand.

Section II. PREVENTIVE MAINTENANCE SERVICES

77. General

Preventive maintenance is performed by direct and general support maintenance personnel at 50 and 100 hour intervals. The preventive maintenance services to be performed at these regular intervals are listed in paragraph 78. The first column headed "inspection", is pro-

vailed for the information of the person performing the inspection. An X in this column indicates that an inspection should be made of the listed items in accordance with instructions given in the text opposite. The indicated items and instructions constitute minimum inspection requirements for the equipment.

78. Direct and General Support Preventive Maintenance Services

Inspection	50 hour	100 hour	GENERAL
X	X	X	<i>Before-operation services.</i> Perform the services listed in daily before-operation services (par. 54).
X	X	X	<i>Lubrication.</i> Inspect for missing or damaged lubrication fittings and inspect for indications of improper lubrication. Inspect lubricant level in engine crankcase. Inspect for oil and grease leaks; also inspect for defective or damaged oil seals.
	X	X	Lubricate as necessary in accordance with the lubrication chart. Replace missing or damaged fittings. Correct all oil or grease leaks.
X	X	X	<i>Appearance.</i> Inspect the general appearance of the equipment, paying particular attention to cleanness, legibility of identification markings, and conditions of the paint. Correct all deficiencies noticed.
X	X	X	<i>Cylinder heads, manifold and muffler.</i> Inspect the cylinder heads, manifolds, and muffler for leaks, loose mounting and defective gaskets. Tighten loose manifolds and muffler mounting bolts and nuts. During the first weekly servicing of a new or reconditioned engine, inspect all the cylinder head bolts for tightness. After warming up the engine to operating temperature, tighten any loose bolts to 25 to 32 ft-lb torque. Replace defective cylinder head and manifold gaskets.
X	X	X	<i>Valve mechanism.</i> If the valves are noisy or loss of power is noticed, inspect the condition of the valve mechanism.
	X	X	Remove valves covers and adjust valve lifter clearance if necessary (par. 125). The correct clearance for the valve lifters is 0.0080 inch for the intake valves and 0.0160 inch for the exhaust valves. Replace cover gaskets if defective.
X		X	<i>Compression test.</i> Remove the spark plugs and test the cylinder compression by turning the engine over several times to stabilize gage reading. If the gage reading varies more than 10 pounds between the four cylinders, inspect the cylinder head bolts for tightness.

	50 hour	100 hour	
		X	Tighten any loose bolts and retest. If low compression or a variation in compression persists, the trouble lies with the cylinder head gasket, valves, or piston rings. Correct all deficiencies.
X	X	X	<i>Electrical System Magneto.</i> Inspect the ignition magneto for loose mounting bolts and wiring connections. Correct any deficiencies noted.
		X	Remove the end cap and inspect the distributor cap for cracks, and corroded terminals. Examine the breaker point gap. The correct gap is 0.015 inch at full separation of points.
X	X	X	<i>Spark plugs.</i> Inspect the spark plugs for looseness, bad connections, and dirty or broken insulators.
		X	Replace damaged spark plugs (par. 114). Clean dirty plugs and set the gap to 0.0300 inch (par. 114).
X	X	X	<i>Generator and starter.</i> Inspect the mounting of the generator and starting motor for loose connections. Examine the brushes, brush holders and springs. Inspect the commutators for dirt and scoring.
		X	Tighten loose mounting bolts. Replace generator brushes worn to one half their original length (par. 112). Replace starter brushes worn to one half their original length (par. 113).
X	X	X	<i>Engine generator regulator.</i> Inspect the generator regulator for proper operation, tight connections, and secure mounting. The generator regulator should allow an appreciable charge to go into the battery after the starter is used. After the battery is fully charged, the ammeter should read only a slight charge.
		X	Tighten loose mounting nuts and connections. Adjust or replace a defective engine generator regulator (par. 111).
CONTROL PANEL			
X	X	X	<i>Gages.</i> Examine the condition of all gages. See that all gages indicate correctly and that the glass is not cracked or broken.
		X	Tighten loose mounting screws and connections. Replace any defective or damaged gage.
X	X	X	<i>Meters.</i> See that all meters are securely mounted and operating properly and that the glass is not cracked or the indicators are not bent or broken.
		X	Tighten loose mounting screws and replace any defective or damaged meter.
X	X	X	<i>Control valves.</i> Inspect all control valves for packing leaks and proper operation. See that handwheels are securely mounted.
		X	Tighten packing or replace as required. Replace a defective or damaged control valve.
RUNNING GEAR			
X	X	X	<i>Tires.</i> Inspect all tires for under inflation, abnormal or uneven wear, cuts, embedded foreign matter, and missing valve caps.
		X	Remove any foreign matter from tires. See that tires are inflated to correct pressure and all valve caps are in place.
X	X	X	<i>Wheels.</i> Inspect for loose wheel mounting bolts. Inspect wheel bearings for proper adjustment.
		X	Tighten loose wheel bolts and adjust wheel bearings as required (par. 163).
X	X	X	<i>Axles.</i> Inspect the axle assemblies for secure mounting and proper alinement. Inspect the springs for cracks, breaks and weakened condition.
		X	Tighten all axle mounting bolts. Aline the front wheels as required (par. 163). Replace defective springs (par. 164).
X	X	X	<i>Brake assembly.</i> Inspect the brake assembly for correct adjustment. Inspect the cables for secure mounting.
		X	Tighten all brake assembly mounting bolts and adjust the brakes (par. 76).
HYDRAULIC SYSTEM			
X	X	X	<i>Hydraulic pump.</i> Inspect the hydraulic pump for loose mounting bolts and hydraulic connections. See that the drive coupling is securely mounted and alined.

Inspection	50 hour	100 hour	
	X	X	Tighten all mounting bolts and loose or leaking hydraulic connections. Replace a defective drive coupling (par. 153).
X	X	X	<i>Hose assemblies.</i> Inspect the hydraulic hose assemblies for loose connections. Inspect the hose for cracks, breaks, and for frayed or rotten fabric covering.
	X	X	Tighten hose connections and replace any defective hose assembly.
X	X	X	<i>Tubing.</i> Inspect all tubing for cracks, breaks, and distortion.
	X	X	Tighten all tube connections. Replace any damaged or defective tube or fitting.
X	X	X	<i>High pressure filter assembly.</i> Inspect the filter for dirty or clogged condition resulting in excessive pressure drop.
	X	X	Remove and replace the filter element.
X	X	X	<i>Thermoswitch.</i> Inspect the thermoswitch for correct temperature response and for secure installation.
	X	X	Replace a defective or damaged thermoswitch (par. 143).

Section III. TROUBLESHOOTING

79. General

This section provides information useful in diagnosis and correction, inspection, operation, or failure of the hydraulic test stand, or any of its components. Each trouble symptom

stated is followed by a list of probable causes of the trouble. The possible remedy recommended is described opposite the probable cause.

80. Engine Hard to Start or Fails to Start

<i>Probable cause</i>
Battery defective.
Choking insufficient.
Battery cables loose on terminals.
Ignition switch faulty.
Battery cable loose on armature relay.
Carburetor flooded.
No ignition spark.
Spark plugs defective.
Magneto faulty.

<i>Possible remedy</i>
Charge or replace defective battery (par. 9). Inspect the choke valve for full open or closed position (par. 122).
Tighten loose connections. Replace switch (par. 138).
Tighten loose connections. Remove spark plugs (par. 114) and crank the engine several times to drive out rich fuel mixture. Test the spark (par. 115).
Clean and adjust or replace spark plugs (par. 114). Repair or replace magneto contact point set (par. 115).

81. Engine Misses or Runs Erratically

<i>Probable cause</i>
Carburetor gasket leaks
Spark weak.
Spark gap incorrect.
Ignition wiring loose.
Magneto contact points pitted or incorrectly adjusted
Governor defective

<i>Possible remedy</i>
Tighten carburetor mounting bolts. Replace gasket if leak persists (par. 122). Test spark (par. 115)
Measure and reset spark plug gap (par. 11.4) . Tighten ignition wire connections. Clean, adjust, or replace contact points (par. 115). Repair governor (par. 135).

82. Engine Stops Suddenly

<i>Probable cause</i>
Fuel pump defective.
Fuel line clogged
Magneto contact set defective

<i>Possible remedy</i>
Repair or replace fuel pump (par. 131). Remove and clean fuel line, replace if defective (par. 131).
Replace defective contact set (par. 115) .

83. Engine Overheats

<i>Probable cause</i>	<i>Possible remedy</i>
Cylinder cooling fins dirty	Clean dust and dirt from cooling fins.
Magneto timed late	Time the magneto (par. 115).
Air shroud partially removed from engine	Install the missing shroud (pars. 118 and 119).

84. Engine Knocks or Develops Excessive Noise

<i>Probable cause</i>	<i>Possible remedy</i>
Magneto timing advanced too far	Time the magneto (par. 115).
Carbon deposits on cylinder heads	Remove and clean cylinder heads (par. 124).
Flywheel loose	Tighten the flywheel (par. 118).

85. Engine Exhaust Smoky

<i>Probable cause</i>	<i>Possible remedy</i>
Carburetor incorrectly adjusted	Adjust the carburetor (par. 122).
Carburetor defective	Repair or replace carburetor (par. 122).

86. Engine Starter Fails to Operate

<i>Probable cause</i>	<i>Possible remedy</i>
Ignition fuse blown	Replace ignition fuse.
Starter brushes worn	Replace brushes (par. 113).
Electrical connections loose or corroded	Tighten connections or replace wiring (par. 113).
Starter switch contacts burned	Replace starter switch (par. 138).
Starter brushes defective	Replace starter brushes (par. 113).

87. Fuel Consumption Excessive

<i>Probable cause</i>	<i>Possible remedy</i>
Carburetor incorrectly adjusted	Adjust the carburetor (par. 122).
Fuel tank leaking	Repair or replace fuel tank (par. 132).
Carburetor defective	Repair or replace carburetor (par. 122).

88. Ammeter Shows No Charge or Discharge With Engine Operating

<i>Probable cause</i>	<i>Possible remedy</i>
Electrical connections loose or corroded	Clean and tighten electrical connections.
Generator regulator incorrectly adjusted or faulty	Replace generator regulator as required (par. 111).
Generator V-belt loose or broken	Adjust or replace V-belt as necessary (par. 112).
Generator inoperative	Replace worn brushes (par. 112).
Ammeter defective	Replace ammeter (par. 137).

89. Ammeter Shows Excessive Charge

<i>Probable cause</i>	<i>Possible remedy</i>
Battery run down	Charge battery.
Generator regulator defective	Replace a defective regulator (par. 111).
Generator field winding grounded	Replace generator (par. 112).

90. Ammeter Needle Fluctuates Rapidly

<i>Probable cause</i>	<i>Possible remedy</i>
Electrical connections shorted or loose	Repair short circuits and tighten loose connections.
Generator commutator has high mica	Report to depot maintenance.

91. Wheel Wobbles

<i>Probable cause</i>	<i>Possible remedy</i>
Wheel bent	Replace the wheel (par. 163).
Wheel loose on the hub	Tighten wheel mounting bolts.
Wheel bearing incorrectly adjusted	Adjust wheel bearing (par. 163).

92. Wheel Bearings Overheat

<i>Probable cause</i>	<i>Possible remedy</i>
Wheel bearings lack lubricant	Lubricate wheel bearings (par. 163).
Wheel bearings incorrectly adjusted	Adjust wheel bearings (par. 163).

93. Tire Wear Abnormal or Uneven

<i>Probable cause</i>	<i>Possible remedy</i>
Wheel loose on the hub	Tighten wheel mounting bolts.
Steering tie rod incorrectly adjusted.....	Adjust tie rods (par. 164).

94. Brake Does Not Hold

<i>Probable cause</i>	<i>Possible remedy</i>
Normal wear	Adjust brakes (par. 76).
Defective brake assembly.....	Repair or replace brake assembly (par. 167).

95. Hydraulic Pump Fails to Deliver Sufficient Pressure

<i>Probable cause</i>	<i>Possible remedy</i>
Defective high pressure relief valve	Repair or replace high pressure relief valve (par. 149).
Fluid pressure gage defective	Replace fluid pressure gage (par. 173).
Compensator control defective	Repair or replace compensator control (par. 153).
Hydraulic pump defective	Replace the pump (par. 153).

96. Hydraulic Pump Fails to Deliver Sufficient Volume

<i>Probable cause</i>	<i>Possible remedy</i>
Fluid volume control defective	Repair fluid volume control (par. 153).
Air in the hydraulic system	Bleed air from the system (par. 70).
Engine speed too low	Check engine with hand speed indicator. Replace tachometer if defective (par. 137).
Fluid flow indicator defective	Replace or repair fluid flow indicator (par. 146).
High pressure filter clogged	Replace high pressure filter (par. 142).
Fluid bypass valve leaking	Replace fluid bypass valve (par. 150).

97. Hydraulic System Pressure Too High

<i>Probable cause</i>	<i>Possible remedy</i>
High pressure filter clogged	Replace high pressure filter (par. 142).
High pressure relief valve defective	Repair or replace high pressure relief valve (par. 149).
Compensator control defective	Repair or replace compensator control (par. 153).
Fluid pressure gage defective	Repair or replace fluid pressure gage (par. 73).

98. Hydraulic Fluid Temperature Too High

<i>Probable cause</i>	<i>Possible remedy</i>
Fluid temperature gage defective	Replace fluid temperature gage (par. 147).
High pressure filter clogged	Replace high pressure filter (par. 142).
Thermoswitch defective	Replace the thermoswitch (par. 143).

Section IV. RADIO INTERFERENCE SUPPRESSION

99. Definition

a. Interference. The term "interference" as used herein applies to electrical disturbances in the radio frequency range which are generated by the test stand and which may interfere with the proper operation of radio receivers or other electronic equipment.

b. Interference Suppression. The term "interference suppression" as used herein applies to the methods used to eliminate or effectively reduce radio interference generated by the test stand.

100. Purpose of Interference Suppression

The tactical importance of effective interference suppression cannot be stressed too greatly. Since the electrical disturbances generated by the test stand are composed partly of electrical waves in the radio frequency range they must be suppressed for two important reasons. First, they will interfere with the proper operation of the friendly radio net, and second, they will enable the enemy to locate the equipment and its associated units.


101. General Sources of Interference

Generally, radio interference is generated anywhere a spark occurs or where a high-frequency current is present. A spark is a small amount of current jumping an air gap in response to the force of a relatively high voltage. The gasoline engine ignition system is a common source. Magneto breaker points, generator

commutators, relay contacts, and static charges collecting on the frame are other common sources which in some way must be suppressed.


102. General Methods Used to Attain Proper Suppression

Essentially, suppression is attained by providing a low-resistance path to ground for the



- | | | |
|------------------------------------|------------------------------|-----------------------------|
| 1 Generator shield box | 8 Screw | 15 Nut |
| 2 Screw | 9 Engine accessory generator | 16 Lockwasher |
| 3 Lockwasher | 10 Bolt | 17 Flat washer |
| 4 Electrical plug connector | 11 Bolt (2 rqr) | 18 Bolt |
| 5 Capacitor, 0.5 μ f, 100 V DC | 12 Lockwasher (3 rqr) | 19 Angle bracket |
| 6 Nut | 13 Flat Washer (3 rqr) | 20 Generator mounting plate |
| 7 Lockwasher | 14 Generator adjusting arm | |

Figure 16. Generator and radio suppression capacitor, removal points.



- | | | |
|---|--|-------------------------------------|
| 1 V-belt | 13 Battery support | 25 Engine generator regulator |
| 2 Generator and mounting bracket assembly | 14 Nut (8 rqr) | 26 Screw (3 rqr) |
| 3 Nut (2 rqr) | 15 Lockwasher (8 rqr) | 27 Lockwasher (3 rqr) |
| 4 Lockwasher (2 rqr) | 16 Bolt (8 rqr) | 28 Box assembly |
| 5 Hook bolt (2 rqr) | 17 Battery tray | 29 Nut (2 rqr) |
| 6 Cover assembly | 18 Armature relay | 30 Lockwasher (2 rqr) |
| 7 Battery terminal adapter, positive | 19 Nut (2 rqr) | 31 Flat washer (2 rqr) |
| 8 Battery terminal adapter, negative | 20 Lockwasher (2 rqr) | 32 Bolt (2 rqr) |
| 9 Battery | 21 Flat washer (2 rqr) | 33 Electrical box connector |
| 10 Nut (2 rqr) | 22 Bolt (2 rqr) | 34 Capacitor, 0.5 μ f, 100 V DC |
| 11 Lockwasher (2 rqr) | 23 Cover | 35 Nut |
| 12 Screw (2 rqr) | 24 Screw, tapping, thread forming, No. 6 x $\frac{3}{8}$ in. (4 rqr) | 36 Lockwasher |
| | | 37 Screw |

Figure 17. Electrical installation.

stray currents. The method used to attain suppression include shielding the ignition and high-frequency wires, grounding the frame with bonding straps, and using capacitors and resistors where necessary.

103. Interference Suppression Components

a. A 0.5 μ f (microfarad), 100-volt dc, capacitor (5, fig. 16) is mounted on the inside of the generator shield box (1).

b. A 0.5 μ f 100-volt de capacitor (34, fig. 17) is mounted on the engine generator regulator (25) inside the box assembly (28).

104. Testing Radio Interference Suppression Components

Test the capacitors for leaks and shorts on a capacitor tester. Replace a defective capacitor. If test equipment is not available and interference is indicated, isolate the cause of interfer-

ence by trial and error method or replacing each capacitor in turn until the cause of interference is determined and eliminated.

105. Replacement of Interference Suppression Components

a. Engine Accessory Generator Capacitor.

- (1) Remove the screw (2, fig. 16) and lockwasher (3) that secure the generator shield box (1) to the engine accessory generator (9),
- (2) Carefully lift the shield box off the generator. Disconnect the leads of the capacitor (5).
- (3) Remove the hex nut (6), lockwasher (7), and screw (8) that secure the capacitor in the shield box and remove the capacitor.
- (4) Secure a new capacitor (5) in the shield box with the screw (8), lockwasher (7), and hex nut (6),
- (5) Connect the leads of the capacitor.

Position the shield box on the generator and secure with the lockwasher (3) and screw (2).

b. Engine Generator Regulator Capacitor.

- (1) Remove the four screws (24, fig. 17) that secure the cover (23) to the box assembly (28) and remove the cover.
- (2) Disconnect the electrical lead from the capacitor (34).
- (3) Remove the hex nut (35), lockwasher (36), and the screw (37) that secures the capacitor in the box and remove the capacitor.
- (4) Position a new capacitor (34) in the box assembly and secure with the screw (37), lockwasher (36), and hex nut (35).
- (5) Connect the electrical lead to the capacitor.
- (6) Place the cover (23) on the box assembly (28) and secure with the four screws (24).

Section V. REMOVAL AND INSTALLATION OF MAJOR COMPONENTS

106. Housing Assembly

a. Removal.

- (1) Loosen the seven thumbscrews (6, fig. 1) and remove the front panel assembly (5) from the housing assembly (4).
- (2) Remove the nine hex nuts, lockwashers and bolts that secure the housing assembly to the frame assembly and lift the housing assembly off the frame.

b. Installation.

- (1) Mount the housing assembly (4) on the frame assembly (7) and secure with nine bolts, lockwashers, and hex nuts.
- (2) Position the front panel assembly (5) on the housing assembly and tighten the seven thumbscrews (6) to secure.

107. Control Panel Assembly

a. Removal.

- (1) Remove the housing assembly (par. 106).

- (2) Open the drain valve in the reservoir and drain the hydraulic fluid into a suitable container. Remove the pipe plug in the bottom of the filter and manifold assembly (47, fig. 12) and drain the remaining hydraulic fluid from the system.
- (3) Disconnect the pressure selector valve-to-pump tubing (28) , outlet selector valve-to-reservoir tubing (21), bypass valve-to-reservoir shutoff valve tubing (45), reservoir shutoff valve-to-manifold tubing (26), flow control valve-to-outlet tubing (17 and 19), high pressure relief valve-to-manifold tubing (12), and the pump-to-high pressure filter hose assembly (8).
- (4) Tag and disconnect the electrical wires from the reservoir level indicator (2, fig. 9).
- (5) Disconnect the sensing element of the fluid temperature gage (4) from the filter and manifold assembly (47, fig. 12).

- (6) Remove the hex nut and handwheel from the reservoir shutoff valve (12, fig. 9).
- (7) Remove the hex nut, handwheel, and the locknut from the fluid volume control (29).
- (8) Remove the hex nut, handwheel, and locknut from the compensator control (25).
- (9) Disconnect the steel cable linking the fluid flow indicator (15) to the hydraulic pump.
- (10) Remove the eight screws (19) and flat washers (18) that secure the panel (1) to the reservoir and control panel support and lift the panel off the support.

b. Installation.

- (1) Mount the control panel (1, fig. 9) on the reservoir and control panel support and secure with the eight flat washers (18) and screws (19).
- (2) Connect the steel cable which links the fluid flow indicator (15) to the hydraulic pump.
- (3) Install the locknut, handwheel, and hex nut on the compensator control (25).
- (4) Install the locknut, handwheel, and hex nut on the fluid volume control (29).
- (5) Place the handwheel on the reservoir shutoff valve (12) and secure with the hex nut.
- (6) Install the sensing element of the fluid temperature gage (4) in the filter and manifold assembly (47, fig. 12).
- (7) Connect the electrical wires to the reservoir level indicator (2, fig. 9).
- (8) Connect the pump-to-high pressure filter hose assembly (8, fig. 12), high pressure relief valve-to-manifold tubing (12), flow control valve-to-outlet tubing (17 and 19), reservoir shutoff valve-to-manifold tubing (26), bypass valve-to-reservoir shutoff valve tubing (45), outlet selector valve-to-reservoir tubing (21), and the pressure selector valve-to-pump tubing (28).

- (9) Fill the hydraulic system (par. 9) and bleed air from the system (par. 70).
- (10) Install the housing assembly (par. 106).

108. Engine

a. Removal.

- (1) Remove the hydraulic pump (par. 153).
- (2) Remove the engine accessory generator (par. 112).
- (3) Remove the electrical engine starter (par. 113).
- (4) Remove air cleaner (par. 116).
- (5) Remove the muffler (par. 121).
- (6) Remove the fuel tank (par. 132).
- (7) Remove the pipe plug from the elbow (23, fig. 11) and drain the oil from the engine.
- (8) Disconnect the throttle control (6) from the governor and the choke control (5) from the carburetor (11).
- (9) Disconnect the fuel line tubing (fig. 18) outlet oil line tubing (2), inlet oil tubing (3), and the pressure gage oil line tubing (4).
- (10) Remove the 4 bolts (25) and 4 lockwashers (26) that secure the engine (24) to the frame.
- (11) Use a suitable lifting device and lift the engine off the frame.

b. Installation.

- (1) Hoist the engine (24, fig. 18) with a suitable lifting device and place it on the frame of the test stand. Secure in place with the 4 lockwashers (26) and 4 bolts (25).
- (2) Connect the pressure gage oil line tubing (4), inlet oil tubing (3), outlet oil line tubing (2), and the fuel line tubing (1).
- (3) Connect the throttle control (6, fig. 11) to the governor and the choke control (5) to the carburetor (11).
- (4) Install the fuel tank (par. 132).
- (5) Install the muffler (par. 121).




Figure 18. Engine and fuel tank, removal points.

1 Fuel line tubing	10 Bolt (4 rqr)	19 Pipe plug
2 Outlet oil line tubing	11 Flat washer (4 rqr)	20 Elbow
3 Inlet oil line tubing	12 Lockwasher (4 rqr)	21 Roller chain
4 Pressure gage oil line tubing	13 Nut (4 rqr)	22 Coupling half
5 Spout support	14 Strap liner (2 rqr)	23 Coupling half
6 Bolt (2 rqr)	15 Fuel tank strap (2 rqr)	24 Engine
7 Flat washer (2 rqr)	16 Fuel tank	25 Bolt (8 rqr)
8 Lockwasher (2 rqr)	17 Fuel tank cap	26 Lockwasher (8 rqr)
9 Nut (2 rqr)	18 Safety pin	

Figure 18—Continued.

-
- | | |
|--|---|
| (6) Install the air cleaner (par. 116). | (9) Install the hydraulic pump (par. 157). |
| (7) Install the electrical engine starter (par. 113). | (10) Install the pipe plug in the elbow (23, fig. 11). Remove the breather cap (1) and fill the crankcase with oil. Refer to the lubrication chart table 1. |
| (8) Install the engine accessory generator (par. 112). | |

CHAPTER 5

ENGINE MAINTENANCE INSTRUCTIONS

Section I. ENGINE ACCESSORIES

109. General

The engine accessories consist of the ignition magneto, electrical engine starter, generator, and generator regulator. The magneto is a flange-mounted type. A permanent magnet, mounted on the rotor shaft, produces a high voltage current as its field passes through a fixed coil. The current produced is fed to the spark plugs at the proper instant by a distributor. The electrical engine starter is a 6-volt, 4-brush, bendix-drive type. The starter converts electrical energy from the battery into mechanical power and transmits this power to the engine flywheel for electrical starting. The engine accessory generator is a 6-volt, shunt wound, 2-bush, belt-driven, direct-current generator used to supply current for charging the 6-volt battery of the test stand. The generator regulator is a 6-volt unit provided to control the charging current from the generator to the battery.

110. Armature Relay Replacement

a. Removal.

- (1) Tag and disconnect the electrical wires and cables from the terminals of the armature relay (18, fig. 17).
- (2) Remove the two hex nuts (19), lockwashers (20), flat washers (21), and bolts (22) that secure the relay to the frame and remove the relay.

b. Installation.

- (1) Position the armature relay (18) on the frame and secure with the two bolts (22), flat washers (21), lockwashers (20), and hex nuts (19).
- (2) Connect the electrical wires and-cables to the armature relay.

111. Engine Generator Regulator

a. On-engine Testing. Defects in the generator or regulator are indicated on the ammeter by a continuous high-charging rate when the battery is fully charged, or by a low-or no-charging rate when the battery is low.

- (1) When a high-charging rate is indicated, run the engine at operating speed and disconnect the lead. from the field terminal. If the output remains high, the trouble is in the generator. Replace or repair a defective generator (par. 112). If the output drops off, the trouble is in the regulator. Replace a defective regulator.
- (2) When a low or no charging rate is indicated, inspect for loose connections, frayed or damaged wires, or a defective battery. If none of these conditions exist, operate the engine at medium speed and momentarily ground the field terminal of the regulator. No increase indicates a defect in the generator. Repair or replace a defective generator (par. 112). An increase indicates the regulator is faulty. Replace a defective regulator.

b. Removal.

- (1) Disconnect the battery terminal adapters (7, and 8, fig. 17).
- (2) Remove the four screws (24) that secure the cover (23) to the box assembly (28) and remove the cover.
- (3) Tag and disconnect all electrical wires from the engine generator regulator (25).
- (4) Remove the three screws (26) and lockwashers (27) that secure the regulator in the box assembly and remove the regulator.

c. Installation.

- (1) Position the engine generator regulator (25, fig. 17) in the box assembly (28) and secure with the three lockwashers (27) and screws (26).
- (2) Connect all electrical leads to the regulator in accordance with tags attached during removal,
- (3) Place the cover (23) on the box assembly and secure with the four screws (24).
- (4) Connect the two battery terminal adapters (7 and 8, fig. 17).

112. Engine Accessory Generator

a. Belt Adjustment.

- (1) Loosen the bolt (10, fig. 16) that secures the engine accessory generator (9) to the generator adjusting arm (14).
- (2) Swing the generator toward or away from the engine as required to obtain a $\frac{3}{4}$ to 1 inch deflection of the belt midway between the pulleys. Tighten the bolt (10) to secure.

b. Belt Replacement.

- (1) Loosen the bolt (10, fig. 16), move the engine accessory generator (9) toward the generator mounting plate (20) and remove the belt from the pulleys.
- (2) Place a new belt on the pulleys and adjust as prescribed in *a* above.

c. Removal.

- (1) Remove the bolt (10, fig. 16) lockwasher (12), and flat washer (13), swing the engine accessory generator (9) in toward the generator mounting plate (20) and remove the V-belt from the pulley of the generator.
- (2) Tag and disconnect the 2 shielded cables from the 2 electrical box connectors (4).
- (3) Remove the two bolts (11), lockwashers (12), and flat washers (13) that secure the generator to the mounting plate and remove the generator.
- (4) Remove the screw (2) and lockwasher (3) that secure the generator shield box (1) to the generator, Lift the

box off the generator and tag and disconnect the leads from the generator.

d. Disassembly.

- (1) Remove the hex nut (17, fig. 19) and lockwasher (16) that secure the pulley (15) and the fan (18) to the shaft of the armature (31).
- (2) Remove the pulley and fan from the armature shaft.

e. Cleaning, Inspection and Repair.

- (1) Clean the outside of the generator with a cloth dampened with an approved cleaning solvent and dry thoroughly. Clean all other metal parts in an approved solvent and dry with a lint-free cloth.
- (2) Inspect the terminal studs for corrosion. Remove all corrosion and apply a thin film of grease.
- (3) Inspect the brushes through the holes in the end bell. Replace brushes that are oil soaked or worn to less than half their original length. See *f* below.
- (4) Inspect the pulley and fan for cracks, breaks, and distortion. Straighten a bent or distorted pulley and fan. Replace a pulley or fan damaged beyond repair.
- (5) Inspect all attaching hardware for distortion and damaged threads. Replace if defective.

f. Brush Replacement.

- (1) Remove the two bolts (2, fig. 19) and lockwashers (3) that secure the end bell (1) to the housing (44) and remove the end bell with attached brushes from the housing.
- (2) Remove the screw (10) and lockwasher (11) that secures the lead of the brush (9) to the grounded brush holder assembly (4).
- (3) Lift the brush arm (12) and remove the brush from the holder.
- (4) Remove the remaining brush in a similar manner.
- (5) Lift the brush arm (12) and install a new brush (9) in the grounded brush holder assembly (4).
- (6) Secure the lead of the brush to the




Figure 19. Engine accessory generator, exploded view.

1 End bell	16 Lockwasher	31 Armature
2 Bolt (2 rqr)	17 Nut	32 Pole piece (2 rqr)
3 Lockwasher (2 rqr)	18 Fan	33 Screw (2 rqr)
4 Grounded brush holder assembly	19 Woodruff key	34 Field winding
5 Insulated brush holder assembly	20 Bearing retaining plate	35 Insulator plate (2 rqr)
6 Screw	21 Screw (3 rqr)	36 Nut (4 rqr)
7 Lockwasher	22 Lockwasher (3 rqr)	37 Lockwasher (4 rqr)
8 Nut	23 Gasket	38 Flat washer (2 rqr)
9 Brush (2 rqr)	24 Flat washer	39 Insulating washer
10 Screw	25 Ball bearing	40 Bushing insulator
11 Lockwasher	26 Felt retainer plate	41 Stud terminal
12 Arm (2 rqr)	27 Preformed felt	42 Bushing insulator
13 Spring (2 rqr)	28 Oiler	43 Stud terminal
14 Flat washer (2 rqr)	29 Collar	44 Housing
15 Pulley	30 End bell	

Figure 19—Continued.

holder with the lockwasher (11) and screw (10).

- (7) Install the other brush in a similar manner.
- (8) Position the end bell (1) on the housing (44) and secure with the two lockwashers (3) and bolts (2).

g. Reassembly.

- (1) Mount the fan (18, fig. 19) and the pulley (15) on the shaft of the armature (31).
- (2) Install the lockwasher (16) and hex nut (17) on the armature shaft.

h. Installation.

- (1) Connect the leads of the shield box (1, fig. 16) to the terminals of the engine accessory generator (9) in accordance with tags attached during removal. Place shield box on the generator and secure with the lockwasher (3) and screw (2).
- (2) Position the generator on the generator mounting plate (20) and secure with the two flat washers (13), lockwashers (12), and bolts (11).
- (3) Install the belt on the pulleys and adjust the belt as prescribed in *a* above.
- (4) Connect the 2 shielded cables to the 2 electrical plug connectors (4) in accordance with tags attached during removal.

113. Electrical Engine Starter

a. Removal.

- (1) Remove the battery (par. 9).


- (2) Disconnect the electrical cable from the starter.
- (3) Remove two hex nuts and lockwashers that secure the starter support bracket (21, fig. 20) to the crankcase.
- (4) Remove the three bolts and lockwashers that secure the starter in the fly-wheel shroud and remove the starter.
- (5) Remove the screw (22) and flat washer (36) that secures the support bracket to the end bell (24) and remove the bracket from the starter.

b. Cleaning and Inspection.

- (1) Clean the external surfaces of the starter with a cloth dampened in an approved cleaning solvent and dry thoroughly. Clean corrosion from the electrical terminal of the starter.
- (2) Inspect the terminal of the starter for corrosion and damaged threads.
- (3) Remove the brush access cover and inspect the starter internally for damage. Inspect the brushes for oil soaked condition and excessive wear. If the brushes are less than half their original length replace the brushes as directed in *c* below. Refer a defective starter to depot maintenance for overhaul.

c. Brush Replacement.

- (1) Lift the four brushes (28 and 29) out of the brush holders.
- (2) Remove the four screws (25) and lockwashers (26) that secure the end bell (24) to the housing assembly (35) and remove the end bell.



- | | |
|---|---|
| 1 Bolt, machine No. 10-32 x $\frac{31}{32}$ in. (4 rqr) | 19 Thrust washer |
| 2 Washer, lock, No. 10 (4 rqr) | 20 Armature |
| 3 Screw, machine No. 8-32 x $\frac{3}{8}$ in. (4 rqr) | 21 Starter support bracket |
| 4 Drive housing | 22 Screw, machine, No. 10-32 x $\frac{1}{2}$ in. |
| 5 Pillow block cap | 23 Brush access cover |
| 6 Sleeve bearing | 24 End bell |
| 7 Plain seal | 25 Screw, machine No. 10-32 x $\frac{3}{8}$ in. (4 rqr) |
| 8 Shoulder bolt | 26 Washer, lock No. 10 (4 rqr) |
| 9 Shoulder bolt | 27 Spring (4 rqr) |
| 10 Key washer (2 rqr) | 28 Brush (2 rqr) |
| 11 Shaft and pinion assembly | 29 Brush (2 rqr) |
| 12 Spring | 30 Nut, plain, hex $\frac{5}{16}$ -24 (2 rqr) |
| 13 Driving head | 31 Washer, lock $\frac{3}{16}$ in. (2 rqr) |
| 14 Gasket | 32 Washer, flat $\frac{3}{16}$ in. |
| 15 Bearing plate assembly | 33 Insulator washer |
| 16 Woodruff key | 34 Field winding assembly |
| 17 Thrust washer (2 rqr) | 35 Housing assembly |
| 18 Spring tension washer | 36 Washer, flat No. 10 |

Figure 20. Electrical engine starter, exploded view.

- | | |
|--|--|
| (3) Unsolder the leads of the two brushes (29) from the field winding assembly (34). | (6) Position the end bell (24) on the housing assembly (35) and secure with the four lockwashers (26) and screws (25). |
| (4) Unsolder the leads of the two brushes (28) from the brush holders. | (7) Insert the four brushes into the brush holders under the tension springs. |
| (5) Solder the leads of four new brushes to the winding assembly and brush holders. | (8) Install the brush access cover (23) on the housing assembly. |

d. Installation.

- (1) Position the starter support bracket (21, fig. 20) on the end bell (24) and secure with the lockwasher (36) and screw (22).
- (2) Install the starter in the flywheel shroud and secure with the three lockwashers and bolts.
- (3) Secure the starter support bracket to the crankcase with two lockwashers and hex nuts.
- (4) Connect the electrical cable to the terminal of the starter.
- (5) Install the battery (par. 9).

114. Spark Plugs and Cables

a. Removal.

- (1) Remove the screw (9, fig. 11) and clamp (12) that secures the ignition cable (8) to the cylinder head shroud (13).
- (2) Tag and disconnect the ignition cable (8) from the spark plug (7) and the ignition magneto (21).
- (3) Remove the spark plug and gasket from the cylinder head.
- (4) Remove the three remaining spark plugs and ignition cables in a similar manner.

b. Cleaning, Inspection, and Repair.

- (1) Clean the outside of the spark plugs and ignition cables with a cloth dampened in cleaning solvent and dry thoroughly.
- (2) Inspect the ignition cables for cracked or frayed shielding, damaged threads, and broken or missing clamps. Replace broken or missing clamps and replace the cables if damaged.
- (3) Clean the spark plugs with a suitable plug cleaner. Inspect the spark plugs for burned electrodes and for cracked porcelain. Replace a defective spark plug.

c. Installation.

- (1) Install the gasket and spark plug (7, fig. 11) in the cylinder head and tighten to a 25 to 30 lb. torque.
- (2) Connect the ignition cable (8) to the

installed spark plug and ignition magneto (21).

- (3) Secure the ignition cable to the cylinder head shroud (13) with the clamp (12) and screw (9).
- (4) Install the three remaining spark plugs and ignition cables in a similar manner.

115. Ignition Magneto

a. Testing Magneto Spark.

- (1) Tag and disconnect the four ignition cables (8, fig. 11) from the ignition magneto (21).
- (2) Insert an insulated wire, bared at both ends, into one of the terminal posts of the magneto.
- (3) Place the ignition switch (1, fig. 10) in the ON position and crank the engine with the starter. With the bared end of the wire held one-eighth inch away from the cylinder head shroud, an intense blue spark should be observed.
- (4) Continue the test inserting the wire in the three remaining terminal posts of the magneto.
- (5) If no spark is observed, disconnect the switch-to-magneto lead by removing the screw (29, fig. 11). Retest for a spark. If a spark is now observed, the ignition switch is defective and must be replaced.
- (6) If no spark is observed in the procedures outlined in (1) through (5) above, replace the breaker points as described in e below.

b. Removal.

- (1) Disconnect the switch-to-magneto lead at the screw (29, fig. 11).
- (2) Tag and disconnect the four ignition cables (8) from the magneto (21).
- (3) Disconnect the ground strap (16) from the cylinder head.
- (4) Remove the two hex nuts and the bolt that secures the magneto in place and remove the magneto and gasket.

c. Disassembly.

- (1) Remove the 2 screws (2, fig. 21) that secure the capacitor (1) in the end cap (9) and remove the capacitor.




Figure 21. Ignition magneto, exploded view.

1	Capacitor	26	Spring
2	Screw, machine, No. 6-32 x $\frac{3}{8}$ in. (2 rqr)	27	Threaded straight pin
3	Nut (2 rqr)	28	Woodruff key
4	Washer (2 rqr)	29	Magneto coupling
5	Screw (2 rqr)	30	Spring
6	Bushing insulator (2 rqr)	31	Packing retainer
7	Electrical contact	32	Flat washer
8	Plate insulator	33	Preformed packing
9	End cap	34	Flat washer
10	Screw, machine, No. 10-24 x $\frac{5}{8}$ in. (2 rqr)	35	Retaining ring
11	Screw, machine, No. 10-24 x $1\frac{1}{8}$ in. (2 rqr)	36	Retaining ring
12	Distributor rotor	37	Ball bearing
13	Wick and holder assembly	38	Retaining ring
14	Screw (2 rqr)	39	Spur gear
15	Lockwasher (2 rqr)	40	Sleeve bearing
16	Contact set	41	Retaining ring
17	Retaining ring	42	Spur gear
18	Lockwasher (2 rqr)	43	Threaded straight pin
19	Screw (2 rqr)	44	Flat washer
20	Screw, machine, No. 8-32 x $\frac{3}{8}$ in. (4 rqr)	45	Roller bearing
21	Cotter pin	46	Contact breaker plate
22	Nut	47	Magneto rotor
23	Helical gear	48	Magneto coil
24	Sleeve bushing	49	Setscrew $\frac{1}{4}$ -20 x $\frac{3}{8}$ in. (2 rqr)
25	Housing	50	Magneto housing

Figure 21.—Continued.

-
- (2) Remove the 2 screws (10) and 2 screws (11) that secure the end cap (9) to the magneto housing (50) and remove the end cap.
 - (3) Remove the distributor rotor (12) from the spur gear (39).
- d. Cleaning, Inspection, and Repair.*
- (1) Clean the outside of the magneto, end cap, and rotor with a cloth dampened with an approved cleaning solvent and dry thoroughly.
 - (2) Inspect the end cap and rotor for cracks, breaks or other visible damage. Replace a defective end cap and rotor.
 - (3) Inspect the points of the contact set for pitting or burning. Replace a defective contact set.
- c. Contact Set Replacement.*
- (1) Remove and disassemble the ignition magneto as described in *b* and *c* above.
 - (2) Remove the screw (19, fig. 21) and lockwasher (18) that disconnect the electrical leads from the contact set, (16).
 - (3) Remove the retaining ring (17) that secures the movable member of the contact set to the contact breaker plate (46) and remove the movable contact.
- (4) Remove the two screws (14) and lockwashers (15) that secure the wick and holder assembly (13) and the stationary member of the contact set (16) to the breaker plate and remove the contact and wick holder.
 - (5) Position the stationary member of the contact set (16) and the wick and holder assembly (13) on the contact breaker plate (46) and secure with the two lockwashers (15) and screws (14).
 - (6) Place the movable member of the contact set (16) on the pin of the contact breaker plate (46) and install the retaining ring (17).
 - (7) Connect the electrical leads of the magneto to the contact set (16) with the lockwasher (18) and screw (19).
 - (8) Adjust the breaker point gap setting as prescribed in *f* below.
 - (9) Reassemble and install the ignition magneto as outlined in *g* and *h* below.
- f. Contact Set Adjustment.*
- (1) Remove and disassemble the magneto as described in *b* and *c* above.
 - (2) Loosen the two screws (14, fig. 21) and increase or decrease the clearance between the stationary point and the

movable point to obtain the proper clearance of 0.015 inch.

- (3) Tighten the 2 screws (14) and reinspect the clearance.
- (4) Reassemble and install the magneto as outlined in *g* and *h* below.

g. Reassembly.

- (1) Install the distributor rotor (12, fig. 21) on the spur gear (39).
- (2) Position the end cap (9) on the magneto housing (50) and secure with the 2 screws (10) and 2 screws (11).
- (3) Insert the capacitor (1) in the end cap and secure with the two screws (2).

h. Timing and Installation.

- (1) Remove the spark plug from the number 1 cylinder (par. 114).
- (2) Crank the engine slowly until air blows from the spark plug hole, indicating start of the compression stroke. Continue cranking until the edge of the marked flywheel vane is in line with the mark on the shroud as shown in figure 22.
- (3) Remove the timing hole plug (18, fig. 11) from the gear cover (19).
- (4) Turn the magneto drive gear clockwise so that when the magneto is positioned on the engine, its drive gear will engage the idler gear with the marked

FIRING ORDER 1-3-4-2




Figure 22. Engine timing marks.

tooth of the drive gear visible through the lower half of the inspection hole as illustrated in figure 22.

- (5) Position a new gasket and the ignition magneto (21, fig. 11) in place on the engine and secure with the bolt and two hex nuts.
- (6) Install the timing hole plug (18) in the hole of the gear cover (19).
- (7) Connect the ground strap (16) to the cylinder head.
- (8) Connect the four ignition cables (8) to the magneto.
- (9) Connect the switch-to-magneto lead at the screw (29).
- (10) Install the spark plug in the number 1 cylinder (par. 114).

116. Air Cleaner Assembly

a. Removal.

- (1) Loosen the two hose clamps that secure the hose to the carburetor (11, fig. 11) and the air cleaner assembly (14) and remove the clamps, sleeve spacer and the hose from the air cleaner and the carburetor.

- (2) Remove the four hex nuts, lockwashers, and bolts that secure the air cleaner assembly to the flywheel shroud and remove the air cleaner.

b. Cleaning and Inspection.

- (1) Clean all metal parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the hose for oil soaked condition and other visible signs of deterioration. Replace a defective hose.
- (3) Inspect the air cleaner assembly for cracks, breaks, and distortion. Inspect the oil cup of the air cleaner for leaks. Replace a defective air cleaner assembly.

c. Installation.

- (1) Position the air cleaner assembly (14, fig. 11) on the flywheel shroud and secure with four bolts, lockwashers, and hex nuts.
- (2) Install the hose sleeve spacer and two hose clamps on the carburetor (11) and air cleaner and tighten the clamps.
- (3) Service the air cleaner assembly as prescribed in paragraph 52.

Section II. AIR SHROUDING GROUP

117. General

The air shrouding group, made up of the flywheel shroud, heat deflectors, cylinder shrouds, and shroud covers, is incorporated to direct forced cooling air from the flywheel over the cooling fin surfaces of the cylinders and cylinder heads.


118. Flywheel and Flywheel Shroud

a. Removal.

- (1) Remove the housing assembly (par. 106).
- (2) Remove the electrical engine starter (par. 113).
- (3) Remove the engine accessory generator (par. 112).
- (4) Remove the muffler (par. 121).
- (5) Remove the eight screws (2, fig. 23) and lockwashers (3) that secure the flywheel shroud screen (1) to the fly-

wheel shroud (18) and remove the screen from the shroud.

- (6) Remove the six bolts (18, fig. 36) and lockwashers (19) that secure the generator drive sheave (17) to the flywheel (20) and remove the sheave.
- (7) Remove the headless straight pin (14) from the crankshaft (34).
- (8) Bend the locking ears of the lockwashers (16) away from the hex nut (15) and remove the nut from the crankshaft.
- (9) Strike the end of the crankshaft with a soft hammer to dislodge the flywheel from the taper on the crankshaft. Remove the flywheel and woodruff key (21) from the crankshaft.
- (10) Remove the eight bolts (9, fig. 23) and lockwashers (10) that secure the flywheel shroud to the cylinder head



- | | | | |
|---|--|----|--|
| 1 | Flywheel shroud screen | 10 | Washer, lock $\frac{1}{4}$ in. (13 rqr) |
| 2 | Screw, machine, $\frac{1}{4}$ -20 x $\frac{3}{8}$ in. (8 rqr) | 11 | Rear shroud cover, right-hand |
| 3 | Washer, lock, $\frac{1}{4}$ in. (8 rqr) | 12 | Rear shroud cover, left-hand |
| 4 | Identification plate | 13 | Bolt, machine, $\frac{1}{4}$ -20 x $\frac{3}{8}$ in. (2 rqr) |
| 5 | Screw, tapping, thread forming,
No. 4 x $\frac{1}{4}$ in. (4 rqr) | 14 | Washer, lock, $\frac{1}{4}$ in. (5 rqr) |
| 6 | Cylinder head shroud, right-hand | 15 | Lower cylinder shroud |
| 7 | Cylinder head shroud, left-hand | 16 | Cylinder heat deflector, right-hand |
| 8 | Screw, machine, $\frac{1}{4}$ -20 x $\frac{3}{8}$ in. (13 rqr) | 17 | Cylinder heat deflector, left-hand |
| 9 | Bolt, machine, $\frac{1}{4}$ -20 x $\frac{3}{8}$ in. (8 rqr) | 18 | Flywheel shroud |

Figure 23. Air shrouding group, exploded view.

shrouds (6 and 7), lower cylinder shrouds (15), and the cylinder heat deflectors (16 and 17).

- (11) Remove the six bolts and lockwashers that secure the flywheel shroud to the gear cover and remove the flywheel shroud.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Inspect the flywheel shroud and the screen for cracks, breaks, distortion, and damaged threads. Straighten a bent or distorted shroud and screen and repair cracks and breaks by welding. Replace a shroud or screen damaged beyond repair.
- (3) Inspect the flywheel for cracks, breaks, and damaged threads. Replace a damaged flywheel.

c. Installation.

- (1) Position the flywheel shroud (18, fig. 23) on the gear cover and secure with six lockwashers and bolts.
- (2) Secure the flywheel shroud to the cylinder heat deflectors (16 and 17), lower cylinder shrouds (15), and cylinder head shrouds (6 and 7) with the eight lockwashers (10), and bolts (9).
- (3) Insert the woodruff key (21, fig. 36) in the crankshaft (34). Install the flywheel (20) on the crankshaft and secure with the lockwasher (16) and hex nut (15).
- (4) Install the headless straight pin (14) in the crankshaft.
- (5) Position the generator drive sheave (17) on the flywheel and secure with the six lockwashers (19) and bolts (18),
- (6) Mount the flywheel shroud screen (1, fig. 23) on the flywheel shroud (18) and secure with the eight lockwashers (3) and screws (2).
- (7) Install the muffler (par. 121).
- (8) Install the engine accessory generator (par. 112).
- (9) Install the electrical engine starter (par. 113).

- (10) Install the housing assembly (par. 106).

119. Cylinder Shrouds and Heat Deflectors

a. Removal.

- (1) Remove the ignition cables and spark plugs (par. 114).
- (2) Remove the five screws (8, fig. 23) and lockwashers (10) that secure the cylinder head shroud (7) to the rear shroud cover (12), lower cylinder shroud (15), and the flywheel shroud (18) and remove the cylinder head shroud.
- (3) Remove the two bolts (13), lockwashers (14), screw (8), and lockwasher (10) that secure the rear shroud cover (12) in place and remove the shroud cover.
- (4) Remove the two bolts (9) and lockwashers (10) that secure the lower shroud (15) to the cylinder and remove the lower shroud.
- (5) Remove the manifold (par. 123).
- (6) Remove the screw (8) and lockwasher (10) that secure the cylinder heat deflector (17) to the flywheel shroud (18) and remove the heat deflector.
- (7) Remove the remaining shrouds and heat deflector in a similar manner.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the various shrouds for dents, cracks, breaks, and damaged threads. Straighten minor dents and repair cracks and breaks by welding. Replace a shroud or heat deflector damaged beyond repair.
- (3) Retouch or repaint all shrouds as required to protect metal surfaces.

c. Installation.

- (1) Position the heat deflector (17, fig. 23) on the flywheel shroud (18) and secure with the lockwasher (10) and screw (8).
- (2) Install the manifold (par. 123).
- (3) Secure the lower shroud (15) to the cylinder with the two lockwashers (10) and bolts (9).

- (4) Position the rear shroud cover (12) on the lower shroud and heat deflector and secure with the lockwasher (10), screw (8), 2 lockwashers (14) and 2 bolts (13).
- (5) Place the cylinder head shroud (7) on the installed shroud cover and lower

shroud and secure with the five lockwashers (10) and screws (8).

- (6) Install the spark plugs and ignition cables (par, 114).
- (7) Install the remaining shrouds and heat deflector in a similar manner.

Section III. MANIFOLD AND CYLINDER BLOCK GROUP

120. General

The manifold and cylinder block group, consisting of the carburetor, intake and exhaust manifold, cylinder heads, cylinder block assemblies, and the muffler, make up the upper portion of the engine where mixing and combustion of the fuel takes place. The carburetor meters fuel into the air stream passing into the manifold. The intake valves of the cylinder block assemblies admit the air-fuel mixture into their respective cylinders at the precise time for compression and combustion. The burnt gases pass out of the cylinder through the exhaust valves, manifold, and muffler.

121. Muffler

a. Removal.

- (1) Remove the two pipe nipples (1 and 4, fig. 8) and elbow (3).
- (2) Remove the elbow (6, fig. 24) from the muffler (7).
- (3) Remove the two hex nuts (10), lockwashers (9), and the clamp (8) that secure the muffler to the muffler mount (11) and unscrew the muffler from the coupling (12).
- (4) Remove the coupling, pipe nipple (13), and elbow (14) from the intake and exhaust manifold (24).

b. Cleaning, Inspection, and Repair.

- (1) Clean rust and corrosion from the muffler and all fittings with a wire brush.
- (2) Inspect the muffler for cracks, breaks, and damaged threads. Replace a defective muffler.
- (3) Inspect the various fittings for cracks, breaks, distortion, and damaged threads. Repair damaged threads.

Replace a fitting damaged beyond repair.

- (4) Inspect all attaching parts for distortion and damaged threads. Replace all defective parts,

c. Installation.

- (1) Install the elbow (14, fig. 24), pipe nipple (13), and coupling (12) in the intake and exhaust manifold (24).
- (2) Install the muffler (7) in the coupling (12) and secure the muffler to the muffler mount (11) with the clamp (8), two lockwashers (9), and hex nuts (10).
- (3) Install the elbow (6) on the muffler.
- (4) Install the two pipe nipples (1 and 4, fig. 8) and the elbow (3).

122. Carburetor

a. Adjustment.

- (1) Start the engine (par. 41) and allow the engine to warm up properly before making any adjustments on the carburetor.
- (2) Close the throttle and adjust the throttle stop screw (14, fig. 25) for the desired idle speed.
- (3) Turn the idle adjusting needle (20) counterclockwise until the engine rolls because of a rich mixture.
- (4) Turn the needle clockwise until the engine runs irregularly because of a lean mixture.
- (5) Turn the needle counterclockwise again as far as possible maintaining smooth engine operation.

Note. This adjustment will give a slower idling speed than a slightly leaner adjustment with the same throttle stop screw setting, but will give the smoothest performance.

- (6) Readjust the throttle stop screw as necessary to obtain proper idle speed.

b. Removal.

- (1) Disconnect the choke control (15, fig. 24) from the carburetor (18).
- (2) Disconnect the fuel line from the carburetor.
- (3) Disconnect the governor linkage from the throttle shaft assembly (16, fig. 25).
- (4) Remove the hose of the air cleaner assembly (par. 116).
- (5) Remove the two bolts (16, fig. 24) and lockwashers (17) that secure the carburetor (18) and gasket (19) to the intake and exhaust manifold (24) and remove the carburetor and gasket.

c. Disassembly.

- (1) Remove the bolt (2, fig. 25) and gasket (3) that secure the fuel sediment bowl (1) and gasket (4) to the body (34) and remove the bowl and gasket.
- (2) Remove the headless straight pin (6) and the float (5) from the body.
- (3) Remove the valve assembly (7) from the body.
- (4) Remove the main nozzle (8), gasket (9), and power jet (10) from the body.
- (5) Remove the packing retainer (17) and preformed packing (18) from the body.
- (6) Remove the idle adjusting needle (20) and the spring (21) from the body.
- (7) Remove the screw (14) and spring (15) from the throttle shaft assembly (16).
- (8) Remove the two screws (13) that secure the throttle fly (12) to the throttle shaft assembly (16) and remove the throttle fly. Remove the throttle shaft assembly from the body.
- (9) Remove the two screws (23) that secure the choke fly (22) to the choke shaft assembly (28) and remove the choke fly.
- (10) Remove the choke shaft assembly from the body (34). Remove the cotter pin (26) and choke swivel (25) from the

shaft assembly. Remove the screw (24) from the swivel.

- (11) Disconnect the spring (27) from the bracket assembly (30). Remove the two screws (31) that secure the bracket assembly to the body and remove the bracket and the preformed packing (32).
- (12) Remove the two sleeve bushings (19) if defective or worn.

d. Cleaning, Inspection, and Repair.

- (1) Clean all metal parts with an approved cleaning solvent and dry thoroughly. Clear all fuel passages with compressed air.
- (2) Inspect the body for cracks, breaks, distortion, and damaged threads. Inspect the fuel passages making certain they are not obstructed. Repair damaged threads. Replace a body damaged beyond repair.
- (3) Inspect the float and sediment bowl for cracks and distortion. Repair cracks by soldering. Replace parts damaged beyond repair.
- (4) Inspect the valve assembly for proper closing and seating. Replace a defective valve assembly.
- (5) Inspect all other parts for distortion and damage. Replace all defective parts.

e. Reassemble.

- (1) Install the two sleeve bushings (19, fig. 25) in the body (34).
- (2) Insert the preformed packing (32) in the body. Position the bracket assembly (30) on the body and secure with the two screws (31). Attach the spring (27) to the bracket.
- (3) Install the choke shaft assembly (28) in the body. Position the choke fly assembly (22) on the shaft assembly and secure with the two screws (23).
- (4) Install the screw (24) in the choke swivel (25). Insert the swivel in the shaft assembly and install the cotter pin (26).
- (5) Insert the throttle shaft assembly (16) in the body (34). Position the throttle




Figure 24. Manifold and crankcase group, removal points.

- 1 Bolt, machine, $\frac{3}{8}$ -16 x $1\frac{1}{2}$ in. (34 rqr)
- 2 Washer, flat, $\frac{3}{8}$ in. (34 rqr)
- 3 Cylinder block head assembly (2 rqr)
- 4 Gasket (2 rqr)
- 5 Gasket (2 rqr)
- 6 Elbow
- 7 Muffler
- 8 Clamp
- 9 Lockwasher (2 rqr)
- 10 Nut (2 rqr)
- 11 Muffler mount
- 12 Coupling
- 13 Pipe nipple
- 14 Elbow
- 15 Choke control
- 16 Bolt, machine, $\frac{7}{16}$ -18 x $1\frac{1}{4}$ in. (2 rqr)
- 17 Washer, lock $\frac{7}{16}$ in. (2 rqr)

- 18 Carburetor
- 19 Gasket
- 20 Plug
- 21 Nut (4 rqr)
- 22 Lockwasher (4 rqr)
- 23 Stud (4 rqr)
- 24 Intake and exhaust manifold
- 25 Gasket insert (6 rqr)
- 26 Gasket (2 rqr)
- 27 Bolt, machine (14 rqr)
- 28 Lockwasher (14 rqr)
- 29 Crankcase bottom plate
- 30 Gasket
- 31 Crankcase assembly
- 32 Expansion plug
- 33 Expansion insert
- 34 Stud

Figure 24—Continued.

fly (12) on the shaft assembly and secure with the two screws (13).

- (6) Install the screw (14) and spring (15) on the throttle shaft assembly.
- (7) Install the preformed packing (18) and packing retainer (17) in the body.
- (8) Install the spring (21) and the idle adjusting needle (20) in the body.
- (9) Install a new gasket (9), main nozzle (8), and the power jet (10) in the body (34).
- (10) Install the valve assembly (7) in the body.
- (11) Position the float (5) on the body and install the headless straight pin (6).
- (12) Secure a new gasket (4) and the fuel sediment bowl (1) to the body with a new gasket (3) and the bolt (2).

f. Installation.

- (1) Secure a new gasket (9, fig. 24) and the carburetor (18) to the intake and exhaust manifold (24) with the two lockwashers (17) and bolts (16).
- (2) Install the hose of the air cleaner assembly (par. 116).
- (3) Connect the governor linkage to the throttle shaft assembly (16, fig. 25).
- (4) Connect the fuel line to the carburetor.
- (5) Connect the choke control (15, fig. 24) to the carburetor (18).
- (6) Adjust the carburetor as outlined in *a* above.

123. Intake and Exhaust Manifold

a. Removal.

- (1) Remove the muffler (par. 121).
- (2) Remove the carburetor (par. 122).
- (3) Remove the 4 hex nuts (21, fig. 24) and lockwashers (22) that secure the intake and exhaust manifold (24) and 2 gaskets (26) to the cylinder blocks. Remove the manifold, gaskets, and 6 gasket inserts (25) from the cylinder blocks.
- (4) Remove the four studs (23) from the cylinder blocks if defective.

b. Cleaning and Inspection.

- (1) Clean all rust and corrosion from the manifold with a wire brush.
- (2) Inspect the manifold for cracks, breaks, distortion, and damaged threads. Replace a defective manifold.
- (3) Inspect all attaching hardware for distortion and damaged threads. Replace if defective.

c. Installation.

- (1) Install the four studs (23, fig. 24) in the cylinder blocks.
- (2) Position the 6 gasket inserts (25), 2 new gaskets (26) and the intake and exhaust manifold (24) on the cylinder blocks and secure with the 4 lockwashers (22) and hex nuts (21). Tighten the nuts to 40 to 50 ft-lb torque.




Figure 25. Carburetor, exploded view.

1	Fuel sediment bowl	18	Preformed packing (2 rqr)
2	Bolt	19	Sleeve bushing (2 rqr)
3	Gasket	20	Idle adjusting needle
4	Gasket	21	Spring
5	Float	22	Choke fly assembly
6	Headless straight pin	23	Screw, machine, No. 4-40 x ¼ in. (2 rqr)
7	Valve assembly	24	Screw, machine, No. 8-32 x ¼ in.
8	Main nozzle	25	Choke swivel
9	Gasket	26	Cotter pin
10	Power jet	27	Spring
11	Cup	28	Choke shaft assembly
12	Throttle fly	29	Screw, machine, No. 8-32 x ¼ in.
13	Screw, machine, No. 4-40 x ¼ in. (2 rqr)	30	Bracket assembly
14	Screw, throttle stop, No. 8-32 x ¼ in.	31	Screw, machine 8-32 x ¾ in. (2 rqr)
15	Spring	32	Preformed packing
16	Throttle shaft assembly	33	Cup
17	Packing retainer (2 rqr)	34	Body

Figure 25—Continued.

(3) Install the carburetor (par. 122).

(4) Install the muffler (par. 121).

124. Cylinder Heads

a. Removal.

(1) Remove the air shrouding group (pars. 118 and 119).

(2) Remove the 17 bolts (1, fig. 24) and flat washers (2) that secure the cylinder block head assembly (3) and the gasket (4) to the cylinder block and remove the head and gasket.

(3) Remove the other cylinder head in a similar manner.

b. Cleaning and Inspection.

(1) Clean all carbon deposits from the cylinder blocks. Clean the carbon from the tops of the pistons and blow carbon away with compressed air.

(2) Brush and scrape the carbon out of the cylinder heads.

(3) Wipe the cylinder heads and blocks with a cloth dampened with an approved solvent and dry thoroughly.

(4) Inspect the cylinder heads for cracks, breaks, or warping. Replace a defective cylinder head.

(5) Inspect the top of the cylinder blocks for cracks or breaks. Inspect the cylinder walls for scoring or pitting. Report a defective block to depot maintenance.

(6) Inspect the top of the valve seats. Report defective valves or seats to depot maintenance.

c. Installation.

(1) Position a new gasket (4, fig. 24) and the cylinder block head assembly (3) on the cylinder block and secure with the 17 flat washers (2) and bolts (1). Tighten the bolts to 25 to 32 ft-lb torque.

(2) Install the remaining cylinder block head assembly in a similar manner.

(3) Install the air shrouding group (pars. 118 and 119).

125. Valve Lifters

a. Valve Inspection Covers.

(1) Removal.

(a) Remove the governor (par. 135).

(b) Remove the bolt (2, fig. 26) and flat washer (3) that secures the valve inspection cover (1) and gasket (4) to the cylinder block (13) and remove the cover and gasket.

(c) Remove the three remaining covers in a similar manner.


(2) Cleaning and Inspection.

(a) Clean the covers in an approved cleaning solvent and dry thoroughly.

(b) Inspect the covers for distortion and other visible damage. Replace a defective cover.

(3) Installation.

(a) Position the gasket (4, fig. 26) and the valve inspection cover (1) on the cylinder block (13) and secure with the flat washer (3) and bolt (2).



- | | | |
|--|-----------------------------|------------------------------|
| 1 Valve inspection cover (4 rqr) | 6 Rotator cap (8 rqr) | 10 Valve (8 rqr) |
| 2 Bolt, machine, $\frac{5}{16}$ -18 x $1\frac{1}{8}$ in. (4 rqr) | 7 Retainer lock (16 rqr) | 11 Valve seat insert (8 rqr) |
| 3 Washer, flat, $\frac{3}{16}$ in. (4 rqr) | 8 Valve spring seat (8 rqr) | 12 Valve stem guide (8 rqr) |
| 4 Gasket (4 rqr) | 9 Spring (8 rqr) | 13 Cylinder block (2 rqr) |
| 5 Tappet assembly (8 rqr) | | |

Figure 26. Cylinder block assembly, exploded view.

- (b) Install the three remaining covers in a similar manner.
- (c) Install the governor (par. 135).
- b. Valve Lifter Adjustment.**
- (1) Remove the valve inspection covers as outlined in **a** above.

- (2) Crank the engine slowly until the number 1 piston rising in compression stroke blows air out of the spark plug hole. Continue until the marked vane on the flywheel aligns with the number 1 centerline mark on the flywheel

shroud which is 45° counterclockwise from vertical as shown in figure 22.

- (3) Insert a feeler gage between the cap of the tappet assembly (5, fig. 26) and the end of the valve (10) and measure the clearance. The proper clearance for the intake valves is 0.008 and 0.016 inch for the exhaust valves cold. The clearance is correct when there is a slight drag felt as the feeler gage is moved.
- (4) Turn the cap of the tappet assembly until the correct clearance is obtained. The adjusting screw is self-locking and will hold this setting.

- (5) Turn the crankshaft 180° clockwise and adjust the lifter clearance of number 3 cylinder as in (3) above.
- (6) Turn the crankshaft until the marked vane is in line with the number 2 cylinder centerline (fig. 22). Adjust the lifter clearance of the number 4 cylinder as in (3) above.
- (7) Turn the crankshaft 180° clockwise and adjust the lifter clearance of the number 2 cylinder as in (3) above.
- (8) Install the valve inspection covers as outlined in *a* above.

Section IV. OIL FILLER AND FILTER MOUNTING GROUP

126. General

The oil filler and filter mounting group, made up of the oil filter, oil filler tube, breather cap, and oil sabre, provides a means of maintaining a clean supply of lubricating oil in the engine crankcase.

127. Oil Filler Tube and Sabre

a. Removal.

- (1) Remove the oil sabre (28, fig. 11) from the crankcase and remove the cork washer from the sabre.
- (2) Pull the breather cap (1) off the oil filler tube and remove the tube and the oil filler screen from the crankcase.

b. Cleaning and Inspection.

- (1) Clean all parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the filler cap, filler tube, and sabre for cracks, breaks, and distortion. Inspect the sabre for legible oil level marks. Replace all defective parts.
- (3) Inspect the screen for tears and clogged condition. Replace a defective screen.

c. Installation

- (1) Install the oil filler screen and the oil filler tube in the crankcase and install the breather cap (1, fig. 11) on the filler tube.

- (2) Install the cork washer on the oil sabre (28) and insert the sabre in the crankcase.

128. Oil Filter

a. Removal.

- (1) Remove the filter element from the oil filter (par. 52).
- (2) Disconnect the oil lines from each of the elbows in the oil filter (24, fig. 11) and remove the elbows from the oil filter.
- (3) Remove the four hex nuts, lockwashers, and bolts (25) that secure the oil filter to the frame and remove the filter.

b. Cleaning and Inspection.

- (1) Clean the oil filter with an approved solvent and dry thoroughly.
- (2) Inspect the oil filter for cracks, breaks, distortion, and damaged threads. Replace a defective oil filter.
- (3) Inspect all attaching parts for distortion and damaged threads. Replace all defective parts.

c. Installation.

- (1) Position the oil filter (24, fig. 11) on the frame and secure with the four bolts (25), lockwashers, and hex nuts.
- (2) Install the two elbows in the oil filter and connect the oil lines to the elbows.
- (3) Install a new filter element in the oil filter (par. 52).

Section V. FUEL PUMP, FUEL STRAINER AND FUEL TANK

129. General

The fuel pump, fuel strainer, and fuel tank make up the major component of the fuel system. The fuel pump delivers fuel from the fuel tank to the carburetor through the fuel strainer. The fuel pump is mounted on the fuel pump adapter and is operated by an arm and plunger mechanism which is actuated by the eccentric on the camshaft.

130. Fuel Strainer

a. Removal.

- (1) Disconnect the fuel line from the fuel strainer (1, fig. 27).
- (2) Remove the fuel strainer from the pipe nipple (2) and remove the nipple and elbow (3) from the fuel pump (5).

b. Cleaning and Inspection.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Inspect the fuel strainer for a cracked or broken glass. Inspect the strainer body for cracks, distortion, and damaged threads. Replace a defective fuel strainer.
- (3) Inspect the nipple and elbow for distortion and damaged threads. Replace a defective part.

c. Installation.

- (1) Install the elbow (3, fig. 27) and the pipe nipple (2) in the fuel pump (5).
- (2) Install the fuel strainer (1) on the nipple.
- (3) Connect the fuel line to the fuel strainer.

131. Fuel Pump and Adapter

a. Testing.

- (1) Be sure the fuel tank is filled.
- (2) Disconnect the fuel line (4, fig. 27) from the carburetor and actuate the primer handle lever (11). If fuel flows from the disconnected fuel line the fuel lines and pump are clear.
- (3) If there is no flow of fuel or very little, perform the following steps:
 - (a) Service the fuel strainer (par. 9).

(b) Inspect all fuel lines from the fuel pump back to the fuel tank and tighten any loose connections.

(c) Inspect for clogged fuel lines between the pump and tank. Blow out with compressed air to clear.

(d) Inspect the fuel pump cover screw and tighten if necessary.

- (4) Reinspect the fuel pump performance as directed in (2) above. If the pump operation is still unsatisfactory, repair or replace the fuel pump as outlined below.

b. Removal.

- (1) Remove the fuel strainer (par. 130).
- (2) Disconnect the fuel line (4, fig. 27) from the fuel pump (5) and the carburetor.
- (3) Remove the two bolts (6) and lockwashers (7) that secure the fuel pump and gasket (8) to the fuel pump adapter (15) and remove the fuel pump,
- (4) Remove the two screws (9) and lockwashers (10) that secure the pump adapter and the gasket (18) to the crankcase and remove the gasket and adapter.
- (5) Lift the plunger cap (17) with attached plunger (16) from the crankcase and remove the cap from the plunger.

c. Disassembly.

(1) Fuel Pump.

(a) Remove the bolt (1, fig. 28) and gasket (2) that secure the pulsator dome (3), gasket (4), and fuel filter (5) to the fuel head (7) and remove the dome, gasket, and filter from the head.

(b) Match mark the head and the mounting bracket (22) to facilitate alining of mating parts during reassembly.

(c) Remove the six screws and lockwasher assemblies (6) that secure the head to the bracket and remove the head with attached valves.

- (d) Remove the 3 screw and lockwasher assemblies (13) that secure the valve plate (12) and gasket (11) to the head and remove the valve plate, gasket, 2 valves (8), 2 springs (9), and spring retainer (10).
 - (e) To remove the diaphragm (14), hold the linkage (21) up by pressing down on the rocker arm (20). Press down on the diaphragm and disconnect the diaphragm from the linkage. Remove the diaphragm, spring (16) and gasket (15) from the mounting bracket (22).
 - (f) Compress and disengage the spring (17) from the rocker arm (20) and the mounting bracket.
 - (g) Drive the headless straight pin (18) out of the mounting bracket. Remove and separate the rocker arm (20), linkage (21), and the bushing (19).
- (2) *Fuel Pump Adapter.*
- (a) Remove the setscrew that secures the primer handle (11, fig. 27) in the primer shaft (14) and remove the handle and shaft from the fuel pump adapter (15).
 - (b) Remove the packing ring (13) and primer spring (12) from the adapter.
- d. *Cleaning, Inspection, and Repair.*
- (1) Clean all metal parts in an approved cleaning solvent and dry thoroughly. Clear all fuel passages with compressed air.
 - (2) Inspect the valve plate, dome, pump head, mounting bracket, and fuel pump adapter for cracks, breaks, distortion, and damaged threads. Replace defective parts.
 - (3) Inspect the rocker arm, linkage, primer shaft, and primer handle for cracks, breaks, and excessive wear. Replace all defective parts.
 - (4) Inspect the fuel filter for clogged or torn condition. Replace a defective filter.
 - (5) Inspect the springs for cracks, distortion and lack of tension. Replace a defective spring.
 - (6) Inspect all attaching hardware for distortion and damaged threads. Replace defective hardware.
- e. *Reassembly.*
- (1) *Fuel Pump Adapter.*
- (a) Install the primer spring (12, fig. 27) and the packing ring (13) on the fuel pump adapter (15).
 - (b) Insert the primer shaft (14) in the adapter. Install the primer handle (11) in the shaft and secure with the set screw in the shaft.
- (2) *Fuel Pump.*
- (a) Assemble the rocker arm (20, fig. 28) and the linkage (21). Insert the bushing (19) in the aligned holes of the arm and linkage.
 - (b) Position the arm and linkage in the mounting bracket (22) and drive the headless straight pin (18) into the aligned holes of the bracket and bushing.
 - (c) Install the spring (17) between the bosses of the rocker arm and the mounting bracket.
 - (d) Position a new gasket (15), spring (16) and a new diaphragm (14) on the mounting bracket (22). Hold the rocker arm (20) down and depress the diaphragm to engage it with the hook end of the linkage (21).
 - (e) Install the spring retainer (10), 2 springs (9), 2 valves (8), gasket (11), and valve plate (12) on the fuel head (7) and secure the valve plate with 3 screw and lockwasher assemblies (13).
 - (f) Position the fuel head on the diaphragm (14) and mounting bracket (22) in accordance with match marks made during disassembly and secure with the six screw and lockwasher assemblies (6).
 - (g) Place the fuel filter (5), a new gasket (4), and the pulsator dome (3) on the fuel head and secure with the gasket (2) and bolt (1).
- f. *Installation.*
- (1) Install the plunger cap (17, fig. 27)





Figure 27. Camshaft and fuel pump mounting group, removal points.

- | | |
|--|--|
| Fuel strainer | 14 Primer shaft |
| Pipe nipple | 15 Fuel pump adapter |
| Elbow | 16 Plunger |
| Fuel line | 17 Plunger cap |
| Fuel pump | 18 Gasket |
| Bolt, machine, $\frac{3}{16}$ -18 x $\frac{5}{8}$ in. (2 rqr) | 19 Plunger button |
| Washer, lock, $\frac{3}{16}$ in. (2 rqr) | 20 Thrust plunger |
| Gasket | 21 Spring |
| Screw, cap, socket head, $\frac{1}{4}$ -20 x $\frac{3}{4}$ in. (2 rqr) | 22 Camshaft gear |
| Washer, lock, $\frac{1}{4}$ in. (2 rqr) | 23 Washer, lock $\frac{3}{16}$ in. (3 rqr) |
| Primer handle | 24 Bolt, machine, $\frac{3}{16}$ -18 x 1 in. (3 rqr) |
| Primer spring | 25 Camshaft |
| Packing ring | |

Figure 27—Continued.



- | | |
|---|--|
| 1 Bolt, machine | 12 Valve plate |
| 2 Gasket | 13 Screw and lockwasher assembly (3 rqr) |
| 3 Pulsator dome | 14 Diaphragm kit |
| 4 Gasket | 15 Gasket |
| 5 Fuel filter | 16 Spring |
| 6 Screw and lockwasher assembly (6 rqr) | 17 Spring |
| 7 Fuel head | 18 Headless straight pin |
| 8 Valve (2 rqr) | 19 Bushing |
| 9 Spring (2 rqr) | 20 Rocker arm |
| 10 Spring retainer | 21 Linkage |
| 11 Gasket | 22 Mounting bracket |

Figure 28. Fuel pump, exploded view.

- on the plunger (16) and insert the plunger in the crankcase.
- (2) Place a new gasket (18) and the fuel pump adapter (15) on the crankcase over the installed plunger and plunger cap and secure in place with the two lockwashers (10) and screws (9).
 - (3) Position a new gasket (8) and the fuel pump (5) on the fuel pump adapter (15) and secure with the two lockwashers (7) and bolts (6).
 - (4) Connect the fuel line (4) to the fuel pump and carburetor.
 - (5) Install the fuel strainer (par. 130).

132. Fuel Tank

a. Removal.

- (1) Disconnect the fuel line tubing (1, fig. 18) from the elbow (20) and remove the elbow from the fuel tank (16).
- (2) Remove the fuel tank cap (17) and the safety pin (18) from the fuel tank.
- (3) Remove the pipe plug (19) from the fuel tank and drain the fuel into a suitable container.
- (4) Remove the two hex nuts (9), lockwashers (8), flat washers (7), and bolts (6) that secure the spout support (5) to the test stand frame.
- (5) Remove the 4 hex nuts (13), lockwashers (12), flat washers (11), and bolts (10) that secure the 2 fuel tank straps (15) and 2 strap liners (14) to the frame and remove the straps and the fuel tank.
- (6) Slip the spout support (5) off the spout.

b. Cleaning, Inspection, and Repair.

- (1) Rinse the tank interior thoroughly with an approved cleaning solvent. Clean the exterior of the fuel tank and all other metal parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the fuel tank for cracks, dents, damaged seams and threads and for weak or rusted spots. Repair minor leaks by soldering. Replace a tank damaged beyond repair.
- (3) Inspect the straps and all attaching parts for damage and distortion. Replace a defective part.

c. Installation.

- (1) Place the spout support (5, fig. 18) over the spout of the fuel tank (16).
- (2) Secure the fuel tank, strap liners (14), and fuel tank straps (15) to the underside of the frame with the four bolts (10), flatwashers (11), lockwashers (12), and hex nuts (13).
- (3) Position the spout support (5) on the frame and secure with the two bolts (6), flat washers (7), lockwashers (8) and hex nuts (9).
- (4) Install the pipe plug (19) in the bottom of the fuel tank.
- (5) Install the elbow (20) in the fuel tank and connect the fuel line (1).
- (6) Fill the tank with the proper grade fuel and install the fuel tank cap (17) and safety pin (18) on the spout of fuel tank.

Section VI. GOVERNOR AND CONTROL ASSEMBLY


133. General

The centrifugal flyweight governor is located at the top and to the rear side of the gear cover, It is driven by the camshaft at one and one-eighth camshaft speed. Centrifugal action of the rotating flyweights causes the governor to pull the carburetor throttle toward the closed or idle position, This action is counteracted by the spring of the control assembly. The adjusted tension on this spring determines the engine speed the governor will maintain.

134. Governor Control Assembly

a. Removal and Disassembly.

- (1) Disconnect the spring (27, fig. 29) from the adjusting screw (4) and the shaft and lever assembly (48).
- (2) Remove the screw (7) that secures the throttle control (6) to the control stop (8) and pull the throttle control out of the swivel block (16).
- (3) Pull the cotter pin (19) and remove the flat washer (20) and the lever



- | | | | | | |
|----|--|----|--------------------------------|----|--------------------------------------|
| 1 | Adjusting screw locknut | 19 | Cotter pin | 37 | Bearing |
| 2 | Spring | 20 | Flatwasher | 38 | Thrust sleeve |
| 3 | Cotter pin | 21 | Lever support pin | 39 | Headless straight pin |
| 4 | Adjusting screw | 22 | Oil line assembly | 40 | Flyweight hub |
| 5 | Swivel pin | 23 | Tee | 41 | Headed straight pin |
| 6 | Throttle control | 24 | Bushing | 42 | Plain tapered pin |
| 7 | Screw, machine | 25 | Pipe plug | 43 | Flyweight hub |
| 8 | Control stop | 26 | Tachometer adapter cap | 44 | Drive shaft |
| 9 | Nut (2 rqr) | 27 | Spring | 45 | Tachometer adapter |
| 10 | Lockwasher | 28 | Nut (3 rqr) | 46 | Gasket |
| 11 | Control support | 29 | Nut | 47 | Expansion plug |
| 12 | Control bracket | 30 | Lockwasher (4 rqr) | 48 | Shaft and lever assembly |
| 13 | Screw, tapping, thread forming,
No. 8 x 1/2 in. (2 rqr) | 31 | Control rod ball joint (2 rqr) | 49 | Preformed packing |
| 14 | Bolt, machine, No. 12-24 x 1/2 in. | 32 | Control lever rod | 50 | Sleeve bearing |
| 15 | Washer, flat, No. 12 (2 rqr) | 33 | Hearing | 51 | Yoke |
| 16 | Swivel pin | 34 | Helical gear | 52 | Pin, tapered, plain, No. 0 x 3/4 in. |
| 17 | Adjustment screw bushing | 35 | Woodruff key | 53 | Headless straight pin |
| 18 | Lever | 36 | Bearing | 54 | Housing |

Figure 29. Governor and control assembly, exploded view.

- (18) with attached parts from the lever support pin (21).
- (4) Remove the bolt (14), two flat washers (15) and the swivel block (16) from the lever.
- (5) Remove the adjusting screw locknut (1) from the adjusting screw (4) and

- remove the screw and spring (2) from the swivel pin (5). Remove the cotter pin (3) from the adjustment screw.
- (6) Remove the swivel pin (5) from the lever.

b. Cleaning and Inspection.

- (1) Clean all parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the lever, swivel pin, and lever support pin for cracks, breaks, and distortion. Replace all defective parts.
- (3) Inspect the springs for cracks, distortion and lack of tension. Replace a defective spring.
- (4) Inspect all other parts for distortion and damaged threads, Replace all defective parts.

c. Reassembly and Installation.

- (1) Install the swivel pin (5, fig. 29) in the lever (18).
- (2) Install the cotter pin (3) in the adjusting screw (4). Place the spring (2) on the adjusting screw and insert the screw in the swivel pin. Install the adjusting screw locknut (1) on the adjustment screw.
- (3) Install the swivel block (16), two flat washers (15), and the bolt (14) in the lever (18).
- (4) Position the lever with attached parts on the lever support pin (21) and install the flat washer (20) and cotter pin (19).
- (5) Insert the throttle control (6) through the swivel pin (16) and secure in the control stop (8) with the screw (7).
- (6) Connect the spring (27) to the adjusting screw (4) and the shaft and lever assembly (48).
- (7) Adjust the governor as outlined in paragraph 135.

135. Governor

a. Governor Adjustment.

- (1) Check and make certain the spring (27, fig. 29) is hooked in the number 6 hole of the shaft and lever assembly counting from the shaft outward.
- (2) With the engine at rest, remove the hex nut (29) and lockwasher (30) from the control rod ball joint (31).
- (3) Slip the ball joint out of the shaft and lever assembly (48) and push the control lever rod (32) toward the carburetor to fully open the throttle fly.

- (4) With the externally threaded portion of the ball joint at a right angle to the control lever rod, the ball joint must be in exact alinement with the top hole in the shaft and lever assembly.
- (5) Loosen the hex nut (28) and turn the ball joint on the rod to attain alinement specified in (4) above, Tighten the hex nut after adjustment.
- (6) Install the ball joint in the shaft and lever assembly and secure with the lockwasher (30) and hex nut (29).

b. Removal.

- (1) Disconnect the oil line assembly (22, fig. 29) from the tee (23).
- (2) Disconnect the tachometer drive from the tachometer adapter (45).
- (3) Remove the two control rod ball joints (31) with attached control lever rod (32) from the carburetor and governor.
- (4) Disconnect the spring (27) from the shaft and lever assembly (48).
- (5) Remove the four bolts and lockwashers that secure the housing (54) to the gear cover spacer and remove the governor and gasket (46).

c. Disassembly.

- (1) Remove the drive shaft (44, fig. 29) with attached parts from the housing (54).
- (2) Remove the two bearings (33 and 36) from the drive shaft.
- (3) Remove the helical gear (34) and the woodruff key (35) from the drive shaft.
- (4) Slide the thrust sleeve (38) with attached bearing (37) off the drive shaft and remove the bearing from the sleeve.
- (5) Remove the 2 headed straight pin (41) from the 2 flyweights (40). Drive the 2 headless straight pins (39) out of the flyweights and remove the flyweights from the flyweights hub (43).
- (6) Remove the plain tapered pin (42) that secures the flyweight hub to the drive shaft and remove the hub from the shaft.

- (7) Remove the two headless straight pins (53) from the housing (54).
- (8) Remove the tee (23), bushing (24) and the tachometer adapter (45) from the housing.
- (9) Remove the pipe plug (25) from the housing.
- (10) Remove the plain tapered pin (52) that secures the yoke (51) to the shaft and lever assembly (48) and remove the shaft and lever assembly preformed packing (49), and the yoke from the housing.
- (11) Remove the expansion plug (47) from the housing.
- (12) Remove the two sleeve bearings (50) from the housing if damaged or worn excessively. For inspection procedure see *d* below.
- (13) Loosen the 2 hex nuts (28) that secure the 2 control rod ball joints (31) to the control lever rod (32) and remove the ball joints and hex nuts from the control rod.

d. Cleaning, Inspection, and Repair.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Inspect the housing, flyweights, thrust sleeve, and yoke for cracks, breaks, distortion and damaged threads. Repair cracks or breaks by welding and repair damaged threads. Replace all parts damaged beyond repair.
- (3) Rotate the bearings, inspecting for rough rolling elements and races. Replace a defective bearing.
- (4) Inspect the oil line assembly for cracks, breaks, and damaged threads. Inspect the adapter, tee, and bushing for damaged threads.
- (5) Inspect the drive shaft and gear for distortion and excessive wear.
- (6) Inspect the shaft and lever assembly and the two sleeve bearings for distortion and excessive wear. Replace all damaged or defective parts.
- (7) Inspect all attaching hardware for distortion and damaged threads. Replace any defective part.

e. Reassembly.

- (1) Install the 2 hex nuts (28, fig. 29) and 2 control rod ball joints (31) on the control lever rod (32).
- (2) Press the two sleeve bearings (50) into the housing (54).
- (3) Install the expansion plug (47) in the housing.
- (4) Position the yoke (51) in the housing. Place the preformed packing (49) on the shaft and lever assembly (48) and insert the shaft and lever assembly in the aligned holes of the yoke and housing. Secure the **yoke** to the shaft with the plain tapered pin (52).
- (5) Install the pipe plug (25), bushing (24), tee (23), and the tachometer adapter (45) in the housing (54).
- (6) Install the two headless straight pins (53) in the housing.
- (7) Install the thrust sleeve hub (38) on the drive shaft (44) and secure with the plain tapered pin (42).
- (8) Position the 2 flyweights (40) on the flyweight hub and install the 2 headless straight pins (39) in the aligned holes of the flyweights and hub. Install the 2 headed straight pins (41) in the 2 flyweights.
- (9) Install the bearing (37) on the thrust sleeve (38) and slide the thrust sleeve on the drive shaft.
- (10) install the woodruff key (35) and the helical gear (34) on the drive shaft.
- (11) Install the two bearings (33 and 36) on the drive shaft.
- (12) Install the drive shaft with Attached parts in the housing.

f. Installation.

- (1) Position a new gasket (46, fig. 29) and the governor on the gear cover spacer and secure with the four lockwashers and bolts.
- (2) Connect the spring (27) in the shaft and lever assembly (48).
- (3) Install the two control rod ball joints (31) with attached control lever rod (32) on the governor and carburetor.
- (4) Connect the tachometer drive to the tachometer adapter (45).

(5) Connect the oil line assembly (22) to the tee (23).

(6) Adjust the governor as outlined in **a** above.

Section VII. ENGINE CONTROLS AND INSTRUMENTS

136. General

All controls and instruments necessary for operation of the engine are located on the control panel. Controls and instruments must be replaced when they become inoperative or show signs of incorrect readings during normal operation. Damage can be caused by overloading, breakage, or wear. Before replacing any control or instrument, inspect all interconnections of tubing or electrical leads between the control or instrument and the component from which it operates. Always handle instruments with care, since they are sensitive. Any mishandling may damage them.

137. Engine Instruments

a. Tachometer.

(1) *Testing.* Inspect the accuracy of the tachometer by comparison with the reading indicated on a suitable hand held mechanical tachometer. Replace a defective or inaccurate tachometer as outlined below.

(2) *Tachometer Replacement.*

- (a) Disconnect the tachometer drive from the tachometer (9, fig. 9).
- (b) Remove the four nuts and screws that secure the tachometer to the panel and remove the tachometer.
- (c) Position a new tachometer (9) on the panel and secure with four screws and nuts.
- (d) Connect the tachometer drive to the tachometer.

b. Head Temperature Gage.

(1) *Testing.* Inspect the accuracy of the head temperature gage by comparison with the reading on a suitable thermocouple test instrument connected to the same terminals as the temperature gage. Replace a defective or inaccurate head temperature gage as outlined below.

(2) *Head Temperature Gage Replacement.*

- (a) Remove the cylinder head shroud

from the right hand cylinder head (par. 119).

- (b) Disconnect the sensing element of the head temperature gage (28, fig. 9) from the cylinder head.
- (c) Remove the four nuts and screws that secure the head temperature gage to the panel and remove the temperature gage.
- (d) Position a new head temperature gage (28) on the panel and secure with the four screws and nuts.
- (e) Attach the sensing element of the head temperature gage to the cylinder head.
- (f) Install the cylinder head shroud (par. 119).

c. Hourmeter.

(1) *Removal.*

- (a) Tag and disconnect the electrical leads from the back of the hourmeter (10, fig. 9).
- (b) Remove the nuts, lockwashers, and bracket that secure the hourmeter to the panel and remove the hourmeter.

(2) *Installation.*

- (a) Position the hourmeter (10) on the panel and secure with the bracket, lockwasher, and nuts.
- (b) Connect the electrical leads to the terminals of the hourmeter.

d. Ammeter. Replace a defective ammeter in a similar manner as described in *c* above.

e. Oil Pressure Gage.

(1) *Removal.*

- (a) Disconnect the oil line tubing from the oil pressure gage (11, fig. 9).
- (b) Remove the nuts, lockwashers, and bracket that secure the oil pressure gage to the panel and remove the gage.

(2) *Installation.*

- (a) Position the oil pressure gage (11)

in the panel and secure with the bracket, lockwashers, and nuts.

- (b) Connect the oil line tubing to the oil pressure gage.

138. Engine Controls

a. Ignition Switch.

- (1) *Testing.* Tag and disconnect the electrical leads from the ignition switch and test the switch for continuity with a suitable test lamp circuit.
- (2) *Ignition Switch Replacement.*
 - (a) Tag and disconnect all electrical leads from the ignition switch (1, fig. 10).
 - (b) Remove the hex nut and lockwasher that secure the ignition switch to the panel and remove the switch.
 - (c) Position a new ignition switch (1) in the panel and secure with the lockwasher and hex nut.
 - (d) Connect the electrical leads to the ignition switch in accordance with tags attached during removal.

b. *Starter Switch.* Test the starter switch for serviceability and replace the starter switch in a manner similar to that described in *a* above.

c. Fuse Holder.

- (1) *Removal.*
 - (a) Disconnect the electrical leads from the fuse holder (3, fig. 10).

- (b) Remove the hex nut and lockwasher that secure the fuse holder in the panel and remove the fuse holder.

(2) *Installation.*

- (a) Position a new fuse holder (3) in the panel and secure with the lockwasher and hex nut.
- (b) Connect the electrical leads to the fuse holder.

d. Throttle.

(1) *Removal.*

- (a) Disconnect the throttle control (6, fig. 11) from the governor control assembly.
- (b) Remove the hex nut (4) that secures the throttle in the engine control panel (2) and remove the throttle.

(2) *Installation.*

- (a) Insert the throttle control (6) in the engine control panel (2) and secure with the hex nut (4).
- (b) Connect the throttle to the governor control assembly.

e. *Choke Control.* Remove and install the choke control (5, fig. 11) in a manner similar to that described in *d* above.

CHAPTER 6

HYDRAULIC SYSTEM MAINTENANCE INSTRUCTIONS

Section I. RESERVOIR AND SUPPORT

139. Reservoir

a. Removal.

- (1) Remove the housing assembly (par. 106).
- (2) Remove the drain assembly (15, fig. 30) from the reservoir (17) and drain the hydraulic fluid and discard.
- (3) Disconnect the relief valve-to-reservoir tubing (22, fig. 12), outlet selector valve-to-reservoir tubing (21), and the reservoir-to-shutoff valve tubing (46) from the flared tube tee (16, fig. 30) and from the elbow in the reservoir.
- (4) Remove the two straps that secure the reservoir to the reservoir and control panel support (18) and remove the reservoir from the support.

b. Disassembly.

- (1) Remove the eight hex nuts, lockwashers, and flat washers that secure the cover assembly (1, fig. 30) and the gasket to the reservoir and remove the cover assembly.
- (2) Remove the reservoir fill cap (2) from the tank filler neck (3). Remove the strainer (4) from the cover assembly.
- (3) Remove the eight hex nuts, lockwashers, and flat washers that secure the cover assembly (5) and gasket to the

reservoir and remove the cover assembly.

- (4) Remove the rubber hose (10) from the filter element (9) and the tubing of the cover assembly.
- (5) Remove the 2 hex nuts (6) and 2 lockwashers (7) that secure the filter element in the reservoir cover assembly (8) and remove the filter element.
- (6) Remove the eight hex nuts, lockwashers, and flat washers that secure the cover assembly (11) and gasket to the reservoir and remove the cover assembly.
- (7) Remove the four screws (13) and lockwashers (14) that secure the sending unit (12) to the cover assembly and remove the sending unit.

c. Cleaning, Inspection, and Repair.

- (1) Rinse the inside of the reservoir thoroughly with an approved cleaning solvent. Clean the remaining metal parts in an approved solvent and dry thoroughly.
- (2) Inspect the reservoir for dents, tears, and damaged and leaking seams. Repair minor leaks by soldering. Replace a reservoir damaged beyond repair.
- (3) Inspect the cover assemblies for cracks, breaks, and distortion. Replace a defective cover assembly.

1 Cover assembly	7 Lockwasher (2 rqr)	13 Screw, socket head $\frac{3}{16}$ -18 x $\frac{3}{4}$ in. (4 rqr)
2 Reservoir	8 Cover assembly	14 Washer, lock, $\frac{3}{16}$ in. (4 rqr)
3 Tank filler neck	9 Filter element	15 Drain assembly
4 Strainer	10 Rubber hose	16 Flared tube tee
5 Cover assembly	11 Cover assembly	17 Reservoir
6 Nut (2 rqr)	12 Sending unit	18 Reservoir and control panel support
		19 Engine control panel

Figure 30. Reservoir, exploded view.




Figure 30—Continued.

- (4) Inspect the strainer for torn and clogged condition. Replace a defective screen.
- (5) Inspect all other parts for distortion and damage. Replace all defective or damaged parts.

d. Reassemble.

- (1) Position the sending unit (12, fig. 30) on the cover assembly (11) and secure with the four lockwashers (14) and screws (13).
- (2) Position a new gasket and the cover assembly (11) with attached parts on the reservoir and secure with the eight flat washers, lockwashers, and hex nuts.
- (3) Place a new filter element (9) in the cover assembly (8) and secure with the two lockwashers (7) and hex nuts (6).
- (4) Install the rubber hose (10) on the filter element and the tubing of the cover assembly (5).
- (5) Position a new gasket and the cover assembly (5) on the reservoir and secure with eight flat washers, lockwashers, and hex nuts.
- (6) Install the strainer (4) and tank filler neck (3) in the cover assembly (1). Install the reservoir fill cap (2) on the filler neck.
- (7) Position a new gasket and the cover assembly (1) on the reservoir and secure with eight flat washers, lockwashers, and hex nuts.

e. Installation.

- (1) Mount the reservoir (17, fig. 30) on the reservoir and control panel support (18) and secure in place with the two straps.
- (2) Connect the reservoir-to-shutoff valve tubing (46, fig. 12), outlet selector

valve-to-reservoir tubing (21), and the relief valve-to-reservoir tubing (22) to the flared tube tee (16, fig. 30) and the elbow.

- (3) Install the drain assembly (15) in the reservoir.
- (4) Install the housing assembly (par. 106).
- (5) Fill the reservoir with hydraulic fluid (par. 9).

140. Reservoir and Control Panel Support

a. Removal.

- (1) Remove the control panel assembly (par. 107).
- (2) Remove the engine controls (par. 138).
- (3) Remove the reservoir (par. 139).
- (4) Remove eight hex nuts, lockwashers, flat washers, and bolts that secure the reservoir and control panel support (18) to the frame and remove the support.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Inspect the support for cracks, breaks, distortion, and damaged threads. Repair minor cracks and breaks by welding. Replace a support damaged beyond repair.
- (3) Inspect all attaching hardware for distortion and damaged threads. Replace any defective hardware.

c. Installation.

- (1) Position the reservoir and control panel support (18, fig. 30) on the frame and secure with eight bolts, flat washers, lockwashers, and hex nuts.
- (2) Install the reservoir (par. 139).
- (3) Install the engine controls (par. 138).
- (4) Install the control panel assembly (par. 107).

Section II. FILTERS AND MANIFOLD ASSEMBLY

141. General

The high pressure and low pressure filters are incorporated in the test stand hydraulic system to assure delivery of the cleanest possi-

ble hydraulic fluid to the aircraft under test. The high pressure filter is installed in the pump discharge line located on the back side of the control panel. This filter has a throw away type

element. The low pressure filter is attached to the manifold which is mounted on the frame at the inside back corner of the test stand.

142. High Pressure Filter

a. Servicing. Service the high pressure filter as outlined in paragraph 71.

b. High Pressure Filter Replacement.

- (1) Disconnect the high pressure filter-to-relief valve tubing (11, fig. 12), pump-to-high pressure filter hose assembly (8), and the high pressure filter-to-outlet selector valve tubing (13).
- (2) Remove the flared tube tee (10) from the high pressure filter (9).
- (3) Install the flared tube tee in a new high pressure filter (9).
- (4) Connect the high pressure filter-to-outlet selector valve tubing (13), pump-to-high pressure filter hose assembly (8), and the high pressure filter-to-relief valve tubing (11).

143. Low Pressure Filter

a. Servicing. Service the low pressure filter as outlined in paragraph 71.

b. Removal.

- (1) Close the reservoir shutoff valve (12, fig. 9).
- (2) Remove the plug (28, fig. 13) from the bottom cover (26) and drain the hydraulic fluid from the filter housing (31) and manifold (20).
- (3) Disconnect the suction tubing (14, fig. 12), high pressure relief valve-to-manifold tubing (12), pump-to-manifold tubing (5), reservoir shutoff valve-to-manifold tubing (26), and the low pressure filter-to-bleed valve tubing (6).
- (4) Disconnect the electrical leads from the thermoswitch (23, fig. 13).
- (5) Remove the sensing element of the fluid temperature gage (4, fig. 9) from the manifold (20, fig. 13).
- (6) Remove the six bolts (21) and lockwashers (22) that secure the manifold housing to the frame of the test stand and remove the manifold with attached low pressure filter.

c. Disassembly.

- (1) Loosen the locknut (1, fig. 13) and remove the flared tube elbow (2) from the top cover (16). Remove the locknut and preformed packing (3) from the elbow.
- (2) Remove the flared tube union (4) and preformed packing (5) from the top cover.
- (3) Remove the six bolts (6) that secure the top cover and the preformed packing (7) to the filter housing (31) and remove the top cover with attached parts from the housing.
- (4) Remove the wing nut (8) that secures the filter element cover (9), two gaskets (10) and the filter element (11) to the plate assembly, (12) and remove the cover, gaskets, and element.
- (5) Remove the 2 bolts (13) and lockwashers (14) that secure the plate assembly to the 2 spacers (15) and remove the plate assembly.
- (6) Remove the two spacers from the top cover.
- (7) Remove the six bolts (27) that secure the bottom cover (26) to the filter housing and remove the bottom cover and preformed packing (30).
- (8) Remove the four bolts (21) and lockwashers (22) that secure the filter housing and preformed packing (25) to the manifold (20) and remove the filter housing and preformed packing.
- (9) Remove the thermoswitch (23) and preformed packing (24) from the manifold.
- (10) Loosen the tube fitting locknut (17) and remove the flared tube elbow (18) and the preformed packing (19) from the manifold. Remove the locknut from the elbow.

d. Cleaning and Inspection.

- (1) Clean all metal parts with an approved cleaning solvent and dry with a lint-free cloth.
- (2) Inspect the filter housing and manifold, top and bottom covers, filter element cover, and plate assembly for cracks, breaks, distortion and dam-

aged threads. Replace all defective parts.

- (3) Inspect the tube fittings and locknuts for distortion and damaged threads. Replace a damaged fitting or locknut.
- (4) Inspect all attaching hardware for distortion and damaged threads. Replace defective hardware,

e. Reassembly.

- (1) Install the locknut (17, fig. 13) and a new preformed packing (19) on the flared tube elbow (18). Install the elbow in the manifold (20) and tighten the locknut to secure.
- (2) Install a new preformed packing (24) and the thermoswitch (23) in the manifold.
- (3) Position a new preformed packing (25) and filter housing (31) on the manifold and secure with the four lockwashers (22) and bolts (21).
- (4) Place a new preformed packing (30) and the bottom cover (26) on the filter housing and secure with six bolts (27) .
- (5) Install the two spacers (15) in the top cover (16).
- (6) Position the plate assembly (12) on the installed spacers and secure with the two lockwashers (14) and bolts (13).
- (7) Mount two new gaskets (10), a new filter element (11), and the filter element cover (9) on the plate assembly (12) and secure with the wing nut (8).

- (8) Place a new preformed packing (7) and the top cover (16) on the filter housing (31) and secure with six bolts (6).

- (9) Install a new preformed packing (5) and the flared tube union (4) in the top cover.

- (10) Install the locknut (1) and a new preformed packing (3) on the flared tube elbow (2). Install the elbow in the top cover and tighten the locknut to secure.

f. Installation.

- (1) Position the manifold (20, fig. 13) with attached parts on the frame of the test stand and secure with six lockwashers (22) and bolts (21).

- (2) install the sensing element of the fluid temperature gage (4, fig. 9) in the end of the manifold.

- (3) Connect the electrical leads to the thermoswitch.

- (4) Connect the low pressure filter-to-bleed valve tubing (6, fig. 12), reservoir shutoff valve-to-manifold tubing (26), pump-to-manifold tubing (5), high pressure relief valve-to-manifold tubing (12), and the suction tubing (14).

- (5) Install the plug (28, fig. 13) and a new preformed packing (29) in the bottom cover (26).

- (6) Open the reservoir shutoff valve (12, fig. 9).

- (7) Bleed air from the hydraulic system (par. 70).

Section III. HYDRAULIC SYSTEM INSTRUMENTS

144. General

The various instruments necessary for operation of the hydraulic system of the test stand are located on the control panel. Instruments must be replaced when they become inoperative or show signs of incorrect readings during normal operation. Damage may be caused by overloading, breakage, or wear. Before replacing any instrument, inspect all interconnections of tubing or electrical leads between the

instrument and the component from which it operates.

145. Reservoir Level Indicator

a. Testing. Inspect the reservoir level indicator accuracy by draining the fluid from the reservoir and adding a measured, predetermined amount of fluid to the reservoir and observe the indicator reading. Replace a defective reservoir level indicator as outlined below.

b. Removal.

- (1) Disconnect the electrical leads from the reservoir level indicator (2, fig. 9).
- (2) Remove the nuts, lockwashers, and bracket that secure the indicator in the control panel (1) and remove the indicator.

c. Installation.

- (1) Position a new reservoir level indicator (2) in the control panel (1) and secure with the bracket, lockwashers, and nuts.
- (2) Connect the electrical leads to the reservoir level indicator.

146. Fluid Flow Indicator

a. Removal.

- (1) Disconnect the flexible cable that links the fluid flow indicator (15, fig. 9) to the pump.
- (2) Remove the four nuts and screws (14) that secure the flow indicator to the control panel (1) and remove the flow indicator.

b. Installation.

- (1) Position a new fluid flow indicator (15) in the control panel (1) and secure with the four screws (14) and nuts.
- (2) Connect the flexible cable between the fluid flow indicator and the pump.

147. Fluid Temperature Gage

a. Testing. A fluid temperature gage that returns to ambient temperature indications when the test stand is inoperative can be considered to be in proper operating condition.

The temperature gage accuracy can be checked by inserting the sensing element of an accurate thermometer in the reservoir with test stand in normal operation and comparing the indicated temperatures. Replace a defective fluid temperature gage as outlined below.

b. Removal.

- (1) Close the reservoir shutoff valve (12, fig. 9) and remove the plug in the bottom of the low pressure filter draining fluid from the filter and manifold assembly.
- (2) Remove the sensing element of the fluid temperature gage (4) from the manifold.
- (3) Remove the three nuts and screws (5) that secure the fluid temperature gage to the control panel (1) and remove the temperature gage.

c. Installation.

- (1) Position a new fluid temperature gage (4, fig. 9) in the control panel (1) and secure with the three screws (5) and nuts.

Caution: Exercise extreme care in handling the capillary tube and sensing element of the temperature gage. The slightest kink may render the gage inoperative.

- (2) Install the sensing element of the fluid temperature gage (4) in the manifold.
- (3) Install the plug in the bottom of the low pressure filter and open the reservoir shutoff valve (12).
- (4) Bleed air from the hydraulic system (par. 70).

Section IV. CONTROL VALVES AND PANEL


148. General

The various control valves of the hydraulic system are located on the control panel. When these control valves become damaged or inoperative they must be repaired or replaced as outlined in this section. After the removal of a control valve, inspect the interconnecting hose assemblies or tubing for damage or obstructions making certain the questionable control valve is the source of trouble.

149. High Pressure Relief Valve

a. Removal.

- (1) Disconnect the high pressure filter-to-relief valve tubing (11, fig. 12), high pressure relief valve-to-manifold tubing (12), high pressure relief valve-to-snubber valve tubing (32), and the relief valve-to-bypass valve tubing (38).



- | | | | | | |
|---|-----------------------|----|--|----|-------------------|
| 1 | Adjusting screw | 7 | Needle valve | 12 | Preformed packing |
| 2 | Locking nut | 8 | Seat | 13 | Plunger |
| 3 | Nut, plain, hex, 1-14 | 9 | Cap | 14 | Spool spring |
| 4 | Gasket | 10 | Screw, machine, $\frac{7}{16}$ -24 x 1 $\frac{3}{8}$ | 15 | Spool |
| 5 | Valve spring guide | 11 | in. (2 rqr) | 16 | Seat |
| 6 | Pilot spring | 12 | Preformed packing | 17 | Body |

Figure 31. High pressure relief valve, exploded view.

- (2) Remove the adjusting screw (1, fig. 31) and locking nut (2) from the cap (9).
 - (3) Remove the hex nut (3) that secures the high pressure relief valve to the control panel and remove the relief valve.
- b. Disassembly.
- (1) Remove the valve spring guide (5, fig. 31), gasket (4), pilot spring (6), needle valve (7), and the seat (8) from the valve cap.
 - (2) Remove the two screws (10) that secure the cap and preformed packing (11) to the body (17) and remove the cap and packing.
 - (3) Lift the plunger (13) and spool spring (14) out of the spool (15) and remove the preformed packing (12) from the plunger.

- (4) Remove the spool and the seat (16) from the body.

c. Cleaning, Inspection, and Repair.

- (1) Clean all metal parts in an approved cleaning solvent and dry with a lint-free cloth.
- (2) Inspect the valve body and valve cap for cracks, breaks, and damaged threads. Retap damaged threads and remove nicks and burrs from gasket seating surfaces. Replace a body or cap damaged beyond repair.
- (3) Inspect the valve spring guide needle valve, seat, plunger, spool, and seat for nicks, burrs, and distortion. Remove minor abrasions. Replace any part damaged beyond repair.
- (4) Inspect the springs for cracks, distortion, and lack of tension. Replace a defective spring.
- (5) Inspect all attaching parts for distortion and damaged threads. Replace all defective parts.

d. Reassembly.

- (1) Insert the seat (16, fig. 31) and the spool (15) in the body (17).
- (2) Install a new preformed packing (12) on the plunger (13) and place the spool spring (14) and the plunger in the spool.
- (3) Position a new preformed packing (11) and the cap (9) on the body and secure with the two screws (10).
- (4) Install the seat (8), needle valve (7), pilot spring (6), a new gasket (4), and the valve spring guide (5) in the cap.

e. Installation.

- (1) Position the high pressure relief valve in the control panel and secure with the hex nut (3, fig. 31).
- (2) Install the locking nut (2) on the adjusting screw (1) and install the screw in the relief valve.
- (3) Connect the relief valve-to-bypass valve tubing (38, fig. 12), high pressure relief valve-to-snubber valve tubing (32), high pressure relief valve-to-manifold tubing (12), and the high

pressure filter-to-relief valve tubing (11).

150. Flow Control, Gage Snubber, Fluid Bypass and Reservoir Shutoff Valves

a. Removal.

- (1) Disconnect the flow control valve-to-outlet tubing (17, fig. 12) and the outlet selector valve-to-outlet tubing (31).
- (2) Remove the hex nut that secures the handwheel on the flow control valve (20, fig. 9) and remove the handwheel and locking nut from the valve.
- (3) Remove the four bolts (32) that secure the flow control valve to the control panel (1) and remove the valve.
- (4) Remove the remaining flow control valve (21), gage snubber valve (23), fluid bypass valve (27), and reservoir shutoff valve (12) in similar manner.

b. Cleaning and Inspection.

- (1) Clean the valves with an approved cleaning solvent and dry thoroughly. Blow the fluid passages of the valves clear with compressed air.
- (2) Inspect the valves for damaged or broken handwheels, damaged threads, and for improper closing. Replace a defective valve.
- (3) Inspect all attaching hardware for distortion and damaged threads. Replace defective or damaged hardware.

c. Installation.

- (1) Position the flow control valve (20, fig. 9) in the control panel (1) and secure with the four bolts (32).
- (2) Install the locking nut and handwheel on the flow control valve and secure with the hex nut.
- (3) Connect the outlet selector valve-to- $\frac{3}{4}$ in. outlet tubing (31, fig. 12) and the flow control valve-to- $\frac{3}{4}$ inch outlet tubing (17).
- (4) Install the remaining flow control valve (21, fig. 9), gage snubber valve (23), fluid bypass valve (27) and reservoir shutoff valve (12) in a similar manner.

151. Outlet Selector Valve and Pressure Selector Valve

a. Removal.

- (1) Disconnect the high pressure filter-to-outlet selector valve tubing (13, fig. 12), outlet selector valve-to-reservoir tubing (21), outlet selector valve-to-outlet tubing (30 and 31).
- (2) Remove the bolt (31, fig. 9) that secures the handle of the outlet selector valve (16) in place and remove the handle.
- (3) Remove the four screws (30) that secure the valve to the control panel (1) and remove the valve.
- (4) Remove the pressure selector valve (8) in a similar manner.

b. Cleaning and Inspection.

- (1) Clean the valves with an approved cleaning solvent and dry thoroughly.

Blow the fluid passages of the valves clear with compressed air.

- (2) Inspect the valves for cracks, breaks, and damaged threads. Inspect the handles for free movement. Replace a defective or damaged valve.
- (3) Inspect all attaching hardware for distortion and damaged threads. Replace any defective hardware.

c. Installation.

- (1) Position the outlet selector valve (16, fig. 9) in the control panel (1) and secure in place with the four screws (30).
- (2) Secure the handle of the outlet selector valve in place with the bolt (31).
- (3) Connect the outlet selector valve-to-outlet tubing (30 and 31, fig. 12) outlet selector valve-to-reservoir tubing (21), and the high pressure filter-to-outlet selector valve tubing (13).

Section V. HYDRAULIC PUMP

152. General

The hydraulic pump is a variable volume, axial piston-type unit designed to deliver up to 10 gpm at a maximum 5000 psi. The volume of fluid delivered is varied by changing the length of piston strokes in the barrel. These piston strokes are controlled by the angle of the cam plate against which they ride. The thrust of the pistons is balanced by the admission of pressure through a drilled hole in the piston into an area in the surface of the piston shoe that contacts the cam plate. This area is slightly less than the effective piston area, which results from the shoe being supported on an oil film at all times. The cylinder barrel is supported on a port plate into which are machined support areas hydraulically balancing this portion of the pump. The radial load created by the angle of the cam plate is supported by a roller bearing. The cylinder barrel is driven by a spline shaft. The variable delivery controls are bolted to the pump housing in easily removable units. All working parts are submerged in a bath of hydraulic fluid.

153. Removal

a. Remove the control panel assembly (par. 107).

b. Drain and discard the hydraulic fluid from the pump by removing the plug in the pump case.

c. Disconnect the pump inlet-to-low pressure filter hose assembly (4, fig. 12) from the filter and manifold assembly (47) and pump (1).

d. Disconnect the pump-to-manifold tubing (5) from the manifold and from the pump case relief valve in the pump. Remove the relief valve from the pump.

e. Disconnect the pump-to-high pressure filter hose assembly (8) from the flared tube tee (10) and from the check valve in the pump (1). Remove the check valve from the pump.

f. Disconnect the pressure selector valve-to-pump tubing (28) from the flared tube elbow (27) and pump (1).

g. Remove the roller chain (21, fig. 18) from the two coupling halves (22 and 23).

h. Remove the four bolts (25) and lockwashers (26) that secure the pump mount to the

engine and remove the pump mount with attached pump from the engine.

154. Disassembly

a. Remove the two setscrews that secure the coupling half (23, fig. 18) to the shaft of the pump and remove the coupling half and woodruff key from the shaft.

b. Remove the four bolts and flat washers that secure the pump mount to the pump and remove the mount.

c. Remove the post of the fluid volume control with attached parts from the pump.

d. Remove the preformed packing, packing retainer, and flat washer from the pushrod and remove the screw and pushrod from the post.

e. Loosen the hex nut and remove the compensator control tube with attached parts from the pump.

f. Remove the bullet and 15 balls from the control tube.

g. Remove the hex nut, screw, and pushrod from the control tube.

155. Cleaning, Inspection, and Repair

a. Wipe the external surfaces clean with a cloth dampened with an approved cleaning solvent.

Caution: Observe precautions necessary to prevent dirt from entering the various openings in the pump while cleaning externally.

b. Clean all disassembled parts with an approved cleaning solvent and dry thoroughly.

c. Inspect the compensator control tube, pushrod, balls, and bullet for nicks, burs, and distortion. Inspect for free movement of the bullet and balls in the control tube. Remove nicks and burs from the pushrod and bullet. Replace any part damaged beyond repair.

d. Inspect the handles, locknuts, and screws for cracks, breaks, and damaged threads. Replace all defective parts.

e. Inspect the coupling halves and the roller chain for cracks, breaks, and excessive wear. Replace a defective coupling or chain.

f. Inspect all attaching parts for distortion and damaged threads. Replace any defective part.

156. Reassembly

a. Install the pushrod and the screw in-the compensator control tube. Install the hex nut on the control tube.

b. Apply a thin film of grease to the 15 balls and the bullet and install the balls and bullet in the control tube.

c. Install the compensator control tube in the pump and tighten the hex nut to secure.

d. Install the pushrod and the volume control screw in the post and install the flat washer, packing retainer, and preformed packing on the pushrod.

e. Install the post with attached parts in the pump.

f. Position the pump mount on the pump and secure with four flat washers and bolts.

g. Install the woodruff key in the shaft of the pump and slide the coupling half (23, fig. 18) on the shaft.

157. Installation

a. Position the pump mount with attached pump on the engine and secure in place with the four lockwashers (26, fig. 18) and bolts (25).

b. Position the coupling half on the pump shaft to allow clearance between the 2 halves and secure in place with the 2 setscrews. Install the roller chain (21) on the coupling.

c. Connect the pressure selector valve-to-pump tubing (28, fig. 12) to the flared tube elbow (27) and the pump (1).

d. Install the check valve in the discharge part of the pump (1) and connect the pump-to-high pressure filter hose assembly (8) to the check valve and the flared tube tee (10).

e. Install the pump case relief valve in the case of the pump and connect the pump-to-manifold tubing (5) to the relief valve and the manifold.

f. Connect the pump-to-low pressure filter hose assembly (4) to the filter and manifold assembly (47) and to the pump.

g. Fill the pump case with hydraulic fluid and install the plug in the case of the pump.

h. Install the panel assembly (par. 107).

CHAPTER 7
HOUSING AND RUNNING GEAR
MAINTENANCE INSTRUCTIONS

Section I. HOUSING ASSEMBLY

158. General

The steel housing assembly consists of a welded steel frame, a four door roof assembly, and front and rear panel assemblies. The four roof doors are mounted to a hinge positioned at the top center, and running the length of the housing roof. These doors permit overhead access to the engine, hydraulic reservoir components, and control panel. The two front side doors hinged at the side, unlock and open out to permit access to both sides of the engine, battery, fuel tank, and other engine accessories. The other side door, also hinged at the side, permits access to the back of the control panel and the entire hydraulic system.

159. Removal and Disassembly

- a.* Remove the housing assembly (par. 106).
- b.* Remove the six hex nuts (32, fig. 32), lockwashers (33), and screws (34) that secure the gasket retaining ring (35) and gasket (36) to the rear top door assembly (44) and remove the ring and gasket.
- c.* Remove the screw (40) and lockwasher (41) that secure the rubber bumper (42) to the spacer (43) and remove the bumper.
- d.* Remove the hex nut, spacer, two lockwashers (39) and screws (38) that secure the door support (37) to the door. Remove the hex nut and bolt that secure the door support to the housing assembly (72) and remove the support.
- e.* Remove the seven hex nuts (45), lockwashers (46), and bolts (47) that secure the door to the butt hinge (59) and remove the door and neoprene strip (48).
- f.* Remove the remaining top door assemblies (30 and 50) in a similar manner as described in *a* through *e* above.

g. Remove the 6 hex nuts, lockwashers, and bolts that secure the 3 hinge retainer assemblies (57 and 58) to the housing assembly and remove the 3 retainers and 2 hinges (59 and 60).

h. Remove the hex nut (14) and clamp arm (15) from the clamp stud (20) and remove the spring (16), flat washer (17) and the stud with attached knob (18) from the door assembly (23). Loosen the setscrew (19) and remove the knob from the stud. Remove the seven remaining knobs in a similar manner.


i. Remove the four remaining door assemblies in a similar manner as described in *c* through *e* above.

j. Remove the headless straight pin (63) that retains the spring (64) and hose support hook (65) in the plate assembly (66). Remove the four bolts (61) and lockwashers (62) that secure the plate assembly to the housing and remove the plate assembly. Disassemble the other hanger assembly in a similar manner.

k. Remove the four hex nuts, lockwashers, flat washers (68) and screws (69) that secure the bow handle (67) to the housing assembly and remove the handle. Remove the remaining three bow handles in a similar manner.

160. Cleaning, Inspection, and Repair

- a.* Clean all metal parts with an approved cleaning solvent and dry thoroughly. Remove rust and corrosion from the housing and doors with a wire brush.
- b.* Inspect all sheet metal parts for dents, cracks, and tears. Straighten all minor dents and repair cracks by welding. Retouch or repaint exposed metal surfaces. Replace any sheet metal part damaged beyond repair.
- c.* Inspect the hinges for seized hinge pins and for bent or distorted condition. Replace a defective hinge.



- | | | |
|--------------------------------|----------------------------|------------------------------------|
| 1 Nut (7 rqr) | 25 Screw (20 rqr) | 49 Weather strip |
| 2 Clamp arm (7 rqr) | 26 Catch loop (6 rqr) | 50 Control panel door assembly |
| 3 Spring (7 rqr) | 27 Catch lever (6 rqr) | 51 Nut (28 rqr) |
| 4 Flatwasher (7 rqr) | 28 Door support | 52 Lockwasher (28 rqr) |
| 5 Thumbscrew (7 rqr) | 29 Door support | 53 Bolt (28 rqr) |
| 6 Front panel assembly | 30 Front top door assembly | 54 Neoprene strip |
| 7 Door support | 31 Weather strip | 55 Bow handle |
| 8 Door support | 32 Nut (6 rqr) | 56 Door catch (2 rqr) |
| 9 Nut (10 rqr) | 33 Lockwasher (6 rqr) | 57 Hinge retainer assembly (2 rqr) |
| 10 Bolt (10 rqr) | 34 Screw (6 rqr) | 58 Hinge retainer assembly |
| 11 Nut (18 rqr) | 35 Gasket retaining ring | 59 Butt hinge |
| 12 Lockwasher (18 rqr) | 36 Gasket | 60 Butt hinge |
| 13 Door clamp assembly (8 rqr) | 37 Door support | 61 Bolt (8 rqr) |
| 14 Nut (8 rqr) | 38 Screw, machine (12 rqr) | 62 Lockwasher (8 rqr) |
| 15 Clamp arm (8 rqr) | 39 Lockwasher (12 rqr) | 63 Headless straight pin (2 rqr) |
| 16 Spring (8 rqr) | 40 Screw (2 rqr) | 64 Spring (2 rqr) |
| 17 Flat washer (8 rqr) | 41 Lockwasher (2 rqr) | 65 Hose support hook |
| 18 Knob (8 rqr) | 42 Rubber bumper (2 rqr) | 66 Plate assembly (2 rqr) |
| 19 Setscrew (8 rqr) | 43 Spacer (2 rqr) | 67 Bow handle (4 rqr) |
| 20 Clamp stud (8 rqr) | 44 Rear top door assembly | 68 Flat washer (16 rqr) |
| 21 Rear door assembly | 45 Nut (28 rqr) | 69 Screw (16 rqr) |
| 22 Left rear door assembly | 46 Lockwasher (28 rqr) | 70 Identification plate |
| 23 Left front door assembly | 47 Bolt (28 rqr) | 71 Identification plate |
| 24 Right front door assembly | 48 Neoprene strip (4 rqr) | 72 Housing assembly |

Figure 32. Housing assembly, exploded view.

d. Inspect all attaching hardware for cracks, breaks, distortion, and damaged threads. Replace all damaged parts.

161. Reassembly and Installation

a. Position the bow handle (67, fig. 32) on the housing assembly (72) and secure with the four screws (69), flat washers (68), lockwashers, and hex nuts. Install the remaining bow handles in a similar manner.

b. Position the plate assembly (66) on the housing assembly and secure with the four lockwashers (62) and bolts (61). Place the spring (64) on the hose support hook (65), insert the hook in the plate assembly and install the headless straight pin (63) in the hook. Reassemble the remaining hose hanger assembly in a similar manner.

c. Position the 2 hinges (59 and 60) and the 3 hinge retainers (57 and 58) on the housing assembly and secure with the six bolts, lockwashers, and hex nuts.

d. Position the door assembly (44) and neoprene strip (48) on the butt hinge (59) and secure with the seven bolts (47), lockwashers (46), and hex nuts (45).

e. Position the door support (37) on the housing assembly and secure with the bolt and hex nut. Secure the other end of the support to the door assembly with the 2 screws (38), 2 lockwashers (39), spacer (43) and hex nut.

f. Assemble the remaining top door assemblies (30 and 50) in a similar manner as described in *d* and *e* above.

g. Install the rubber bumper (42) on the spacer (43) and secure with the lockwasher (41) and screw (40).

h. Install the four door assemblies (21, 22, 23, and 24) in a similar manner as described in *c* through *e* above.

i. Install the knob (18) in the clamp stud (20) and secure with the setscrew (19). Place the flat washer (17) on the stud, insert the stud in the door and install the spring (16), clamp arm (15), and hex nut (14) on the stud. Assemble the seven remaining door clamp assemblies in a similar manner.

j. Position the gasket (36) and gasket retaining ring (35) on the door assembly (44) and secure with the six screws (34), lockwashers (33), and hex nuts (32).

k. Install the housing assembly (par. 106).

Section II. WHEEL AND AXLE ASSEMBLIES

162. General

The wheels of the running gear are secured to cast iron hubs into which are pressed the outer races of the wheel bearings. Grease retainers are installed in the inner ends of the hubs to prevent lubricant leakage. The axles which carry the bearing cones and rollers are supported by the arm assemblies. The rear axles are secured directly to the arms, while the front axles are pivot mounted with a king-pin and connected to the steering gear with tie rods. Each arm assembly has independent coil spring suspension, pivoting on pins and bushings installed in the arm supports.

163. Wheels

a. Wheel Bearing Adjustment.

- (1) Support the frame, at a point near the wheel to be adjusted, with a suitable jack.

- (2) Remove the grease cap (41, fig. 14) from the hub (51).
- (3) Remove the cotter pin (42) and tighten the nut (43) until a slight drag is felt when the wheel is rotated back and forth. This operation will seat the cones and rollers in the bearing cups.
- (4) Loosen the nut just enough to line up the nearest slot in the nut with the cotter pin hole in the axle assembly (69). Install a new cotter pin.
- (5) Install the grease cap and lower the jack.

b. Removal and disassembly.

- (1) Release the brake lever assembly (25, fig. 14) and block a wheel to prevent the test stand from rolling.
- (2) Remove the wheel (par. 74).

- (3) Remove the tire valve cap (39) and check valve (40) from the inner tube (38) deflating the tube.
 - (4) Remove the 8 hex nuts (32), lockwashers (33), and bolts (34) and remove the 2 wheel halves (35 and 36) from the pneumatic tire (37). Remove the inner tube from the tire.
 - (5) Remove the grease cap (41) from the hub (51).
 - (6) Remove the cotter pin (42), nut (43), and key washer (44) from the axle assembly (69).
 - (7) Remove the roller bearing cone (45) and the hub with attached parts from the axle.
 - (8) Remove the hub from the brake drum (52) and remove the five rib neck bolts (50) from the brake drum.
 - (9) Remove the grease seal (47), roller bearing cone (48), and the two roller bearing cups (46 and 49) from the hub.
 - (10) Remove and disassemble the other wheels in a similar manner.
- c. Cleaning, Inspection, and Repair.*
- (1) Clean all metal parts in an approved cleaning solvent and dry thoroughly.
 - (2) Rotate the bearing cones in their respective cups inspecting rough or worn rolling elements and races. Replace a defective bearing.
 - (3) Inspect the wheel halves and brake drum for cracks and distortion. Replace a defective wheel half or brake drum.
 - (4) Inspect the tire for cuts, bruises, wear, and damaged cord inside the tire. Vulcanize cuts and bruises if possible. Replace a tire worn or damaged beyond repair.
 - (5) Inspect the tube for leaks by inflating with air and immersing in water. Repair a leaking tube with rubber patching material. Replace a tube damaged beyond repair.
 - (6) Inspect all attaching hardware for distortion and damaged threads. Replace all unserviceable hardware.

d. Reassembly and Installation.

- (1) Install the two roller bearing cups (46 and 49, fig. 14), roller bearing cone (48), and the grease seal (47) in the hub (51).
- (2) Press the five rib neck bolts (50) into the brake drum (52) and mount the drum on the hub.
- (3) Install the hub with attached parts and the roller bearing cone (45) on the axle assembly (69).
- (4) Install the key washer (44) and castellated hex nut (43) on axle, adjust the bearings as outlined in *a* above and install the cotter pin (42).
- (5) Install the grease cap (41) in the hub.
- (6) Insert the inner tube (38) in the pneumatic tire (37). Install the 2 wheel halves (35 and 36) in the tire and secure together with the 8 bolts (34), lockwashers (33), and hex nuts (32).
- (7) Install the check valve (40) in the inner tube and inflate the tube to 30 psi. Install the tire valve cap (39) on the tube.
- (8) Install the wheel (par. 74).
- (9) Lower the jack, remove the wheel blocks and set the brake lever assembly (25).

164. Axles and Steering Tie Rods

a. Tie Rod Adjustment.

- (1) Make sure the test stand is on a smooth and level surface.
- (2) Lay the drawbar assembly (11, fig. 14) on the surface pointed straight ahead.
- (3) Measure the distance between the kingpin (57) on each side to a center point on the end of the drawbar and move the drawbar as necessary to equalize these measurements.
- (4) Measure the distance between each outer tie rod end (4) and the steering arm assembly (14). Equalize these measurements by loosening the bolts (8) in the loop clamps (9) and rotate the tie rods (10) as required. Tighten the bolts after the adjustment is made.

- (5) Place a mark on the outside diameter of each front tire at a point level with the hub.
- (6) Measure the distance between these marks. Move the test stand until the marks are level with the hub on the back side of the tires and measure the distance between the marks.
- (7) The distance between the marks when at the front side of the tires should be one-fourth inch less than at the rear. Loosen the loop clamps (9) on each end of both tie rods (10) and rotate both tie rods equally until this adjustment is obtained. Secure the clamps after the adjustment is made.

b. Removal and Disassembly.

- (1) Remove the wheels (par. 163).
- (2) Disconnect the cable assembly (23), fig. 14 from the brake assembly (66).
- (3) Remove the four hex nuts (67, fig. 14) and lockwashers (68) that secure the brake assembly to the axle assembly (69) and remove the brake assembly.
- (4) Remove the four bolts (64) and lockwashers (65) that secure the axle assembly (69) to the arm assembly (77) and remove the axle.
- (5) Remove the other rear axle in a similar manner.
- (6) Remove the 2 cotter pins (1) and 2 nuts (2) that secure the 2 tie rod ends (4 and 5) in place and remove the tie rod ends with attached parts.
- (7) Remove the 2 hex nuts (6), lockwashers (7), and bolts (8) that secure the 2 loop clamps (9) on the tie rod (10) and remove the tie rod ends and clamps from the tie rod.
- (8) Disassemble the other steering tie rod assembly in a similar manner.
- (9) Drive the kingpin (57) out of the 2 sleeve bearings (61 and 62) and the spindle assembly (60) and remove the spindle and 2 thrust washers (58 and 59) from the axle bracket (63).
- (10) Remove the four bolts (55) and lockwashers (56) that secure the axle bracket to the support and arm assembly (70) and remove the bracket.

- (11) Press the two sleeve bearings out of the bracket if defective.
- (12) Remove and disassemble the remaining spindle and bracket in a similar manner.

c. Cleaning, Inspection, and Repair.

- (1) Clean all metal parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the axles and spindles for cracks, breaks, distortion, and damaged threads. Remove minor abrasions and repair damaged threads. Replace an axle or spindle damaged beyond repair.
- (3) Inspect the axle brackets for cracks, breaks and distortion. Repair a cracked bracket by welding. Replace a bracket damaged beyond repair.
- (4) Inspect the kingpins and sleeve bearings for nicks, burs, distortion, and excessive wear. Replace a defective or excessively worn kingpin and sleeve bearing.
- (5) Inspect all attaching hardware for distortion and damaged threads. Replace all defective hardware.

d. Reassembly and Installation.

- (1) Press the two sleeve bearings (61 and 62, fig. 14) into the axle bracket (63).
- (2) Position the bracket on the support and arm assembly (70) and secure with the four lockwashers (56) and bolts (55).
- (3) Position the spindle assembly (60) and two thrust washers (58 and 59) in the bracket and drive the kingpin (57) into the spindle.
- (4) Reassemble and install the remaining spindle and bracket in a similar manner.
- (5) Install the 2 loop clamps (9) on the tie rod (10) and screw the 2 tie rod ends (4 and 5) into the tie rod. Secure the clamps with the 2 bolts (8), lockwashers (7), and hex nuts (6).
- (6) Install the assembled tie rod in the spindle and the steering arm assembly and secure with the 2 nuts (2) and 2 cotter pins (1).
- (7) Reassemble and install the remaining

tie rod and tie rod ends in a similar manner.

- (8) Position the axle assembly (69) on the arm assembly (77) and secure with the four lockwashers (65) and bolts (64).
- (9) Position the brake assembly (66) on

the axle and secure with the four lockwashers (68) and hex nuts (67).

- (10) Connect the cable assembly (23) to the brake assembly.
- (11) Install the remaining axle assembly in a similar manner.
- (12) Install the wheels (par. 163).

Section III. HANDBRAKE ASSEMBLY

165. General

The handbrake assembly is mounted on the rear axle and is mechanically operated, through cables, by the brake lever assembly. Moving the lever to a horizontal position actuates the expanding-type brake assemblies in the rear wheels, forcing the brake shoes out against the brake drums, which are mounted to the rear wheel hubs.

166. Brake Lever Assembly

a. Removal and Disassembly.

- (1) Remove the brake lever assembly (par. 76).
- (2) Remove the 3 cotter pins (10 and 14, fig. 15) from the 3 headed straight pins (11 and 18) and remove the headed straight pins and 5 flat washers (13 and 15) from the brake lever assembly.
- (3) Remove the 2 rod end clevises (12), 2 levers (16), and 2 sleeve spacers (17) from between the side plates of the brake lever assembly.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the spacers, levers, and clevises for cracks, breaks, and distortion. Straighten minor bends and repair cracks by welding. Replace any part damaged beyond repair.
- (3) Inspect the lever assembly for free movement between the side plates. Inspect the knurled knob at the outer end of the lever for free rotation. Replace a defective lever assembly.
- (4) Inspect all hardware for distortion and damaged threads. Replace if defective.

c. Reassembly and Installation.

- (1) Position the 2 sleeve spacers (17, fig. 15), 2 levers (16), and 2 rod end clevises (12) between the side plates of the brake lever assembly.
- (2) Insert the 3 headed straight pins (11 and 18) in the aligned holes of the spacers, clevises, levers, and 5 flat washers (13 and 15) and install the 3 cotter pins (10 and 14) in the headed straight pins.
- (3) Install the brake lever assembly (par. 76).

167. Brake and Cable Assemblies

a. Removal and Disassembly.

- (1) Remove the brake assemblies (par. 163).
- (2) Disconnect the cable assemblies from the brake lever assembly (par. 76).
- (3) Remove the 2 elastic grommets (24, fig. 14) that secure the cable assemblies (22 and 23) to the frame assembly (87) and remove the cable assemblies.

b. Cleaning, Inspection, and Repair.

- (1) Clean all metal parts with an approved cleaning solvent and dry thoroughly.
- (2) Blow all dust and dirt from the brake assemblies with compressed air.
- (3) Inspect the cable assemblies for free movement of the cables in their respective housings. Inspect the cable housings for visible signs of damage. Replace defective cable assemblies.
- (4) Inspect the shoes of the brake assemblies for damage and excessive

wear. Replace worn brake lining on the shoes. Inspect the return springs for cracks, distortion and lack of tension. Replace a defective brake assembly.

c. Reassembly and Installation.

- (1) Secure the 2 cable assemblies (22 and

23, fig. 14) to the frame assembly (87) with the 2 elastic grommets (24).

- (2) Connect the cables to the brake lever assembly (par. 76).
- (3) Install the brake assemblies (par. 163).

Section IV. FRAME ASSEMBLY

168. General

The frame assembly is a welded steel fabrication providing the mounting place for all major components of the test stand as well as the attachment point for the various parts of the running gear,

169. Arm and Support Assemblies

a. Removal and Disassembly.

- (1) Remove the axle assembly (par. 164).
- (2) Remove the two bolts (28, fig. 14) and lockwashers (29) that secure the stop bracket (27) to the support assembly (84) and remove the stop bracket releasing the spring (53).
- (3) Remove the 4 retaining rings (75) from the 2 headless grooved pins (76) and remove the pins from the 2 sleeve bearings (78) releasing the arm assembly (77) from the support assembly,
- (4) Remove the two sleeve bearings from the arm assembly if defective.
- (5) Remove the hex nut (80), lockwasher (81), bolt (83), and flat washer (82) that secure the rubber bumper (79) to the arm assembly and remove the bumper.
- (6) Remove the other arm assemblies in a similar manner.
- (7) Remove the six hex nuts (71), lockwashers (72), flat washers (73) and bolts (74) that secure the support assembly to the frame assembly (87) and remove the support assembly.
- (8) Remove the other support assembly in a similar manner.

b. Cleaning, Inspection, and Repair.

- (1) Clean all metal parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the arm and support assemblies for cracks, breaks, distortion, and damaged threads. Straighten bends and repair cracks and breaks by welding. Replace an arm or support assembly damaged beyond repair.
- (3) Inspect the pins and bearings for nicks, burs, and excessive wear. Remove minor abrasions from the pins and bearings, Replace if defective or excessively worn.
- (4) Inspect the rubber bumper for oil soaked condition or other visible signs of deterioration. Replace a defective rubber bumper.
- (5) Inspect all attaching hardware for distortion and damaged threads. Replace any defective parts.

c. Reassembly and Installation.

- (1) Position the support assembly (84, fig. 14) under the frame assembly (87) and secure with the six bolts (74), flat washers (73), lockwashers (72), and hex nuts (71).
- (2) Install the other support assembly in a similar manner.
- (3) Place the rubber bumper (79) on the arm assembly (77) and secure with the bolt (83), flat washer (82), lockwasher (81), and hex nut (80).
- (4) Press the two sleeve bearings (78) into the arm assembly (77).
- (5) Position the arm assembly on the support assembly and install the 2 head-

less grooved pins (76). Install the 4 retaining rings (75) in the grooves of the pins.

- (6) Place the spring (53) over the rubber bumper on the arm assembly. Raise the arm assembly and secure the stop

bracket (27) to the support assembly with the 2 lockwashers (29) and 2 bolts (28).

- (7) Install the other arm assemblies in a similar manner.
- (8) Install the axle assembly (par. 164).

CHAPTER 8
DEPOT MAINTENANCE INSTRUCTIONS

Section I. DEPOT MAINTENANCE SPECIAL TOOLS AND EQUIPMENT

No special tools or equipment are required to perform depot maintenance of this test stand.

Section II. TROUBLESHOOTING

170. General

This section provides information useful in diagnosis and correction, inspection, operation, or failure of the hydraulic test stand, or any of its components. Each trouble symptom stated is followed by a list of probable causes of the trouble. The possible remedy recommended is described opposite the probable cause.

171. Engine Hard to Start or Fails to Start

<i>Probable cause</i>	<i>Possible remedy</i>
Magneto defective -----	Repair or overhaul the magneto (par. 185).
Valves defective -----	Reseat or replace defective valves (par. 186).

172. Engine Misses or Runs Erratically

<i>Probable cause</i>	<i>Possible remedy</i>
Magneto defective -----	Repair or overhaul the magneto (par. 185).
Valves burned, warped, or broken -----	Grind or replace valves (par. 186).
Valve seats cracked -----	Reface valve inserts (par. 187).
Compression poor -----	Replace valves (par. 186). Replace pistons and/or piston rings (par. 195).

173. Engine Stops Suddenly

<i>Probable cause</i>	<i>Possible remedy</i>
Magneto defective -----	Repair or overhaul magneto (par. 185).
Connecting rod and crankshaft bearings seized due to lack of oil.	Replace bearing and repair or replace crankshaft (par. 196).

174. Engine Will Not Idle Smoothly

<i>Probable cause</i>	<i>Possible remedy</i>
Valves burned, warped, or sticking -----	Grind or replace valves (par. 186).
Valve springs weak or broken -----	Replace defective valve springs (par. 186).
Piston rings worn -----	Replace piston rings (par. 195).
Pistons and cylinder walls scored -----	Rebore cylinder blocks and install oversize pistons and rings (pars. 195 and 199).

175. Engine Knocks or Develops Excessive Noise

<i>Probable cause</i>	<i>Possible remedy</i>
Connecting rod and crankshaft bearings defective -----	Replace worn or defective bearings (pars. 195 and 196).
Oil pump defective -----	Repair or replace oil pump (par. 193).

176. Engine Exhaust Smokey

<i>Probable cause</i>	<i>Possible remedy</i>
Pistons and/or piston rings defective-----	Replace pistons and/or piston rings (par. 195).

177. Engine Starter Fails to Operate

<i>Probable cause</i>	<i>Possible remedy</i>
Bendix drive spring broken -----	Replace spring (par. 184).
Commutator worn, burned or has high mica -----	Repair commutator (par. 184).
Armature or field coils defective -----	Overhaul starter (par. 184).

178. Ammeter Shows No Charge or Discharge With Engine Operating

<i>Probable cause</i>	<i>Possible remedy</i>
Generator regulator defective -----	Repair generator regulator (par. 182).
Generator defective -----	Repair or overhaul generator (par. 183).

179. Ammeter Needle Fluctuates Rapidly

<i>Probable cause</i>	<i>Possible remedy</i>
Generator commutator has high mica -----	Turn down commutator and undercut mica (par. 183).
Generator regulator points burned -----	Clean or replace defective regulator points (par. 182).

180. Hydraulic Pump Fails to Deliver Sufficient Pressure

<i>Probable cause</i>	<i>Possible remedy</i>
Pump pistons and cylinder barrel defective -----	Replace pistons and cylinder barrel (pars. 207-209).
Pump shaft assembly sheared -----	Replace drive shaft assembly (pars. 207-209).
Compensator control defective -----	Repair compensator control (pars. 202-206).

181. Hydraulic Pump Fails to Deliver Sufficient Volume

<i>Probable cause</i>	<i>Possible remedy</i>
Pump pistons and cylinder barrel defective or excessively worn.	Replace pistons and barrel assembly (pars. 207-209).
Port plate excessively worn -----	Replace port plate (pars. 207-209).

CHAPTER 9

ENGINE MAINTENANCE INSTRUCTIONS

Section I. ENGINE ACCESSORIES

182. Engine Generator Regulator

a. Removal. Remove the engine generator regulator (par. 111).

b. Cleaning and Inspection.

- (1) Clean the outside of the regulator with a cloth dampened with an approved cleaning solvent and dry thoroughly.
- (2) Remove the two screws (2, fig. 33) and flat washers (3) that secure the cover (1) and gasket (4) in place and remove the cover and gasket.
- (3) Clean all leads, windings, insulators, resistors, and other parts with a clean, dry, lint-free cloth.
- (4) Inspect the coils, resistors, and insulation for signs of burning. Replace a defective regulator.
- (5) Inspect the contacts on all three units. In normal use, the contacts will become grayed. If the contacts are burned, dirty, or rough, file them with a contact point dresser. File just enough so the contacts present smooth surfaces toward each other. It is not necessary to remove all traces of burning. After filing, draw a piece of linen tape, moistened with carbon tetrachloride, between the contacts. Repeat with dry tape. If contact points are too badly burned to dress, replace contacts as described in *c* below.
- (6) Adjust and test the regulator as instructed in *e* below.
- (7) Position the cover (1) and gasket (4) on the regulator and secure in place with the two screws (2) and flat washers (3).

c. Contact Replacement.

(1) *Removal.*

- (a) Remove the two screws (8) and

lockwashers (7) that secure the armature (6) in place and remove the armature.

- (b) Remove the two screws (11) and the lockwasher (12) that secure the contact (16) in place and remove the contact.
- (c) Remove the remaining contact in a similar manner.


(2) *Installation.*

- (a) Position the contact (16) insulator bushing (15), and insulator (13) on the bus bar (14) and secure in place with the lockwasher (12) and the two screws (11).
- (b) Install the other contact in a similar manner.
- (c) Install the armature (6) securing in place with the lockwashers (7) and screws (8).
- (d) Adjust and test the regulator as instructed in *d* below.

d. Testing and Adjustment.

(1) *Continuity Test.* Use a multimeter to test the series and field circuits of the regulator.

- (a) To test the series circuits, remove the cover and touch test probes to the armature terminal (center terminal) and cutout relay armature (6). If the circuit is open, replace the regulator. Hold the cutout relay armature (6) down and test the armature terminal to the battery terminal (left terminal). If the circuit is open, clean and file the contact points. Test again, if the circuit is still open, replace the regulator.
- (b) To test the field circuit, touch the test probes to the field terminal (right terminal) and regulator



- | | | | |
|----|--|----|---------------------------|
| 1 | Cover | 11 | Screw (4 rqr) |
| 2 | Screw, machine, No. 8-32 x 2 1/2 in. (2 rqr) | 12 | Lockwasher (2 rqr) |
| 3 | Washer flat No. 8 (2 rqr) | 13 | Insulator (2 rqr) |
| 4 | Gasket | 14 | Bus bar |
| 5 | Adjusting screw | 15 | Insulator bushing (4 rqr) |
| 6 | Armature | 16 | Contact (2 rqr) |
| 7 | Lockwasher (2 rqr) | 17 | Screw (3 rqr) |
| 8 | Screw (2 rqr) | 18 | Clamp (3 rqr) |
| 9 | Spring | 19 | Grommet (3 rqr) |
| 10 | Screw, machine, No. 6-32 x 5/8 in. (2 rqr) | | |

Figure 33. Engine generator regulator, exploded view.

base. The meter must show zero resistance. Open the contacts (16) of the voltage regulator unit. The meter must show the resistance of the shunt resistor. If the circuits do not test as above, file and clean the voltage and current regulator

contacts (16) and repeat the test. If it tests faulty, replace the regulator.

(2) *Cutout Relay.* The cutout relay acts to close the circuit between the battery-charging generator and the battery when the voltage output is suffi-

cient to charge the battery, and acts to open the circuit as soon as reverse current flows from the battery to the generator.

(a) *Air Gap Adjustment.*

1. Be sure the regulator is disconnected from the battery.
2. Remove the regulator cover as described in *b* above.
3. Press down on the cutout relay armature (6) until contacts just close.
4. Measure the air gap with a feeler gage between the armature and the center core. The gap should be 0.020 inch. Adjust, if necessary, by loosening the two armature attaching screws (8) and raising or lowering the armature. Tighten the screws and measure the gap after adjustment.

Note. Be sure that both contacts are alined accurately and close simultaneously.

(b) *Contact Gap Adjustment.*

1. Measure the gap between the contact points on the cutout relay with a feeler gage. The gap should be 0.020 inch.
2. Adjust, if necessary, by bending the upper armature stop to give the proper contact gap.

(c) *Closing Voltage.*

1. Disconnect the battery lead from the regulator.
2. Mount the regulator on the unit, or on a regulator test stand if available, in the operating position. Connect the regulator to the generator. Connect a voltmeter lead to the armature terminal and ground the other voltmeter lead on the regulator.
3. Polarize the generator to prevent contacts from vibrating and burning by momentarily placing a jumper wire across the regulator terminals marked GEN and BAT. Do this after connecting all leads.
4. Start the engine and slowly increase its speed. Observe the voltmeter readings at which the cutout relay closes. They should close be-

tween 5.9 and 6.7 volts. Turn the closing voltage adjusting screw (5) clockwise to increase closing voltage or counterclockwise to decrease closing voltage until it is set at 6.0 volts.

Note. The regulator must be at operating temperature in order that proper values be obtained during testing. Operate the unit for 15 minutes at operating speed to bring up to normal operating temperature.

- (3) *Voltage Regulator Unit.* The voltage regulator unit maintains a constant battery-charging generator voltage after the voltage has been allowed by circuit valves to build up to the operational setting.

(a) *Air Gap Adjustment.*

1. Be sure the regulator is disconnected from the battery.
2. Remove the cover as described in *b* above.
3. Press down on the armature of the voltage regulator unit until the contact points are just touching.
4. Measure the air gap between the armature and the center core. The air gap should be 0.075 inch. Adjust, if necessary, by loosening the screws (11) and raising or lowering the contact (16). Tighten the screws after adjustment is made.

(b) *Voltage setting.*

1. Disconnect the battery lead from the regulator.
2. Mount the regulator on the unit, or on a regulator test stand if available, in the operating position. Connect the regulator to the generator. Connect a voltmeter lead to the battery terminal on the regulator and ground the other voltmeter lead to the regulator. Connect a fixed resistor to the battery terminal of the regulator and ground it. Fixed resistance should be 0.75 ohm and must be capable of carrying 10 amperes without any change of resistance because of heat.
3. With the regulator cover in place, bring the regulator to normal operating temperature. Reduce engine

speed and then increase slowly again to operating speed. The indicated voltage should be 7.2 volts at a 70° ambient temperature.

4. Turn the voltage adjusting screw (5) clockwise to increase voltage setting and counterclockwise to decrease it. After each adjustment, install the cover before observing indicated voltage.
- (4) *Current regulator unit.* The current regulator unit, centrally located on the regulator, limits the battery-charging generator current output to a predetermined maximum value.
- (a) *Air gap adjustment.* The current regulator unit air gap is inspected and adjusted in the same manner as the voltage regulator unit as described in (3) (a) above.
- (b) *Current setting.*
1. Mount the regulator on the unit or on a regulator test stand, if available, in the operating position. Connect the regulator to the generator. Connect an ammeter to the battery terminal of the regulator and to the ammeter lead. Connect a carbon pile or other suitable resistor across the battery to permit variation of current.
 2. Polarize the generator as described in (2) (c) 3 above and allow it to attain normal operating temperature.
 3. Slowly increase to operating speed. Adjust the resistor across the battery to allow 32 amperes to flow when the current regulator unit contacts are held shut.
 4. Release the contacts and adjust them until the ammeter reads 30 amperes. Turn the current adjusting screw clockwise to increase the current setting and counterclockwise to decrease it.

Note. Replace the regulator if it will not respond to the adjustments outlined due to mechanical or electrical faults.

e. Install the engine generator regulator (par. 111).

183. Engine Accessory Generator

a. *Removal.* Remove the generator (par. 112).

b. *Disassembly.*

- (1) Remove the pulley (15, fig. 19), fan (18), and brushes (9) as outlined in paragraph 112.
 - (2) Disconnect the spring (13) from the grounded brush holder assembly (4) and remove the brush arm (12), flat washer (14), and spring from the brush holder.
 - (3) Remove the hex nut (8), lockwasher (7), and screw (6) that secure the brush holder to the end bell (1) and remove the brush holder.
 - (4) Remove the insulated brush holder assembly (5) in a similar manner.
 - (5) Remove the end bell (30) with attached parts from the housing (44). Remove the woodruff key (19) and collar (29) from the armature (31).
 - (6) Press the armature out of the ball bearing (25).
 - (7) Remove the three screws (21) and lockwashers (22) that secure the bearing retaining plate (20) and gasket (23) to the end bell and remove the plate, gasket, flat washer (24), ball bearing, felt retainer plate (26) and preformed felt (27) from the end bell.
- Note.* Do not perform the instructions in (8), (9), and (10) below unless the tests in *d* below show the frame and field assembly defective.
- (8) Remove the two hex nuts (36), lockwashers (37), flat washer (38), and the insulating washer (39) that secure the bushing insulator (40) and stud terminal (41) in the housing and push the stud out of the housing.
 - (9) Remove the remaining stud terminal in a similar manner.
 - (10) Remove the 2 screws (33) that secure the 2 pole pieces (32) to the housing and remove the pole pieces, 2 insulator plates (35), and windings (34) from the housing.

c. Cleaning, Inspection, and Repair.

- (1) Clean a slightly dirty or discolored commutator with a strip of NO. 00 sand paper. Blow sand and dust out of the generator with clean, dry compressed air.
- (2) Clean the housing and end bells with an approved cleaning solvent and dry thoroughly.
- (3) Inspect the armature shaft and shaft bearing surfaces for nicks, burs, distortion and damaged threads. Replace a defective armature.
- (4) Inspect the armature to be sure all windings are secure in the core slots and are properly soldered in the commutator segments. Replace a defective armature.
- (5) Inspect the commutator for roughness and high mica. Place the armature shaft bearing surfaces in v-blocks, and, with a dial indicator, check the commutator for out-of-round. Turn down a commutator that is scored, rough, has high mica, or is over 0.003 inch out-of-round.
- (6) If the mica is high or the commutator has been turned, undercut the mica.
- (7) Inspect the housing for cracks, faulty insulation, or damaged threads and replace if defective.
- (8) Inspect and replace the brushes if necessary (par. 112).
- (9) Rotate the ball bearing and inspect for rough rolling elements and races. Visually inspect the bearing for excessive wear. Replace a rough or worn ball bearing.
- (10) Inspect all other parts for cracks, breaks, distortion, and damaged threads and replace if defective.

d. Testing. Test the armature for shorts, open circuits, and grounds using a suitable growler. Test the field windings for continuity and grounds with a test lamp circuit,

e. Reassembly.

- (1) Before assembling the generator, paint its interior surfaces, with the exception of bearing surfaces and points of electrical contact, with fungicidal varnish.

- (2) Position the field winding (34, fig. 19), 2 insulator plates (35), and 2 pole pieces (32) in the housing (44) and secure with the 2 screws (33).
- (3) Place the bushing insulator (40) on the stud terminal (41) and insert the terminal in the housing. Install the insulating washer (39), flat washer (38), 2 lockwashers (37), and 2 hex nuts (36). Install the remaining stud terminal in a similar manner.
- (4) Install the preformed felt (27), felt retainer plate (26), ball bearing (25) and flat washer (24) in the end bell (30). Position the gasket (23) and the bearing retaining plate (20) on the end bell and secure with the 3 lockwashers (22) and 3 screws (21).
- (5) Press the armature (31) into the installed ball bearing (25).
- (6) Install the armature and attached end bell in the housing. Place the collar (29) on the shaft of the armature and install the woodruff key (19).
- (7) Position the grounded brush holder assembly (4) on the end bell and secure with the screw (6), lockwasher (7), and the hex nut (8).
- (8) Install the flat washer (14), brush arm (12) and spring (13) on the brush holder (4) and connect the spring to apply tension to the brush arm.
- (9) Install the insulated brush holder assembly (5) in a similar manner.
- (10) Install the fan (18), pulley (15), and brushes (9) as outlined in paragraph 112.

f. Bench Testing the Generator. Test the assembled generator for current draw and output on a suitable generator test stand.

g. Installation. Install the generator (par. 112).

184. Electrical Engine Starter

a. Removal. Remove the starter (par. 113).

b. Disassembly.

- (1) Remove the brush access cover (23, fig. 20) from the housing assembly

- (35) and remove the brushes (par. 113).
 - (2) Remove the four bolts (1) and lockwashers (2) that secure the drive housing (4) to the housing assembly (35) and remove the armature (20) with attached parts from the housing.
 - (3) Remove the four screws (3) that secure the bearing plate assembly (15) and gasket (14) to the drive housing and remove the drive housing from the shaft of the armature.
 - (4) Remove the pillow block cap (5), sleeve bearing (6), and plain seal (7) from the drive housing if these parts are defective.
 - (5) Bend the tabs of the 2 key washers (10) away from the 2 shoulder bolts (8 and 9) and remove the bolts from the shaft and pinion assembly (11) and driving head (13).
 - (6) Remove the shaft and pinion assembly, spring (12), driving head, gasket, woodruff key (16), and bearing plate from the shaft of the armature.
 - (7) Remove the three thrust washers (17 and 19) and spring tension washer (18) from the armature shaft.
 - (8) Remove the two hex nuts (30), lockwashers (31), flat washer (32), and insulator washer (33) from the terminal stud of the field winding assembly (34).
 - (9) Remove the four screws that secure the winding assembly in the housing and remove the winding if defective.
- c. Cleaning, Inspection, and Repair.*
- (1) Clean all parts of the starter in the same manner as described in paragraph 183.
 - (2) Inspect the armature, field winding assembly and housing as outlined in paragraph 183.
 - (3) Inspect the sleeve bearing and the bearing plate assembly for nicks, burs, and distortion. Inspect the fit of the bearings on the armature shaft. Replace excessively worn bearings.
 - (4) Inspect the shaft and pinion assembly for damaged gear teeth and distorted threads and replace if defective.
- (5) Inspect the spring for cracks and distortion. Replace a defective spring.
 - (6) Inspect all other parts for distortion and damaged threads and replace if defective.
- d. Testing.* Test the starter in a manner similar to that outlined in paragraph 183.
- e. Reassembly.*
- (1) Position the field winding assembly (34) in the housing assembly (35) and secure with the four screws.
 - (2) Install the insulator washer (33), flat washer (32), 2 lockwashers (31), and 2 hex nuts (30) on the terminal stud of the winding assembly.
 - (3) Install the three thrust washers (17 and 19) and the spring tension washer (18) on the shaft of the armature (20).
 - (4) Apply a thin film of oil on the bearing surfaces of the armature shaft and slide the bearing plate assembly (15) on the shaft.
 - (5) Insert the woodruff key (16) in the armature shaft and slide the driving head (13), spring (12), and shaft and pinion assembly (11) on the armature shaft.
 - (6) Secure the spring (12), driving head (13) and shaft and pinion assembly (11) to the armature shaft with 2 new key washers (10) and the 2 shoulder bolts (8 and 9). Be sure the bolt (9) seats in the hole provided in the armature shaft.
 - (7) Press the plain seal (7), sleeve bearing (6), and pillow block cap (5) into the drive housing (4).
 - (8) Secure a new gasket (14) and the bearing plate assembly (15) to the drive housing with the four screws (3).
 - (9) Insert the armature with attached parts in the housing assembly (35) and secure the drive housing in place with the four lockwashers (2) and bolts (1) .

- (10) Install the brushes (par. 113) and the brush access cover (23).

f. Bench-Testing the Starter.

- (1) *No-load Test.* Connect a 100-ampere ammeter, a carbon-pile rheostat, and a 6-volt battery in series with the starter terminal and housing. connect a voltmeter from the terminal to the housing. With the voltage adjusted to 5.0 volts, the current should be 68 amperes maximum at 4,000 rpm. If the current and speed are both low, check for high resistance in the internal connections. If the current is high and the speed is low, check the armature for binding.
- (2) *Stall Torque Test.* With the starter connected as in (1) above, fasten a torque arm and a spring scale to the armature at the drive end. Adjust the rheostat to give 2.0 volts. The correct current reading is 280 amperes maximum and a stall torque of 4.4 ft-lb minimum. Stall torque is the product of the spring scale reading in pounds, multiplied by the length of the torque arm in feet. If current and torque are both low, check the internal connections for high resistance and the brushes for proper contact. High current and low torque may be caused by a defective armature or field winding.

g. Installation. Install the starter (par. 113).

185. Ignition Magneto

a. Removal. Remove the magneto (par. 115).

b. Disassembly.

- (1) Remove the distributor contact set (par. 115).
- (2) Remove the retaining ring (41, fig. 21) and the threaded straight pin (43) that secure the spur gear (42) to the magneto rotor (47) and remove the gear.
- (3) Remove the four screws (20) that secure the contact breaker plate (46) to the magneto housing (50) and remove the breaker plate and flat washer (44).

- (4) Remove the retaining ring (38) that secures the spur gear (39) in the sleeve bearing (40) and remove the gear.
- (5) Press the roller bearing (45) and the sleeve bearing (40) from the contact breaker plate (46) if defective.
- (6) Remove the two setscrews (49) that secure the magneto coil (48) in the housing and remove the coil.
- (7) Remove the cotter pin (21) and castellated hex nut (22) that secure the helical gear (23) and sleeve bushing (24) on the rotor and remove the gear and bushing.
- (8) Using a suitable gear puller, remove the magneto coupling (29) with attached spring (26) and housing (25) from the rotor.
- (9) Remove the housing and spring from the coupling. Remove the spring (30) from the coupling.
Warning: Remove the housing from the spring carefully and slowly to prevent the rapid uncoiling of the spring.
- (10) Remove the woodruff key (28), packing retainer (31), flat washer (32), preformed packing (33), and flat washer (34) from the rotor.
- (11) Remove the retaining ring (35) from the shaft of the rotor and press the rotor out of the ball bearing (37).
- (12) Remove the retaining ring (36) and the ball bearing from the housing.
- (13) Remove the threaded straight pin (27) from the housing.

c. Cleaning, Inspection, and Repair.

- (1) Clean all metal parts with an approved cleaning solvent and dry thoroughly.
- (2) Test the coil on a coil tester. The primary draw must be 1.6 amperes. Replace a defective coil.
- (3) Test the capacitor on a capacitor tester for shorts, opens, and leakage and for capacitance that should test between 0.17 and 0.21 μf (microfarad). Replace a defective capacitor.
- (4) Inspect the bearings for nicks, burs, and abrasions. Rotate the ball bear-

ing, inspecting for rough rolling elements and races. Replace defective bearings.

- (5) Inspect the end cap and housing for cracks, breaks, and damaged threads. Replace a damaged end cap or housing.
- (6) Inspect the rotor for cracks, breaks, and corrosion. Replace a defective rotor.
- (7) Inspect the gears for wear, chipped or broken teeth. Check the fit of the gears on their respective shaft and bearings. Replace any defective part.
- (8) Inspect the springs for distortion, cracks, and loss of tension. Replace a defective spring.
- (9) Inspect the coupling for freedom of movement. Inspect the housing for cracks, breaks, and distortion.
- (10) Inspect the rotor and shaft for nicks, burs, distortion, and damaged threads. Remove minor abrasions from the shaft of the rotor. Replace a defective rotor.
- (11) Inspect all other parts for distortion and damage and replace if defective.

d. Reassembly.

- (1) Install the threaded straight pin (27, fig. 21) in the magneto housing (50).
- (2) Install the ball bearing (37) and the retaining ring (36) in the housing.
- (3) Press the magneto rotor (47) into the ball bearing and install the retaining ring (35) on the shaft of the rotor.
- (4) Install the coil (48) in the magneto housing (50) and secure with the two setscrews (49).
- (5) Press the roller bearing (45) and sleeve bearing (40) into the contact breaker plate (46).

- (6) Insert the spur gear (39) in the installed sleeve bearing and install the retaining ring (38).
- (7) Install the flat washer (44) on the rotor. Position the breaker plate with attached parts in the housing, and secure with the four screws (20).
- (8) Install the spur gear (42) on the rotor (47) alining the marked teeth of each spur gear and at the same time align the pin holes of the gear and rotor shaft. Secure the gear in place with the threaded straight pin (43) and the retaining ring (41).
- (9) Install the two springs (30) on the magneto coupling (29). Install the outer end of the spring (26) on the spring anchor in the housing (25). Engage the inner end of the spring in the long slot of the coupling. Wind one full turn clockwise and press the coupling into the housing.
- (10) Install the assembled magneto impulse coupling on the shaft of the magneto rotor (47) alining key and keyway.
- (11) Install the contact set (16) and distributor rotor (12) as outlined in paragraph 115.
- (12) Rotate the magneto rotor (47) until the distributor rotor (12) is in position to fire No. 1 cylinder. Place the sleeve bushing (24) in the helical gear (23) and install the gear on the rotor shaft with the punch marked tooth alined with the threaded straight pin (27). Secure the gear in place with the castellated hex nut (22) and cotter pin (21).
- (13) Install the end cap (9) and capacitor (1) as described in paragraph 115.

e. installation. Install and time the magneto (par. 115).

Section II. CYLINDER BLOCK GROUP

186. Valves

a. Removal.

- (1) Remove the intake and exhaust manifold (par. 123).
- (2) Remove the cylinder heads (par. 124).

- (3) Use a valve spring compressor to compress the spring (9, fig. 26). Remove the pair of retainer locks (7), rotator cap (6), and the valve spring seat (8). Remove the spring compressor,

lift out the valve (10) and remove the spring from the cylinder block (13). Remove the seven other valves in the same manner.

Note. Tag or otherwise identify each valve and its related parts to assure reinstallation in the same valve chamber.

b. Cleaning and Inspection.

- (1) Clean the valves with a wire wheel brush to remove carbon from the valve faces and gum deposits from the stems.
- (2) Clean all other removed parts with an approved cleaning solvent and dry thoroughly.
- (3) Clean the valve guides in the cylinder blocks and blow clean with compressed air.
- (4) Clean the valve seat inserts in the cylinder blocks and the top of the blocks.
- (5) Inspect the valves for burned, pitted, or cracked faces. Replace a defective valve.
- (6) Inspect the valve springs for cracks or pitting. Replace cracked or pitted valve springs. Check spring tension with a dial-type spring tester. If the scale reading is less than 85 pounds when spring is compressed to $1\frac{7}{8}$ inches, replace the spring.
- (7) Inspect the valve seat inserts for loose or worn condition. Replace loose valve seat inserts.
- (8) Measure the clearance between the valve stems and the valve guides. Replace the valve guides if the clearance exceeds 0.007 inch.

c. Valve and Valve Seat Refacing.

- (1) Using a valve face grinder, reface the valves to a 45° angle. Replace any valve that measures less than 0.0625 inch from the top of the head to the edge of the refaced outer circle.
- (2) Install a pilot in the valve guide. Set the stone at 45° and dress the stone. Grind the seat just enough to remove pits and abrasions.

d. Valve Grinding Procedure.

- (1) Remove all traces of carbon from the face of the cylinder block.

- (2) Lightly coat the entire seat with water-soluble valve grinding compound. Grind the valves by rotating them back and forth with a reciprocating advancing valve tool. Occasionally lift the valve and reseat it in a different position to insure a uniform seat. After the valves have been ground in evenly, remove them and clean the valves and blocks thoroughly with an approved cleaning solvent.

e. Installation.

- (1) Position the spring (9, fig. 26) in the cylinder block (13) and insert the valve (10) in the valve stem guide (12).
- (2) Compress the valve spring and install the valve spring seat (8), retainer locks (7), and the rotator cap (6) on the valve stem. Install the seven other valves in a similar manner.
- (3) Adjust the valve lifters (par. 125).
- (4) Install the cylinder heads (par. 124).
- (5) Install the intake and exhaust manifold (par. 123).

187. Valve Seat Inserts and Valve Guides

a. Cleaning and Inspection.

- (1) Remove the valves (par. 186).
- (2) Use a valve guide cleaning tool to ream carbon from the valve guides. Blow carbon from the guides with clean compressed air.
- (3) Clean the face of the valve seat inserts with a wire brush or buffing wheel.
- (4) Clean the valve stem and insert the valve into the guide. Check the side play of the valve in the guide with a dial indicator. If the clearance between the stem and the guide exceeds 0.007 inch replace the valve guide.
- (5) Inspect the valve seat inserts for pitting, cracks, abrasions or uneven wear. If the inserts cannot be repaired by grinding (par. 186) they must be replaced.

b. Removal.

- (1) Use a drift to drive the valve stem guide (12, fig. 26) down through the

block into the valve spring chamber. Remove the other valve stem guides in the same manner.

- (2) Use a puller to remove the valve seat inserts (11).

c. Installation.

- (1) Place the valve stem guide (12) in position with the countersunk end downward. Drive the guide into place with top of the guide flush with the valve chamber. Install the other valve stem guides in the same manner.

- (2) Ream the counterbore to an inside diameter of 0.004 inch smaller than the valve seat insert (11) to be installed.
- (3) Chill each new insert in dry ice for ten minutes to reduce its diameter slightly.
- (4) Use a pilot driver to tap the insert into place.
- (5) Grind the valves to the new inserts (par. 186).
- (6) Install the valves (par. 186).

Section III. GEAR COVER AND TIMING GEARS

188. General

The gear cover, located on the front of the engine, encloses the timing gear train. The timing gear train consists of the camshaft gear, crankshaft gear, idler gear, oil pump gear, and magneto gear. The governor and magneto gears can be removed from the gear train without removing the gear cover. The remaining gears, with the exception of the crankshaft gear, can be removed after removal of the gear cover.

189. Gear Cover

a. Removal.


- (1) Remove the magneto (par. 115).
- (2) Remove the air shrouding group (pars. 118 and 119).
- (3) Remove the governor (par. 135).
- (4) Drain the oil from the engine into a suitable container.
- (5) Drive the two headless straight pins (1, fig. 34) from the gear cover (10).
- (6) Remove the 10 bolts (5) and lockwashers (6) that secure the gasket (4) and the gear cover to the gear cover spacer (2). Remove two additional bolts and lockwashers from the rear top side of the gear cover spacer and remove the cover and gasket from the spacer.
- (7) Remove the timing hole plug (7) and plunger button (8) from the gear cover.
- (8) Remove the oil seal (9) if defective.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Inspect the gear cover for cracks, breaks, distortion, and damaged threads. Repair cracks by welding and retap damaged threads. Replace a gear cover damaged beyond repair.
- (3) Inspect all other parts for distortion and damaged threads and replace if defective.

c. Installation.

- (1) Install the plunger button (8, fig. 34) and the timing hole plug (7) in the gear cover (10).
- (2) Press the oil seal (9) into the gear cover.
- (3) Position a new gasket (4) and the gear cover (10) on the gear cover spacer (2) and install the two headless straight pins (1).
- (4) Secure the cover in place with the 10 lockwashers (6) and bolts (5). Install the 2 remaining lockwashers and bolts from the rear top side of the gear cover. Tighten the bolts to 14 to 18 ft-lb torque.
- (5) Fill the engine crankcase with the proper grade oil. Refer to table 1.
- (6) Install the governor (par. 135).
- (7) Install the air shrouding group (pars. 118 and 119).
- (8) Install the magneto (par. 115).



- | | | | |
|---|---|----|---|
| 1 | Headless straight pin (2 rqr) | 6 | Washer, lock, $\frac{5}{16}$ in. (10 rqr) |
| 2 | Gear cover spacer | 7 | Timing hole plug |
| 3 | Gasket | 8 | Plunger button |
| 4 | Gasket | 9 | Oil seal |
| 5 | Bolt, machine, $\frac{5}{16}$ -18 x $1\frac{1}{4}$ in. (10 rqr) | 10 | Gear cover |

Figure 34. Gear cover group, exploded view.

190. Timing Gears

a. Removal.

- (1) Remove the gear cover (par. 189).
- (2) Remove the setscrew that secures the idler gear stud in the crankcase and remove the stud and the idler gear.
- (3) Remove the plunger button (19, fig. 27), thrust plunger (20) and spring (21) from the camshaft (25).
- (4) Remove the three bolts (24) and lockwashers (23) that secure the camshaft gear (22) to the camshaft and remove the gear from the camshaft.
- (5) Remove the hex nut (1, fig. 35) that secures the oil pump gear (2) in place and remove the gear and woodruff key.
- (6) Remove the eight bolts and lockwashers that secure the gear cover spacer (2, fig. 34) and the gasket (3) to the crankcase and remove the spacer and gasket.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the gears for cracked, broken, or chipped teeth. Replace a damaged or excessively worn gear.
- (3) Inspect the idler gear stud, plunger, and plunger button for nicks, burs, and minor abrasions. Remove nicks and burs with fine emery cloth. Replace any part damaged beyond repair.
- (4) Inspect the spring for cracks, distortion, and lack of tension. Replace a defective spring.
- (5) Inspect all attaching hardware for distortion and damaged threads and replace if defective.

c. Installation.

- (1) Position a new gasket (3, fig. 34) and the gear cover spacer (2) on the

crankcase and secure with the eight lockwashers and bolts.

- (2) Install the woodruff key and the oil pump gear (2, fig. 35) on the drive shaft (16) and secure in place with the hex nut (1).
- (3) Position the camshaft gear (25, fig. 27) on the camshaft aligning the holes of the gear and camshaft and at the same time align the marked teeth of the crankshaft and camshaft gears. Secure the gear in place with the three lockwashers (23) and bolts (24).
- (4) Insert the spring (21), camshaft thrust plunger (20), and plunger button (19) in the camshaft.
- (5) Position the idler gear on the crankcase and install the idler gear stud in the aligned holes of the gear and crankcase. Secure the stud in place with the setscrew.
- (6) Install the gear cover (par. 189).

Section IV. CRANKCASE BOTTOM PLATE AND OIL PUMP

191. General

The crankcase cover is essentially the engine oil pan. It is an attached container into which the engine lubricating oil is returned after being circulated by the oil pump. A gear-type oil pump, driven from the idler gear in the timing gear train, draws oil from the oil pan through its screen. The oil pump delivers the oil under pressure to an oil header, which sprays oil against the fins of the connecting rod caps for rod bearing lubrication and directs oil through exterior oil lines to the governor and bypass-type oil filter. The cylinders are lubricated by the oil mist arising from the connecting rod caps. Lubrication and splash plates are installed inside the crankcase to prevent excess lubrication of the cylinder walls.

192. Crankcase Bottom Plate

a. Removal.

- (1) Drain the oil from the engine.
- (2) Remove the fuel tank (par. 132).
- (3) Remove the elbow (23, fig. 11) and pipe nipple (22) from the crankcase bottom plate (20).

- (4) Remove the 14 bolts (27, fig. 24) and lockwashers (28) that secure the crankcase bottom plate (29) and gasket (30) to the crankcase assembly (31) and remove the plate and gasket.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the plate, elbow, and nipple for cracks, breaks, distortion, and damaged threads. Repair cracks or leaks in the plate by welding. Replace any part damaged beyond repair.
- (3) Inspect all attaching hardware for distortion and damaged threads and replace if defective.

c. Installation.

- (1) Position a new gasket (30, fig. 24) and the crankcase bottom plate (29) on the crankcase assembly (31) and secure with the 14 lockwashers (28) and bolts (27). Tighten the bolts to a torque of 6 to 7 ft-lb.
- (2) Install the pipe nipple (22, fig. 11)

and the elbow (23) in the crankcase bottom plate (20).

- (3) Install the fuel tank (par. 132).
- (4) Fill the engine crankcase with oil. Refer to table 1.

193. Oil Pump


a. Removal.

- (1) Remove the engine (par. 108).
- (2) Remove the crankcase bottom plate (par. 192).
- (3) Remove the oil pump (par. 190).
- (4) Remove the pipe plug and the oil pump lock screw that secure the oil

pump assembly in the crankcase and remove the oil pump.

b. Disassembly.

- (1) Remove the four screws (3, fig. 35) and lockwashers (4) that secure the screen (5) to the cover (11) and remove the screen.
- (2) Pull the cotter pin (8) from the cover releasing the spring (9) and bearing ball (10).
- (3) Remove the six screws (6) and lockwashers (7) that secure the cover and gasket (12) to the body (18) and remove the cover and gasket.



- | | |
|---|--------------------------|
| 1 Nut | 10 Bearing ball |
| 2 Oil pump gear | 11 Cover |
| 3 Screw, machine, No. 10-32 x $\frac{3}{8}$ in. (4 rqr) | 12 Gasket |
| 4 Washer, lock, No. 10 | 13 Spur gear |
| 5 Screen | 14 Headless straight pin |
| 6 Screw, machine, No. 10-32 x $\frac{1}{2}$ | 15 Spur gear |
| 7 Washer, lock, No. 10 | 16 Drive shaft |
| 8 Cotter pin | 17 Stub shaft |
| 9 Spring | 18 Body |

Figure 35. Oil pump assembly, exploded view.

- (4) Remove the spur gear (13) and stub shaft (17) from the body.
 - (5) Remove the drive shaft (16) with attached spur gear (15) from the pump body. Drive the headless straight pin (14) out of the gear and press the drive shaft out of the gear.
- c. Cleaning, Inspection, and Repair.*
- (1) Clean all parts with an approved cleaning solvent and dry thoroughly. Blow oil passages clean with compressed air.
 - (2) Inspect the gears for cracked, chipped, or excessively worn teeth. Replace a defective gear.
 - (3) Inspect the cover and body for cracks, breaks, distortion and damaged threads. Replace a defective cover or body.
 - (4) Inspect the shafts for nicks, burs, and distortion. Remove minor abrasions. Check the fit of the stub shaft in the gear. Replace a defective shaft. Check the fit of the drive shaft in the pump body. Replace an excessively worn shaft or pump body.
 - (5) Inspect the bearing ball for pits and proper seating in the cover. Replace a defective ball.
 - (6) Inspect the spring for cracks, distortion, and for lack of tension. Replace a defective spring.
- (7) Inspect all attaching hardware for distortion and damaged threads and replace if defective.
- d. Reassembly.*
- (1) Press the drive shaft (16, fig. 35) into the spur gear (15) and install the headless straight pin (14). Insert the drive shaft with attached gear in the body (18).
 - (2) Install the stub shaft (17) and spur gear (13) in the body.
 - (3) Position a new gasket (12) and the cover (11) on the pump body and secure with the six lockwashers (7) and screws (6).
 - (4) Insert the bearing ball (10) and spring (9) in the cover, compress the spring and install the cotter pin (8).
 - (5) Mount the screen (5) on the cover and secure with the four lockwashers (4) and screws (3).
- e. Installation.*
- (1) Install the oil pump assembly in the crankcase and secure with the oil pump lock screw and pipe plug.
 - (2) Install the oil pump gear (par. 190).
 - (3) Install the crankcase bottom plate (par. 192).
 - (4) Install the engine (par. 108).

Section V. CRANKSHAFT AND CAMSHAFT GROUP

194. General

The crankshaft is supported at both ends by roller bearings. The outer race of the bearing at the power take off end of the engine, is carried in the main bearing retainer plate, which is secured to the crankcase. Shims are installed between the bearing plate and crankshaft to provide a means of adjusting crankshaft end play. The connecting rods, which are installed on the crankshaft, are drop forgings fitted with shell-type bearings. The pistons are made of cast iron with four rings fitted to each piston. Two compression rings are in the two top grooves, followed by a scraper ring and an oil

ring in the other grooves. The camshaft is driven through gears by the crankshaft. The camshaft, through the valve lifters, operates the intake and exhaust valves at the precise time in relation to engine cycle.

195. Connecting Rod and Piston

a. Removal.

- (1) Remove the oil pump (par. 193).
- (2) Remove the cylinder heads (par. 124).
- (3) Turn the crankshaft until the lower end of the desired connecting rod (12, fig. 36) is accessible.


(4) Remove the 2 stamped nuts (7), 2 hex nuts (8), and 2 bolts (9) that secure the cap of the connecting rod in place, remove the cap and push the connecting rod with attached piston (4) out through the top of the cylinder block. Reassemble the cap and bearing on the connecting rod to prevent damage or loss.

(5) Remove the three remaining connecting rods and pistons in a similar manner.

Note. The connecting rods, bearings, and caps are marked and must be paired together to insure correct installation.

b. Disassembly.

(1) Remove the two retaining rings (5) and the piston pin (6) from the piston



- | | | | |
|----|--|----|--|
| 1 | Piston ring (8 rqr) | 18 | Bolt (6 rqr) |
| 2 | Piston ring (4 rqr) | 19 | Lockwasher (6 rqr) |
| 3 | Piston ring (4 rqr) | 20 | Flywheel |
| 4 | Piston (4 rqr) | 21 | Woodruff key |
| 5 | Retaining ring (8 rqr) | 22 | Bolt, machine, $\frac{3}{8}$ -16 x 1 $\frac{1}{4}$ in. (6 rqr) |
| 6 | Piston pin (4 rqr) | 23 | Washer, lock, $\frac{3}{8}$ in. (6 rqr) |
| 7 | Stamped nut, $\frac{3}{8}$ -24 (8 rqr) | 24 | Oil seal |
| 8 | Nut, plain, hex, $\frac{3}{8}$ -24 (8 rqr) | 25 | Bearing plate |
| 9 | Bolt (8 rqr) | 26 | Gasket (2 rqr) |
| 10 | Sleeve bearing (8 rqr) | 27 | Shim (2 rqr) |
| 11 | Sleeve bearing (4 rqr) | 28 | Shim (2 rqr) |
| 12 | Connecting rod | 29 | Oil slinger |
| 13 | Starting crank | 30 | Crankshaft gear |
| 14 | Headless straight pin | 31 | Woodruff key |
| 15 | Nut | 32 | Bearing cup (2 rqr) |
| 16 | Washer, lock | 33 | Bearing cone (2 rqr) |
| 17 | Generator drive sheave | 34 | Crankshaft |

Figure 36. Crankshaft, piston and connecting rod group, exploded view.

- (4) and remove the piston from the connecting rod.
 - (2) Remove the piston rings (1, 2, and 3) from the piston.
 - (3) Press the sleeve bearing (11) out of the connecting rod if defective or un-serviceable.
 - (4) Disassemble the other pistons and connecting rods in the same manner.
- c. Cleaning, Inspection, and Repair.*
- (1) Clean carbon from the top of the pistons. Wash all parts with an approved cleaning solvent and dry thoroughly.
 - (2) Use an inside micrometer to measure the cylinder bores for wear. All cylinders should measure 3.504 to 3.505 inches. Remove, rebore, and hone the the cylinder blocks (par. 199) whose measurement exceeds the allowable wear of 0.005 inch and install oversize pistons and rings.
 - (3) To measure the piston ring gap, place the ring in the cylinder bore in the approximate operating position and measure the gap with a feeler gage. The piston ring gaps should measure between 0.010 and 0.015 inch. If the gap is too great replace the piston ring with an oversize ring. If the gap is too small remove stock by filing.
 - (4) Place two strips of 0.002 inch shim stock 1/2 inch wide, on opposite sides of the piston. Invert the piston and slide it into the cylinder bore. Attach a spring pull scale to one of the pieces of shim stock and pull up on the scale. A pull of 4 to 8 pounds should be required to pull the stock out. If the shim stock pulls out too freely replace the piston with an oversized one. Re-bore and rehone the cylinder bore as necessary.
 - (5) Measure the piston ring side clearance. Replace the piston when clearance exceeds 0.003 inch in the three top grooves or 0.004 inch in the bottom groove.
 - (6) Measure the piston pin fit in the piston. If the clearance exceeds 0.0005 inch, replace the piston and piston pin.
 - (7) Check the piston pin sleeve bearing for wear, scoring, and out-of-round. The clearance between the piston pin and bearing should not exceed 0.001 inch. Replace a defective bearing.
 - (8) Inspect the bearing halves for wear or scoring. Replace both bearing halves if either is un-serviceable. Measure the bearing-to-crankshaft clearance by installing a piece of 0.001 inch shim stock on each bearing half. Assemble the connecting rod and cap with shimmed bearing to its respective crankshaft journal and tighten the nuts to a torque of 14 to 18 ft-lb. A slight drag on the shaft, when turned by hand indicates proper clearance. The connecting rod bearing should not bind using shim stock with a minimum thickness of 0.0005 inch.
- d. Reassembly.*
- (1) Press the sleeve bearing (11, fig. 36) into the connecting rod (12). Ream and hone new bearings (11) to provide a clearance of from 0.0005 to 0.001 inch between the piston (6) and the bearing.

Note. Be sure to aline the oil holes of the connecting rod and bearing.
 - (2) Position the piston on the connecting rod and install the piston pin (6) and the two retaining rings (5).
 - (3) Install the oil piston ring (3) in the bottom groove of the piston (4) with its scraper edge down. Install the scraper piston ring (2) in the adjacent groove with its scraper edge down. Install the two remaining piston rings (1) in the upper grooves. Stagger the ring gaps around the piston.
 - (4) Reassemble the three remaining pistons and connecting rods in a similar manner.
- e. Installation.*
- (1) Place a ring compressor on the piston.
 - (2) Insert the connecting rod (12, fig. 36) with attached piston in its respective cylinder bore and push piston out of the ring compressor into the cylinder block.

Note. When installing the pistons in the cylinders, install those in numbers 1 and 3 cylinders so the slits in the piston skirts face toward the center of the engine. The slits in pistons 2 and 4 face away from the center of the engine.

- (3) Apply a thin film of oil to the crankshaft journal to which the rod is to be connected. Position the rod and cap with installed sleeve bearing (10) on the journal of the crankshaft (34) and install the 2 bolts (9), 2 hex nuts (8), and 2 stamped nuts (7). Tighten the hex nuts to a torque of 14 to 18 ft-lb.

Note. Be sure the oil hole in the cap of the connecting rod faces the spray nozzle in the oil header of the crankcase.

- (4) Install the four remaining pistons and connecting rods in the same manner.
- (6) Measure the side clearance between the sleeve bearing (10) and the crankshaft with a feeler gage. It should measure at least 0.004 inch and not more than 0.016 inch.
- (6) Install the cylinder heads (par. 124).
- (7) Install the oil pump (par. 193).

196. Crankshaft

a. Removal.

- (1) Remove the oil pump (par. 193).
- (2) Remove the connecting rods and pistons (par. 195).
- (3) Remove the oil slinger (29, fig. 36) from the front end of the crankshaft (34).
- (4) Remove the six bolts (22) and lockwashers (23) that secure the bearing plate (25) to the crankcase and remove the bearing plate with attached oil seal (24) and bearing cup (32), gaskets (26) and shims (27 and 28).
- (5) Remove the cup and oil seal from the bearing plate if defective.
- (6) Carefully remove the crankshaft with attached parts through the rear opening in the crankcase.
- (7) Press the crankshaft gear (30) off the crankshaft and remove the woodruff key (31) from the crankshaft.
- (8) Press the two bearing cones (33) off the crankshaft.

- (9) Remove the six bolts and lockwashers (23) that secure the bearing retainer plate to the crankcase and remove the retainer plate.

- (10) Remove the bearing cup (32, fig. 36) from the crankcase if defective.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the connecting rod journals of the crankshaft for scoring. Hone a crankshaft to remove scores or replace a defective crankshaft.
- (3) Measure the journals. Replace the crankshaft if the journals measure less than 2.125 inches.
- (4) Inspect the bearing plate for cracks and breaks. Replace if defective.
- (5) Inspect the oil seal for damage or signs of wear. Replace a defective oil seal.
- (6) Inspect the bearing cones and cups for rough rolling elements and races. Replace if defective.
- (7) Inspect all attaching hardware for distortion and damaged threads and replace if defective.

c. Installation.

- (1) Install the bearing cup (32, fig. 36) in the crankcase.
- (2) Position the bearing retainer plate on the crankcase and secure with the 6 lockwashers and 6 bolts.
- (3) Press the two bearing cones (33, fig. 36) onto the crankshaft (34).
- (4) Insert the woodruff key (31) in the crankshaft and press the crankshaft gear (30) onto the crankshaft.
- (5) Carefully insert the crankshaft in the crankcase through the rear opening.
- (6) Press the oil seal (24) and the bearing cup (32) into the bearing plate (25).
- (7) With a thin film of grease, position one gasket (26) on the crankcase, the other on the bearing plate. Position the shims (27 and 28) and the bearing plate on the crankcase and secure with 6 lockwashers (23) and 6 bolts (22).

Tighten the bolts to a torque of 25 to 30 ft-lbs.

- (8) Clamp a dial indicator on the crankcase with its plunger touching the end of the crankshaft. Pry the crankshaft back and forth while noting the indicator reading. Add or delete shims (27 and 28) as necessary to obtain end play between 0.002 and 0.004 inch.
- (9) Install the oil slinger (29) on the crankshaft.
- (10) Install the connecting rods and pistons (par. 195).
- (11) Install the oil pump (par. 193).

197. Camshaft

a. Removal.

- (1) Remove the valves (par. 186).
- (2) Remove the crankshaft (par. 196).
- (3) Remove the 8 tappet assemblies (5, fig. 26) from the 2 cylinder blocks (13). Tag the tappets to assure installation in their respective bores.
- (4) Remove the crankshaft gear (par. 190).
- (5) Remove the camshaft (25, fig. 27) from the crankcase.
- (6) Remove the 6 bolts and lockwashers that secure the 2 splash plates in place and remove the splash plates from inside the crankcase.

- (7) Remove the expansion plug (32, fig. 24) if defective.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts with an approved cleaning solvent and dry thoroughly.
- (2) Inspect the bearing surfaces and cam lobes of the camshaft for nicks, burs, and scores. Remove minor abrasions with fine emery cloth. Replace a defective camshaft.
- (3) Inspect the tappet assemblies for nicks, burs, distortion, and damaged threads. Replace a defective tappet assembly.
- (4) Inspect the expansion plug in the crankcase for signs of oil leaks. Remove and replace if defective.

c. Installation.

- (1) Install the expansion plug (32, fig. 24) in the crankcase.
- (2) Position the 2 splash plates in the crankcase and secure with the 6 lockwashers and 6 bolts.
- (3) Install the camshaft (25, fig. 27) in the crankcase.
- (4) Install the camshaft gear (par. 190).
- (5) Insert the 8 tappet assemblies (5, fig. 26) in the 2 cylinder blocks (13).
- (6) Install the crankshaft (par. 196).
- (7) Install the valves (par. 186).

Section VI. CYLINDER BLOCKS AND CRANKCASE

198. General

The cylinder blocks are cast in pairs and are provided with cooling fins. The valve stem guide bores are machined in the blocks. The cylinder blocks are secured to the crankcase with studs and hex nuts. The crankcase is a one-piece casting with an integral cast oil vane on the left-side into which are installed the oil nozzles.

199. Cylinder Blocks

a. Removal.

- (1) Remove the valves (par. 186).
- (2) Remove the connecting rods and pistons (par. 195).

- (3) Remove the six hex nuts and lockwashers that secure the cylinder block to the crankcase and remove the block and gasket (5, fig. 24) from the crankcase.
- (4) Remove the six studs (34) from the crankcase, if defective.
- (5) Remove the other cylinder block in the same manner.

b. Cleaning, Inspection, and Repair.

- (1) Use a wire brush, compressed air, and an approved cleaning solvent to clean the fins of the cylinder blocks.
- (2) Inspect the cylinder bores of the cylin-

der blocks for scores. Rebore and hone a scored cylinder block and install oversized pistons (par. 195).

- (3) Inspect the cylinder block for cracks, breaks, distortion and damaged threads. Replace a defective cylinder block.
- (4) Inspect all attaching hardware for distortion and damaged threads and replace if defective.

c. Installation.

- (1) Install the six studs (34, fig. 24) in the crankcase.
- (2) Position a new gasket (5) and the cylinder block on the crankcase and secure with the six lockwashers and hex nuts. Tighten the nuts to a torque of 62 to 78 ft-lb.
- (3) Install the connecting rods and pistons (par. 195).
- (4) Install the valves (par. 186).

- (5) Install the other cylinder block in the same manner.

200. Crankcase

a. Removal.

- (1) Remove the timing gears (par. 190).
- (2) Remove the camshaft (par. 197).
- (3) Remove the cylinder blocks (par. 199).

b. Cleaning, Inspection, and Repair.

- (1) Clean the crankcase with an approved cleaning solvent and dry thoroughly. Blow the oil header clear with compressed air.
- (2) Inspect the crankcase for cracks, breaks, distortion, and damaged threads. Replace a defective crankcase.

c. Installation.

- (1) Install the cylinder blocks (par. 199).
- (2) Install the camshaft (par. 197).
- (3) Install the timing gears (par. 190).

CHAPTER 10

HYDRAULIC SYSTEM AND RUNNING GEAR MAINTENANCE INSTRUCTIONS

Section I. PRESSURE COMPENSATOR CONTROL

201. General

The pressure compensator control is similar in operation to a pressure relief valve. As the pressure is increased in the system, the flow from the compensator valve is applied directly against a piston, pressing this piston against the hanger mechanism, reducing the angle of the cam plate. The greater the pressure, the greater the distance the hanger is depressed, reducing the volume while maintaining the pressure. The volume will continue to reduce until the bottom stop is encountered. This minimum stop is used only when it is not desirable to go to zero volume delivery.

202. Removal

- a.* Remove the pump (par. 153).
- b.* Remove the compensator and volume hand controls (par. 154).
- c.* Disconnect the tube (1, fig. 37) from the two tube fittings (2) and remove the fittings from the control cap (9) and the pressure flange (39).
- d.* Remove the four screws (6) that secure the control cap to the hanger housing assembly (13) and remove the control cap and gasket (12).
- e.* Remove the 20 screws (4) that secure the end cap (3) and gasket (5) to the hanger housing assembly (13) and remove the end cap and gasket.
- f.* Remove four screws (7) that secure the stop body assembly (10) and gasket (12) to the hanger housing and remove the stop body and gasket.
- g.* Remove the four screws (8) that secure the clevis (11) in place and remove the clevis.

203. Disassembly

- a.* Remove the stop spool (1, fig. 38) and O-ring packing (2) from the control cap (21).
- b.* Pull the control sleeve (5) with attached parts out of the control cap. Remove the retaining ring (3) and O-ring packing (4) from the control sleeve.
- c.* Remove the control piston (6), spring (7), and spring retainer (8) from the control cap.
- d.* Remove the lockwasher (9) and preformed packing (10) from the adjustment housing (15).
- e.* Remove the adjustment housing and preformed packing (16) from the control cap. Remove the seal piston (11), spring (12), ball support (13), and ball (14) from the adjustment housing.
- f.* Remove the control sleeve (19) with attached parts from the control cap (21). Remove the control piston (17) from inside the sleeve and remove the retaining ring (18) and preformed packing (20) from the control sleeve.
- g.* Remove the two screws (22) that secure the control cap (21) to the control housing (26) and remove the control cap, O-ring packing (23), and O-ring gasket (24). Remove the piston (25) from the control housing.
- h.* Remove the 2 dowel pins (35 and 37) and the 2 bearings (36 and 38) from the clevis (39).
- i.* Remove the nut (27) from the stop body (34). Pull the tongue (29) out of the stop body and remove the O-ring packing (28) from the tongue.
- j.* Unscrew the stop (32) from the stop body (34). Remove the spring (33). Remove the roll pin (30) and piston (31) from the stop.




Figure 37. Pump, exploded view.

1. Tube	27 Cylinder barrel
2 Tube fitting (2 rqr)	28 Screw, socket head, $\frac{1}{4}$ -20 x $1\frac{1}{2}$ in. (7 rqr)
3 End cap	29 Bearing
4 Screw, socket head, $\frac{1}{4}$ -20 x $\frac{7}{8}$ in. (20 rqr)	30 O-ring gasket (2 rqr)
5 Gasket	31 Port plate
6 Screw, socket head, $\frac{7}{16}$ -14 x 1 in. (4 rqr)	32 Dowel pin
7 Screw, socket head, $\frac{7}{16}$ -14 x 1 in. (4 rqr)	33 Plug (5 rqr)
8 Screw, socket head, $\frac{7}{16}$ -18 x 1 in. (4 rqr)	34 Pump body
9 Control cap	35 Screw, socket head, $\frac{3}{8}$ -16 x $2\frac{3}{4}$ in. (6 rqr)
10 Stop body assembly	36 O-ring gasket
11 Clevis	37 Suction flange
12 Gasket (2 rqr)	38 Screw, socket head, $\frac{5}{8}$ -11 x 2 in. (4 rqr)
13 Hanger housing assembly	39 Pressure flange
14 Screw, socket head, $\frac{3}{8}$ -16 x $2\frac{1}{2}$ in. (2 rqr)	40 Screw, socket head, $\frac{5}{8}$ -11 x 2 in. (4 rqr)
15 Screw, socket head, $\frac{3}{8}$ -16 x $2\frac{1}{2}$ in. (4 rqr)	41 O-ring gasket (2 rqr)
16 Gasket (6 rqr)	42 Seal retainer
17 Creep plate	43 Screw, socket head, No. 10-24 x $\frac{1}{2}$ in. (6 rqr)
18 Retainer, piston and shoe assembly	44 Seal
19 Shoe retainer	45 O-ring packing
20 Piston and shoe assembly	46 Shaft assembly
21 Ball	47 Locknut
22 Spring socket	48 Washer
23 Spring	49 Ball bearing
24 Spring retainer	50 Spacers
25 Spring retainer pin	51 Shaft and sleeve assembly
26 Bearing and barrel assembly	52 Port block

Figure 37—Continued.

204. Cleaning, Inspection, and Repair

a. Clean all parts with an approved cleaning solvent and dry with a lint free cloth.

b. Inspect the control sleeves, pistons, tongue, stop, and ball support for nicks, burs, scores, and distortion. Remove minor abrasions. Replace a damaged or defective part.

c. inspect the control cap, control housing, stop body, and clevis for cracks, breaks, distortion, and damaged threads. Replace a defective part.

d. Inspect the springs for cracks, distortion, and for lack of tension. Replace a defective spring.

e. Inspect the bearings for rough rolling elements and races. Replace a defective bearing.

f. Inspect all attaching hardware for distortion and damaged threads and replace if defective.

205. Reassembly

a. Insert the piston (31, fig. 38) in the stop (32) and install the roll pin (30). Place the spring (33) on the stop and screw the stop into the stop body (34).

b. Install the O-ring packing (23) on the tongue (29) and slide the tongue into the stop body. Install the nut (27) on the stop body.

c. Position the 2 bearings (36 and 38) on the clevis (39) and install the 2 dowel pins (35 and 37).

d. Place new O-ring packing (23) and O-ring gasket (24) on the control housing (26). Position the control cap (21) on the housing and secure with the two screws (22). Insert the piston (25) in the housing.

e. Install a new preformed packing (20) and the retaining ring (18) on the control sleeve (19). Insert the control piston (17) in the control sleeve and install the sleeve with attached parts in the control cap.


f. Insert the ball (14), ball support (13), spring (12) and seal piston (11) in the adjustment housing (15) and install the housing and a new preformed packing (16) in the control cap.

g. Install a new preformed packing (10) and the lockwasher (9) in the adjustment housing.

h. Insert the spring retainer (8), spring (7), and the control piston (6) in the control cap.

i. Install a new O-ring packing (4) and retaining ring (3) on the control sleeve (5) and slide the sleeve into the control cap.

j. Install a new O-ring packing (2) and the stop spool (1) in the control cap.



- | | | |
|----------------------|---|-------------------|
| 1 Stop spool | 15 Adjustment housing | 27 Nut |
| 2 O-ring packing | 16 Preformed packing | 28 O-ring packing |
| 3 Retaining ring | 17 Control piston | 29 Tongue |
| 4 O-ring packing | 18 Retaining ring | 30 Roll pin |
| 5 Control sleeve | 19 Control sleeve | 31 Piston |
| 6 Control piston | 20 Preformed packing | 32 Stop |
| 7 Spring | 21 Control cap | 33 Spring |
| 8 Spring retainer | 22 Screw, socket head, No. 10-24
x 1/2 in. (2 rqr) | 34 Stop body |
| 9 Lockwasher | 23 O-ring packing | 35 Dowel pin |
| 10 Preformed packing | 24 O-ring gasket | 36 Ball bearing |
| 11 Seal piston | 25 Piston | 37 Dowel pin |
| 12 Spring | 26 Control housing | 38 Ball bearing |
| 13 Ball support | | 39 Clevis |
| 14 Ball | | |

Figure 38. Pressure compensator control, exploded view.

206. Installation

a. Secure the clevis (11, fig. 37) in place with the four screws (8).

b. Position a new gasket (12) and the stop body assembly (10) on the hanger housing assembly (13) and secure with the four screws (7).

c. Position a new gasket (5) and the end cap (3) on the hanger housing and secure with 20 screws (4).

d. Position a new gasket (12) and the control cap (9) on the hanger housing and secure with the four screws (6).

e. Install the two tube fittings (2) in the pressure flange (39) and control cap and connect the tube (1) to the fittings.

f. Install the compensator and volume hand controls (par. 156).

g. Install the pump (par. 157).

Section II. HYDRAULIC PUMP

207. Removal and Disassembly

a. Remove the pressure compensator control (par. 202).

b. Remove the 4 screws (15, fig. 37), 2 screws (14), and 6 gaskets (16) that secure the hanger housing assembly (13) and O-ring gasket (30) to the bearing (29) and remove housing and O-ring. Remove the creep plate (17) from the index plate (15, fig. 39).

c. Remove the screw (2) that secures the indicator link (1) to the indicator shaft (7) and remove the link from the shaft.

d. Remove the pin (4) that secures the indicator (3) to the shaft and remove the indicator.

e. Remove the three screws (6) that secure the indicator plate (5) to the hanger housing (26) and remove the plate.

f. Remove the indicator shaft (7) from the housing and remove the O-ring packing (8) from the shaft.

g. Remove the 8 screws (10) that secure the 2 end plates (9) and 2 gaskets (11) to the housing and remove the plates and gaskets.

h. Remove the two trunnion pins (12) from the housing releasing the hanger (23) and remove the hanger from the housing. Remove the two O-ring packings (13) from the trunnion pins.

i. Remove the two trunnion spacers (14) from the housing.

Caution: Exercise extreme care in handling the trunnion spacers to prevent scratching the bearing surfaces.

j. Match mark the index plate (15) and the hanger (23) to assure alignment during reas-

sembly. Remove the screw (16) that secures the index plate to the hanger and remove the index plate and two dowel pins (17) from the hanger.

k. Remove the bolt (18), two setscrews (19 and 21), and the indicator operating pin (20) from the hanger.

l. Press the two needle bearings (22) out of the hanger (23) if defective.

m. Remove the two plugs (24 and 25) from the hanger housing (26).

n. Remove the outer race of bearing (29, fig. 37) from the inner race and remove the O-ring gasket (30) from the pilot of the pump body (34).


o. Remove the retainer, piston and shoe assembly (18) from the cylinder barrel (27).

Note. Mark each piston to make certain it is installed in the same bore from which it was removed.

p. Remove the ball (21), spring socket (22), spring (23), spring retainer (24), and spring retainer pin (25) from the cylinder barrel.

q. Slide the cylinder barrel (27) with attached inner race of bearing (29) out of the pump body (34). Remove the seven screws (28) that secure the bearing inner race to the barrel and remove the bearing. The port plate (31) may stick to the cylinder barrel during its removal. Use caution to prevent port plate from dropping. Remove the port plate if it has remained in the pump body.

r. Remove the six screws (35) that secure the pump body (34) to the port block (52) and remove the body, O-ring gasket (36) and the dowel pin (32) from the port block. Remove five plugs (33) from the pump body.



- | | | | |
|----|--|----|--------------------------------------|
| 1 | Indicator link | 14 | Trunnion spacer (2 rqr) |
| 2 | Screw, socket head, No. 10-32 x 1/2 in. | 15 | Index plate |
| 3 | Indicator | 16 | Screw, socket head, 1/4-20 x 5/8 in. |
| 4 | Pin | 17 | Dowel pin |
| 5 | Indicator plate | 18 | Bolt |
| 6 | Screw, machine (3 rqr) | 19 | Setscrew |
| 7 | Indicator shaft | 20 | Indicator operating pin |
| 8 | O-ring packing | 21 | Setscrew, 1/4-20 x 5/8 in. |
| 9 | End plate (2 rqr) | 22 | Needle bearing |
| 10 | Screw, socket head, 1/4-20 x 1/2 in. (8 rqr) | 23 | Hanger |
| 11 | Gasket (2 rqr) | 24 | Plug |
| 12 | Trunnion pin (2 rqr) | 25 | Plug |
| 13 | O-ring packing (2 rqr) | 26 | Hanger housing |

Figure 39. Hanger housing assembly, exploded view.

s. Remove the six screws (43) that secure the seal retainer (42) to the port block (52) and remove the seal retainer. Remove the O-ring packing (45) from the seal retainer. Remove the seal (44) from the seal retainer only if defective.

t. Remove the shaft and sleeve assembly (51) with attached bearings from the port block. Bend the tabs of the washer (48) away from the lock nut (47) and remove the nut and washer.

u. Mark the position of the ball bearings (49) on the shaft and sleeve assembly and press the shaft out of the bearings and spacers (50).

Caution: Note the bearing surfaces contacting the spacers. These are preloaded bearings and must be reassembled exactly as removed.

v. Remove the 8 screws (38 and 40) that secure the suction flange (37) and the pressure flange (39) to the port block (52) and remove the flanges and 2 O-ring gaskets (41).

208. Cleaning, Inspection, and Repair

a. Clean all metal parts with an approved cleaning solvent and dry with a lint free cloth.

b. Rotate the bearings and inspect for rough rolling elements and races. Replace a defective or worn bearing.

c. Inspect the creep plate for pits, scores and scratches. Replace a defective creep plate.

d. Inspect the piston and shoe assembly, and the cylinder barrel for pits, scratches, and abrasion. If either item is found to be defective the barrel and bearing assembly must be replaced as a matched set.

e. Inspect the port plate for scratches and distortion. Remove scratches by lapping. Replace a port plate damaged beyond repair.

f. Inspect the shaft seal lip for cracks and scratches. Replace a damaged seal or one that has been leaking.

g. Inspect the splines of the shaft and sleeve assembly for cracked or chipped teeth. Replace a damaged shaft and sleeve assembly.

h. Inspect the index plate for nicks, burs, scratches and abrasion. Replace a defective index plate.

i. Inspect the port block for cracks, breaks, and damaged threads. Check the face which mates with the port plate for irregular surface. Reface by crown grinding, the center being 0.0002 to 0.0004 inch high. Replace a port block damaged beyond repair.

j. Inspect all other parts for cracks, breaks, distortion, and damaged threads and replace if defective.

209. Reassembly and Installation

a. Place 2 new O-ring gaskets (41, fig. 37) on the port block (52). Position the suction and pressure flanges (37 and 39) on the port block and secure with the 8 screws (38 and 40).

b. Press the 2 ball bearings (49) and 2 spacers (50) onto the shaft and sleeve assembly (51) and secure with the washer (48) and locknut (47).

c. Install the shaft and sleeve assembly in the port block.

d. Install the seal (44) in the seal retainer (42). Place a new O-ring packing (45) on the

seal retainer, insert the retainer in the port block (52) and secure with the six screws (43).

e. install plugs (33) in the pump body (34). Install the dowel pin (32) in the port block (52). Place a new O-ring gasket (36) and the pump body on the port block and secure with the six screws (35).

f. Apply a film of hydraulic oil to the port plate (31). Install the port plate in the pump body (34) over the splined end of the shaft and sleeve assembly. Turn the port plate in the direction of pump rotation until the last of the three holes in the back of the port plate engages the dowel pin (32). Make certain the port plate will move slightly and freely.

g. Position the inner race of bearing (29) on the cylinder barrel (27) and secure with the seven screws (28). Apply a film of hydraulic oil to the barrel and bearing and slide the barrel into the pump body.

h. Install the spring retainer pin (25), spring retainer (24), spring (23), spring socket (22), and ball (21) in the cylinder barrel.

i. Install the retainer, piston and shoe assembly (18) in the cylinder barrel (27). Make certain the pistons enter the same bore from which they were removed.

j. Place a new O-ring gasket (30) on the pilot of the pump body and install the outer race of the bearing (29) on the inner race.

k. Install the two plugs (24 and 25, fig. 39) in the hanger housing (26).

l. Press the two needle bearings. (22) into the hanger (23).

m. Install the indicator operating pin (20), two setscrews (19 and 21), and the bolt (18) in the hanger.

n. Install the two dowel pins (17) and the index plate (15) on the hanger (23) and secure with the screw (16). Make certain the index plate is installed in accordance with marks made during disassembly.

o. Install the two trunnion spacers (14) in the hanger housing (26).

p. Install two new O-ring packings (13) on the two trunnion pins (12). Position the hanger (23) with attached parts in the hanger housing and insert the two trunnion pins in the aligned holes of the spacers and needle bearings.

q. Place two new gaskets (11) and the two end plates (9) on the housing and secure with the eight screws (10).

r. Install a new O-ring packing (8) on the indicator shaft (7) and insert the shaft in the housing.

s. Position the indicator plate (5) on the hanger housing over the shaft and secure with the three screws (6).

t. Install the indicator (3) on the indicator shaft and secure with the pin (4).

u. Set the indicator on zero. Position the indicator link (1) on the indicator shaft with the slot of the link horizontal or pointing to the rear of the pump and secure with the screw (2).

v. Install the creep plate (17, fig. 37) on the index plate.

w. Place a new O-ring gasket (30) and the hanger housing assembly (13) on the bearing (29) and secure with the 6 gaskets (16), 2 screws (14), and 4 screws (15).

x. Install the compensator control (par. 205).

Section III. FRAME ASSEMBLY

210. General

In the event the welded steel frame of the running gear should become damaged beyond repair, it is the responsibility of depot maintenance to replace the damaged frame. This constitutes the removal of all major components of the test stand.

211. Removal

a. Remove the pump (par. 153).

b. Remove the engine (par. 108).

c. Remove the steering gear (par. 75).

d. Remove the arm assemblies and arm supports (par. 169).

212. Installation

a. Install the arm assemblies and arm supports (par. 169).

b. Install the steering gear (par. 75).

c. Install the engine (par. 108).

d. Install the pump (par. 157).

CHAPTER 11
SHIPMENT AND LIMITED STORAGE AND DEMOLITION
OF MATERIAL TO PREVENT ENEMY USE

Section I. SHIPMENT AND LIMITED STORAGE

213. Preparation of Equipment for Shipment

a. Remove the drain plug from the fuel tanks and drain the fuel into a suitable container.

b. Drain the carburetor and fuel lines into a container.

c. Disconnect the battery cables from the battery and wrap the clamps with tape. Drain the electrolyte from the battery.

d. Drain the hydraulic system by removing the drain plug from the bottom of the low pressure filter (par. 9).

e. Replace drain plug and refill the system with preservative hydraulic oil.

f. Drain the hydraulic pump (par. 153) and refill the pump with preservative hydraulic oil.

g. Drain the engine crankcase (par. 108) and refill with corrosion preventive compound.

h. Cap all inlet and outlet parts and fasten cabinet doors securely.

i. Place several bags of desiccant in the cabinet interior.

214. Limited Storage

a. Locate the test stand so there will be sufficient room on all sides to perform the inspection and maintenance necessary while it is in storage. Jack up the test stand to get the tires off the surface and place suitable blocks under the frame.

b. Perform a monthly inspection while the equipment is in storage and inspect for evidence of physical damage, such as rusting, accumulation of water, pilferage, or leakage.

Section II. DEMOLITION OF TEST STAND TO PREVENT ENEMY USE

215. General

When capture or abandonment of the unit to the enemy is imminent, the responsible unit commander must make the decision either to destroy the equipment or render it inoperative. Based on this decision, orders are issued which cover the desired extent of destruction. Whatever method of demolition is employed, it is essential to destroy the same vital parts of all air compressors and all corresponding repair parts.

216. Demolition to Render the Equipment Inoperative

a. Demolition by Misuse.

(1) Cut the fan belt.

(2) Drain the oil from the engine crankcase and pour sand in the oil filler opening.

(3) Start the engine and remove the governor control rod. Allow the engine to run at ungoverned speed until it fails.

(4) Pour sand into the hydraulic reservoir and let the sand be drawn through the hydraulic system.

b. Demolition by Mechanical Means. Use a sledge hammer, pickaxe, or other heavy tool and destroy the following:

(1) Manifold and Carburetor

(2) Cylinder block

(3) Battery

(4) Relief valves

(5) Control panel

(6) Low pressure filter




Figure 40. Placement of charges.

217. Demolition by Explosives or Weapons' Fire

a. Demolition By Explosives. Place the following charges, and detonate them simultaneously with detonating cord and a suitable detonator.

- (1) One 1/2 pound charge on each wheel.
- (2) Two 1/2 pound charges on the engine.
- (3) One 1/2 pound charge on the battery.
- (4) Two 1/2 pound charges on the hydraulic pump.
- (5) Two 1/2 pound charges on the reservoir.

b. Demolition By Weapons' Fire. Fire on the test stand with the heaviest suitable weapons available.

218. Other Demolition Methods

a. Demolition by Scattering and Concealment. Remove all easily accessible vital parts from the engine and from the pump. Scatter these parts through dense foliage or throw them in a lake, stream, or other body of water.

b. Demolition By Burning. Pack rags, clothing, or canvas around the engine, fuel tank, control panel, battery, and pump. Saturate this packing with gasoline, oil, or diesel fuel, and ignite.

c. Demolition By Submersion. Totally submerge the test stand in a body of water to provide water damage and concealment.

219. Training

All operators should receive thorough training in the destruction of the test stand (FM 5-25). Simulated destruction, using all of the methods listed above, should be included in the operator training program. It must be emphasized in training, that demolition operations are usually necessitated by critical situations when time available for carrying out destruction is limited. For this reason, it is necessary that operators be thoroughly familiar with all methods of destruction of equipment, and be able to carry out demolition instructions without reference to this or any other manual.

APPENDIX I

REFERENCES

1. Dictionaries of Terms and Abbreviations

- AR 320-50 Authorized Abbreviations and Brevity Codes.
AR 320-5 Dictionary of United States Army Terms.

2. Fire Protection

- TM 5-687 Repairs and Utilities; Fire Protection Equipment and Appliances; Inspections, Operations, and Preventive Maintenance.
TM 9-1799 Ordnance Maintenance: Fire Extinguishers.

3. Preventive Maintenance

- AR 750-5 Organization, Policies, and Responsibilities for Maintenance Operation.

4. Painting

- TM 9-213 Painting Instructions For Field Use.

5. Publication Indexes

- DA Pam 108-1 Index of Army Motion Pictures, Film Strips, Slides, Tapes, and Phonorecordings.
DA Pam 310-1 Index of Administrative Publications.
DA Pam 310-2 Index of Blank Forms.
DA Pam 310-3 Index of Training Publications.
DA Pam 310-4 Index of Technical Manuals, Technical Bulletins, Supply Manuals (types 4, 6, 7, 8, and 9), Supply Bulletins, Lubricated Orders, and Modification Work Orders.
DA Pam 310-5 Index of Graphic Training Aids and Devices.

6. Training Aids

- FM 5-25 Explosives and Demolition.
FM 21-5 Military Training.
FM 21-6 Techniques of Military Instruction.
FM 21-30 Military Symbols.

APPENDIX II

MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

1. General

This Maintenance Allocation Chart lists all maintenance and repair operations authorized for the various levels of maintenance.

2. Maintenance

Maintenance is any action taken to keep materiel in a serviceable condition or to restore it to serviceability when it is unserviceable. Maintenance of materiel includes the following:

a. Service. To clean, to preserve, and to replenish fuel and lubricants.

b. Adjust. To regulate periodically to prevent malfunction.

c. Inspect. To verify serviceability and to detect incipient mechanical failure by scrutiny.

d. Test. To verify serviceability and to detect incipient mechanical failure by use of special equipment such as gages, meters, and so on.

e. Replace. To substitute serviceable assemblies, subassemblies, and parts for unserviceable components.

f. Repair. To restore to a serviceable condition by replacing unserviceable parts or by any other action required utilizing tools, equipment, and skills available, to include welding, grinding, riveting, straightening, and adjusting.

g. Overhaul. To restore an item to a completely serviceable condition by inspecting, disassembling its assemblies and subassemblies as necessary, replacing parts, and performing necessary boring, grinding or machining operations, followed by reassembly and final inspection.

3. Explanation of Columns

a. Components and Related Operation. This column contains the functional index grouping

heading, subgroup headings, and a brief description of the part starting with the noun name. It also designates the operation to be performed such as service, adjust, inspect, test, replace, repair, and overhaul.

b. Level of Maintenance.

(1) *Operator Maintenance.* Operator maintenance performed by the user or operator of the equipment, such as servicing, cleaning, lubricating, and limited adjustments. It also includes removal and replacement of items to accomplish servicing and lubrication.

(2) *Organizational Maintenance.* **organizational** maintenance is that maintenance performed by trained personnel provided for that purpose in the using organization, such as replacement of all items in the organizational maintenance column, limited parts fabrication from bulk material, adjustments, and repair of assemblies, components, and end items that can be accomplished without extensive disassembly.

(3) *Direct Support Maintenance.* Direct support maintenance is that maintenance performed by specially trained units in direct support of the using organization, such as replacement of all items in the organizational and direct support maintenance columns; repair of assemblies, components, and end items; and fabrication of parts from bulk material.

(4) *General Support Maintenance.* General support maintenance is that maintenance performed by units organized as semifixed or permanent shops to serve lower levels of maintenance

within a geographical area, such as replacement of items in the organizational, direct support, and general support columns; repair of end items; overhaul of assemblies and components; and fabrication of general use common hardware and parts.

- (5) *Depot Maintenance.* Depot maintenance is that maintenance authorized to overhaul assemblies, components, end items, and replacement of all parts in the organizational, direct support, general support, and depot maintenance columns.

c. Symbol X. The symbol X indicates the lowest level of maintenance responsible for performing that particular maintenance operation, but does not necessarily indicate repair parts will be stocked at that level.

d. Remarks. The remarks column is used to explain why maintenance, that would normally be done at a lower level of maintenance, is moved to a higher level of maintenance because of some peculiarity in the construction of the end item.

Section II. MAINTENANCE ALLOCATION CHART

Group No.	Component and related operations	O/C	O	DS	GS	D	Tools required	Remarks
1.0	TEST STAND, AIRCRAFT HYDRAULIC							
	Service		X					
	Adjust		X					
	Align			X				
	Calibrate				X			
	Inspect		X		X			
	Test				X			
	Replace			X				
	Repair				X			
	Overhaul					X		
2.0	ELECTRICAL SYSTEM							
2.1	Battery:							
	Service		X					
	Replace			X				
	Repair			X				
2.2	Ignition Harness:							
	Inspect		X					
	Replace			X				
	Repair				X			
2.3	Generator:							
	Service		X					
	Inspect		X					
	Replace			X				
	Repair				X			
	Overhaul					X		
2.4	Voltage Regulator:							
	Adjust			X				
	Replace			X				
	Repair				X			
	Inspect		X					
2.5	Starter:							
	Service		X					
	Inspect		X					
	Replace			X				
	Repair				X			
	Overhaul					X		

Group No.	Component and related operations	O/C	O	DS	GS	D	Tools required	Remarks
2.6	Thermo Switch:							
	Inspect -----		X					
	Replace -----			X				
2.7	Pilot Lights:							
	Inspect -----		X					
	Replace -----			X				
2.8	Fuses:							
	Inspect -----		X					
	Replace -----			X				
3.0	HYDRAULIC SYSTEM							
3.1	Lines, Tubing, Fittings:							
	Inspect -----		X					
	Replace -----			X				
3.2	Fluid Reservoir:							
	Service -----		X					
	Inspect -----		X					
	Replace -----			X				
	Repair -----			X				
3.3	Pump:							
	Service -----		X					
	Inspect -----		X					
	Replace -----				X			
	Repair -----				X			
	Calibrate -----				X			
	Overhaul -----					X		
3.4	Controls:							
	Inspect -----		X					
	Replace -----			X				
3.5	Filter Elements:							
	Inspect -----		X					
	Replace -----		X					
3.6	Coupling Half:							
	Inspect -----		X					
	Replace -----		X					
3.7	Hose Assemblies:							
	Inspect -----		X					
	Replace -----		X					
3.8	Pressure Gage:							
	Inspect -----		X					
	Replace -----		X					
	Calibrate -----				X			
3.9	O-Rings:							
	Replace -----			X				
3.10	Valves:							
	Replace -----			X				
	Repair -----				X			
	Overhaul -----					X		
3.11	Dampener:							
	Replace -----				X			
3.12	Compensator Control:							
	Replace -----				X			
	Repair -----				X			
3.13	Drain Assembly, Petcock:							
	Replace -----		X					
3.14	Neck, Tank Filler:							
	Replace -----			X				
3.15	Send Unit:							
	Replace -----			X				

Group No.	Component and related operations	O/C	O	DS	GS	D	Tools required	Remarks
3.16	Filter Housing:							
	Replace			X				
	Repair				X			
3.17	Control Panel and Accessories:							
	Replace				X			
	Repair				X			
4.0	ENGINE							
4.1	Manifold:							
	Replace				X			
4.2	Instruments:							
	Replace			X				
	Calibrate				X			
4.3	Spark Plugs:							
	Replace			X				
4.4	Magneto:							
	Replace			X				
	Repair				X			
	Overhaul					X		
4.5	Oil Filter:							
	Replace			X				
4.6	Muffler:							
	Replace			X				
	Repair			X				
4.7	Air Shroud:							
	Replace			X				
	Repair			X				
4.8	Governor:							
	Replace			X				
	Repair				X			
4.9	Fuel Pump:							
	Replace			X				
	Repair			X				
4.10	Gaskets:							
	Replace			X				
4.11	Carburetor:							
	Replace			X				
	Repair			X				
	Overhaul				X			
4.12	Fuel Strainer:							
	Replace			X				
4.13	Oil Filter:							
	Replace			X				
4.14	Manifold Assembly:							
	Replace				X			
	Repair				X			
4.15	Cylinder Block and Components:							
	Replace				X			
	Repair					X		
	Overhaul					X		
4.16	Camshaft and Components:							
	Replace					X		
	Repair					X		
	Overhaul					X		
5.0	ISCELLANEOUS							
5.1	Tires:							
	Replace		X					

Group No.	Component and related operations	O/C	O	DS	GS	D	Tools required	Remarks
5.2	Fuel Tank: Replace ----- Repair -----				X X			
5.3	Thermometer: Replace -----			X				
5.4	Lubrication Fittings: Service ----- Replace -----		X	X				
5.5	Brake Assembly: Inspect ----- Replace ----- Repair -----		X	X	X			
5.6	Tie Rod Assembly: Inspect ----- Replace ----- Repair -----			X X X				
5.7	Drawbar Assembly: Replace ----- Repair -----		X	X				
5.8	Steering Arm Assembly: Replace ----- Repair -----		X	X				
5.9	Brake Lever Assembly: Replace ----- Repair -----		X	X				
5.10	Latch, Steering Arm: Replace ----- Repair -----		X	X				
5.11	Wheel and Hub Assembly: Replace ----- Repair -----			X X				
5.12	Inner Tube: Replace -----			X				
5.13	Brake Drum: Replace ----- Repair -----			X X				
5.14	Springs: Replace ----- Repair -----			X	X			
5.15	Axles Assemblies: Replace ----- Repair -----				X X			
5.16	Kingpin, Steering Knuckle: Replace -----				X			
5.17	Bearing Sleeves: Inspect ----- Replace -----			X	X			
5.18	Bumper, Rubber: Replace -----			X				
5.19	Support Assemblies: Replace ----- Repair -----			X X				
5.20	Cable Assembly, Brake: Inspect ----- Replace ----- Repair -----		X	X X				

Group No.	Component and related operations	O/C	O	DS	GS	D	required Tools	Remarks
5.21	Frame Assembly: Replace					X		
	Repair				X			
5.22	Bearings: Service			X				
	Replace			X				
5.23	Bearing Race: Replace			X				
5.24	Brackets: Replace			X				
	Repair			X				
5.25	Spacers: Replace			X				

APPENDIX III

REPAIR PARTS LIST

Section I. INTRODUCTION TO GROUP ASSEMBLY PARTS LIST

1. General

This portion of the manual lists the repair parts and special tools authorized for operator, organizational, direct support, general support, and depot maintenance of Test Stand, Hydraulic System, Aircraft, Type D-5A, Model AHT-5A-1, Sun Electric Corp. This is the authority to requisition for operator and organizational maintenance, and the authority to requisition and issue for direct support, general support, and depot maintenance. It serves as a guide to determine the quantity of items authorized for initial stockage in accordance with AR 700-70 and AR 711-16. It supplements tables of equipment, allowances, and other applicable authorization documents.

2. Arrangement

All repair parts are listed in disassembly order and indented when required to indicate relationship to the next higher assembly.

3. Tools

No special tools are required.

4. Explanation of Columns

a. AMC Materiel Code. (Formerly Technical Service Code). Materiel basic number. Items which are the logistic responsibility of a commodity command, other than U. S. Army Aviation Materiel Command (USAAVCOM), are indicated by the basic number assigned to the commodity command.

The basic numbers are:

- 3—Chemical Materiel
- 5—Engineer Materiel
- 8—Medical Materiel
- 9—Ordnance Materiel
- 10—Quartermaster Materiel
- 11—Signal Materiel

b. Source Codes. Source codes are shown in this column as assigned to items by USAAVCOM. The code symbols indicate the selection status and source of supply for each repair part as defined hereafter.

- (1) Code P applies to high mortality repair parts which are stocked in or supplied from the commodity command depot system, and authorized for use at indicated maintenance echelons.
- (2) Code P1 applies to repair parts which are low mortality parts, stocked in or supplied from commodity command depots, and authorized for installation at indicated maintenance echelons.

Note. General use, common hardware and bulk material listed herein are not assigned source, maintenance, or recoverability codes.

c. Maintenance Level Code. The code symbol used in the maintenance level column indicates the lowest maintenance level authorized to install the repair parts. Capabilities of higher maintenance levels are considered equal or better.

- (1) Code O—Operator and Organizational Maintenance
- (2) Code F—Direct Support Maintenance
- (3) Code H—General Support Maintenance
- (4) Code D—Depot Maintenance

d. Recoverability Code. Recoverability codes reflect the recoverability or repairability characteristics of repair parts upon removal from equipment at time of maintenance, repair, or overhaul.

- (1) Code R applies to repair parts and assemblies which are economically repairable at direct and general support

maintenance activities and are normally furnished by supply on an exchange basis.

- (2) Code U applies to repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, high dollar value, reusable casings or castings, etc.
- (3) Repair parts and assemblies not assigned a recoverability code shall be considered "throwaway" items.

e. Federal Stock Number. The Federal Stock Number consists of the applicable 4-digit FSC Code Number plus the 7-digit Federal Item Identification Number, and is utilized for requisitioning, storage and accountability purposes.

f. Description. This column furnishes the item name, a brief description when necessary, and authorized abbreviations or dimensions when required to provide further identification.

- (1) *Part numbers.* Three basically different kinds of part numbers are found within this column.

- (a) Identification of manufacturer, e.g., 4776-4.
- (b) Government standard or Military part numbers which begin with the letters AN, AF, MS, NAF, NAS, etc.
- (c) Miscellaneous vendor or commercial part numbers.

- (2) *Manufacturer's code number.* The manufacturer's code number is a 5-digit Federal Supply Code identifying a particular manufacturer.

g. Unit of Issue. This column lists the standard or minimum basic quantity in which the item is issued (each, pound, set, etc.).

h. Quantity Per Assembly. Quantities in this column are those required for one assembly only. When similar assemblies are broken down together, the quantities are those required for one assembly only. When attaching parts are shown as attaching two or more items, the quantities of the attaching parts are those necessary to attach only one of the items.

i. Allowance Factors. An asterisk (*), code contained within an allowance factor subcolumn

indicates that the item is authorized for use at that maintenance level, but is not authorized to be stocked. When such an item is required, it must be requisitioned for immediate use only. An AR code within an allowance factor subcolumn indicates that the item is authorized for use at that level, but is to be requisitioned as required and a minimum quantity to be stocked. This code applies only to common hardware and bulk material.

j. Illustrations. This column lists the figure number of the items illustrated and when applicable, the item number. When no item number is reflected for an item, it indicates the item is included in the referenced figure, but is not visible in the presented view.

5. Federal Supply Code for Manufacturers

<i>Code</i>	<i>Manufacturer and location</i>
00624 -----	Aeroquip Corp., Aircraft Division, Jackson Plant, Jackson, Mich.
00724 -----	Air Associates, Inc., Electronic Division, Orange, N. J.
01930 -----	Amerock Corp., Rockford, Ill.
04198 -----	Ashcroft Gauge Co., Bridgeport, Conn.
06499 -----	Volta Battery Corp., Chicago, Ill.
10100 -----	Flow Products, Inc., Chicago, Ill.
11583 -----	Champion Spark Plug Co., Toledo, Ohio
11862 -----	Chevrolet Motor Division of General Motors Corp., Detroit, Mich.
15605 -----	Cutler Hammer, Inc., Milwaukee, Wis.
16764 -----	Delco Remy Division of General Motors Corp., Anderson, Ind.
16954 -----	Denison Engineering Co., Columbus, Ohio
18265 -----	Donaldson Co., Inc., St. Paul, Minn.
19728 -----	Electric Auto-Lite Co., Toledo, Ohio
21387 -----	Fairbanks, E. and T., and Co., Chicago, Ill.
30327 -----	Imperial-Eastman Corp., Chicago, Ill.
38508 -----	Marsh Instrument Co., Division of Colorado Oil and Gas Corp., Skokie, Ill.
41615 -----	Morse Chain Co., Detroit, Mich.
42689 -----	National Lock Co., Rockford, Ill.
43766 -----	Nice Bail Bearing Co., Nicetown, Philadelphia, Pa.
51240 -----	American-Standard Controls Division of American Radiator and Standard Sanitary Corp., Rochester, N. Y.
56289 -----	Sprague Electric Co., North Adams, Mass.
60038 -----	Timken Roller Bearing Co., Canton, Ohio
60380 -----	Torrington Co., The, Torrington, Conn.
66289 -----	Wisconsin Motor Corp., Milwaukee, Wis.
66295 -----	Witteck Mfg. Co., Chicago, Ill.
70417 -----	Amplex Division of Chrysler Corp., Detroit, Mich.
70485 -----	Atlantic India Rubber Works, Inc., Chicago, Ill.
70955 -----	Blackstone Mfg. Co., Chicago, Ill.
73370 -----	Fram Corp., Providence, R. I.

<i>code</i>	<i>Manufacturer and location</i>
73809 -----	Geneva Metal Wheel Co., Geneva, Ohio
74400 -----	Hobbs, John W., Corp., Springfield, Ill.
75915 -----	Littelfuse, Inc., Chicago, Ill.
77060 -----	Packard Electric Division of General Motors Corp., Warren, Ohio
77344 -----	Potter Co., Chicago, Ill.
78439 -----	Porter, H. K., Co. of Delaware, Thermoid Division, Thermoid Works, Trenton, N. J.
78480 -----	Tillotson Mfg. Co., The, Toledo, Ohio
78500 -----	Rockwell-Standard Corp., Transmission and Axle Division, Detroit, Mich.
78553 -----	Tinnerman Products, Inc., Cleveland, Ohio
79470 -----	Featherhead Co., The, Cleveland, Ohio

<i>Code</i>	<i>Manufacturer and location</i>
79934 -----	Tire and Rim Association, Inc., The, Akron, Ohio
80089 -----	R B M Mfg. Co., Logansport, Ind.
82386 -----	Sun Mfg. Co., Chicago, Ill.
85925 -----	Electro Mechanical Instrument Co., Perkasie, Pa.
86768 -----	Republic Mfg. Co., Cleveland, Ohio
87541 -----	Stanley Hardware Co., Philadelphia, Pa.
88234 -----	United Electric Controls Co., Watertown, Mass.
90005 -----	Bendix Filter Division of Bendix Corp., Royal Oak, Mich.
96152 -----	Marvel Schebler Products Division of Borg-Warner Corp., Decatur, Ill.
98441 -----	Stratoflex, Inc., Ft. Worth, Tex.

(1) SOURCE MAINT. & RECOVERABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF MEASURE	(5) EXPENDABILITY	(6) QTY PER UNIT	(7) ALLOWANCES				ILLUSTRATIONS		
MAINT CODE	SOURCE	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHOLON	FIG NO. (A)	ITEM NO. (B)	
			2ND ECHOLON	3RD ECHOLON	4TH ECHOLON									
				SECTION II GROUP ASSEMBLY PARTS LIST CONTROLS AND INSTRUMENTS										
P	F	R	4920-710-6669	TEST STAND: hydraulic systems, gasoline engine driven (P/N ART-5A-1)	EA		1	*	*	*		1		
				PANEL ASSEMBLY: control (P/N A426-7-3200)	EA		1	*	*	*	*	9		
				PANEL (P/N A426-4-3211A)	EA		1	*	*	*	*	9	1	
P	O		6680-991-8579	GAGE: level (P/N 4060)	EA		1	*	*	*	*	9	2	
P	O		6685-585-4511	GAGE: pressure (P/N 1377)	EA		1	*	*	*	*	9	3	
P	O		6685-783-6616	THERMOMETER: indicating, model DFFM (P/N A280-3016)	EA		1	*	*	*	*	9	4	
				SCREW: machine (P/N AN520-10-8)	EA		3	AR	AR	AR	AR	9	5	
P	O		6620-783-6614	GAGE: compound, model FMS (P/N A280-3014)	EA		1	*	*	*	*	9	6	
				SCREW: machine (P/N AN505-10-8)	EA		2	AR	AR	AR	AR	9	7	
P	F	R	4920-733-6857	VALVE: 2-way (P/N A361-2-103)	EA		1		*	*	*	9	8	
P	O	R	6630-515-5910	TACHOMETER (P/N 2-214-10)	EA		1	*	*	*	*	9	9	
P	O	R	6645-557-8035	METER: time totalizing (P/N ML-972)	EA		1	*	*	*	*	9	10	
P	O	R	6620-377-6805	GAGE: oil pressure (P/N 2550)	EA		1	*	*	*	*	9	11	
				VALVE ASSEMBLY: shut-off (P/N A280-2-3206)	EA		1	*	*	*	*	9	12	
P	O	R	6625-783-6615	AMMETER (P/N NF2C)	EA		1	*	*	*	*	9	13	

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS		
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP	2ND ECHELON	3RD ECHELON	4TH ECHELON	QUANTITY RE-ADVANCED FOR RESULTS OF 100 EQUIPMENTS 5TH ECHELON	FIG NO.	ITEM NO.
				SECTION II GROUP ASSEMBLY PARTS LIST - (CONTINUED) CONTROLS AND INSTRUMENTS (CONTINUED)											
5	F1	F	R	6680-532-2915	INDICATOR: flow (P/N 2-1183)	EA		1		*	*	*		9	15
					VALVE: outlet (P/N 8042B-108B)	EA		1	*	*	*	*		9	16
	F1	F	R	4920-793-0645	VALVE: high pressure relief (P/N A361-100)	EA		1		*	*	*		9	17
					WASHER: lock (P/N AN935-416)	EA		8	AR	AR	AR	AR		9	18
					SCREW: socket head cap (P/N 686-80)	EA		8	*	*	*	*		9	19
					VALVE: flow control (P/N 2-1158-8)	EA		2	*	*	*	*		9	20
	P1	F		4920-713-4705	DAMPENER: pulsation (P/N A361-2-108)	EA		1		*	*	*		9	22
					VALVE ASSEMBLY: needle (P/N 4009-4A)	EA		1	*	*	*	*		9	23
					CAP ASSEMBLY: seal (P/N AN929-4S)	EA		1	AR	AR	AR	AR		9	24
					COMPENSATOR CONTROL ASSEMBLY (P/N 2-1253)	EA		1	*	*	*	*		9	25
					CAP ASSEMBLY: seal (P/N AN924-4S)	EA		1	AR	AR	AR	AR		9	26
					VALVE ASSEMBLY: needle (P/N 4009-4A)	EA		1	*	*	*	*		9	27
11	P1	O	R	6685-704-0845	GAGE: temp (P/N A300-5079)	EA		1	*	*	*	*		9	28
					CONTROL ASSEMBLY: vol (P/N A280-2-3071-1)	EA		1	*	*	*	*		9	29
					SCREW: machine (P/N AN515-416-12)	EA		4	AR	AR	AR	AR		9	30

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC PER UNIT	(7) ALLOWANCES				ILLUSTRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
									2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ENGINE CONTROL PANEL														
11	P1	O		5930-655-1582	SWITCH: toggle (P/N AN3027-3)	EA		1	AR	AR	AR	AR	10	1
	P1	O	U	5930-132-8283	SWITCH: push (P/N 1996041)	EA		1	*	*	*	*	10	2
					HOLDER: fuse (P/N 342001)	EA		1	*	*	*	*	10	3
	P	O		5920-011-7142	FUSE: 3 AG (P/N 311010)	EA		1	*	*	*	*	10	3
					CAP: filler (P/N 10-60)	EA		1	*	*	*	*	11	1
					CAP: intake (P/N 2X-1674-1)	EA		1	*	*	*	*	11	10
9	P1	O		2940-799-7687	AIR CLEANER (P/N A-552)	EA		1	*	*	*	*	11	14
					FILTER: oil (P/N F21-P)	EA		1	*	*	*	*	11	24
					BOLT: machine (P/N AN65-4-6)	EA		4	AR	AR	AR	AR	11	25
					COVER (P/N 11559)	EA		1	*	*	*	*	11	26
					SCREW (P/N 11580)	EA		1	*	*	*	*	11	27
					SABRE: oil (P/N RJ-153A-S1)	EA		1	*	*	*	*	11	28
					HYDRAULIC SYSTEM INSTALLATION (P/N A280-4-4000)	EA		1	*	*	*	*	12	
	P1	F	R	4320-787-2586	PUMP: axial piston, variable vol, model PA072564X2010 (P/N A280-4-3001)	EA		1		*	*	*	12	1

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS					
SOURCE MAINT. & RECOVER- ABILITY CODE									DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVERING ABILITY										2ND ECHELON	3RD ECHELON	4TH ECHELON			
				4820-783-6670	SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ENGINE CONTROL PANEL (CONTINUED)													
					CAP: protective (P/N 155-S7-12D)	EA		1	*	*	*	*		12	18			
					TUBING: flow control valve to 1/2 in. outlet (P/N A280-2-3332A)	EA		1	*	*	*	*		12	19			
					CAP: protective (P/N 155-S7-8D)	EA		1	*	*	*	*		12	20			
					TUBING: 4-way valve to reservoir tee (P/N A280-2-3348A)	EA		1	*	*	*	*		12	21			
					TUBING: relief valve to reservoir tee (P/N A426-2-3262A)	EA		1	*	*	*	*		12	22			
5	P	O			VALVE: relief (P/N A280-3005)	EA		1	*	*	*	*		12	23			
					TEE (P/N A280-3219)	EA		1	*	*	*	*		12	24			
					ELBOW (P/N AN833-16)	EA		1	AR	AR	AR	AR		12	25			
					TUBING: reservoir shut-off valve to low pressure manifold (P/N A426-2-3261A)	EA		1	*	*	*	*		12	26			
					ELBOW (P/N AN833-4)	EA		1	AR	AR	AR	AR		12	27			
					TUBING: filter selector valve to pump inlet (P/N A426-2-3263A)	EA		1	*	*	*	*		12	28			
					ELBOW (P/N AN833-12)	EA		3	AR	AR	AR	AR		12	29			
					TUBING: 4-way valve to 1/2 in. outlet (P/N A280-2-3316A)	EA		1	*	*	*	*		12	30			
				TUBING: 4-way valve to 3/4 in. outlet (P/N A280-2-3318A)	EA		1	*	*	*	*		12	31				
				TUBING: high pressure relief valve to gage snubber valve (P/N A280-2-3306A)	EA		1	*	*	*	*		12	32				

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
MAT CODE	SOURCE	MAINT LEVEL RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
								2ND ECHELON	3RD ECHELON	4TH ECHELON			
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ENGINE CONTROL PANEL (CONTINUED)									
			4720-990-9014	TEE (P/N AN804-4)	EA		1	AR	AR	AR	AR	12	33
				TEE (P/N AN834-4)	EA		1	AR	AR	AR	AR	12	34
				TUBING: damper valve to tee in snubber valve (P/N A280-2-3320A)	EA		1	*	*	*	*	12	35
				TUBING: gage, snubber valve to fluid gage tap (P/N A280-2-3304A)	EA		1	*	*	*	*	12	36
P1	O			HOSE ASSEMBLY: high pressure gage to tee in gage dampener (P/N A280-2-3300)	EA		1	*	*	*	*	12	37
				TUBING: relief valve to by-pass valve (P/N A280-2-3308A)	EA		1	*	*	*	*	12	38
				TEE (P/N AN804-4)	EA		1	AR	AR	AR	AR	12	39
				TUBING: selector valve to by-pass valve (P/N A280-2-3312A)	EA		1	*	*	*	*	12	40
				TEE (P/N AN834-4)	EA		1	AR	AR	AR	AR	12	41
				TUBING: selector valve to filter gage (P/N A280-2-3310A)	EA		1	*	*	*	*	12	42
			ELBOW (P/N AN833-4)	EA		2	AR	AR	AR	AR	12	43	
P1	O		4720-990-9011	HOSE ASSEMBLY: selector valve to filter gage (P/N A280-2-3302)	EA		1	*	*	*	*	12	44
				TUBING: tee in by-pass valve to tee in reservoir shut-off valve (P/N A280-2-3314A)	EA		1	*	*	*	*	12	45
				TUBING: reservoir to reservoir shut-off valve (P/N A280-2-3328A)	EA		1	*	*	*	*	12	46
				FILTER AND MANIFOLD ASSEMBLY (P/N A280-4-3216)	EA		1	*	*	*	*	12	47

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
MAT CODE	SOURCE	MAINT LEVEL RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
								2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) FILTER AND MANIFOLD ASSEMBLY									
				LOCKNUT (P/N AN924-4)	EA		1	AR	AR	AR	AR	13	1
				ELBOW (P/N AN833-4)	EA		1	AR	AR	AR	AR	13	2
				PACKING: preformed (P/N AN6290-4)	EA		1	AR	AR	AR	AR	13	3
				UNION (P/N AN815-16)	EA		1	AR	AR	AR	AR	13	4
				PACKING: preformed (P/N AN6290-16)	EA		1	AR	AR	AR	AR	13	5
				BOLT: machine (P/N 65-5-10)	EA		6	*	*	*	*	13	6
9	P1	F	5330-197-9611	PACKING: preformed (P/N AN6227-69)	EA		1		AR	AR	AR	13	7
				NUT: wing (P/N AN350-1032)	EA		1	AR	AR	AR	AR	13	8
				COVER: element (P/N 4235)	EA		1	*	*	*	*	13	9
9	P	D	5330-285-9705	GASKET (P/N GH15190-16-2)	EA		1				*	13	10
	P1	F	1650-242-9425	FILTER ELEMENT (P/N AN6236-3)	EA		1		AR	AR	AR	13	11
				PLATE ASSEMBLY (P/N 4234A)	EA		1	*	*	*	*	13	12
				BOLT: machine (P/N 65-4-12)	EA		2	*	*	*	*	13	13
				WASHER: lock (P/N AN935-416)	EA		2	AR	AR	AR	AR	13	14
				SPACER (P/N 401-160)	EA		2	*	*	*	*	13	15

(1) SOURCE MAINT. & RECOVER- ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- TRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
									2ND ECHELON	3RD ECHELON	4TH ECHELON			
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) FILTER AND MANIFOLD ASSEMBLY (CONTINUED)									
					COVER: top (P/N 7-193-1)	EA		1	*	*	*	*	13	16
					LOCKNUT (P/N AN924-16)	EA		1	AR	AR	AR	AR	13	17
					ELBOW (P/N AN833-16)	EA		1	AR	AR	AR	AR	13	18
					PACKING: preformed (P/N AN6290-16)	EA		1	AR	AR	AR	AR	13	19
					MANIFOLD (P/N A280-4-3068)	EA		1	*	*	*	*	13	20
					BOLT: machine (P/N 65-5-7)	EA		10	*	*	*	*	13	21
					WASHER: lock (P/N AN935-516L)	EA		10	AR	AR	AR	AR	13	22
	PI	F		5930-607-6280	THERMOSWITCH (P/N 4738-2) (Modified from G-R441)	EA		1		*	*	*	13	23
9	PI	F		5330-285-9842	PACKING: preformed (P/N AN6290-10)	EA		1		AR	AR	AR	13	24
	PI	F		5330-815-1712	PACKING: preformed (P/N AN6230-14)	EA		1		AR	AR	AR	13	25
					COVER: bottom (P/N 4-490-1)	EA		1	*	*	*	*	13	26
					BOLT: machine (P/N AN65-5-10)	EA		6	AR	AR	AR	AR	13	27
					PLUG: machine (P/N AN814-3)	EA		1	AR	AR	AR	AR	13	28
9	PI	F		5330-835-7485	PACKING: preformed (P/N AN6290-3)	EA		1		AR	AR	AR	13	29
	PI	F		5330-197-9611	PACKING: preformed (P/N AN6227-69)	EA		1		AR	AR	AR	13	30

(1) SOURCE MAINT. & RECOVERABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS		
MAT CODE	SOURCE MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO.	ITEM NO.	
								2ND ECHELON	3RD ECHELON	4TH ECHELON		(A)	(B)	
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) RUNNING GEAR AND BRAKE ASSEMBLY										
				HOUSING (P/N A280-7-3211)	EA		1	*	*	*	*	13	31	
				RUNNING GEAR AND BRAKE ASSEMBLY (P/N 10-103)	EA		1	*	*	*	*	14		
				PIN: cotter (P/N AN380-2-3)	EA		4	AR	AR	AR	AR	14	1	
				NUT: castellated (P/O tie rod end, P/N 3692952)	EA		4	*	*	*	*	14	2	
				FITTING: lubrication (P/N MS15002-2)	EA		4	AR	AR	AR	AR	14	3	
P1	F		2530-495-4341	TIE ROD END (P/N 3692951)	EA		2		*	*	*	14	4	
P1	F		4920-589-3517	TIE ROD END (P/N 4005-1) (Modified from P/N 3692952)	EA		2		*	*	*	14	5	
				NUT: hex (P/N AN335-5)	EA		4	AR	AR	AR	AR	14	6	
				WASHER: lock (P/N AN935-516)	EA		4	AR	AR	AR	AR	14	7	
				BOLT: machine (P/N AN65-5-10)	EA		4	AR	AR	AR	AR	14	8	
				CLAMP: loop (P/N 599234)	EA		4	*	*	*	*	14	9	
P1	F		2530-859-5767	TIE ROD (P/N 4480-4)	EA		2		*	*	*	14	10	
				DRAWBAR ASSEMBLY (P/N 5780)	EA		1	*	*	*	*	14	11	
				PIN: grooved, headed (P/N 5781)	EA		1	*	*	*	*	14	12	
				RING: retaining (P/N 619-19)	EA		1	*	*	*	*	14	13	

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS					
SOURCE MAINT. & RECOVER- ABILITY CODE			FEDERAL STOCK NUMBER						DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL											RECOVER- ABILITY	2ND ECHELON	3RD ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) RUNNING GEAR AND BRAKE ASSEMBLY (CONTINUED)																		
					ARM ASSEMBLY: steering (P/N 4-690)	EA		1	*	*	*	*	14	14				
					PIN: cotter (P/N AN380-4-6)	EA		1	AR	AR	AR	AR	14	15				
					NUT: castellated (P/N AN330-10)	EA		1	AR	AR	AR	AR	14	16				
					WASHER: thrust (P/N TRC-1220)	EA		2	*	*	*	*	14	17				
					BOLT: shear (P/N 5807)	EA		1	*	*	*	*	14	18				
					LATCH (P/N 5803)	EA		1	*	*	*	*	14	19				
					NUT: self-locking (P/N AN365-6-16)	EA		1	AR	AR	AR	AR	14	20				
					BOLT: machine (P/N AN65-6-10)	EA		1	AR	AR	AR	AR	14	21				
					GROMMET: brake cable (P/N AN931-9-13)	EA		2	AR	AR	AR	AR	14	24				
					BRAKE LEVER ASSEMBLY	EA		1	*	*	*	*	14	25				
					BRACKET: stop, rh (P/N 5693)	EA		2	*	*	*	*	14	26				
					BRACKET: stop, lh (P/N 5693-1)	EA		2	*	*	*	*	14	27				
					BOLT: machine (P/N AN65-4-6)	EA		4	AR	AR	AR	AR	14	28				
					WASHER: lock (P/N AN935-416)	EA		4	AR	AR	AR	AR	14	29				
					NUT: hex (P/N AN325-8)	EA		20	AR	AR	AR	AR	14	30				

(1)			(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUSTRATIONS						
SOURCE MAINT. & RECOVERABILITY CODE								FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL											RECOVERABILITY	2ND ECHELON	3RD ECHELON			
				SECTION II <u>GROUP ASSEMBLY PARTS LIST (CONTINUED)</u> <u>RUNNING GEAR AND BRAKE ASSEMBLY (CONTINUED)</u>														
					WASHER: lock (P/N AN935-816)	EA		20	AR	AR	AR	AR		14	31			
					NUT: hex (P/N AN325-6)	EA		32	AR	AR	AR	AR		14	32			
					WASHER: lock (P/N AN935-616)	EA		32	AR	AR	AR	AR		14	33			
					BOLT: machine (P/N AN60-6-6)	EA		32	AR	AR	AR	AR		14	34			
					WHEEL HALF: w/hole for valve stem	EA		4	*	*	*	*		14	35			
					WHEEL HALF: w/o hole for valve stem	EA		4	*	*	*	*		14	36			
	P1	O	U	2610-050-9840	TIRE: pneumatic (P/N MS35389-6)	EA		4	AR	AR	AR	AR		14	37			
	9	P	F	2610-269-7354	TUBE: inner (P/N MS35392-52)	EA		4		AR	AR	AR		14	38			
					CAP: valve	EA		4	*	*	*	*		14	39			
					VALVE: check (P/N 150.135)	EA		4	*	*	*	*		14	40			
					CAP: hub (P/N C447)	EA		4	*	*	*	*		14	41			
					PIN: cotter (P/N AN380-4-7)	EA		4	AR	AR	AR	AR		14	42			
					NUT: castellated (P/N AN320-16)	EA		4	AR	AR	AR	AR		14	43			
					WASHER: key (P/N 4102)	EA		4	*	*	*	*		14	44			
	P	O		3110-626-9463	CONE: bearing, outer (P/N 15123)	EA		4	*	*	*	*		14	45			

(1) SOURCE MAINT. & RECOVER- ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS BYN ECHIELO	FIG NO. (A)	ITEM NO. (B)
									2ND ECHIELO	3RD ECHIELO	4TH ECHIELO			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) RUNNING GEAR AND BRAKE ASSEMBLY (CONTINUED)														
9	P	D		3110-198-2170	CUP: bearing, outer (P/N 15245)	EA		4			*		14	46
					WASHER: seal (P/N 5731)	EA		4	*	*	*	*	14	47
9	P	O		3110-100-3537	CONE: bearing, inner (P/N 24780)	EA		4	*	*	*	*	14	48
	P	O		3110-100-0542	CUP: bearing, inner (P/N 24720)	EA		4	*	*	*	*	14	49
					BOLT: lug, wheel mtg, 1/2-20 x 1-7/8 in. lg	EA		20	*	*	*	*	14	50
	P	F		2530-533-2650	HUB (P/N B448)	EA		4		*	*	*	14	51
9	P	F	R	2530-528-9090	DRUM: brake (P/N 3719-R-44)	EA		2		*	*	*	14	52
					SPRING: coil (P/N 4083-1)	EA		4	*	*	*	*	14	53
					AXLE ASSEMBLY: front, rh (P/N 4-698)	EA		1	*	*	*	*	14	54
					AXLE ASSEMBLY: front, lh (P/N 4-698-1)	EA		1	*	*	*	*	14	54
					BOLT: machine (P/N AN65-8-12)	EA		4	AR	AR	AR	AR	14	55
					WASHER: lock (P/N AN935-816)	EA		4	AR	AR	AR	AR	14	56
9				2930-362-9155	KINGPIN (P/N 5796)	EA		1	*	*	*	*	14	57
9				3120-661-6270	WASHER: thrust, upper (P/N 400-272)	EA		1	*	*	*	*	14	58
	P	F		3120-684-5681	WASHER: thrust, lower (P/N TED1625)	EA		1		*	*	*	14	59

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES					ILLUSTRATIONS	
MAY CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						-18 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)	
									2ND ECHELON	3RD ECHELON	4TH ECHELON				
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) RUNNING GEAR AND BRAKE ASSEMBLY (CONTINUED)															
					WASHER: thrust, lower (P/N 400-268)	EA		1	*	*	*	*	14	59	
					SPINDLE: rh (P/N 4-756)	EA		1	*	*	*	*	14	60	
					SPINDLE: lh (P/N 4-756-1)	EA		1	*	*	*	*	14	60	
9	P1	F		3120-580-4514	BEARING: sleeve, upper (P/N A11154-1)	EA		1		*	*	*	14	61	
					BEARING: sleeve, lower (P/N A11108-1)	EA		1	*	*	*	*	14	62	
9	P1	F		3120-489-4244	BEARING: sleeve, lower (P/N A1133-2)	EA		1		*	*	*	14	62	
					BRACKET: rh (P/N 4-689)	EA		1	*	*	*	*	14	63	
					BRACKET: lh (P/N 4-689-1)	EA		1	*	*	*	*	14	63	
					BOLT: machine (P/N A165-8-12)	EA		4	AR	AR	AR	AR	14	64	
					WASHER: lock (P/N A1935-816)	EA		4	AR	AR	AR	AR	14	65	
	P1	F	R	2530-541-3003	BRAKE ASSEMBLY (P/N A4-3736-R-70)	EA		1		*	*	*	14	66	
					NUT: hex (P/N A1345-616)	EA		4	AR	AR	AR	AR	14	67	
					WASHER: lock (P/N A1935-616)	EA		4	AR	AR	AR	AR	14	68	
					AXLE: rh (P/N 4-685)	EA		1	*	*	*	*	14	69	
					AXLE: lh (P/N 4-685-1)	EA		1	*	*	*	*	14	69	

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) L T S E T	(7) ALLOWANCES				ILLUSTRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO.	ITEM NO.
									2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) RUBBLING GEAR AND BRAKE ASSEMBLY (CONTINUED)														
					SUPPORT AND ARM ASSEMBLY: front (P/N 4-693)	EA		1	*	*	*	*	14	70
					SUPPORT AND ARM ASSEMBLY: rear (P/N 4-694)	EA		1	*	*	*	*	14	70
					NUT: hex (P/N AN335-10)	EA		6	AR	AR	AR	AR	14	71
					WASHER: lock (P/N AN335-1016)	EA		6	AR	AR	AR	AR	14	72
					WASHER: flat (P/N AN960-1016)	EA		12	AR	AR	AR	AR	14	73
					BOLT: machine (P/N 675-143)	EA		6	*	*	*	*	14	74
					RING: retaining (P/N 619-20)	EA		8	*	*	*	*	14	75
					PIN: grooved headless (P/N 5786-1)	EA		4	*	*	*	*	14	76
					ARM ASSEMBLY: rh (P/N 4-672-2)	EA		1	*	*	*	*	14	77
					ARM ASSEMBLY: lh (P/N 4-672-3)	EA		1	*	*	*	*	14	77
					ARM ASSEMBLY: rh (P/N 4-673-2)	EA		1	*	*	*	*	14	77
					ARM ASSEMBLY: lh (P/N 4-673-3)	EA		1	*	*	*	*	14	77
P	F			2805-992-0585	BEARING: sleeve (P/N AA1339-2)	EA		4		*	*	*	14	78
9	P	F		5340-664-5785	BUMPER: rubber (P/N 613)	EA		2		*	*	*	14	79
					NUT: hex (P/N AN335-6)	EA		2	AR	AR	AR	AR	14	80
					WASHER: lock (P/N AN935-616)	EA		2	AR	AR	AR	AR	14	81

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER- ABILITY CODE									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) BRAKE LEVER ASSEMBLY																			
					WASHER: flat (P/N AN960-616)	EA		2	AR	AR	AR	AR	14	82					
					BOLT: machine (P/N AN65-6-14)	EA		2	AR	AR	AR	AR	14	83					
					SUPPORT ASSEMBLY: front (P/N 7-224-1)	EA		1	*	*	*	*	14	84					
					SUPPORT ASSEMBLY: rear (P/N 7-226-1)	EA		1	*	*	*	*	14	84					
					BEARING: sleeve (P/N FF838-3)	EA		2	*	*	*	*	14	85					
					CLAMP (P/N A426-1001)	EA		1	*	*	*	*	14	86					
					FRAME ASSEMBLY: trailer (P/N A426-4-1800)	EA		1	*	*	*	*	14	87					
	P	F		4920-785-5243	CABLE ASSEMBLY: rh (P/N 2-1671)	EA		1		*	*	*	15	1					
	P	F		4920-785-5242	CABLE ASSEMBLY: lh (P/N 2-1671-1)	EA		1		*	*	*	15	2					
					NUT: 1/2 (P/N AN345-516)	EA		2	AR	AR	AR	AR	15	3					
					LEVER ASSEMBLY (P/N 2-1670)	EA		1	*	*	*	*	15	4					
					SPACER: sleeve (P/N 401-198)	EA		3	*	*	*	*	15	5					
					SPACER: sleeve (P/N 401-205)	EA		1	*	*	*	*	15	6					
					SPACER: sleeve (P/N 401-197)	EA		2	*	*	*	*	15	7					
					WASHER: lock (P/N AN935-616)	EA		3	AR	AR	AR	AR	15	8					
					BOLT: machine (P/N AN65-6-24)	EA		3	AR	AR	AR	AR	15	9					

(1) SOURCE MAINT. & RECOVER-ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS-TRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVER-ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
									2ND ECHELON	3RD ECHELON	4TH ECHELON			
<u>SECTION II</u> <u>GROUP ASSEMBLY PARTS LIST (CONTINUED)</u> <u>GENERATOR AND RADIO SUPPRESSION CAPACITOR</u>														
					PIN: cotter (P/N AK380-4-4)	EA		2	AR	AR	AR	AR	15	10
					PIN: straight, headed (P/N 5688)	EA		2	*	*	*	*	15	11
					CLEVIS: cable (P/N 5692)	EA		2	*	*	*	*	15	12
					WASHER: flat (P/N AN960-516)	EA		4	AR	AR	AR	AR	15	13
					PIN: cotter (P/N AK380-4-4)	EA		1	AR	AR	AR	AR	15	14
					WASHER: flat (P/N AN960-616)	EA		1	AR	AR	AR	AR	15	15
					LEVER (P/N 5687)	EA		2	*	*	*	*	15	16
					SPACER: sleeve (P/N 401-196)	EA		2	*	*	*	*	15	17
					PIN: straight, headed (P/N 5688-2)	EA		1	*	*	*	*	15	18
					BOX: shield (P/N 2-1152)	EA		1	*	*	*	*	16	1
					SCREW (P/N AN501-416-7)	EA		1	AR	AR	AR	AR	16	2
					WASHER: lock (P/N MS35338-44)	EA		1	AR	AR	AR	AR	16	3
					CONNECTOR: box (P/N 946-1)	EA		2	*	*	*	*	16	4
11	P1	O		5910-609-7473	CAPACITOR: fixed, 0.50 uf (P/N Z2020)	EA		2	*	*	*	*	16	5
					NUT: hex (P/N AK340-c)	EA		2	AR	AR	AR	AR	16	6

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS					
SOURCE MAINT. & RECOVER- ABILITY CODE									DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC E UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY										2ND ECHELON	3RD ECHELON	4TH ECHELON			
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ELECTRICAL INSTALLATION													
					WASHER: lock (P/N AN936A6)	EA		2	AR	AR	AR	AR	16	7				
					SCREW: machine (P/N AN526-632-5)	EA		2	AR	AR	AR	AR	16	8				
P1	F	R		2920-623-0409	GENERATOR ASSEMBLY (P/N 1102811)	EA		1		*	*	*	16	9				
					BOLT: machine (P/N AN65-5-6)	EA		1	AR	AR	AR	AR	16	10				
					BOLT: machine (P/N AN101208)	EA		2	AR	AR	AR	AR	16	11				
					WASHER: lock (P/N AN935-516L)	EA		3	AR	AR	AR	AR	16	12				
					WASHER: flat (P/N 400-11M)	EA		3	*	*	*	*	16	13				
					ARM: generator adjusting (P/N 4134-1)	EA		1	*	*	*	*	16	14				
					NUT: hex (P/N AN335-5)	EA		1	AR	AR	AR	AR	16	15				
					WASHER: lock (P/N AN935-516L)	EA		1	AR	AR	AR	AR	16	16				
					WASHER: flat (P/N 400-11M)	EA		1	*	*	*	*	16	17				
					BOLT: machine (P/N AN65-5-10)	EA		1	AR	AR	AR	AR	16	18				
					BRACKET: angle (P/N 4136-1)	EA		1	*	*	*	*	16	19				
					PLATE: mtg (P/N 2-1259)	EA		1	*	*	*	*	16	20				
					ELECTRICAL INSTALLATION	EA		1					17					

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS	
SOURCE MAINT. & RECOVER- ABILITY CODE				FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY						2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ELECTRICAL INSTALLATION (CONTINUED)														
5	P1	O		30-251-7484	BELTING, V (P/N 5LA70)	EA		1	*	*	*	*	17	1
					GENERATOR AND MOUNTING BRACKET ASSEMBLY	EA		1					17	2
					NUT: hex (P/N AN335-6)	EA		2	AR	AR	AR	AR	17	3
					WASHER: lock (P/N AN935-616)	EA		2	AR	AR	AR	AR	17	4
					BOLT: hook (P/N A426-1709)	EA		2	*	*	*	*	17	5
					COVER: holddown, battery (P/N A426-1806)	EA		1	*	*	*	*	17	6
					ADAPTER: terminal (P/N 5292849)	EA		1	*	*	*	*	17	7
					ADAPTER: terminal (P/N 5292850)	EA		1	*	*	*	*	17	8
11	P1	O		6140-785-1098	BATTERY: storage (P/N K-171-G)	EA		1	*	*	*	*	17	9
					NUT: hex (P/N AN335-4)	EA		2	AR	AR	AR	AR	17	10
					WASHER: lock (P/N AN935-416)	EA		2	AR	AR	AR	AR	17	11
					SCREW: machine (P/N AN515-416-16)	EA		2	AR	AR	AR	AR	17	12
					SUPPORT: battery (P/N A426-1810)	EA		2	*	*	*	*	17	13
					NUT: hex (P/N AN345-10)	EA		4	AR	AR	AR	AR	17	14
					WASHER: lock (P/N AN935-10)	EA		4	AR	AR	AR	AR	17	15

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
MAT CODE	SOURCE	MAINT LEVEL RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 3TH ECHELON	FIG NO. (A)	ITEM NO. (B)
								2ND ECHELON	3RD ECHELON	4TH ECHELON			
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ELECTRICAL INSTALLATION (CONTINUED)									
			20-991-7052	BOLT: machine (P/N AN101008)	EA		4	AR	AR	AR	AR	17	16
				TRAY: battery (P/N A426-1811)	EA		1	*	*	*	*	17	17
P10				RELAY: armature (P/N 70-103224)	EA		1	*	*	*	*	17	18
				NUT: hex (P/N AN335-4)	EA		2	AR	AR	AR	AR	17	19
				WASHER: lock (P/N AN935-416)	EA		2	AR	AR	AR	AR	17	20
				WASHER: flat (P/N AN945-4F)	EA		2	AR	AR	AR	AR	17	21
				BOLT: machine (P/N AN65-4-4)	EA		2	AR	AR	AR	AR	17	22
				COVER: box (P/N 2-1073-11)	EA		1	*	*	*	*	17	23
				SCREW: tapping (P/N 610-47)	EA		4	*	*	*	*	17	24
				SCREW: machine (P/N AN515-416-10)	EA		3	AR	AR	AR	AR	17	26
				WASHER: lock (P/N AN935-416)	EA		3	AR	AR	AR	AR	17	27
9	P10	R	2920-394-5988	REGULATOR: generator (P/N 1118300)	EA		1	*	*	*	*	17	28
				BOX ASSEMBLY: regulator (P/N 4-445-5)	EA		1	*	*	*	*	17	28
				NUT: hex (P/N AN335-4)	EA		2	AR	AR	AR	AR	17	29
				WASHER: lock (P/N AN935-416)	EA		2	AR	AR	AR	AR	17	30
				WASHER: flat (P/N AN945-4F)	EA		2	AR	AR	AR	AR	17	31

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
								15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY	1ST ECHELON	2ND ECHELON	3RD ECHELON	4TH ECHELON						
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ENGINE AND FUEL TANK													
				BOLT: machine (P/N AN65-4-6)	EA		2	AR	AR	AR	AR	17	32
				CONNECTOR: box (P/N 946)	EA		2	*	*	*	*	17	33
11	P1	0	5910-538-3232	CAPACITOR: fixed (P/N 48P18)	EA		1	*	*	*	*	17	34
				NUT: hex (P/N AN345-10)	EA		1	AR	AR	AR	AR	17	35
				WASHER: lock (P/N AN935-10)	EA		1	AR	AR	AR	AR	17	36
				SCREW: machine (P/N AN520UB10-6)	EA		1	AR	AR	AR	AR	17	37
				ENGINE INSTALLATION	EA		1					18	
				TUBING: fuel line (P/N A426-2-1712A)	EA		1	*	*	*	*	18	1
				TUBING: oil, outlet (P/N A426-2-1713A)	EA		1	*	*	*	*	18	2
				TUBING: oil, inlet (P/N A426-2-1714A)	EA		1	*	*	*	*	18	3
				TUBING: oil, tee to gage (P/N A426-2-1722A)	EA		1	*	*	*	*	18	4
				SUPPORT: spout (P/N A426-1720A)	EA		1	*	*	*	*	18	5
				BOLT: machine (P/N AN65-4-5)	EA		2	AR	AR	AR	AR	18	6
				WASHER: flat (P/N AN945-4P)	EA		2	AR	AR	AR	AR	18	7
				WASHER: lock (P/N AN935-416)	EA		2	AR	AR	AR	AR	18	8

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS-STRATIONS						
SOURCE MAINT. & RECOVERABILITY CODE									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON			
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ENGINE AND FUEL TANK (CONTINUED)														
					NUT: hex (P/N AN335-4)	EA		2	AR	AR	AR	AR		18	9				
					BOLT: machine (P/N AN65-8-14)	EA		4	AR	AR	AR	AR		18	10				
					WASHER: flat (P/N AN960-816)	EA		8	AR	AR	AR	AR		18	11				
					WASHER: lock (P/N AN935-816)	EA		4	AR	AR	AR	AR		18	12				
					NUT: hex (P/N AN335-8)	EA		4	AR	AR	AR	AR		18	13				
					LINER: strap (P/N A426-1707)	EA		2	*	*	*	*		18	14				
					STRAP: tank (P/N A426-1717)	EA		2	*	*	*	*		18	15				
					TANK: fuel (P/N 4-483)	EA		1	*	*	*	*		18	16				
					CAP: fuel (P/N 4077-1)	EA		1	*	*	*	*		18	17				
					PIN: safety (P/N 4537)	EA		1	*	*	*	*		18	18				
					PLUG: pipe, brass, 1/8 (P/N 650-257)	EA		1	*	*	*	*		18	19				
					ELBOW: male (P/N 69F)	EA		1	*	*	*	*		18	20				
PL F				3010-793-3455	CHAIN: roller (P/N 116055)	EA		1		*	*	*		18	21				
					COUPLING HALF (P/N 116649)	EA		1	*	*	*	*		18	22				
					COUPLING HALF (P/N 116650)	EA		1	*	*	*	*		18	23				

(1)			(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES					ILLUSTRATIONS					
SOURCE MAINT. & RECOVERY ABILITY CODE								FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF MEASURE	EXPENDABILITY	QTY INC UNIT	90 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS WITH SCHEDULE	FIG NO.	ITEM NO.
MAT CODE	SOURCE	MAINT LEVEL											RECOVERY ABILITY	1ST SCHEDULE	2ND SCHEDULE			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ENGINE ACCESSORY GENERATOR																		
P1	P	R	2805-679-3594	ENGINE: gasoline, model M7G4D	EA		1	*	*	*		18	24					
				BOLT: machine (P/N 65-4-10)	EA		8	*	*	*		18	25					
				WASHER: lock (P/N AN935-1016)	EA		8	AR	AR	AR	AR	18	26					
				END BELL (P/N 1923069)	EA		1	*	*	*	*	19	1					
				BOLT: thru (P/N 809763)	EA		2	*	*	*	*	19	2					
				WASHER: lock (P/N ME35338-45)	EA		2	AR	AR	AR	AR	19	3					
				HOLDER ASSEMBLY: grounded brush (P/N 192298)	EA		1	*	*	*	*	19	4					
				HOLDER ASSEMBLY: insulated brush (P/N 192289)	EA		1	*	*	*	*	19	5					
				SCREW (P/N AN515-6-7)	EA		2	AR	AR	AR	AR	19	6					
				WASHER: lock (P/N AN935-5L)	EA		2	AR	AR	AR	AR	19	7					
				NUT: hex (P/N AN340-6)	EA		2	AR	AR	AR	AR	19	8					
P1	P		5977-553-4418	BRUSH (P/N 1923295)	EA		2	*	*	*	*	19	9					
				SCREW (P/N AN515-6-4)	EA		2	AR	AR	AR	AR	19	10					
				WASHER: lock (P/N 190437?)	EA		2	*	*	*	*	19	11					
				ARM: brush (P/N 1878183)	EA		2	*	*	*	*	19	12					

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS			
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO.	ITEM NO.		
									2ND ECHELON	3RD ECHELON	4TH ECHELON		(A)	(B)		
SECTION II																
<u>GROUP ASSEMBLY PARTS LIST (CONTINUED)</u>																
<u>ENGINE ACCESSORY GENERATOR (CONTINUED)</u>																
				5315-012-4545	SPRING: brush (P/N 1908829)	EA		2	*	*	*	*	19	13		
					WASHER: flat (P/N 1857412)	EA		2	*	*	*	*	19	14		
					PULLEY: groove (P/N 1913926)	EA		1	*	*	*	*	19	15		
					WASHER: lock (P/N 804000)	EA		1	*	*	*	*	19	16		
					NUT: hex (P/N 806915)	EA		1	*	*	*	*	19	17		
					FAN (P/N 1866400)	EA		1	*	*	*	*	19	18		
				5315-012-4545	KEY: woodruff (P/N AN280R405)	EA		1	AR	AR	AR	AR	19	19		
					PLATE: bearing retaining (P/N 1911263)	EA		3	*	*	*	*	19	20		
					SCREW (P/N 1904370)	EA		3	*	*	*	*	19	21		
					WASHER: lock (P/N 1880781)	EA		1	*	*	*	*	19	22		
				2920-285-3818	GASKET (P/N 1912008)	EA		1			*	*	19	23		
					WASHER: flat (P/N 809945)	EA		1	*	*	*	*	19	24		
9				3110-151-8140	BEARING: ball (P/N 954378)	EA		1			*	*	19	25		
					PLATE: felt retainer (P/N 819961)	EA		1	*	*	*	*	19	26		
9				5330-171-3619	WASHER, NONMETALLIC (P/N 809961)	EA		1			*	*	19	27		

(1)				(2)	(3)	(4)	(5)	(6)	(7)				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER- ABILITY CODE									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ENGINE ACCESSORY GENERATOR (CONTINUED)																			
					OILER: hand (P/N 125609)	EA		1	*	*	*	*		19	28				
				2920-362-6772	SPACER SLEEVE (P/N 1858603)	EA		1			*	*		19	29				
					END BELL (P/N 1910404)	EA		1	*	*	*	*		19	30				
9	P1	H	R	2920-358-6283	ARMATURE (P/N 1912599)	EA		1			*	*		19	31				
	P1	H		5999-502-1857	POLE PIECE (P/N 1912725)	EA		2			*	*		19	32				
					SCREW (P/N 1843646)	EA		2	*	*	*	*		19	33				
	P1	H		2920-669-6139	WINDING: field (P/N 1922702)	EA		1			*	*		19	34				
					INSULATOR: plate (P/N 1912073)	EA		2	*	*	*	*		19	35				
					NUT: hex (P/N 121743)	EA		4	*	*	*	*		19	36				
					WASHER: lock (P/N 1904661)	EA		4	*	*	*	*		19	37				
					WASHER: flat (P/N 1881409)	EA		2	*	*	*	*		19	38				
					WASHER: insulating (P/N 1858753)	EA		1	*	*	*	*		19	39				
					INSULATOR: bushing (P/N 1885090)	EA		1	*	*	*	*		19	40				
					TERMINAL: stud (P/N 1921860)	EA		1	*	*	*	*		19	41				
					INSULATOR: bushing (P/N 1921362)	EA		1	*	*	*	*		19	42				

MAY CODE	SOURCE	MAINT LEVEL	RECOVERABILITY	(1) SOURCE MAINT. & RECOVER- ABILITY CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- TRATIONS	
										15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHOLON	FIG NO.	ITEM NO.
										2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
						SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) ELECTRICAL ENGINE STARTER									
						TERMINAL: stud (P/N 1921369)	EA		1	*	*	*	*	19	43
						HOUSING	EA		1	*	*	*	*	19	44
P1	O				2920-507-3205	MOTOR: starter (P/N MZ-4184-T)	EA		1	*	*	*	*	20	
						BOLT: machine (P/N MZ-52B)	EA		4	*	*	*	*	20	1
						WASHER: lock (P/N AM935-10)	EA		4	AR	AR	AR	AR	20	2
						SCREW: machine (P/N AM505-8-6)	EA		4	AR	AR	AR	AR	20	3
						HOUSING, DRIVE (P/N P81330A)	EA		1	*	*	*	*	20	4
						CAP: pillow block (P/N MZ-358A)	EA		1	*	*	*	*	20	5
P1	F				2920-592-3979	BEARING (P/N MZ-364)	EA		1	*	*	*	*	20	6
P	P1	F			5330-508-1111	SEAL: plain (P/N XA-832)	EA		1	*	*	*	*	20	7
						BOLT: shoulder (P/N EB-8507A)	EA		1	*	*	*	*	20	8
						BOLT: shoulder (P/N EB-8506A)	EA		1	*	*	*	*	20	9
						WASHER: key (P/N EB-108A)	EA		2	*	*	*	*	20	10
P1	F				2920-367-4255	SHAFT AND PINION (P/N EEB-4511A)	EA		1	*	*	*	*	20	11
P	P1	F			5340-353-6994	SPRING: torsion (P/N EBA-405A)	EA		1	*	*	*	*	20	12

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC R UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
MAINT CODE	RECOVER CODE	MAINT LEVEL	RECOVER LEVEL											2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) <u>IGNITION MAGNETO</u>														
					SPRING (P/N MZ-19C)	EA		4	*	*	*	*		20	27				
P2	F			5977-627-3579	BRUSH (P/N MZ-1034CS)	EA		2		*	*	*		20	28				
P1	F			5977-391-4031	BRUSH (P/N MZ-12D)	EA		2		*	*	*		20	29				
					NUT: hex (P/N AN325B5)	EA		2	AR	AR	AR	AR		20	30				
					WASHER: lock (P/N AN935-516)	EA		2	AR	AR	AR	AR		20	31				
					WASHER: flat (P/N AN960B516)	EA		1	AR	AR	AR	AR		20	32				
					INSULATOR	EA		1						20	33				
					FIELD	EA		1						20	34				
					HOUSING	EA		1						20	35				
P1	F	R		2920-656-7336	MAGNETO: ignition (P/N FM-XZE4B-7)	EA		1		*	*	*		21					
P1	H			2920-799-7683	CAPACITOR: fixed (P/N MK2433X)	EA		1			*	*		21	1				
					SCREW: machine (P/N AN515-6-6)	EA		2	AR	AR	AR	AR		21	2				
					NUT: hex (P/N AN340-6)	EA		1	AR	AR	AR	AR		21	3				
					WASHER: lock (P/N AN935-6)	EA		2	AR	AR	AR	AR		21	4				
					SCREW: machine (P/N AN515-6-8)	EA		1	AR	AR	AR	AR		21	5				

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- TRATIONS		
MAY CODE	SOURCE	MAINT LEVEL						RECOVER- ABILITY	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS BYN SCHEDULE	FIG NO.	ITEM NO.
									1ST SCHEDULE	2ND SCHEDULE	3RD SCHEDULE		(A)	(B)
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) IGNITION MAGNETO (CONTINUED)										
				BUSHING: insulator (P/N G2457AX)	EA		1	*	*	*	*		21	6
				CONTACT (P/N H2514)	EA		1	*	*	*	*		21	7
				PLATE: insulator (P/N W2514)	EA		1	*	*	*	*		21	8
				CAP: end (P/N KX2430A)	EA		1	*	*	*	*		21	9
				SCREW: machine (P/N AN501AC10-10)	EA		2	AR	AR	AR	AR		21	10
				SCREW: machine (P/N AN501AC10-18)	EA		2	AR	AR	AR	AR		21	11
P	PL H		2920-377-6723	ROTOR (P/N X2765X)	EA		1			*	*		21	12
				WICK AND HOLDER (P/N G2788)	EA		1	*	*	*	*		21	13
				SCREW: machine (P/N 508-8-6)	EA		1	*	*	*	*		21	14
				WASHER: lock (P/N AN935-8)	EA		1	AR	AR	AR	AR		21	15
	PL H		2910-640-7794	CONTACT SET (P/N W2437X)	EA		1			*	*		21	16
				RING: retaining (P/N T1498)	EA		1	*	*	*	*		21	17
				SCREW: machine (P/N AN508-6-6)	EA		2	AR	AR	AR	AR		21	18
				WASHER: lock (P/N AN935-6L)	EA		2	AR	AR	AR	AR		21	19
				SCREW: machine (P/N AN507C832-6)	EA		4	AR	AR	AR	AR		21	20

(1) SOURCE MAINT. & RECOVER- ABILITY CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC Z UNIT	(7) ALLOWANCES					ILLUS- STRATIONS	
						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR RESULT OF 100 EQUIPMENTS 8TH ECHELON	FIG NO.	ITEM NO.	
						2ND ECHELON	3RD ECHELON	4TH ECHELON				(A)
		SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) IGNITION MAGNETO (CONTINUED)										
		PIN: cotter (P/N 5931A)	EA		1	*	*	*	*	21	21	
		NUT: castellated, hex (P/N M2570)	EA		1	*	*	*	*	21	22	
		GEAR: drive (P/N GD-103)	EA		1	*	*	*	*	21	23	
		BUSHING (P/N A2572)	EA		1	*	*	*	*	21	24	
		HOUSING: coupling (P/N Y5957)	EA		1	*	*	*	*	21	25	
		SPRING: spiral (P/N E2565)	EA		1	*	*	*	*	21	26	
		PIN: thd (P/N A2568)	EA		1	*	*	*	*	21	27	
		KEY: woodruff (P/N AN280R405)	EA		1	AR	AR	AR	AR	21	28	
9	F1 F	2920-566-7395 COUPLING (P/N BW2563C)	EA		1		*	*	*	21	29	
		SPRING: spiral (P/N B5963)	EA		1	*	*	*	*	21	30	
		RETAINER: packing (P/N E2303)	EA		1	*	*	*	*	21	31	
		WASHER: flat (P/N A2492A)	EA		1	*	*	*	*	21	32	
9	F1 F	2920-356-1221 PACKING: preformed (P/N G3861)	EA		1		*	*	*	21	33	
		WASHER: flat (P/N A2492C)	EA		1	*	*	*	*	21	34	
		RING: retaining (P/N C1498D)	EA		1	*	*	*	*	21	35	

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
MAT CODE	SOURCE	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
								2ND ECHELON	3RD ECHELON	4TH ECHELON			
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) IGNITION MAGNETO (CONTINUED)									
9	P1	F	110-144-8998	RING: retaining (P/N B1498B)	EA		1	*	*	*	*	21	36
				BEARING: ball (P/N C5949)	EA		1		*	*	*	21	37
				RING: retaining (P/N D1498)	EA		1	*	*	*	*	21	38
				GEAR: spur (P/N Q5939)	EA		1	*	*	*	*	21	39
				BEARING: sleeve (P/N D5950C)	EA		1	*	*	*	*	21	40
				RING: retaining (P/N G1498)	EA		1	*	*	*	*	21	41
				GEAR: spur (P/N F5952)	EA		1	*	*	*	*	21	42
				PIV: thd (P/N F2533)	EA		1	*	*	*	*	21	43
				WASHER: flat (P/N A2492C)	EA		1	*	*	*	*	21	44
	P1	F	2920-844-7154	BEARING: roller (P/N D5949A)	EA		1		*	*	*	21	45
				PLATE: breaker (P/N UX4631)	EA		1	*	*	*	*	21	46
				ROTOR: magnetic (P/N TS2480)	EA		1	*	*	*	*	21	47
	P1	F	2920-656-7411	COIL (P/N B2477C)	EA		1		*	*	*	21	48
				SETSCREW (P/N 259S14A)	EA		1	*	*	*	*	21	49
				BOULDER (P/N WV2425)	EA		1	*	*	*	*	21	50

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER.									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	ABILITY CODE	MAINT LEVEL	RECOVER ABILITY											2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) AIR SHROUDING GROUP														
				805-397-9648	AIR SHROUDING GROUP	EA		1						23					
					SCREEN: flywheel (P/N SE-48-1)	EA		1		*	*	*		23	1				
					SCREW: machine (P/N AN515C416-16)	EA		8	AR	AR	AR	AR		23	2				
					WASHER: lock (P/N AN935-416)	EA		8	AR	AR	AR	AR		23	3				
					PLATE: identification & instruction (P/N SD-115-N)	EA		1	*	*	*	*		23	4				
					SCREW: tapping (P/N AN530-4-4)	EA		4	AR	AR	AR	AR		23	5				
					SHROUD: cylinder head, rh (P/N SE-127)	EA		1	*	*	*	*		23	6				
					SHROUD: cylinder head, lh (P/N SE-127-A)	EA		1	*	*	*	*		23	7				
					SCREW: machine (P/N AN515C416-6)	EA		6	AR	AR	AR	AR		23	8				
					BOLT: machine (P/N 65-4-4)	EA		2	*	*	*	*		23	9				
					WASHER: lock (P/N AN935-416)	EA		10	AR	AR	AR	AR		23	10				
					SHROUD: rear, rh (P/N SE-125)	EA		1	*	*	*	*		23	11				
					SHROUD: rear, lh (P/N SE-125-A)	EA		1	*	*	*	*		23	12				
					BOLT: machine (P/N 65-4-4)	EA		4	*	*	*	*		23	13				
					WASHER: lock (P/N AN935-416)	EA		10	AR	AR	AR	AR		23	14				

(1)			(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUSTRATIONS						
SOURCE MAINT. & RECOVERABILITY CODE								FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL											RECOVER ABILITY	2ND ECHOLON	3RD ECHOLON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) MANIFOLD AND CRANKCASE GROUP																		
					SHROUD: lower cylinder, lh (P/N SE-126-A)	EA		1	*	*	*	*	23	15				
					DEFLECTOR: heat, rh (P/N SE-128-B)	EA		1	*	*	*	*	23	16				
					DEFLECTOR: heat, lh (P/N SE-128-C)	EA		1	*	*	*	*	23	17				
					SHROUD: flywheel (P/N SE-124-Y)	EA		1	*	*	*	*	23	18				
					MANIFOLD AND CRANKCASE GROUP	EA		1					24					
					BOLT: machine (P/N AN65-6-14)	EA		34	AR	AR	AR	AR	24	1				
					WASHER: flat (P/N AN945-6)	EA		34	AR	AR	AR	AR	24	2				
					HEAD ASSEMBLY: cylinder (P/N AB-7B-2-S1)	EA		2	*	*	*	*	24	3				
9	P1	F	2805-399-6984		GASKET: head (P/N QD-631)	EA		2		*	*	*	24	4				
9	P1	F	2805-428-2159		GASKET: block (P/N QD-632)	EA		2		*	*	*	24	5				
					ELBOW: pipe, 1-1/2 x 90 deg (P/N 650-209)	EA		1	*	*	*	*	24	6				
9	P1	F	2990-540-5066		MUFFLER (P/N WD50A)	EA		1		*	*	*	24	7				
					CLAMP: muffler (P/N 4141)	EA		1	*	*	*	*	24	8				
					WASHER: lock (P/N AN935-416)	EA		2	AR	AR	AR	AR	24	9				
					NUT: hex (P/N AN340-416)	EA		2	AR	AR	AR	AR	24	10				

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES					ILLUS-STRATIONS					
SOURCE MAINT. & RECOVERABILITY CODE									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) MANIFOLD AND CRANKCASE GROUP (CONTINUED)																			
					MOUNT: muffler (P/N 4140)	EA		1	*	*	*	*		24	11				
					COUPLING: pipe, 1-1/2 (P/N 650-211)	EA		1	*	*	*	*		24	12				
					NIPPLE: pipe, 1-1/2 x 3-1/2 (P/N 650-212)	EA		1	*	*	*	*		24	13				
					ELBOW: pipe, street, 1-1/2 x 90 deg (P/N 650-210)	EA		1	*	*	*	*		24	14				
9	P1	F		2990-816-5714	CHOKE CONTROL (P/N VE-435-E)	EA		1		*	*	*		24	15				
					BOLT: machine (P/N AN65-5-12)	EA		2	AR	AR	AR	AR		24	16				
					WASHER: lock (P/N AN935-516)	EA		2	AR	AR	AR	AR		24	17				
9	P1	F		2910-255-2298	CARBURETOR: model VH-69-A (P/N 10-3774)	EA		1		*	*	*		24	18				
	P1	F		2805-624-9940	GASKET (P/N QF-91)	EA		1		*	*	*		24	19				
					PLUG: pipe (P/N XK-1)	EA		1	*	*	*	*		24	20				
					NUT: hex (P/N 325B7)	EA		4	*	*	*	*		24	21				
					WASHER: lock (P/N AN935-716)	EA		4	AR	AR	AR	AR		24	22				
					STUD: manifold (P/N PC-251)	EA		4	*	*	*	*		24	23				
					MANIFOLD (P/N LD-240-18)	EA		1	*	*	*	*		24	24				
9	P1	H		2805-292-3984	INSERT: gasket (P/N QB-83)	EA		6				*		24	25				

(1) SOURCE MAINT. & RECOVER ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS		
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY REQUIRED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)	
									2ND ECHELON	3RD ECHELON	4TH ECHELON				
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) CARBURETOR										
9	P1	H		2805-399-6982	GASKET: manifold (P/N QC-62)	EA		2			*	*	24	26	
					BOLT: machine (P/N AN65-5-5)	EA		14	AR	AR	AR	AR	24	27	
					WASHER: lock (P/N AN935-516)	EA		14	AR	AR	AR	AR	24	28	
					PLATE: bottom, crankshaft (P/N BH-155-C)	EA		1	*	*	*	*	24	29	
9	P1	H		2805-428-2162	GASKET (P/N QD-635)	EA		1			*	*	24	30	
					CRANKCASE ASSEMBLY (P/N BA-49A-8-S1)	EA		1	*	*	*	*	24	31	
					PLUG: exp, 1-3/8 (P/N SA-58)	EA		1	*	*	*	*	24	32	
					INSERT: exp (P/N SA-26)	EA		2	*	*	*	*	24	33	
					STUD: block mtg (P/N PC-435)	EA		12	*	*	*	*	24	34	
					BOWL: sediment (P/N 65-172)	EA		1	*	*	*	*	25	1	
					BOLT: machine (P/N 80-166)	EA		1	*	*	*	*	25	2	
9	P1	F		5330-291-7918	GASKET (P/N 16-4)	EA		1		*	*	*	25	3	
	P1	F		2910-522-5358	GASKET (P/N 16-A105)	EA		1		*	*	*	25	4	
	P1	F		2910-429-2155	FLOAT (P/N 30-666)	EA		1		*	*	*	25	5	
					PIN (P/N 32-27)	EA		1	*	*	*	*	25	6	

(1)			(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER- ABILITY CODE								FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL											RECOVER- ABILITY	2ND ECHELON	3RD ECHELON			
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) CARBURETOR (CONTINUED)														
					VALVE ASSEMBLY: float (P/N 233-536)	EA	1	*	*	*	*	25	7					
F1	F	2505-992-0579			NOZZLE: main (P/N 47-395)	EA	1		*	*	*	25	8					
P1	F	5330-496-5413			GASKET (P/N 16-456)	EA	1		*	*	*	25	9					
					POWER JET (P/N 49-253)	EA	1	*	*	*	*	25	10					
					CUP: idle (P/N 55-316)	EA	1	*	*	*	*	25	11					
					THROTTLE FLY (P/N 14-214)	EA	1	*	*	*	*	25	12					
					SCREW: machine (P/N 15-A46)	EA	2	*	*	*	*	25	13					
					SCREW: machine (P/N AN5000AC8-12)	EA	1	AR	AR	AR	AR	25	14					
					SPRING (P/N 24-262)	EA	1	*	*	*	*	25	15					
					SHAFT ASSEMBLY: throttle (P/N 13-956)	EA	1	*	*	*	*	25	16					
					RETAINER: packing (P/N 55-231)	EA	2	*	*	*	*	25	17					
					PACKING: preformed (P/N 44-63)	EA	2	*	*	*	*	25	18					
					BUSHING: sleeve (P/N 60-439)	EA	2	*	*	*	*	25	19					
					NEEDLE: idle (P/N 43-129)	EA	1	*	*	*	*	25	20					
					SPRING (P/N 24-485)	EA	1	*	*	*	*	25	21					

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER- ABILITY CODE									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO.	ITEM NO.
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON			
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) CYLINDER BLOCK ASSEMBLY														
					CHOKE FLY (P/N 27-559)	EA		1	*	*	*	*		25	22				
					SCREW: machine (P/N 15-A47)	EA		2	*	*	*	*		25	23				
					SCREW: machine (P/N AN500C8-5)	EA		1	AR	AR	AR	AR		25	24				
					SWIVEL: choke (P/N 28-49)	EA		1	*	*	*	*		25	25				
					PIN: cotter (P/N 82-16)	EA		1	*	*	*	*		25	26				
					SPRING (P/N 24-213)	EA		1	*	*	*	*		25	27				
					SHAFT ASSEMBLY: choke (P/N 26-720)	EA		1	*	*	*	*		25	28				
					SCREW: machine (P/N 15-A99)	EA		1	*	*	*	*		25	29				
					BRACKET ASSEMBLY: choke (P/N 29-537)	EA		1	*	*	*	*		25	30				
					SCREW: machine (P/N 15-A93)	EA		2	*	*	*	*		25	31				
P1	F			5330-726-0220	PACKING: preformed (P/N 44-38)	EA		1		*	*	*		25	32				
					CUP: shaft (P/N 55-230)	EA		1	*	*	*	*		25	33				
					BODY (P/N 10-3685)	EA		1	*	*	*	*		25	34				
					CYLINDER BLOCK ASSEMBLY (P/N AA-90A-2-S1)	EA		1	*	*	*	*		26					
					COVER: valve (P/N BH-103)	EA		2	*	*	*	*		26	1				

MAY CODE	SOURCE	MAINT LEVEL	RECOVER-ABILITY	(1) SOURCE MAINT. & RECOVER-ABILITY CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS-TRATIONS		
										15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO.	ITEM NO.	
										2ND ECHELON	3RD ECHELON	4TH ECHELON				(A)
						SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) CAMSHAFT AND FUEL PUMP MOUNTING GROUP										
						BOLT: machine (P/N AN65-5-14)	EA		2	AR	AR	AR	AR	26	2	
						WASHER: flat (P/N AN960B516)	EA		2	AR	AR	AR	AR	26	3	
	Pl H				2805-536-9804	GASKET: cover (P/N QD-482)	EA		2			*	*	26	4	
9	Pl H				2805-674-4865	TAPPET ASSEMBLY: valve (P/N F-65-S1)	EA		1			*	*	26	5	
	Pl H				2805-374-9746	ROTATOR CAP (P/N MS13998-1)	EA		4			AR	AR	26	6	
	Pl H				2805-528-6097	LOCK: retainer (P/N MS13997-1)	EA		8			AR	AR	26	7	
						SEAT, SPRING (P/N AG-30)	EA		4	*	*	*	*	26	8	
						SPRING: valve (P/N AF-49A)	EA		4	*	*	*	*	26	9	
9	Pl H				2805-382-8033	VALVE: poppet (P/N MS13999-8)	EA		4			AR	AR	26	10	
9	Pl H				2805-424-2806	INSERT: seat (P/N HG-150D)	EA		4			*	*	26	11	
	Pl H				2805-574-8856	GUIDE: valve (P/N AD-42A)	EA		4			*	*	26	12	
						CYLINDER BLOCK (P/N AA-90A-2)	EA		1	*	*	*	*	26	13	
						CAMSHAFT AND FUEL PUMP MOUNTING GROUP	EA		1						27	
	Pl O				4730-142-1741	STRAINER: fuel (P/N OW-418T)	EA		1	*	*	*	*	27	1	
						NIPPLE: pipe (P/N RF-794-A)	EA		1	*	*	*	*	27	2	

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- TRATIONS		
MAT CODE	SOURCE	MAINT LEVEL RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHOLON	FIG NO. (A)	ITEM NO. (B)	
								2ND ECHOLON	3RD ECHOLON	4TH ECHOLON				
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) CAMSHAFT AND FUEL PUMP MOUNTING GROUP (CONTINUED)										
				ELBOW: street, 90 deg (P/N RF-996)	EA		1	*	*	*	*	27	3	
9	PI	F	910-447-9285	FUEL LINE (P/N RM-1049A)	EA		1		*	*	*	27	4	
	PI	F	2910-339-4836	FUEL PUMP (P/N GI-195-C)	EA		1		*	*	*	27	5	
				BOLT: machine (P/N AN65-5-5)	EA		2	AR	AR	AR	AR	27	6	
				WASHER: lock (P/N AN935-516)	EA		2	AR	AR	AR	AR	27	7	
9	PI	F	5330-599-5966	GASKET: fuel pump (P/N 24240)	EA		1		*	*	*	27	8	
				SCREW: cap, socket head (P/N XB-75)	EA		2	*	*	*	*	27	9	
				WASHER: lock (P/N AN935-416)	EA		2	*	*	*	*	27	10	
				HANDLE (P/N TA-115)	EA		1	*	*	*	*	27	11	
				SPRING (P/N PM-145)	EA		1	*	*	*	*	27	12	
	PI	F	5330-050-1218	RING: packing (P/N JK-50)	EA		1		*	*	*	27	13	
				SHAFT (P/N TA-114)	EA		1	*	*	*	*	27	14	
				ADAPTER (P/N TB-105-B)	EA		1	*	*	*	*	27	15	
				CAP: plunger (P/N TA-116)	EA		1	*	*	*	*	27	16	
				PLUNGER (P/N TA-111-A)	EA		1	*	*	*	*	27	17	

(1) SOURCE MAINT. & RECOVER- ABILITY CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO.	ITEM NO.
						2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) FUEL PUMP											
P1 F	2805-366-6351	GASKET (P/N QD-67)	EA		1		*	*	*	27	18
		BUTTON (P/N PF-52)	EA		1	*	*	*	*	27	19
P1 F	2805-366-6248	PLUNGER (P/N PF-101)	EA		1		*	*	*	27	20
P1 F	2805-366-6249	SPRING (P/N PM-108)	EA		1		*	*	*	27	21
		GEAR: camshaft (P/N GB-46)	EA		1	*	*	*	*	27	22
		BRACKET: mtg (P/N GI-22)	EA		1	*	*	*	*	27	22
		BOLT: machine (P/N AN65-5-10)	EA		3	AR	AR	AR	AR	27	23
		WASHER: lock (P/N AN936B516)	EA		3	AR	AR	AR	AR	27	24
9 P1 F	2805-524-9552	CAMSHAFT (P/N EA-112)	EA		1		*	*	*	27	25
		BOLT, MACHINE (P/N FP-765)	EA		1	*	*	*	*	28	1
P1 F	5330-656-7475	GASKET (P/N FP-766)	EA		1		*	*	*	28	2
		DOMS (P/N FP-754)	EA		1		*	*	*	28	3
P1 F	5330-656-7474	GASKET (P/N FP-614)	EA		1		*	*	*	28	4
P1 F	2910-684-4405	FILTER: fuel (P/N FP-657)	EA		1		*	*	*	28	5
		SCREW AND LOCKWASHER ASSEMBLY (P/N FP-762)	EA		6	*	*	*	*	28	6

(1) SOURCE MAINT. & RECOVER. ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- TRATIONS		
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)	
									2ND ECHELON	3RD ECHELON	4TH ECHELON				
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) FUEL PUMP (CONTINUED)										
					FUEL HEAD (P/N GI-46)	EA		1	*	*	*	*	28	7	
					VALVE (P/N FP-756)	EA		2	*	*	*	*	28	8	
					SPRING (P/N FP-644-7)	EA		2	*	*	*	*	28	9	
P1	F	2805-992-0851			RETAINER: spring (P/N FP-757)	EA		1		*	*	*	28	10	
P1	F	5330-991-7008			GASKET (P/N FP-613)	EA		1		*	*	*	28	11	
					PLATE: valve (P/N FP-750)	EA		1	*	*	*	*	28	12	
					SCREW AND LOCKWASHER ASSEMBLY (P/N FP-759)	EA		3	*	*	*	*	28	13	
P1	F	2910-958-7663			DIAPHRAGM (P/N IQ-21-E)	EA		1		*	*	*	28	14	
P1	F	5330-991-7010			GASKET (P/N FP-615)	EA		1		*	*	*	28	15	
					SPRING: diaphragm (P/N FP-642S)	EA		1	*	*	*	*	28	16	
P1	F	5340-237-2275			SPRING: rocker arm (P/N FP-645)	EA		1		*	*	*	28	17	
					PIN: straight headless (P/N FP-553)	EA		1	*	*	*	*	28	18	
					BUSHING (P/N FP-499)	EA		1	*	*	*	*	28	19	
					ARM: rocker (P/N FP-5455)	EA		1	*	*	*	*	28	20	
					LINKAGE (P/N FP-505)	EA		1	*	*	*	*	28	21	

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES						ILLUSTRATIONS			
MAY CODE	BOUNCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)				
									2ND ECHELON	3RD ECHELON	4TH ECHELON							
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) GOVERNOR AND CONTROL ASSEMBLY													
					GOVERNOR ASSEMBLY	EA		1									29	
					LOCKNUT (P/N PD-173-A)	EA		1	*	*	*	*					29	1
					SPRING (P/N PM-111)	EA		1	*	*	*	*					29	2
					PIN: cotter (P/N AN381-2-8)	EA		1	AR	AR	AR	AR					29	3
					SCREW: adjusting (P/N P1-145-1)	EA		1	*	*	*	*					29	4
					PIN: swivel (P/N TC-368-A)	EA		1	*	*	*	*					29	5
9	PI	F		2990-818-3962	CONTROL ASSEMBLY (P/N VE-527-WV)	EA		1		*	*	*					29	6
					SCREW: machine (P/N AN515C5-4)	EA		1	AR	AR	Ak	AR					29	7
					STOP: wire (P/N VE-339-A)	EA		1	*	*	*	*					29	8
					NUT: hex (P/N AN335-6)	EA		2	AR	AR	AR	AR					29	9
					WASHER: lock (P/N AN935-616)	EA		1	AR	AR	AR	AR					29	10
					SUPPORT (P/N VE-556)	EA		1	*	*	*	*					29	11
					BRACKET (P/N PG-475)	EA		1	*	*	*	*					29	12
					SCREW: tapping (P/N AN530C8-8)	EA		2	AR	AR	AR	AR					29	13
					BOLT: machine (P/N PB-163)	EA		1	*	*	*	*					29	14

(1) SOURCE MAINT. & RECOVER- ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- TRATIONS		
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)	
									2ND ECHELON	3RD ECHELON	4TH ECHELON				
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) GOVERNOR AND CONTROL ASSEMBLY (CONTINUED)										
					WASHER: lock (P/N PH-293-A)	EA		2	*	*	*	*	29	15	
					BLOCK: swivel (P/N VE-598)	EA		1	*	*	*	*	29	16	
					BUSHING (P/N HC-203)	EA		1	*	*	*	*	29	17	
					LEVER (P/N VB-134A-9)	EA		1	*	*	*	*	29	18	
					PIN: cotter (P/N AK381-2-8)	EA		1	AR	AR	AR	AR	29	19	
					WASHER: flat (P/N AN960CS16)	EA		1	AR	AR	AR	AR	29	20	
					PIN: support (P/N TC-365-D)	EA		1	*	*	*	*	29	21	
B	PL	P		2805-371-4615	OIL LINE ASSEMBLY (P/N RM-536)	EA		1		*	*	*	29	22	
					TEE: oil line (P/N RF-1281)	EA		1	*	*	*	*	29	23	
					BUSHING: rod (P/N RF-1165)	EA		1	*	*	*	*	29	24	
					KIPPLE: pipe (P/N RF-269)	EA		1	*	*	*	*	29	25	
					CAP: tachometer adapter (P/N TC-403)	EA		1	*	*	*	*	29	26	
					SPRING: extension (P/N PH-76)	EA		1	*	*	*	*	29	27	
					NUT: hex (P/N AK345-10)	EA		3	AR	AR	AR	AR	29	28	
					NUT: hex (P/N PD-115-A)	EA		1	*	*	*	*	29	29	

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
									2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
SECTION II. GROUP ASSEMBLY PARTS LIST (CONTINUED) GOVERNOR AND CONTROL ASSEMBLY (CONTINUED)														
					WASHER: lock (P/N AN935-10)	EA		4	AR	AP	AF	AR	29	30
					BALL JOINT (P/N VE-674-A)	EA		2	*	*	*	*	29	31
					ROD: control lever (P/N VE-689-A)	EA		1	*	*	*	*	29	32
9	P	H		3110-117-0587	BEARING: shaft (P/N 123)	EA		1			*	*	29	33
					GEAR: helical (P/N GD-95-A)	EA		1	*	*	*	*	29	34
					KEY: woodruff (P/N AN280H404)	EA		1	AR	AR	AR	AR	29	35
9	P	H		3110-117-0575	BEARING: housing (P/N 120)	EA		1			*	*	29	36
	P	H		3110-120-4464	BEARING (P/N 607)	EA		1			*	*	29	37
					SLEEVE (P/N TC-348A)	EA		1	*	*	*	*	29	38
					PIN: straight headless (P/N PA-340)	EA		2	*	*	*	*	29	39
					FLYWEIGHT (P/N TC-322D-S1)	EA		2	*	*	*	*	29	40
					PIN: headed (P/N TC-328-D)	EA		2	*	*	*	*	29	41
					PIN: tapered (P/N AN385A2P10)	EA		1	AR	AR	AR	AR	29	42
					HUB: flyweight (P/N TC-346-B)	EA		1	*	*	*	*	29	43
					SHAFT: drive (P/N TA-112-A)	EA		1	*	*	*	*	29	44

(1) SOURCE MAINT. & RECOVERABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS		
MAT CODE	SOURCE	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO.	ITEM NO.	
								2ND ECHELON	3RD ECHELON	4TH ECHELON		(A)	(B)	
				SECTION II. GROUP ASSEMBLY PARTS LIST (CONTINUED) RESERVOIR (CONTINUED)										
				COVER ASSEMBLY (P/N A290-3029-1A)	EA		1	*	*	*	*	30	5	
				NUT: hex (P/N AN345-10)	EA		2	AR	AR	AR	AR	30	6	
				WASHER: lock (P/N AN936B10)	EA		2	AR	AR	AR	AR	30	7	
				COVER ASSEMBLY (P/N A290-3227A)	EA		1	*	*	*	*	30	8	
PI O			4330-024-9665	FILTER ELEMENT (P/N AN6237-1)	EA		1	AR	AR	AR	AR	30	9	
PI O			4720-992-0537	HOSE: 6 in. lg (P/N 669-119)	EA		1	*	*	*	*	30	10	
				COVER ASSEMBLY (P/N A280-3028A)	EA		1	*	*	*	*	30	11	
PI F			6680-786-9283	TRANSMITTER, LIQUID QUANTITY (P/N A280-5006) (Modified from P/N 4110)	EA		1		*	*	*	30	12	
				SCREW: socket head cap (P/N 686-89)	EA		4	*	*	*	*	30	13	
				WASHER: lock (P/N AN936B516)	EA		4	AR	AR	AR	AR	30	14	
				DRAIN ASSEMBLY (P/N 2-1668)	EA		1	*	*	*	*	30	15	
				TEE (P/N AN834-16)	EA		1	AR	AR	AR	AR	30	16	
				RESERVOIR (P/N A280-4-3006)	EA		1	*	*	*	*	30	17	
				SUPPORT (P/N 7-222-2)	EA		1	*	*	*	*	30	18	
				ENGINE CONTROLS INSTALLATION	EA		1					30	19	

(1) SOURCE MAINT. & RECOVER-ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS-STRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVER-ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 9TH ECHELON	FIG	ITEM
									2ND ECHELON	3RD ECHELON	4TH ECHELON		NO.	NO.
								(A)	(B)					
SECTION II - GROUP ASSEMBLY PARTS LIST (CONTINUED) HOUSING ASSEMBLY														
					HOUSING ASSEMBLY: trailer (P/N A426-4-1805)	EA		1	*	*	*	*	32	
					NUT: hex, self-locking (P/N AN365-420)	EA		7	AR	AR	AR	AR	32	1
					ARM: clamp (P/N 5665)	EA		7	*	*	*	*	32	2
					SPRING (P/N 5629)	EA		7	*	*	*	*	32	3
					WASHER: flat (P/N AN960B4-1)	EA		7	AR	AR	AR	AR	32	4
					THUMBSCREW (P/N 675-213)	EA		7	*	*	*	*	32	5
					PANEL ASSEMBLY: front (P/N 4-634-2)	EA		1	*	*	*	*	32	6
PL	O			4920-707-5676	SUPPORT: door (P/N 50-927LH)	EA		8	*	*	*	*	32	7
PL	O			4920-707-3126	SUPPORT: door (P/N 50-927RH)	EA		1	*	*	*	*	32	8
					NUT: hex, self-locking (P/N AN364-832)	EA		4	AR	AR	AR	AR	32	9
					BOLT: shoulder (P/N 4100)	EA		4	*	*	*	*	32	10
					NUT: hex (P/N AN340-6)	EA		3	AR	AR	AR	AR	32	11
					WASHER: lock (P/N AN935-8)	EA		6	AR	AR	AR	AR	32	12
					CLAMP ASSEMBLY: door (P/N 5666-4)	EA		6	*	*	*	*	32	13
					CLAMP ASSEMBLY: door (P/N 5666-6)	EA		6	*	*	*	*	32	13

(1)			(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER- ABILITY CODE								FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL RECOVER- ABILITY											3RD ECHOLON	3RD ECHOLON	4TH ECHOLON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) HOUSING ASSEMBLY (CONTINUED)																		
				NUT: hex, self-locking (P/N AN365-420)	EA		3	AR	AR	AR	AR		32	14				
				ARM: clamp (P/N 5664) (U/O P/N 5666-4)	EA		6	*	*	*	*		32	15				
				ARM: clamp (P/N 5665) (U/O P/N 5666-6)	EA		2	*	*	*	*		32	15				
				SPRING (P/N 5629)	EA		8	*	*	*	*		32	16				
				WASHER: flat (P/N AN960B416)	EA		8	AR	AR	AR	AR		32	17				
				KNOB (P/N 1185)	EA		8	*	*	*	*		32	18				
				SETSCREW (P/N AN565D8H5)	EA		9	AR	AR	AR	AR		32	19				
				STUD: clamp (P/N 5663-1)	EA		8	*	*	*	*		32	20				
				DOOR ASSEMBLY: rear (P/N 2-1677)	EA		1	*	*	*	*		32	21				
				DOOR ASSEMBLY: left rear (P/N 2-1128-2)	EA		1	*	*	*	*		32	22				
				DOOR ASSEMBLY: left front (P/N 2-1127-2)	EA		1	*	*	*	*		32	23				
				DOOR ASSEMBLY: right front (P/N 2-1126-2)	EA		1	*	*	*	*		32	24				
				SCREW: machine (P/N AN510-10-8)	EA		5	AR	AR	AR	AR		32	25				
				SCREW: machine (P/N AN510-10-8)	EA		15	AR	AR	AR	AR		32	25				
				LOOP: catch (P/N 2397-4)	EA		6	*	*	*	*		32	26				

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY IN UNIT	(7) ALLOWANCES					ILLUSTRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						90 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHOLON	FIG NO. (A)	ITEM NO. (B)	
									2ND ECHOLON	3RD ECHOLON	4TH ECHOLON				
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) HOUSING ASSEMBLY (CONTINUED)															
					LEVER: catch (P/N 2397-5)	EA		6	*	*	*	*		32	27
					SUPPORT: door (P/N 61-3653RH)	EA		2	*	*	*	*		32	29
					SUPPORT: door (P/N 61-3653LH)	EA		2	*	*	*	*		32	29
					DOOR ASSEMBLY: front, top (P/N 2-1117A)	EA		2	*	*	*	*		32	30
					STRIP: weather (P/N X-197)	EA		4	*	*	*	*		32	31
					NUT: hex (P/N AN340-8)	EA		6	AR	AR	AR	AR		32	32
					WASHER: lock (P/N AN935-8)	EA		6	AR	AR	AR	AR		32	33
					SCREW: machine (P/N AN515-8-8)	EA		6	AR	AR	AR	AR		32	34
					RING: retaining (P/N 4323)	EA		1	*	*	*	*		32	35
					BASKET: reservoir (P/N 4324)	EA		1	*	*	*	*		32	36
					SUPPORT: door (P/N 61-3653LH)	EA		1	*	*	*	*		32	37
					SUPPORT: door (P/N 61-3653RH)	EA		1	*	*	*	*		32	37
					SCREW: machine (P/N AN515-8-12)	EA		1	AR	AR	AR	AR		32	38
					WASHER: lock (P/N AN935-8)	EA		1	AR	AR	AR	AR		32	39
					SCREW: machine (P/N AN515UB8-5)	EA		1	AR	AR	AR	AR		32	40

(1)			(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER- ABILITY CODE								FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL RECOVER- ABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON			
																	2ND ECHELON	3RD ECHELON
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) HOUSING ASSEMBLY (CONTINUED)														
				WASHER: lock (P/N AN935-8)	EA		1	AR	AR	AR	AR		32	41				
				BUMPER: rubber (P/N 1489-2)	EA		1	*	*	*	*		32	42				
				SPACER (P/N A426-1601)	EA		1	*	*	*	*		32	43				
				DOOR ASSEMBLY: rear, top (P/N 2-1118-3A)	EA		1	*	*	*	*		32	44				
				NUT: hex (P/N AN340-416)	EA		7	AR	AR	AR	AR		32	45				
				WASHER: lock (P/N AN935-416)	EA		7	AR	AR	AR	AR		32	46				
				BOLT: machine (P/N AN65-4-4)	EA		7	AR	AR	AR	AR		32	47				
				STRIP: weather (P/N 671-173-28.875)	EA		1	*	*	*	*		32	48				
				STRIP: weather (P/N X-197)	EA		2	*	*	*	*		32	49				
				DOOR ASSEMBLY: control panel (P/N 2-1120-1)	EA		1	*	*	*	*		32	50				
				NUT: hex (P/N AN340-416)	EA		7	AR	AR	AR	AR		32	51				
				WASHER: lock (P/N AN935-416)	EA		7	AR	AR	AR	AR		32	52				
				BOLT: machine (P/N AN65-4-4)	EA		7	AR	AR	AR	AR		32	53				
				STRIP: weather (P/N 671-173-28.875)	EA		1	*	*	*	*		32	54				
				HANDLE: bow (P/N 3282)	EA		1	*	*	*	*		32	55				

MAY CODE	(1) SOURCE MAINT. & RECOVERABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS			
	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO. (A)	ITEM NO. (B)		
									2ND ECHOLON	3RD ECHOLON	4TH ECHOLON					
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) HOUSING ASSEMBLY (CONTINUED)											
					CATCH: door (P/N 2397-3L)	EA		2	*	*	*	*	32	56		
					RETAINER ASSEMBLY: hinge (P/N 4043-1)	EA		2	*	*	*	*	32	57		
					RETAINER ASSEMBLY: hinge (P/N 4044-1)	EA		1	*	*	*	*	32	58		
					HINGE: butt (P/N 4041-1)	EA		1	*	*	*	*	32	59		
					HINGE: butt (P/N 4042-1)	EA		1	*	*	*	*	32	60		
					BOLT: machine (P/N AN65-6-10)	EA		8	AR	AR	AR	AR	32	61		
					WASHER: lock (P/N AN935-616)	EA		8	AR	AR	AR	AR	32	62		
					PIN: headless (P/N 5747)	EA		2	*	*	*	*	32	63		
					SPRING (P/N 5695)	EA		2	*	*	*	*	32	64		
					HOOK: support (P/N 5744A)	EA		2	*	*	*	*	32	65		
					PLATE ASSEMBLY (P/N 5833)	EA		2	*	*	*	*	32	66		
9	PL 0		5340-687-5300		HANDLE: bow (P/N 2-1428)	EA		2	*	*	*	*	32	67		
					WASHER: flat (P/N AN960-10L)	EA		8	AR	AR	AR	AR	32	68		
					SCREW: machine (P/N AN510-10-8)	EA		8	AR	AR	AR	AR	32	69		
					PLATE: identification, test stand (P/N 4055-3)	EA		1	*	*	*	*	32	70		

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES					ILLUSTRATIONS			
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)			
									2ND ECHELON	3RD ECHELON	4TH ECHELON						
					SECTION II GROUP ASSEMBLY PARTS LIST - (CONTINUED) ENGINE GENERATOR REGULATOR												
					PLATE: identification, mfg (P/N 4330)	EA		1	*	*	*	*		32	71		
					HOUSING ASSEMBLY: trailer (P/N 4-472-2)	EA		1	*	*	*	*		32	72		
					COVER (P/N 1878514)	EA		1	*	*	*	*		33	1		
					SCREW: machine (P/N 1878499)	EA		2	*	*	*	*		33	2		
					WASHER: flat (P/N 813731)	EA		2	*	*	*	*		33	3		
					GASKET (P/N 1875510)	EA		1	*	*	*	*		33	4		
					SCREW: adjusting (P/N 1812159)	EA		1	*	*	*	*		33	5		
	PL H			2920-259-1695	ARMATURE (P/N 1878467)	EA		1			*	*		33	6		
					SCREW: machine (P/N AN515-6-5)	EA		2	AR	AR	AR	AR		33	7		
					WASHER: lock (P/N AN935-6L)	EA		2	AR	AR	AR	AR		33	8		
	9 PL H			2920-512-1788	SPRING: extension (P/N 1912176)	EA		2			*	*		33	9		
					SCREW: machine (P/N 1922408)	EA		2	*	*	*	*		33	10		
					SCREW: machine (P/N AN515-3-6)	EA		4	AR	AR	AR	AR		33	11		
					WASHER: lock (P/N 1878505)	EA		2	*	*	*	*		33	12		
					INSULATOR (P/N 1878507)	EA		1	*	*	*	*		33	13		

(1) SOURCE MAINT. & RECOVER- ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO.	ITEM NO.
									2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II - GROUP ASSEMBLY PARTS LIST (CONTINUED) GEAR COVER GROUP														
					BAR: bus (P/N 1878504)	EA		1	*	*	*	*	33	14
					BUSHING: insulator (P/N 1878506)	EA		4	*	*	*	*	33	15
9	PL	H		2920-378-0420	CONTACT (P/N 1878493)	EA		2			*	*	33	16
					SCREW: machine (P/N AN520-10-9)	EA		3	AR	AR	AR	AR	33	17
					CLAMP: terminal (P/N 1878503)	EA		3	*	*	*	*	33	18
					GROMMET (P/N 1879663)	EA		3	*	*	*	*	33	19
					GEAR COVER GROUP	EA		1					34	
					PIN: straight headless (P/N PA-291)	EA		2	*	*	*	*	34	1
					SPACER (P/N WE-243-1)	EA		1	*	*	*	*	34	2
9	PL	H		2805-536-8818	GASKET (P/N QD-633)	EA		1			*	*	34	3
9	PL	H		2805-428-2161	GASKET (P/N QD-634)	EA		1			*	*	34	4
					BOLT: machine (P/N AN65-5-12)	EA		10	AR	AR	AR	AR	34	5
					WASHER: lock (P/N AN935-516)	EA		10	AR	AR	AR	AR	34	6
					PLUG: timing hole (P/N PF-25)	EA		1	*	*	*	*	34	7
					BUTTON: thrust (P/N PF-52)	EA		1	*	*	*	*	34	8

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS		
SOURCE MAINT. & RECOVER- ABILITY CODE				FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)	
MAT CODE	SOURCE	MAINT LEVEL	RECOVER ABILITY						2ND ECHELON	3RD ECHELON	4TH ECHELON				
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) OIL PUMP ASSEMBLY															
9	P1	H		5330-579-3545	SEAL: oil (P/N PH-269)	EA		1			*	*	34	9	
					COVER (P/N ED-101)	EA		1	*	*	*	*	34	10	
					OIL PUMP ASSEMBLY (P/N K-95-D)	EA		1	*	*	*	*	35		
					NUT: hex (P/N PD-195)	EA		1	*	*	*	*	35	1	
					GEAR: drive (P/N GD-94-C)	EA		1	*	*	*	*	35	2	
					SCREW: machine (P/N AN520-10-8)	EA		6	AR	AR	AR	AR	35	3	
					WASHER: lock (P/N AN935-10)	EA		6	AR	AR	AR	AR	35	4	
9	P1	H		2805-332-3722	SCREEN (P/N RD-112)	EA		1			*	*	35	5	
					SCREW: machine (P/N AN520-10-6)	EA		1	AR	AR	AR	AR	35	6	
					WASHER: lock (P/N AN935-10)	EA		1	AR	AR	AR	AR	35	7	
					PIN: cotter (P/N AN381-4-16)	EA		1	AR	AR	AR	AR	35	8	
9	P1	H		2805-253-6919	SPRING (P/N PM-111)	EA		1			*	*	35	9	
9	P1	H		3110-100-6151	BALL: bearing (P/N ME-60)	EA		1			*	*	35	10	
					COVER (P/N KB-42)	EA		1	*	*	*	*	35	11	
9	P1	H		2805-443-3433	GASKET (P/N QD-53)	EA		1			*	*	35	12	

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS						
SOURCE MAINT. & RECOVER- ABILITY CODE									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY											2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) CRANKSHAFT, PISTON AND CONNECTING ROD GROUP																			
					GEAR: spur (P/N KC-56-2)	EA		1	*	*	*	*		35	13				
					PIN: straight headless (P/N PA-64)	EA		1	*	*	*	*		35	14				
					GEAR: spur (P/N KC-56-1)	EA		1	*	*	*	*		35	15				
					SHAFT: drive (P/N KD-121)	EA		1	*	*	*	*		35	16				
					STUB SHAFT (P/N KD-122)	EA		1	*	*	*	*		35	17				
					BODY (P/N KA-61A-1)	EA		1	*	*	*	*		35	13				
					CRANKSHAFT, PISTON AND CONNECTING ROD GROUP	EA		1						36					
					RING: composition, std (P/N MS13933-7)	EA		4	AR	AR	AR	AR		36	1				
9	PI	H		2805-554-3950	RING: composition, 1020 (P/N MS13933-8) (Use as necessary)	EA		4			AR	AR		36	1				
9	PI	H		2805-554-3952	RING: composition, 1040 (P/N MS13933-9) (Use as necessary)	EA		4			AR	AR		36	1				
					RING: composition, std (P/N MS13932-7)	EA		4	AR	AR	AR	AR		36	2				
	PI	H		2805-554-3954	RING: composition, .020 (P/N MS13932-8) (Use as necessary)	EA		4			AR	AR		36	2				
	PI	H		2805-554-3953	RING: composition, .040 (P/N MS13932-9) (Use as necessary)	EA		4			AR	AR		36	2				
					RING: oil, std (P/N MS13931-10)	EA		9	AR	AR	AR	AR		36	3				
	PI	H		2805-554-3956	RING: oil, .020 (P/N MS13931-11) (Use as necessary)	EA		9			AR	AR		36	3				

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUSTRATIONS	
SOURCE MAINT. & RECOVER-ABILITY CODE				FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVER-ABILITY						2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) CRANKSHAFT, PISTON AND CONNECTING ROD GROUP (CONTINUED)														
P1	H			2805-554-3955	RING: oil, .040 (P/N MSL3931-12) (Use as necessary)	EA		8			AR	AR	36	3
P1	H			2805-554-9255	PISTON ASSEMBLY: std (P/N MSL3957-1)	EA		4			AR	AR	36	4
P1	H			2805-554-9822	PISTON ASSEMBLY: 1020 outside (P/N MSL3957-2) (Use as necessary)	EA		4			AR	AR	36	4
P1	H			2805-540-5299	PISTON ASSEMBLY: .040 outside (P/N MSL3957-3) (Use as necessary)	EA		4			AR	AR	36	4
					RING: retaining (P/N MSL3962-1)	EA		8	AR	AR	AR	AR	36	5
					PIN: piston (P/N MSL3996-6)	EA		4	AR	AR	AR	AR	36	6
					NUT: stamped (P/N AN356-624)	EA		8	AR	AR	AR	AR	36	7
					NUT: hex. (P/N AN345-616)	EA		8	AF	AR	AR	AR	36	8
					BOLT: machine (P/N FB-146-1)	EA		8	*	*	*	*	36	9
P1	H			2805-374-9738	BEARING: rod (P/N MSL3993-1)	EA		8			AR	AR	36	10
P1	H			2805-386-3257	BEARING: piston pin (P/N MSL3963-1)	EA		4			AR	AR	36	11
P1	H			2805-624-9951	ROD: connecting (P/N DA-66A-4)	EA		4			*	*	36	12
					CRANK: starting (P/N U230-B)	EA		1	*	*	*	*	36	13
					PIN: straight headless (P/N PA-334)	EA		1	*	*	*	*	36	14
					NUT: hex (P/N PD-157)	EA		1	*	*	*	*	36	15

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUSTRATIONS						
SOURCE MAINT. & RECOVER. ABILITY CODE									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 6TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL	RECOVER ABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) CRANKSHAFT, PISTON AND CONNECTING ROD GROUP (CONTINUED)																			
					WASHER: lock (P/N PE-65-1)	EA		1	*	*	*	*		36	16				
					PULLEY: drive (P/N MD-285)	EA		1	*	*	*	*		36	17				
					BOLT: machine (P/N AN65-8-12)	EA		6	AR	AR	AR	AR		36	18				
					WASHER: lock (P/N AN935-816)	EA		6	AR	AR	AR	AR		36	19				
					FLYWHEEL ASSEMBLY (P/N NC-146-C2-S1)	EA		1	*	*	*	*		36	20				
					KEY: woodruff, #29 (P/N PL24)	EA		1	*	*	*	*		36	21				
					BOLT: machine (P/N AN65-6-12)	EA		6	AR	AR	AR	AR		36	22				
					WASHER: lock (P/N PE-5-41)	EA		6	*	*	*	*		36	23				
9	PL	H		2805-383-3549	OIL SEAL (P/N PH-202)	EA		1			*	*		36	24				
					PLATE: bearing (P/N BG-193A)	EA		1	*	*	*	*		36	25				
9	PL	H		2805-600-7101	GASKET (P/N QD-636-A)	EA		2			*	*		36	26				
9	PL	H		5340-584-1613	SHIM (P/N QF-67-C)	EA		2			*	*		36	27				
9	PL	H		5340-584-1612	SHIM (P/N QF-67-B)	EA		2			*	*		36	28				
9	PL	H		2805-353-5912	SLINGER: oil (P/N RK-173)	EA		1			*	*		36	29				
					GEAR (P/N GA-35A-1)	EA		1	*	*	*	*		36	30				

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUSTRATIONS				
SOURCE MAINT. & RECOVERABILITY CODE				FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS BTH ECHELON	FIG NO. (A)	ITEM NO. (B)			
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						2ND ECHELON	3RD ECHELON	4TH ECHELON						
					SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) PUMP												
					KEY: woodruff (P/N PL-49)	EA		1	*	*	*	*	36	31			
					CUP: bearing (P/N 453A)	EA		2	*	*	*	*	36	32			
					CONE: bearing (P/N 455S)	EA		2	*	*	*	*	36	33			
P1 H			2805-992-0578		CRANKSHAFT (P/N CA-69D-4)	EA		1			*	*	36	34			
					TUBE (P/N 803-04035)	EA		1	*	*	*	*	37	1			
					FITTING: tube (P/N 4-4-CBIX-5)	EA		2	*	*	*	*	37	2			
					CAP: end (P/N 035-18438)	EA		1	*	*	*	*	37	3			
					SCREW: socket head cap	EA		20	*	*	*	*	37	4			
P1 F			4320-631-4047		GASKET: cap (P/N 035-18437)	EA		1		*	*	*	37	5			
					SCREW: socket head cap	EA		4	*	*	*	*	37	6			
					SCREW: socket head cap	EA		4	*	*	*	*	37	7			
					SCREW: socket head cap	EA		4	*	*	*	*	37	8			
					CAP: control	EA		1					37	9			
					BODY ASSEMBLY: stop	EA		1					37	10			
P1 F			4935-886-0312		GASKET (P/N 035-12279)	EA		2		*	*	*	37	12			

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS		
MAY CODE	SOURCE	MAINT LEVEL						RECOVER- ABILITY	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
									2ND ECHELON	3RD ECHELON	4TH ECHELON			
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) PUMP (CONTINUED)										
				HOUSING ASSEMBLY: hanger	EA		1					37	13	
				SCREW: socket head cap	EA		2	*	*	*	*	37	14	
				SCREW: socket head cap	EA		4	*	*	*	*	37	15	
P1	H	5310-271-7442		GASKET (P/N 035-22733)	EA		6			*	*	37	16	
P1	H	1450-815-1373		PLATE: creep (P/N 035-14074)	EA		1			*	*	37	17	
				RETAINER: piston & show asy (P/N 25-1523)	EA		1	*	*	*	*	37	18	
				RETAINER (P/N 035-11826)	EA		1	*	*	*	*	37	19	
P1	H	2905-992-0574		PISTON AND SHOW ASSEMBLY (P/N 25-1525)	EA		1			*	*	37	20	
P1	H	3110-992-0547		BALL (P/N 201-24001)	EA		1			*	*	37	21	
P1	H	4320-631-0146		SOCKET: spring (P/N 035-13342)	EA		1			*	*	37	22	
P1	H	4320-712-4640		SPRING (P/N 035-22174)	EA		1			*	*	37	23	
				RETAINER: spring (P/N 035-11818)	EA		1	*	*	*	*	37	24	
				PIN: retainer (P/N 035-12481)	EA		1	*	*	*	*	37	25	
P1	H	2805-992-0572		BEARING AND BARREL ASSEMBLY (P/N 015-00113)	FA		1			*	*	37	26	
				BARREL: cylinder (P/N 035-11816)	EA		1	*	*	*	*	37	27	

(1) SOURCE MAINT. & RECOVERY ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS		
MAT CODE	SOURCE MAINT LEVEL	RECOVER ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)	
								2ND ECHELON	3RD ECHELON	4TH ECHELON				
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) PUMP (CONTINUED)										
P1	H		4920-511-3335	SCREW: socket head cap	EA		7	*	*	*	*	37	28	
				BEARING (P/N 035-11897)	EA		1	*	*	*	*	37	29	
P1	H		4920-511-3335	GASKET (P/N 035-11899)	EA		2			*	*	37	30	
				PLATE: port (P/N 035-18543)	EA		1	*	*	*	*	37	31	
				PIN: dowel (P/N 324-21208)	EA		1	*	*	*	*	37	32	
				PLUG: pipe, socket	EA		5	*	*	*	*	37	33	
				BODY: pump (P/N 035-11811)	EA		1	*	*	*	*	37	34	
				SCREW: socket head cap	EA		6	*	*	*	*	37	35	
P1	F		5330-054-6390	PACKING: preformed (P/N AN6320B32)	EA		1		AR	AR	AR	37	36	
				FLANGE: suction (P/N 535-19425)	EA		1	*	*	*	*	37	37	
				SCREW: socket head cap	EA		4	*	*	*	*	37	38	
				FLANGE: pressure (P/N 035-19246)	EA		1	*	*	*	*	37	39	
				SCREW: socket head cap	EA		4	*	*	*	*	37	40	
P1	H		5330-576-9732	PACKING: preformed (P/N MS28775-226)	EA		2			AR	AR	37	41	
				RETAINER: seal (P/N 035-21934)	EA		1	*	*	*	*	37	42	

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
MAT CODE	SOURCE	MAINT LEVEL RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
								2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II. GROUP ASSEMBLY PARTS LIST (CONTINUED) PRESSURE COMPENSATOR CONTROL													
				SCREW: socket head cap	EA		6	*	*	*	*	37	43
P1	H		4920-775-4921	SEAL (P/N 10402)	EA		1			*	*	37	44
P	F		5330-815-1712	PACKING: preformed (P/N MS28775-236)	EA		1		AR	AR	AR	37	45
P1	H	R	2805-992-0571	SHAFT ASSEMBLY (P/N 015-02556)	EA		1			*	*	37	46
				NUT: lock (P/N 035-17681)	EA		1	*	*	*	*	37	47
				WASHER: lock (P/N 350-01010)	EA		1	*	*	*	*	37	48
P1	H		3110-992-0527	BEARING: ball (P/N 20210BX1A)	EA		2			*	*	37	49
				SPACERS: matched set (P/N 015-99889)	EA		1	*	*	*	*	37	50
				SHAFT AND SLEEVE ASSEMBLY (P/N 25-3466)	EA		1	*	*	*	*	37	51
				BLOCK: port (P/N 535-11812)	EA		1	*	*	*	*	37	52
				STOP: spool (P/N 035-12562)	EA		1	*	*	*	*	38	1
P1	F		5330-808-0794	PACKING: preformed (P/N AN6290-8)	EA		1		AR	AR	AR	38	2
				RING: retaining (P/N 364-15885)	EA		1	*	*	*	*	38	3
P1	F		5330-584-0265	PACKING: preformed (P/N MS28775-10)	EA		1		AR	AR	AR	38	4
				SLEEVE (P/N 035-13981)	EA		1	*	*	*	*	38	5

(1)			(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS- STRATIONS	
SOURCE MAINT. & RECOVER- ABILITY CODE			FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL						2ND ECHOLON	3RD ECHOLON	4TH ECHOLON			
				SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) PRESSURE COMPENSATOR CONTROL (CONTINUED)									
				PISTON (P/N 035-13973)	EA		1	*	*	*	*	38	6
				SPRING (P/N 035-22051)	EA		1	*	*	*	*	33	7
				RETAINER (P/N 035-13976)	EA		1	*	*	*	*	33	3
				WASHER: lock, internal (P/N 1223)	EA		1	*	*	*	*	38	9
				PACKING: preformed (P/N AN6227-7)	EA		1	AR	AR	AR	AR	33	10
				PISTON: seal (P/N 035-11712)	EA		1	*	*	*	*	33	11
P1	F	4320-779-0200		SPRING (P/N 035-12289)	EA		1		*	*	*	38	12
P1	F	2805-992-0570		SUPPORT: ball (P/N 035-11697Z)	EA		1		*	*	*	33	13
P1	F	3110-992-0546		BALL (P/N 201-08801)	EA		1		*	*	*	33	14
				HOUSING: adjustment (P/N 035-12555)	EA		1	*	*	*	*	33	15
P1	F	5330-613-0801		PACKING: preformed (P/N MS28775-114)	EA		1		AR	AR	AR	33	16
				PISTON (P/N 035-13973)	EA		1	*	*	*	*	38	17
				RING: retaining (P/N 356-15885)	EA		1	*	*	*	*	33	13
				SLEEVE (P/N 035-13982)	EA		1	*	*	*	*	38	19
				PACKING: preformed (P/N AN6227-7)	EA		1	AR	AR	AR	AR	33	20

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUS-TRATIONS					
SOURCE MAINT. & RECOVER-ABILITY CODE			FEDERAL STOCK NUMBER						DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHOLON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL											RECOVER-ABILITY	2ND ECHOLON	3RD ECHOLON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) HANGER HOUSING ASSEMBLY																		
P1 F				0110-931-8857	BEARING: ball (P/N MO-10-N)	EA		1		*	*	*		39	36			
					PIN: dowel (P/N 324-24048)	EA		1	*	*	*	*		38	37			
					BEARING: ball (P/N M-10-N)	EA		1	*	*	*	*		38	38			
					CLEVIS (P/N 035-15821)	EA		1	*	*	*	*		38	39			
					LINK: indicator (P/N 035-14391)	EA		1	*	*	*	*		39	1			
					SCREW: socket head cap	EA		1	*	*	*	*		39	2			
					INDICATOR (P/N 035-12871)	EA		1	*	*	*	*		39	3			
					PIN: 1/8 x 3/4, type A	EA		1	*	*	*	*		39	4			
					PLATE: indicator (P/N 035-12870)	EA		1	*	*	*	*		39	5			
					SCREW (P/N AN515-10-6)	EA		3	AR	AR	AR	AR		39	6			
					SHAFT: indicator (P/N 035-12956)	EA		1	*	*	*	*		39	7			
					PACKING: preformed (P/N AN6227-7)	EA		1	AR	AR	AR	AR		39	8			
					PLATE: end (P/N 035-12610)	EA		2	*	*	*	*		39	9			
					SCREW: socket head cap	EA		8	*	*	*	*		39	10			
P1 H				4935-886-0320	GASKET (P/N 035-15090)	EA		2			*	*		39	11			

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES					ILLUSTRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO.	ITEM NO.	
									2ND ECHELON	3RD ECHELON	4TH ECHELON				(A)
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) HANGER HOUSING ASSEMBLY (CONTINUED)															
					PIN: trunnion (P/N 035-12955)	EA		2	*	*	*	*		39	12
9	FL	H		5330-292-0570	PACKING: preformed (P/N AN6227-15)	EA		2			AR	AR		39	13
					SPACER: trunnion (P/N 035-12958)	EA		2	*	*	*	*		39	14
					PLATE: index (P/N 035-15206)	EA		1	*	*	*	*		39	15
					SCREW: socket head cap	EA		1	*	*	*	*		39	16
					PIN: dowel (P/N 324-21610)	EA		2	*	*	*	*		39	17
					BOLT (P/N AN65-6-10)	EA		1	AR	AR	AR	AR		39	18
					SETSCREW (P/N AN565D816H14)	EA		1	AR	AR	AR	AR		39	19
					PIN: operating (P/N 035-14857)	EA		1	*	*	*	*		39	20
					SETSCREW	EA		1	*	*	*	*		39	21
	PI	H		2505-992-0592	BEARING: needle (P/N NC162416)	EA		2			*	*		39	22
					HANGER (P/N 035-15205)	EA		1	*	*	*	*		39	23
					PLUG (P/N AN913-6D)	EA		1	AR	AR	AR	AR		39	24
					PLUG: pipe, socket	EA		1	*	*	*	*		39	25
					HOUSING: hanger (P/N 035-12951)	EA		1	*	*	*	*		39	26

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS		
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO.	ITEM NO.	
									2ND ECHELON	3RD ECHELON	4TH ECHELON		(A)	(B)	
<p>SECTION II - <u>GROUP ASSEMBLY PARTS LIST (CONTINUED)</u> <u>REQUISITION BY PART NUMBER. ITEMS NOT ASSIGNED FSN.</u></p>															
					PART NUMBER										
					AN345B516	NUT									
					AM6 227-8	PACKING									
					A230-2-3229	RING, SHOCK MOUNT									
					A280-2-3332A	TUBING									
					A230-3207	GASKET									
					A280-3217	BUSHING									
					A280-4-3223	HOSE ASSEMBLY, HYDRAULIC									
					A280-4-3224	HOSE ASSEMBLY									
					A230-4-3225	HOSE ASSEMBLY, HYDRAULIC									
					A361-112-2	BODY									
					A361-112-3	POPPET									
					A361-112-4	RETAINER									
					A361-112-5	SPRING									
					A361-117-2	BODY									
					A361-117-3	STEM									
					A426-1600	DOOR STOP ASSEMBLY									
					A426-1703	PAD AND STRAP									
					A426-1713	PIPE									
					A426-1719	ELBOW									
					A426-1809	TRAY ASSEMBLY									
					A426-3253	HANDLE									
					ED-101-S1	COVER ASSEMBLY									
					EG-193A-S1	PLATE ASSEMBLY									
					EG-223	PLATE, RETAINER									
					C-21P	CARTRIDGE									
					CA-63D-4-S1	CRANKSHAFT ASSEMBLY									
					CZ2563	HUB ASSEMBLY									

(1)				(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES					ILLUSTRATIONS					
SOURCE MAINT. & RECOVERABILITY CODE									FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR RESULT OF 100 EQUIPMENTS 8TH ECHELON	FIG NO.	ITEM NO.
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON		(A)	(B)
SECTION II - GROUP ASSEMBLY PARTS LIST (CONTINUED) REQUISITION BY PART NUMBER. ITEMS NOT ASSIGNED FSN. (CONTINUED)																			
					PART NUMBER														
					C106-436-24														
					DA-66A-4-S1														
					DR-25														
					DR-25-S20														
					DR-25-S40														
					EBB-45A														
					GC-23														
					GH-43														
					HF-454														
					KA-61A-1-S1														
					KP-42-S2														
					KD-121-S1														
					LJ-3COM														
					LK-3														
					LL-120														
					MS-33														
					MS24322-5A6														
					MS24325-1														
					MS24323-1														
					MS23740-16														
					MS23740-4														
					MS22741-16-1200														
					MS23759-12-1200														
					MS22759-8-1200														
					MS23760-12														
					MS23760-2														
					MS35643-32														

(1) SOURCE MAINT. & RECOVERABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUSTRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVERABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
									2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) REQUISITION BY PART NUMBER. ITEMS NOT ASSIGNED FSN. (CONTINUED)														
					PART NUMBER	ITEM NAME								
					MZ-2001-LS	HOUSING AND FIELD ASSEMBLY								
					MZ-2012ES	BRUSH SET								
					MC-146-C2	FLYWHEEL								
					OW-352	SCREEN								
					OW-361	COVER								
					OW-363	BOWL								
					OW-432	COCK								
					OW-446	CLAMP WIRE AND STUD								
					OW-447	CLAMP ASSEMBLY								
					OW-462	THUMB NUT AND CUP								
					PB-24	BOLT								
					PC-112	STUD								
					PC-396	STUD								
					PC-429	STUD								
					PF-18	PLUG, PIPE								
					PG-512	BAND								
					PH-245	WASHER, CORK								
					PJ-105	STUD, GEAR								
					QD-595-A	GASKET								
					QD-616	GASKET								
					QO653	GASKET								
					RC-91	SCREEN, OIL								
					RF-270	ELBOW, 90 DEGREE								
					RF-270-4	ELBOW, RESTRICTED, 90 DEGREE								
					RK-181	PLATE, SPLASH								
					SA-65-A	PAD, COVER								
					SE-126	SHROUD								

(1) SOURCE MAINT. & RECOVER- ABILITY CODE				(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
MAT CODE	SOURCE	MAINT LEVEL	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 5TH ECHELON	FIG NO. (A)	ITEM NO. (B)
									2ND ECHELON	3RD ECHELON	4TH ECHELON			
SECTION II GROUP ASSEMBLY PARTS LIST (CONTINUED) REQUISITION BY PART NUMBER. ITEMS NOT ASSIGNED FSN. (CONTINUED)														
					PART NUMBER						ITEM NAME			
					JA-112A-S						DRIVE SHAFT ASSEMBLY			
					TE155-S4-12D						COUPLING HALF			
					TE155-S4-8D						COUPLING HALF			
					TC-343A-S1						SLEEVE AND BEARING ASSEMBLY			
					TC-363B-2-S1						HOUSING ASSEMBLY			
					TF-36-4						ADAPTER AND PRIMER ASSEMBLY			
					TT-61F-3						CONTROL ASSEMBLY			
					TT-54H-1						GOVERNOR ASSEMBLY			
					X-179						STRIP			
					XE-17						SETScrew			
					XE-3						SPARK PLUG			
					XE-7-A						PLUG			
					06137						BOWL			
					102153						STRAP			
					1046-3						BALL			
					111-161						HOSE			
					111-4-L						HOSE			
					112-12						HOSE			
					112-4						HOSE			
					11332A						GASKET			
					11562						SPACER			
					11562						GASKET, COVER			
					11563						SPRING			
					11634						PLUG, DRAIN			
					11634						NUT, SQUARE			
					149-S1-16D						COUPLING HALF			
					150-S9-12D						CAP, SEAL			

(1)			(2)	(3)	(4)	(5)	(6)	(7) ALLOWANCES				ILLUSTRATIONS						
SOURCE MAINT. & RECOVERABILITY CODE								FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY INC IN UNIT	15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP			QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)	ITEM NO. (B)
MAT CODE	SOURCE	MAINT LEVEL RECOVERABILITY											2ND ECHELON	3RD ECHELON	4TH ECHELON			
<p>SECTION II <u>GROUP ASSEMBLY PARTS LIST (CONTINUED)</u> <u>REQUISITION BY PART NUMBER. ITEMS NOT ASSIGNED FSM. (CONTINUED)</u></p>																		
				PART NUMBER	ITEM NAME													
				150-S9-3D	CAP, SEAL													
				155-SL-12D	COUPLING HALF													
				155-S1-3D	COUPLING HALF													
				155S5-12D	NUT, UNION													
				155S5-3D	NUT, UNION													
				15900	HANDLE													
				15900-1	HANDLE, VALVE													
				1672-17	PIN													
				1900PM-FFG-1/4	VALVE, NEEDLE													
				2-1249	TUBE													
				2-1249A	TUBE ASSEMBLY													
				2-1673	HANGER ASSEMBLY													
				2397-4A	CATCH ASSEMBLY													
				25-5871	CONTROL													
				275-2	GROMMET													
				29-914	GROMMET													
				313-12	CONNECTOR													
				313-4	CONNECTOR													
				4-699	AXLE AND BRAKE ASSEMBLY													
				4-699-1	AXLE AND BRAKE ASSEMBLY													
				400-11	WASHER													
				400-210	WASHER													
				407-19	NUT, WING													
				4091-2	COUPLING													
				4099	PUSHROD													
				409-121	NUT													
				4095	POST													

(1) SOURCE MAINT. & RECOVER- ABILITY CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) EXPENDABILITY	(6) QTY INC IN UNIT	(7) ALLOWANCES				ILLUS- STRATIONS	
MAT CODE	SOURCE MAINT LEVEL	RECOVER- ABILITY						15 DAYS MAINTENANCE ALLOWANCE PER 100 EQUIP	2ND ECHELON	3RD ECHELON	4TH ECHELON	QUANTITY RECOMMENDED FOR REBUILD OF 100 EQUIPMENTS 8TH ECHELON	FIG NO. (A)
SECTION II													
<u>GROUP ASSEMBLY PARTS LIST (CONTINUED)</u>													
<u>REQUISITION BY PART NUMBER. ITEMS NOT ASSIGNED FSN. (CONTINUED)</u>													
			PART NUMBER	ITEM NAME									
			4200A	LEVEL ASSEMBLY									
			4205	LOCKNUT									
			4413	BULLET									
			4414	PUSHROD									
			4415	SCREW									
			4723	LOCKNUT									
			5100-S10	CHAIN ASSEMBLY									
			5121	HANDLE									
			5241	COVER ASSEMBLY									
			5310	BODY, FILTER									
			5666-3	CLAMP ASSEMBLY									
			569412	FILTER									
			5817	BODY									
			5818	STEM									
			5819	KNOB									
			671-173-16	STRIP									
			671-173-255	STRIP									
			72-F	CONNECTOR									
			9510	GROMMET									

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
A-552	16954	2940-799-7687	AIR CLEANER	11-14
AA-90A-2	66289		CYLINDER BLOCK	26-13
AA-90A-2-81	66289		CYLINDER BLOCK ASSEMBLY	26
AA1108-1	70417		BEARING	14-62
AA1154-1	70417	3120-586-4514	BEARING	14-61
AA1339-2	70417	2805-992-0585	BEARING	14-78
AB-7B-2-81	66289		HEAD ASSEMBLY	24-3
AD-42A	66289	2805-574-8856	GUIDE	26-12
AF-49A	66289		SPRING	26-9
AG-30	66289		SEAT SPRING	26-8
AKT-5A-1	82386	4920-710-6669	TEST STAND	1
AK101008			BOLT	17-16
AK101208			BOLT	18-11
AK121503			NUT	
AK280-505			KEY	20-16
AK280H204			KEY, WOODRUFF	
AK280H404			KEY	29-35
AK280H405	21387	5315-012-4545	KEY	19-19, 21-28
AK3027-3	88044	5930-655-1582	SWITCH	10-1
AK320-16			NUT	14-43
AK325-10			NUT	
AK325-5			NUT, HEXAGON	
AK325-6			NUT	14-32
AK325-8			NUT	14-30
AK325B5			NUT	20-30
AK330-10			NUT	14-16
AK335-10			NUT	14-71
AK335-4			NUT	17-10, 17-19, 17-29, 18-9
AK335-5			NUT	14-6, 16-15
AK335-6			NUT	14-80, 17-3, 29-9
AK335-8			NUT	18-13
AK340-416			NUT	24-10, 32-45, 32-51
AK340-6			NUT	16-6, 19-8, 21-3, 32-11
AK340-8			NUT	32-32
AK345-10			NUT	17-14, 17-35, 29-28, 30-6
AK345-516			NUT	15-3
AK345-616			NUT	14-67, 36-8
AK345B516			NUT	
AK350-1032			NUT	13-8
AK356-624			NUT	36-7
AK364-832			NUT	32-9
AK365-420			NUT	32-1, 32-14
AK365-6-18			NUT	14-20
AK380-2-3			PIN	14-1
AK380-4-4			PIN	15-10, 15-14
AK380-4-6			PIN	14-15
AK380-4-7			PIN	14-42
AK381-2-8			PIN	29-3, 29-19
AK381-4-16			PIN, COTTER	35-8
AK385A2 P10			PIN	29-42
AK500A10-18			SCREW, MACHINE	
AK500C8-5			SCREW	25-24
AK5000AC8-12			SCREW	25-14
AK501-416-7			SCREW	16-2
AK501A-10-8			SCREW	20-25

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
AN501AC10-10			SCREW	21-10
AN501AC10-18			SCREW	21-11
AN504-6-4			SCREW	
AN505-10-8			SCREW	9-7
AN505-8-6			SCREW	20-3
AN507C832-6			SCREW	21-20
AN508-6-6			SCREW	21-18
AN510-10-8			SCREW	32-25, 32-69
AN510C10-12			SCREW	
AN515-10-6			SCREW	39-6
AN515-3-6			SCREW	33-11
AN515-416-10			SCREW	17-26
AN515-416-12			SCREW	9-30
AN515-416-16			SCREW	17-12
AN515-416-28			SCREW	
AN515-416-48			BOLT, MACHINE	
AN515-6-4			SCREW	19-10
AN515-6-5			SCREW	33-7
AN515-6-6			SCREW	21-2
AN515-6-7			SCREW	19-6
AN515-6-8			SCREW	21-5
AN515-8-12			SCREW	32-38
AN515-8-8			SCREW	32-34
AN515C416-16			SCREW	23-2
AN515C416-40			SCREW	
AN515C416-6			SCREW	23-8
AN515C5-4			SCREW	29-7
AN515UB8-5			SCREW	32-40
AN520-10-20			SCREW	
AN520-10-6			SCREW	20-22, 35-6
AN520-10-8			SCREW	9-5, 33-17, 35-3
AN520C10-12			SCREW	
AN520C10-14			SCREW	
AN520UB10-6			SCREW	17-37
AN526-1032-6			SCREW	
AN526-632-5			SCREW	16-8
AN526-832-6			SCREW	
AN530-4-4			SCREW	23-5
AN530C8-8			SCREW	29-13
AN535-6-4			SCREW, TAPPING	
AN535-614			SCREW, TAPPING	
AN565A51686			SETScrew	
AN565D885			SETScrew	32-19
AN565D816814			SETScrew	39-19
AN60-6-6			BOLT	14-34
AN6227-10		5330-350-9013	PACKING	
AN6227-15		5330-292-0570	PACKING	39-13
AN6227-19		5330-196-5382	PACKING	38-28
AN6227-26		5330-198-6187	PACKING	
AN6227-69		5330-197-9611	PACKING	13-7, 13-30
AN6227-7			PACKING	38-10, 38-20, 39-8
AN6227-8	88144	5330-050-1211	PACKING	
AN6230-14	45681	5330-815-1712	PACKING	13-25, 37-45
AN6230-3		5330-297-6290	PACKING	38-24
AN6236-3		1650-242-9425	FILTER ELEMENT	13-11
AN6237-1	88044	4330-024-9665	FILTER ELEMENT	30-9
AN6246-8			RETAINER	
AN6289-12			LOCKNUT	

NUMERICAL INDEX - PART I
SECTION III

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
AN6289-4			LOCKNUT	
AN6290-10		5330-285-9842	PACKING	13-24
AN6290-12		5330-251-8839	PACKING	
AN6290-18		5330-285-9843	PACKING	13-5,13-19
AN6290-3		5330-835-7485	PACKING	13-29
AN6290-4	98441	5330-805-2966	PACKING	13-3
AN6290-8		5330-808-0794	PACKING	38-2
AN6291-12			RETAINER	
AN6291-4			RETAINER	
AN6320B32	88044	5330-054-6890	PACKING	37-36
AN65-4-4			BOLT	17-22, 32-47, 32-53
AN65-4-5			BOLT	18-6
AN65-4-6				11-25,14-28, 17-32
AN65-5-10			BOLT	13-27,14-8, 16-18,27-23
AN65-5-12			BOLT	24-16,34-5
AN65-5-14			BOLT	26-2
AN65-5-5			BOLT	24-27,27-6
AN65-5-6			BOLT	16-10
AN65-5-7			BOLT	
AN65-6-10			BOLT	14-21, 32-61
AN65-6-12			BOLT, MACHINE	36-22
AN65-6-14			BOLT	14-83,24-1
AN65-6-24			BOLT	15-9
AN65-6-7			BOLT	
AN65-8-10			BOLT	39-18
AN65-8-12			BOLT	14-55,14-64, 36-18
AN65-8-14			BOLT	18-10
AN804-4			TEE	12-33,12-39
AN814-3			PLUG	13-28
AN815-16			UNION	13-4
AN815-4			UNION	
AN832-4			NIPPLE, TUBE	
AN833-12			ELBOW	12-29
AN833-16			ELBOW	12-25,13-18
AN833-4			ELBOW	12-27,12-43, 13-2
AN834-12			TEE	12-10
AN834-16			TEE	30-16
AN834-4			TEE	12-34,12-41
AN837-12			ELBOW	
AN813-6D			PLUG	39-24
AN819-20			REDUCER	
AN824-16			LOCKNUT	13-17
AN824-4			LOCKNUT	13-1
AN824-48			CAP ASSEMBLY	9-26
AN829-48			CAP ASSEMBLY	9-24
AN831-8-13			BONNET	14-24
AN835-10			WASHER	17-15,17-36, 20-2,20-26, 29-30,38-4, 35-7
AN835-1016			WASHER	14-72,18-26

SECTION III
 NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
AN935-416			WASHER	9-18,13-14, 14-29,17-11, 17-20,17-27, 17-30,18-8, 23-3, 23-10, 23-14,24-9, 27-10,32-46, 32-52
AN935-51			WASHER	19-7
AN935-516			WASHER	14-7,20-31, 24-17,27-7, 34-6
AN935-516L			WASHER	13-22,16-12, 16-16
AN935-6			WASHER	21-4
AN935-61			WASHER	21-19, 33-8
AN935-616			WASHER	14-33,14-68, 14-81,15-8, 17-4,29-10, 32-62
AN935-716			WASHER	24-22
AN935-8			WASHER	21-15,32-12, 32-33,32-39, 32-41
AN935-816			WASHER	14-31,14-56, 14-65,18-12, 36-19
AN936A6			WASHER	16-7
AN936A716			WASHER, LOCK	
AN936B10			WASHER	30-7
AN936B516			WASHER	27-24,30-14
AN936B616			WASHER	
AN945-4P			WASHER	17-21,17-31, 18-7
AN945-5P			WASHER	
AN945-6			WASHER	24-2
AN960-10L			WASHER	32-68
AN960-1016			WASHER	14-73
AN960-516			WASHER	15-13,24-28
AN960-616			WASHER	14-82,15-15
AN960-8			WASHER	
AN960-816			WASHER	18-11
AN960B416			WASHER	32-4,32-17
AN960B516			WASHER	20-32,26-3
AN960C516			WASHER	29-20
A1133-2	12204	3120-489-4244	BEARING	14-62
A2492A	21387		WASHER	21-32
A2492C	21387		WASHER	21-34,21-44
A2568	21387		PIN	21-27
A2572	21387		BUSHING	21-24
A280-2-3071-1	82386		CONTROL ASSEMBLY	9-29
A280-2-3206			VALVE ASSEMBLY	9-12
A280-2-3221		4920-793-0667	VALVE ASSEMBLY	
A280-2-3229	82386		RING, SHOCK MOUNT	
A280-2-3300		4720-990-9014	HOSE ASSEMBLY	12-37
A280-2-3302	82386	4720-990-9011	HOSE ASSEMBLY	12-44
A280-2-3304A	82386		TUBING	12-36
A280-2-3306A	82386		TUBING	12-32
A280-2-3308A	82386		TUBING	12-38
A280-2-3310A	82386		TUBING	12-42

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
A280-2-3312A	82386		TUBING	12-40
A280-2-3314A	82386		TUBING	12-45
A280-2-3316A	82386		TUBING	12-30
A280-2-3318A	82386		TUBING	12-31
A280-2-3320A	82386		TUBING	12-35
A280-2-3322	82386		TUBING	12-17
A280-2-3328A	82386		TUBING	12-46
A280-2-3332A	82386		TUBING	12-19
A280-2-3334A			TUBING	12-13
A280-2-3336	82386		TUBING	12-11
A280-2-3348A	82386		TUBING	12-21
A280-2-3350A	82386		TUBING	12-6
A280-3005	82386	4820-783-6670	VALVE	12-23
A280-3014	82386	6620-783-6614	GAGE	9-6
A280-3016	82386	6685-783-6616	GAGE	9-4
A280-3028A			COVER ASSEMBLY	30-11
A280-3029-1 A	82386		COVER ASSEMBLY	30-5
A280-3030A	82386		COVER ASSEMBLY	30-1
A280-3207	82386	5330-991-8569	GASKET	
A280-3217	82386		BUSHING	
A280-3219			TEE	12-24
A280-3227A	82386		COVER ASSEMBLY	30-8
A280-3231			ELBOW 90 DEGREE	
A280-4-3001	82386	4320-787-2586	PUMP	12-1
A280-4-3006	82386		RESERVOIR	30-17
A280-4-3068			MANIFOLD	13-20
A280-4-3210			VALVE ASSEMBLY	
A280-4-3216	82386		FILTER AND MANIFOLD ASSEMBLY	12-47
A280-4-3220	82386		FILTER ASSEMBLY	12-9
A280-4-3222			PLATE, NAME, HYDRAULIC CIRCUIT SCHEMATIC	
A280-4-3223	82386	4720-793-0558	HOSE ASSEMBLY, HYDRAULIC	
A280-4-3224	82386	4920-790-8109	HOSE ASSEMBLY	
A280-4-3225	82386	4920-790-8108	HOSE ASSEMBLY, HYDRAULIC	
A280-4-4000	82386		HYDRAULIC SYSTEM	12
A280-5006	51240	6680-786-9283	INSTALLATION	
A280-7-3211	82386		TRANSMITTER	30-12
A300-5079		6685-704-0845	HOUSING	13-31
A361-100		4920-793-0645	GAGE	9-28
A361-100-10		4920-991-6999	VALVE	9-17
A361-100-11		2805-992-0588	PLUNGER	
A361-100-12		2805-992-0589	SPRING, SPOOL	
A361-100-13			SPRING, PILOT	
A361-100-3			BEAT, INSERT	
A361-100-4		2805-992-0586	CAP, VALVE	
A361-100-5			VALVE, NEEDLE	
A361-100-6			NUT	
A361-100-8		2805-992-0587	SCREW	
A361-103-3		2805-992-0590	GUIDE, SPRING	
A361-103-4			FILTER	
A361-103-5			PIN	
A361-103-6			STEM	
A361-103-7			PLUG	
A361-103-8		2805-992-0591	RETAINER, SPRING	
A361-112-2	82386		SPRING	
A361-112-3	82386		BODY	
			POPPET	

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO	ITEM NAME	FIGURE AND INDEX NO.
A361-112-4	82386		RETAINER	
A361-112-5	82386		SPRING	
A361-117-2	82386		BODY	
A361-117-3	82386		STEM	
A361-2-100-2			BODY, VALVE	
A361-2-100-7			SEAT, SPOOL	
A361-2-100-9			SPOOL	
A361-2-103		4920-783-6857	VALVE	9-8
A361-2-103-2			BODY	
A361-2-108		4920-713-4705	DAMPENER	9-22
A361-2-112		4820-783-6678	VALVE	
A361-2-117	82386		VALVE	12-7
A4-3736-R-70	78500	2530-541-3003	BRAKE ASSEMBLY	14-66
A426-1001	82386		CLAMP	14-86
A426-1600	82386		DOOR STOP ASSEMBLY	
A426-1601	82386		SPACER	32-43
A426-1703	82386		PAD AND STRAP	
A426-1707	82386		LINER	18-14
A426-1709	82386		BOLT	17-5
A426-1717	82386		STRAP	18-15
A426-1718	82386		PIPE	
A426-1719	82386		ELBOW	
A426-1720A	82386		SUPPORT	18-5
A426-1806	82386		COVER	17-6
A426-1809	82386		TRAY ASSEMBLY	
A426-1810	82386		SUPPORT	17-13
A426-1811			TRAY	17-17
A426-2-1712A	82386		TUBING	18-1
A426-2-1713A	82386		TUBING	18-2
A426-2-1714A	82386		TUBING	18-3
A426-2-1722A	82386		TUBING	18-4
A426-2-3220	82386	4720-990-9012	HOSE ASSEMBLY	12-4
A426-2-3221	82386	4720-990-9015	HOSE ASSEMBLY	12-8
A426-2-3260A	82386		TUBING	12-14
A426-2-3261A	82386		TUBING	12-26
A426-2-3262A	82386		TUBING	12-22
A426-2-3263A	82386		TUBING	12-28
A426-2-3264A	82386		TUBING	12-12
A426-2-3265A	82386		TUBING	12-5
A426-3213			BRACKET	
A426-3250			PLATE, NAME, OUTLET 1/2 INCH	
A426-3251			PLATE, NAME, OUTLET 3/4 INCH	
A426-3253	82386		HANDLE	
A426-4-1800	82386		FRAME ASSEMBLY	14-87
A426-4-1805	82386		HOUSING ASSEMBLY	32
A426-4-3210			PANEL ASSEMBLY	
A426-4-3211A			PANEL	9-1
A426-7-3200			PANEL ASSEMBLY, CONTROL	9
A426-7-3202			PLATE, CONTROL PANEL	
BA-49A-8-81	66289		CRANKCASE ASSEMBLY	24-31
BD-101	66289		COVER	34-10
BD-101-81	66289		COVER ASSEMBLY	
BG-193A	66289		PLATE, BEARING	36-25
BG-193A-81	66289		PLATE ASSEMBLY	
BG-223	66289		PLATE, RETAINER	
BH-103	66289		COVER	26-1
BH-155-C	66289		PLATE	24-29

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
BW2563C	21387	2920-566-7395	COUPLING	21-29
B1498B	21387		RING	21-36
B448		2530-533-2650	HUB	14-51
B5963	21387		SPRING	21-30
C-21P	73370	2940-141-9025	CARTRIDGE	
CA-69 D-4	66289	2805-992-0578	CRANKSHAFT	36-34
CA-69D-4-81	66289		CRANKSHAFT ASSEMBLY	
CZ2563	21387		HUB ASSEMBLY	
C106-436-24	78553		NUT	
C1498D	21387		RING	21-35
C447	73809		CAP	14-41
C5949	21387	3110-144-8998	BEARING	21-37
DA-66A-4	66289	2805-624-9951	ROD, CONNECTING	36-12
DA-66A-4-81	66289		CONNECTING ROD ASSEMBLY	
DR-25	66289	2805-654-4274	RING SET	
DR-25-820	66289		RING SET	
DR-25-840	66289	2805-992-0576	RING SET	
D1498	21387		RING	21-38
D5949A	21387	2920-844-7154	BEARING	21-45
D5950C	21387		BEARING	21-40
EA-112	66289	2805-524-9552	CAMSHAFT	27-25
EB-108A	19728		WASHER	20-10
EB-8503A	19728		HEAD	20-13
EB-8506A	19728		BOLT	20-9
EB-8507A	19728		BOLT	20-8
EBA-405A	19728	5340-353-6994	SPRING	20-12
EBB-45A	19728		DRIVE ASSEMBLY	
EBB-4511A	19728	2920-367-4255	SHAFT AND PINION ASSEMBLY	20-11
E2303	21387		RETAINER	21-31
E2565	21387		SPRING	21-26
F-65-81	66289	2805-674-4865	TAPPET ASSEMBLY	26-5
FB338-3	70417		BEARING	14-85
FM-XZE4B-7	21387	2920-656-7336	MAGNETO	21
FP-498	70955		BUSHING	28-19
FP-505	70955		LINKAGE	28-21
FP-5455	70955		ARM	28-20
FP-553	70955		PIN	28-18
FP-613	70955	5330-991-7008	GASKET	28-11
FP-614	70955	5330-656-7474	GASKET	28-4
FP-615	70955	5330-991-7010	GASKET	28-15
FP-6428	70955		SPRING	28-16
FP-644-7	70955		SPRING	28-9
FP-645	70955	5340-237-2275	SPRING	28-17
FP-657	70955	2910-684-4405	FILTER	28-5
FP-750	70955		PLATE	28-12
FP-754	70955		DOME	28-3
FP-756	70955		VALVE	28-8
FP-757	70955	2805-992-0851	SPRING	28-10
FP-759	70955		SCREW AND LOCKWASHER ASSEMBLY	28-13
FP-762	70955		SCREW AND LOCKWASHER ASSEMBLY	28-6
FP-765	70955		BOLT	28-1
FP-766	70955	5330-656-7475	GASKET	28-2
F21-P	73370		FILTER, OIL	11-24
F2533	21387		PIN	21-43
F5952	21387		GEAR	21-42
GA-35A-1	66289		GEAR	36-30
GB-46	66289		GEAR	27-22

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	PAGES AND INDEX NO.
QC-28	66289		GEAR, IDLER	
QD-103	21387		GEAR	21-23
QD-94-C	66289		GEAR, DRIVE	35-2
QD-95-A	66289		GEAR	29-34
QE-43	66289		GEAR	
QEL5190-16-2	28337	5330-285-9705	GASKET	13-10
QI-195-C	70955	2910-339-4836	FUEL PUMP	27-5
QI-22	70955		BRACKET	27-22
QI-46	70955		FUEL HEAD	28-7
QI498	21387		RING	21-41
Q2457AX	21387		BUSHING	21-6
Q2788	21387		WICK AND HOLDER ASSEMBLY	21-13
Q3861	21387	2920-356-1221	PACKING	21-33
QF-454	66289		SPACER	
QO-150D	66289	2805-424-2806	INSERT	26-11
QO-203	66289		BUSHING	29-17
Q2514	21387		CONTACT	21-7
QK-50	66289	5330-050-1218	RING	27-13
QK-52	66289		PACKING	29-49
K-171-G	06499	6140-785-1098	BATTERY	17-9
K-95-D	66289		OIL PUMP ASSEMBLY	35
KA-61A-1	66289		BODY	35-18
KA-61A-1-G1	66289		BODY ASSEMBLY	
KB-42	66289		COVER	35-11
KB-42-82	66289		COVER ASSEMBLY	
KC-56-1	66289		GEAR, SPUR	35-15
KC-56-2	66289		GEAR, SPUR	35-13
KD-121	66289		SHAFT, DRIVE	35-16
KD-121-G1	66289		DRIVE SHAFT ASSEMBLY	
KD-122	66289		STUD SHAFT	35-17
LD-240-18	66289		MANIFOLD	24-24
LJ-300M	66289		TUBE, FILLER	
LK-9	66289		CLAMP	
LL-120	66289	4720-799-7634	BOGE	
LO-60	66289		CAP, FILLER	11-1
LQ-21-E	70955	2910-958-7663	DIAPHRAGM	28-14
N-10-N	39317		BEARING	36-38
ND-285	66289		PULLEY, DRIVE	36-17
NE-153	66289		BEARING	29-50
NE-60	66289	3110-100-6151	BALL, BEARING	35-10
NE-98	66289	3110-100-9162	BEARING ASSEMBLY	
NE13931-10	96906		RING	36-3
NE13931-11	96906	2805-554-3956	RING	36-3
NE13931-12	96906	2805-554-3955	RING	36-3
NE13932-7	96906		RING	36-2
NE13932-8	96906	2805-554-3954	RING	36-2
NE13932-9	96906	2805-554-3953	RING	36-2
NE13933-7	96906		RING	36-1
NE13933-8	96906	2805-554-3950	RING	36-1
NE13933-9	96906	2805-554-3952	RING	36-1
NE13957-1	96906	2805-554-9255	PISTON	36-4
NE13957-2	96906	2805-554-9822	PISTON	36-4
NE13957-3	96906	2805-540-5299	PISTON	36-4
NE13962-1	96906		RING	36-5
NE13963-1	96906	2805-386-3257	BEARING, SLEEVE	36-11
NE13983-1	96906	2805-374-9738	BEARING, SLEEVE	36-10
NE13996-6	96906		PIN	36-6
NE13997-1		2805-528-6097	LOCK	26-7
NE13998-1	96906	2805-374-9746	ROTATOR CAP	26-6

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
MS13999-8	96906	2805-382-8033	VALVE	26-10
MS15002-2	96906		FITTING	14-3
MS24322-5A6	96906		WHEEL AND HUB ASSEMBLY	
MS24325-1	96906	2530-528-7224	WHEEL ASSEMBLY	
MS24328-1	96906		HUB ASSEMBLY	
MS28740-16	96906		CONNECTOR	
MS28740-4	96906		CONNECTOR	
MS28741-16-1200	96906	4720-990-9010	HOSE ASSEMBLY	
MS28759-12-1200	96906		HOSE ASSEMBLY	
MS28759-8-1200	96906	4720-580-8446	HOSE ASSEMBLY	
MS28760-12	96906		ADAPTER	
MS28760-8	96906		ADAPTER	
MS28775-008	96906	5330-684-2380	PACKING	38-23
MS28775-10		5330-684-0265	PACKING	38-4
MS28775-114	96906	5330-618-0803	PACKING	38-16
MS28775-226	96906	5330-618-0803	PACKING	37-41
MS35338-44	96906		WASHER	16-3
MS35338-45	96906		WASHER	19-3
MS35389-6	96906	261 0-050-9840	TIRE	14-37
MS35392-52	96906	2610-269-7354	TUBE	14-38
MS35649-82	96906		NUT	
MU-54	19728		WASHER	20-19
MVG4D	66289	2805-679-3594	ENGINE	18-24
MZ-1024AD	19728		COVER	20-23
MZ-1034CS	19728	5977-627-3579	BRUSH	20-28
MZ-12D	19728	5977-391-4031	BRUSH	20-29
MZ-1 360A	19728		PLATE	20-15
MZ-19C	19728		SPRING	20-27
MZ-2001-LS	19728		HOUSING AND FIELD ASSEMBLY	
MZ-2002G	19728		END BELL	20-24
MZ-2012ES	19728		BRUSH SET	
MZ-2366-T	19728	2920-505-5108	ARMATURE	20-20
MZ-357	19728		WASHER	20-17
MZ-358A	19728		CAP	20-5
MZ-359A	19728	5330-559-6862	GASKET	20-14
MZ-364	19728	2920-592-3979	BEARING	20-6
MZ-365	19728		WASHER	20-18
MZ-4184-T	19728	2920-507-3205	STARTER	20
MZ-52B	19728		BOLT	20-1
MD-10-N	39317	3110-991-8557	BEARING	38-36
ML-972	74400	6645-557-8035	METER	9-10
M2570	21387		NUT	21-22
NC-146-C2	66289		FLYWHEEL	
NC-146-C2-SL	66289		FLYWHEEL ASSEMBLY	36-20
NC162416	60380	2805-992-0592	BEARING	39-22
NF2C		6625-783-6615	AMMETER	9-13
NW2 433X	21387	2920-799-7683	CAPACITOR	21-1
NX2430A	21387		CAP	21-9
PA-291	66289		PIN	34-1
PA-294	66289		PIN	29-53
PA-334			PIN	36-14
PA-340	66289		PIN	29-39
PA-64	66289		PIN	35-14
PB-146-1	66289		BOLT	36-9
PB-163	66289		BOLT	29-14
PB-24	66289		BOLT	
PC-112	66289		STUD	
PC-251	66289		STUD	24-23

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
PC-396	66289		STUD	
PC-429	66289		STUD	
PC-435			STUD	24-34
PD-115-A	66289		NUT	29-29
PD-157			NUT	36-15
PD-173-A	66289		LOCKNUT	29-1
PD-195	66289		NUT, HEXAGON	35-1
PE-5-4	66289		WASHER, LOCK	36-23
PE-65-1			WASHER, LOCK	36-16
PF-101	66289	2805-366-6248	PLUNGER	27-20
PF-18	66289		PLUG, PIPE	
PF-25	66289		PLUG	34-7
PF-52	66289		BUTTON	27-19, 34-8
PG-475	66289		BRACKET	29-12
PG-512	66289		BAND	
PG-515-A	19728		BRACKET	20-21
PH-194	19728		WASHER	20-22A
PH-202	66289	2805-383-3549	OIL SEAL	36-24
PH-245	66289		WASHER, CORK	
PH-269	66289	5330-579-9545	SEAL, OIL	34-9
PH-293-A	66289		WASHER	29-15
PJ-105	66289		STUD, GEAR	
PL-24	66289		KEY	36-21
PL-49	66289		KEY, WOODRUFF	36-31
PM-108	66289	2805-366-6249	SPRING	27-21
PM-111	66289	2805-253-6919	SPRING	29-2, 35-9
PM-145	66289		SPRING	27-12
PM-76	66289		SPRING	29-27
PS1330A	19728		HOUSING	20-4
PL-145-1	66289		SCREW	29-4
QB-83	66289	2805-292-3984	INSERT	24-25
QC-62	66289	2805-399-6982	GASKET	24-26
QD-482	66289	2805-536-8804	GASKET	26-4
QD-535	66289	2805-448-3433	GASKET	35-12
QD-595-A	66289	2940-536-1257	GASKET	
QD-615A	66289	2805-358-4789	GASKET	29-46
QD-616	66289	2805-360-8536	GASKET	
QD-631	66289	2805-399-6984	GASKET	24-4
QD-632	66289	2805-428-2159	GASKET	24-5
QD-634	66289	2805-428-2161	GASKET	34-4
QD-635	66289	2805-428-2162	GASKET	24-30
QD-636-A	66289	2805-600-7101	GASKET	36-26
QD-663	66289	2805-536-8818	GASKET	34-3
QD-67	66289	2805-366-6351	GASKET	27-18
QF-67-B	66289	5340-584-1612	SHIM	36-23
QF-67-C	66289	5340-584-1613	SHIM	36-27
QF-91	66289	2805-624-9940	GASKET	24-19
QO653	66289	5330-187-2962	GASKET	
Q5939	21387		GEAR	21-39
RC-91	66289	2805-360-8326	SCREEN, OIL	
RD-112	66289	2805-332-3722	SCREEN	35-5
RF-1165	66289		BUSHING	29-24
RF-1281	66289		TEE	29-23
RF-269	66289		NIPPLE	29-25
RF-270	66289		ELBOW, 90 DEGREE	
RF-270-4	66289		ELBOW, RESTRICTED, 90 DEGREE	
RF-794-A	66289		NIPPLE	27-2
RF-996	66289		ELBOW	27-3
RJ-153A-81	66289		SABRE, OIL	11-28

SECTION III
 NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
RK-173	66289	2805-353-5912	SLINGER, OIL	36-29
RK-181	66289		PLATE, SPLASH	
RM-1049A	66289	2910-447-9285	FUEL LINE	27-4
RM-536	66289	2805-371-4615	OIL LINE ASSEMBLY	29-22
RS2477C	21387	2920-656-7411	COIL	21-48
SA-26	66289		INSERT	24-33, 29-47
SA-58	66289		PLUG	24-32
SA-65-A	66289		PAD, COVER	
SD-115-N	66289		PLATE	23-4
SE-124-Y	66289		SHROUD	23-18
SE-125	66289		SHROUD	23-11
SE-125-A	66289		SHROUD	23-12
SE-126	66289		SHROUD	
SE-126-A	66289		SHROUD	23-15
SE-127	66289		SHROUD	23-6
SE-127-A	66289		SHROUD	23-7
SE-128-B	66289		DEFLECTOR	23-16
SE-128-C	66289		DEFLECTOR	23-17
SE-48-1	66289	2805-397-9648	SCREEN	23-1
TA-111-A	66289		PLUNGER	27-17
TA-112-A	66289		SHAFT	29-44
TA-112A-B	66289		DRIVE SHAFT ASSEMBLY	
TA-114	66289		SHAFT	27-14
TA-115	66289		HANDLE	27-11
TA-116	66289		CAP	27-16
TB-105-B	66289		ADAPTER	27-15
TB-109	66289		ADAPTER	29-45
TB155-84-12D	00624		COUPLING HALF	
TB155-84-8D	00624		COUPLING HALF	
TC-322D-81	66289		FLYWEIGHT	29-40
TC-328-D	66289		PIN	29-41
TC-346-B	66289		HUB	29-43
TC-348A	66289		SLEEVE	29-38
TC-348A-81	66289		SLEEVE AND BEARING ASSEMBLY	
TC-363B-2	66289		HOUSING	29-54
TC-363B-2-81	66289		HOUSING ASSEMBLY	
TC-365-D	66289		PIN	29-21
TC-368-A	66289		PIN	29-5
TC-398-15	66289		SHAFT AND LEVER ASSEMBLY	29-48
TC-403	66289		CAP	29-26
TF-96-4	66289		ADAPTER AND PRIMER ASSEMBLY	
TRC-1220	60380		WASHER	14-17
TRD1625	60380	3120-684-5681	WASHER	14-59
TS2480	21387		ROTOR	21-47
TT-61F-3	66289		CONTROL ASSEMBLY	
TT-84H-1	66289		GOVERNOR ASSEMBLY	
T1498	21387		RING	21-17
UX4631	21387		PLATE	21-46
U230-B			CRANK, STARTING	36-13
VB-134A-9	66289		LEVER	29-18
VB-98A-5	66289		YOKE	29-51
VE-339-A	66289		STOP	29-8
VE-435-E	66289	2990-816-5714	CHOKE CONTROL	24-15
VE-527-WV	66289	2990-818-3962	THROTTLE CONTROL	29-6
VE-556	66289		SUPPORT	29-11
VE-598	66289		BLOCK	29-16
VE-674-A	66289		BALL JOINT	29-31
VE-689-A	66289		ROD	29-32
VE-243-1	66289		SPACER	34-2

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
W250A	66289	2990-540-5366	MUFFLER	24-7
W2425	21387		HOUSING	21-50
W2437X	21387	2910-640-7794	CONTACT SET	21-16
W2514	21387		PLATE	21-8
X-179	70485		STRIP	
X-197	70485		STRIP	
XA-832	19728	5330-508-1111	SEAL	32-31, 32-49
XB-75	66289		SCREW	20-7
XB-17	66289		SEWSCREW	27-9
XB-8	11583	2920-229-6563	SPARK PLUG	
XB-1	66289		PIN	29-52
XC-1	66289		PLUG	24-20
XC-7-A	82386		PLUG	
X2765X	21387	2920-377-6723	ROTOR	21-12
Y5957	21387		HOUSING	21-25
Z2020	77344	5910-609-7473	CAPACITOR	16-5
OM-352	78480		SCREEN	
OM-361	78480		COVER	
OM-363	78480	2910-269-7126	BOWL	
OM-418T	78480	4730-142-1741	STRAINER	27-1
OM-432	78480		COCK	
OM-446	78480		CLAMP WIRE AND STUD	
OM-447	78480		CLAMP ASSEMBLY	
OM-462	78480		THUMBUT AND CUP	
015-00113	16954	2805-992-0572	BEARING AND BARREL ASSEMBLY	37-26
015-00162			CLEVIS ASSEMBLY	
015-02247	16954		HOUSING	38-26
015-02556	16954	2805-992-0571	SHAFT ASSEMBLY	37-46
015-99889	16954		SPACERS	37-50
035-11697E	16954	2805-992-0570	SUPPORT	38-13
035-11712	16954		PISTON	38-11
035-11811	16954		BODY	37-34
035-11816	16954		BARREL	37-27
035-11818	16954		RETAINER	37-24
035-11826	16954		RETAINER	37-19
035-11897	16954		BEARING	37-29
035-11899	16954	4920-511-8385	GASKET	37-30
035-12279	16954	4935-886-0312	GASKET	37-12
035-12289	16954	4320-779-0200	SPRING	38-12
035-12481	16954		PIN	37-25
035-12555	16954		HOUSING	38-18
035-12562	16954		STOP	38-1
035-12610	16954		PLATE	39-9
035-12670	16954		PLATE	39-5
035-12671	16954		INDICATOR	38-3
035-12951	16954		HOUSING	39-26
035-12955	16954		PIN	39-12
035-12956	16954		SHAFT	39-7
035-12958	16954		SPACER	39-14
035-13342	16954	4320-631-0146	SOCKET	37-22
035-13873	16954		PISTON	38-8, 38-17
035-13876	16954		RETAINER	38-8
035-13961	16954		SLEEVE	38-5
035-13962	16954		SLEEVE	38-19
035-14074	16954	1450-815-1373	PLATE	37-17
035-14082	16954		PISTON	38-25
035-14391	16954		LINK	39-1
035-14751	16954		TORQUE	38-29
035-14752	16954		NUT	38-27
035-14857	16954		PIN	39-20

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
035-15070	16954		BODY, STOP	36-34
035-15071	16954		STOP	38-32
035-15072	16954		PISTON	38-31
035-15090	16954	4935-886-0320	GASKET	39-11
035-15205	16954		RANGER	39-23
035-15206	16954		PLATE	39-15
035-15821	16954		CLEVIS	38-39
035-17681	16954		NUT	37-47
035-17999	16954		CAP	36-21
035-18437	16954	4320-631-4047	GASKET	37-5
035-18438	16954		CAP	37-3
035-18543	16954		PLATE	37-31
035-19246	16954		FLANGE	37-38
035-21934	16954		RETAINER	37-42
035-22051	16954		SPRING	38-7
035-22174	16954	4320-7 12-4640	SPRING	37-23
035-22413	16954		SPRING	38-33
035-22733	16954	5310-271-7442	GASKET	37-16
06137	78480		BOWL	
10-103			RUNNING GEAR AND BRAKE ASSEMBLY	14
10-3685	96152		BODY	25-34
10-3774	96152	2910-255-2298	CARBURETOR	24-18
102153	73370		STRAP	
10402	77931	4920-775-4921	SEAL	37-44
1046-3	82386		BALL	
1102811	16764	2920-623-0409	GENERATOR ASSEMBLY	16-8
111-161	98441		HOSE	
111-4-L	98441		HOSE	
1118300	16764	2920-394-5988	REGULATOR	17-28
112-12	98441		HOSE	
112-4	98441		HOSE	
11382A	28265	5310-282-9555	GASKET	
11559	73370		COVER	11-26
11562	73370		SPACER	
11580	73370		SCREW	11-27
11582	73370	5330-290-1423	GASKET, COVER	
11583	73370		SPRING	
11584	73370		PLUG, DRAIN	
116055	41615	3010-793-3455	CHAIN	18-21
116649	41615		COUPLING HALF	18-22
116650	41615		COUPLING HALF	18-23
1185	82386		KNOB	32-18
120	43766	3110-117-0575	BEARING	29-36
121743	16764		NUT	19-36
1226	77900		WASHER	36-9
123	43766	3110-117-0587	BEARING	29-33
12384	66289		NUT, SQUARE	
125609	16764		OILER	19-28
13-956	96152		SHAFT ASSEMBLY	25-16
1377	04196	6685-585-4511	GAGE	9-3
14-214	96152		THROTTLE FLY	25-12
140-80-16D			CAP, SEAL	
145-81-16D	00624		COUPLING HALF	
145-84-16D	00624		COUPLING HALF	12-15
14585-16D			NUT, UNION	
145-87-16D	00624		CAP	12-16
1489-2	82386		BUMPER	32-42
15-446	96152		SCREW	25-13

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
15-A47	96152		SCREW	25-23
15-A93	96152		SCREW	25-31
15-A99	96152		SCREW	25-29
150-89-12D	00624		CAP, SEAL	
150-89-8D	00624		CAP, SEAL	
150.135	79934		VALVE	14-40
15123	60038	3110-626-9463	CONE	14-45
15245	60038	3110-198-2170	CUP	14-46
155-SL-12D	00624		COUPLING HALF	
155-81-8D	00624		COUPLING HALF	
155-87-12D	00624		CAP	12-18
155-87-8D	00624		CAP	12-20
15585-12D	00624		NUT, UNION	
15585-8D	00624		NUT, UNION	
15900	81966		HANDLE	
15900-1	81996		HANDLE, VALVE	
16-A105	96152	2910-522-5358	GASKET	25-4
16-4	96152	5330-291-7918	GASKET	25-3
16-456	96152	5330-496-5413	GASKET	25-9
1672-17	82386		PIN	
1812159	16764		SCREW	33-5
1843646	16764		SCREW	19-33
1857412	16764		WASHER	19-14
1858603	16764	2920-362-6772	SPACER SLEEVE	19-29
1858753	16764		WASHER	19-39
1866400	16764		FAN	19-18
1875510	16764		GASKET	33-4
1878183	16764		ARM	19-12
1878467	16764	2920-259-1695	ARMATURE	33-6
1878493	16764	2920-378-0420	CONTACT	33-16
1878503	16764		CLAMP	33-18
1878504	16764		BAR	33-14
1878505	16764		WASHER	33-12
1878506	16764		BUSHING	33-15
1878507	16764		INSULATOR	33-13
1878514	16764		COVER	33-1
187899	16764		SCREW	33-2
1879663	16764		GROMMET	33-19
1880781	16764		WASHER	19-22
1881409	16764		WASHER	19-38
1885090	16764		INSULATOR	19-40
1900PM-FTG-1/4	81996		VALVE, NEEDLE	
1904370	16764		SCREW	19-21
1904377	16764		WASHER	19-11
1904661	16764		WASHER	19-37
1908829	16764		SPRING	19-13
1910404	16764		END BELL	19-30
1911263	16764		PLATE	19-20
1912008	16764	2920-285-3818	GASKET	19-23
1912073	16764		INSULATOR	19-35
1912176	16764	2920-512-1788	SPRING	33-9
1912599	16764	2920-358-6283	ARMATURE	19-31
1912725	16764	5999-502-1857	POLE PIECE	19-32
1913926	16764		PULLEY	19-15
1921362	16764		INSULATOR	19-42
1921369	16764		TERMINAL	19-43
1921860	16764		TERMINAL	19-41
	16764		SCREW	33-10
	16764	2920-669-6139	WINDING	19-34

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
192288	16764		HOLDER ASSEMBLY	19-4
192289	16764		HOLDER ASSEMBLY	19-5
1923069	16764		END BELL	19-1
1923295	16764	5977 -553-4418	BRUSH	19-9
1996041	16764	5930-132-8283	SWITCH	10-2
2-1073-11	82386		COVER	17-23
2-1105-6			TIE ROD ASSEMBLY	
2-1117A	82366		DOOR ASSEMBLY	32-30
2-1118-3A	82336		DOOR ASSEMBLY	32-44
2-1120-1	82386		DOOR ASSEMBLY	32-50
2-1126-2	82386		DOOR ASSEMBLY	32-24
2-1127-2	82386		DOOR ASSEMBLY	32-23
2-1128-2	82386		DOOR ASSEMBLY	32-22
2-1143-2			MOUNT	12-2
2-1152	82386		BOX	16-1
2-1158-8	86768		VALVE	9-20
2-1183		6680-532-2915	INDICATOR	9-15
2-1249	82386		TUBE	
2-1249A	82386		TUBE ASSEMBLY	
2-1253	82386		COMPENSATOR CONTROL ASSEMBLY	9-25
2-1259	82386		PLATE	16-20
2-1428	82386	5340-687-5300	HANDLE	32-67
2-1668	82386		DRAIN ASSEMBLY	30-15
2-1670			LEVER ASSEMBLY	15-4
2-1671		4920-785-5243	CABLE ASSEMBLY	15-1
2-1671-1		4920-785-5242	CABLE ASSEMBLY	15-2
2-1677	82386		DOOR ASSEMBLY	32-21
2-1678	82386		HANGER ASSEMBLY	
2-214-10		6680-515-5910	TACHOMETER	9-9
2X-1674-1	66289		CAP	11-10
201-08801	16954	3110-992-0546	BALL	38-14
201-24001	16954	3110-992-0547	BALL	37-21
20210BK1A	43334	3110-992-0527	BEARING	37-49
233-536	96152		VALVE ASSEMBLY	25-7
2397-3L	82386		CATCH	32-56
2397-4	82386		LOOP	32-26
2397-4A	82386		CATCH ASSEMBLY	
2397-5	82386		LEVER	32-27
24-213	96152		SPRING	25-27
24-262	96152		SPRING	25-15
24-485			SPRING	25-21
24240	79150	5330-599-5966	GASKET	27-8
24720	60038	3110-100-0542	CUP	14-49
24780	60038	3110-100-3537	CONE	14-48
25-1523	16954		RETAINER	37-18
25-1525	16954	2805-992-0574	PISTON AND SHOE ASSEMBLY	37-20
25-3466	16954		SHAFT AND SLEEVE ASSEMBLY	37-51
25-5871	16954	4320-857-0869	CONTROL	
258814A	21387		SETSCREW	21-49
2550	51240	6620-377-6805	GAGE	9-11
26-720	96152		SHAFT ASSEMBLY	25-28
27-559	96152		CHOKE FLY	25-22
275-2	81860		GROMMET	
28-49	96152		SWIVEL	25-25
29-537	96152		BRACKET ASSEMBLY	25-30
29-914	15605		GROMMET	
30-666	96152	2910-429-2155	FLOAT	25-5
308-10200	16954		SCREW	38-22
311010	75915	5920-011-7142	HOLDER, FUSE	10-3

SECTION III
 NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
313-12	98441		CONNECTOR	
313-4	98441		CONNECTOR	
32-27	96152		PIN	25-6
324-21208	16954		PIN	37-32
324-21610	16954		PIN	39-17
324-24022	16954		PIN	38-35
324-24048	16954		PIN	38-37
325-12150	16954		PIN	38-30
325B7	66289		NUT	24-21
3282	71694		HANDLE	32-55
342001	75915		HOLDER	10-3
350-01010	16954		WASHER	37-48
356-15885	16954		RING	38-18
364-15885	16954		RING	38-3
3692951	11862	25 30-4 95-4341	TIE ROD END	14-4
3719-R-44	78500	25 30-528-9000	DRUM	14-52
39B4233	00724		NECK	30-3
4-4-CETX-5	88979		FITTING	37-2
4-445-5	82386		BOX ASSEMBLY	17-28
4-472-2	82386		HOUSING ASSEMBLY	32-72
4-483	82386		TANK	18-16
4-490-1	82386		COVER	13-26
4-672-2	82386		ARM ASSEMBLY, RIGHT HAND	14-77
4-672-3	82386		ARM ASSEMBLY, LEFT HAND	14-77
4-673-2	82386		ARM ASSEMBLY, RIGHT HAND	14-77
4-673-3	82386		ARM ASSEMBLY, LEFT HAND	14-77
4-684-1	82386		PANEL ASSEMBLY	32-6
4-685	82386		AXLE	14-69
4-685-1	82386		AXLE	14-69
4-689	82386		BRACKET	14-63
4-689-1			BRACKET	14-63
4-690			ARM ASSEMBLY	14-14
4-693	82386		SUPPORT AND ARM ASSEMBLY	14-70
4-694	82386		SUPPORT AND ARM ASSEMBLY	14-70
4-698	82386		AXLE ASSEMBLY	14-54
4-698-1	82386		AXLE ASSEMBLY	14-54
4-699	82386		AXLE AND BRAKE ASSEMBLY	
4-699-1	82386		AXLE AND BRAKE ASSEMBLY	
4-756	82386		SPINDLE	14-60
4-756-1	82386		SPINDLE	14-60
400-11	82386		WASHER	
400-11M	82386		WASHER	16-13,16-17
400-210	82386		WASHER	
400-268	82386		WASHER	14-59
400-27			WASHER	
400-272	82386	3120-661-6270	WASHER	14-58
4005-1	11862	4920-589-3517	TIE ROD END	14-5
4009-4A			VALVE ASSEMBLY	9-23,9-27
401-160	82386		SPACER	13-15
401-196			SPACER	15-17
401-197			SPACER	15-7
401-1 30			SPACER	15-5
401-1 25			SPACER	15-6
4041-1	82386		HINGE	32-59
4042-1	82386		HINGE	32-60
4043-1A	82386		RETAINER ASSEMBLY	32-57
4044-1A	82386		RETAINER ASSEMBLY	32-58
4055-3	82386		PLATE	32-70

SECTION III
 NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
4056-1			PLATE, INSTRUCTION, CAPACITY	
4057-11			PLATE, NAME, OFF-IGNITION-ON	
4057-21			PLATE, NAME, TACHOMETER	
4057-22			PLATE, NAME, OIL PRESSURE	
4057-23			PLATE, NAME, TEMPERATURE	
4057-24			PLATE, NAME, AMMETER	
4057-26			PLATE, NAME, HOURMETER	
4057-3			PLATE, NAME, FUSE	
4057-4			PLATE, NAME, CHOKE	
4057-5			PLATE, NAME, STARTER	
4057-6			PLATE, NAME, THROTTLE	
4057-69			PLATE, NAME, OFF	
4058-13			PLATE, NAME, FLUID PRESSURE GAGE	
4058-14			PLATE, NAME, FLUID PRESSURE GAGE	
4058-15			PLATE, NAME, GAGE SNUBBER VALVE	
4058-16			PLATE, NAME, FLUID FLOW INDICATOR	
4058-17			PLATE, NAME, RESERVOIR LEVEL INDICATOR	
4058-18			PLATE, NAME, FLUID TEMPERATURE GAGE	
4058-19			PLATE, NAME, RESERVOIR SHUT-OFF VALVE	
4058-20			PLATE, NAME, FLUID VOLUME CONTROL	
4058-21			PLATE, NAME, COMPENSATOR CONTROL	
4058-22			PLATE, NAME, FLUID BY-PASS VALVE	
4058-23			PLATE, NAME, HIGH PRESSURE RELIEF VALVE	
4058-25			PLATE, NAME, OUTLET SELECTOR VALVE	
4058-41			PLATE, NAME, FLUID PRESSURE GAGE TAP	
4058-42			PLATE, NAME, FILTER PRESSURE GAGE TAP	
4058-81			PLATE, NAME, GAGE DAMPENER PRE-CHARGE	
4059-4			PLATE, NAME, FLOW CONTROL 1/2 INCH OUTLET	
4059-5			PLATE, NAME, FLOW CONTROL 3/4 INCH OUTLET	
4059-6			PLATE, NAME, PRESSURE SELECTOR VALVE	
4060	51240	6680-991-8579	GAGE	9-2
407-19	82386		NUT, WING	
4077-1	82386		CAP	18-17
4078-1	82386		CAP	30-2
4080	82386	2805-992-0575	STRAINER	30-4
4081-2	82386		COUPLING	
4083-1	82386		SPRING	14-53
4089	82386		PUSHROD	
409-121	82386		NUT	
409-132			NUT	

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
4095	82386		POST	
4100	82386		BOLT	32-10
4102	82386		WASHER	14-44
4116			SCREW	
4134-1	82386		ARM	16-14
4136-1	82386		BRACKET	16-19
4140	82386		MOUNT	24-11
4141	82386		CLAMP	24-8
4200A	82386		LEVEL ASSEMBLY	
4205	82386		LOCKNUT	
4234A	82386		PLATE ASSEMBLY	13-12
4235	82386		COVER	13-9
4249			BRACKET	
4275			U BOLT	
43-129	96152		NEEDLE	25-20
4323	82386		RING	32-35
4324	82386		GASKET	32-36
4330	82386		PLATE	32-71
44-38		5330-726-0220	PACKING	25-32
44-63	96152		PACKING	25-18
4413	82386		BULLET	
4414	82386		PUSHROD	
4415	82386		SCREW	
4480-4		2530-859-5767	TIE ROD	14-10
453A	60038		CUP, BEARING	36-32
4537	82386		PIN	18-18
4558	60038		CONE, BEARING	36-33
47-395	96152	2805-992-0579	NOZZLE	25-8
4723	82386		LOCKNUT	
4738-2	82386	5930-607-6280	THERMOSWITCH	13-23
48P18	56289	5910-538-3232	CAPACITOR	17-34
49-253	96152		POWER JET	25-10
5L470	78439	3030-251-7484	BELTING	17-1
50-927LH	01930	4920-707-5676	SUPPORT	32-7
50-927RH	01930	4920-707-3126	SUPPORT	32-8
508-8-6			SCREW	21-14
5100-810	00624		CHAIN ASSEMBLY	
5121	10100		HANDLE	
5241	73370		COVER ASSEMBLY	
5292849	77060		ADAPTER	17-7
5292850	77060		ADAPTER	17-8
5310	73370		BODY, FILTER	
535-11812	16954		BLOCK	37-52
535-19425	16954		FLANGE	37-37
55-230	96152		CUP	25-33
55-231	96152		RETAINER	25-17
55-316	96152		CUP	25-11
5629	82386		SPRING	32-3, 32-16
5663-1	82386		STUD	32-20
5664	82386		ARM	32-15
5665	82386		ARM	32-2, 32-15
5666-3	82386		CLAMP ASSEMBLY	
5666-4	82386		CLAMP ASSEMBLY	32-13
5666-6	82386		CLAMP ASSEMBLY	32-13
5687			LEVER	15-16
5688			PIN	15-11
5688-2			PIN	15-18
5692			CLEVIS	15-12

SECTION III
NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
5693			BRACKET	14-26
5693-1			BRACKET	14-27
569412	90005	4330-541-0410	FILTER	
5695	82386		SPRING	32-64
5731			WASHER	14-47
5744A	82386		HOOK	32-65
5747	82386		PIN	32-63
5780			DRUMBAR ASSEMBLY	14-11
5781			PIN	14-12
5786-1	82386		PIN	14-76
5796	54641	2930-362-9155	KINGPIN	14-57
5803			LATCH	14-19
5807			BOLT	14-18
5817	82386		BODY	
5818	82386		STEM	
5819	82386		KNOB	
5833	82386		PLATE ASSEMBLY	32-66
5931A	21387		PIN	21-21
599234	11862		CLAMP	14-9
60-439	96152		BUSHING	25-19
607	43766	3110-120-4464	BEARING	29-37
61-3653RH	42689		SUPPORT	32-28,32-37
61-3653LH	42689		SUPPORT	32-29,32-37
610-47	82386		SCREW	17-24
613	70485	5340-664-5785	BUMPER	14-79
619-19			RING	14-13
619-20	82386		RING	14-75
65-172	96152		BOWL	25-1
65-4-10			BOLT	18-25
65-4-12			BOLT	13-13
65-4-4			BOLT	23-9,23-13
65-5-10			BOLT	13-6
65-5-5			BOLT	
65-5-7			BOLT	13-21
65-6-24			BOLT	
65-6-4			BOLT	
650-209	82386		ELBOW	24-6
650-210	82386		ELBOW	24-14
650-211	82386		C OUEPLING	24-12
650-212	82386		NIPPLE	24-13
650-257	82386		PLUG	18-19
669-119	82386	4720-992-0537	HOSE	30-10
671-173-16	82386		STRIP	
671-173-255	82386		STRIP	
671-173-28,875	82386		STRIP	32-48,32-54
675-143	82386		BOLT	14-74
675-218	82386		THUMBSCREW	32-5
686-80			SCREW	9-19
686-89	82386		SCREW	30-13
69F	30327		ELBOW	18-20
7-193-1	82386		COVER	13-16
7-222-2			SUPPORT	30-18
7-224-1	82386		SUPPORT ASSEMBLY	14-84
7-226-1	82386		SUPPORT ASSEMBLY	14-84
70-103224	80089	2920-991-7052	RELAY	17-18
72-F	30327	6620-377-6805	CONNECTOR	
80-166	96152		BOLT	25-2
803-04035	16954		TUBE	37-1

SECTION III
 NUMERICAL INDEX - PART I

PART NO.	MANUFACTURERS CODE	FEDERAL STOCK NO.	ITEM NAME	FIGURE AND INDEX NO.
804000	16764		WASHER	19-16
8042B-10HB	86768		VALVE	9-16
806915	16764		NUT	19-17
809763	16764		BOLT	19-2
809945	16764		WASHER	19-24
809961	16764	5330-171-3619	WASHER	19-27
813731	16764		WASHER	33-3
819961	16764		PLATE	19-26
946	82386		CONNECTOR	17-33
946-1	82386		CONNECTOR	16-4
9510	81860	5340- 664-9238	GROMMET	
954378	16764	3110-151-8140	BEARING	19-25

SECTION III
NUMERICAL INDEX - PART II

FEDERAL STOCK NO.	ITEM NAME	MANUFACTURERS CODE	PART NO.	FIGURE AND INDEX NO.
1450-815-1373	PLATE	16954	035-14074	37-17
1650-242-9425	FILTER ELEMENT		AM6236-3	13-11
2530-495-4341	TIE ROD END	11062	3692951	14-4
2530-528-7224	WHEEL ASSEMBLY	96906	MB24325-1	
2530-528-9080	DRUM	78500	3719-R-44	14-52
2530-533-2650	HUB		B448	14-51
2530-541-3003	BRAKE ASSEMBLY	78500	A4-3736-R-70	14-66
2530-859-5767	TIE ROD		4480-4	14-10
2610-060-9840	TIRE	96906	MB35389-6	14-37
2610-209-7354	TUBE	96906	MB35382-52	14-38
2805-253-6919	SPRING	66289	FM-111	29-2, 35-9
2805-282-3984	INSERT	66289	QB-83	24-25
2805-332-3722	SCREEN	66289	RD-112	35-5
2805-353-5912	SLINGER, OIL	66289	RK-173	36-29
2805-358-4789	GASKET	66289	QD-615A	29-46
2805-360-8326	SCREEN, OIL	66289	RC-91	
2805-366-6248	PLUNGER	66289	PF-101	27-20
2805-366-6249	SPRING	66289	PM-108	27-21
2805-366-6351	GASKET	66289	QD-67	27-18
2805-371-4615	OIL LINE ASSEMBLY	66289	RM-536	29-22
2805-374-9738	BEARING, SLEEVE	96906	MB13993-1	36-10
2805-374-9746	ROTOR CAP	96906	MB13998-1	26-6
2805-382-8033	VALVE	96906	MB13999-8	26-10
2805-383-3549	OIL SEAL	66289	PM-202	36-24
2805-386-3257	BEARING, SLEEVE	96906	MB13963-1	36-11
2805-397-9648	SCREEN	66289	SB-48-1	23-1
2805-399-6982	GASKET	66289	QC-62	24-26
2805-399-6984	GASKET	66289	QD-631	24-4
2805-424-2806	INSERT	66289	HG-150D	26-11
2805-428-2159	GASKET	66289	QD-632	24-5
2805-428-2161	GASKET	66289	QD-634	34-4
2805-428-2162	GASKET	66289	QD-635	24-30
2805-448-3433	GASKET	66289	QD-535	35-12
2805-524-9552	CAMSHAFT	66289	EA-112	27-25
2805-528-6097	LOCK		MB13997-1	26-7
2805-536-8804	GASKET	66289	QD-482	26-4
2805-536-8818	GASKET	66289	QD-633	34-3
2805-540-5299	PISTON	96906	MB13957-3	36-4
2805-554-3950	RING	96906	MB13933-8	36-1
2805-554-3952	RING	96906	MB13933-9	36-1
2805-554-3953	RING	96906	MB13932-9	36-2
2805-554-3954	RING	96906	MB13932-8	36-2
2805-554-3955	RING		MB13931-12	36-3
2805-554-3956	RING	96906	MB13931-11	36-3
2805-564-8255	PISTON	96906	MB13957-1	36-4
2805-554-9822	PISTON	96906	MB13957-2	36-4
2805-574-8856	GUIDE	66289	AD-42A	26-12
2805-600-7101	GASKET	66289	QD-636-A	36-26
2805-624-9940	GASKET	66289	QF-91	24-19
2805-624-9951	ROD, CONNECTING	66289	DA-66A-4	36-12
2805-654-4274	RING SET	66289	DR-25	
2805-874-4865	TAPPET ASSEMBLY	66289	F-65-B1	26-5
2805-678-3594	ENGINE	66289	MV64D	18-24
2805-992-0570	SUPPORT	16954	035-11697Z	38-13
2805-992-0571	SHAFT ASSEMBLY	16954	015-02556	37-46
2805-992-0572	BEARING AND BARREL ASSEMBLY	16954	015-00113	37-26

SECTION III
NUMERICAL INDEX - PART II

FEDERAL STOCK NO.	ITEM NAME	MANUFACTURERS CODE	PART NO.	FIGURE AND INDEX NO.
2805-992-0574	PISTON AND SHOE ASSEMBLY	16954	25-1525	37-20
2805-992-0575	STRAINER	82386	4080	30-4
2805-992-0576	RING SET	66289	DR-25-840	
2805-992-0578	CRANKSHAFT	66289	CA-69 D-4	36-34
2805-992-0579	NOZZLE	96152	47-395	25-8
2805-992-0585	BEARING	70417	AAL339-2	14-78
2805-992-0586	VALVE, NEEDLE		A361-100-4	
2805-992-0587	GUIDE, SPRING		A361-100-8	
2805-992-0588	SPRING, SPOOL		A361-100-11	
2805-992-0589	SPRING, PILOT		A361-100-12	
2805-992-0590	FILTER		A361-103-3	
2805-992-0591	SPRING		A361-103-8	
2805-992-0592	BEARING	60380	NCL62416	39-22
2805-992-0851	RETAINER	70955	FP-757	28-10
2910-255-2298	CARBURETOR	96152	10-3774	24-18
2910-269-7126	BOWL	78480	OW-363	
2910-339-4836	FUEL PUMP	70955	GI-195-C	27-5
2910-429-2155	FLOAT	96152	30-666	25-5
2910-447-9285	FUEL LINE	66289	RM-1049A	27-4
2910-522-5358	GASKET	96152	16-A105	25-4
2910-640-7794	CONTACT SET	21387	W2437X	21-16
2910-684-4405	FILTER	70955	FP-657	28-5
2910-958-7663	DIAPHRAGM	70955	LQ-21-E	28-14
2920-229-6563	SPARK PLUG	11583	XE-8	
2920-259-1695	ARMATURE	16764	1878467	33-6
2920-285-3818	GASKET	16764	1912008	19-23
2920-356-1221	PACKING	21387	G3861	21-33
2920-358-6283	ARMATURE	16764	1912599	19-31
2920-362-6772	SPACER SLEEVE	16764	1858603	19-29
2920-367-4255	SHAFT AND PINION ASSEMBLY	19728	EBB-4511A	20-11
2920-377-6723	ROTOR	21387	X27 65X	21-12
2920-378-0420	CONTACT	16764	1878493	33-16
2920-394-5988	REGULATOR	16764	1118300	17-28
2920-505-5108	ARMATURE	19728	MZ-2366-T	20-20
2920-507-3205	STARTER	19728	MZ-4184-T	20
2920-512-1788	SPRING	16764	1912176	33-9
2920-566-7395	COUPLING	21387	BW2563C	21-29
2920-592-3979	BEARING	19728	MZ-364	20-6
2920-623-0409	GENERATOR ASSEMBLY	16764	1102811	16-9
2920-656-7336	MAGNETO	21387	FM-XZE4B-7	21
2920-656-7411	COIL	21387	RS2477C	21-48
2920-669-6139	WINDING	16764	1922702	19-34
2920-799-7683	CAPACITOR	21387	MMX2433X	21-1
2920-844-7154	BEARING	21387	D5949A	21-45
2920-991-7052	RELAY	80089	70-103224	17-18
2930-362-9155	KINGPIN	54641	5796	14-57
2940-141-9025	CARTRIDGE	73370	C-21P	
2940-536-1257	GASKET	66289	QD-595-A	
2940-799-7687	AIR CLEANER	16954	A-552	11-14
2990-540-5066	MUFFLER	66289	WD50A	24-7
2990-816-5714	CHOKER CONTROL	66289	VE-435-E	24-15
2990-818-3962	THROTTLE CONTROL	66289	VE-527-WV	29-6
3010-793-3455	CHAIN	41615	116055	18-21
3030-251-7484	BELTING	78439	5L470	17-1
3110-100-0542	CUP	60038	24720	14-49
3110-100-3537	CONE	60038	24780	14-48
3110-100-6151	BALL, BEARING	66289	ME-60	35-10

SECTION III
NUMERICAL INDEX - PART II

FEDERAL STOCK NO.	ITEM NAME	MANUFACTURERS CODE	PART NO.	FIGURE AND INDEX NO.
3110-100-9162	BEARING ASSEMBLY	66289	MS-98	
3110-117-0575	BEARING	43766	120	29-36
3110-117-0587	BEARING	43766	123	29-33
3110-120-4464	BEARING	43766	607	29-37
3110-144-8998	BEARING	21387	C5949	21-37
3110-151-8140	BEARING	16764	954378	19-25
3110-198-2170	CUP	60038	15245	14-46
3110-626-9463	CONE	60038	15123	14-45
3110-991-8557	BEARING	39317	MO-10-M	38-36
3110-992-0527	BEARING	43334	202108CLA	37-49
3110-992-0546	BALL	16954	201-08801	38-14
3110-992-0547	BALL	16954	201-24001	37-21
3120-489-4244	BEARING	12204	A1133-2	14-62
3120-580-4514	BEARING	70417	AA1154-1	14-61
3120-661-6270	WASHER	82386	400-272	14-58
3120-684-5681	WASHER	60380	TRD1625	14-59
4320-631-0146	SOCKET	16954	035-13342	37-22
4320-631-4047	GASKET	16954	035-18437	37-5
4320-712-4640	SPRING	16954	035-22174	37-23
4320-779-0200	SPRING	16954	035-12289	38-12
4320-787-2586	PUMP	82386	A280-4-3001	12-1
4320-857-0869	CONTROL	16954	25-5871	
4330-024-9665	FILTER ELEMENT	88044	AM6237-1	30-9
4330-541-0410	FILTER	90005	569412	
4720-580-8446	HOSE ASSEMBLY	96906	MS28759-8-1200	
4720-793-0558	HOSE ASSEMBLY, HYDRAULIC	82386	A280-4-3223	
4720-799-7634	HOSE	66289	LL-120	
4720-990-9010	HOSE ASSEMBLY	96906	MS28741-16-1200	
4720-990-9011	HOSE ASSEMBLY	82386	A280-2-3302	12-44
4720-990-9012	HOSE ASSEMBLY	82386	A426-2-3220	12-4
4720-990-9014	HOSE ASSEMBLY		A280-2-3300	12-37
4720-990-9015	HOSE ASSEMBLY	82386	A426-2-3221	12-8
4720-992-0537	HOSE	82386	669-119	30-10
4730-142-1741	STRAINER	78480	OW-418T	27-1
4820-783-6670	VALVE	82386	A280-3005	12-23
4820-783-6678	VALVE		A361-2-112	
4920-511-8385	GASKET	16954	035-11899	37-30
4920-589-3517	TIE ROD END	11862	4005-1	14-5
4920-707-3126	SUPPORT	01930	50-927RH	32-8
4920-707-5676	SUPPORT	01930	50-927LH	32-7
4920-710-6669	TEST STAND	82386	AHT-5A-1	1
4920-713-4705	DAMPENER		A361-2-108	9-22
4920-775-4921	SEAL	77931	10402	37-44
4920-783-6857	VALVE		A361-2-103	9-8
4920-785-5242	CABLE ASSEMBLY		2-1671-1	15-2
4920-785-5243	CABLE ASSEMBLY		2-1671	15-1
4920-790-8108	HOSE ASSEMBLY, HYDRAULIC	82386	A280-4-3225	
4920-790-8109	HOSE ASSEMBLY	82386	A280-4-3224	
4920-793-0645	VALVE		A361-100	9-17
4920-793-0667	VALVE ASSEMBLY		A280-2-3221	
4920-991-6998	PLUNGER		A361-100-10	
4935-886-0312	GASKET	16954	035-12279	37-12
4935-886-0320	GASKET	16954	035-15090	39-11
5310-271-7442	GASKET	16954	035-22733	37-16
5310-282-8555	GASKET	28265	11382A	
5315-012-4545	KEY		AM280R405	19-19

SECTION III
NUMERICAL INDEX - PART II

FEDERAL STOCK NO.	ITEM NAME	MANUFACTURERS CODE	PART NO.	FIGURE AND INDEX NO.
5315-992-0553	FIN		A361-103-4	
5330-050-1211	PACKING	88144	AM6227-8	
5330-050-1218	RING	66289	JK-50	27-13
5330-054-6890	PACKING	88044	AM6320B32	37-36
5330-171-3619	WASHER	16764	809961	19-27
5330-187-2962	GASKET	66289	Q0653	
5330-196-5382	PACKING		AM6227-19	38-28
5330-197-9611	PACKING		AM6227-69	13-7, 13-30
5330-198-6187	PACKING		AM6227-26	
5330-251-8839	PACKING		AM6290-12	
5330-285-9705	GASKET	26337	GR15190-16-2	13-10
5330-285-9842	PACKING		AM6290-10	13-24
5330-285-9843	PACKING		AM6290-16	13-5, 13-19
5330-290-1423	GASKET, COVER	73370	11582	
5330-291-7918	GASKET	96152	16-4	25-3
5330-292-0570	PACKING		AM6227-15	39-13
5330-297-6290	PACKING		AM6230-3	38-24
5330-350-9013	PACKING		AM6227-10	
5330-496-5413	GASKET	96152	16-456	25-9
5330-508-1111	SEAL	19728	XA-832	20-7
5330-559-6862	GASKET	19728	MZ-359A	20-14
5330-576-9732	PACKING	96906	MS28775-226	37-41
5330-579-9545	SEAL, OIL	66289		34-9
5330-584-0265	PACKING		MS28775-10	38-4
5330-599-5966	GASKET	79150	24240	27-8
5330-618-0801	PACKING	96906	MS28775-114	38-16
5330-656-7474	GASKET	70955	FP-614	28-4
5330-656-7475	GASKET	70955	FP-766	28-2
5330-684-2380	PACKING	96906	MS28775-008	38-23
5330-726-0220	PACKING			25-32
5330-805-2966	PACKING	98441	AM6290-4	13-3
5330-808-0794	PACKING		AM6290-8	38-2
5330-815-1712	PACKING	45681	AM6230-14	13-25, 37-45
5330-835-7485	PACKING		AM6290-3	13-29
5330-991-7008	GASKET	70955	FP-613	28-11
5330-991-7010	GASKET	70955	FP-615	28-15
5330-991-8569	GASKET	82386	A280-3207	
5340-237-2275	SPRING	70955	FP-645	28-17
5340-353-6994	SPRING	19728	EBA-405A	20-12
5340-584-1612	SHIM	66289	QF-67-B	36-28
5340-584-1613	SHIM	66289	QF-67-C	36-27
5340-664-5785	BUMPER	70485	613	14-79
5340-664-9238	ROCKET	81860	9510	
5340-687-5300	HANDLE	38	2-1428	32-67
5910-538-3232	CAPACITOR		48P18	17-34
5910-609-7473	CAPACITOR	77344	22020	16-5
5920-011-7142	HOLDER, FUSE	75915	311010	10-3
5930-132-8283	SWITCH	16764	1996041	10-2
5930-607-6280	THERMOSWITCH	82386	4738-2	13-23
5930-655-3562	SWITCH	880 44	AN3027-3	10-1
5977-391-4031	BRUSH	19728	MZ-12D	20-29
5977-553-4418	BRUSH	16764	29	19-9
5977-627-3579	BRUSH	19728	MZ-1034CS	20-28
5999-502-1857	SOLE PIECE	16764	1912725	19-32
6140-785-1098	BATTERY	06499	K-171-8	17-9
6620-377-6805	GAGE	51240	2550	9-11
6620-783-6614	GAGE	82386	A280-3014	9-6
6625-783-6615	AMMETER		MF2C	9-13
6645-557-8035	METER	74400	ML-972	9-10

TM 55-4920-226-15

SECTION III
NUMERICAL INDEX - PART II

FEDERAL STOCK NO.	ITEM NAME	MANUFACTURERS CODE	PART NO.	FIGURE AND INDEX NO.
6680-515-5910	TACHOMETER		2-214-10	9-9
6680-532-2915	INDICATOR		2-1183	9-15
6680-788-9283	TRANSMITTER	51240	A280-5008	30-12
6680-991-8579	GAGE	51240	4060	9-2
6685-585-4511	GAGE	04198	1377	9-3
6685-704-0849	GAGE		A300-5079	9-28
6685-783-6616	GAGE	82386	A280-3016	9-4

INDEX

	Paragraph	Page		Paragraph	Page
Adjustments:			Controls and instruments-Continued		
Brake lever assembly -----	76d	30	Pressure selector valve ---	36	14
Carburetor -----	122a	54	Reservoir level indicator --	14	11
Contact set -----	115c	47	Reservoir shutoff valve ---	15	11
Engine generator regulator	182d	92	Starter switch -----	20	12
Generator drive belt -----	112	43	Tachometer -----	21	12
Governor -----	135a	68	Throttle control -----	18	11
Tie rod -----	164a	85	Control panel assembly -----	107	38
Valve lifter -----	125b	60	Crankcase -----	200	110
Wheel bearing -----	163a	84	Crankcase bottom plate	192	103
Air cleaner -----	116	51	Crankshaft -----	196	108
Ammeter -----	23	13	Cylinder blocks -----	199	109
Arm and support assemblies ---	169	88	Cylinder heads -----	124	59
Axles -----	164	85	Cylinder shrouds and heat deflectors -----	119	53
Battery needs frequent recharging -----	64	21	Data -----	6	6
Bleeding air from the hydraulic system -----	70	23	Definition of radio interference suppression -----	99	35
Brake and cable assemblies --	167	87	Demolition by explosives or weapons fire -----	217	120
Brake does not hold -----	94	35	Demolition methods, other -----	218	120
Brake lever assembly -----	13, 76, 166	11,29,87	Demolition to render the equipment inoperative -----	216	119
Camshaft -----	197	109	Description -----	3	3
Carburetor -----	122	54	Detailed lubrication information	52	17
Choke control -----	17, 138e	11,71	Deviations in models -----	5	6
Compensator control -----	30	13	Drawbar and steering arm assemblies -----	75	29
Connecting rod and piston -----	195	105	Electrical engine starter -----	113,184	45, 96
Controls, engine -----	138	71	Electrical engine starter fails to operate -----	86, 177	34,91
Controls and instruments:			Engine -----	108	39
Ammeter -----	23, 137d	13, 70	Engine accessory generator ----	112, 183	43, 95
Brake lever assembly -----	13	11	Engine controls -----	138	71
Choke control -----	17	11	Engine exhaust smoky -----	62,85,176	21,34,90
Compensator control -----	30	13	Engine generator regulator -----	111, 187	42, 100
Filter pressure gage -----	34	14	Engine hard to start or fails to start -----	56,80,171	20,33,90
Filter pressure gage tap --	35	14	Engine instruments -----	137	70
Flow control valves -----	26	13	Engine knocks or develops excessive noise -----	60,84,175	21,34,90
Fluid bypass valve -----	16	11	Engine misses or runs erratically -----	57,81,172	20,33,90
Fluid flow indicator -----	28	13	Engine oil pressure low -----	61	21
Fluid pressure gage -----	31	13	Engine overheats -----	59, 83	20, 34
Fluid pressure gage tap -----	33	13	Engine stops suddenly -----	58,82,173	20,33,90
Fluid temperature gage ----	39	14	Engine will not idle smoothly --	174	90
Fluid volume control -----	27	13	Field preventive maintenance services -----	78	31
Gage dampener precharge valve -----	37	14	Filter, high pressure -----	142	75
Gage snubber valve -----	32	13			
Head temperature gage -----	24	13			
High pressure relief valve --	29	13			
Hourmeter -----	25	13			
Ignition switch -----	19	11			
Oil pressure gage -----	22	13			
Outlet pressure gage -----	22	13			
Outlet selector valve -----	38	14			

	Paragraph	Page		Paragraph	Page
Filter, low pressure -----	143	75	Magneto, ignition -----	115, 185	47, 98
Filter, oil -----	128	61	Manifold, intake and exhaust ---	123	57
Filter element replacement -----	71	23	Methods used to attain proper		
Filter pressure gage -----	34	14	suppression -----	102	36
Filter pressure gage tap -----	35	14	Movement to a new work site ---	44	15
Flow control valves -----	26, 150	13, 79	Muffler -----	11	54
Fluid bypass valve -----	16	11	Oil filler tube and sabre -----	2	61
Fluid flow indicator -----	28, 146	13, 77	Oil filter -----	9, 128	9, 61
Fluid pressure gage -----	31	13	Oil pressure gage -----	22, 137e	13, 70
Fluid pressure gage tap -----	33	13	Oil pump -----	193	104
Fluid temperature gage -----	39, 147	14, 77	Operating details -----	43	15
Fluid volume control -----	27	13	Operation at high altitude ---	50	16
Flywheel and flywheel shroud ---	118	51	Operation in dusty or sandy		
Frame assembly -----	211-212	18	areas -----	47	16
Fuel consumption excessive -----	63, 87	21, 34	Operation in extreme cold -----	45	16
Fuel pump and adapter -----	131	62	Operation in extreme heat -----	46	16
Fuel strainer -----	130	62	Operation in salt water areas ---	49	16
Fuel tank -----	132	66	Operation under rainy and		
Fuse holder -----	138c	71	humid conditions -----	48	16
Gage dampener precharge valve	37	14	Operator's daily services -----	54	19
Gage, filter pressure -----	34	14	Other demolition methods -----	218	120
Gage, fluid pressure -----	31	13	Outlet selector valve -----	38, 151	14, 80
Gage, head temperature -----	24	13	Preparation of equipment for		
Gage snubber valve -----	32, 150	13, 79	shipment -----	213	119
Gear cover -----	189	101	Pressure compensator control:		
Gear, timing -----	190	102	Cleaning, inspection, and		
Generator, engine accessory ---	112, 183	43, 95	repair -----	204	113
General source of interference	101	36	Disassembly -----	203	111
Governor -----	135	68	Installation -----	206	115
Governor control assembly ---	134	66	Reassembly -----	205	113
Head temperature gage -----	24	13	Removal -----	202	111
High pressure filter -----	142	75	Pressure gages -----	73	26
High pressure relief valve -----	29, 149	13, 77	Pressure selector valve -----	36, 151	14, 80
Hose assemblies -----	72	25	Pump, fuel -----	131	62
Hourmeter -----	25, 137c	13, 70	Pump, hydraulic -----	153-157,	80
Housing assembly -----	106, 159-161	38, 82		207-209	115
Hydraulic pump fails to deliver			Pump, oil -----	193	104
sufficient pressure -----	65, 95, 180	21, 35, 91	Purpose of interference		
Hydraulic pump fails to deliver			suppression -----	100	35
sufficient volume -----	66, 96, 181	21, 35, 91	Radio interference suppression:		
Hydraulic fluid temperature too			Definition -----	99	35
high -----	68, 98	21, 35	General sources of		
Hydraulic pump -----	153-157,	80	interference -----	101	36
	207-209	115	Interference suppression		
Hydraulic system pressure too			components -----	103	37
high -----	67, 97	21, 35	Methods used to attain		
Identification -----	4	6	proper suppression -----	102	36
Ignition magneto -----	115, 185	47, 98	Purpose of interference		
Ignitions witch -----	19, 138a	11, 17	suppression -----	100	35
Inspection of new equipment ----	8	9	Replacement of interference		
Inspection of used equipment ----	10	11	suppression components --	105	38
Instruments, engine -----	137	70	Testing interference		
Intake and exhaust manifold ---	123	57	suppression components --	104	37
Interference suppression			Regulator, engine generator ---	111	42
components -----	103	37	Record and report forms -----	2	3
Limited storage -----	214	119	Reservoir -----	105, 139	38, 72
Low pressure filter -----	143	75	Reservoir and control panel		
Lubrication:			support -----	140	74
Detailed lubrication			Reservoir level indicator -----	14, 145	11, 76
information -----	52	17	Reservoir shutoff valve -----	15, 150	11, 79
General -----	51	17			

	Paragraph	Page		Paragraph	Page
Scope -----	1	3	Troubleshooting - Continued		
Servicing new equipment -----	9	9	Engine exhaust smoky ---	62,85,176	21,34,90
Servicing used equipment -----	11	11	Engine hard to start or fails to start -----	56,80,171	20,33,90
Shroud and heat deflectors, cylinder -----	119	53	Engine knocks or develops excessive noise -----	60,84,175	21,34,90
Sources of interference -----	101	36	Engine misses or runs erratically -----	57,81,172	20,33,90
Spark plugs and ignition cables	114	47	Engine oil pressure low ---	61	21
Starter, electrical engine -----	113,184	45, 96	Engine overheats -----	51,83	17, 34
Starter switch -----	20, 138b	12,71	Engine stops suddenly ---	58,82,173	20,33,90
Starting the test stand -----	41	14	Engine will not idle smoothly -----	174	90
Stopping the test stand -----	42	15	Fuel consumption excessive	63,87	21,34
Switch, ignition -----	19, 138a	11,71	Hydraulic fluid temperature too high -----	68,98	21,35
Switch, starter -----	20, 138b	12,71	Hydraulic pump fails to deliver sufficient pressure	65,95,180	21,35,91
Tabulated data -----	6	6	Hydraulic pump fails to deliver sufficient volume	66,96,181	21,35,91
Tachometer -----	21	12	Hydraulic system pressure too high -----	67,97	21,35
Testing:			Tire wear abnormal or uneven -----	93	35
Electrical engine starter ---	184	96	Wheel bearings overheat --	92	34
Engine accessory generator	183	95	Wheel wobbles -----	91	34
Engine generator regulator	111,182	42,92	Unloading and unpacking of equipment -----	7	9
Fluid temperature gage ---	147	77	Valve, flow control -----	26,150	13,79
Fuel pump -----	131	62	Valve, fluid bypass -----	16	11
Head temperature gage ---	137	70	Valve, gage dampener pre-charge -----	37	14
Ignition switch -----	138	71	Valve, gage snubber -----	32,150	13,79
Magneto spark -----	115a	47	Valve, high pressure relief -----	29,149	13,77
Pressure gages -----	73	26	Valve lifters -----	125	59
Radio interference suppression components --	104	37	Valve, outlet selector -----	38,151	14,80
Reservoir level indicator --	145	76	Valve, pressure selector -----	36,151	14,80
Tachometer -----	137a	70	Valve, reservoir shutoff -----	15	11
Throttle control -----	18, 138d	11,71	Valve seat inserts and valve guides -----	187	100
Timing gears -----	190	102	Valves -----	186	99
Timing the engine -----	115h	50	Wheels -----	74,163	26,84
Tire wear abnormal or uneven	93	35	Wheel wobbles -----	91	34
Training -----	219	120	Wheel hearings overheat -----	92	34
Troubleshooting:					
Ammeter needle fluctuates rapidly -----	90,179	34,91			
Ammeter shows excessive charge -----	89	34			
Ammeter shows no charge or discharge with engine operating -----	88,178	34,91			
Battery needs frequent recharging -----	64	21			
Brake does not hold -----	94	35			
Electrical engine starter fails to operate -----	86,177	34,91			

By Order of the Secretary of the Army:

HAROLD K. JOHNSON,
General, United States Army,
Chief of Staff.

Official:

J. C. LAMBERT,
Major General, United States Army,
The Adjutant General.

Distribution:

To be distributed in accordance with DA Form 12-31 requirements for other literature of a general nature.

