

TM 55-4920-401-13&P

TECHNICAL MANUAL

**OPERATOR'S,
AVIATION UNIT AND AVIATION INTERMEDIATE
MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND
SPECIAL TOOLS LIST)**

FOR

**TESTER, EXHAUST GAS TEMPERATURE
MODEL BH112JB-53
(NSN 4920-00-372-4593)**

HEADQUARTERS, DEPARTMENT OF THE ARMY

15 NOVEMBER 1979

CHANGE
NO. 6

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 1 FEBRUARY 1994

OPERATOR'S, AVIATION UNIT AND AVIATION INTERMEDIATE
MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)

TESTER, EXHAUST GAS TEMPERATURE
BH112JB-53 (NSN 4920-00-372-4593)
BH112JB-79 (NSN 4920-01-209-0664)

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 55-4920-401-13&P, 15 November 1979, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

1-1 and 1-2
2-9 through 2-12
4-25 and 4-26
C-7 and C-8

Insert pages


1-1 and 1-2
2-9 through 2-12
4-25 and 4-26
C-7 and C-8

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

Official:


MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

06358

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 1376, requirements for TM 55-4920-401-13&P.

CHANGE

NO. 5

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 15 JULY 1993

OPERATOR'S, AVIATION UNIT AND AVIATION INTERMEDIATE
MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)

TESTER, EXHAUST GAS TEMPERATURE
BH112JB-53 (NSN 4920-00-372-4593)
BH112JB-79 (NSN 4920-01-209-0664)

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 55-4920-401-13&P, 15 November 1979, is changed as follows:

1. Title has been changed to add new Model and NSN as stated above.
2. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

i through iv
1-1 and 1-2
1-45 and 1-46

3-1 and 3-2
4-25 and 4-26
4-39 and 4-40

Insert pages

i through iv
1-1 and 1-2
1-45 and 1-46
1-46.1 through 1-46.5/
(1-46.6 blank)


3-1 and 3-2
4-25 and 4-26
4-39 and 4-40

3. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

Official:


MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army

04617

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 1376, requirements for TM 55-4920-401-13&P.

CHANGE }
NO. 4 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 1 March 1991

OPERATOR'S
AVIATION UNIT AND AVIATION INTERMEDIATE
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LISTS)

TESTER, EXHAUST GAS TEMPERATURE

MODEL BH112JB-53

(NSN 4920-00-372-4593)

TM 55-4920-401-13&P, 15 November 1979, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

i and ii
2-1 and 2-2
- - - -
2-7 through 2-10
2028's and Envelopes

Insert pages

i and ii
2-1 and 2-2
2-2.1/2-2.2
2-7 through 2-10
2028's and Envelopes

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARLE E. VUONO
General, United States Army
Chief of Staff

Official:

THOMAS F. SIKORA
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no 1376, -10 & CL, AVUM and AVIM maintenance requirements for TM 55-4920-401-13&P.

CHANGE }
No. 3 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 10 July 1989

Operator's
Aviation Unit and Aviation Intermediate
(Including Repair Parts and Special Tools Lists)

TESTER, EXHAUST GAS TEMPERATURE

MODEL BH112JB-53

(NSN 4920-00-372-4593)

TM 55-4920-401-13&P, 15 November 1979, is changed as follows:

1. Remove and insert pages as indicated below. New or changes text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove Pages	Insert Pages
i and ii	i and ii
1-45 and 1-46	1-45 and 1-46
3-1 and 3-2	3-1 and 3-2
4-1 and 4-2	4-1 and 4-2
A-1/A-2	A-1/A-2

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN II
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, -10 & CL, AVUM and AVIM Maintenance requirements for All Fixed and Rotary Wing Aircraft.

CHANGE }
No. 2 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 8 December 1987

Operator's
Aviation Unit and Aviation Intermediate
(Including Repair Parts and Special Tools Lists)

TESTER, EXHAUST GAS TEMPERATURE

MODEL BH112JB-53

(NSN 4920-00-372-4593)

TM 55-4920-401-13&P, 15 November 1979, is changed as follows:

1. Remove and insert pages as indicated below. New or changes text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

i and ii
1-1 and 1-2
2-1 and 2-2
2-11 and 2-12

A-1/A-2
B-1 and B-2

C-1 through C-52

Insert pages

i and ii
1-1 and 1-2
2-1 and 2-2
2-11 and 2-12
2-12.1/2-12.2
A-1/A-2
B-1 and B-2
B-2.1/B-2.2
C-1 through C-64

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

R. L. DILWORTH
Brigadier General, United States Army
The Adjutant General

CARLE E. VUONO
General, United States Army
Chief of Staff

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, -10 & CL, AVUM and AVIM Maintenance requirements for All Fixed and Rotary Wing Aircraft.

CHANGE }
No. 1 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 25 June 1981

Operator's,
Aviation Unit and Aviation Intermediate
Maintenance Manual
(Including Repair Parts and Special Tools Lists)

TESTER, EXHAUST GAS TEMPERATURE

MODEL BH112JB-53

(NSN 4920-00-372-4593)

TM 55-4920-401-13&P, 15 November 1979, is changed as follows:

1. Remove and insert pages as indicated below.

	Remove pages	Insert pages
Appendix C	C-1/C-2	C-1 thru C-52

2. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

3. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

E. C. MEYER
General, United States Army
Chief of Staff

Official:

J. C. PENNINGTON
Major General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, Operator Maintenance requirements for All Fixed and Rotor Wing Aircraft.

WARNING

Personnel performing operations, procedures, and practices which are included or implied in this technical manual shall observe the following warnings. Disregard of these warnings and precautionary information can cause serious injury, death, or destruction of material.

Operate the tester using a grounded three-wire power source.

Stop operation immediately if a defect is noted that could cause damage to the tester by continuing operation.

Do not tow the tester behind a vehicle, use as a step, or place it under aircraft dump valve.

Wear protective gloves while handling hot thermocouple heater probes.

OPERATOR'S, AVIATION UNIT AND AVIATION INTERMEDIATE
MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)

TESTER, EXHAUST GAS TEMPERATURE
BH112JB-53 (NSN 4920-00-372-4593)
BH112JB-79 (NSN 4920-01-209-0664)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual direct to: Commander, U.S. Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. A reply will be furnished directly to you.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited
TABLE OF CONTENTS

	Paragraph	Page
CHAPTER 1	INTRODUCTION	
Section I	General Information	1-1
II	Description and Leading Particulars	1-1
III	Test Equipment, Special Tools and Materials	1-46.5
CHAPTER 2	OPERATING INSTRUCTIONS	
CHAPTER 3	AVIATION UNIT MAINTENANCE INSTRUCTIONS	
Section I	Preparation for Installation, Storage, and Shipment	3-1
II	Installation	
III	Inspections and Servicing	3-4
IV	Preventive Maintenance	3-6
V	Operational Checkout	3-10
VI	Repair and Replacement of Authorized Parts	3-12
CHAPTER 4	AVIATION INTERMEDIATE MAINTENANCE INSTRUCTIONS	
Section I	Preparation for Maintenance, Storage, and Reshipment	4-1
II	Checkout and Analysis	4-4
III	Repair Procedures	4-9
IV	Reassembly and Alignment	4-11
v	Parts Listing	4-18
APPENDIX A - REFERENCES	A-1	A-1
APPENDIX B - MAINTENANCE ALLOCATION CHART	B-1	B-1
APPENDIX C - REPAIR PARTS AND SPECIAL TOOLS LIST	C-1	C-1
ALPHABETICAL INDEX		Index-1

LIST OF ILLUSTRATIONS

Figure	Title	Page
1-1	BH112JB-53 and BH112JB-79 Exhaust Gas Temperature Tester	1-2
1-2	Tester Block Diagram (Sheet 1 of 2)	1-3
1-2	Tester Block Diagram (Sheet 2 of 2)	1-4
1-3	Block Diagram of A/D Converter	1-5
1-4	Integrator	1-6
1-5	Charge-Discharge Curves of Linear A/D Converter	1-7
1-6	Charge-Discharge Curves of Nonlinear A/D Converter	1-7
1-7	Typical Reference Voltage Shaping	1-8
1-8	Comparator	1-9
1-9	FET Switch Control	1-9
1-10	Circuitry That Generates Transfer-to-Memory	1-10
1-11	Clock Oscillator	1-10
1-12	Typical Display and Counter Board Circuitry	1-11
1-13	Temperature Indicator Compensator	1-12
1-14	Temperature Indicator Amplifier Circuit	1-13
1-15	Temperature Indicator Reference Voltage Divider	1-14
1-16	Temperature Signal Flow Diagram (for Aircraft Indicator Check, Spread, Heater Probe, Trim, and Calibrator Signals)	1-15
1-17	Temperature Signal Flow Diagram (for Heater Probe Temp Set Signal)	1-16
1-18	Aircraft Indicator Check Circuit for D-Arsonval Indicators	1-17
1-19	Aircraft Indicator Check Circuit for Null-Balance Indicators	1-18
1-20	Partial Schematic of Tach Converter	1-19
1-21	% RPM Signal Flow Diagram	1-20
1-22	Schematic Diagram of Standard Day Correction Circuit	1-22
1-23	Insulation Check Circuit (Simplified Schematic)	1-23
1-24	Resistance Check Circuit (Simplified Schematic)	1-24
1-25	Power Flow Block Diagram	1-26
1-26	Integrated Circuit Pin Locations	1-27
1-27	Quad 2-Input NOR Gate	1-28
1-28	Dual D-Type Flip-Flop	1-29
1-29	Triple 3-Input NAND Gate	1-30
1-30	Functional Diagram of 7-Stage Binary Counter	1-31
1-31	Seven-Segment LED Display	1-32
1-32	Counter-Latch-Decoder	1-33
1-33	Quadruple 2-Input NAND Gate	1-35
1-34	Quad 2-Input NOR Gate	1-35
1-35	Dual D-Type Edge-Triggered Flip-Flop	1-36
1-36	Dual J-K Master-Slave Flip-Flop	1-37
1-37	Clock Waveform to Master-Slave Flip-Flop	1-37
1-38	Decade Counter	1-38
1-39	Resistor Network Schematic	1-39
1-40	Tester Indicators and Controls	1-41
1-41	Probe Controller Support	1-47
2-1	Thermocouple Systems Continuity Check Setup	2-2
2-2	Temperature Systems Accuracy Check Setup	2-3
2-3	Thermocouple and Harness Check Setup	2-5
2-4	D'Arsonval Temperature Indicator Check Setup	2-6
2-5	Null Balance Temperature Indicator Check Setup	2-6
2-6	Temperature Circuit Resistance Check Setup	2-8
2-7	Insulation Resistance Check Setup	2-8
2-8	Temperature Spread Test Setup	2-9

List of Illustrations (Continued)

Figure	Title	Page
2-9	Switch Box	2-10
2-10	Engine Trim Check Setup Using Trimmer in Tester	2-10
2-11	Engine Trim Check Setup Using Trimmer Removed from Tester	2-11
2-12	RPM Indicator Check Setup	2-12
2-13	Heat Detection System Check Setup	2-13
3-1	Shipping Pallet	3-2
4-1	Temperature Indicator Test Setup	4-2
4-2	% RPM Indicator Test Setup	4-3
4-3	Test Setup of Heater Probe Control Circuit	4-3
4-4	Switch-Power Board, BH15720-3, Test Points	4-15
4-5	Probe Control and Function Switch Board, BH15801-1, Test Points (Sheet 1 of 2)	4-16
4-5	Probe Control and Function Switch Board, BH15801-1, Test Points (Sheet 2 of 2)	4-17
4-6	Calibrator Board, BH16365-1, Test Points	4-18
4-7	Indicator Waveforms	4-19
4-8	Temperature Board, BH15715-1, Test Points	4-20
4-9	Tachometer Board, BH15717-1, Test Points	4-21
4-10	Trimmer Test Points and Adjustments	4-25
4-11	Trimmer Assembly, BH15195A-8, Schematic	4-27
4-12	Mother Board, BH15719-2, Schematic	4-28
4-13	Display Board, BH16358-2, Schematic	4-29
4-14	Switch Box, BH123-3, Schematic	4-30
4-15	Junction Box, BH361-8, Schematic	4-30
4-16	Heater Cable, BH405, Schematic	4-31
4-17	Check Cable, BH450, Schematic	4-31
4-18	Instrument Cable, BH485, Schematic	4-31
4-19	Power Cable, BH499A, Schematic	4-32
4-20	RPM Check Adapter, BH820, Schematic	4-32
4-21	Insulation Check Adapter, BH821, Schematic	4-32
4-22	EGT Indicator Check Adapter, BH822, Schematic	4-33
4-23	Resistance Check Adapter, BH823, Schematic	4-33
4-24	Heater Probe, BH996-40, Schematic	4-33
4-25	Check Cable Adapter, BH1504, Schematic	4-34
4-26	Check Cable Adapter, BH4548, Schematic	4-34
4-27	CAL ADJ Potentiometer Installation Detail	4-37
4-28	Power SCR Installation Detail	4-38
4-29	BH112JB-53 and BH112JB-79 Jetcal Tester	4-41
4-30	BH16700-12 Accessory Kit	4-43
4-31	BH15720-3 Switch-Power Board Assembly	4-48
4-32	BH15719-2 Mother Board Assembly	4-51
4-33	BH16358-2 Display Board Assembly	4-52
4-34	BH15715-1 Temperature Board Assembly	4-54
4-35	BH15717-1 Tachometer Board Assembly	4-57
4-36	BH16365-1 Calibrator Board Assembly	4-60
4-37	BH15801-1 Probe Control and Function Switch Board Assembly	4-64
4-38	BH16367-3 Resistance and Insulation Check Board Assembly	4-67
4-39	H122 Accessory Case	4-70
FO-1	Schematic Diagram of Heater Probe Control Circuit	
PO-2	Probe Controller Assembly, BH15194A-4, Schematic	
FO-3	Switch-Power Board, BH15720-3, Schematic	
FO-4	Temperature Board, BH15715-1, Schematic	
FO-5	Tachometer Board, BH15717-1, Schematic	

List of Illustrations (Continued)

Figure	Title	Page
FO-6	Calibrator Board, BH16365-1, Schematic.....	
FO-7	BH15195A-8 Trimmer Assembly.....	
FO-8	BH1519A-4 Probe Controller Assembly.....	
FO-9	BH15835-2 Instrument Case Assembly.....	

List of Tables

Table	Title	Page
1-1	NOR Gate Truth Table.....	1-28
1-2	Truth Table for D-Type Flip-Flop.....	1-29
1-3	Truth Table for 3-Input NAND Gate.....	1-30
1-4	LED Display Pin Functions.....	1-33
1-5	Counter-Latch-Decoder Functional Truth Table.....	1-34
1-6	Truth Table of 2-Input NAND Gate.....	1-35
1-7	NOR Gate Truth Table.....	1-36
1-8	Truth Table for D-Type Flip-Flop.....	1-37
1-9	J-K Flip-Flop Truth Table.....	1-38
1-10	Decade Counter Truth Table.....	1-39
1-11	Leading Particulars.....	1-40
1-12	Indicator and Control Functions.....	1-42
1-13	Accessory Functions.....	1-44
1-14	Basic Accessories Required for Most Aircraft.....	1-45
1-15	Special Tools and Test Equipment.....	1-46.5
1-16	Consumable Materials.....	1-47
3-1	Accessories List.....	3-1
3-2	Troubleshooting Table.....	3-5
4-1	Temperature Indicator Accuracy Check Table.....	4-2
4-2	Standard Day Circuit Test Table.....	4-4
4-3	Spread Circuit Check Table.....	4-5
4-4	General Troubleshooting Table.....	4-8
4-5	TEMP °C Indicator Troubleshooting Table.....	4-8
4-6	% RPM Indicator Troubleshooting Table.....	4-9
4-7	Standard Day Circuit Troubleshooting Table.....	4-9
4-8	Heater Probe Control Circuit Troubleshooting Table.....	4-10
4-9	Insulation Check Circuit Troubleshooting Table.....	4-11
4-10	Resistance Check Circuit Troubleshooting Table.....	4-12
4-11	Aircraft Indicator Check Circuit Troubleshooting Table.....	4-13
4-12	DC Power Supply Voltages.....	4-14
4-13	Indicator Data Table.....	4-22
4-14	Heater Probe Control Circuit Waveforms.....	4-23

Chapter 1

INTRODUCTION

Section I. GENERAL INFORMATION

1-1. SCOPE. The purpose of the BH112JB-53 and BH112JB-79 Exhaust Gas Temperature Tester (fig. 1-1) is to provide ground support for gas turbine aircraft engines. When the appropriate cables and accessories are used with the tester, it can perform any of the following functions

- a. Test Engine thermocouple harness for error.
- b. Test continuity of thermocouples in parallel engine harness.
- c. Test aircraft temperature indicator.
- d. Test resistance of aircraft temperature circuit.
- e. Test insulation of aircraft temperature circuit.
- f. Verify accuracy of aircraft rpm system.
- g. Verify accuracy of aircraft temperature indicating system.

h. Monitor temperature during engine trimming.

i. Monitor rpm during engine trimming.

j. Check cockpit instruments directly by using portable trim module in cockpit.

k. Automatically correct temperature and rpm to standard day conditions.

l. Test temperature spread.

m. Test individual thermocouples on bench.

n. Test thermal switches on aircraft or bench.

1-2 FORMS AND RECORDS. Maintenance forms, records and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by DA PAM 738-751.

Section II. DESCRIPTION AND LEADING PARTICULARS

1-3. PHYSICAL DESCRIPTION. The BH112JB-53 and BH112JB-79 Exhaust Gas Temperature Tester consists of an instrument case assembly (2 fig. 1-1) and an accessory case assembly (1, fig. 1-1). The instrument case latches to the top of the accessory case and contains two assemblies—a portable trimmer assembly (3, fig. 1-1) and a probe controller assembly. Two wheels, a support post, and a handle provide mobility for the tester. Cables and accessories needed to operate the tester are housed in the accessory case.

1-4. ELECTRICAL DESCRIPTION.

a. General Theory of Operation.

(1) **Block Diagram.** Figure 1-2 is a block diagram of the tester. All circuitry is located in the probe controller and trimmer. Input power distribution is shown with two lines. All other power and signal connections are shown with single lines for simplicity. Function switching is omitted for the same reason. Board and cable connectors reference designations are shown in parentheses.

(2) **Digital Indicators.** The trimmer contains two solid state indicators (analog-to-digital converters) for measuring temperature and engine speed (% rpm). Each indicator circuit is on a printed circuit board (temperature board or tachometer board) that plugs into the mother board. Displays for the indicators are located on the display and counter board which also plugs into the mother board. Brightness of the displays is adjusted with the DISPLAY potentiometer. Two calibration signals for the indicators are generated by the calibrator board. One is an equivalent 600°C chromel-alumel signal and the other is a crystal-controlled 70 Hz signal. External calibration adjustments of an indicator are made with its respective CAL ADJ potentiometer.

(3) **Standard Day Measurements.** For the Purpose of comparing an engine's performance against the manufacturer's specifications, engine temperature and speed measurements are corrected to standard day conditions. During the engine trimming procedure, egt and % rpm measurements, corrected to standard day condition, are obtained by turning the AMB TEMP potentiometer to display ambient temperature and the STD DAY switch on ON.




Figure 1-1. BH112JB-53 and BH112JB-79 Exhaust Gas Temperature Tester




Figure 1-2. Tester Block Diagram (Sheet 1 of 2).




Figure 1-2. Tester Block Diagram (Sheet 2 of 2).

(4) **Probe Controller.** The probe controller portion of the tester contains circuitry that controls the heating of various types of temperature probes. The temperature to which a probe is to be heated is set using the PROBE CONTROL while observing the setting on the TEMP °C indicator. Precision thermocouples in the temperature probes accurately measure the probe temperature which is displayed by the TEMP °C indicator. Both the set temperature signal and the measured temperature signal are applied to a voltage comparator in the probe control circuit. This circuit drives the gates of SCR's 1 and 2 and controls the application of full-wave power from transformer T1 to the heater probes. The PROBE POWER lamp burns continuously when continuous power is applied to the probes. It extinguishes when power is removed from the probes and flashes when their temperature is regulating.

(5) **Insulation Check Circuit.** This circuit measures the insulation resistance between the aircraft thermocouple harness and aircraft ground. The INSULATION CHECK meter is an ohmmeter having two ranges-RX100 and RX1000. The circuit is powered by a 9 vdc supply on the probe control and function switch board.

(6) **Resistance Check Circuit.** The resistance check circuit is used to check and adjust the resistance of the aircraft thermocouple circuit. The RESISTANCE CHECK meter is the galvanometer of a Wheatstone bridge. One leg of the bridge contains a precision wirewound resistor selected with the RESISTANCE & A/C INDICATOR CHECK switch. The other leg contains the aircraft thermocouple circuit (less the indicator). Correct resistance is obtained in aircraft circuit by adjusting resistance spool while observing galvanometers.

(7) **Aircraft Indicator Check Circuit.** This circuit may be used to check the calibration of both D-Arsonval and null-balance type egt indicators. The appropriate aircraft indicator circuit is selected with the RESISTANCE and A/C INDICATOR CHECK switch. Calibration signals are adjusted with the A/C IND ADJ while they are read on the TEMP °C indicator. Calibration signals are compared with aircraft indicator readings to determine the error in the aircraft indicator.

b. Detailed Theory of Operation. The detailed theory of operation will be discussed in the following order:

- (1) A/d conversion.
- (2) Temperature indicator.

- (3) Temperature signal circuits.
- (4) % rmp indicator.
- (5) % rpm signal circuits.
- (6) Standard day correction circuit.
- (7) Heater probe control circuit.
- (8) Insulation check circuit.
- (9) Resistance check circuit.
- (10) Power supplies and power distribution.
- (11) Logic circuitry.

Logic levels and integrated circuits used in the tester are described in paragraph 1-4b, 1-11 c and following.

(1) **A/D Conversion.**

(a) **An Overview.** Figure 1-3 is a block diagram of circuitry common to both tester A/D converters. The A/D converters use the "dual-slope integration" technique. The slopes refer to the charge and discharge curves of integrating capacitor C, figure 1-3. C is charged by the integrator during a fixed interval of time called the signal integration period when the amplified input signal is allowed to pass through the signal field-effect transistor (FET) switch and drive the integrator. The signal integration period is controlled by the continuously running clock oscillator, BCD decade counters, BCD-DAC decoding, and FET switch control. At the conclusion of the signal integration period, which is the beginning of the reference integration period, the counters are reset, the signal FET switch is opened, and the appropriate reference FET switch (+ or - reference) is closed. During the reference integration period, the integrating capacitor is discharged by the integrator. The discharging voltage is a +5 vdc if the input signal is negative and it is the output of a precision negative reference voltage divider if the input signal is positive. If the input signal is in-range, the comparator detects the instant the capacitor is completely discharged and clocks flip-flop FF1A, causing the generation of a transfer-to-memory pulse, ending the reference integration period. Transfer-to-memory (TRANSFER, fig. 1-3) shifts the "reference integration period" count, which represents the digitized input signal, into the latches of the counter-latch-decoders, updating the display. If the input signal is negative, this fact is detected by FF2A at the start of the reference integration period and FF2A causes FF1A to be cleared, generating transfer-to-memory. If the input signal exceeds the range of the indicator, out-of-range decoding causes FF1A to be cleared and generate transfer-to-memory. A positive or nega-




Figure 1-3. Block Diagram of A/D Converter.

tive out-of-range input signal causes an indicator's display to flash on and off through the action of the blanking signal.

(b) **Equations.** Dual-slope integration of a linear A/D converter, like the % rpm converter, is defined by the following equation:

$$\frac{V(\text{amplified signal}) \times \int \text{signal counts}}{V(\text{reference}) \times \int \text{reference counts}} =$$

A linear A/D converter uses a constant reference voltage. A non-linear A/D converter, like the temperature converter, uses a stepped (shaped) reference voltage. Nonlinear dual-slope integration is defined by the following equation:

$$\frac{V(\text{amplified signal}) \times \int \text{signal counts}}{V(\text{reference 1}) \times \int \text{reference 1 counts} + V(\text{reference 2}) \times \int \text{reference 2 counts} + \dots} =$$

(c) **Integrator.** The integrator (fig. 1-4)

charges and discharges the integrating capacitor with current that is proportional to the integrator input voltage. Since the input voltage is applied to the inverting (-) input, the integrator charges the capacitor negatively when a positive voltage is applied, and positively when a negative voltage is applied. Figure 1-5 shows typical charge-discharge curves of a linear A/D converter and figure 1-6 illustrates curves of a nonlinear converter. Both figures have two sets of curves representing positive readings R1 and R2. Note in figure 1-5 that the discharge rate of a linear A/D converter is a constant. Hence, a constant reference voltage is used by linear A/D converters, such as the % rpm indicator, when standard day measurements are not being made. On the other hand, note in figure 1-6 that the discharge rate of a nonlinear A/D converter, such as the temperature indicator, varies in increments (S1, S2 . . .) as the reference count increases. The discharge curve is an "amplified reflection" of the




Figure 1-4. Integrator.




Figure 1-5. Charge-Discharge Curves of Linear A/D Converter.




Figure 1-6. Charge-Discharge Curves of Nonlinear A/D Converter.




Figure 1-7. Typical Reference Voltage Shaping.

(d) **Comparator.** The output of the integrator is applied to the noninverting (+) input of the comparator (fig. 1-8). The output of the comparator swings to 0 vdc when a positive voltage is applied to the integrator and to +5 vdc when a negative voltage is applied to the integrator.

(e) **FET Switch Control.** Three junction field-effect transistors (Q5-Q7, fig. 1-9) control the input to the integrator. The output of the signal amplifier is controlled by Q5, the positive reference voltage is controlled by Q6, and the negative reference voltage is controlled by Q7. The FET controlling signals are the comparator output and a decoded signal, INTEGRATE SIGNAL, which is low during its active period.

1. At the beginning of the signal integration period, INTEGRATE SIGNAL goes to logic 0, turning Q1 on and Q2 off. The values of R1 and R3 are such that Q2 remains off even if the comparator output goes to 0 vdc. Q3 and Q4 turns on. Plus 15 vdc from Q3 turns on Q5. Minus 15 vdc from Q4 turns off Q6. Minus 15 vdc also turns off Q7.

2. At the beginning of the reference integration period, INTEGRATE SIGNAL goes to logic 1, turning off Q1, Q3, and Q5. At the same time, Q2 is enabled so that 0 vdc from the comparator can turn on Q2. If the input signal is positive, the com-

parator will have a 0 vdc output at the end of the signal integration period and will turn on Q2. Logic 1 voltage from Q2 will turn on both Q4 and Q7. Q4 holds Q6 off, keeping the positive reference voltage off. The negative reference voltage is turned on by Q7. If the input signal to the A/D converter is negative, then the output of the comparator will be +5 vdc at the end of the signal integration period. Q2 will turn off, reversing the sequence for a negative input signal. The positive reference voltage will be turned on and the negative reference will be turned off.

3. The period from the conclusion of the reference integration period to the beginning of the subsequent signal integration period is referred to as the oscillate period. During the oscillate period, the integrator output is kept close to 0 vdc by rapidly and alternately turning on and off the positive and negative reference voltage FET's. This high frequency oscillation ends when INTEGRATE SIGNAL goes low.

(f) **Generation of Transfer-to-Memory.** At the conclusion of the reference integration period, transfer-to-memory transfers the contents of the counter-latch-decoder counters on the display-counter board into the latches, updating the numerical display. Transfer-to-memory is




Figure 1-8. Comparator.




Figure 1-9. FET Switch Control.




Figure 1-10. Circuitry That Generates Transfer-to-Memory.

generated when FF1A (fig. 1-10) is cleared. FF1A may be cleared in one of two ways: (1) when it is clocked by the comparator at the conclusion of the reference integration period of an in-range signal, and (2) by the out-of-range signal (OOR) when the input signal is detected to be negative or positive out-of-range. Positive out-of-range signals are detected by out-of-range decoding (fig. 1-3) and negative out-of-range signals cause the comparator to set FF2A at the conclusion of the signal integration period. FF1A (fig. 1-10) is preset at the beginning of the signal integration period.

(g) **Clock Oscillator.** The clock oscillator (fig. 1-11) provides the time base for the signal and reference integration periods. It consists of a relaxation oscillator and pulse amplifier transistor. Oscillator frequency is determined by the type of input signal and indicator range.

(h) **Display and Counter Board.** The clock oscillator signal (CLOCK) from each A/D converter is applied to a string of counter-latch-decoder (CLD) integrated circuits (fig. 1-12) on the display and counter board. The counter-latch-decoders drive resistor devices (RD's) which in turn drive the dis-




Figure 1-11. Clock oscillator.




Figure 1-12. Typical Display and Counter Board Circuitry.

plays (I's). Since the CLD's have no BCD decade counter output; for BCD-DAC decoding, BCD decade counters (DC's) are added to the display and counter board for this purpose. LAMP TEST, generated by the PRESS TO TEST switch, lights all segments in the displays. RESET, from the A/D converter, resets the counter-latch-decoders at the beginning of the reference integration period. TRANSFER-TO-MEMORY, from the A/D converter, transfers the CLD count into the CLD latches at the conclusion of the reference integration period to update the display. The blanking

input of the CLD's is controlled by FF2B (fig. 1-3) and goes high to blank an indicator display on every other reading when the input signal to the indicator is out-of-range.

(2) *Temperature Indicator.* The following subparagraphs describe circuitry that is unique to the temperature indicator.

(a) *Temperature Signal Conditioning.* A thermocouple circuit is formed when the thermocouple wire of the measuring junction is connected to the copper wiring of the A/D converter at the Compensator (fig. 1-13). The junction at the




Figure 1-13. Temperature Indicator Compensator.

compensator is called the reference junction. Any variation in the temperature of the reference junction will cause either an increase or decrease in the signal voltage. To measure temperature accurately, the reference junction must either be held at a constant temperature or referenced to a voltage which varies with temperature and in relation to the thermocouple curve. The compensator generates a reference voltage through the use of a thermal resistor,

R_T . The negative thermocouple lead is connected with copper wire to the higher potential end of this resistor. The thermal resistor, having a positive temperature coefficient, modifies the reference voltage when the ambient temperature increases. To assure that their temperatures are the same, the reference junction and thermal resistor are encapsulated.




Figure 1-14. Temperature Indicator Amplifier Circuit.

1. The input signal is filtered by an R-C network consisting of R28, C18, R29, and C19 (fig. 1-14). A voltage divider incorporating a potentiometer (R31) makes it possible to adjust the indicator so it will drift upscale, downscale, or remain constant when the input is open. The voltage divider supply (9 vdc) is controlled by Q10 which in turn is driven by the output of amplifier A1. Q10 limits the voltage on the filter capacitors when the potentiometer is adjusted for upscale drift.

2. The input signal is applied to the non-inverting input of amplifier A1. A full-scale signal is amplified to approximately 8.8 vdc. Applied to the inverting input is the signal from a zero adjust circuit that has the configuration shown in figure 1-14 when the STD DAY switch is off. The zero adjust circuit balances out the fixed compensator output and amplifier offset voltages. R59 controls the gain of the amplifier and calibrates the A/D converter at the high end of the range.

(b) *Reference Voltage Divider.* The precision reference voltage divider consisting of resistors R46-R52 is shown in figure 1-15. Transistors Q11-Q15 ground different points of the divider during the reference integration period and "shape"

the reference voltage, generating a reference voltage curve that closely approximates the input signal curve. A transistor turns on when the cathode of one of biasing zener diodes CR1-CR5 (2.6v) goes to logic 0. The biasing circuits are controlled by flip-flops on the temperature A/D converter board. Note in figure 1-15 that all transistors are off during reference count 0-99. Transistor Q14 turns on during counts 100-299, etc. The STD DAY switch grounds the gate of Q17 in OFF position and turns Q17 on.

(3) *Temperature Signal Circuits.* The following subparagraphs explain all temperature input signal circuitry except the standard day circuitry. Figures 1-16 and 1-17 show the temperature input circuits. No attempt has been made to show the circuits in detail, but merely to show the course of each signal path so that a circuit can be traced easily when troubleshooting. A single broken line is shown for each path, whereas in reality, a circuit contains two leads and passes through two sets of switch poles and two sets of switch contacts. Copper-constantan thermocouple wire is used to wire the thermocouple input circuits because it is easier to solder and its thermal characteristics are identical to chromel-alumel wire at normal ambient temperatures.




Figure 1-15. Temperature Indicator Reference Voltage Divider.





Figure 1-16. Temperature Signal Flow Diagram (for Aircraft Indicator Check, Spread, Heater Probe, Trim, and Calibrator Signals).



* PROBE CONTROL IS NOT EXCITED UNLESS FUNCTION SELECT SWITCH IS IN HEATER PROBE POSITION.

Figure 1-17. Temperature Signal Flow Diagram (for Heater Probe Temp Set Signal).

(a) *Aircraft Indicator Check Circuits.* The aircraft indicator check circuits (figs. 1-18 and 1-19), located in the probe control section of the analyzer/trimmer, supply calibration check signals to the TEMP indicator and to the aircraft indicator simultaneously. Switch poles are identified in these figures and poles of the same switch are joined with broken lines. When checking a

D'Arsonval type indicator, the appropriate resistance (R21-R25, fig. 1-18) is selected with the RESISTANCE & A/C INDICATOR CHECK switch. Since null-balance indicators do not draw current when they are balanced, R19 in figure 1-19 assures that the A/C IND ADJ has approximately the same range as it does in the circuit of fig. 1-18.




Figure 1-18. Aircraft Indicator Check Circuit for D'Arsonval Indicators.

(b) *Spread Circuit.* Spread signals (fig. 1-16) are applied through the spread cable to the SPREAD CABLE receptacle on the probe control. Eight chromel signals are applied to eight poles of the SPREAD switch on the probe control and function switch board. Each pole supplies its signal through a different contact position corresponding to one of eight engine thermocouples. In any posi-

tion of S4, except ALL, one of the chromel leads is connected to the SPREAD position of deck 7 of the FUNCTION SELECT switch. In the ALL position, all chromel leads are connected to the SPREAD position of deck 7. The alumel lead is common to all the alumel leads and is connected to the SPREAD position of deck 8 of the FUNCTION SELECT switch.




Figure 1-19. Aircraft Indicator Check Circuit for Null-Balance Indicators.

(c) **Heater Probe Temperature Circuit.** The averaged heater probe temperature signal of the precision thermocouples in the heater probes is applied through the heater cable (fig. 1-16) to the HEATER CABLE receptacle. This signal is selected by the T/C INPUT switch and applied to the "heater probe" contacts of decks 7 and 8 of the FUNCTION SELECT switch.

(d) **Trim Circuit.** The averaged egt signal from the engine thermocouple harness is applied through the check cable (fig. 1-16) to the CHECK CABLE receptacle on the trimmer. This signal is selected by the T/C INPUT switch and applied to the "trim" contacts of decks 7 and 8 of the FUNCTION SELECT switch.

(e) **Temperature Indicator Calibration Circuit.** The temperature indicator calibration signal generator is on the calibrator board (fig. 1-16) in the trimmer. A2 and A3 on this board form an isolated power source that generates approximately 22 vdc at C14. This power source drives A4 which provides a source of constant current for 9 vdc zener diode CR11. The 9 vdc from CR11 powers compensator MOD-1, which is identical to the compensator in the temperature indicator. Since the compensator outputs are series opposed, the thermocouple effect is cancelled. R3 on the calibrator board adjusts the calibration signal to an equivalent 600° C.

(f) **Heater Probe Temperature Set Circuit.** The heater probe temperature set circuit (fig.

1-17) sets the temperature to which heater probes are heated. Eighteen and one-half vac from a secondary winding of transformer T1 in the trimmer is half-wave rectified by CR12 on the probe control and function switch board. This rectified voltage is filtered by C11 and C12 and voltage regulated to 9 vdc by R27, R28, CR13, and CR14. The 9 vdc passes through deck 3 of the FUNCTION SELECT switch when it is in HEATER PROBE position and excites the PROBE CONTROL potentiometer. Current from the PROBE CONTROL wiper passes through R19 and R20 on the probe control circuit. The voltage developed across R20 represents the heater probe set temperature and is applied directly to the input filter of the temperature indicator,

(4) % **RPM Indicator.** The following is a description of circuitry that is unique to the % RPM indicator. The indicator measures the rotational speed (% rpm) of the low pressure (N1) and high pressure (N2) compressors. The selected tachometer signal is applied through C17 and R30 on the tachometer board to the inverting input of amplifier A3. Connected to the noninverting input is the common signal return. Diodes CR2 and CR3 clamp the

input signal level to 0.7 vdc. The output of A3 is adjusted to a symmetrical square wave by R26. Negative half-cycles of the input signal cause optical coupler OC1 to conduct and turn on Q13. Plus 15 vdc from Q13 turns on Q12 (fig. 1-20) during the negative half-cycle. During the positive half-cycle, Q13 turns off and -15 vdc through R37 turns on Q11. When Q12 turns on, C19 is charged by +9 vdc through two precision resistance paths. One path contains R47 and the other path contains R48, R49, and R50. When Q12 turns off and Q11 turns on, C19 discharges through two precision resistance paths. One path contains R48 and the other path contains R47, R49, and R50. Since resistors R47 and R48 are equal (3.7K), the resistance path containing R50 is equal for both charge and discharge current. Both the charge and discharge currents develop equal positive pulses across resistor R50. These pulses charge filter capacitors C20 and C21 at the input of amplifier A4. The gain of A4 is adjusted with R44 and R45 and the zero calibration point is adjusted with R41 when the % RPM indicator CAL ADJ pot is set to the center of its range.




Figure 1-20. Partial Schematic of Tach Converter.

(5) **% RPM Signal Circuits.** The % rpm signal circuits are shown in figure 1-21. The % RPM indicator calibration signal generator is on the calibrator board in the trimmer. The circuitry of crystal XT1 and gates G2B, C, D forms a crystal controlled

oscillator with a frequency of 455K Hz. Binary counters BC1 and BC2 and gates G1A,B and G2A divide the frequency by 3250 to 140 Hz and FF1 divides the frequency by 2 to 70 Hz.




Figure 1-21. % RPM Signal Flow Diagram.

(6) **Standard Day Correction Circuitry.** The standard day circuit, when activated, corrects temperature and % rpm readings to standard day conditions during engine trim. To activate the circuitry, set ambient temperature on the AMB TEMP potentiometer, turn the FUNCTION SELECT switch to TRIM, the TEMPERATURE switch to OPERATE, the RPM switch to N1 or N2, and the STD DAY lamp burns continuously if the other switches are in their correct positions. If one or more of the other switches named above are not "in position", the STD DAY lamp flashes.

(a) **STD DAY lamp Circuit.** The circuitry that controls the STD DAY lamp is located on the

switch-power board. Q16 drives the STD DAY lamp when the STD DAY switch is on. When all above named switches are in the proper position, Q17 turns on Q16. The STD DAY lamp burns continuously. If a switch is "out-of-position", the base circuit of Q18 is returned to ground through the switch. Q18 turns on, turning off Q17 and Q16. C12 and C13 charge until the emitter-base junction of Q17 becomes forward biased, at which point Q17 and Q16 turn on again.

(b) **Standard Day Equations.** Standard day corrections are made according to the following equations:

$$\text{Corrected temperature (}^\circ\text{C)} = \frac{\text{uncorrected temperature (}^\circ\text{C)} + 273}{0}$$

$$-273, \text{ Corrected percent rpm} = \frac{\text{uncorrected percent rpm}}{0}$$

where 0 = observed ambient temperature (°F) + 460
519
or 0 = observed ambient temperature (°C) + 273

An investigation of these equations will show that standard day readings are lower than uncorrected readings when the ambient temperature is above standard day temperature (59° F or 15° C) and higher than uncorrected readings when the ambient temperature is below standard day temperature.

(c) Standard Day Correction Circuit Schematic. Figure 1-22 is a schematic diagram of the standard day correction circuit. Note that when the STD DAY switch is on, Q17 on the temperature board turns off, removing the "uncorrected" reference divider from the temperature converter, and Q18 turns on. Likewise, Q8 on the tachometer board turns off and Q9 turns on. Note also that when standard day corrections are being made, temperature amplifier A1 becomes referenced to the combined effects of two voltage sources, -9 vdc and the output of A1 on the calibrator board. The AMB TEMP potentiometer adjusts the gain of A1 on the calibrator board in relation to ambient temperature. If ambient temperature increases, the gain of A1 is increased and causes higher negative reference voltages to be generated by A4 on the temperature board and A7 on the tachometer board. Higher reference voltages decrease the reference integration period for a given input signal and consequently create lower readings. The circuitry of A5 and Q10 on the tachometer board increases the slope of the corrected % rpm curve above 49° F (9.4° C) ambient temperature setting. Q10 turns on at the 49° F ambient temperature setting and parallels resistors R63 and R64.

(7) Heater Probe Control Circuit. The heater probe control circuit regulates the application of power to heater probes and allows them to be heated to the set temperature.

(a) When the FUNCTION SELECT switch (fig. FO-1) is turned to HEATER PROBE position, 28 vdc from the switch energizes K1, applying input power to transformer TB1. T1B steps up the voltage to 135 vac. This 135 vac heats the probes and is controlled by SCR's 1B and 2B.

(b) It is desirable to apply heater voltage to the heater probes when the voltage is passing through 0 vac in order to prevent the generation of voltage spikes and the accompanying radio frequency interference. This is accomplished by controlling the inputs of comparator A2 with 18.5 vac (test point 42), which is in phase with the heater probe excitation voltage.

(c) Setting the desired probe temperature with the PROBE CONTROL adjusts the dc level at

the inverting (-) input of comparator A1. Probes are heated when this level is more positive than the heater probe thermocouple signal level at the non-inverting (+) input. Added to the dc level at the - input is an exponential voltage of approximately 3 Hz generated by unijunction oscillator Q3. This voltage, having an amplitude equivalent to approximately 10° C, provides the time base for the heater duty cycle when the set temperature is being approached and lessens probe temperature overshoot and undershoot.

(d) When the circuit is requesting heat, the output of A1 goes to -15 vdc, back biasing diode CR1. Test point 4.2 (table 4-13) alternates between +0.7 vdc and -1.4 vdc and Q1 turns on when the test point becomes -0.7 vdc or more negative. Q1 assures that Q2 is off at the beginning of the next positive alternation after the output of A1 goes to -15 vdc. When Q2 is off, comparator A2 is allowed to generate trigger pulses in transformer T1A and trigger SCR2A. The + input (test point 42) of A2 momentarily is more positive than the - input (test point 44) when the + input passes through the -0.7 vdc level at the leading edge of the positive alternations of 18.5 vac (test point 43). When the + input of A2 exceeds the - input, the output of A2 goes to +15 vdc and generates a pulse in T1A. See test point 45 waveform in table 4-13.

(e) When a trigger pulse is generated in T1A, conduction through the heater probes continues for one or more complete cycles depending on the heat demand. The trigger pulse from T1A turns on SCR2A. SCR2A triggers SCR2B, a power SCR mounted on a heat sink inside the probe control. Current from T1B flows through the heater probes and SCR2B during the positive half-cycle of heater voltage. Also during the positive half-cycle, C9 charges through CR10, R23, and SCR2B. When the heater voltage passes through 0 vac at the leading edge of the negative alternation, SCR2B turns off. The positive voltage on C9 (approximately 75 vdc) turns on SCR1A through R22 and CR11. SCR1A triggers SCR1B, the other power SCR. SCR1B allows current to flow through the probes during the negative half-cycle. During the negative half-cycle, C9 discharges through CR8, CR9, and R23.

(8) Insulation Check Circuit. This circuit (fig. 1-23), located in the probe controller, measures the insulation resistance between the aircraft thermocouple harness and aircraft ground. The INSULATION CHECK meter is the ohmmeter of a calibrated ohmmeter circuit having two ranges, RX100 and RX1000. The circuit is powered by 9 vdc from a supply on the probe control and function switch




Figure 1-22. Schematic Diagram of Standard Day Correction Circuit.




Figure 1-23. Insulation Check Circuit (Simplified Schematic)

board.

(9) **Resistance Check Circuit.** This circuit (fig. 1-24), located in the probe controller, is used to check and adjust the resistance of the aircraft thermocouple circuit. It consists of a Wheatstone bridge with the RESISTANCE CHECK meter serving as the galvanometers. One leg of the bridge contains a precision wirewound resistor that is selected with the RESISTANCE % A/C INDICATOR CHECK switch. The aircraft thermocouple circuit (less the indicator) is placed in the other leg of the bridge. The aircraft resistance spool is then adjusted until the galvanometer is balanced.

(10) **Power Supplies and Power Distribu-**

tion. Primary line voltage (115 vat. 50-400 Hz) is applied to the POWER INPUT receptacle on the probe controller. The voltage is applied through the interconnect cable and the MASTER POWER switch to the primary windings of T1 in the trimmer. There are five secondary windings on transformer T1 (fig. 1-25). All secondary windings are center-tapped. Only switch positions that switch power are shown in figure 1-25.

(a) **Twenty-Eight VDC Supply.** This supply consists of the circuitry of CR9, CR10, and Q10-Q12 on the switch-power board. It is referenced to the -15 vdc supply. The 28 vdc supply excites the STD DAY lamp and its control circuit. It is also switched by the FUNCTION SELECT switch to the




Figure 1-24. Resistance Check Circuit (Simplified Schematic).

resistance check circuit (fig. 1-24) and the heater probe power relay (fig. FO-1).

(b) Plus and Minus 15 VDC Supply. One of the 37 vac secondaries of T1 (fig. 1-25) is full-wave rectified by diodes CR5-CR8 on the switch-power board to form a positive and negative supply. The positive supply is regulated to +15 vdc by Q1, Q2, and A1 and filtered by C3. The + input of A1 is referenced to 8.95 vdc generated by CR15. The negative supply is regulated to -15 vdc by Q3, Q4, and A2 and filtered by C4. The + input of A2 is referenced to ground.

(c) Display Lamp Supply. On the switch-power board diodes CR1 and CR2 full-wave rectify and C9 filters the 14 vac winding to provide a 5 vdc supply to excite the display diodes. The circuitry of A3 and the DISPLAY control convert the supply to an adjustable square wave by controlling the on-off time of series regulator Q15. At the 50% duty cycle, the square wave frequency is 800 Hz + 20%. When the DISPLAY control wiper is at the +15 vdc end the display is full on, and when the wiper is at the -15 vdc end the display is full off.

(d) Logic Voltage Supply. The 18.5 vac winding of T1 is full-wave rectified by CR3 and CR4 on the switch-power board, filtered by C5, and regulated to +5 vdc by Q5. Q5 is controlled by a differential amplifier consisting of Q8 and Q9 and by transistors Q6 and Q7. The differential amplifier

maintains its base voltages at ground potential. Assume an increase in the base voltage of Q9. Additional current from Q9 flows through R13, decreasing the bias on Q8. The bias on Q7 increases, causing the bias on Q6 to decrease. The base of Q5 becomes more positive, decreasing the current through Q5.

(e) Nine VDC Supply. This supply is located on the probe control and function switch board. It is powered by one-half of a 37 vac winding which is half-wave rectified by CR12 and filtered by C11. CR13 regulates the dc voltage to 18 vdc and CR14 regulates it to 9 vdc. The 9 vdc is switched by the FUNCTION SELECT switch to power the aircraft indicator check circuit (figs. 1-18 and 1-19), the PROBE CONTROL and probe control compensator (MOD-1, fig. FO-1), and the insulation check circuit (fig. 1-23).

(f) Plus and Minus 7 VDC Supply. This supply, on the calibrator board provides an isolated source of power to drive the % rpm calibrator circuit and the wave-shaping circuitry of A3 on the tachometer board.

(11) Logic Circuitry.

(a) Definition of Logic Levels. Standard positive logic is used. Logic 0 is a low voltage (= 0.4 vdc) and is said to be "false". Logic 1 is a high voltage (= 2.4 vdc) and is said to be "true". The logic circuitry excitation voltage is +5 vdc.




Figure 1-25. Power Flow Block Diagram.

(b) *Integrated Circuit Pin Locations.* Figure 1-26 shows top views and pin locations of integrated circuits.




Figure 1-26. Integrated Circuit Pin Locations.

(c) *Definitions of Logic Circuits.*

1. *Quad 2-Input NOR Gate (CD4001A).* If one or both inputs of a single gate (fig. 1-27) are at the 1 logic level, the output will be at the 0 logic level. If both inputs are at the 0 logic level, the output will be at the 1 level. The input and output relationships of a NOR gate are expressed in "truth" table 1-1.

2. *Dual D-Type Flip-Flop (CD4013AE).* Each flip-flop (fig. 1-28) has independent data, set reset, and clock inputs and Q and

Q outputs. The logic level present at the D input is transferred to the Q output during the positive-going transition of the clock pulse (table 1-2). Setting or resetting is independent of the clock and is accomplished by a high level on the set or reset line, respectively.

3. *Triple 3-Input NAND Gate (CD4023AE).* If all inputs of a single gate (fig. 1-29) are at the 1 logic level, the output will be at the 0 level (table 1-3). If one or more inputs are at the 0 level, the output will be at the 1 level.




Figure 1-27. Quad 2 Input NOR Gate.

Table 1-1. NOR Gate Truth Table.

A	B	C
0	0	1
0	1	0
1	0	0
1	1	0




Figure 1-28. Dual D-Type Flip-Flop.

Table 1-2. Truth Table for D-Type Flip-Flop.

CL	D	R	S	Q	Q
	0	0	0	0	1
	1	0	0	1	0
	X	0	0	Q	Q
X	X	1	0	0	1
X	X	0	1	1	0
X	X	1	1	*	*

- No Change

X = don't care case

* = invalid condition




Figure 1-29. Triple 3-Input NAND Gate.

Table 1-3. Truth Table for 3-Input NAND Gate.

A	B	C	D
0	0	0	1
0	0	1	1
0	1	1	1
1	1	1	0

4. Seven-Stage Binary Counter (CD4024AE). This counter consists of an input pulse shaping circuit, reset line driver circuitry, and seven binary counter stages (fig. 1-30). The counter

is reset to "zero" by a high level on the reset input. Each counter stage is a static master-slave flip-flop. The counter state is advanced one count on the negative-going transition of each input pulse.




Figure 1-30. Functional Diagram of 7-Stage Binary Counter.

5. Seven-Segment LED Display (5082-7650). This is a large (0.43") red, common anode, seven-segment display with left-hand decimal point. Figure. 1-31 shows the schematic and the connection to drive circuitry. Table 1-4 lists pin functions.

6. Counter-Latch-Decoder (MC4350L). This device (fig. 1-32) combines the functions of an NBCD counter, four-bit latch, and a seven-segment decoder/driver. The counter advances on input. The serial output is high driving the ninth count, allow-

ing synchronous or asynchronous counter operation when used in conjunction with the enable input and some external gating. The counter reset places the counter in a non-NBCD state, turning off the output driver transistors when transferred through the latch and decoded. This feature gives automatic suppression of leading zeros in the display. The latch section admits information while the strobe is high and latches the data on the negative edge of the strobe. A lamp blanking input is provided for intensity modulation, A lamp test feature is also available. Circuit operation is summarized in table 1-5.




Figure 1-31. Seven-Segment LED Display.

Table 1-4. LED Display Pin Functions

PIN	FUNCTION
1	CATHODE - a
2	CATHODE - f
3	ANODE*
4	NO PIN
5	NO PIN
6	CATHODE - dp
7	CATHODE - e
8	CATHODE - d
9	NO CONN
10	CATHODE - c
11	CATHODE - g
12	NO PIN
13	CATHODE - b
14	ANODE*

* Redundant anodes.




Figure 1-32. Counter-Latch-Decoder.

Table 1-5. Counter-Latch-Decoder Functional Truth Table

Function	Input						Output							
	\overline{C}	\overline{E}	R	S	LT	LB	S _{out}	a	b	c	d	e	f	g
Lamp Test	X	X	X	X	1	X	--	0	0	0	0	0	0	0
Lamp Blanking	X	X	X	X	0	1	--	1	1	1	1	1	1	1
<u>Reset</u>	X	X	1	1	0	0	0	1	1	1	1	1	1	1
Enable	P	1	0	1	0	0	0	1	1	1	1	1	1	1
State Sequence	1	P1	0	0	1	0	0	0	1	0	0	1	1	1
	2	P2	0	0	1	0	0	0	0	0	1	0	0	1
	3	P3	0	0	1	0	0	0	0	0	0	0	1	1
	4	P4	0	0	1	0	0	0	1	0	0	1	1	0
	5	P5	0	0	1	0	0	0	0	1	0	0	1	0
	6	P6	0	0	1	0	0	0	0	1	0	0	0	0
	7	P7	0	0	1	0	0	0	0	0	0	1	1	1
	8	P8	0	0	1	0	0	0	0	0	0	0	0	0
	9	P9	0	0	1	0	0	1	0	0	0	0	1	0
	0	P10	0	0	1	0	0	0	0	0	0	0	0	0
	1	P11	0	0	1	0	0	0	1	0	0	1	1	1
	Latch	P	0	0	0	0	0	0	1	0	0	1	1	1

P = any number of pulses may be applied.

P = n pulses on the clock input

X = don't care

7. *Quadruple 2-Input NAND Gate (SN5400)*. Gate pins are identified in figure 1-33

and the operation of a single gate is summarized in Table 1-6.

Table 1-6. Truth Table of 2- Input NAND Gate

A	B	Y
1	1	0
0	1	1
1	0	1
0	0	1




Figure 1-33. Quadruple 2-Input NAND Gate.

8. *Quad 2-Input NOR Gate (SN5402)*. If one or both inputs of a single gate (fig. 1-34) are at the 1 level, the output is at the 0

level. If both inputs are at the 0 level, the output is at the 1 level. Input and output relationships are summarized in Table 1-7.




Figure 1-34. Quad 2-Input NOR Gate.

Table 1-7. NOR Gate Truth Table

A	B	Y
0	0	1
0	1	0
1	0	0
1	1	0




Figure 1-35. Dual D-Type Edge-Triggered Flip-Flop.

9. Dual D-Type Edge-Triggered Flip-Flop (SN5474). This flip-flop (fig. 1-35) has direct clear and preset inputs and complementary Q and Q outputs. Input information is transferred to the outputs on the positive edge of the clock pulse. Clock triggering occurs at a voltage level of the clock pulse and is not directly related to the transition time of the positive-going pulse. A low input to clear sets Q to logic 0. A low input to preset sets Q to logic 1. Clear and preset inputs dominate regardless of clock and D inputs. Table 1-8 summarizes the input-output relationships.

10. Dual J-K Master-Slave Flip-Flop with Preset and Clear (SN5476). The J-K flip-flop (fig. 1-36) is based on the master-slave principle. Inputs to the master section are controlled by

the clock pulse (fig. 1-37). The clock pulse also regulates the state of the coupling transistors which connect the master and slave sections. The sequence of operation is as follows:

1. Isolate slave from master.
2. Enter information from J and K inputs to master.
3. Disable J and K inputs.
4. Transfer information from master to slave.

Clear and preset are independent of the clock. A low input to preset sets Q to logic 1. A low input to clear sets Q to logic 0. Input-output relationships of each flip-flop are summarized in table 1-9.

Table 1-8. Truth Table for D-Type Flip-Flop.

Before Clock Pulse	After clock Pulse	
INPUT D	OUTPUT Q	OUTPUT Q
0	0	1
1	1	0




Figure 1-36. Dual J-K Master-Slave Flip-Flop.




Figure 1-37. Clock Waveform to Master-Slave Flip-Flop.

Table 1-9. J-K Flip-Flop Truth Table.

Before Clock Pulse		After Clock Pulse
J	K	Q
0	0	Q _n *
0	1	0
1	0	1
1	1	Q _n *

* Q_n means Q remains at the level it was before the clock pulse.
 Q_n means Q changes to the level opposite the level before the clock pulse.

11. **Decade Counter (SN5490).** When output QA (fig. 1-38) is connected to input BD, the circuit provides a BCD output as shown in table 1-

10. The counter is clocked by logic 0 pulses at terminal 14 and cleared to zero by logic 1 applied to terminals 2 and 3.




Figure 1-38. Decade Counter.

Table 1-10. Decade Counter Truth Table.

Count	Output			
	QD	QC	QB	QA
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1

12. Resistor Network (889-3-ohm \pm 2%, 0.25w resistors. R150). This circuit (fig. 1-39) contains seven 150-




Figure 1-39. Resistor Network Schematic.

1-5. Leading Particulars. Leading particulars of the tester are listed in table 1-11. Indicators and controls are shown in figure 1-40 and their functions are described in table 1-12. Tester accessories, some or all of which may be used on a particular air-

craft, are pictured in figure 1-41 and described in table 1-13. Basic accessories required for most aircraft are identified by manufacturer's part number and national stock number in table 1-14.

Table 1-11. Leading Particulars.

Temperature Measurements	
Signal Source:	Chromel-alumel (type K) thermocouple
Readout Range:	0 to 1399° C
Readout Increments:	1° C
Readout Accuracy:	± 2° C
% RPM Measurements	
Signal Source:	Standard two-pole tachometer generator
Readout Range:	0 to 119.9% rpm
Readout Increments:	0.1% rpm
Readout Accuracy:	± 0.1% rpm
Standard Day Measurements	
Ambient Temperature Range:	-41 to 139° F
Temperature Accuracy:	± 4° C
% RPM Accuracy:	± 0.5% rpm
Calibration Signal Range:	Ambient to 1399° C
Tests Temperature Indicator Types:	4.21, 8, 15, and 22 ohms and null balance
Resistance Check Circuit Ranges:	4.21, 8, 15, and 22 ohms (all have ± 0.05 ohm tolerance)
Ambient Operating Temperature Range:	-40 to 75° C
Power:	115 vat, 50-400 Hz, single phase, 3100 va maximum
Size (less handle):	22.5 in. long, 21 in. wide, 23.5 in. high
Weight:	96 lbs (less accessories)




Figure 1-40. Tester Indicators and Controls.

Table 1-12. Indicator and Control Functions.

Indicator or Control	Function
A/C IND ADJ (INCREASE) potentiometer	Adjusts test signal for aircraft temperature indicator.
AMB TEMP potentiometer	Controls equivalent ambient temperature electrical signal for standard day correction circuit.
CAL ADJ potentiometer	Calibrates related indicator to internal calibration signal.
DISPLAY (BRIGHT)	Adjusts brightness of indicator displays.
FUNCTION SELECT switch	A seven-position switch that selects the circuit of the function being performed by the tester.
INSULATION CHECK meter	Indicates insulation resistance of engine temperature circuit during insulation resistance check.
INSULATION CHECK switch	Selects range of INSULATION CHECK meter.
MASTER POWER switch	Applies and removes power from tester,
POWER TO TEST switch	Tests all indicator displays.
PROBE CONTROL potentiometer	Adjusts the test temperature of the temperature probe.
PROBE POWER lamp	Glows while probes are heating, turns off during probe control overshoot, then blinks rapidly when test temperature is reached.
RESISTANCE & A/C INDICATOR CHECK switch	Places proper resistance in bridge circuit when checking resistance of engine thermocouple harness or checking aircraft indicator.
RESISTANCE CHECK meter	Indicates resistance error of aircraft temperature circuit.
% RPM indicator	Indicates N1 and N2 % rpm.
RPM switch	Selects N1 or N2 rpm. Calibration of % RPM indicator is displayed when switch is in CAL 100% RPM position.
SPREAD switch	With FUNCTION SELECT switch in SPREAD position, individual thermocouple signals applied to SPREAD CABLE receptacle can be read on TEMP° C indicator. In ALL position average of all thermocouple signals is displayed.

Table 1-12. Indicator and Control Functions (Continued).

Indicator or Control	Function
STD DAY lamp	Flashes when controls are not in correct position to make standard day corrections and glows steadily when positions are correct.
STD DAY switch	In ON position, rpm and temperature readings are automatically corrected to standard day conditions.
TEMP °C indicator	Indicates aircraft indicator test signal, spread thermocouple outputs, average output of egt thermocouples, heater probe temperature set signal, and heater probe temperature.
TEMPERATURE switch	The OPERATE position in conjunction with other controls selects the signal (heater probe output, aircraft thermocouple output, or aircraft indicator test) to be displayed by TEMP °C indicator. Heater probe set temperatures of internal calibration signal are displayed when this switch is in HEATER PROBE TEMP SET or CAL 600 °C position respectively.
T/C INPUT switch	Connects output of either heater probe thermocouples (in HEATER CABLE position) or engine thermocouples (CHECK CABLE position) to TEMP °C indicator.

Table 1-13. Accessory Functions.

Index Number (Figure 4-	Accessory	Function
1	Switch Box	During trim, permits thermocouple signal to be monitored on cockpit indicator or on tester. Used only with D'Arsonval indicators.
2	Junction Box	Connects to heater cable and probes. Power distribution box for probes. Also combines signals from probe thermocouples to obtain average thermocouple signal.
3	Heater Cable	Connects to junction box. Supplies power from tester to heat probes. Also carries probe thermocouple signal to tester.
4	Check Cable	Connects engine thermocouple signal to tester.
5	Instrument Cable	Connects tester to a variety of adapters including resistance check adapter, insulation check adapter, indicator check adapter, RPM adapter, and RPM indicator adapter.
6	Extension Handle	Where thermocouples are relatively inaccessible, extension handle holds probes and allows them to be properly positioned.
7	Power Cable	Supplies power to tester.
8	RPM Check Adapter	During trim, supplies tach generator output to tester through instrument cable and to cockpit RPM indicator, simultaneously. Connects at tach indicator.
9	Insulation Check Adapter	Connects through instrument cable to tester. Checks insulation resistance of complete aircraft thermocouple system.
10	EGT Indicator Check Adapter	Connects through instrument cable to tester. Provides calibrated signal to check cockpit indicator.
11	Resistance Check Adapter	Connects through instrument cable to tester. Checks resistance of complete aircraft thermocouple system.
12	Heater Probes	Heat aircraft thermocouples. Probes include their own thermocouples which permit their temperatures to be indicated on the tester. Probes must be matched to engine thermocouples. Connect to junction box.
13, 14	Check Cable Adapter	Adapts check cable to engine harness junction connector.

Table 1-14. *Basic Accessories Required for Most Aircraft.*

		BASIC ACCESSORIES INCLUDED WITH BH112JB-53	
		BASIC ACCESSORIES INCLUDED WITH BH112JB-79	
<u>QTY</u>		<u>P/N</u>	<u>ITEM</u>
1		BH123-3	Switch Box 5930-00-338-2591
1		BH361-8	Junction Box 4920-00-329-8294
	1	BH361-12	Junction Box 4920-00-524-8644
1	1	BH405	Heater Cable 4920-00-503-1889
1	1	BH450	Check Cable 4920-00-503-1890
1	1	BH485	Instrument Cable 4920-00-548-7118
1		BH492B-3	Extension Handle 4920-00-612-9496
1	1	BH499A	Power Cable 4920-00-941-6503
1		BH820	RPM Indicator Adapter 4920-00-204-6457
1		BH821	Insulation Check Adapter 4920-00-549-6093
1		BH823	Resistance Check Adapter 4920-00-504-3192
3		BH996-40	Heater Probes 4920-00-670-9379
1		BH1504	Check Cable Adapter 4920-00-670-9410
1		BH4548	Check Cable Adapter 4920-00-953-2370
1	1	BH15184A	Interconnect Cable 4920-01-019-1628
1	1	BH15185A	Power Cable Adapter 4920-01-020-5328

Table 1-14. *Basic Accessories Required for most Aircraft (cont)*
AH-1S WITH T53-L-703-ENGINE

		ACCESSORIES REQUIRED WITH BH112JB-53	
		ACCESSORIES REQUIRED WITH BH112JB-79	
<u>QTY</u>		<u>P/N</u>	<u>ITEM</u>
*1	1	BH361-12	Junction Box 4920-00-524-8644
1	1	BH405	Heater Cable 4920-00-503-1889
1	1	BH450	Check Cable 4920-00-503-1890
1	1	BH485	Instrument Cable 4920-00-548-7118
1	1	BH499A	Power Cable 4920-00-941-6503
1	*1	BH22279	Insulation Check Adapter 4920-00-549-6093
*1	*1	BH907	RPM Check Adapter (tach gen) 4920-00-715-4661
1	*1	BH14167	Check Cable Adapter 4920-00-670-9410
*1	*1	BH22196	RPM Check Adapter (tach ind) 4920-01-115-3654
*2	*2	BH7454AH-40	Heater Probes (bench check)
*2	*2	BH7454BH-40	Heater Probes (bench check)
*1	*1	BH16492	Temp Indicator Check Adapter
*1	*1	BH16491	Temp Adapter, Engine Run
1	1	BH15184A	Interconnect Cable 4920-01-019-1628
1	1	BH15185A	Power Cable Adapter 4920-01-020-5328

*These accessories are not included with basic tester.

Table 1-14. Basic Accessories Required for most Aircraft (cont)

OH-58A WITH T63A-700 ENGINE

		ACCESSORIES REQUIRED WITH BH112JB-53	
		ACCESSORIES REQUIRED WITH BH112JB-79	
<u>QTY</u>		<u>P/N</u>	<u>ITEM</u>
1	*1	BH123-3	Switch Box 5930-00-338-2591
1	*1	BH361-8	Junction Box 4920-00-329-8294
OR	OR	NOTE: Either Junction Box can be used	
*1	1	BH361-12	Junction Box 4920-00-524-8644
1	1	BH405	Heater Cable 4920-00-503-1889
1	1	BH450	Cheek Cable 4920-00-503-1890
1	1	BH485	Instrument Cable 4920-00-548-7118
1	1	BH499A	Power Cable 4920-00-941-6503
1	*1	BH820	RPM Check Adapter (tach ind) 4920-00-204-6457
1	*1	BH821	Insulation Check Adapter 4920-00-549-6093
1	*1	BH822	Temp Indicator Check Adapter 4920-00-539-9260
1	*1	BH823	Resistance Check Adapter 4920-00-504-3192
*1	*1	BH7424	Check Cable Adapter 4920-00-354-7956
*4	*4	BH7413-40	Heater Probes (bench check)
1	1	BH15184A	Interconnect Cable 4920-01-019-1628
1	1	BH15185A	Power Cable Adapter 4920-01-020-5328

*These accessories are not included with basic tester.

Table 1-14. *Basic Accessories Required for most Aircraft (cont)*

OH-58C WITH T63A-720 ENGINE

		ACCESSORIES REQUIRED WITH BH112JB-53	
		ACCESSORIES REQUIRED WITH BH112JB-79	
<u>QTY</u>		<u>P/N</u>	<u>ITEM</u>
1	*1	BH361-8	Junction Box 4920-00-329-8294
OR	OR	NOTE: Either Junction Box can be used	
*1	1	BH361-12	Junction Box 4920-00-524-8644
1	1	BH405	Heater Cable 4920-00-503-1889
1	1	BH450	Check Cable 4920-00-503-1890
1	1	BH485	Instrument Cable 4920-00-548-7118
1	1	BH499A	Power Cable 4920-00-941-6503
1	*1	BH23318-19	RPM Check Adapter (tach ind)
1	*1	BH22278	Insulation Check Adapter
*1	*1	BH7424	Check Cable Adapter 4920-00-354-7956
*4	*4	BH7413-40	Heater Probes (bench check)
*1	*1	BH22167	Temp Indicator Check Adapter 5975-01-102-8759
*1	*1	BH22168	Temp Adapter, Engine Run 5975-01-102-8758
1	1	BH15184A	Interconnect Cable 4920-01-019-1628
1	1	BH15185A	Power Cable Adapter 4920-01-020-5328

*These accessories are not included with basic tester.

Table 1-14. *Basic Accessories Required for most Aircraft (cont)*
U-21 AND RU-21 WITH T74 OR PT6 ENGINES

		ACCESSORIES REQUIRED WITH BH112JB-53	
		ACCESSORIES REQUIRED WITH BH112JB-79	
<u>QTY</u>		<u>P/N</u>	<u>ITEM</u>
1	1	BH123-3	Switch Box 5930-00-338-2591
1	1	BH405	Heater Cable 4920-00-503-1889
1	1	BH450	Check Cable 4920-00-503-1890
1	1	BH485	Instrument Cable 4920-00-548-7118
1	1	BH499A	Power Cable 4920-00-941-6503
*2	*2	BH820A	RPM Check Adapters (tach ind)
1	*1	BH821	Insulation Check Adapter 4920-00-549-6093
1	*1	BH822	Temp Indicator Check Adapter 4920-00-539-9260
1	*1	BH823	Resistance Check Adapter 4920-00-504-3192
*2	*2	BH907	RPM Check Adapter (tach gen) 4920-00-715-4661
*1	*1	BH7424	Check Cable Adapter 4920-00-354-7956
*1	*1	BH14101-40	Heater Probe 6685-00-345-0508
*1	*1	BH14102-40	Continuity Heater Probe 6685-00-345-0507
*1	*1	BH15572	RPM "Y" Adapter
1	1	BH15184A	Interconnect Cable 4920-01-019-1628
1	1	BH15185A	Power Cable Adapter 4920-01-020-5328

*These accessories are not included with basic tester.

Table 1-14. Basic Accessories Required for most Aircraft (cont)
UH-1H WITH T53-L-13 ENGINE

		ACCESSORIES REQUIRED WITH BH112JB-53	
		ACCESSORIES REQUIRED WITH BH112JB-79	
<u>QTY</u>			
1	1	BH123-3	Switch Box 5930-00-338-2591
1	1	BH361-8	Junction Box 4920-00-329-8294
1	1	BH405	Heater Cable 4920-00-503-1889
1	1	BH450	Check Cable 4920-00-503-1890
1	1	BH485	Instrument Cable 4920-00-548-7118
1	1	BH499A	Power Cable 4920-00-941-6503
1	*1	BH820	RPM Check Adapter (tach ind) 4920-00-204-6457
1	*1	BH821	Insulation Check Adapter 4920-00-549-6093
1	*1	BH822	Temp Indicator Check Adapter 4920-00-539-9260
1	*1	BH823	Resistance Check Adapter 4920-00-504-3192
*1	*1	BH907	RPM Check Adapter (tach gen) 4920-00-715-4661
1	*1	BH1504	Check Cable Adapter 4920-00-670-9410
*1	*1	BH3810-40	Continuity Heater Probe 4920-00-861-0736
*1	*1	BH4352	Check Cable Adapter 4920-00-714-1317
*3	*3	BH7434L-40	Heater Probes 6685-00-235-4594
*3	*3	BH7434R-40	Heater Probes 6685-00-235-4593
1	1	BH15184A	Interconnect Cable 4920-01-019-1628
1	1	BH15185A	Power Cabel Adapter 4920-01-020-5328

*These accessories are not included with basic tester.


Section III. TEST EQUIPMENT, SPECIAL TOOLS AND MATERIALS

1-6 Special tools and Test Equipment List.

Table 1-15 lists special tools and test equipment and application figures when applicable.

Table 1-15. *Special tools and Test Equipment.*

Figure	Nomenclature	Part Number or Equivalent
1-42	probe controller support	
4-1	ice-bath cold junction	Howell Instruments BH14106
-	power interconnect cable	Howell Instruments BH15184A-1
-	extender board assembly	Howell Instruments BH15824-1
-	precision 4.21 resistor	Howell Instruments BH2434
-	precision 8 resistor	Howell Instruments BH2435
-	precision 22 resistor	Howell Instruments BH2436
-	precision 15 resistor	Howell Instruments H3492
	oscilloscope	Hewlett-Packard Co. 130C
4-2	low frequency function generator	Hewlett-Packard Co. 202A
	volt-ohm-microammeter	Simpson Electric Co. 269
	digital multimeter	Data Technology Corporation 370
4-2	frequency counter	Hewlett-Packard Company 522B
4-1,4-30	millivolt potentiometer	Leeds & Northrup Company 8686



MATERIAL : 1" x 4" LUMBER

Figure 1-41. Probe Controller Support.

1-7. Consumable Materials List. Table 1-16 lists all consumable materials required to maintain the tester.

Table 1-16. Consumable Materials.

Item No.	Nomenclature	Military Specification	Item Part No. and FSCM
1	dessicant	MIL-D-3464	-
2	dry cleaning	P-D-680	-
3	grease	MIL-G-3027BA	Beacon 325 (29700)
4	alcohol, isopropyl	TT-I-735 (± 10% water)	-
5	adhesive	-	Pliobond 30 (86839)
6	RTV sealant	-	3140 (71984)
7	60/40 tin-lead solder	QQ-S-57 composition Sn 60)	-
8	flux	-	Eutector flux 157 (72271)
9	heat sink compound	-	DC340 (71984)

CHAPTER 2

OPERATING INSTRUCTIONS

2-1. Indicators, Controls, and Accessories.

Tester indicators and controls are shown in figure 1-40 and listed with their functions in table 1-12. Tester accessories are shown in figure 4-30 and listed with their functions in table 1-13. Table 1-14 lists those accessories common to most aircraft.

2-2. Instruction Plate. The lid of the instrument case contains an operating instruction plate that covers all tests performed with the tester. The following paragraphs include all the tests as well as test setup diagrams.

WARNING

Ground the tester with the pigtail ground wire in the power inlet cable before using the tester.

NOTE

A flashing indicator indicated an out-of-range condition. Temperature indicator is designed to drift upscale to the out-of-range condition when input is open.

CAUTION

To prevent overheating of and possible damage to the heater probes, determine that all probes being used will heat per paragraph 3-4b.

2-3. Aircraft Temperature System Check. Paragraphs *a* and *b* give procedures necessary to check the aircraft temperature system. Perform the procedures in the order given.

a. Thermocouple System Continuity (Heat Rise) Check. The continuity test checks continuity of aircraft thermocouple system by heating each engine thermocouple independently and checking for a temperature increase on aircraft temperature indicator. Refer to figure 2-1 and proceed as follows:

(1) Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position.

NOTE

If continuity probe is not available perform continuity check with applicable heater probe. Junction box must be connected between BH405 heater cable and heater probe, refer to Fig. 2-2.

CAUTION

To prevent overheating of and possible damage to heater probe if used in place of applicable continuity probe, insure probe has cooled to ambient temperature before performing temperature system accuracy check, para 2-3 b.

(2) Connect BH405 heater cable between HEATER CABLE receptacle on tester and applicable continuity probe.

(3) Place T/C INPUT switch in HEATER CABLE position and turn PROBE CONTROL potentiometer full counterclockwise.

(4) Turn FUNCTION SELECT switch to HEATER PROBE, TEMPERATURE switch to HEATER PROBE TEMP SET, and MASTER POWER switch to ON position. Adjust PROBE CONTROL to test temperature (approximately 700° C). Place TEMPERATURE switch in OPERATE position.

NOTE

Lower test temperatures require a longer stabilization of time than higher test temperatures. When probe control overshoots the test temperature, the PROBE POWER lamp turns off to indicate that power has been removed from the continuity probe. Monitor the probe temperature by turning the TEMPERATURE switch to OPERATE.

(5) When temperature stabilizes at test temperature, PROBE POWER lamp flashes on and off rapidly. Apply continuity probe to each aircraft thermocouple junction. Aircraft indicator should indicate a temperature rise as each thermocouple is heated. A slight temperature rise on indicator is sufficient. The continuity check determines if all thermocouples are operating. All thermocouples must be operating before additional tests can be made.

(6) In some instances, the aircraft indicator may not be sensitive enough to detect temperature rise. If this occurs, connect BH450 check cable to CHECK CABLE receptacle and to engine thermocouple harness. Use check cable adapter if required. Apply applicable continuity probe or heater probe to each aircraft thermocouple junction. With T/C INPUT switch in CHECK




Figure 2-1. Thermocouple System Continuity Check Setup.

CABLE position, TEMP indicator should indicate temperature rise as each thermocouple junction is heated.

(7) Three continuity possibilities exist:

(a) Continuity O.K. Proceed to paragraph

(b) Continuity on some, but not all, thermocouples. Check thermocouples and harness wiring.

(c) No continuity. Make a rapid check of all connectors and associated wiring and if no malfunction is detected, make harness check (para a), indicator check (paras b or c) and insulation check (para e) until open circuit point is detected. After discontinuity is detected and repaired, perform accuracy test in paragraph b.

b. Temperature System Accuracy Check. The accuracy check is used to test the entire aircraft temperature system by heating all engine thermocouples and comparing the temperature displayed on the aircraft temperature indicator with the heater probe temperature displayed on the tester TEMP indicator. Refer to figure 2-2 and proceed as follows:

NOTE

To check an engine not installed in an aircraft, follow the procedure listed below with the following exception. The check cable (and check cable adapter, if required) must be connected to the engine harness junction connector and to the CHECK CABLE receptacle. The temperature of the engine thermocouples is read on the tester TEMP indicator by switching the T/C INPUT switch to CHECK CABLE position.

(1) Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position and turn PROBE CONTROL fully counter-clockwise.

(2) Connect BH405 heater cable to HEATER CABLE receptacle on tester and connect junction box to heater cable.

(3) Connect as many heater probes having the correct part number to the junction box as there are engine thermocouples.

CAUTION

Both the heater probe and heater probe cable length are extremely critical. Therefore, never check an aircraft engine without first determining that the probes and probe cable lengths are all identical and correct for the particular thermocouple. Combining heater probes of different part numbers and heater probes with




Figure 2-2. Temperature System Accuracy Check Setup.

cables of unequal length will produce erroneous readings. Never connect a cold heater probe to the tester when it is regulating other probes at an elevated temperature. To do so could cause overheating of the hot probes.

(4) Place a heater probe over each engine thermocouple. The heater probes must fit firmly and be positioned properly on the thermocouples.

(5) Turn FUNCTION SELECT switch to HEATER PROBE position, T/C INPUT switch to HEATER CABLE position, TEMPERATURE switch to HEATER PROBE TEMP SET position, and MASTER POWER switch to ON position.

(6) Adjust PROBE CONTROL until TEMP indicator reads approximately 600 °C. Turn TEMPERATURE switch to OPERATE position to read probe temperature.

NOTE

Check applicable technical manual for exact test temperature and adjust PROBE CONTROL accordingly. While heater probes are heating, PROBE POWER lamp burns continuously. Probe control will overshoot test temperature and lamp will go out until

probe temperature falls below set temperature. After test temperature has been reached (PROBE POWER lamp flashes), allow five minutes "soak" time. The time necessary to heat and stabilize probes depends upon line voltage, ambient temperature, and air currents. Some engines, after being idle for some time, collect moisture on the thermocouple terminals and extra time must be allowed for this moisture to evaporate. Normally a 10-minute "soak" time is sufficient. However, if after 10 minutes, the system is not within limits, an additional 20 minutes "soak" time should be allowed. If the system is still not within tolerance, out-of-tolerance difference is system error.

(7) If necessary, place cover over engine tail cone to obtain stabilized test temperature.

(8) The difference between the heater probe temperature indicated on the tester and the aircraft indicator reading (or aircraft thermocouple temperature as read on the tester when engine is not installed in aircraft) is the error in the aircraft system and should not exceed allowable engine

tolerance. If system is not within tolerance, note the number of degrees out-of-tolerance and proceed to troubleshooting, paragraph 2-4.

NOTE

If an engine thermocouple is suspected of opening up at the test temperature, each thermocouple may be tested separately by momentarily removing the heater probe and observing the tester or aircraft indicator for a drop in average thermocouple temperature. If a Thermocouple is open, there will be no drop in temperature when its heater probe is removed.

(9) Turn FUNCTION SELECT and MASTER POWER switches to OFF position before removing heater probes from aircraft engine and tester.

2-4. Troubleshooting Temperature System. If the temperature system error exceeds applicable technical manual tolerance, one or more of the causes listed below will probably be the source of trouble. The complete temperature system and all of its components must be correct before the temperature system can be used for reliable temperature readings. The possible sources of trouble are:

1. Thermocouples and thermocouple harness (para *a*).
2. Resistance of circuit out of tolerance (para *d*).
3. Temperature indicator error (paras *b* and *c*).
4. Shorts to ground (para *e*).

When troubleshooting, keep in mind the system error detected in paragraph 2-3, subparagraph *b*. As each malfunction is corrected, the amount of error reduction can be compared to system error to determine if system has been returned within allowable limits.

a. Thermocouple and Harness Check. The thermocouple and harness check tests the aircraft thermocouple harness and the aircraft thermocouples by heating all the thermocouples and comparing the average output of the engine thermocouples with the average output of the heater probe thermocouples as read on the TEMP indicator. Refer to figure 2-3 and proceed as follows:

(1) Turn FUNCTION SELECT, STD DAY, and master power switches to OFF position and turn PROBE CONTROL fully counterclockwise.

(2) Connect BH405 heater cable to HEATER CABLE receptacle on tester and connect junction

box to heater cable.

CAUTION

Never connect a cold heater probe to the tester when it is at an elevated temperature. To do so could cause overheating of the hot probes.

(3) Connect as many heater probes having the correct part number to the junction box as there are engine thermocouples.

(4) Place a heater probe over each engine thermocouple. The heater probes must fit firmly and be positioned properly on the thermocouples.

(5) Connect BH450 check cable to CHECK CABLE receptacle on tester and to aircraft thermocouple harness at engine disconnect. If required, use check cable adapter at engine disconnect.

(6) Turn FUNCTION SELECT switch to HEATER PROBE position, T/C INPUT switch to HEATER CABLE position, TEMPERATURE switch to HEATER PROBE TEMP SET position, and MASTER POWER switch to ON position.

(7) Adjust PROBE CONTROL until TEMP indicator reads test temperature.

(8) Turn TEMPERATURE switch to OPERATE position to read probe temperature.

(9) Place T/C INPUT switch in CHECK CABLE position to read temperature of engine thermocouples and in HEATER CABLE position to read probe temperature on tester TEMP indicator.

(10) The difference in engine thermocouple temperature and probe temperature read in step 9 is the error of the engine thermocouples and should not exceed technical manual tolerance.

(11) If temperatures are within tolerance, perform temperature indicator check in paragraph *b* or *c*. If temperatures are not within limits, troubleshoot and repair harness and/or thermocouples.

(12) Turn PROBE CONTROL fully counterclockwise and turn FUNCTION SELECT and MASTER POWER switches to OFF position before removing heater probes and cables from aircraft and tester.

b. D'Arsonval Temperature Indicator Check.

In the aircraft temperature indicator check, a simulated thermocouple signal from the tester is applied to both the aircraft indicator and the tester TEMP indicator and the two indicator readings are




Figure 2-3. Thermocouple and Harness Check Setup.

compared. Refer to figure 2-4 and proceed as follows:

(1) Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position.

(2) Connect BH485 instrument cable to INSTRUMENT CABLE receptacle on tester and to egt indicator check adapter. Connect BH822 egt indicator check adapter to proper terminal posts on aircraft indicator. Place RESISTANCE & A/C INDICATOR CHECK switch in proper resistance position (see indicator for circuit resistance value).

NOTE

If indicator is left in instrument panel, one aircraft lead must be disconnected. If indicator is removed from instrument panel, a more accurate check will be accomplished if indicator is kept in normal operating position.

(3) Turn FUNCTION SELECT switch to A/C IND CHECK position, TEMPERATURE switch to OPERATE position, and MASTER POWER switch to ON position.

(4) Observe reading on tester TEMP indicator and adjust A/C IND ADJ control to test temperature reading (usually 600 °C).

(5) The difference in the indication of the tester TEMP indicator and the aircraft indicator is the error of the aircraft indicator and should not exceed allowable technical manual tolerance.

(6) If aircraft indicator exceeds technical manual tolerance, repair or replace indicator.

(7) If indicator is within tolerance, proceed to check resistance in paragraph *d*.

(8) Turn FUNCTION SELECT and MASTER POWER switches to OFF position before removing cables from tester and aircraft indicator.

c. Null-Balance Temperature Indicator Check. Connect the tester to the indicator at the engine disconnect or at the indicator using the appropriate adapter as shown in figure 2-5 and proceed as follows:

(1) Turn FUNCTION SELECT switch to A/C IND CHK position, RESISTANCE & A/C INDICATOR CHECK switch to NULL BAL position, TEMPERATURE switch to OPERATE




Figure 2-4. D'Arsonval Temperature Indicator Check Setup.




Figure 2-5. Null Balance Temperature Indicator Check Setup.

position, and MASTER POWER switch to ON position.

(2) observe reading on tester TEMP indicator and adjust A/C IND ADJ control to test temperature (usually 600 °C).

(3) The difference in the indication of the tester TEMP indicator and the aircraft indicator is the error of the aircraft indicator and should not exceed allowable technical manual tolerance.

(4) If aircraft indicator exceeds technical manual tolerance, repair or replace indicator.

(5) Turn FUNCTION SELECT and MASTER POWER switches to OFF position before removing cables from tester and aircraft.

d. Temperature Circuit Resistance Check (D'Arsonval Indicator(s)). In the resistance check, the resistance of the aircraft thermocouple wire, thermocouples, and resistance spool is measured on the tester RESISTANCE CHECK meter. Refer to figure 2-6 and proceed as follows:

CAUTION

A high resistance condition is dangerous because the aircraft temperature indicator will read low and the engine will be operating above indicated temperature.

(1) Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position.

(2) Connect BH485 instrument cable to INSTRUMENT CABLE receptacle on tester and to BH823 resistance check adapter.

(3) Disconnect aircraft thermocouple leads from indicator(s).

(4) Connect one set of aircraft thermocouple leads to resistance check adapter terminal block. Make sure polarity is correct. If there are two indicators, the other set of leads is left disconnected.

(5) Turn RESISTANCE & A/C INDICATOR CHECK switch to proper resistance position. (See proper aircraft maintenance manual for resistance value).

(6) Turn FUNCTION SELECT switch to RES position and MASTER POWER switch to ON position.

(7) RESISTANCE CHECK meter on tester should read within technical manual tolerance. If not, adjust resistance spool in aircraft for proper resistance. One increment on meter equals 0.05 ohm.

CAUTION

Check and clean all connections in the thermocouple system before adjusting aircraft resistance spool. Deflection of meter needle in clockwise direction indicates excessive resistance.

(8) If resistance is within tolerance, proceed to check insulation resistance as described in paragraph *e*.

(9) Turn FUNCTION SELECT and MASTER POWER switches to OFF position before removing cables from tester and aircraft.

e. Insulation Resistance Check. In the insulation resistance check, the resistance between the thermocouple conductors and aircraft ground is measured first, followed by a check of the resistance between the conductors. Refer to figure 2-7 and proceed as follows:

(1) Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position.

(2) Connect BH485 instrument cable to INSTRUMENT CABLE receptacle on tester and to BH821 insulation check adapter, and disconnect both leads at aircraft indicator.

(3) Turn FUNCTION SELECT switch to INSUL position, INSULATION CHECK switch to RX1000 position, an MASTER POWER switch to ON position.

(4) Short alligator clips together. Meter should read 0 ohms.

(5) Connect one lead of insulation check adapter to a bare thermocouple lead in aircraft and connect other lead to aircraft ground.

(6) INSULATION RESISTANCE meter should indicate resistance specified for aircraft being checked.

(7) Disconnect engine thermocouple harness from airframe thermocouple harness.

(8) Disconnect insulation check adapter from aircraft ground and connect to other thermocouple lead.

(9) INSULATION RESISTANCE meter




Figure 2-6. Temperature Circuit Resistance Check Setup.




Figure 2-7. Insulation Resistance Check Setup.

should indicate resistance specified for aircraft being checked.

(10) If either insulation resistance reading is not within tolerance, locate source of leakage and repair.

NOTE

Heating of EGT harness of 200 degrees F for 1 hour, letting cool to ambient temperature, will increase insulation resistance.

(11) Turn FUNCTION SELECT and MASTER POWER switches to OFF position before removing cables from tester and aircraft.

2-6. Temperature Spread Test. The temperature spread test checks combustion chamber flame propagation during engine run. During this test, the temperature of each thermocouple in the engine can be read independently with the tester. The average temperature may also be read at any time during the test. Refer to figure 2-8 and proceed as follows:

a. Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position.

b. Connect spread cable to SPREAD CABLE receptacles on tester and to spread connector on engine (if required, use spread adapter).

c. Turn FUNCTION SELECT switch to SPREAD position.




Figure 2-8. Temperature Spread Test Setup.

d. Turn TEMPERATURE switch to OPERATE position and MASTER POWER switch to ON position.

e. Start engine and stabilize rpm.

f. Turn SPREAD switch successively to each thermocouple position and note reading of each thermocouple on tester TEMP indicator. Temperature gradient (spread) between engine thermocouples should not exceed allowable technical manual limits.

g. Turn FUNCTION SELECT and MASTER POWER switches to OFF position before removing cables from tester and aircraft.

2-5 Engine Trim Check. During operation, the relationship between rpm, temperature, and fuel flow is critical. Therefore, the tester, which measures rpm to ± 0.1 percent and temperature to ± 2 degrees C, is used to measure these engine functions. The portable trimmer portion may be removed and placed in the cockpit during trimming.

If aircraft has D'Arsonval type indicator(s) and it is desirable to check indicator accuracy during engine trim, a switch box (fig. 2-9), which is an accessory to the tester, must be used. Refer to figure 2-10 or 2-11 and proceed as follows:

a. Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position and T/C INPUT switch to CHECK CABLE position.

NOTE

If trimmer section is to be removed and placed in cockpit, remove power interconnect cable from tester. Connect power cable and power cable adapter to POWER INTERCONNECT connector and to power source identified at the POWER INTERCONNECT connector. Disregard reference to FUNCTION SELECT and T/C INPUT switch positions.




Figure 2-9. Switch Box




Figure 2-10. Engine Trim Check Setup Using Trimmer in Tester

b. Connect BH450 check cable to CHECK CABLE receptacle on tester and to aircraft thermocouple circuit using either (1) or (2) below.

(1) *When switch box is not used:* Break aircraft thermocouple circuit at engine temperature junction connector. Connect check cable to engine junction connector (if required, use check cable adapter to match engine

temperature connector). Read out temperature on tester TEMP indicator.

(2) *When switch box is used:* Break aircraft thermocouple circuit at indicator if aircraft has a single D'Arsonval indicator or at engine if aircraft has dual D'Arsonval indicators. Connect aircraft thermocouple leads to AIRCRAFT T.C. LEADS terminals on BH123-3




Figure 2-11. Engine Trim Check Setup Using Trimmer Removed from Tester

switch box. Connect check cable to JETCAL receptacle on switch box. When switch SW-5 on switch box is turned to JETCAL position, temperature of aircraft thermocouples is indicated by TEMP indicator on tester. When SW-5 is turned to EGT position, aircraft thermocouple temperature is read on aircraft indicator(s) for comparison with TEMP indicator.

c. Turn TEMPERATURE switch to OPERATE position.

NOTE

Refer to table 1-14 for appropriate RPM check adapter.

d. Connect BH485 instrument cable to RPM INPUT INSTRUMENT CABLE receptacle and through appropriate adapter to aircraft N1 or N2 tachometer generator.

e. Turn RPM switch to appropriate position (N1 or N2).

f. Turn FUNCTION SELECT switch to **TRIM** position and MASTER POWER switch to ON.

NOTE

If trimmer is used in cockpit, monitor engine temperature on tester TEMP indicator for hot start.

g. Start engine and trim to applicable engine specifications.

h. RPM and TEMPERATURE indications may be temperature corrected to standard day conditions as follows:

(1) Adjust AMB TEMP potentiometer until ambient temperature is displayed in adjacent window.

(2) Turn STD DAY switch to ON position. If STD DAY lamp flashes, indicative of a switch being in wrong position, that RPM switch is in N1 or N2 position, and that FUNCTION SELECT switch is in TRIM position. % RPM and TEMPERATURE readings will be automatically temperature corrected to standard day conditions.

i. Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position before removing cables from tester and aircraft.

2-7. RPM Indicator Check. In the rpm indicator check, engine rpm is read simultaneously on the tester and the cockpit indicators during engine run. The two readings are compared to determine the rpm system error. Refer to figure 2-12 and proceed as follows:

a. Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position.

b. Connect BH485 instrument cable to RPM INPUT INSTRUMENT CABLE connector on tester and to proper rpm check adapter.

NOTE

Refer to table 1-14 for appropriate RPM check adapter.

c. Disconnect aircraft rpm circuit either at rpm indicator or tachometer generator (depending on type of rpm check adapter used) and insert rpm check adapter as shown in figure 2-12.

d. Turn FUNCTION SELECT switch to TRIM position and MASTER SWITCH to on.

e. Turn RPM SWITCH to either N1 or N2 position.

f. With aircraft engine running, monitor % rpm on rpm indicator of tester and compare with cockpit indicator.

NOTE

1% RPM difference is allowed. If a difference exists, refer to appropriate TM for testing of the indicator and tachometer generator.

g. Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position before removing cables from tester and aircraft.




Figure 2-12. RPM Indicator Check Setup

2-8. Heat Detection Systems Check (Fire Warning). The tester can be used to check various types of heat detecting systems including thermal switches and continuous wire heat detection systems. The tester is used in conjunction with Tempcal probes to apply known heat to check the operating temperature of thermal detectors. Refer to figure 2-13 and proceed as follows:

- a.* Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position and PROBE CONTROL fully counterclockwise.
- b.* Connect BH405 heater cable to HEATER CABLE receptacle and to Tempcal probe.
- c.* Apply Tempcal probe to overheat detector.




Figure 2-13. Heat Detection System Check Setup.

d. Turn FUNCTION SELECT switch to HEATER PROBE position, T/C INPUT switch to HEATER CABLE position, TEMPERATURE switch to HEATER PROBE TEMP SET position, and MASTER POWER switch to ON position.

e. Turn PROBE CONTROL until overheat detector test temperature is displayed by TEMP indicator.

f. Turn TEMPERATURE switch to OPERATE position and observe Tempcal probe temperature on tester TEMP indicator. Allow temperature to stabilize at over heat detection system operating point.

CAUTION

Do not apply temperatures beyond

the tolerance of the overheat system. Excessive heat may damage overheat detector or Tempcal probe.

g. As overheat temperature is approached, observe heat detection system for proper operation.

h. With PROBE CONTROL, cycle temperature above and below actuating point of heat detector to determine true cm-off temperature of overheat detection system. Temperature should not exceed limits for system.

i. Turn PROBE CONTROL fully counterclockwise and turn FUNCTION SELECET and MASTER POWER switches to OFF position before removing cables from tester and aircraft.

CHAPTER 3

AVIATION UNIT MAINTENANCE INSTRUCTIONS

Section I. PREPARATION FOR INSTALLATION, STORAGE, AND SHIPMENT

3-1. UNPACKING. There are no special unpacking procedures. Unlatch and remove the instrument case from the accessory case. Open the accessory case, remove the dessicant, and check for the items in table 3-1.

Table 3-1. *Accessories List*

BH112JB-79 Quantity	BH112JB-53 Quantity	Part Number	Part Name
	1	BH123-3	switch box
	1	BH361-8	junction box
1	1	BH405	heater cable
1	1	BH450	check cable
1	1	BH485	instrument cable
	1	BH492B-3	extension handle
	1	BH499A	power cable
	1	BH820	rpm check adapter
	1	BH821	insulation check adapter
	1	BH822	egt indicator check adapter
	1	BH823	resistance check adapter
	3	BH996-40	heater probes
	1	BH1504	check cable adapter
	1	BH4548	check cable adapter
1		BH361-12	junction box
1	1	BH15184A	interconnect cable
1	1	BH15185A	power cable adapter

Loosen the wing nuts on the handle and place handle in a comfortable position for pushing. Retighten the wing nuts. The tester is ready for use after unpacking. Operation instructions are contained in the instrument case lid and detailed operation instructions accompanied by setup illustrations are contained in Chapter 2.

3-2. PREPARATION FOR STORAGE. Before storing the tester, place 5 eight-unit bags of dessicant (item 1, table 1-16) in the accessory case. Store the tester in a dry area where the temperature range does not exceed -65 to 160°F (-54 to 71 °C).

3-3 PREPARATION FOR SHIPMENT. Place 5 eight-unit bags of dessicant (item 1, table 1-16) in the accessory case. Surround the tester with 2 inches of rubberized hog hair when it is packed for shipment. Use the latest revision of specification MIL-P-1 16, method IIb, and JAN-P-100. A pallet (fig. 3-1) may be prepared to secure the tester in the shipping carton. Four holes in the pallet are for tie-down straps.

3-3.1. GENERAL INFORMATION FOR STORAGE AND SHIPMENT. For general technical information on preparation for storage and shipment, refer to TM 1-1500-204-23 (series). For regulatory requirement pertaining to equipment placed in administrative storage, refer to AR750-1.

Section II. INSTALLATION

Not applicable.

Section III. INSPECTIONS AND SERVICING

3-4. DAILY INSPECTION. Following the unpacking of the tester and prior to each day's operation, perform the following inspection procedures.

a. Visual Inspection.

- (1) Inspect exterior of tester for evidence of damage and

condition of paint.

- (2) Lift instrument case lid and examine instrument case deck for broken knobs, broken meter glass, and damaged meter movements. INSULATION CHECK meter should be indicating in-




Figure 3-1. Shipping Pallet.

finite resistance and RESISTANCE CHECK meter should be indicating 0 ohms.

(3) Examine the instrument case lid for the condition of the instruction plate, the inclusion of spare heater probe controller fuses, and the inclusion and condition of the ambient temperature thermometer.

b. Functional Inspection. If a malfunction is detected during the functional inspection, refer to table 3-2 for the probable cause and corrective action.

NOTE

Lamp caps are interchangeable. PROBE POWER and POWER ON caps are red. STD DAY cap is yellow.

CAUTION

Do not interchange STD DAY lamp with POWER ON or PROBE POWER lamps. STD DAY lamp is 28V while the others are 115V.

(1) Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position.

(2) Connect BH499A power cable to POWER INPUT receptacle and to 115 vat, 50-400 Hz power source.

(3) Connect BH15184A power interconnect cable to two INTERCONNECT connectors on tester deck.

(4) Turn MASTER POWER switch to ON position and allow 15 minute warmup. POWER ON lamp shall light and displays shall light.

(5) Press PRESS TO TEST switch. All digits shall read "8".

(6) Turn TEMPERATURE switch to CAL 600° C position. Tester shall read 600 (± 2) °C. See step 8.

(7) Turn RPM switch to CAL 100° RPM position. Tester shall read 100 (± 1) % RPM. See step 8.

(8) Adjust applicable CAP ADJ potentiometer to bring each indicator within tolerances listed in steps 6 and 7. If an indicator cannot be calibrated by adjusting applicable CAL ADJ potentiometer, indicator shall be calibrated.

(9) With TEMP and RPM switches in CAL positions, note readings of TEMP and % RPM indicators.

(10) Adjust AMB TEMP control for a 59° F reading in window.

NOTE

STD DAY lamp should flash in next step indicating switches are not in correct positions for making standard day measurements.

(11) Turn STD DAY switch to ON position. TEMP and % RPM indicator readings shall not change by more than $\pm 2^{\circ}\text{C}$ and ± 0.1 % RPM respectively. If readings are not in tolerance, the standard day circuit shall be calibrated.

(12) Turn STD DAY switch to OFF position.

(13) Turn FUNCTION SELECT switch to A/C IND CHK position.

(14) Turn TEMPERATURE switch to OPERATE position.

(15) Observe that TEMP indicator reading is stable and that clockwise rotation of A/C IND ADJ causes reading to increase and that adjustment covers the range from ambient through 1399° C.

(16) Turn PROBE CONTROL fully counterclockwise.

(17) Turn T/C INPUT switch to HEATER CABLE position.

(18) Turn FUNCTION SELECT switch to HEATER PROBE position.

(19) Connect heater cable to HEATER CABLE receptacle.

(20) Connect junction box to heater cable.

(21) Connect one heater probe to junction box.

(22) Turn TEMPERATURE switch to HEATER PROBE TEMP SET and adjust PROBE CONTROL until TEMP indicator displays 60° C (140° F).

(23) Turn TEMPERATURE switch to OPERATE position and monitor probe temperature as probe heats up.

(24) Observe PROBE POWER lamp for normal probe controller operation. Lamp burns steadily when probe is heating, extinguishes when probe is cooling, and flashes when probe is regulating at set temperature.

(25) Disconnect probe from junction box and connect another probe, using a different junction box connector.

(26) Determine that heater probe is heating by observing TEMP indicator.

(27) Repeat steps 25 and 26 until all probes and junction box connectors have been tested.

(28) Turn PROBE CONTROL fully counterclockwise, turn MASTER power switch off, and remove heater cable, junction box, and heater probes from HEATER CABLE receptacle and return to accessory case.

3-5. Periodic Inspection. Every 180 days, perform the checkout instructions of Chapter 4, Section II.

Section IV. PREVENTIVE MAINTENANCE

3-6. General. The preventive maintenance inspections will be recorded in accordance with procedures outlined in the inspection worksheets listed in paragraph 1-2. Each form covers a specific inspection period, providing a system of progressive preventive maintenance. These forms are available through normal supply channels.

3-7. Cleaning. Clean the tester and accessories with dry cleaning solvent (item 2, table 1-16).

3-8. Lubrication. As conditions warrant, remove the two wheels from the accessory case, wipe off old grease from wheel and axle bearing surfaces, and apply a fresh coat of grease (item 3, table 1-16).

3-9. Extreme Environmental Maintenance.

a. Cold. Provide best possible shelter to protect tester from freezing rain, sleet, or snow.

b. Heat. Provide best possible shelter to protect tester from direct rays of sun.

c. Dust and Sand. If possible, perform all maintenance in a sheltered, well protected area.

(1) Reduce inspection and servicing intervals and keep tester wiped clean.

(2) Keep tester under a protective cover.

d. Humidity. If possible, perform all maintenance in a well ventilated or dry area.

Section V. Operational Checkout

3-10. Performance Checks. The daily inspection procedures of paragraph 3-4b are sufficient for checking the operation of the tester.

3-11. Troubleshooting Data. Table 3-2 provides information useful in diagnosing and correcting unsatisfactory operation of the tester. Each

malfunction is followed by a list of probable causes. The possible corrective action recommended is described opposite the probable case. The use of conventional troubleshooting and corrective methods will enable aviation unit maintenance personnel to maintain the tester in operational readiness.

Section VI. REPAIR AND REPLACEMENT OF AUTHORIZED PARTS

3-12. Replacement of Lamps.

a. Unscrew and remove lamp cap.

b. Pull lamp out of lamp socket.

c. Align pins of new lamp with holes in lamp socket and insert lamp.

d. Reinstall lamp cap.

3-13. Replacement of Indicator Displays.

a. Use a phillips head screwdriver to remove four screws from display bezel and remove bezel.

b. Use a flat bladed screwdriver to pry defective

display from display socket.

c. Insert new display in socket, orienting decimal point at bottom of socket. Be careful not to bend display pins when inserting display in socket.

d. Reinstall display bezel.

3-14. Replacement of Probe Controller Fuse (52, fig. FO-8).

a. Unscrew fuseholder cap and remove fuse.

b. Insert new fuse in cap.

c. Reinstall cap in fuseholder.

Table 3.2. Troubleshooting Table

Malfunction	Probable Cause	Corrective Action
1. INSULATION CHECK meter does not read infinite resistance when FUNCTION SELECT switch is off	a. Mechanical zero screw out of adjustment	a. Adjust screw.
2. RESISTANCE CHECK meter does not read 0 when FUNCTION SELECT switch is off	a. Mechanical zero screw out of adjustment	a. Adjust screw.
3. Entire tester inoperative with power source connected and MASTER POWER switch in ON position.	a. No input voltage b. Defective power cable c. Defective power interconnect cable	a. Check power source. b. Replace cable. c. Replace cable.
4. POWER ON lamp does not light when MASTER POWER switch is on.	a. Defective POWER ON lamp	a. Replace lamp (para. 3-12).
5. Power is applied to tester but displays do not light.	a. DISPLAY control in full counterclockwise position	a. Turn control clockwise.
6. All display digits do not read 8 when PRESS TO TEST button is pressed.	a. Defective display on display board	a. Replace display (para. 3-13).
7. STD DAY lamp does not light when STD DAY switch is on	a. Defective STD DAY lamp	a. Replace lamp (para. 3-12).
8. PROBE POWER lamp does not light when heater probes are connected, FUNCTION SELECT switch is in HEATER PROBE position, T/C INPUT switch is in HEATER CABLE position, and PROBE CONTROL is turned clockwise.	a. Defective PROBE POWER lamp b. FUSE 20A blown	a. Replace lamp (para. 3-12). b. Replace fuse (para. 3-14).
9. No heater probes heat.	a. Defective heater cable.	a. Replace cable.
10. One of several heater probes does not heat.	a. Defective heater probe b. Defective junction box	a. Replace probe. b. Replace box.
11. INSULATION CHECK meter reads infinity when insulation check adapter is jumpered.	a. Defective insulation check adapter b. Defective instrument cable	a. Replace adapter. b. Replace cable.

Table 3-2. Troubleshooting Table (Continued)

Malfunction	Probable Cause	Corrective Action
<p>12. RESISTANCE CHECK meter deflects in full clockwise direction even with resistance check adapter jumpered.</p>	<p>a. Defective resistance check adapter b. Defective instrument cable</p>	<p>a. Replace adapter. b. Replace cable.</p>
<p>13. Aircraft indicator check circuit will not drive aircraft indicator</p>	<p>a. Defective egt indicator check adapter b. Defective instrument cable</p>	<p>a. Replace adapter b. Replace cable.</p>

CHAPTER 4

AVIATION INTERMEDIATE MAINTENANCE INSTRUCTIONS

Section I. PREPARATION FOR MAINTENANCE, STORAGE, AND RESHIPMENT

4-1. Preparation for Maintenance. There are no special unpacking procedures. Unlatch and remove the instrument case from the accessory case. Open the accessory case, remove the dessicant, and check for the items in table 3-1. Loosen the wing nuts on the handle and rotate it to a comfortable position for pushing. Retighten the wing nuts. The tester is ready to be operated after unpacking.

4-2. Preparation for Storage. Place 5 eight-unit bags of dessicant (item 1, table 1-16) in the accessory case. Store the tester in a dry area where the temperature range does not exceed -65 to 160°F (-54 to 71°C).

4-3. Preparation for Reshipment. Place 5 eight-unit bags of dessicant (item 1, table 1-16) in the accessory case. Surround the tester with 2 inches of rubberized hog hair when packing for reshipment. Use the latest revision of specification MIL-P-116, method IIb, and JAN-P-100. A pallet (fig. 3-1) may be prepared to secure the tester in the shipping carton. Four holes in the pallet are for tie-down straps.

4-3.1. General Information for Storage and Shipment. For general technical information on preparation for storage and shipment, refer to TM 55-1500-204-25/1. For regulatory requirements pertaining to equipment placed in administrative storage, refer to AR 750-1.

Section II. CHECKOUT AND ANALYSIS

4-4. General. This section contains information for testing the performance and accuracy of the tester. This information, together with troubleshooting information contained in tables 4-4 through 4-11 enable maintenance personnel to rapidly localize tester malfunctions.

4-5. Warmup Procedure.

a. Turn FUNCTION SELECT, STD DAY, and MASTER POWER switches to OFF position.

b. Connect BH499A power cable to POWER INPUT receptacle and to 115 vat, 50-400 Hz power source.

c. Connect BH15184A power interconnect cable to two INTERCONNECT connectors on tester deck.

d. Place the MASTER POWER switch in ON position and allow 15 minute warmup. POWER ON lamp glows when power is applied to tester.

4-6. Checkout Instructions.

a. Temperature Indicator Accuracy Check.

(1) Make the test setup of figure 4-1.

(2) Place T/C INPUT switch in CHECK CABLE position.

(3) Turn FUNCTION SELECT switch to TRIM.

(4) Turn TEMPERATURE switch to CAL 600° C and adjust CAL ADJ pot until the temperature indicator reads 600° C.

(5) Turn TEMPERATURE switch to OPERATE.

(6) Using temperature vs emf values in table 4-1 or other values equivalent to those in NBS Circular 561 for a chromelalumel thermocouple, check the accuracy of the temperature indicator throughout its range (0° to 1399° C).

(7) The displayed temperatures shall agree with the test signals + 2° C.

b. % RPM Indicator Accuracy Check.

(1) Turn RPM switch to CAL 100% RPM and adjust rpm CAL ADJ potentiometer until display reads 100.0% rpm.

(2) Turn RPM switch to N1 and short pin A to pin B in RPM INPUT INSTRUMENT CABLE receptacle. Display shall read 000.0 + 0.1% rpm.

(3) Turn RPM switch to N2 and short pin C to pin B in RPM INPUT INSTRUMENT CABLE receptacle. Display shall read 000.0 + 0.1% rpm.




Figure 4-1. Temperature Indicator Test Setup.

Table 4-1. Temperature Indicator Accuracy Check Table.

Temperature °C	Millivolt Signal
0	0.00
200	8.13
400	16.40
600	24.91
800	33.30
1000	41.31
1200	48.89
1399	55.89




Figure 4-2. % RPM Indicator Test Setup.

c Standard Day Circuit Accuracy Check.

- (1) Make testsetups of figures 4-1 and 4-2.
- (2) Turn TEMPERATURE switch to OPERATE, RPM switch to N1, STD DAY switch to ON, FUNCTION SELECT switch to TRIM, and place T/C INPUT switch in CHECK CABLE position.
- (3) Using 16.398 mvdc and 63 Hz as inputs (table 4-2), set AMB TEMP potentiometer to different settings in table 4-2 and check readings of temperature and % rpm displays against readings in table.
- (4) Readings of the TEMP °C display shall not differ more than + 3-1/2° and readings of the % RPM display shall not differ more than + 0.5% rpm from the corresponding values in the table.

d. Heater Probe Check and Heater Probe Control Circuit Accuracy Check.

CAUTION

Never add cold probes to a tester that is regulating other probes at elevated temperature. To do so could cause overheating of hot probes, since probe controller operates on average temperature.

NOTE

If less than 8 heater probes are used, the correlation between the PROBE CONTROL setting and the heater probe temperature may exceed +40 C.

- (1) Make test setup of figure 4-3.




Figure 4-3. Test Setup of Heater Probe Control Circuit.

Table 4-2. Standard Day Circuit Test Table

Amp Temp Setting (°F)	Temperature Display			% RPM Display		
	16.398 (rev)	24.911 (rev)	33.299 (rev)	63 Hz (tpa = 15.893 ms)	70 Hz (tpa = 14.286 ms)	77 Hz (tpa = 12.987 ms)
-41	560	809	1055	100.1	111.2	flashes (out-of-range)
- 1	487	715	939	95.8	106.4	117.0
59	399	601	799	90.0	100.0	110.0
99	351	538	723	86.8	96.4	106.1
139	310	484	656	83.8	93.1	102.4

CAUTION

Suspend heater probes in air away from flammable material.

(2) Turn FUNCTION SELECT switch to HEATER PROBE, place T/C INPUT switch in HEATER CABLE position, turn PROBE CONTROL fully counterclockwise, turn TEMPERATURE switch to HEATER PROBE TEMP SET, and turn STD DAY switch to off.

(3) Adjust PROBE CONTROL until temperature indicator reads 600°C.

(4) Turn TEMPERATURE switch to OPERATE and observe probe temperature on indicator. While probes are heating up, PROBE POWER lamp glows continuously. As probe temperature approaches set temperature, PROBE POWER lamp begins to flash. If probe temperature exceeds set temperature, PROBE POWER lamp will go out until probe temperature falls below set temperature. Wait until probe temperature begins to stabilize (lamp flashes on and off regularly) before taking a reading. Temperature indicator shall read $600 \pm 4^\circ\text{C}$.

WARNING

Do not touch hot heater probes as severe burns could result.

(5) Place hand near each heater probe to determine if each probe is heating.

(6) Turn PROBE CONTROL fully counterclockwise and remove power from tester

before disconnecting heater probes.

e. Spread Circuit Functional Check.

(1) Turn TEMPERATURE switch to OPERATE.

(2) Turn FUNCTION SELECT switch to SPREAD.

(3) Remove dust cap from SPREAD CABLE receptacle.

(4) Using a copper jumper wire with male contacts, jumper SPREAD CABLE receptacle contacts listed in table 4-3 when SPREAD switch is in corresponding positions and observe temperature indicator for an ambient temperature reading for each jumper position.

f. Insulation Resistance Accuracy Check.

(1) Connect BH485 instrument cable to INSTRUMENT CABLE receptacle and connect BH821 insulation adapter to instrument cable.

(2) Turn FUNCTION SELECT switch to INSUL.

(3) Adjust screw on INSULATION CHECK meter until meter reads infinity.

(4) Short alligator clips on insulation adapter.

(5) Turn INSULATION CHECK switch to RX100. Meter shall read zero.

(6) Connect a 10K (+ 5%) resistor between the alligator clips. Meter shall read 10K (+ 10%).

(7) Turn INSULATION CHECK switch to

Table 4-3. Spread Circuit Check Table.

Spread Switch Position	Jumper Position
All	A-B, A-C, A-D, A-E, A-F, A-G, A-I-I, A-I
1	A-B
2	A-C
3	A-D
4	A-E
5	A-F
6	A-G
7	A-H
8	A-I

RX1000. Remove resistor and short alligator clips. Meter shall read zero.

(8) Connect 1 100K (+ 5%) resistor between the alligator clips. Meter shall read 100K (+ 10%).

g. Resistance Check Circuit Accuracy Check.

(1) Connect BH485 instrument cable to INSTRUMENT CABLE receptacle and connect resistance check adapter to instrument cable.

(2) Turn RESISTANCE and A/C INDICATOR CHECK switch to NULL BAL position and turn FUNCTION SELECT switch to RES.

(3) Adjust screw on RESISTANCE & A/C INDICATOR CHECK meter until meter reads zero.

(4) Connect a precision 22-ohm resistor (table 1-15) to terminals of resistance check adapter.

(5) Turn RESISTANCE & A/C INDICATOR CHECK switch to 22 . RESISTANCE & A/C INDICATOR check meter shall read zero.

(6) Replace 22-ohm resistor of step (4) with a precision 15-ohm resistor and turn RESISTANCE & A/C INDICATOR CHECK switch to 15 . Meter shall read zero.

(7) Replace 15-ohm resistor of step (6) with a precision 8-ohm resistor and turn RESISTANCE & A/C INDICATOR CHECK switch to 8 . Meter shall read zero.

(8) Replace 8-ohm resistor of step (7) with a precision 4.21 ohm resistor and turn RESISTANCE & A/C indicator check switch to 4.21 . Meter shall read zero.

h. Functional and Accuracy Check of Aircraft Indicator Check Circuit.

(1) Connect BH485 instrument cable to INSTRUMENT CABLE receptacle and connect BH822 egt indicator check adapter to instrument cable.

(2) Turn FUNCTION SELECT switch to A/C IND CHK position, RESISTANCE & A/C INDICATOR CHECK switch to NULL BAL position, and TEMPERATURE switch to OPERATE position.

(3) Connect a digital multimeter (table 1-15) with a 100 mdc range between the + and - eyelet of the egt indicator check adapter if the adapter is for D'Arsonval type indicators or between terminal A (+) and terminal B (-) if the adapter is for null-balance type indicators.

(4) Turn A/C IND ADJ potentiometer from counterclockwise end to clockwise end while observing multimeter. Range of potentiometer shall be approximately 0-65 mdc and there shall be no open spots throughout the range. During this check, TEMP °C indicator shall follow setting of potentiometer and display readings throughout the range of ambient temperature to 1399° C.

NOTE

4.21 position of RESISTANCE & A/C INDICATOR CHECK switch is for checking aircraft circuit resistance only.

(5) Turn RESISTANCE & A/C INDICATOR CHECK switch successively to 8 , 15 , and 22 positions. In each of the above positions, multimeter shall read higher than when switch is in NULL BAL position.

4-7. Trouble Analysis.

a. General Troubleshooting Information.

(1) *Initial Check.* Before troubleshooting a tester using tables 4-4 through 4-11 and paragraphs 4-7 b through 4-7 e, determine (1) that power of the proper voltage and frequency, as specified at the POWER INPUT receptacle, is applied to the tester, and (2) that the MASTER POWER switch is on.

(2) *Gaining Access to Circuit Boards.*

CAUTION

Always remove power from the tester when removing or installing a circuit board,

(a) Probe Controller Boards.

1. Disconnect BH15184A power interconnect cable from INTERCONNECT connectors.
2. Support tester lid and remove lid stop arm screw (12, fig. 4-29).
3. Remove screws (3) around edge of probe controller deck.
4. Lift controller assembly high enough to slip support (fig. 1-43) under back edge of deck.
5. To operate tester after opening probe controller, connect BH15184A-1 power interconnect cable (table 1-15) to INTERCONNECT connectors.

(b) Trimmer Card Cage Boards

CAUTION

For proper terminal identification and to prevent damage to a circuit card in the card cage, install an extender board assembly (table 1-15) such that the lettered terminals are toward the deck and the circuit board such that its components are toward the deck.

1. Disconnect BH15184A power interconnect cable from INTERCONNECT connectors.
2. Remove screws (1, fig. FO-7) around edge of trimmer deck and lift deck assembly from case.

3. Remove circuit card retainers, (8) to gain access to circuit cards.

4. Place an extender board assembly (table 1-15) between the card cage receptacle and the circuit board being tested, observing the caution above.

5. To power the tester after removing the trimmer assembly, connect the BH15184A-1 power interconnect cable (table 1-15) between the INTERCONNECT connectors.

(3) *Test Points.* Test points, star-encircled Arabic numerals, e.g. , are identified on the schematic diagrams and board assembly drawings for the purpose of troubleshooting.

(4) *Integrated Circuits.* Note from the part lists in Section V of Chapter 4 that one board assembly may contain several integrated circuits having the same manufacturer's part number. Swapping locations of identical integrated circuits may provide a clue to a malfunction. Care should be exercised when swapping gates to note which circuits are affected by the gates.

CAUTION

Integrated circuit leads are fragile. Exercise care when removing or installing integrated circuits.

Always remove power from the tester when removing or installing a circuit component. The numbering of integrated circuit pins is explained in paragraph 1-4 b (11) (b).

b. Troubleshooting the DC Power Supplies. Table 4-12 lists voltages and voltage test points of the dc power supplies in the tester. Voltages shall be within voltage ranges when line voltage is 115 ± 15 percent. There are no adjustments to these voltages.

c. Troubleshooting the A/D Converters. Before troubleshooting an A/D converter, open the trimmer assembly per paragraph 4-7a. (2) (b). Make the testsetup of figure 4-1 when troubleshooting the TEMP °C indicator and of figure 4-2 when troubleshooting the % RPM indicator. When troubleshooting either indicator, apply a full-scale signal and use an oscilloscope to check the waveforms of figure 4-7. Indicator data is listed in table 4-13. Test points are identified in figures 4-8 and 4-9 and on the A/D converter schematics (figs. FO-4 and FO-5).

d. Troubleshooting the Temperature Compensator Circuits. There are three temperature compensators in the tester. One is on the calibrator board, one is on the temperature board, and one is on the probe control and function switch board. With power turned off, check the resistance of the precision 34K dropping resistor; R5 (19, fig. 4-36) on the calibrator board, R64 (28, fig. 4-34) on the temperature board, or R2 (43, fig. 4-37) on the probe control and function switch board. Do this by lifting one end of the resistor and measuring it with a digital multimeter. It shall measure $34K \pm 34$ ohms at $25^{\circ} C$ ($77^{\circ}F$). With the end of the resistor still up, measure the resistance of the compensator between terminals B and E. The compensator shall measure 33.2 ± 0.4 ohms at $20^{\circ}C$ ($68^{\circ}F$).

e. Troubleshooting Heater Probe Control Circuit. When troubleshooting the heater probe control circuit, open the probe controller assembly per paragraph 4-7a (2) (a). Connect the BH405 heater cable to the tester and connect a known good heater probe to the heater cable receptacle.

WARNING

To prevent electrical shock or damage to test equipment, use an isolation transformer to power the oscilloscope or tester when troubleshooting the secondary winding of T1 on the probe control and function switch board or the SCR circuits.

CAUTION

Suspend the probe away from flammable material.

Turn the TEMPERATURE switch to HEATER PROBE TEMP SET, and adjust PROBE CONTROL to an elevated temperature (not to exceed $600^{\circ} C$). Use an oscilloscope to check the waveforms of table 4-14. Test points are identified in figure 4-5 and on the probe controller schematic (fig. FO-2).

Table 4-4. General Troubleshooting Table.

Malfunction	Probable Cause	Corrective Action
POWER ON lamp does not light when MASTER POWER switch is on.	<ul style="list-style-type: none"> a. Open circuit breaker, CB1, in probe controller b. Open circuit breaker, CB1, in trimmer. c. Defective MASTER POWER switch d. Defective power transformer 	<ul style="list-style-type: none"> a. Replace circuit breaker (30, figure FO-8). b. Replace circuit breaker (25, figure FO-7). c. Replace switch (41). d. Replace transformer (39).
POWER ON lamp lights when MASTER POWER switch is on but displays do not light when DISPLAY control is turned clockwise.	<ul style="list-style-type: none"> a. Defective DISPLAY control b. Trimmer PCB retainer left off card cage and boards loose in connectors. c. Defective 15 vdc supply d. Defective lamp voltage e. Defective logic voltage supply. 	<ul style="list-style-type: none"> a. Replace control (63, figure FO-7). b. Install retainer (8). c. Repair 15 vdc supply. d. Repair lamp voltage supply. e. Repair logic voltage supply.
Display digit shows wrong numeral sequence or digit has missing segments but checks OK on press-to-test.	<ul style="list-style-type: none"> a. One of decade counters DC1-DC3, DC6, DC7 or one of counter-latch-decoders CLD1-CLD4, or CLD9-CLD12 defective 	<ul style="list-style-type: none"> a. Replace defective circuit.

Table 4-5. TEMP °C Indicator Troubleshooting Table.

Malfunction	Probable Cause	Corrective Action
TEMP °C indicator drifts upscale to 1400°C then flashes on and off.	<ul style="list-style-type: none"> a. Open input circuit 	<ul style="list-style-type: none"> a. Provide an input signal and check for open in appropriate temperature signal circuit. See figures 1-16 and 1-17.
TEMP °C indicator cannot be calibrated with CAL ADJ pot.	<ul style="list-style-type: none"> a. Temperature indicator out of calibration. b. Temperature signal generator out of calibration. c. Defective CAL ADJ pot or connecting wires d. Defective A/D converter 	<ul style="list-style-type: none"> a. Calibrate. b. Calibrate. c. Replace pot (69, figure FO-7) or repair wire. d. Troubleshoot per para. 4-7c.

Table 4-6. % RPM Indicator Troubleshooting Table.

Malfunction	Probable Cause	Corrective Action
% RPM indicator cannot be calibrated with CAL ADJ pot.	<ul style="list-style-type: none"> a. %RPM indicator out of calibration b. Defective + 7 vdc supply cm calibrator board c. Defective 70 Hz signal generator on calibrator board d. Defective CAL ADJ pot or connecting wires e. Defective A/D converter 	<ul style="list-style-type: none"> a. Calibrate. b. Repair + 7 vdc supply. c. Repair signal generator d. Replace pot (65, figure FO-7) e. Troubleshoot per para. 4-7C.

Table 4-7. Standard Day Circuit Troubleshooting Table.

Malfunction	Probable Cause	Corrective Action
Standard day circuit causes excessive shift in temperature and % rpm readings.	a. Standard day circuit out of calibration	a. Calibrate.
AMB TEMP potentiometer circuit cannot be calibrated.	<ul style="list-style-type: none"> a. Defective AMP TEMP b. Defective amplifier A1 on calibrator board c. One of resistors R7-R11 on calibrator board defective d. Defective 9-volt zener diode, CR1, on calibrator board 	<ul style="list-style-type: none"> a. Replace potentiometer b. Replace amplifier (4, figure 4-36) c. Replace defective resistor. d. Replace diode (13).

Table 4-8. Heater Probe Control Circuit Troubleshooting Table.

Malfunction	Probable Cause	Corrective Action
Heater probes will not heat.	<ul style="list-style-type: none"> a. Defective heater cable b. Probe controller circuit breaker CB1 open c. Relay K1 defective d. Probe controller transformer T1 defective e. Defective amplifier (A 1 or A2) transformer (T1), or silicon controlled rectifier (SCR2) on probe control and function switch board. f. Voltage at test point 43 not in phase with line voltage g. SCR2 (rectifier furthest from transformer T1 inside probe control compartment defective. 	<ul style="list-style-type: none"> a. Repair or replace cable. b. Replace circuit breaker (30, figure FO-8) c. Replace relay (28). d. Replace transformer (2). e. Check waveforms per para. 4-7e and replace defective component. f. Check phasing and correct at transformer T1 on probe control and function switch board. g. Replace rectifier.
Heater probes heat too slowly.	<ul style="list-style-type: none"> a. SCR1 on probe control and function switch board defective b. SCR1 rectifier nearest transformer T1 inside probe control compartment) defective 	<ul style="list-style-type: none"> a. Replace rectifier (11, figure 4-37). b. Replace rectifier.
Heater probe temperature cannot be set with PROBE CONTROL.	<ul style="list-style-type: none"> a. PROBE CONTROL defective b. TEMPERATURE switch defective 	<ul style="list-style-type: none"> a. Replace control (20, figure FO-8) b. Replace switch (23, figure 4-31).
Heater probe temperature excessively overshoots or undershoots temperature setting.	<ul style="list-style-type: none"> a. Q3 on probe control and function switch board defective 	<ul style="list-style-type: none"> a. Check waveform per para. 4-7e and replace Q3 (49, figure 4-37) if defective.
Heater probes heat continuously.	<ul style="list-style-type: none"> a. A1, A2, Q2, SCR1, or SCR2 on probe control and function switch board defective b. SCR1 or SCR2 (rectifiers inside probe control compartment defective 	<ul style="list-style-type: none"> a. Check waveforms per para. 4-7e and replace defective component. b. Replace defective rectifier.
Heater probe temperature and set temperature differ more than + 4°C.	<ul style="list-style-type: none"> a. Fewer than 8 heater probes being used with tester. b. Heater probe control circuit out of calibration. 	<ul style="list-style-type: none"> a. Calibrate heater probe control circuit. b. Calibrate circuit.

Table 4-9. Insulation Check Circuit Troubleshooting Table.

Malfunction	Probable Cause	Corrective Action
INSULATION CHECK meter cannot be adjusted to read infinity when FUNCTION SELECT switch is not in INSUL position.	a. INSULATION CHECK meter	a. Replace meter (37, figure figure FO-8).
INSULATION CHECK meter reads infinity with insulation check adapter jumpered and INSULATION CHECK switch in either position.	a. Defective insulation check adapter. b. Defective instrument cable. c. Resistor R26 or R27 on resistance and insulation check board d. Defective FUNCTION SELECT switch e. Defective INSULATION CHECK switch	a. Repair or replace adapter. b. Repair or replace cable c. Replace defective resistor (3, 6, figure 4-38). d. Replace switch (32, figure 4-37). e. Replace switch (13, figure 4-38).
INSULATION CHECK meter drives to zero end with INSULATION CHECK switch in either position.	a. Resistor R30 or R32 on resistance and insulation check board b. Defective FUNCTION SELECT switch.	a. Replace defective resistor (5, 2, figure 4-38). b. Replace switch (32, figure 4-37).

Table 4-10. Resistance Check Circuit Troubleshooting Table.

Malfunction	Probable Cause	Corrective Action
RESISTANCE CHECK meter cannot be zeroed.	<ul style="list-style-type: none"> a. Defective RESISTANCE CHECK meter 	<ul style="list-style-type: none"> a. Replace meter (34, figure FO-8).
RESISTANCE CHECK meter does not deflect when RESISTANCE & A/C INDICATOR CHECK switch is in any position.	<ul style="list-style-type: none"> a. Defective RESISTANCE CHECK meter b. Defective FUNCTION SELECT switch c. Defective BAL potentiometer (R2) on resistance and insulation check board 	<ul style="list-style-type: none"> a. Replace meter (34, figure FO-8). b. Replace switch 32, figure (4-37). c. Replace potentiometer (7, figure 4-38).
RESISTANCE CHECK meter deflects in full clockwise direction in all resistance positions of RESISTANCE & A/C INDICATOR CHECK switch.	<ul style="list-style-type: none"> a. Defective resistance check adapter b. Defective instrument cable c. Resistor R3 open on resistance and insulation check board. d. Defective FUNCTION SELECT switch 	<ul style="list-style-type: none"> a. Repair or replace adapter b. Repair or replace cable. c. Replace resistor (1, figure 4-38). d. Replace switch (32, figure 4-37).

Table 4-11. Aircraft Indicator Check Circuit Troubleshooting Table.

Malfunction	Probable Cause	Corrective Action
TEMP °C indication cannot be adjusted with A/C IND ADJ.	<ul style="list-style-type: none"> a. Defective A/C IND ADJ potentiometer b. Defective 9 vdc power supply on probe control and function switch board. c. Defective RESISTANCE & A/C INDICATOR CHECK switch d. Defective FUNCTION SELECT switch 	<ul style="list-style-type: none"> a. Replace potentiometer (25, figure FO-8). b. Repair power supply. c. Replace switch (18, figure 4-38). d. Replace switch (32, figure 4-37).
Range of A/C IND ADJ is too high when RESISTANCE & A/C INDICATOR CHECK switch is in NULL BAL position.	<ul style="list-style-type: none"> a. Resistor R19 open on resistance and insulation check board 	<ul style="list-style-type: none"> a. Replace resistor (25, figure 4-38).
Aircraft indicator check circuit cable will not drive aircraft indicator.	<ul style="list-style-type: none"> a. Defective instrument cable b. Defective egt indicator check adapter c. Defective FUNCTION SELECT switch d. Defective RESISTANCE & A/C INDICATOR CHECK switch e. One of resistors R22, R23, or R24 on resistance and insulation check board open (D'Arsonval indicator) 	<ul style="list-style-type: none"> a. Repair or replace cable. b. Repair or replace adapter. c. Replace switch (32, figure 4-37). d. Replace switch (18, figure 4-38). e. Replace defective resistor (21, 20, 19).

Table 4-12. DC Power Supply Voltages,

Power Supply	Board Location	Test Points			Voltage Range (vdc)
		+	-	Figure No.	
+28 vdc	BH15720-3	16	13	4-4	25 to 32
+15 vdc	BH15720-3	15	13	4-4	14.8 to 15.2
+9 vdc	BH15801-1	20	21	4-5, sht 1	8.78 to 9.23
+7 vdc	BH16365-1	46	23	4-6	5 to 9*
+5 vdc (logic voltage)	BH15720-3	19	13	4-4	4.7 to 5.2
+5 vdc (lamp voltage)	BH15720-3	17	18	4-4	4.5 to 5.2
-7 vdc	BH16465-1	23	22	4-6	-5 to -9*
15 vdc	BH15720-3	13	14	4-4	-14.8 to -15.2

* ± 7 vdc supply is non-regulated.




Figure 4-4. Switch-Power Board, BH15720-3, Test Points




Figure 4-5. Probe Control and Function Switch Board, BH15801-1, Test Points (Sheet 1 of 2)




Figure 4-5. Probe Control and Function Switch Board, BH15801-1, Test Points (Sheet 2 of 2)





Figure 4-6. Calibrator Board, BH16365-1, Test Points

TEST POINTS
(NOTE 1)

TEMP	%RPM
3	29
7	32
5	30
6	31
9	34
8	33
10	35
11	36
12	37

SEE TABLE 4-13
FOR CLOCK PERIOD



CLOCK 2-5 V
0 V

INT SIG (NOTE 2) 2-5 V
0 V

INTEGRATOR (NOTE 3) 0 V
NEGATIVE VOLTAGE
AMPLITUDE DEPENDS
ON INPUT SIGNAL
LEVEL (15 VOLTS MAX)

COMPARATOR
OUTPUT (A2) 2-5 V
0 V


CLEAR COUNTERS 2-5 V
0 V

TRANSFER-
TO-MEMORY 2-5 V
0 V

SIGNAL SWITCH
Q5 GATE DRIVE
(Q3, COLLECTOR) +15 V
0 V
-15 V

-REF SWITCH
(Q2, COLLECTOR) 2-5 V
0 V
-15 V

+REF SWITCH
(Q4 COLLECTOR) +15 V
0 V
-15 V



NOTES: 1. TEST POINTS ARE IDENTIFIED IN FIGURES 4-8 AND 4-9
WAVEFORMS ARE MEASURED RELATIVE TO GROUND TEST POINT.
2. SIGNAL AND REFERENCE INTEGRATION PERIODS ARE IDENTIFIED
IN TABLE 4-13.
3. INTEGRATOR DISCHARGE CURVE SHOULD BE A STRAIGHT LINE FOR
% RPM INDICATOR

Figure 4-7. Indicator Waveforms




Figure 4-8. Temperature Board, BH 15715-1, Test Points









Figure 4-9. Tachometer Board, BH15717-1, Test Points

Table 4-13. Indicator Data Table.

Indicator Parameter	Clock Period (usec)	Signal Counter Start	Period States Finish	Reference Period Counter State + Out-of-Range	Preamp Output for Full-Scale Inputs	Preamp Output for Zero Reading
Temperature	100	3000	4000	1400	8.44 vdc (+ 0.4 vdc) at 1399° C. Measure at test point 4 in figure 4-8.	0 + 0.04 vdc
% rpm	100	3000	4000	1200	7.16 vdc (+ 0.72 vdc) at 199.9% rpm. Measure at test point 25 in figure 4-9.	0 + 0.04 vdc

Table 4-14. Heater Probe Control Circuit Waveforms.

Test Point (figure 4-5, sht 2)	Waveform*	Remarks
40		Use internal sync.
41		Heater probes cooling. Use line sync. Period determined by line frequency.
41		Heater probes heating. Use line sync. Period determined by line frequency.
42		Use line sync. Period determined by line frequency.
43		Use line sync. Period determined by line frequency.

* All waveforms are referenced to test point 38. Waveform amplitudes may vary $\pm 10\%$ due to component tolerances.

Table 4-14. Heater Probe Control Circuit Waveforms. (Continued)

Test Point (figure 4-5, sht 2)	Waveform*	Remarks
44		Heater probes cooling. Use line sync. Period determined by line frequency.
44		Heater probes heating. Use line sync. Period determined by line frequency.
45		Heater probes cooling. Use line sync.
45		Heater probes heating. Use line sync. Period determined by line frequency

* All waveforms are referenced to test point 38. Waveform amplitudes may vary $\pm 10\%$ due to component tolerances.




Figure 4-10. Trimmer Tester Points and Adjustments

4-8. SCHEMATIC DIAGRAMS. The following is a list of the schematic diagrams. Tester schematics appear first followed by accessory schematics.

Index of Schematic Diagrams

Figure	Title	Page
4-11	Trimmer Assembly, BH15195A-8, Schematic	4-27
4-12	Mother Board, BH15719-2, Schematic	4-28
4-13	Display Board, BH16358-2, Schematic	4-29
4-14	Switch Box, BH123-3, Schematic	4-30
4-15	Junction Box, BH361-8, Schematic	4-30
4-16	Heater Cable, BH405, Schematic	4-31
4-17	Check Cable, BH450, Schematic	4-31
4-18	Instrument Cable, BH485, Schematic	4-31
4-19	Power Cable, BH499A, Schematic	4-32
4-20	RPM Check Adapter, BH820, Schematic	4-32
4-21	Insulation Check Adapter, BH821, Schematic	4-32
4-22	EGT Indicator Check Adapter, BH822, Schematic	4-33
4-23	Resistance Check Adapter, BH823, Schematic	4-33
4-24	Heater Probe, BH996-40	4-33
4-25	Check Cable Adapter, BH1504, Schematic	4-34
4-26	Check Cable Adapter, BH4548, Schematic	4-34
FO-2	Probe Controller Assembly, BH15194A-4, Schematic	
FO-3	Switch-Power Board, BH15720-3, Schematic	
FO-4	Temperature Board, BH15715-1, Schematic	
FO-5	Tachometer Board, BH15717-1, Schematic	
FO-6	Calibrator Board, BH16365-1, Schematic	




Figure 4-11. Trimmer Assembly, BH15195A-8, Schematic





Figure 4-12. Mother Board, BH15719-2, Schematic



PI MATES J1
ON BH15719-2
MOTHER B'D

NOTE:
1. RESISTANCE IS IN OHMS AND
CAPACITANCE IS IN MICROFARADS
UNLESS OTHERWISE NOTED.

Figure 4-13. Display Board, BH16358-2, Schematic





Figure 4-14. Switch Box, BH123-3, Schematic.



NOTES:

1. WIRES CONNECTED TO PINS A AND B ARE 16 GA COPPER
2. WIRES CONNECTED TO PINS C ARE 24 GA ALUMEL
3. WIRES CONNECTED TO PINS D ARE 24 GA CHROMEL
4. ALL CONNECTORS EXCEPT JI MATE HEATER PROBES

Figure 4-15. Junction Box, BH361-8, Schematic




Figure 4-16. Heater Cable, BH405, Schematic.




Figure 4-17. Check Cable, BH450, Schematic.




Figure 4-18. Instrument Cable, BH485, Schematic




Figure 4-19. Power Cable, BH499A, Schematic.




Figure 4-20. RPM Check Adapter, BH820, Schematic.




Figure 4-21. Insulation Check Adapter, BH821, Schematic




Figure 4-22. EGT Indicator Check Adapter, BH822, Schematic.




Figure 4-23. Resistance Check Adapter, BHH23, Schematic.




Figure 4-24. Heater Probe, BH996-40, Schematic




Figure 4-25. Check Cable Adapter, BH1504, Schematic.




Figure 4-26. Check Cable Adapter, BH4548, Schematic.

Section III. REPAIR PROCEDURES

4-9. Soldering. Use a minimum amount of heat when unsoldering and resoldering components. Resolder components using 60/40 tin-lead rosin-core solder (item 2, table 1-16). Also use a flux (item 8) when soldering thermocouple wire. Isopropyl alcohol (item 4) may be used to remove excess flux.

4-10. Removal and Disassembly.

a. Removal of Trimmer Deck Assembly.

(1) Disconnect BH15184A power interconnect cable from INTERCONNECT connectors.

(2) Remove screws around edge of trimmer deck and lift trimmer deck assembly from case.

(3) See paragraph 4-11 for installation of trimmer deck assembly.

b. Removal of Probe Controller Assembly.

(1) Disconnect BH15184A power interconnect cable from INTERCONNECT connectors.

(2) Support tester lid and remove lid stop arm screw (12, fig. 4-29).

(3) Remove screws (3) around edge of probe controller deck.

(4) Lift controller assembly high enough to gain access to components in probe controller compartment.

(5) Mark wires to SCR's and remove screws holding terminal lugs to cathodes and unsolder wires to gates.

(6) Unscrew SCR's from heatsinks.

(7) Remove four screws holding transformer (2, fig. FO-8) to bottom of probe controller compartment and remove probe controller assembly, wire harness, and transformer.

(8) See paragraph 4-12 for installation of probe controller assembly.

c. Removal of Switch-Power Board.

(1) Open trimmer assembly per paragraph 4-10a

(2) Disconnect thermocouple connectors P13 (20, fig. 4-31) and P14 (21) on side of card cage.

(3) Remove four screws (4, fig. FO-7) attaching harness connectors J8 and J9 (5) to the board and remove the connectors.

(4) Remove three screws (18) at each end of

the board that hold connectors P6 and P7 between this board and the mother board.

(5) Remove the TEMPERATURE, RPM, and STD DAY switch knobs and retaining nuts.

(6) Remove six screws (19) that are in line with the above switches and remove the board.

(7) See paragraph 4-13 for installation of board.

d. Removal of Probe Control and Function Switch Board.

(1) Open probe controller assembly per paragraph 4-10 b.

(2) Remove two screws (11, fig. FO-8) holding connector J6 to the probe control and function switch board.

(3) Remove four screws (1) holding harness connectors P12 and P13 to board.

(4) Note location of and unsolder compensator chromel and alumel wires (white and green wires) from T/C INPUT switch (22).

(5) Mark and unsolder following wires from probe control and function switch board: (1) blue wire from eyelet POLE 7; (2) red wire from eyelet POLE 8; (3) blue wire from eyelet D7, P4; (4) red wire from eyelet P3; and (5) red wire from eyelet P8.

(6) Remove knobs (7) and seal nuts (9) from SPREAD and FUNCTION SELECT switches and remove board.

(7) See paragraph 4-14 for installation of board.

e. Removal of Resistance and Insulation Check Board.

(1) Open probe controller assembly per paragraph 4-10 b.

(2) Remove two screws (23, fig. 4-38) holding board to connector J6.

(3) Remove two screws (1, fig. FO-8) holding harness connector P7 to board.

(4) Remove knobs (12) and seal nuts (14) from INSULATION CHECK switch and RESISTANCE & A/C INDICATOR CHECK switch and remove board.

(5) Install board per paragraph 4-15.

f. Removal of CAL ADJ Potentiometers.

(1) Open trimmer assembly per paragraph 4-10a.

(2) Mark and unsolder wires from potentiometer.

(3) Relieve tension on pot hook clip (fig. 4-27) by turning nut on potentiometer shaft.

(4) Unscrew potentiometer shaft from panel bushing and remove potentiometer.

(5) Install CAL ADJ potentiometers per paragraph 4-16.

g. Removal of Heater Probe Power SCR.

(1) Open probe controller assembly per paragraph 4-10 b.

(2) Mark and remove wires from SCR cathodes and gates.

(3) Unscrew SCR from heat sink.

(4) Install SCR per paragraph 4-17.

Section IV. REASSEMBLY AND ALIGNMENT

4-11. Installation of Trimmer Deck Assembly.

CAUTION

Do not force circuit boards into card cage. Circuit boards are keyed to prevent insertion into incorrect connectors.

a. Inspect deck gasket (91, fig. FO-7) for breaks and deterioration and replace if necessary to ensure a watertight seal. When replacing deck gasket, apply adhesive (item 5, table 1-16), or an equivalent, to the underneath side of the gasket to hold it in place and assure a watertight seal.

b. Inspect the bead of sealant around the flange of the case for creaks or voids and replace as necessary with sealant (item 6, table 1-16), or an equivalent, for a watertight seal.

c. Ascertain that all circuit boards and card cage circuit card retainers are secured in place.

d. Set trimmer assembly in instrument case.

e. Use new seal screws (1, fig. FO-7) to secure trimmer assembly to instrument case.

f. Connect BH15184A power interconnect cable between INTERCONNECT connectors.

4-12. Installation of Probe Controller Assembly.

a. Inspect deck gasket (18, fig. FO-9) for breaks and deterioration and replace if necessary to ensure a watertight seal.

b. Inspect the bead of sealant at the ends and bottom of the case divider and around the flange for breaks or voids and repair as necessary with sealant (item 6, table 1-16).

c. Install deck gasket, applying adhesive (item 5, table 1-16) to the bottom side to ensure a watertight

seal.

d. Install the transformer (2, fig. FO-8) in the bottom of the probe controller compartment using new seal screws (4, fig. 4-29) if required.

e. Reconnect wires to cathodes and gates of SCR's.

f. Install probe controller deck in instrument case, using new seal screws (3).

g. Attach lid stop arm to stop arm support with stop arm screw (12).

h. Connect BH15184A power interconnect cable between INTERCONNECT connectors.

4-13. Installation of Switch-Power Board.

NOTE

Perform the accuracy check of paragraph 4-6g after installing the switch-power board.

a. Attach heat sinks to trimmer deck with six seal screws (19, fig. FO-7).

b. Install seal nuts (17) on TEMPERATURE, RPM, and STD DAY switch shafts.

c. Install knobs (15) on TEMPERATURE, RPM, and STD DAY switches.

d. Install three screws (18) at each end of board that hold connectors P6 and P7 (2, fig. 4-32) between this board the mother board.

4-14. Installation of Probe Control and Function Switch Board.

NOTE

Perform the checks of paragraphs 4-6d, f, and h after installing the probe control and function switch board.

a. Place non-turn washers (19, fig. FO-8) over shafts of SPREAD and FUNCTION SELECT

switches and insert shafts through holes in probe controller deck.

b. Install seal nuts (9) and knobs (7) on switch shafts.

c. Resolder wires, removed in step (5) of paragraph 4-10d, to board.

d. Resolder chromel and alumel wires to T/C INPUT switch using solder (item 7, table 1-16) and flux (item 8).

e. Attach harness connector P12 (fig. FO-8) to board using two screws (1).

f. Attach harness connector P13 to board using two screws (1).

g. Install two screws (11) that attach connector P6 to board

4-15. Installation of Resistance and Insulation Check Ward.

NOTE

Perform the accuracy checks of para-

graphs 4-6f, g, and h after replacing resistance and insulation check board.

a. Place non-turn washers (15, fig. FO-8) over shafts of INSULATION CHECK and RESISTANCE & A/C INDICATOR CHECK switches and insert shafts through holes in probe controller deck.

b. Install seal nuts (14) and knobs (12) on switch shafts.

c. Attach harness connector P7 to board with two screws (1).

d. Install two screws (23, fig. 4-38) that hold against connector J6.

4-16. Installation of CAL ADJ Potentiometers.

a. Inspect condition of pot hook gasket and o-ring (fig. 4-27). If worn or deteriorated, replace old pot hook with new pot hook.

b. Place gasket on bushing and insert bushing in trimmer deck.




Figure 4-27. CAL ADJ Potentiometer Installation Detail




Figure 4-28. Power SCR Installation Detail.

- c. Place clip over potentiometer shaft and screw shaft about two turns into bushing.
- d. Apply tension to clip with nut.
- e. Resolder wires removed from potentiometer.

4-17. Installation of Heater Probe Power SCR and Heat Sink.

- a. Apply heat sink compound (item 9, table 1-16) to the area of the case where the mica insulation makes contact with the case and to the case side of the heat sink.
- b. Insert two seal screws (fig. 4-28) through case and place two pieces of mica insulation over pro-

truding ends of screws.

- c. Place a plastic sleeve over each screw.
- d. Place heat sink over screws and sleeves and fasten heat sink to case with two fiber washers and two locknuts.
- e. Ascertain with an ohmmeter that there is no electrical contact between the heatsink and the case.
- f. Place anode soldering lug on SCR and screw SCR into heat sink.
- g. Reconnect cathode and gate wires to SCR.

Section V. PARTS LISTING

4-18. General. This section contains figures and parts lists of all tester assemblies. Included are exploded views of assemblies with parts numbered in disassembly order. Each index number in a parts list is followed by the part number, the part name, and the manufacturer's federal supply code (FSCM).

4-19. Federal Supply Code List of Manufacturers. The following is a list of the names and addresses of all manufacturers supplying items or articles together with their code symbols. Absence of a manufacturer's code in the description column indicates that the part is a Government standard part.

00779	Amp, Inc. Harrisburg, Pa 17105	14752	Electro Cube, Inc. San Gabriel, Ca 91776
01073	Acor, Inc. El Monte, Ca 91731	18677	Scanbe Mfg. Corp. El Monte, Ca 91731
01295	Texas Instruments, Inc. Semiconductor-Components Div. Dallas, Tx 75222	21604	Buckeye Stamping Co., The Columbus, Oh 43207
02660	Bunker Ramo Corp. Amphenol Connector Div. Broadview, 1160153	31589	Apc Mfg. Co. Massapequa, NY 11758
02799	Arco Electronics Torrance, Ca 90501	37942	Mallory PR and Co., Inc. Indianapolis, In 46206
03508	General Electric Co. Semiconductor Products Dept. Syracuse, NY 13201	50436	Hewlett-Packard Co. Microwave Div. Palo Alto, Ca 94304
04157	Omega Engineering, Inc. Canoga Park, Ca 91304	53507	Robleyco Richardson, Tx 75080
04274	Rosemont, Inc. Eden Prairie, Mn 55343	56289	Sprague Electric Co. North Adams, Ma 01247
04618	American Pamcor, Inc. Paoli, Pa 19301	63743	Ward Leonard Electric Co., Inc. Mount Vernon, NY 10550
04713	Motorola, Inc. Semiconductor Products Div. Phoenix, AZ 85008	64467	Weksler Instruments Corp. Long Island, NY 11520
06928	Teledyne Kinetics Solana Beach, Ca 92075	70485	Atlantic India Rubber Works, Inc. Chicago, 1160607
07263	Fairchild Semiconductor Div. of Fairchild Camera and Instruments Corp. Mountain View, Ca 94042	7 279	Cambridge Thermionic Corp. Cambridge, Ma 02138
12040	National Semiconductor Corp. Danbury, Ct 06810	7 400	Bussman Mfg. Div. of McGraw-Edison Co. St. Louis, Mo 63017
12697	Clarostat Mfg. Co., Inc. Dover, NH 03820	71590	Globe-Union, Inc. Centralab Div. Milwaukee, Wi 53201
13074	Multi-Flex Seals, Inc. Hackensack, NJ 07601	71785	TRW Electronics Components Cinch Div. Elk Grove Village, 1160007
13861	National Precision Products Co. Dallas, Tx 75220	72619	Dialight Corp. Sub. of Digitronics Corp. Brooklyn, NY 11237
		72982	Erie Technological Products, Inc. Erie, Pa 16512

- | | |
|---|--|
| <p>73138 Beckman Instruments, Inc.
Helipot Div.
Fullerton, Ca 92634</p> <p>75915 Littelfuse, Inc.
DesPlaines,1160016</p> <p>77342 AMF Inc.
Potter and Brumsfield Div.
Princeton, In 47570</p> <p>77820 Bendix Corp.
Electrical Components Div.
Sidney, NY 13838</p> <p>78046 Salisbury WH and Co., Inc.
Chicago, 1160622</p> <p>79136 Waldes Kohinoor, Inc.
Long Island City, NY 11101</p> <p>80031 Mepco/Electra Inc.
A North American Phillips Co.
Morristown, NJ 07960</p> <p>80294 Bourns, Inc. Instrument Div.
Riverside, Ca 92506</p> <p>81073 Greyhill, Inc.
La Grange, 1160525</p> <p>81095 Triad-Utrad
Div. Litton Systems, Inc.
National City, Ca 92050</p> | <p>82647 Texas Instruments, Inc.
Control Products Div.
Attleboro, Ma 02703</p> <p>83330 Smith, Herman H., Inc.
Brooklyn, NY 11207</p> <p>86684 RCA Corp. Electronic Components
Harrison, NJ 07029</p> <p>86928 Seastrom Manufacturing Co.
Glendale, Ca 91201</p> <p>88245 Litton Systems, Inc.
USECO Div.
Van Nuys, Ca 91409</p> <p>91506 Augat, Inc.
Attleboro, Ma 02703</p> <p>91637 Dale Electronics, Inc.
Columbus, Nc 68601</p> <p>94721 Weston Instruments, Inc.
Weston Components Div.
Archbald, Pa 18403</p> <p>94603 Waters Mfg., Inc.
Wayland, Ma 01778</p> <p>97539 Apm-Hexseal Corp.
Englewood, NJ 07631</p> <p>98869 Howell Instruments, Inc.
3479 W. Vickery Blvd.
Ft. Worth, Tx 76107</p> |
|---|--|

Index of Parts List Figures

Figure	Title	Page
4-29	BH112JB-53 and BH112JB-79 Tester, Exhaust Gas Temperature	4-41
4-30	BH16700-12 Accessory Kit	4-43
4-31	BH15720-3 Switch-Power Circuit Board Assembly	4-48
4-32	BH156719-2 Mother Circuit Board Assembly	4-51
4-33	BH16358-2 Display Circuit Board Assembly	4-52
4-34	BH15715-1 Temperature Circuit Board Assembly	4-54
4-35	BH15717-1 Tachometer Circuit Board Assembly	4-57
4-36	BH16365-1 Calibrator Circuit Board Assembly	4-60
4-37	BH15801-1 Probe Control and Function Switch Circuit Board Assembly	4-64
4-38	BH16367-3 Resistance and Insulation Check Circuit Board Assembly	4-66
4-39	H122 Accessory Case	4-69
FO-7	BH15195A-8 Trimmer Assembly	
FO-8	BH15194A-4 Probe Controller Assembly	
FO-9	BH15835-2 Instrument Case Assembly	

4-40 Change 5




Figure 4-29. BH112JB-53 Jetcal Tester.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-29	BH112JB-53								TESTER, Exhaust gas temperature (98869)	1
	BH16700-12								. . ACCESSORY KIT (See figure 4-30 for breakdown.) (98869)	1
	BH112JB-916								. . JETCAL ANALYZER (98869)	1
-1	BH15195A-8								. . TRIMMER ASSEMBLY (See figure FO-7 for breakdown.) (98869)	1
-2	BH15194A-4								. . PROBE CONTROLLER ASSEMBLY (See figure FO-8 for breakdown.) (98869)	1
-3	SEELSKREW/R/ 6-32x1/2"								. . SCREW, Seal (AP) (13074)	8
-4	SEELSKREW/R/ 10-32x1/2"								. . SCREW, Seal (AP) (13074)	4
	MS20365-1032A								. . NUT (not shown) (AP)	4
-5	BH15835-2								. . INSTRUMENT CASE ASSEMBLY (See figure FO-9 for breakdown.) (98869)	1
-6	BH760-1								. . NAMEPLATE (98869)	1
-7	MS21318-1								. . SCREW (AP)	4
-8	BH16805								. . INSTRUCTION PLATE (98869)	1
-9	MS21318-1								. . SCREW (AP)	12
-10	BH14978-2								. . STOP ARM (98869)	1
-11	BH437								. . STOP ARM SUPPORT (98869)	1
-12	MS51958-61								. . SCREW (AP)	1
-13	5151								. . THERMOMETER (64467)	1
-14	H122								. . ACCESSORY CASE (See figure 4-39 for breakdown.) (98869)	1
	BH15185A								. . POWER CABLE ADAPTER (Not shown) (98869)	1
	BH15184A								. . INTERCONNECT CABLE (Not shown) (98869)	1




Figure 4-30. BH16700-12 Accessory Kit.

TM 55-4920-401-13&P

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-30	BH16700-12								ACCESSORY KIT (98869).....	REF
-1	BH123-3								. SWITCH BOX (98869).....	1
-2	BH361-8								. JUNCTION BOX (98869).....	1
-3	BH405								. HEATER CABLE (98869).....	1
-4	BH450								. CHECK CABLE (98869).....	1
-5	BH485								. INSTRUMENT CABLE (98869).....	1
-6	BH492B-3								. EXTENSION HANDLE (98869).....	1
-7	BH499A								. POWER CABLE (98869).....	1
-8	BH820								. RPM CHECK ADAPTER (98869).....	1
-9	BH821								. INSULATION CHECK ADAPTER (98869).....	1
-10	BH822								. EGT INDICATOR CHECK ADAPTER (98869).....	1
-11	BH823								. RESISTANCE CHECK ADAPTER (98869).....	1
-12	BH996-40								. HEATER PROBE (98869).....	1
-13	BH1504								. CHECK CABLE ADAPTER (98869).....	1
-14	BH4548								. CHECK CABLE ADAPTER (98869).....	1

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
FO-7	BH15195A-8	TRIMMER ASSEMBLY (See figure 4-29 for NHA.) (98869)							REF	
- 1	SEELSKREW/R/10-32 x 1/2"	. SCREW, Seal (AP) (13074).....							8	
- 2	BH15813-I	. TRIMMER HARNESS (98869).....							1	
- 3	MS35275-206	. SCREW (AP).....							3	
- 4	COML	. SCREW, Machine, flat hd, cross recess, 2-56x9/16 inch 1 (AP) (13861).....							4	
	34567	. . TERMINAL LUG (Not shown) (04618).....							2	
- 5	C406-021	. . CONNECTOR (06928).....							2	
- 6	NMP-COCO-F	. . CONNECTOR (04157).....							1	
- 7	Not Used									
- 8	BH16295	. RETAINER (98869).....							2	
- 9	MS51957-28	. SCREW (AP).....							4	
-10	BH16365-1	. CALIBRATOR CIRCUIT BOARD ASSEMBLY (See figure 4-36 for breakdown.) (98869).....							1	
-11	BH15717-1	. TACHOMETER CIRCUIT BOARD ASSEMBLY (See figure 4-35 for breakdown.) (98869).....							1	
-12	Not used									
-13	BH15715-I	. TEMPERATURE CIRCUIT BOARD ASSEMBLY (See figure 4-34 for breakdown.) (98869).....							1	
-14	BH16358-2	. DISPLAY CIRCUIT BOARD ASSEMBLY (See figure 4-33 for breakdown.) (98869).....							1	
-15	SS-70BL-2 BLK	. KNOB (21604).....							3	
-16	BH15720-3	. SWITCH-POWER CIRCUIT BOARD ASSEMBLY (See figure 4-31 for breakdown.) (98869).....							1	
-17	N-9030-1/4	. SEAL NUT (AP) (97539).....							3	
-18	MS51957-2	. SCREW (AP).....							6	
-19	SEELSKREW/R/4-40x3/8"	. SCREW, Seal (AP) (13074).....							6	
-20	BH15719-2	. MOTHER CIRCUIT BOARD ASSEMBLY (See figure 4-32 for breakdown.) (98869).....							1	
-21	MS51957-28	. SCREW (AP).....							4	
-22	BH15814	. CARD CAGE (98869).....							1	
-23	SEELSKREW/R/8-32x5/8"	. SCREW, Seal (AP) (13074).....							2	
-24	SEELSKREW/R/8-32x1/2"	. SCREW, Seal (AP) (13074).....							2	
-25	6756-1-1/2	. CIRCUIT BREAKER (82647).....							1	
-26	1415-4	. TERMINAL LUG (AP) (83330).....							1	
-27	MS51957-14	. SCREW (AP).....							2	
-28	BH15559-I	. BEZEL (98869).....							1	
-29	BH15561	. WINDOW (98869).....							1	
-30	BH15560	. BEZEL GASKET (98869).....							1	
-30A	SEELSKREW/R/4-40x7/16"	. SCREW, Seal (AP) (13074).....							2	
-31	Not used									
-32	Not used									
-33	Not used									
-34	Not used									
-35	Not used									
-36	Not used									

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
FO-7-37	Not used									
-38	Not used									
-39	BH15712	.							TRANSFORMER (98869)	1
-40	MS20365-1032A	.							NUT (AP)	4
-40	SEELSKREW/R/ 1032x1/2"	.							SCREW, Seal (AP) (13074)	4
-41	MS35059-24	.							SWITCH	1
-42	N-9030-B	.							SEAL NUT (AP) (97539)	1
-43	250-1471-500	.							LAMP CAP (72619)	1
-44	507-5824-0747-600	.							LAMP (72619)	1
-45	250-8758-33-504	.							LAMP BASE (72619)	1
-46	250-1473-500	.							LAMP CAP (72619)	1
-47	507-5821-0747-600	.							LAMP (72619)	1
-48	250-8758-33-504	.							LAMP BASE (72619)	1
-49	Not used									
-50	BH17956-1	.							CLAMP (98869)	1
-51	MS51957-43	.							SCREW (AP)	1
	MS35333-72	.							WASHER (AP)	1
-52	BH17957	.							SPACER (AP) (98869)	1
-53	SEELSKREW/R/ 8-32 X 1/2"	.							SCREW, Seal (AP) (13074)	1
-54	Not used									
-55	Not used									
-56	Not used									
-57	Not used									
-58	H5600P-56	.							TA'POT POTENTIOMETER (98869)	1
-59	BH6522	.							GASKET (98869)	1
-60	Not used									
-61	SEELSKREW/R/ 4-40x5/16"	.							SCREW, Seal (AP) (13074)	2
-62	SSN-70-2 SHORT BLK	.							KNOB (21604)	1
-62A	SSN-70-2 BLK	.							KNOB (21604)	1
-63	53C3-50K	.							POTENTIOMETER (12697)	1
-64	N-9030-1/4	.							SEAL NUT (AP) (97539)	1
-65	BH18690-2	.							POTENTIOMETER (98869)	1
-66	CA10006	.							POTENTIOMETER HOOK (AP) (94693)	1
-67	Not used									
-68	Not used									
-69	BH18690-3	.							POTENTIOMETER (98869)	1
-70	CA10006	.							POTENTIOMETER HOOK (AP) (94603)	1
-71	30-252R	.							SWITCH (81073)	1
-72	MS25043-12C	.							DUST CAP	1
-73	BH9020P	.							CONNECTOR (98869)	1
-74	10-36675-12	.							GASKET (77829)	1
-75	SEELSKREW/R/ 4-40x1/2"	.							SCREW, Seal (AP) (13074)	4
	MS20365-440A	.							NUT (AP)	4
-76	MS25043-14C	.							DUST CAP	1
-77	BH9140S	.							CONNECTOR (98869)	1
-78	10-36675-14	.							GASKET (77829)	1

Figure & index Number	Part Number	1 2 3 4 5 6 7	Description	Units Per Assy
FO-7-79	SEELSKREW/R/4-40x1/2"	.	SCREW, Seal (AP) (13074)	4
	MS20365-440A	.	NUT (AP)	4
-80	10-101960-143	.	DUST CAP (77829)	1
-81	BH9385P	.	CONNECTOR (98869)	1
-82	36675-14	.	GASKET (77829)	1
-83	SEELSKREW/R/4-40x1/2"	.	SCREW, Seal (AP) (13074)	4
	MS20365-440A	.	NUT (AP)	4
-84	1291-1	.	HANDLE (71279)	2
-85	MS51959-45	.	SCREW (AP)	4
-86	BH6555	.	WINDOW (98869)	1
-87	Not used			
-88	BH15807A	.	DECK, Marked (98869)	1
-89	BH15179-2	.	INSTRUMENT CASE (Partial breakdown follows.) (98869)	1
-80	BH4742-2	.	NAMEPLATE (98869)	1
-91	BH16833	.	GASKET (98869)	1
-92	165A	.	RUBBER FOOT (70485)	4
-93	MS20365-832A	.	NUT (AP)	4




Figure 4-31. BH15720-3 Switch-Power Circuit Board Assembly.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-31	BH15720-3	SWITCH-POWER CIRCUIT BOARD ASSEMBLY (See figure FO-7 for NHA.) (98869)								REF
-1	CG872U020V2C3PL	.							CAPACITOR (37942)	1
-2	MS51960-62	.							SCREW (AP)	2
-3	2N4945	.							TRANSISTOR (07263)	9
-4	CK05BX222K	.							CAPACITOR	1
-5	1-4-5P1K5	.							RESISTOR (80031)	1
-6	1N5624	.							DIODE (03508)	4
-7	131OD	.							TERMINAL (88245)	8
-8	TTX200MFD35VDC	.							CAPACITOR (37942)	2
-9	1N5059	.							DIODE (03508)	7
-10	RN55D1002F	.							RESISTOR	5
-11	TCG122U050N2C3P	.							CAPACITOR (37942)	2
-12	1-4-5P4K7	.							RESISTOR (80031)	3
-13	1-4-5P1K	.							RESISTOR (80031)	1
-14	RN55D6981F	.							RESISTOR	1
-15	RN55D8060F	.							RESISTOR	1
-16	C933	.							DIODE (98869)	1
-17	SN52741L	.							INTEGRATED CIRCUIT (01295)	3
-18	8-ICS	.							SOCKET (71785)	3
-19	1-4-5P470E	.							RESISTOR (80031)	4
-20	NMP-COCO-M	.							CONNECTOR (04157)	1
-21	NMP-CHAL-M	.							CONNECTOR (04157)	1
-22	NMP-CHAL-F	.							CONNECTOR (04157)	1
-23	71BY23198-1-3N	.							SWITCH (81073)	1
-24	2N6109	.							TRANSISTOR (86684)	2
-25	MS18212-5	.							SCREW (AP)	6
-26	MS35649-224	.							NUT (AP)	6
-27	BH15721	.							HEAT SINK (98869)	2
-28	2N4402	.							TRANSISTOR (04713)	3
-29	2N6290	.							TRANSISTOR (86684)	2
-30	Not used	.								
-31	2N5296	.							TRANSISTOR (86684)	2
-32	CS13BC396K	.							CAPACITOR	1
-33	TT50X150	.							CAPACITOR (37942)	1
-34	71BY23195-1-3N	.							SWITCH (81073)	1
-35	1-4-5P2K2	.							RESISTOR (80031)	2
-36	BH15721-1	.							HEAT SINK (98869)	1
-37	1N702	.							DIODE (01295)	2
-38	C389	.							CAPACITOR (98869)	1
-39	71BY23197-1-2N	.							SWITCH (81073)	1
-40	1-4-5P470K	.							RESISTOR (80031)	1
-41	1-4-5P100K	.							RESISTOR (80031)	2
-42	1-4-5P100E	.							RESISTOR (80031)	1
-43	CK05BX103K	.							CAPACITOR	1
-44	1-4-5P10K	.							RESISTOR (80031)	2
-45	RC20GF271K	.							RESISTOR	1
-46	1-4-5P5K6	.							RESISTOR (80031)	1
-47	1-4-5P39K	.							RESISTOR (80031)	2
-48	1-4-5P22K	.							RESISTOR (80031)	1
-49	CS13BF226K	.							CAPACITOR	2

Figure & Index Number	Part Number	2	3	4	5	6	7	Description	Units Per Assy
4-31-50	1N5232B	.						DIODE (04713).....	1
-51	36D132G050AA2A	.						CAPACITOR (56289).....	1
-52	RN55D5761F	.						RESISTOR.....	1
-53	TCG412UO15N1L	.						CAPACITOR (37942).....	1
-54	BH15722	.						NUT PLATE (98869).....	1
-55	MS51957-3	.						SCREW (AP).....	2
-56	5610-9-10	.						NYLON WASHER (AP) (86928).....	2
-57	RN55D3321F	.						RESISTOR.....	1
-58	1-4-5P6K8	.						RESISTOR (80031).....	1
-59	BH15720	.						PRINTED CIRCUIT BOARD, Machined (98869).....	1
4-32	BH15719-2	MOTHER CIRCUIT BOARD ASSEMBLY (See figure FO-7 for NHA.) (98869).....							REF
-1	225-22821-110	.						CONNECTOR (02660).....	4
-2	B304-038	.						CONNECTOR (06928).....	2
-3	MS51957-2	.						SCREW (AP).....	6
-4	MS35333-69	.						WASHER (AP).....	6
-5	225-594	.						POLARIZING KEY (02660).....	4
-6	BH15719	.						PRINTED CIRCUIT BOARD, Machined (98869).....	1




Figure 4-32. BH15719-2 Mother Circuit Board Assembly.




Figure 4-33. BH16358-2 Display Circuit Board Assembly.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-33	BH16358-2	DISPLAY CIRCUIT BOARD ASSEMBLY (See figure FO-7 for NHA.) (98869)								REF
-1	SN5490N	.	INTEGRATED CIRCUIT (01295).....							5
-2	US-2-14-160-G-B	.	SOCKET (18677).....							5
-3	CK06BX103K	.	CAPACITOR.....							3
-4	MC4350L	.	INTEGRATED CIRCUIT (04713).....							8
-5	US-2-16-160-G-B	.	SOCKET (18677).....							8
-6	899-3-R150	.	RESISTOR NETWORK (73138).....							8
-7	5082-7650	.	DISPLAY (50436).....							8
-8	US-2-14-160-G-B	.	SOCKET (18677).....							8
-9	1-4-5P4K7	.	RESISTOR (80031).....							1
-10	Not used									
-11	1-4-5P270E	.	RESISTOR (80031).....							2
-12	R-1003-A-2	.	EJECTOR (53507).....							2
-13	BH16357	.	BUSS (98869).....							1
-14	2024B	.	TERMINAL (88245).....							13
-15	BH16358	.	PRINTED CIRCUIT BOARD, Machined (98869)							1




Figure 4-34. BH15715-1 Temperature Circuit Board Assembly.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-34	BH15715-1	TEMPERATURE CIRCUIT BOARD ASSEMBLY (See figure FO-7 for NHA.) (98869)								REF
-1	H3536	.							RESISTOR (98869)	1
-2	C933	.							DIODE (98869)	2
-3	RN55D6980F	.							RESISTOR	1
-4	H3895	.							RESISTOR (98869)	1
-5	CK05CW102K	.							CAPACITOR	2
-6	H3905	.							RESISTOR (98869)	1
-7	1-4-5P2K2	.							RESISTOR (80031)	11
-8	1-4-5P4K7	.							RESISTOR (80031)	5
-9	C1904	.							TRANSISTOR (98869)	4
-10	SN5442N	.							INTEGRATED CIRCUIT (01295)	1
-11	US-2-16-160-G-B	.							SOCKET (18677)	1
-12	SN5400N	.							INTEGRATED CIRCUIT (01295)	2
-12A	US-2-14-160-6-B	.							SOCKET (18677)	5
-13	SN5474N	.							INTEGRATED CIRCUIT (01295)	2
-14	1N702	.							DIODE (01295)	5
-15	1-4-5P18K	.							REISTOR	7
-16	2N4402	.							TRANSISTOR (04713)	8
-17	H3783	.							RESISTOR (98869)	1
-18	H3784	.							RESISTOR (98869)	1
-19	H3785	.							RESISTOR (98869)	1
-20	H3736	.							RESISTOR (98869)	1
-21	H3786	.							RESISTOR (98869)	1
-22	BH4446	.							RESISTOR (88869)	1
-23	BH10666-8	.							COMPENSATOR (98869)	1
-24	NMP-CHAL-M	.							CONNECTOR (04157)	1
-25	R-1003-A-2	.							EJECTOR (53507)	2
-26	RC07GF226K	.							RESISTOR	6
-27	H3697	.							RESISTOR (98869)	1
-28	H3674	.							RESISTOR (98869)	1
-29	1-4-5P470E	.							RESISTOR (80031)	3
-30	1-4-5P47K	.							RESISTOR (80031)	2
-31	430	.							TEST POINT (83330)	3
-32	3800P-203	.							RESISTOR, Variable (02660)	2
-33	3800P-502	.							RESISTOR, Variable (02669)	2
-34	533-00HS50K	.							RESISTOR, Variable (94271)	1
-35	150D606X0006B2	.							CAPACITOR (56289)	2
-36	RN55D7870F	.							RESISTOR	1
-37	1-4-5P27K	.							RESISTOR (80031)	7
-38	C4600	.							AMPLIFIER (98869)	1
-39	BH12068-1	.							CLIP (98869)	1
-40	1-331892-0	.							SOCKET (00779)	8
-41	BH5007	.							RESISTOR (98869)	2
-42	1-4-5P47E	.							RESISTOR (80031)	2
-43	112A1C104	.							CAPACITOR (14752)	1
-44	CK05CW471K	.							CAPACITOR	1
-45	533-00HS250K	.							RESISTOR, Variable (94271)	1
-46	SN52741L	.							INTEGRATED CIRCUIT (01259)	2
-47	8-ICS	.							SOCKET (71785)	3

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-34-48	3800P-202	.							RESISTOR, Variable (02669)	1
-49	H3828	.							RESISTOR (98869)	1
-50	DD-500	.							CAPACITOR (71590)	2
-51	1-4-5P10K	.							RESISTOR (80031)	1
-52	1N914	.							DIODE (04713)	2
-53	LM211H	.							INTEGRATED CIRCUIT (12040)	1
-54	DD-100	.							CAPACITOR (71590)	1
-55	RN55D1003F	.							RESISTOR	1
-56	625C1C105K	.							CAPACITOR (14752)	1
-57	5GAS-S10	.							CAPACITOR (56289)	2
-57A	CK05BX221K	.							CAPACITOR	1
-58	CK05BX220K	.							CAPACITOR	3
-59	H3524	.							RESISTOR (98869)	1
-60	2N4861	.							TRANSISTOR (01295)	5
-61	SN5476N	.							INTEGRATED CIRCUIT (01295)	1
-62	US-2-16-160-G-B	.							SOCKET (18677)	1
-63	SN5402N	.							INTEGRATED CIRCUIT (01295)	1
-64	CS13BF226K	.							CAPACITOR	3
-65	3711-2-2	.							CHOKE (71279)	2
-66	2N4852	.							TRANSISTOR (04713)	1
-67	H3378	.							RESISTOR (98869)	1
-68	H3627	.							RESISTOR (98869)	1
-69	H3690	.							RESISTOR (98869)	1
-70	BH15715	.							PRINTED CIRCUIT BOARD, Machined (98869)	1




Figure 4-35. BH15717-1 Tachometer Circuit Board Assembly.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-35	BH15717-1	TACHOMETER CIRCUIT BOARD ASSEMBLY (See figure FO-7 for NHA.) (98869)							REF	
-1	1-4-5P2K2	.	RESISTOR (80031)	RESISTOR (80031)	10
-2	1-4-5P4K7	.	RESISTOR (80031)	RESISTOR (80031)	5
-3	ACF-50-.22-10	.	CAPACITOR (31589)	CAPACITOR (31589)	1
-4	CK05CW102K	.	CAPACITOR	CAPACITOR	1
-5	1-4-5P47E	.	RESISTOR (80031)	RESISTOR (80031)	2
-6	H3378	.	RESISTOR (98869)	RESISTOR (98869)	1
-7	H3447	.	RESISTOR (98869)	RESISTOR (98869)	1
-8	H3627	.	RESISTOR (98869)	RESISTOR (98869)	3
-9	2N4852	.	TRANSISTOR (04713)	TRANSISTOR (04713)	1
-10	RN55D7870F	.	RESISTOR	RESISTOR	2
-11	C933	.	DIODE (98869)	DIODE (98869)	2
-12	CS13BF226K	.	CAPACITOR	CAPACITOR	3
-13	1-4-5P470E	.	RESISTOR (80031)	RESISTOR (80031)	4
-14	CS13BB187K	.	CAPACITOR	CAPACITOR	2
-15	H3564	.	RESISTOR (98869)	RESISTOR (98869)	1
-16	1-4-5P100E	.	RESISTOR (80031)	RESISTOR (80031)	2
-17	RN60D4643F	.	RESISTOR	RESISTOR	2
-18	624C1C105K	.	CAPACITOR (14752)	CAPACITOR (14752)	2
-19	TIL111	.	OPTICAL COUPLER (01295)	OPTICAL COUPLER (01295)	1
-20	H3485	.	RESISTOR (98869)	RESISTOR (98869)	3
-21	112A1C104	.	CAPACITOR (14752)	CAPACITOR (14752)	1
-22	RN55D1003F	.	RESISTOR	RESISTOR	4
-29	1N914	.	DIODE (04713)	DIODE (04713)	5
-24	2N4402	.	TRANSISTOR (04713)	TRANSISTOR (04713)	3
-25	SN52741L	.	INTEGRATED CIRCUIT (01295)	INTEGRATED CIRCUIT (01295)	5
-26	8-ICS	.	SOCKET (71785)	SOCKET (71785)	6
-27	1-4-5P330K	.	RESISTOR (80031)	RESISTOR (80031)	1
-28	CK05CW102K	.	CAPACITOR	CAPACITOR	3
-29	1-4-5P10K	.	RESISTOR (80031)	RESISTOR (80031)	3
-30	R-1003-A-2	.	EJECTOR (53507)	EJECTOR (53507)	2
-31	3800P-203	.	RESISTOR, Variable (02669)	RESISTOR, Variable (02669)	2
-32	430	.	TEST POINT (83339)	TEST POINT (83339)	6
-33	2N4352	.	TRANSISTOR (04713)	TRANSISTOR (04713)	1
-34	2N4351	.	TRANSISTOR (04713)	TRANSISTOR (04713)	1
-35	H-1022	.	CAPACITOR (02799)	CAPACITOR (02799)	1
-36	C4600	.	INTEGRATED CIRCUIT (98869)	INTEGRATED CIRCUIT (98869)	1
-36A	BH12068-1	.	RETAINER (98869)	RETAINER (98869)	1
-363	1-331892-0	.	SOCKET (00779)	SOCKET (00779)	8
-37	533-00HS100K	.	RESISTOR, Variable (94271)	RESISTOR, Variable (94271)	1
-38	3800P-502	.	RESISTOR, Variable (02669)	RESISTOR, Variable (02669)	3
-39	533-00HS250K	.	RESISTOR, Variable (94271)	RESISTOR, Variable (94271)	1
-40	BH4446	.	RESISTOR (98869)	RESISTOR (98869)	1
-41	H3470	.	RESISTOR (98869)	RESISTOR (98869)	1
-42	BH3274	.	RESISTOR (98869)	RESISTOR (98869)	2
-43	3800P-103	.	RESISTOR, Variable (02669)	RESISTOR, Variable (02669)	1
-44	2N4861	.	TRANSISTOR (01295)	TRANSISTOR (01295)	6
-46	3800P-202	.	RESISTOR, Variable (02669)	RESISTOR, Variable (02669)	1
-46	CK05BX220K	.	CAPACITOR	CAPACITOR	4
-47	DD-500	.	CAPACITOR (71590)	CAPACITOR (71590)	2

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-35-48	C1904	.							TRANSISTOR (98869)	3
-49	1-4-5P27K	.							RESISTOR (80031)	8
-50	1-4-5P47K	.							RESISTOR (80031)	1
-51	LM211H	.							INTEGRATED CIRCUIT (12040)	1
-52	DD-100	.							CAPACITOR (71590)	1
-53	5GAS-S10	.							CAPACITOR (56289)	2
-54	RC07GF226K	.							RESISTOR	6
-55	H3524	.							RESISTOR (98869)	1
-56	SN5474N	.							INTEGRATED CIRCUIT (01295)	1
-57	US-2-14-160-G-B	.							SOCKET (18677)	3
-58	H3515	.							RESISTOR (98869)	1
-59	SN5402N	.							INTEGRATED CIRCUIT (01295)	1
-60	SN5476N	.							INTEGRATED CIRCUIT (01295)	1
-61	US-2-16-160-G-B	.							SOCKET (18677)	1
-62	SN5400N	.							INTEGRATED CIRCUIT (01295)	1
-63	3711-2-2	.							CHOKE (71279)	2
-64	H3588	.							RESISTOR (98869)	1
-65	H3582	.							RESISTOR (98869)	1
-66	BH15717	.							PRINTED CIRCUIT BOARD, Machined (88869)	1




Figure 4-36. BH16365-1 Calibrator Circuit Board Assembly.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-36	BH16365-1	CALIBRATOR CIRCUIT BOARD ASSEMBLY (See figure FO-7 for NHA.) (98869)								REF
-1	3711-2-2	CHOKE (71279)	2
-2	CK05BX270K	CAPACITOR	2
-3	CS13BF226K	CAPACITOR	4
-4	LM101A	INTEGRATED CIRCUIT (07263)	1
-5	8-ICS	SOCKET (71785)	4
-6	RN55D2002F	RESISTOR	1
-7	SN52741L	INTEGRATED CIRCUIT (01295)	3
-8	1-4-5P1M	RESISTOR (80031)	1
-9	CK05CW102K	CAPACITOR	1
-10	1-4-5P150K	RESISTOR (80031)	1
-11	1-4-5P10K	RESISTOR (80031)	1
-12	RN55D7870F	RESISTOR	1
-13	C933	DIODE (98869)	2
-14	CS13BF685M	CAPACITOR	1
-15	625C1C105K	CAPACITOR (14752)	2
-16	1N914	DIODE (04713)	4
-17	BH10666-8	COMPENSATOR (98869)	1
-18	NMP-CHAL-F	CONNECTOR (04157)	1
-19	H3674	RESISTOR (98869)	1
-20	3800P-502	RESISTOR (02669)	1
-21	430	TEST POINT (83339)	3
-22	450-3422-01-03	SOCKET (71279)	2
-23	461-2871-01-03-12	PLUG (71279)	1
-24	BH5070	RESISTOR (98869)	1
-25	BH5058	RESISTOR (98869)	1
-26	3311P-100	RESISTOR (02660)	1
-27	BH3274	RESISTOR (98869)	1
-28	BH4098	RESISTOR (98869)	1
-29	3800P-202	RESISTOR (02669)	2
-30	H3512	RESISTOR (98869)	1
-31	C389	CAPACITOR (98869)	1
-32	CK4023AE	INTEGRATED CIRCUIT (86684)	1
-33	US=2-14-160-G-B	SOCKET (18677)	5
-34	CK06BX103K	CAPACITOR	2
-35	CD4013AE	INTEGRATED CIRCUIT (86684)	1
-36	1-4-5P15K	RESISTOR (80031)	2
-37	R-1003-A-2	EJECTOR (53507)	2
-38	CR-45/U	CRYSTAL	1
-39	8000-AG9	SOCKET (91506)	1
-40	1N4736A	DIODE (04713)	2
-41	VC3D-350	RESISTOR (12697)	1
-42	1N5059	DIODE (03508)	2
-43	TTX200MFD35VDC	CAPACITOR (37942)	1
-44	1-4-5P47K	RESISTOR (80031)	1
-45	CD4001AE	INTEGRATED CIRCUIT (86684)	1
-46	RC07GF106K	RESISTOR	1
-47	CD4024AE	INTEGRATED CIRCUIT (86684)	2
-48	RN55D6650F	RESISTOR	1

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-36-49	BH16365								PRINTED CIRCUIT BOARD, Machined (98869).....	1
FO-8	BH15194A-4								PROBE CONTROLLER ASSEMBLY (See figure 4-29 for NHA.) (98869).....	
	BH15802	.							PROBE CONTROLLER HARNESS (98869).....	1
-1	MS51957-17	.							SCREW (AP).....	6
-2	BH15713	.	.						TRANSFORMER (See items 4 & 5, figure 4-29 for attaching parts) (98869).....	1
-3	C406-021	.	.						CONNECTOR (06928).....	2
-4	C404-010	.	.						CONNECTOR (06928).....	1
-5	34567	.	.						TERMINAL LUG (04618).....	4
-6	35316	.	.						TERMINAL LUG (Not shown) (04618).....	2
-7	SS-70BL-2 BLK	.							KNOB (21694).....	2
-8	BH15801-1	.							PROBE CONTROL-FUNCTION SWITCH BOARD ASSEMBLY (See figure 4-37 for breakdown.) (98869).....	1
-9	N-9030-1/4	.							SEAL NUT (AP) (97539).....	2
-10	12C1087	.							WASHER, Non-turn (AP) (01073).....	2
-11	MS51957-5	.							SCREW (AP).....	2
-12	SS-7013L-2 BLK	.							KNOB (21604).....	2
-13	BH16367-3	.							RESISTANCE-INSULATION BOARD ASSEMBLY (See figure 4-38 for breakdown.) (98869).....	1
-14	N-9030-1/4	.							SEAL NUT (AP) (97539).....	2
-15	12C1087	.							WASHER, Non-turn (AP) (01073).....	2
-16	250-1471-500	.							LAMP CAP (72619).....	1
-17	507-5824-0747-600	.							LAMP (72619).....	1
-18	250-8758-33-504	.							LAMPHOLDER (72619).....	1
-19	SSN-70-2 BLK	.							KNOB (26104).....	1
-20	3540-S-1-203	.							POTENTIOMETER (80294).....	1
-21	N-9030-1/4	.							SEAL NUT (AP) (97539).....	1
-22	MS35059-23	.							SWITCH.....	1
-23	N-9030-B	.							SEAL NUT (AP) (97539).....	1
-24	SSN-70-2 BLK	.							KNOB (21694).....	1
-25	3540-S-1-101	.							POTENTIOMETER (80294).....	1
-26	N-9030-1/4	.							SEAL NUT (AP) (97539).....	1
-27	1N5059	.							DIODE (03508).....	1
-28	KR7826	.							RELAY (77342).....	1
-29	MS20365-6342A	.							NUT (AP).....	3
	1415-6	.							TERMINAL LUG (83339).....	1
-30	PDA-20	.							CIRCUIT BREAKER (01295).....	1
-31	MS51957-47	.							SCREW (AP).....	2
-32	BH15180	.							BRACKET (98869).....	1
-33	SEELSKREW/R/ 6-32x112" MS20365-632A	.							SCREW, Seal (AP) (13074).....	2
		.							NUT (AP).....	2
-34	BH2825	.							METER (98869).....	1

Figure Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
FO-8-35	SEELSKREW/R/ 4-40x1/2"	.							SCREW, Seal (AP) (13074)	3
-36	BH581-1	.							GASKET (98869)	1
-37	BH6510	.							METER (98869)	1
-38	SEELSKREW/R/ 4-40x1/2"	.							SCREW, Seal (AP) (13074)	3
-39	BH581-1	.							GASKET (98869)	1
-40	BH9020P	.							CONNECTOR (98869)	1
-41	MS25043-12C	.							DUST CAP	1
-42	SEELSKREW/R/ 4-40x1/2"	.							SCREW, Seal (AP) (13074)	4
	MS20365-440A	.							NUT (AP)	4
-43	10-36675-12	.							GASKET (77829)	1
-44	BH9039S	.							CONNECTOR (98869)	1
-45	MS25043-20C	.							DUST CAP	1
-46	SEELSKREW/R/ 4-40x1/2"	.							SCREW, Seal (AP) (13074)	4
	MS20365-440A	.							NUT (AP)	4
-47	10-36675-20	.							GASKET (78820)	1
-48	BH9030S	.							CONNECTOR (98869)	1
-49	MS25043-14C 4-40x1/2"	.							DUST CAP	1
	MS20365-440A	.							NUT (AP)	4
-51	10-36675-14	.							GASKET (77829)	1
-52	KAW-20	.							FUSE (71400)	1
-53	FHN23W	.							FUSE HOLDER (71400)	1
-54	SEELSKREW/R/ 6-32x1/2"	.							SCREW, Seal (AP) (13074)	2
-55	BH9033P	.							CONNECTOR (98869)	1
-56	MS25043-16C	.							DUST CAP	1
-57	SEELSKREW/R/ 4-40x1/2"	.							SCREW, Seal (AP) (13074)	4
	MS20365-440A	.							NUT (AP)	4
-58	10-36675-16	.							GASKET (77829)	1
-59	BH9385S	.							CONNECTOR (98869)	1
-60	10-101960-143	.							DUST CAP (77820)	1
-61	SEELSKREW/R/ 4-40X1/2"	.							SCREW, Seal (AP) (13074)	4
	MS20365-440A	.							NUT (AP)	4
-62	10-36675-14	.							GASKET (78820)	1
-63	BH799	.							STOP ARM SUPPORT (98869)	1
-64	MS51960-63	.							SCREW (AP)	2
-65	C45H	.							RECTIFIER (Not shown) (See figure FO-9 for physical location (03508)	2
-66	BH15189A-2	.							DECK, Marked (98869)	1
4-37	BH15801-1	.							PROBE CONTROL-FUNCTION SWITCH CIR- CUIT BOARD ASSEMBLY (See figure FO-8 for NHA.) (98869)	REF




Figure 4-37. BH15801-1 Probe Control-Function Switch Circuit Board Assembly.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-37-1	1N914	.							DIODE (04713)	4
-2	1-4-5P39K	.							RESISTOR (80031)	4
-3	1-4-5P2K2	.							RESISTOR (80031)	1
-4	1N702	.							DIODE (01295)	1
-5	SN52741L	.							INTEGRATED CIRCUIT (01295)	1
-6	8-ICS	.							SOCKET (71785)	2
-7	ACF-50-2.0-10	.							CAPACITOR (31589)	1
-8	TZ-17XT	.							TRANSFORMER (81095)	1
-9	1-4-5P3K3	.							RESISTOR (80031)	1
-10	CK05BX103K	.							CAPACITOR	2
-11	2N6336	.							RECTIFIER (01295)	2
-12	5203-8	.							INSULATOR (86928)	2
-13	1-4-5P10K	.							RESISTOR (80031)	3
-14	DD-102	.							CAPACITOR (71590)	1
-15	637B1D563K	.							CAPACITOR (14752)	1
-16	VC3D-1K	.							RESISTOR (12697)	1
-17	1N5059	.							DIODE (03508)	2
-18	1-4-5P15K	.							RESISTOR (80031)	1
-19	1N4761A	.							DIODE (04713)	1
-20	1N4005	.							DIODE (04713)	2
-21	RC20GF331K	.							RESISTOR	1
-22	TTX200MFD35VDC	.							CAPACITOR (37942)	1
-23	IN4746A	.							DIODE (04713)	1
-24	CS13BD226K	.							CAPACITOR	1
-25	RN55D10C1F	.							RESISTOR	1
-26	C933	.							DIODE (98869)	1
-27	1N4736A	.							DIODE (04713)	1
-28	CK06BX223K	.							CAPACITOR	2
-29	2N3646	.							TRANSISTOR (07263)	2
-30	71BY23199-1-9N	.							SWITCH (81073)	1
-31	CS13BB187K	.							CAPACITOR	1
-32	71BY2300-1-7N	.							SWITCH (81073)	1
-33	CS13BF105M	.							CAPACITOR	1
-34	H3440	.							RESISTOR (98869)	1
-36	RC07GF106K	.							RESISTOR	1
-36	LM725H	.							INTEGRATED CIRCUIT (12040)	1
-37	H3378	.							RESISTOR (98869)	1
-38	BH4527	.							RESISTOR (98869)	1
-39	H3617	.							RESISTOR (98869)	1
-40	3800P-203	.							RESISTOR, Variable (02660)	2
-41	3800P-502	.							RESISTOR, Variable (02660)	1
-42	BH10666-8	.							COMPENSATOR (98869)	1
-43	H3674	.							RESISTOR (98869)	1
-44	1-4-5P4K7	.							RESISTOR (80(80031)	1
-47	1-4-5P220K	.							RESISTOR (80031)	2
-48	2754-2	.							RESISTOR (80031)	1
-49	2N4852	.							TEST POINT (71279)	2
-50	ACF-50-.22-10	.							CAPACITOR (31589)	1
-51	BH15801	.							PRINTED CIRCUIT BOARD, Machined (98869)	1




Figure 4-38. BH16367-3 Resistance-Insulation Circuit Board Assembly.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-38	BH16367-3	RESISTANCE-INSULATION CIRCUIT BOARD ASSEMBLY (See figure FO-8 for NHA.)								
									(98869).....	REF
-1	5XM225	.							RESISTOR (63743).....	2
-2	H3395	.							RESISTOR (98869).....	1
-3	H3522	.							RESISTOR (98869).....	1
-4	H3394	.							RESISTOR (98869).....	1
-5	224P-1-101	.							RESISTOR, Variable (80294).....	1
-6	224P-1-501	.							RESISTOR, Variable (80294).....	1
-7	535-00HS10	.							RESISTOR, Variable (94271).....	1
-8	3811P-500	.							RESISTOR, Variable (94271).....	1
-9	RS-1A, 7.00, 1W	.							RESISTOR (91637).....	2
-10	RS-1A, 120, 1W	.							RESISTOR (91637).....	1
-11	BH1771	.							RESISTOR (98869).....	1
-12	BH1773	.							RESISTOR (98869).....	1
-13	71BY23196-1-2N	.							SWITCH (81073).....	1
-14	RS-1A, 220, 1W	.							RESISTOR (91637).....	1
-15	RS-1A, 350, 1W	.							RESISTOR (91637).....	1
-16	RS-1A, 300, 1W	.							RESISTOR (91637).....	1
-17	RS-1A, 450, 1W	.							RESISTOR (91637).....	1
-18	71BY23213-1-6N	.							SWITCH (81073).....	1
-19	BH275	.							RESISTOR (98869).....	1
-20	H3493	.							RESISTOR (98869).....	1
-21	BH274	.							RESISTOR (98869).....	1
-22	A402-010	.							CONNECTOR (06928).....	1
-23	MS51957-5	.							SCREW (AP).....	2
	MS35333-69	.							SCREW (AP).....	2
-24	RN55D6811F	.							RESISTOR.....	1
-25	RN55C1000F	.							RESISTOR.....	1
-26	RS-1A, 150, 1W	.							RESISTOR (91637).....	1
-27	BH16367	.							PRINTED CIRCUIT BOARD, machined (98869).....	1

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
FO-9	BH15835-2	INSTRUMENT CASE ASSEMBLY (See figure 4-29 for NHA.) (98869)								REF
-1	BH14548A-1	LID (98869)	1
-2	MS20253-2-1812	HINGE PIN (AP)	1
-3	123002	CLIP (75915)	2
-4	COML	SCREW, Seal, machine, cross recess, 4-40 x 5/16 inch 1 (AP) (13861)	2
	MS20365-440A	NUT (AP)	2
-5	BH15827	SPARE FUSEHOLDER (98869)	1
-6	KAW-20	FUSE (71400)	2
-7	COML	WING NUT, 4-40 (AP)	2
	MS51957-21	SCREW (AP)	2
	MS20365-440A	NUT (AP)	2
-8	BH15826	HEAT SINK (98869)	2
-9	BH17427	MICA SHEET (98869)	4
-10	COML	SCREW, Seal, machine, cross recess, 8-32 x 1 inch 1 (AP) (13861)	4
	MS20365-832A	NUT (AP)	4
	2163	WASHER (AP) (83330)	4
-11	BH15524	MOLD STRIP (98869)	2
-12	BH15525	BUMPER STRIP (98869)	2
-13	COML	SCREW, Machine, pan hd, cross recess, 4-40 x 9/16 inch 1 (AP) (13861)	8
	MS20365-440A	NUT (AP)	8
-14	21	BUMPER (70485)	4
-15	COML	SCREW, Seal, machine, cross recess, 4-40 x 3/4 inch 1 (AP) (13861)	4
	MS20365-440A	NUT (AP)	4
-16	R-116	BUMPER (78046)	6
-17	COML	SCREW, Seal, machine, cross recess, 4-40 x 3/8 inch 1 (AP) (13861)	6
	MS20365-440A	NUT (AP)	6
	MS27183-4	WASHER (AP)	6
-18	BH15197	GASKET (98869)	1
-19	BH15834	CASE (98869)	1




Figure 4-39. H122 Accessory Case.

Figure & Index Number	Part Number	1	2	3	4	5	6	7	Description	Units Per Assy
4-39	H122	ACCESSORY CASE (See figure 4-29 for NHA.)								
		(98869).....								REF
-1	BH585	.							HANDLE (98869).....	1
-2	MS35426-15	.							WING NUT (AP).....	2
-3	MS35308-341	.							BOLT (AP).....	2
-4	BH727	.							PIVOT SOCKET (98869).....	2
-5	BH796	.							STOP ARM ASSEMBLY (98869).....	1
-6	BH723	.							SPACER (98869).....	1
-7	BH437	.							STOP ARM SUPPORT (98869).....	1
-8	MS51958-61	.							SCREW (AP).....	1
	MS35333-73	.							WASHER (AP).....	1
-9	BH834-1	.							POST (98869).....	1
-10	MS51957-63	.							SCREW (AP).....	8
	MS20365D-1032A	.							NUT (AP).....	8
-11	BH834-2	.							PAD (98869).....	1
-12	MS51957-27	.							SCREW (AP).....	4
	MS35333-71	.							WASHER (AP).....	4
-13	BH3506	.							WHEEL (98869).....	2
-14	5100-62	.							RETAINING RING (AP) (79136).....	2
-15	BH835	.							WHEEL MOUNT (98869).....	2
-16	MS51957-65	.							SCREW (AP).....	8
	MS20365D-1032A	.							NUT (AP).....	8
-17	BH6554	.							PROBE RETAINER (98869).....	1
-18	BH6551	.							PROBE RACK (98869).....	1

APPENDIX A

REFERENCES

A-1. Dictionaries of Terms and Abbreviations.

H4-1 and H4-2	Federal Supply Code for Manufacturers
MIL-STD-12C	Abbreviations for Use on Drawings, Specifications, Standards and in Technical Documents

A-2. Publication Indexes.

AR 750-1	Army Material Maintenance Concepts and Policies
----------	---

DA PAM 738-751	Functional Users Manual for the Army Maintenance Management System-Aviation (TAMMS-A)
----------------	---

A-3. Technical Manuals.

TM 9-213	Painting Instructions for Field Use
----------	-------------------------------------

TM 55-744-1-4	Destruction of Aviation Equipment to Prevent Enemy Use
---------------	--

TM 55-1500-204-25/1	General Aircraft Maintenance Manual
---------------------	-------------------------------------

TM 55-1500-323-25	Organizational, DS and GS and Depot Maintenance Manual Installation Practices for Aircraft Electric and Electronic Wiring
-------------------	---

APPENDIX B

MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

B-1. Maintenance Allocation Chart.

a. This Maintenance Allocation Chart (MAC) assigns maintenance functions in accordance with the Three Levels of Maintenance concept for army aircraft. These maintenance levels: Aviation Unit Maintenance (AVUM), Aviation Intermediate Maintenance (AVIM) and Depot Maintenance are depicted on the MAC as:

AVUM which corresponds to the O code in the Repair Parts and Special Tools List (RPSTL).

AVIM which corresponds to the F code in the Repair Parts and Special Tools List (RPSTL).

DEPOT which corresponds to the D code in the Repair Parts and Special Tools List (RPSTL).

b. The maintenance to be performed below depot and in the field is described as follows:

(1) Aviation Unit Maintenance (AVUM). AVUM activities will be staffed and equipped to perform high frequency "On-Equipment" maintenance tasks required to retain or return equipment to a serviceable condition. The maintenance capability of the AVUM will be governed by the MAC and limited by the amount and complexity of support equipment, facilities required, and number of spaces and critical skills available. The range and quantity of authorized spare modules/components will be consistent with the mobility requirements dictated by the air mobility concept. (Assignment of maintenance tasks to divisional company size aviation units will consider the overall maintenance capability of the division, the requirement to conserve personnel and equipment resources and air mobility requirements).

(a) Company Size Aviation Units. Perform those tasks which consist primarily of preventive maintenance and maintenance repair and replacement functions associated with sustaining a high level of equipment operational readiness. Perform maintenance inspections and servicing to include daily, intermediate, periodic and special inspections as authorized by the MAC or higher headquarters. Identify the cause of equipment/system malfunctions using applicable technical manual troubleshooting instructions, Built-In Test Equipment (BITE), installed instruments, or easy

to use Test Measurement and Diagnostic Equipment (TMDE). Replace worn or damaged modules/components which do not require complex adjustments or system alignment and which can be removed/installed with available skills, tools and equipment. Perform operational and continuity checks and make minor repairs. Perform servicing, functional adjustments, and minor repair/replacement. Evacuate unserviceable modules/components and end items beyond the repair capability of AVUM to the supporting AVIM.

(b) Less than Company Size Aviation Units. Aviation elements organic to brigade, group, battalion headquarters and detachment size units are normally small and have less than ten aircraft assigned. Maintenance tasks performed by the aircraft crew chief or assigned aircraft repairman will normally be limited to preventive maintenance, inspections, servicing, spot painting, stop drilling, minor adjustments, module/component fault diagnosis and replacement of selected modules/components. Repair functions will normally be accomplished by the supporting AVIM unit.

(2) Aviation Intermediate Maintenance (AVIM). AVIM provides mobile, responsive "One Stop" maintenance support. (Maintenance functions which are not conducive to sustaining air mobility will be assigned to depot maintenance). Performs all maintenance functions authorized to be done at AVUM. Repair of equipment for return to user will emphasize support or operational readiness requirements. Authorized maintenance includes replacement and repair of modules/components and end items which can be accomplished efficiently with available skills, tools, and equipment. Establishes the Direct Exchange (DX) program for AVUM units by repairing selected items for return to stock when such repairs cannot be accomplished at the AVUM level. Inspects, troubleshoots, tests, diagnoses, repairs, adjusts, calibrates, and aligns system modules/components. Module/component disassembly and repair will support the DX program and will normally be limited to tasks requiring cleaning and the replacement of seals, fittings and items of common hardware. Unserviceable repairable modules/components and end items which are beyond the capability of AVIM to

repair will be evacuated to Depot Maintenance. This level will perform special inspections which exceed AVUM capability. Provides quick response maintenance support, on-the-job-training, and technical assistance through the use of mobile maintenance contact teams. Maintains authorized operational readiness float. Provides collections and classification services for serviceable/unserviceable material. Operates a cannibalization activity in accordance with AR 750-50. (The aircraft maintenance company within the maintenance battalion of a division will perform AVUM functions consistent with air mobility requirements and conservation of personnel and equipment resources. Additional intermediate maintenance support will be provided by the supporting non-divisional AVIM unit).

B-2. Use of the Maintenance Allocation Chart.

a. The MAC assigns maintenance functions to the lowest level of maintenance based on past experience and the following consideration:

(1) Skills available.

(2) Time required

(3) Tools and test equipment required and/or available.

b. Only the lowest level of maintenance authorized to perform a maintenance function is indicated. If the lowest level of maintenance cannot perform all tasks of any single maintenance function (e.g., test, repair), then the higher maintenance level(s) that can accomplish additional tasks will also be indicated.

c. A maintenance function assigned to a maintenance level will automatically be authorized to be performed at any higher maintenance level.

d. A maintenance function that cannot be performed at the assigned level of maintenance for any reason may be evacuated to the next higher maintenance organization. Higher maintenance levels will perform the maintenance functions of lower maintenance levels when required or directed by the appropriate commander.

e. The assignment of a maintenance function will not be construed as authorization to carry the associated repair parts in stock. Authority to requisition, stock, or otherwise secure necessary repair parts will be as specified in the repair parts and special tools list appendix.

f. Normally there will be no deviation from the

assigned level of maintenance. In cases of operational necessity, maintenance functions assigned to a maintenance level may, on a one-time basis and at the request of the lower maintenance level, be specifically authorized by the maintenance officer of the level of maintenance to which the function is assigned. The special tools, equipment, etc. required by the lower level of maintenance to perform this function will be furnished by the maintenance level to which the function is assigned. This transfer of a maintenance function to a lower maintenance level does not relieve the higher maintenance level of the responsibility of the function. The higher level of maintenance has the authority to determine:

(1) If the lower level is capable of performing the work,

(2) If the lower level will require assistance or technical supervision and on-site inspection.

(3) If the authorization will be granted.

g. Organizational through depot maintenance of the US Army Electronics Command equipment will be performed by designated US Army Electronics Command personnel.

h. Changes to the MAC will be based on continuing evaluation and analysis by responsible technical personnel and on reports received from field activities.

B-3. Definitions.

a. Inspect. To determine serviceability of an item by comparing its physical, mechanical and electrical characteristics with established standards.

b. Test. To verify serviceability and detect incipient failure by measuring the mechanical or electrical characteristics of an item and comparing those characteristics with prescribed standards.

c. Service. To clean, to preserve, to charge, and to add fuel, lubricants, cooling agents and air.

d. Adjust. To rectify to the extent necessary to bring into proper operating range.

e. A line. To adjust specified variable elements of an item to bring to optimum performance.

f. Calibrate. To determine the corrections to be made in the readings of instruments or test equipment used in precise measurement. Consists of the comparison of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument or test equipment being compared with the certified standard.

g. Install. To set up for use in an operational environment such as an emplacement, site or vehicle.

h. Replace. To replace unserviceable items with serviceable assemblies, subassemblies or parts.

i. Repair. To restore an item to serviceable condition through correction of a specific failure or unserviceable condition. This includes, but is not limited to, inspection, cleaning, preserving, adjusting, replacing, welding, riveting, and strengthening.

j. Overhaul. To restore an item to a completely serviceable condition as prescribed by maintenance serviceability standards prepared and published for the specific item to be overhauled.

k. Rebuild. To restore an item to a standard as nearly as possible to the original or new condition in appearance, performance, and life expectancy. This is accomplished through the maintenance technique of complete disassembly of the item, inspection of all parts or components, repair or replacement of worn or unserviceable elements (items) using original manufacturing tolerances and specifications, and subsequent reassembly of the item.

B-4. Functional Groups. Standard functional groupings are not considered feasible for aviation ground support equipment due to variation and

complexity. Therefore, variations to functional groupings may occur.

B-5. Maintenance Categories and Work Times.

The maintenance categories (levels) AVUM, AVIM, and DEPOT are listed on the Maintenance Allocation Chart with individual columns that indicate the work times for maintenance functions at each maintenance level. Work time presentations such as 0.1 indicate the average time it requires a maintenance level to perform a specified maintenance function. If a work time has not been established, the columnar presentation shall indicate “_.”. Maintenance levels higher than the level of maintenance indicated are authorized to perform the indicated function.

B-6. Tools and Test Equipment (Section III).

Common tool sets (not individual tools), special tools, test and support equipment required to perform maintenance functions are listed alphabetically with a reference number to permit cross-referencing to column 5 in the MAC. In addition, the maintenance category authorized to use the device is listed along with the item National Stock Number (NSN) and, if applicable, the tool number to aid in identifying the tool/device.

Section II. MAINTENANCE ALLOCATION CHART

NOMENCLATURE OF END ITEMS

Tester, Exhaust Gas Temperature

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
			00	Exhaust Gas Temperature			
01	Case Accessory, Wheels, Wheel Mount, Probe Rack, Stops and Supports	Inspect Replace Repair Service	.3	1.5 1.		106 115	A
02 0201	Deck Assembly Power On and Galvo Lamps	Inspect Repair Replace Test Adjust	.2	.5		106	C
03	Switches, Circuit Breakers and Relays	Inspect Replace	.2	1.		106	
04	Cables, Connectors and Adapters	Inspect Repair Replace	.2	1.2 .5		106 109	B
05 0501 0502 0503 0504	Circuit Boards Calibration Tachometer Temperature Display	Inspect Replace Repair Test Calibrate		.3 1. .3	3. .2	106 109	B C
06	Trimmer Assembly	Inspect Service Test Repair Replace Test Calibrate		.2 .1 .1 .3 .5 .2 .3		106 109	B C
07	Insulation Check Meter	Replace Test		.5 .3		106	C
08	Probe Assembly	Repair Replace Test		.6 .2 .3		109 106	B C

REMARKS
TESTER, EXHAUST GAS TEMPERATURE

Reference Code	Remarks
A	Use Available Motor Pool Tools
B	Use Available Equipment from Shop Set
C	Operational Test On Unit

Section III. TOOL AND TEST EQUIPMENT REQUIREMENT

REF. NO.	MAINT CAT.	NOMENCLATURE	NATIONAL STOCK NUMBER	TOOL NO.
100	0	Tool Set, AVUM, Set No. 1	4920-00-159-8727	SC492099CLA90
101	0	Tool Set, AVUM, Set No. 2	4920-00-567-0476	SC492099CLA92
102	0	Tool Kit, Acft Mech Gen	5180-00-323-4692	SC518099CLA01
103	0	Tool Kit, Arfrm Rpmn	5180-00-323-4876	SC518099CLA02
104	0	Tool Kit, Hyd Rpmn	5180-00-323-4891	SC518099CLA03
105	0	Tool Kit, Instr Rpmn	5180-00-323-4913	SC518099CLA05
106	0	Tool Kit, Elec Rpmn	5180-00-323-4915	SC518099CLA06
107	0	Tool Kit, Eng Rpmn	5180-00-323-4944	SC518099CAL07
108	0	Tool Kit, Pwr Trn	5180-00-003-5267	SC518099CLA13
109	F	Shop Set, AVIM, Elec-Instr	4920-00-165-1453	SC492099CLA91ELAM
110	F	Shop Set, AVIM, Hyd	4920-00-165-1454	SC492099CLA91HYAM
111	F	Shop Set, AVIM, Machine Shop	4920-00-405-9279	SC492099CLA91MAAM
112	F	Shop Set, AVIM, Pwr Trn	4920-00-001-4132	SC492099CLA91PTAM
113	AVIM	Shop Set, AVIM, Rtr Shop	4920-00-405-9270	SC492099CLA91ROAM
114	AVIM	Shop Set, AVIM, Sheet Metal	4920-00-166-5505	SC492099CLA91SMAM
115	AVIM	Shop Set, AVIM, Tool Crib	4920-00-472-4183	SC492099CLA91TCAM
116	AVIM	Shop Set, AVIM, Turbine Eng	4920-00-224-3684	492099CLA91ENTAM
117	AVIM	Shop Set, AVIM, Welding	4920-00-163-5093	492099CLA91WEAM

APPENDIX C

REPAIR PARTS AND SPECIAL TOOLS LIST

SECTION I. INTRODUCTION

C-1. Scope. This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of Aviation Unit and Aviation Intermediate maintenance of the Tester, Exhaust Gas Temperature. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the source, maintenance and recoverability (SMR) codes.

C-2. General. In addition to Section I. Introduction, this Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence, Bulk materials are listed in item name sequence, Repair parts kits are listed separately in their own functional group within Section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s) figure(s).


b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance. (Not applicable)

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbered items appearing in the listing, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

C-3. Explanation of Columns (Sections II and III).

a. Item No. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



*Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use user environment in order to restore serviceability to a failed item.

(1) Source Code. The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item equipment. Explanations of source codes follows:

Code	Explanation
PA PB PC** PD PE PF PG	Stocked items; use the applicable NSN to request requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3d position of the SMR code. **NOTE: Items coded PC are subject to deterioration.
KD KF KB	Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3d position of the SMR code. The complete kit must be requisitioned and applied.

Code	Explanation
MO- (Made at org AVUM Level) MF- (Made at DS AVUM Level) MH- (Made at GS Level) ML- (Made at Specialized Repair Act (SRA)) MD- (Made at Depot)	Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION AND USABLE ON CODE (UOC) column and listed in the Bulk Material group of the repair parts list in this RPSTL. If the item is authorized to you by the 3d position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of maintenance.

Code	Explanation
AO- (Assembled by org/ AVUM Level) AF- (Assembled by DS/ AVIM Level) AH- (Assembled by GS Category) AL- (Assembled by SRA) AD- (Assembled by Depot)	Items with these codes are not to be requested requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the 3d position code of the SMR code authorizes you to replace the item, but the source code indicates the item is assembled at a higher level, order the item from the higher level of maintenance.

- XA - Do not requisition an "XA"-coded item. Order its next higher assembly. (Also, refer to the NOTE below.)
- XB - If an "XB" item is not available from salvage, order it using the FSCM and part number given.
- XC - Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.
- XD - Item is not stocked. Order an "XD"-coded item through normal supply channels using the FSCM and part number given, if no NSN is available.

NOTE: Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes, except for those source coded "XA" or those aircraft support items restricted by requirements of AR 700-42.

(2) Maintenance Code. Maintenance codes tells you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the SMR Code as follows:

(a) The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to one of the following levels of maintenance.

Code	Application/Explanation
C	-Crew or operator maintenance done within organizational or aviation unit maintenance.
O	-Organizational or aviation unit category can remove, replace, and use the item.
F	-Direct support or aviation intermediate level can remove, replace, and use the item.
H	-General support level can remove, replace, and use the item.
L	-Specialized repair activity can remove, replace, and use the item.
D	-Depot level can remove, replace, and use the item.

(b) The maintenance code entered in the fourth position tells whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i.e., perform all authorized repair functions.) (NOTE: Some limited repair may be done on the item at a lower level of maintenance, if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.) This position will contain one of the following maintenance codes.

Code	Application/Explanation
O	-Organizational or (aviation unit) is the lowest level that can do complete repair of the item.
F	-Direct support or aviation intermediate is the lowest level that can do complete repair of the item.
H	-General support is the lowest level that can do complete repair of the item.
L	-Specialized repair activity (designate the specialized repair activity) is the lowest level that can do complete repair of the item,
D	-Depot is the lowest level that can do complete repair of the item.
Z	-Nonreparable. No repair is authorized.
B	-No repair is authorized. (No parts or special tools are authorized for the maintenance of a "B" coded item), However, the item may be reconditioned by adjusting, lubricating, etc., at the user level.

(3) Recoverability Code. Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR Code as follows:

Recoverability Codes	Application/Explanation
Z	-Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in 3d position of SMR Code.
O	-Reparable item. When uneconomically repairable, condemn and dispose of the item at organizational or aviation unit level.
F	-Reparable item. When uneconomically repairable, condemn and dispose of the item at the direct support or aviation intermediate level
H	-Reparable item. When uneconomically repairable, condemn and dispose of the item at the general support level.
D	-Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal of item not authorized below depot level.
L	-Reparable item. Condemnation and disposal not authorized below specialized repair activity (SRA).
A	-Item requires special handling or condemnation procedures because of specific reasons (e.g., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals directives for specific instructions.

c. FSCM (Column 3). The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code which is used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

d. Part Number (Column (4)). Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specification standards, and inspection requirements to identify an item or range of items,

NOTE: When you use a NSN to requisition an item, the item you receive may have a different part number from the part ordered.

e. Description and Usable On Code (UOC) (Column (5)). This column includes the following information:

(1) The Federal item name and, when required, a minimum description to identify the item.

(2) The physical security classification of the item is indicated by the parenthetical entry (insert applicable physical security classification abbreviation, e.g., Phy Sec C1 (C) - Confidential, Phy Sec C1 (S) - Secret, Phy Sec C1 (T) - Top Secret).

(3) Items that are included in kits and sets are listed below the name of the kit or set.

(4) Spare repair parts that make up an assembled item are listed immediately following the assembled item line entry.

(5) Part numbers for bulk materials are referenced in this column in the line item entry for the item to be manufactured fabricated.

(6) When the item is not used with all serial numbers of the same model, the effective serial numbers are shown on the last line(s) of the description (before UOC).

(7) The usable on code, when applicable (see paragraph 5, Special information).

(8) In the Special Tools List section, the basis of issue (BOI) appears as the last line(s) in the entry for each special tool, special TM DE, and other special support equipment. When density of equipments supported exceeds density spread indicated in the basis of issue, the total authorization is increased proportionately.

(9) The statement "END OF FIGURE" appears just below the last item description in Column 5 for a given figure in both Section 11 and Section 111.

f. QTY (Column (6)). The QTY (quantity per figure column) indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that the quantity is variable and the quantity may vary from application to application.

C-4. Explanation of Columns (Sect. IV).

a. National Stock Number (NSN) Index.

(1) **Stock Number Column.** This column lists the NSN by National item identification number (NIIN) sequence. The NIIN consists of the last nine digits of the NSN (i.e., 5305-01-674-1467). When using this NIIN column to locate an item, ignore the first 4 digits of the NSN. However, the complete NSN should be used when ordering items by stock number.

(2) Fig. Column. This column lists the number of the figure where the item is identified located. The figures are in numerical order in Section II and Section III.

(3) Item Column. The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line,

b. Part Number Index. Part numbers in this index are listed by part number in ascending alphanumeric sequence (i.e., vertical arrangement of letter and number combination which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).

(1) FSCM Column. The Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

(2) Part Number Column. Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

(3) Stock Number Column. This column lists the NSN for the associated part number and manufacturer identified in the Part Number and FSCM Columns to the left.

(4) FIG. Column. This column lists the number of the figure where the item is identified located in Section II and III.

(5) Item Column. The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column,

C-5. Special Information. Use the following subparagraphs as applicable:

a. Usable On Code. The usable on code appears in the lower left corner of the Description column heading. Usable on codes are shown as "UOC: . ." in the Description Column (justified left) on the first line applicable item description/nomenclature. Uncoded items are applicable to all models.

b. Index Numbers. Items which leave the word BULK in the figure column will have an index number shown in the item number column. This index number is a cross-reference between the National Stock Number/Part Number Index and the bulk material list in Section II.

c. Associated Publications. Not Applicable.

C-6. How to Locate Repair Parts.

a. When National Stock Number or Part Number is Not Known.

(1) First. Using the table of contents, determine the assembly group or subassembly group to which the item belongs. This is necessary since figures are prepared for assembly groups and subassembly groups, and listings are divided into the same groups.

(2) Second. Find the figure covering the assembly group or subassembly group to which the item belongs.

(3) Third. Identify the item on the figure and note the item number.

(4) **Fourth.** Refer to the Repair Parts List for the figure to find the part number for the item number noted on the figure.

(5) **Fifth.** Refer to the Part Number Index to find the NSN, if assigned.

b. When National Stock Number or Part Number is Known:

(1) **First.** Using the Index of National Stock Numbers and Part Numbers, find the pertinent National Stock Number or Part Number. The NSN index is in National Item Identification Number (NIIN) sequence (see C-4a(1)). The part numbers in the Part Number index are listed in ascending alphanumeric sequence (see 4b). Both indexes cross-reference you to the illustration figure and item number of the item you are looking for.

(2) **Second.** After finding the figure and item number, verify that the item is the one you're looking for, then locate the item number in the repair parts list for the figure.




Figure 1. BH112JB-53 and BH112JB-79 Jetcal Tester

SECTION II

TM 55-4920-401-13&P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES(UOC)	(6) QTY
GROUP 01. EXHAUST GAS TESTER, ACCESSORY CASE-KIT AND COMPONENTS					
FIGURE 1. BH112JB-53 JETCAL TESTER					
	XAFDD	98869	BH112JB916	ANALYZER,ENGINE.....	1
1	PBFFF	98869	BH15195A8	.TRIMMER ASSEMBLY SEE FIGURE 11 FOR BREAKDOWN.....	1
2	PBFFD	98869	BH15194A-4	.PROBE CONTROLLER SEE FIGURE 12 FOR BREAKDOWN.....	1
3	PBFZZ	97539	SEELSKREWR6-32-1 -2	.SCREW,MACHINE.....	8
5	PBFFD	98869	BH15835-2	.CASE,CARRYING, INSTR.....	1
6	XDFZZ	98869	BH760-1	.NAMEPLATE.....	1
7	XDFZZ	96906	MS21318-1	.SCREW,DRIVE.....	4
8	XDFZZ	98869	BH16805	.PLATE INSTRUCTION.....	1
9	XDFZZ	96906	MS21318-1	.SCREW,DRIVE.....	12
10	PBDZZ	98869	BH14978-2	.STOP ARM ASSEMBLY.....	1
11	PBFZZ	98869	BH437	.STOP ARM SUPPORT.....	1
12	PBFZZ	96906	MS51958-61	.SCREW,MACHINE.....	1
13	PBOZZ	81348	GGT318TYPE2	.THERMOMETER,SELF-IN.....	1
14	XDFFF	98869	H122	.CASE ACCESSORY SEE FIGURE 10 FOR BREAKDOWN.....	1

END OF FIGURE




Figure 2. BH16700-12 Accessory Kit

SECTION II			TM 55-4920-401-13&P		
(1)	(2)	(3)	(4)	(5)	(6)
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
				FIGURE 2. BH16700-12 ACCESSORY KIT.	
	PBFFF	98869	BH16700-12	ACCESSORY KIT, ANALY.....	1
1	PBFZZ	98869	BH123-3	.SWITCHBOX.....	1
2	PBFL	98869	BH361-8	.INTERCONNECTING BOX.....	1
3	PBFZZ	98869	BH405	.CABLE ASSEMBLY, SPEC --HEATER.....	1
4	PBFZZ	98869	BH450	.CABLE ASSEMBLY, SPEC --CHECK.....	1
5	PBFZZ	98869	BH485	.CABLE ASSEMBLY, SPEC --INSTRUMENT..	1
6	PBFZZ	98869	BH492B3	.HANDLE, EXTENSION.....	1
7	PBFZZ	98869	BH499A	.CABLE ASSEMBLY, POWE.....	1
8	PBFZZ	98869	BH820	.CABLE ASSEMBLY, POWE.....	1
9	PBFZZ	98869	BH821	.CABLE ASSEMBLY, POWE --INSULATION	1
10	PBFZZ	98869	BH822	CHECK ADAPTER.....	1
11	PBFZZ	98869	BH823	.CABLE ASSEMBLY, SPEC --EGT	1
12	PBFZZ	98869	BH996-40	INDICATOR CHECK ADAPTER.....	1
13	PBFZZ	98869	BH1504	.CABLE ASSEMBLY, POWE --RESISTANCE	1
14	PBFZZ	98869	BH4548	CHECK ADAPTER.....	1
				.PROBE ASSY, HEATER.....	3
				.CABLE ASSEMBLY, SPEC --CHECK CABLE	1
				ADAPTER.....	1
				.CABLE ASSEMBLY, SPEC --CHECK CABLE	1
				ADAPTER.....	1

END OF FIGURE




Figure 3. BH15720-3 Switch-Power Circuit Board Assembly

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES(UOC)	(6) QTY
GROUP 02. SWITCHES, CIRCUIT BREAKERS -BOARDS					
FIGURE 3. BH15720-3 SWITCH-POWER CIRCUIT BOARD ASSEMBLY					
	PBFDD	98869	BH15720-1	CIRCUIT CARD ASSEMB --SWITCH-POWER.	1
1	PBDZZ	37942	CG872U020V2C3PL	.CAPACITOR, FIXED, ELE.....	1
2	PBDZZ	96906	MS51960-62	.SCREW, MACHINE.....	2
3	PBDZZ	07263	2N4945	.TRANSISTOR.....	9
4	XDDZZ	81349	CK058X222K	.CAPACITOR, FIXED, CER.....	1
5	PBDZZ	81349	RLR07C1501GS	.RESISTOR, FIXED, FILM.....	1
6	PBDZZ	80131	1N5624	.SEMICONDUCTOR DEVIC.....	4
7	PBDZZ	81349	M55155/32-6	.TERMINAL, STUD.....	8
8	PBDZZ	56289	500D207G050FF7	.CAPACITOR, FIXED, ELE.....	2
9	PBDZZ	80131	1N5059	.SEMICONDUCTOR DEVIC.....	7
10	PBDZZ	81349	RNC55K1002FS	.RESISTOR, FIXED, FILM.....	5
11	PBDZZ	37942	TCG122U050N2C 3P	.CAPACITOR, FIXED, ELE.....	2
12	XADZZ	81349	RLR07C4701GS	.RESISTOR, FIXED, FILM.....	3
13	PBDZZ	81349	RLR07C1001GS	.RESISTOR, FIXED, FILM.....	1
14	PBDZZ	81349	RNC55K6981FS	.RESISTOR, FIXED, FILM.....	1
15	PBDZZ	81349	RNC55K8060FS	.RESISTOR, FIXED, FILM.....	1
16	PBDZZ	98869	C933	.SEMICONDUCTOR DEVIC.....	1
17	PBDZZ	81349	M38510/10101BGC	.MICROCIRCUIT, LINEAR.....	3
18	XDDZZ	71785	8-ICS	.SOCKET, PLUG-IN, ELEC.....	3
19	PBDZZ	81349	RLR07C4700GS	.RESISTOR, FIXED, FILM.....	4
20	PBDZZ	04157	NMP-COCO-M	.CONNECTOR, PLUG, ELEC.....	1
21	PBDZZ	04157	NMP-CHAL-M	.CONNECTOR, PLUG, ELEC.....	1
22	PBDZZ	29907	NMP-CHAL-F	.CONNECTOR, PLUG, ELEC.....	1
23	PBDZZ	98869	C05229	.SWITCH, ROTARY.....	1
24	PBDZZ	80131	2N6109	.TRANSISTOR.....	2
25	PBDZZ	96906	MS18212-5	.SCREW, MACHINE.....	6
26	PBDZZ	96906	MS35649-224	.NUT, PLAIN, HEXAGON.....	6
27	PBDZZ	98869	BH15721	.HEAT SINK, ELECTRICA.....	2
28	PBDZZ	80131	2N4402	.TRANSISTOR.....	3
29	PBDZZ	80131	2N6290	.TRANSISTOR.....	2
31	PBDZZ	80131	2N5294	.TRANSISTOR.....	2
32	PBDZZ	81349	M39003/01-2979	.CAPACITOR, FIXED, ELE.....	1
33	XDDZZ	37942	TT50X150B	.CAPACITOR.....	1
34	PBDZZ	98869	C05231	.SWITCH, ROTARY.....	1
35	PADZZ	81349	RLR07C2201GS	.RESISTOR, FIXED, FILM.....	2
36	PBDZZ	98869	BH15721-1	.HEAT SINK, ELECTRICA.....	1
37	PBDZZ	80131	1N702A	.SEMICONDUCTOR DEVIC.....	2
38	PBDZZ	21207	MMF504K2	.CAPACITOR, FIXED, MET.....	1
39	PBDZZ	98869	C05230	.SWITCH, ROTARY.....	1
40	XDDZZ	80031	1-4-5P470K	.RESISTOR, FIXED.....	1
41	XDDZZ	80031	1-4-5P100K	.RESISTOR, FIXED, FILM.....	2
42	XDDZZ	81349	RLR07C1000GR	.RESISTOR, FIXED, FILM.....	1
43	PBDZZ	81349	M39014/01-1575	.CAPACITOR, FIXED, CER.....	1
44	XDDZZ	80031	1-4-5P10K	.RESISTOR, FIXED, FILM.....	2
45	PBDZZ	81349	RCR20G271JS	.RESISTOR, FIXED, COMP.....	1
46	XDDZZ	81349	RLR07C5601GR	.RESISTOR, F IXED, FILM.....	1

SECTION II

TM 55-4920-401-13&P

(1)	(2)	(3)	(4)	(5)	(6)
TEM	SMR		PART		
NO	CODE	FSCM	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
47	PBDZZ	81349	RLR07C3902GR	.RESISTOR, FIXED, FILM.....	2
48	XDDZZ	81349	RLR07C2202GR	.RESISTOR, FIXED, FILM.....	1
49	PBDZZ	81349	M39003/01-3026	.CAPACITOR, FIXED, ELE.....	2
50	PBDZZ	81349	JAN1N5524B	.SEMICONDUCTOR DEVIC.....	1
51	PBDZZ	56289	36D132G050AA2A	.CAPACITOR, FIXED, ELE.....	1
52	PBDZZ	81349	RNC55K5761FS	.RESISTOR, FIXED, FILM.....	1
53	PBDZZ	37942	TCG412U015N1L	.CAPACITOR, FIXED, ELE.....	1
54	PBDZZ	98869	BH15722	.SPACER, PLATE.....	1
55	PBDZZ	96906	MS51957-3	.SCREW, MACHINE.....	2
56	PBDZZ	86928	5610-9-10	.INSULATOR, WASHER.....	2
57	XDDZZ	81349	RN55D3321F	.RESISTOR, FIXED, FILM.....	1
58	XDDZZ	81349	RLR07C6801GR	.RESISTOR, FIXED, FILM.....	1
59	XADZZ	98869	BH15720	.PRINTED CIRCUIT BOA.....	1

END OF FIGURE

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO	(b) ITEM NO	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	QTY INC IN UNIT
5		P8FD	492J-01-02C-5563	58865	BH15715-1	CIRCUIT CARD ASSEMB --TEMPERATURE.....	EA	1
5	1	P8DZZ	5905-00-685-2927	58865	H3536	.RESISTOR, FIXED, WIRE.....	EA	1
5	2	P8DZZ	5561-00-405-8427	58865	C533	.SEMICONDUCTOR DEVICE.....	EA	2
5	3	P8DZZ	5905-00-258-5413	E1345	RNC55K6980FS	.RESISTOR, FIXED, FILM.....	EA	1
5	4	P8CZZ	5905-01-031-1358	58865	H3895	.RESISTOR, FIXED, WIRE.....	EA	1
5	5	P8CZZ	591J-00-010-8668	E1345	H35014-01-1357	.CAPACITOR, FIXED, CEP.....	EA	2
5	6	P8DZZ	5905-01-038-3034	58865	H3505	.RESISTOR, FIXED, WIRE.....	EA	1
5	7	X0DZZ	5905-00-184-7705	E1349	FLR07C2201GR	.RESISTOR, FIXED, FILM.....	EA	11
5	8	P8DZZ	5905-00-438-0505	EC031	1-4-5F4K7	.RESISTOR, FIXED FILM.....	EA	5
5	9	P8DZZ	5561-00-505-8836	58865	C1904	.TRANSISTOR.....	EA	4
5	10	XCCZZ		C1255	SA5442A	.INTEGRATED CIRCUIT.....	EA	1
5	11	P8CZZ	5935-01-065-9763	18677	LS-2-16-160-G-B	.SOCKET.....	EA	1
5	12	P8DZZ	5962-00-318-2223	C1255	SA54CCN	.MICROCIRCUIT, DIGITA.....	EA	2
5	12A	P8CZZ	5935-01-065-9350	18677	LS-2-14-160-G-B	.SOCKET, PLUG- INELEC.....	EA	5
5	13	P8DZZ	5561-00-348-2541	C1255	SA547A	.MICROCIRCUIT, DIGITA.....	EA	2
5	14	P8DZZ	5961-00-846-9125	EC131	1N702A	.SEMICONDUCTOR DEVICE.....	EA	5
5	15	P8CZZ	5905-00-240-2736	E1345	FLR07C1P02GR	.RESISTOR, FIXED, FILM.....	EA	7
5	16	P8DZZ	5961-00-450-2040	C4713	2A4402	.TRANSISTOR.....	EA	8
5	17	P8DZZ	5905-01-037-2380	58865	H3783	.RESISTOR, FIXED, WIRE.....	EA	1
5	18	P8CZZ	5905-01-038-0617	58865	H3784	.RESISTOR, FIXED, WIRE.....	EA	1
5	19	P8DZZ	5905-00-055-5500	58865	H3785	.RESISTOR, FIXED, WIRE.....	EA	1
5	20	P8DZZ		58865	H3736	.RESISTOR, FIXED, WIRE.....	EA	1
5	21	P8DZZ		58865	H3786	.RESISTOR, FIXED, WIRE.....	EA	1
5	22	P8DZZ	5905-00-412-1212	58865	BH4446	.RESISTOR, FIXED, WIRE.....	EA	1
5	23	P8DZZ	5935-01-015-7885	58865	BH10666-9	.RESISTOR ASSEMBLY.....	EA	1
5	24	P8DZZ	5935-01-021-5435	C4151	NMP-CHAL-M	.CONNECTOR, PLUG, FLEC.....	EA	1
5	25	P8CZZ	5959-01-022-2226	53507	R-1003-A-2	.RETAINER-EJECTOR, EL.....	EA	2
5	26	P8CZZ	5905-00-126-8703	E1345	RCR07CF226JS	.RESISTOR, FIXED, COMP.....	EA	6
5	27	P8DZZ	5905-01-037-8088	58865	H3697	.RESISTOR, FIXED, WIRE.....	EA	1
5	28	P8DZZ	5905-01-031-0432	58865	H3674	.RESISTOR, FIXED, WIRE.....	EA	1
5	29	X0DZZ	5905-00-240-7675	E1345	FLR07C4700GR	.RESISTOR.....	EA	3
5	30	P8DZZ	5905-00-562-1555	E1345	FLR07C4702GR	.RESISTOR, FIXED, FILM.....	EA	2
5	31	P8CZZ	5935-00-411-7525	E2330	430	.JACK, TIP.....	EA	3
5	32	P8CZZ	5905-00-185-2380	58865	380CF2C3	.RESISTOR, VARIABLE, W.....	EA	2
5	33	P8DZZ	5905-00-168-5267	C2660	3800P-502	.RESISTOR, VARIABLE, W.....	EA	2
5	34	P8DZZ	5905-00-107-4872	54271	533-CCF553K	.RESISTOR, VARIABLE, N.....	EA	1
5	35	P8CZZ	591J-00-007-2001	E1345	H35003-01-2966	.CAPACITOR, FIXED, ELE.....	EA	2
5	36	P8CZZ	5905-00-273-5825	E1345	RNC55K7870FS	.RESISTOR, FIXED, FILM.....	EA	1
5	37	P8DZZ	5905-00-240-2745	E1345	FLR07C2702GR	.RESISTOR, FIXED, FILM.....	EA	7
5	38	P8DZZ	5562-00-107-4853	58865	C4600	.INTEGRATED CIRCUIT.....	EA	1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO	(b) ITEM NO	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
5	39	PBDZZ	5340-01-023-5121	58869	BH12000-1	.CLIP, RETAINING.....	EA	1
5	40	PBDZZ	5999-00-402-2485	CC779	1-331892-0	.CONTACT, ELECTRICAL.....	EA	8
5	41	PBDZZ	5905-00-312-3804	58869	BH5007	.RESISTOR, FIXED, WIRE.....	EA	2
5	42	PBDZZ	5905-00-438-0447	8CC31	1-4-5F47E	.RESISTOR, FIXED, FILM.....	EA	2
5	43	PBDZZ	5910-00-409-2049	14752	112A1C104	.CAPACITOR, FIDEC, PLA.....	EA	1
5	44	PBDZZ	5910-00-113-5274	E1345	W35014-01-1351	.CAPACITOR, FIDEC, CER.....	EA	1
5	45	PBDZZ	5905-01-021-6818	54271	533-CC-S250K	.RESISTOR, VARIABLE, N.....	EA	1
5	46	PBDZZ	5962-00-453-7115	C1295	SN52741L	.INTEGRATED CIRCUIT.....	EA	2
5	47	XDDZZ		71705	133-58-92-061	.SOCKET, PLUG-IN, ELEC.....	EA	3
5	48	PBDZZ	5905-00-225-7351	C266C	3800P2C2	.RESISTOR, VARIABLE, W.....	EA	1
5	49	PBDZZ	5905-01-030-5147	58869	H3828	.RESISTOR, FIXED, WIRE.....	EA	1
5	50	PBDZZ	5910-00-81C-4854	7155C	00500	.CAPACITOR, FIDEC, CER.....	EA	2
5	51	XDDZZ	5905-00-240-2728	8CC31	1-4-5F10K	.RESISTOR, FIXED, FILM.....	EA	1
5	52	PBDZZ	5961-00-842-5664	C4713	1N914	.SEMICONDUCTOR, DEVIC.....	EA	2
5	53	PBDZZ	5962-00-157-2430	12C4C	LM211P	.MICROCIRCUIT, LINEAR.....	EA	1
5	54	PBDZZ	5910-00-983-5388	7155C	00100	.CAPACITOR, FIDEC, CER.....	EA	1
5	55	PBDZZ	5905-00-208-4253	E1345	RAC55K1003FS	.RESISTOR, FIXED, FILM.....	EA	1
5	56	PBDZZ	5910-00-211-1574	14752	425C1C105J	.CAPACITOR.....	EA	1
5	57	PBDZZ	5910-00-788-0328	56289	5GAS-510	.CAPACITOR, FIDEC, CER.....	EA	2
5	57A	XDDZZ		E1349	CK050x221K	.CAPACITOR, FIDEC.....	EX	1
5	58	PBDZZ	5910-00-988-6171	E1345	CK050x220K	.CAPACITOR, FIDEC, CER.....	EA	3
5	59	PBDZZ	5905-01-032-0007	58869	H3524	.RESISTOR, FIXED, WIRE.....	EA	1
5	60	XDDZZ	5961-00-466-7029	C1295	2N4861	.TRANSISTOR.....	EA	5
5	61	PBDZZ	5962-00-118-3871	C1295	SN5476A	.MICROCIRCUIT, DIGITA.....	EA	1
5	62	PBDZZ	5935-01-065-5783	1F677	LS-2-16-160-G-8	.SOCKET, ELEC.....	EA	1
5	63	PBDZZ	5962-00-118-3868	C1295	SN5402A	.MICROCIRCUIT, DIGITA.....	EA	1
5	64	PBDZZ	5910-00-144-4383	E1345	W35003-01-3026	.CAPACITOR, FIDEC, ELE.....	EA	3
5	65	PBDZZ	5950-00-470-4200	E1345	LT10K144	.COIL, RADIO FREQUENC.....	EA	2
5	66	PBDZZ	5961-00-118-4775	04713	2N4852	.TRANSISTOR.....	EA	1
5	67	PBDZZ	5905-00-415-6502	58869	H3378	.RESISTOR, FIXED, WIRE.....	EA	1
5	68	PBDZZ	5905-01-031-1401	58869	H3627	.RESISTOR, FIXED, WIRE.....	EA	1
5	69	PBDZZ		58869	H369C	.RESISTOR, FIXED, WIRE.....	EA	1
5	70	PBDZZ	4920-01-085-7538	58869	BH15715	.PRINTED CIRCUIT BOA.....	EA	1




Figure 4. BH16358-2 Display Circuit Board Assembly

SECTION II

TM 55-4920-401-13&P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES(UOC)	(6) QTY
				FIGURE 4. BH16358-2 DISPLAY CIRCUIT BOARD ASSEMBLY	
	PBFDD	98869	BH16358-2	PRINTED CIRCUIT BOA --DISPLAY	1
1	XDDZZ	01295	SNC5490AJ	.MICROCIRCUIT,DIGITA	5
2	XDDZZ	18677	US-2-14-160-G-B	.SOCKET,PLUG-IN ELEC	5
3	PBDZZ	81349	M39014/02-1338	.CAPACITOR,FIXED,CER	3
4	XDDZZ	04713	MC4350L	.MICROCIRCUIT,DIGITA	8
5	PBDZZ	18677	US-2-16-160-G-B	.SOCKET,PLUG-IN ELEC	8
6	PBDZZ	73138	899-3R150	.RESISTOR NETWORK,FI	8
7	XDDZZ	50436	5082-7650	.DISPLAY	8
8	XDDZZ	18677	US-2-14-160-G-B	.SOCKET,PLUG-IN ELEC	8
9	XADZZ	81349	RLR07C4701GS	.RESISTOR,FIXED,FILM	1
11	PBDZZ	81349	RLR07C2700GS	.RESISTOR,FIXED,FILM	2
12	PBDZZ	53507	R-1003-A-2	.RETAINER-EJECTOR,EL	1
13	PBDZZ	98869	BH16357	.BUS,CONDUCTOR	1
14	XDDZZ	88245	2024B	.TERMINAL,STUD	13
15	XADZZ	98869	BH16358	.PRINTED CIRCUIT BOA	1

END OF FIGURE




Figure 5. BH15715-1 Temperature Circuit Board Assembly




Figure 6. BH15717-1 Tachometer Circuit Board Assembly

SECTION II

TM 55-4920-401-13&P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES(UOC)	(6) QTY
				FIGURE 5. BH15715-1 TEMPERATURE CIRCUIT BOARD ASSEMBLY	
	PBFDD	98869	BH15715-1	CIRCUIT CARD ASSEMB --TEMPERATURE..	1
1	XDDZZ	98869	H3536	.RESISTOR, FIXED, WIRE.....	1
2	PBDZZ	98869	C933	.SEMICONDUCTOR DEVIC.....	2
3	PBDZZ	81349	RNC55K6980FS	.RESISTOR, FIXED, FILM.....	1
4	PBDZZ	98869	H3895	.RESISTOR, FIXED, WIRE.....	1
5	PBDZZ	81349	M39014/01-1357	.CAPACITOR, FIXED, CER.....	2
6	XDDZZ	98869	H3905	.RESISTOR, FIXED, WIRE.....	1
7	PADZZ	81349	RLR07C2201GS	.RESISTOR, FIXED, FILM.....	11
8	XADZZ	81349	RLR07C4701GS	.RESISTOR, FIXED, FILM.....	5
9	PBDZZ	04713	SM5365	.TRANSISTOR.....	4
10	XDDZZ	01295	SN5442N	.INTEGRATED CIRCUIT.....	1
11	PBDZZ	18677	US-2-16-160-G-B	.SOCKET, PLUG-INELEC.....	1
12	PBDZZ	81349	M38510/001048CB	.MICROCIRCUIT, DIGITA.....	2
12A	XDDZZ	18677	US-2-14-160-G-B	.SOCKET, PLUG-INELEC.....	5
13	PBDZZ	81349	M38510/002058CB	.MICROCIRCUIT, DIGITA.....	2
14	PBDZZ	80131	1N702A	.SEMICONDUCTOR DEVIC.....	5
15	XDDZZ	81349	RLR07C1802GR	.RESISTOR, FIXED, FILM.....	7
16	PBDZZ	80131	2N4402	.TRANSISTOR.....	8
17	PBDZZ	98869	H3783	.RESISTOR, FIXED, WIRE.....	1
18	XDDZZ	98869	H3784	.RESISTOR, FIXED, WIRE.....	1
19	PBDZZ	05591	4H8A23180B	.RESISTOR, FIXED, WIRE.....	1
20	XDDZZ	05591	4H8A23790B	.RESISTOR, FIXED, WIRE.....	1
21	XDDZZ	05591	4H8A14630B	.RESISTOR, FIXED, WIRE.....	1
22	PBDZZ	05591	4H8A30000B	.RESISTOR, FIXED, WIRE.....	1
23	PBDZZ	98869	BH10666-8	.RESISTOR ASSEMBLY.....	1
24	PBDZZ	04157	NMP-CHAL-M	.CONNECTOR, PLUG, ELEC.....	1
25	PBDZZ	53507	R-1003-A-2	.RETAINER-EJECTOR, EL.....	2
26	PBDZZ	81349	RCR07G226JS	.RESISTOR, FIXED, COMP.....	6
27	XDDZZ	98869	H3697	.RESISTOR, FIXED, WIRE.....	1
28	PBDZZ	98869	H3674	.RESISTOR, FIXED, WIRE.....	1
29	PBDZZ	81349	RLR07C4700GS	.RESISTOR, FIXED, FILM.....	3
30	PBDZZ	81349	RLR07C4702GS	.RESISTOR, FIXED, FILM.....	2
31	PBDZZ	82389	430	.JACK, TELEPHONE.....	3
32	PBDZZ	04454	3800P203	.RESISTOR, VARIABLE, W.....	2
33	PBDZZ	02660	3800P502	.RESISTOR, VARIABLE, W.....	2
34	PBDZZ	94271	830P-50K	.RESISTOR, VARIABLE, N.....	1
35	PBDZZ	81349	M39003/01-2966	.CAPACITOR, FIXED, ELE.....	2
36	PBDZZ	81349	RNC55K7870FS	.RESISTOR, FIXED, FILM.....	1
37	XDDZZ	81349	RLR07C2702GS	.RESISTOR, FIXED, FILM.....	7
38	PBDZZ	98869	C4600	.MICROCIRCUIT, LINEAR.....	1
39	PBDZZ	98869	BH12068-1	.CLIP, RETAINING.....	1
40	PBDZZ	55974	1945708-2	.CLIP, ELECTRICAL.....	8
41	PBDZZ	98869	BH5007	.RESISTOR, FIXED, WIRE.....	2
42	PBDZZ	81349	RLR07C47R0GS	.RESISTOR, FIXED, FILM.....	2
43	PBDZZ	14752	112A1C104J	.CAPACITOR, FIXED, MET.....	1
44	PBDZZ	81349	M39014/01-1351	.CAPACITOR, FIXED, CER.....	1
45	PBDZZ	94271	533-00HS250K	.RESISTOR, VARIABLE, N.....	1
46	PBDZZ	81349	M38510/101018GC	.MICROCIRCUIT, LINEAR.....	2
47	XDDZZ	71785	133-98-92-061	.SOCKET, PLUG-IN, ELEC.....	3

SECTION II						(6)
(1)	(2)	(3)	(4)	(5)		(6)
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)		QTY
48	PBDZZ	04454	3800P202	.RESISTOR,VARIABLE,W.....		
49	PBDZZ	98869	H3828	.RESISTOR,FIXED,WIRE.....		1
50	PBDZZ	84171	CCD470	.CAPACITOR,FIXED,CER.....		2
51	XDDZZ	80031	1-4-5P10K	.RESISTOR,FIXED,FILM.....		1
52	PBDZZ	81349	JAN1N914	.SEMICONDUCTOR DEVIC.....		2
53	XDDZZ	88818	G193-064-001	.MICROCIRCUIT,LINER.....		1
54	PBDZZ	81349	CK60BX100K	.CAPACITOR,FIXED,CER.....		1
55	PBDZZ	81349	RNC55K1003FS	.RESISTOR,FIXED,FILM.....		1
56	PBDZZ	14752	625C1C105J	.CAPACITOR,FIXED,MET.....		1
57	XDDZZ	56289	C023B501G103M	.CAPACITOR,FIXED,CER.....		2
57A	XDDZZ	81349	CK05BX221K	.CAPACITOR,FIXED.....		1
58	XDDZZ	81349	CK05BX220K	.CAPACITOR,FIXED,CER.....		3
59	PBDZZ	98869	H3524	.RESISTOR,FIXED,WIRE.....		1
60	XDDZZ	01295	2N4861	.TRANSISTOR.....		5
61	PBDZZ	81349	M38510/00204BEB	.MICROCIRCUIT,DIGITA.....		1
62	PBDZZ	18677	US-2-16-160-G-B	.SOCKET,PLUG-INELEC.....		1
63	PBDZZ	81349	M38510/00401BCB	.MICROCIRCUIT,DIGITA.....		1
64	PBDZZ	81349	M39003/01-3026	.CAPACITOR,FIXED,ELE.....		3
65	PBDZZ	81349	LT10K144	.COIL,RADIO FREQUENC.....		2
66	PBDZZ	04713	2N4852	.TRANSISTOR.....		1
67	XDDZZ	05591	4H8A2300B	.RESISTOR,FIXED,WIRE.....		1
68	PBDZZ	98869	H3627	.RESISTOR,FIXED,WIRE.....		1
69	PBDZZ	05591	4H8A14402B	.RESISTOR,FIXED,WIRE.....		1
70	XADZZ	98869	BH15715	.PRINTED CIRCUIT BOA.....		1

END OF FIGURE




Figure 6. BH15717-1 Tachometer Circuit Board Assembly

SECTION II			TM 55-4920-401-13&P			
(1)	(2)	(3)	(4)	(5)	(6)	
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY	
				FIGURE 6. BH15717-1 TACHOMETER CIRCUIT BOARD ASSEMBLY.		
	PBFDD	98869	BH15717-1	CIRCUIT CARD ASSEMB --TACHOMETER...	1	
1	PADZZ	81349	RLR07C2201GS	.RESISTOR, FIXED, FILM.....	10	
2	XADZZ	81349	RLR07C4701GS	.RESISTOR, FIXED, FILM.....	5	
3	PBDZZ	50369	ACF50-0-22-5	.CAPACITOR, FIXED, MET.....	1	
4	PBDZZ	81349	M39014/01-1357	.CAPACITOR, FIXED, CER.....	1	
5	PBDZZ	81349	RLR07C47R0GS	.RESISTOR, FIXED, FILM.....	2	
6	XDDZZ	05591	4H8A2300B	.RESISTOR, FIXED, WIRE.....	1	
7	PBDZZ	98869	H3447	.RESISTOR, FIXED, WIRE.....	1	
8	PBDZZ	98869	H3627	.RESISTOR, FIXED, WIRE.....	3	
9	PBDZZ	04713	2N4852	.TRANSISTOR.....	1	
10	PBDZZ	81349	RNC55K7870FS	.RESISTOR, FIXED, FILM.....	2	
11	PBDZZ	98869	C933	.SEMICONDUCTOR DEVIC.....	2	
12	PBDZZ	81349	M39003/01-3026	.CAPACITOR, FIXED, ELE.....	3	
13	PBDZZ	81349	RLR07C47C0GS	.RESISTOR, FIXED, FILM.....	4	
14	PBDZZ	81349	M39003/01-2969	.CAPACITOR, FIXED, ELE.....	2	
15	PBDZZ	98869	H3564	.RESISTOR, FIXED, WIRE.....	1	
16	XDDZZ	80031	1-4-5P100E	.RESISTOR.....	2	
17	PBDZZ	81349	RNC60K4643FS	.RESISTOR, FIXED, FILM.....	2	
18	PBDZZ	14752	625C1C105J	.CAPACITOR, FIXED, MET.....	2	
19	PBDZZ	01295	TIL111	.COUPLER, OPTOELECTRO.....	1	
20	PBDZZ	98869	H3485	.RESISTOR, FIXED, WIRE.....	3	
21	XDDZZ	14752	112A1C104J	.CAPACITOR, FIXED, MET.....	1	
22	PBDZZ	81349	RNC55K1003FS	.RESISTOR, FIXED, FILM.....	4	
23	PBDZZ	04713	1N914	.SEMICONDUCTOR DEVIC.....	5	
24	PBDZZ	80131	2N4402	.TRANSISTOR.....	3	
25	PBDZZ	81349	M38510/10101BGC	.MICROCIRCUIT, LINEAR.....	5	
26	XDDZZ	71785	133-98-92-061	.SOCKET, PLUG-IN, ELEC.....	6	
27	XDDZZ	81349	RLR07C3303GR	.RESISTOR, FIXED, FILM.....	1	
28	PBDZZ	81349	M39014/01-1357	.CAPACITOR, FIXED, CER.....	3	
29	XDDZZ	80031	1-4-5P10K	.RESISTOR, FIXED, FILM.....	3	
30	PBDZZ	53507	R-1003-A-2	.RETAINER-EJECTOR, EL.....	2	
31	PBDZZ	04454	3800P203	.RESISTOR, VARIABLE, W.....	2	
32	PBDZZ	82389	430	.JACK, TELEPHONE.....	6	
33	PBDZZ	80131	2N4352	.TRANSISTOR.....	1	
34	PBDZZ	13499	352-0840-0: 2	.TRANSISTOR.....	1	
35	XDDZZ	02799	H-1022	.CAPACITOR, FIXED, PLA.....	1	
36	PBDZZ	98869	C4600	.MICROCIRCUIT, LINEAR.....	1	
36A	PBDZZ	98869	BH12068-1	.CLIP, RETAINING.....	1	
36B	PBDZZ	19315	1945708-2	.CLIP, ELECTRICAL.....	8	
37	PBDZZ	20747	101-127-104	.RESISTOR, VARIABLE, N.....	1	
38	PBDZZ	02660	3800P502	.RESISTOR, VARIABLE, W.....	3	
39	PBDZZ	94271	533-00HS250K	.RESISTOR, VARIABLE, N.....	1	
40	PBDZZ	05591	4H8A30000B	.RESISTOR, FIXED, WIRE.....	1	
41	PBDZZ	98869	H3470	.RESISTOR, FIXED, WIRE.....	1	
42	PBDZZ	98869	BH3274	.RESISTOR, FIXED, WIRE.....	2	
43	PBDZZ	13499	381-0003-100	.RESISTOR, VARIABLE, W.....	1	
44	XDDZZ	01295	2N4861	.TRANSISTOR.....	6	
45	PBDZZ	04454	3800P202	.RESISTOR, VARIABLE, W.....	1	
46	XDDZZ	81349	CK05BX220K	.CAPACITOR, FIXED, CER.....	4	

SECTION II

TM 55-4920-401-13&P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES(UOC)	(6) QTY
47	PBDZZ	84171	CCD470	.CAPACITOR, FIXED, CER.....	1
48	PBDZZ	04713	SM5365	.TRANSISTOR.....	3
49	XDDZZ	81349	RLR07C2702GS	.RESISTOR, FIXED, FILM.....	8
50	PBDZZ	81349	RLR07C4702GS	.RESISTOR, FIXED, FILM.....	1
51	XDDZZ	88818	G193-064-001	.MICROCIRCUIT, LINEAR.....	1
52	PBDZZ	81349	CK60BX100K	.CAPACITOR, FIXED, CER.....	1
53	XDDZZ	56289	C023B501G103M	.CAPACITOR, FIXED, CER.....	2
54	PBDZZ	81349	RCR07G226JS	.RESISTOR, FIXED, COMP.....	6
55	PBDZZ	98869	H3524	.RESISTOR, FIXED, WIRE.....	1
56	PBDZZ	81349	M38510/00205BCB	.MICROCIRCUIT, DIGITA.....	1
57	XDDZZ	18677	US-2-14-160-G-B	.SOCKET, PLUG-IN ELEC.....	3
58	PBDZZ	98869	H3515	.RESISTOR, FIXED, WIRE.....	1
59	PBDZZ	81349	M38510/00401BCB	.MICROCIRCUIT, DIGITA.....	1
60	PBDZZ	81349	M38510/00204BEB	.MICROCIRCUIT, DIGITA.....	1
61	PBDZZ	18677	US-2-16-160-G-B	.SOCKET, PLUG-IN ELEC.....	1
62	PBDZZ	81349	M38510/00104BCB	.MICROCIRCUIT, DIGITA.....	1
63	PBDZZ	81349	LT10K144	.COIL, RADIO FREQUENC.....	2
64	XDDZZ	05591	4H8A22001B	.RESISTOR, FIXED, WIRE.....	1
65	PBDZZ	05591	4H8A3802B	.RESISTOR, FIXED, WIRE.....	1
66	XADZZ	98869	BH15717	.PRINTED CIRCUIT BOA.....	1

END OF FIGURE




Figure 7. BH16365-1 Calibrator Circuit Board Assembly

SECTION II

TM 55-4920-401-13&P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES(UOC)	(6) QTY
				FIGURE 7. BH16365-1 CALIBRATOR CIRCUIT BOARD ASSEMBLY	
	PBFDD	98869	BH16365-1	CIRCUIT CARD ASSEMB --CALIBRATOR...	1
1	PBDZZ	81349	LT10K144	.COIL,RADIO FREQUENC.....	2
2	XDDZZ	81349	M39014/01-1329	.CAPACITOR, FIXED, CER.....	2
3	PBDZZ	81349	M39003/01-3026	.CAPACITOR, FIXED, ELE.....	4
4	XDDZZ	81349	M38510/10103BGB	.MICROCIRCUIT, LINEAR.....	1
5	XDDZZ	71785	133-98-92-061	.SOCKET, PLUG-IN, ELEC.....	4
6	XDDZZ	81349	RNC55K2002FS	.RESISTOR, FIXED, FILM.....	1
7	PBDZZ	81349	M38510/10101BGC	.MICROCIRCUIT, LINEAR.....	3
8	PBDZZ	81349	RLR07C1004GS	.RESISTOR, FIXED, FILM.....	1
9	PBDZZ	81349	M39014/01-1357	.CAPACITOR, FIXED, CER.....	1
10	XDDZZ	81349	RLR07C1503GR	.RESISTOR, FIXED, FILM.....	1
11	XDDZZ	80031	1-4-5P10K	.RESISTOR, FIXED, FILM.....	1
12	PBDZZ	81349	RNC55K7870FS	.RESISTOR, FIXED, FILM.....	1
13	PBDZZ	98869	C933	.SEMICONDUCTOR DEVIC.....	2
14	PBDZZ	81349	M39003/01-3024	.CAPACITOR, FIXED, ELE.....	1
15	PBDZZ	14752	625C1C105J	.CAPACITOR, FIXED, MET.....	2
16	PBDZZ	81349	JAN1N914	.SEMICONDUCTOR DEVIC.....	4
17	PBDZZ	98869	BH10666-8	.RESISTOR ASSEMBLY.....	1
18	PBDZZ	29907	NMF-K-F	.CONNECTOR, PLUG, ELEC.....	1
19	PBDZZ	98869	H3674	.RESISTOR, FIXED, WIRE.....	1
20	PBDZZ	04454	3800P502	.RESISTOR, VARIABLE, W.....	1
21	PBDZZ	82389	430	.JACK, TELEPHONE.....	3
22	PBDZZ	71279	3422-1-03	.JACK, TIP.....	2
23	PBDZZ	71279	461-2871-01-03-1 2	.DUMMY CONNECTOR, PLU.....	1
24	PBDZZ	98869	BH5070	.RESISTOR, FIXED, WIRE.....	1
25	PBDZZ	98869	BH5058	.RESISTOR, FIXED, WIRE.....	1
26	PBDZZ	04454	3811P100	.RESISTOR, VARIABLE, N.....	1
27	PBDZZ	98869	BH3274	.RESISTOR, FIXED, WIRE.....	1
28	PBDZZ	98869	BH4098	.RESISTOR, FIXED, WIRE.....	1
29	PBDZZ	04454	3800P202	.RESISTOR, VARIABLE, W.....	2
30	XDDZZ	05591	4H8A19301B	.RESISTOR, FIXED, WIRE.....	1
31	PBDZZ	21207	NMF504K2	.CAPACITOR, FIXED, MET.....	1
32	XDDZZ	81349	M38510/05003BCA	.MICROCIRCUIT, DIGITA.....	1
33	XDDZZ	18677	US-2-14-160-G-8	.SOCKET, PLUG-IN ELEC.....	5
34	PBDZZ	81349	M39014/02-1338	.CAPACITOR, FIXED, CER.....	2
35	XDDZZ	81349	M38510/05101BCA	.MICROCIRCUIT, DIGITA.....	1
36	XDDZZ	81349	RLR07C1502GR	.RESISTOR, FIXED, FILM.....	2
37	PBDZZ	53507	R-1003-A-2	.RETAINER-EJECTOR, EL.....	2
38	XDDZZ	81349	CR45U	.SEMICONDUCTOR DEVIC.....	1
39	XDDZZ	91506	8000-AG9	.SOCKET, PLUG-IN ELEC.....	1
40	PBDZZ	81349	JAN1N4461	.SEMICONDUCTOR DEVIC.....	2
41	PBFZZ	81349	RW69V360	.RESISTOR, FIXED, WIRE.....	1
42	PBDZZ	80131	1N5059	.SEMICONDUCTOR DEVIC.....	2
43	PBDZZ	56289	500D207G050FF7	.CAPACITOR, FIXED, ELE.....	1
44	PBDZZ	81349	RLR07C4702GS	.RESISTOR, FIXED, FILM.....	1
45	XDDZZ	02735	CD4001AE	.MICROCIRCUIT, DIGITA.....	1
46	PBDZZ	81349	RCR07G106JS	.RESISTOR, FIXED, COMP.....	1
47	PBDZZ	81349	M38510/05605BCB	.MICROCIRCUIT, DIGITA.....	2

SECTION II

TM 55-4920-401-13&P

(1)	(2)	(3)	(4)	(5)	(6)
ITEM	SMR		PART		
NO	CODE	FSCM	NUMBER	DESCRIPTION AND USABLE ON COD ES(UOC)	QTY
48	PBDZZ	81349	RNC55K6650FS	.RESISTOR, FIXED, FILM.....	1
49	XDDZZ	98869	BH16365	.PRINTED CIRCUIT BOA.....	1

END OF FIGURE




Figure 8. BH15801-1 Probe Control-Function Switch Circuit Board Assembly

SECTION II

TM 55-4920-401-13&P

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
				FIGURE 8. BH15801-1 PROBE CONTROL- FUNCTION SWITCH CIRCUIT BOARD ASSEMBLY	
	PBFFF	98869	BH15801-1	CIRCUIT CARD ASSEMB --PROBE CONTROL-FUNCTIONSWITCH.....	1
1	PBFZZ	81349	JAN 1N914	.SEMICONDUCTOR DEVIC.....	4
2	PBFZZ	81349	RLR07C3902GR	.RESISTOR, FIXED, FILM.....	4
3	PAFZZ	81349	RLR07C2201GS	.RESISTOR, FIXED, FILM.....	1
4	PBFZZ	80131	1N702A	.SEMICONDUCTOR DEVIC.....	1
5	PBFZZ	81349	M38510/10101BGC	.MICROCIRCUIT, LINEAR.....	1
6	XDFZZ	71785	8-ICS	.SOCKET, PLUG-IN, ELEC.....	2
7	XDDZZ	31589	ACF50-2-0-10	.CAPACITOR, FIXED, MET.....	1
8	PBFZZ	04386	TZ-17XT	.TRANSFORMER, AUDIOF.....	1
9	XDDZZ	80031	1-4-5P3K3	.RESISTOR, FIXED, FILM.....	1
10	PBFZZ	81349	M39014/01-1575	.CAPACITOR, FIXED, CER.....	2
11	PBFZZ	80131	2N6336	.SEMICONDUCTOR DEVIC.....	2
12	PBFZZ	86928	5203-8	.INSULATOR, DISK.....	2
13	XDFZZ	80031	1-4-5P10K	.RESISTOR, FIXED, FILM.....	3
14	PBFZZ	18876	10015417-054	.CAPACITOR, FIXED, CER.....	1
15	XDDZZ	14752	637B1D563K	.CAPACITOR.....	1
16	XDFZZ	12697	VC30-1K	.RESISTOR, FIXED, WIRE.....	1
17	PBFZZ	80131	1N5059	.SEMICONDUCTOR DEVIC.....	2
18	XDFZZ	81349	RLR07C1502GR	.RESISTOR, FIXED, FILM.....	1
19	PBFZZ	81349	JAN1N4486	.SEMICONDUCTOR DEVIC.....	1
20	PBFZZ	81349	JAN1N3613	.SEMICONDUCTOR DEVIC.....	2
21	PBFZZ	81349	RCR20G331JS	.RESISTOR, FIXED, COMP.....	1
22	PBFZZ	56289	500D207G050FF7	.CAPACITOR, FIXED, ELE.....	1
23	PBFZZ	81349	JAN1N4471	.SEMICONDUCTOR DEVIC.....	1
24	PBFZZ	81349	M39003/01-2991	.CAPACITOR, FIXED, ELE.....	1
25	PBFZZ	81349	RNC55K1001FS	.RESISTOR, FIXED, FILM.....	1
26	PBFZZ	98869	C933	.SEMICONDUCTOR DEVIC.....	1
27	PBFZZ	81349	JAN1N4461	.SEMICONDUCTOR DEVIC.....	1
28	XDFZZ	81349	CK06BX223K	.CAPACITOR, FIXED, CER.....	2
29	PBFZZ	80131	2N3646	.TRANSISTOR.....	2
30	PBFZZ	98869	C05228	.SWITCH, ROTARY.....	1
31	PBFZZ	81349	M39003/01-2969	.CAPACITOR, FIXED, ELE.....	1
32	PBFZZ	98869	C05227	.SWITCH, ROTARY.....	1
33	PBFZZ	81349	M39003/01-3076	.CAPACITOR, FIXED, ELE.....	1
34	PBFZZ	98869	H3440	.RESISTOR, FIXED, WIRE.....	1
35	PBFZZ	81349	RCR07G106JS	.RESISTOR, FIXED, COMP.....	1
36	XDFZZ	27014	LM725AN/6838	.MICROCIRCUIT, LINEAR.....	1
37	XDFZZ	05591	4H8A2300B	.RESISTOR, FIXED, WIRE.....	1
38	PBFZZ	05591	4H8A40001B	.RESISTOR, FIXED, WIRE.....	1
39	PBFZZ	05591	4H8A16302B	.RESISTOR, FIXED, WIRE.....	1
40	PBFZZ	04454	3800P203	.RESISTOR, VARIABLE, W.....	2
41	PBFZZ	04454	3800P502	.RESISTOR, VARIABLE, W.....	1
42	PBFZZ	98869	BH10666-8	.RESISTOR ASSEMBLY.....	1
43	PBFZZ	98869	H3674	.RESISTOR, FIXED, WIRE.....	1
44	XAFZZ	81349	RLR07C4701GS	.RESISTOR, FIXED, FILM.....	1
45	PBFZZ	81349	RCR07G226JS	.RESISTOR, FIXED, COMP.....	1
46	PBFZZ	81349	RLR07C4700GS	.RESISTOR, FIXED, FILM.....	2

SECTION II

TM 55-4920-401-13&P

(1)	(2)	(3)	(4)	(5)	(6)
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON COD ES(UOC)	QTY
47	XDFZZ	81349	RLR07C2203GS	.RESISTOR, FIXED, FILM.....	1
48	PBFZZ	81349	SE23XC02	.TERMINAL, STUD.....	2
49	PBFZZ	04713	2N4852	.TRANSISTOR.....	1
50	XDDZZ	31589	ACF&504.22&10	.CAPACITOR, FIXED, MET.....	1
51	XADZZ	98869	BH15801	.PRINTED CIRCUIT BO A.....	1

END OF FIGURE

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 03 TRIMMER ASSY, CASE AND COMPONENTS		
10		XDFFF		48869	H122	CASE ACCESSOR Y	EA	1
10		PBFZZ	4920-01-086-1464	48869	BH585	. HANDLE, CARRYING CAS	EA	1
10		PBFZZ	5310-00-063-6717	49066	MS35426-15	. NUT, PLAIN, WING	EA	2
10		PBFZZ	5306-00-080-0680	49506	MS35308-341	. BOLT, MACHI CE.	EA	2
10		PBFZZ	4920-00-565-3702	48869	BH727	. SOCKET, PIVOT	EA	2
10		PBFZZ	4920-00-565-3710	48869	BH796	. STOP, ARM ASSY.	EA	1
10		PBFZZ	5365-01-032-7243	48869	BH723	. SPACER, SLEEVE	EA	1
10		PBFZZ	4920-00-734-8321	48869	BH437	. STOP ARM SUPPORT	EA	1
10		PBFZZ	5305-00-055-3657	49506	MS51956-61	. SCREW, MACHI CE	EA	1
10		PBFZZ	4620-01-086-1488	48869	BH834-1	. MOUNT, SUPPORT	EA	1
10	1	PBFZZ	5305-00-050-9229	49506	MS51957-63	. SCREW, MACHI NE	EA	8
10	1	PBFZZ		48869	BH834-2	. SPACER, PLATE	EA	1
10	1	PBFZZ	5305-00-054-6651	49506	MS51957-27	. SCREW, MACHI NE	EA	4
10	1	PBFZZ	4920-00-589-8409	48869	BH3506	. WHEEL, SOLID RUBBER	EA	2
10	1	PBFZZ	5365-00-298-6563	74136	5100-62	. RING, RETAINING	EA	2
10	1	PBFZZ	4920-00-565-3714	48869	BH835	. MOUNT, WHEEL	EA	2
10	1	PBFZZ	5305-00-050-9231	49506	MS51957-65	. SCREW, MACHI NE	EA	8
10	1	PBFZZ	4920-01-086-1470	48869	BH6554	. PROBE HOLDER	EA	1
10	1	PBFZZ	4920-01-086-1471	48869	BH6551	. RACK, TEST PROCEDURES.	EA	1




Figure 9. BH16367-3 Resistance-Insulation Circuit Board Assembly

SECTION II

TM 55-4920-401-13&9

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODE(UOC)	(6) QTY
				FIGURE 9. BH16367-3 RESISTANCE- INSULATION CIRCUIT BOARD ASSEMBLY	
	XDFFF	98869	BH16367-3	CIRCUIT CARD ASSEMB --RESISTANCE- INSULATION	1
1	XDDZZ	63743	5XM225	. RESISTOR, FIXED, WI RE	2
2	PBFZZ	98869	H3395	. RESISTOR, FIXED, WI RE	1
3	PBFZZ	98869	H3522	. RESISTOR, FIXED, FI LM	1
4	XDFZZ	98869	H3394	. RESISTOR, FIXED, WI RE	1
5	PBFZZ	81349	RT12C2P101	. RESISTOR, VARIABLE, W.	1
6	PBFZZ	81349	M39015/1-003PP	. RESISTOR, VARIABLE, W	1
7	PBFZZ	81349	RT12C2P100	. RESISTOR, VARIABLE, W.	1
8	PBFZZ	52599	249E500M90	. RESISTOR, VARIABLE, W.	4
9	XDFZZ	91637	RS-1A7-1W	. RESISTOR, FIXED, FI LM.	2
10	XDFZZ	91637	RS-1A12-1W	. RESISTOR, FIXED, FI LM.	1
11	PBFZZ	98869	H3318	. RESISTOR, FIXED, WI RE RPLS--PN BH1771.	1
12	PBFZZ	98689	BH1773	. RESISTOR, FIXED, WI RE	1
13	PBFZZ	81073	71BY23196-1-2N	. SWITCH, ROTARY	1
14	XDFZZ	91637	RS-1A22-1W	. RESISTOR, FIXED, FI LM.	1
15	XDFZZ	91637	RS-1A35-1W	. RESISTOR, FIXED, FI LM	1
16	XDFZZ	91637	RS-1A30-1W	. RESISTOR, FIXED, FI LM	1
17	XDFZZ	91637	RS-1A45-1W	. RESISTOR, FIXED, FI LM.	1
18	PBFZZ	98869	C5225	. SWITCH, ROTARY	1
19	PBFZZ	98869	BH275	. RESISTOR, FIXED, WI RE.	1
20	PBFZZ	98869	H3493	. RESISTOR, FIXED, WI RE	1
21	PBFZZ	98869	BH274	. RESISTOR, FIXED, WI RE	1
22	PBFZZ	06928	A402-010	. CONNECTOR, RECEPTCL.	1
23	PBFZZ	96906	MS51957-5	. SCREW, MACHINE	2
24	PBFZZ	81349	RNC55K6811FS	. RESISTORS, FIXED, FI LM.	1
25	PBFZZ	91349	RNC55H1000FS	. RESISTOR, FIXED, FI LM.	1
26	XDFZZ	91637	RS-1A15-1W	. RESISTOR, FIXED, FI LM.	1
27	XDFZZ	98869	BH16367	. PRINTED CIRCUIT BOA	1

END OF FIGURE




Figure 10. H122 Accessory Case

(1) ITEM NO	(2) SMR CODE	(3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODE S(UOC)	(6) QTY
GROUP 03. TRIMMER ASSY, CASE AND COMPONENTS.					
FIGURE 10. H122 ACCESSORY CASE					
1	XDFFF	98869	H122	CASE ACCESSORY.....	1
1A	PBFZZ	98869	BH585	.HANDLE, CARRYING CAS.....	1
2	PBFZZ	96906	MS35426-15	.NUT, PLAIN, WING.....	2
3	PBFZZ	96906	MS35308-341	.BOLT, MACHINE.....	2
4	PBFZZ	98869	BH727	.SOCKET, PIVOT.....	2
5	PBFZZ	98869	BH796	.STOP, ARM, ASSEMBLY.....	1
6	PBFZZ	98869	BH723	.SPACER, SLEEVE.....	1
7	PBFZZ	98869	BH437	.STOP ARM SUPPORT.....	1
8	PBFZZ	96906	MS51958-61	.SCREW, MACHINE.....	1
9	PBFZZ	98869	BH834-1	.MOUNT, SUPPORT.....	1
10	PBFZZ	96906	MS51957-63	.SCREW, MACHINE.....	8
11	PBFZZ	09728	BH834-2	.PLATE, MENDING.....	1
12	PBFZZ	96906	MS51957-27	.SCREW, MACHINE.....	4
13	PBFZZ	98869	BH3506	.WHEEL, SOLID RUBBER.....	2
14	PBFZZ	79136	5100-62	.RING, RETAINING.....	2
15	PBFZZ	98869	BH835	.MOUNT, WHEEL.....	2
16	PBFZZ	96906	MS51957-65	.SCREW, MACHINE.....	8
17	PBFZZ	98869	BH6554	.PROBE HOLDER.....	1
18	PBFZZ	98869	BH6551	.RACK, TEST PROBES.....	1

END OF FIGURE




Figure 11. Trimmer Assembly (Sheet 2 of 2)

SECTION II

TM 55-4920-401-13&P

(1) ITEM NO	(2) SMR CODE	(3) (3) FSCM	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES(UOC)	(6) QTY
FIGURE 11. TRIMMER ASSEMBLY					
	PBFFF	98869	BH15195A8	TRIMMER ASSEMBLY.....	1
1	XDFZZ	97539	SEELSKREWR10-32X 1-2	.SCREW, MACHINE.....	8
2	PBFDD	98869	BH16365-1	.CIRCUIT CARD ASSEMB --CALIBRATOR SEE FIGURE 7 FOR BREAKDOWN.....	1
3	PBFDD	98869	BH15717-1	.CIRCUIT CARD ASSEMB --TACHOMETER SEE FIGURE 6 FOR BREAKDOWN.....	1
4	PBFDD	98869	BH15715-1	.CIRCUIT CARD ASSEMB --TEMPERATURE SEE FIGURE 5 FOR BREAKDOWN.....	1
5	PBFDD	98869	BH16358-2	.PRINTED CIRCUIT BOA --DISPLAY SEE FIGURE 4 FOR BREAKDOWN.....	1
6	PBFZZ	98869	BH15814	.HOLDER, CIRCUIT CARD.....	1
8	XDFDD	98869	BH15179-2	.CASE, INSTRUMENT.....	1
9	PBFZZ	98869	BH16833	..GASKET.....	1
10	XDFZZ	98869	BH472-2	..NAMEPLATE.....	1
11	PBFZZ	96906	MS21044C08	..NUT, SELF-LOCKING, HE.....	4
12	PBFZZ	70485	165A	..BUMPER, RUBBER.....	4
13	PBFFF	98869	BH15813-1	.WIRING HARNESS.....	1
13A	XDFZZ	96906	MS35206-208	..SCREW, MACHINE.....	4
13B	PBFZZ	96906	MS35275-206	..SCREW, MACHINE.....	3
14	PBFZZ	06928	C406-021	..CONNECTOR, RECEPTACLE.....	2
14A	PBFZZ	04157	NMP-COCO-F	..CONNECTOR, PLUG, ELEC.....	1
15	PBOZZ	21604	SS70BL2BLK	.KNOB.....	3
16	PBFDD	98869	BH15720-1	.CIRCUIT CARD ASSEMB SWITCH-POWER SEE FIG. 3 FOR BRKDN.....	1
17	PBFZZ	81349	M5423-09-02	.BOOT, DUST AND MOIST.....	3
18	PBFZZ	96906	MS51957-2	.SCREW, MACHINE.....	6
19	PBFZZ	97539	SEELSKREWR4-40-3 -8	.SCREW, MACHINE.....	6
20	PBFZZ	98869	BH15719-2	.PRINTED CIRCUIT BOA --MOTHER.....	1
21	PBFZZ	96906	MS51957-28	.SCREW, MACHINE.....	4
23	PBFZZ	97539	SEELSKREWR8-32X5 -8	.SCREW, MACHINE.....	2
24	PBFZZ	97539	SEELSKREWR8-32X1 -2	.SCREW, MACHINE.....	2
25	XDFZZ	82647	D6756-1-1-2	.CIRCUIT BREAKER.....	1
26	XDFZZ	83330	1415-4	.TERMINAL LUG.....	1
27	PBFZZ	96906	MS51957-14	.SCREW, MACHINE.....	2
28	PBFZZ	98869	BH15559-1	.BEZEL, INSTRUMENT MO.....	1
29	PBFZZ	98869	BH15561	.WINDOW, OBSERVATION.....	1
30	PBFZZ	98869	BH15560	.GASKET.....	1
30A	PBFZZ	97539	SEELSKREWR4-40X7 -16	.SCREW, MACHINE.....	2
39	PBFZZ	98869	BH15712	.TRANSFORMER, POWER.....	1
40	PBFZZ	96906	MS21044N3	.NUT, SELF-LOCKING, HE.....	4
41	PBFZZ	96906	MS35059-24	.SWITCH, TOGGLE.....	1
42	PBFZZ	97539	N-9030-B-1/4	.BOOT, DUST AND MOIST.....	1
43	PBOZZ	72619	250-1471-500	.LENS, LIGHT.....	1
44	PBOZZ	72619	507-5824-0747-60	.LAMP, CARTRIDGE.....	1

0

SECTION II			TM 55-4920-401-13&P			(6)
(1)	(2)	(3)	(4)	(5)		(6)
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)		QTY
45	PBFZZ	72619	250-8458-33-504	. LIGHT, I NDI CATOR		1
46	PBOZZ	72619	250-1473-500	. LENS, LI GHT		1
47	PBOZZ	72619	507-5821-0747-60	. LAMP, CARTRI DGE		1
			0			
48	PBFZZ	72619	250-8458-33-504	. LI GHT, I NDI CATOR		1
50	PBFZZ	98869	BH17956-1	. STRAP, RETAI NI NG		1
51	PBFZZ	96906	MS51957-43	. SCREW, MACHI NE		1
51A	PBFZZ	96906	MS35333-72	. WASHER, LOCK		1
52	PBFZZ	98869	BH17957	. POST, ELECTRI CAL-MEC.		1
53	PBFZZ	97539	SELLSKREWR8-32X1	. SCREW, MACHI NE		1
			-2			
58	PBFZZ	98869	H5600P-56	. RESI STOR, VARI ABLE		1
59	PBFZZ	98869	BH6522	. GASKET		1
61	PBFZZ	97539	SEELSKREWR4-40-5	. SCREW, MACHI NE		2
			-16			
62	PBFZZ	21604	SSN-70-2 SHORT B	. KNOB		1
			LACK			
62A	PBOZZ	21604	SSN70-2	. KNOB		1
63	PBFZZ	12697	53C3-50K	. RESI STOR, VARI ABLE, N		1
64	PBFZZ	97539	N9030-1-4	. BOOT, DUST AND MOI ST		1
65	PBFZZ	98869	BH18690-2	. RESI STOR, VARI ABLE, W.		1
66	PBFZZ	94603	CA10006	. HOOK, POTENTI OMETER		1
69	PBFZZ	98869	BH18690-3	. RESI STOR, VARI ABLE, W.		1
70	PBFZZ	98869	RH24765-1	. HOOK, POTENTI OMETER		1
71	PBFZZ	81073	30-252 RED	. SWI TCH, PUSH		1
72	PBFZZ	96906	MS25043-12DA	. COVER, ELECTRI CAL CO.		1
73	PBFZZ	98869	BH9020P	. CONNECTOR, RECEPTACL.		1
74	PBFZZ	24454	B74143PS8	. GASKET		1
75	XDFZZ	97539	SEELSKREWS440X1-	. SCREW, MACHI NE		4
			2			
76	PBFZZ	96906	MS25043-14D	. COVER, ELECTRI CAL CO.		1
77	PBFZZ	98869	BH9140S	. CONNECTOR, RECEPTACL.		1
78	PBFZZ	18876	8528783	. GASKET		1
79	XDFZZ	97539	SEELSKREWS440X1-	. SCREW, MACHI NE		4
			2			
80	PBFZZ	96906	MS3181-14C	. COVER, ELECTRI CAL CO.		1
81	PBFZZ	98869	BH9385P	. CONNECTOR, RECEPTACL.		1
82	PBFZZ	18876	8528783	. GASKET		1
83	XDFZZ	97539	SEELSKREWS440X1-	. SCREW, MACHI NE		4
			2			
84	PBFZZ	71279	1291-1	. HANDLE, BOW.		2
85	PBFZZ	96906	MS51959-45	. SCREW, MACHI NE		4
86	XDFZZ	98869	BH6555	. WI NDOW, OBSERVATI ON.		1
88	XDFZZ	98869	BH15807A	. DECK		1
89	PBFZZ	96906	MS51957-28	. SCREW, MACHI NE		4
90	PBFZZ	98869	BH16295	. RETAI NER, PRI NTED CI.		2

END OF FIGURE

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO	(b) TEM NO	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	QTY INC IN UNIT
						GROUP 04 PROBE ASSY, CASE		
12		PBFFF	4920-01-086-1465	58869	BH15154A-4	PROBECONTROLLERASSEMBLY.....	EA	1
12		PBOFF	4920-01-086-1465	58869	BH158C2	.CABLEASSEMBLY,SPEC--PRCBECONTROLLER.....	EA	1
12	1	PBFZZ	5305-00-054-5651	59506	MS51557-17	..SCREW,MACHINE.....	EA	6
12	2	PBFZZ	5950-01-047-1673	58869	BH15712	..TRANSFORMER,POWER,F.....	EA	1
12	3	XDDZ	5935-01-022-5628	69528	C406-C21	..CONNECTOR.....	EA	2
12	4	XDDZZ		69528	C404-C10	..CONNECTOR.....	EA	1
12	5	PACZZ	5540-00-107-1461	64618	34567	..TERMINAL,LUC.....	EA	4
12	6	XDCZZ	5540-00-660-3633	64618	35316	..TERMINAL LUG.....	EA	2
12	7	PBOZZ	5355-00-403-1550	21604	SS70BL2BLK	..KNOB.....	EA	2
12	8	PBFFF	4920-01-020-5561	58869	BH158C1-1	.CIRCUIT CARD ASSEMB -- PROBE CONTROL-FUNCTIONAL SWITCH SEE FIGURE 8 FOR BREAKDOWN.....	EA	1
12	9	PBFZZ	5930-00-823-0462	57539	N9030-1-4	.BOOT,DUSTANDMOIST.....	EA	2
12	10	PBFZZ	5310-00-637-4885	81073	12C10E7	.WASHER,KEY.....	EA	2
12	11	PBFZZ	5305-00-054-5625	59506	MS51557-5	.SCREW,MACHINE.....	EA	2
12	12	PBOZZ	5355-00-403-1550	21604	SS70BL2BLK	..KNOB.....	EA	2
12	13	PBFFF	4920-01-020-0535	58869	BH16367-3	.CIRCUIT CARD ASSEMB -- RESISTANCE-INSULATION SEE FIGURE 9 FOR BREAKDOWN.....	EA	1
12	14	PBFZZ	5930-00-823-0462	57539	N9030-1-4	.BOOT,DUSTANDMOIST.....	EA	2
12	15	PBFZZ	5310-00-637-4885	81073	12C10E7	.WASHER,KEY.....	EA	2
12	16	PBOZZ	6210-00-470-7602	72619	250-1471-500	.LENS,LIGHT.....	EA	1
12	17	PBOZZ	6240-00-924-6438	72619	507-5824-0747-610	.LAMP,CARTRIDGE.....	EA	1
12	18	PBFZZ	6210-00-244-1994	72619	250-8758-33-504	.LIGHT,INDICATOR.....	EA	1
12	19	PBOZZ	5355-00-403-6496	21604	SSA70-2BLK	..KNOB.....	EA	1
12	20	PBFZZ	5905-01-021-6166	80254	3540-5-1-203	.RESISTOR,VARIABLE,H.....	EA	1
12	21	PBFZZ	5930-00-823-0482	57539	N9030-1-4	.BOOT,DUSTANDMOIST.....	EA	1
12	22	PBFZZ	5930-00-655-1582	59506	MS35059-23	.SWITCH,TOGGLE.....	EA	1
12	23	PBFZZ		57539	N-9030-B-1/4	.BOOT,DUSTANDMOIST.....	EA	1
12	24	PBOZZ	5355-00-403-6496	21604	SSA70-2BLK	..KNOB.....	EA	1
12	25	PBFZZ	5905-01-022-0134	80254	3540-5-1-101	.RESISTOR,VARIABLE,W.....	EA	1
12	26	PBFZZ	5930-00-823-0482	57539	N9030-1-4	.BOOT,DUSTANDMOIST.....	EA	1
12	27	PBFZZ	5961-00-088-8782	02508	1N5059	.SEMICONDUCTOR DEVICE.....	EA	1
12	28	PBFZZ	5945-01-021-7183	77342	KR-7826	.RELAY,ARMATURE.....	EA	1
12	29	PBFZZ	5310-00-081-8087	59506	MS20365-632A	.NUT,SELF-LOCKING,HE.....	EA	3
12	29A	PBFZZ	5940-00-816-6103	59506	MS77066-2	.TERMINAL LUG.....	EA	1
12	30	PBFZZ	5925-00-283-6513	82647	PDA20	.CIRCUITBREAKER.....	EA	1
12	31	PBFZZ	5305-00-054-6672	59506	MS51557-47	.SCREW,MACHINE.....	EA	2
12	32	PBFZZ	4920-01-087-5155	58869	BH15180	.BRACKET,MOUNTING.....	EA	1
12	33	PBFZZ	5305-00-758-0882	57539	SEEL SCREW6-32-2	.SCREW,MACHINE.....	EA	2
12	33A	PBFZZ	5310-00-081-6687	59506	MS20365-632A	.NUT,SELF-LOCKING,HE.....	EA	2

(1) ILLUSTRATION (A) FIG NO	(2) ITEM NO	(3) SMR CODE	(4) NATIONAL STOCK NUMBER	TM55-4920-401-13&P		(6) DESCRIPTION	(7) USABLE ON CODE	(8) QTY INC IN UNIT
				(5) FSCM	PART NUMBER			
12	36	PBFZZ	4920-00-877-3948	98869	BH2825	.METER, RESISTANCE	EA	1
12	35	PBFZZ	5305-00-964-6032	97539	SEELSKREWS440X1-2	.SCREW, MACHINE	EA	3
12	36	PBFZZ	5330-00-914-1916	98869	BH581-1	.GASKET	EA	1
12	37	PBFZZ	6625-00-948-1646	98869	BH6510	.METER, INSULATION	EA	1
12	38	PBFZZ	5305-00-964-6032	97539	SEELSKREWS440X1-2	.SCREW, MACHINE	EA	3
12	39	PBFZZ	5330-00-914-1916	98869	BH581-1	.GASKET	EA	1
12	40	PBFZZ	5935-00-228-4395	98869	BH9020P	.CONNECTOR, RECEPTACL	EA	1
12	41	PBFZZ	5935-00-238-6419	96906	MS25043-12C	.COVER, ELETRICAL	EA	1
12	42	PBFZZ	5305-00-964-6032	97539	SEELSKREWS440X1-2	.SCREW, MACHINE	EA	4
12	42A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA	4
12	43	PBFZZ	5330-00-576-9890	77820	10-36675-12	.GASKET	EA	1
12	44	PBFZZ	5935-00-763-5629	98869	BH9039S	.CONNECTOR, PLUG, ELEC	EA	1
12	45	XDFZZ	5935-00-577-0091	96906	MS25043-20C	.COVER, ELECTRICAL CO	EA	1
12	46	PBFZZ	5305-00-964-6032	97539	SEELSKREWS440X1-2	.SCREW, MACHINE	EA	4
12	46A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA	4
12	47	PBFZZ	5330-00-599-9126	77820	10-36675-20	.GASKET	EA	1
12	48	PBFZZ	5935-00-925-9061	98869	BH9030S	.CONNECTOR, ELECTRICA	EA	1
12	49	PBFZZ	5935-00-137-4669	96906	MS35043-14D	.COVER, ELECTRICAL CO	EA	1
12	50	PBFZZ	5305-00-964-6032	97539	SEELSKREWS440X1-2	.SCREW, MACHINE	EA	4
12	50A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA	4
12	51	PBFZZ	5330-00-355-8976	06840	36675-14	.GASKET	EA	1
12	52	PBOZZ	5920-00-936-1649	71400	RAW20	.FUSE, CATRIDGE	EA	1
12	53	PBFZZ	5920-00-225-0420	71400	FHN23W	.FUSEHOLDER, EXTRACTO	EA	1
12	54	PBFZZ	5305-00-798-0862	97539	SEELSKREWR6-32-1-2	.SCREW, MACHINE	EA	2
12	55	PBFZZ	5935-00-763-5630	98869	BH9033F	.CONNECTOR, PLUG, ELEC	EA	1
12	56	PBFZZ	5935-00-137-4671	96906	MS25043-16D	.COVER, ELECTRICAL CO	EA	1
12	57	PBFZZ	5305-00-964-6032	97539	SEELSKREWS440X1-2	.SCREW, MACHINE	EA	4
12	57A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA	4
12	58	PBFZZ	5330-00-292-3958	77820	10-36675-16	.GASKET	EA	1
12	59	PBFZZ	5935-01-021-5493	98869	BH9385S	.CONNECTOR, RECEPTACL	EA	1
12	60	PBFZZ	5935-00-899-9361	96906	MS3181-14C	.COVER, ELECTRICAL CO	EA	1
12	61	PBFZZ	5305-00-964-6032	97539	SEELSKREWS440X1-2	.SCREW, MACHINE	EA	4
12	61A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA	4
12	62	PBFZZ	5330-00-355-8976	06840	36675-14	.GASKET	EA	1
12	63	PBFZZ	5340-01-032-8106	98869	BH799	.STOP ARM SUPPORT	EA	1
12	64	PBFZZ	5305-00-071-1320	96906	MS51960-63	.SCREW, MACHINE	EA	2

CHANGE 1

C-42




Figure 12. Probe Controller Assembly

SECTION II			TM 55-4920-401-13&P	(5)	(6)
(1)	(2)	(3)	(4)		
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
GROUP 04. PROBE ASSY, CASE					
FIGURE 12. PROBE CONTROLLER ASSY					
	PBFFD	98869	BH15194A-4	PROBE CONTROLLER ASSEMBLY.....	1
	PBOFF	98869	BH15802	.CABLE,SPECIAL --PROBE CONTROLLER..	1
1	PBFZZ	96906	MS51957-17	..SCREW,MACHINE.....	6
2	XDFZZ	98869	BH15713	..TRANSFORMER,POWER,F.....	1
3	XDDZZ	06928	C406-021	..CONNECTOR,RECEPTACL.....	2
4	XDDZZ	06928	C404-010	..CONNECTOR.....	1
5	PADZZ	96906	MS20659-104	..TERMINAL,LUG.....	4
6	XDDZZ	04618	35316	..TERMINAL LUG.....	2
7	PBOZZ	21604	SS70BL2BLK	.KNOB.....	2
8	PBFFF	98869	BH15801-1	.CIRCUIT CARD ASSEMB --PROBE CONTROL-FUNCTION SWITCH SEE FIGURE 8 FOR BREAKDOWN N.....	1
9	PBFZZ	81349	M5423-09-02	.BOOT,DUST AND MOIST.....	2
10	PBFZZ	81073	12C1087	.WASHER,KEY.....	2
11	PBFZZ	96906	MS51957-5	.SCREW,MACHINE.....	2
12	PBOZZ	21604	SS70BL2BLK	.KNOB.....	2
13	PBFFF	98869	BH16367-3	.CIRCUIT CARD ASSEMB RESISTANCE- INSULATION SEE FIG. 9 FOR BRKDN...	1
14	PBFZZ	81349	M5423-09-02	.BOOT,DUST AND MOIST.....	2
15	PBFZZ	81073	12C1087	.WASHER,KEY.....	2
16	PBDZZ	72619	250-1471-500	.LENS,LIGHT.....	1
17	PBOZZ	72619	507-5824-0747-60 0	.LAMP,CARTRIDGE.....	1
18	PBFZZ	72619	250-8758-33-504	.LIGHT,INDICATOR.....	1
19	PBOZZ	21604	SSN70-2	.KNOB.....	1
20	PBFZZ	80294	3540-S-1-203	.RESISTOR,VARIABLE,W.....	1
21	PBFZZ	97539	N9030-1-4	.BOOT,DUST AND MOIST.....	1
22	PBFZZ	96906	MS35059-23	.SWITCH,TOGGLE.....	1
23	PBFZZ	81349	M5423-09-02	.BOOT,DUST AND MOIST.....	1
24	PBOZZ	21604	SSN70-2	.KNOB.....	1
25	PBFZZ	80294	3540-S-1-101	.RESISTOR,VARIABLE,W.....	1
26	PBFZZ	81349	M5423-09-02	.BOOT,DUST AND MOIST.....	1
27	PBFZZ	80131	1N5059	.SEMICONDUCTOR DEVIC.....	1
28	PBFZZ	98869	C5218	.RELAY,ELECTROMAGNET.....	1
29	PBFZZ	96906	MS21044N06	.NUT,SELF-LOCKING,HE.....	3
29A	PBFZZ	96906	MS77066-2	.TERMINAL,LUG.....	1
30	PBFZZ	99832	101197	.CIRCUIT BREAKER.....	1
31	PBFZZ	96906	MS51957-47	.SCREW,MACHINE.....	2
32	PBFZZ	98869	BH15180	.BRACKET,MOUNTING.....	1
33	PBFZZ	97539	SEELSKREWR6-32-1 -2	.SCREW,MACHINE.....	2
33A	PBFZZ	96906	MS21044N06	.NUT,SELF-LOCKING,HE.....	2
34	PBFZZ	98869	BH2825	.METER,RESISTANCE.....	1
35	XDFZZ	97539	SEELSKREWS440X1- 2	.SCREW,MACHINE.....	3
36	PBFZZ	98869	BH581-1	.GASKET.....	1
37	PBFZZ	98869	BH6510	.METER,INSULATION.....	1
38	XDFZZ	97539	SEELSKREWS440X1-	.SCREW,MACHINE.....	3

SECTION II

TM 55-4920-401-13&P

(1) ITEM NO	(2) SMR CODE	(3) (3) FSCM	(4) (4) PART NUMBER	(5) (5) DESCRIPTION AND USABLE ON CODES(UOC)	(6) (6) QTY
			2		
39	PBFZZ	98869	BH581-1	.GASKET.....	1
40	PBFZZ	98869	BH9020P	.CONNECTOR,RECEPTACL.....	1
41	PBFZZ	96906	MS25043-12DA	.COVER,ELECTRICAL CO.....	1
42	XDFZZ	97539	SEELSKREWS440X1-	.SCREW,MACHINE.....	4
			2		
42A	PBFZZ	96906	MS21044N04	.NUT,SELF-LOCKING,HE.....	4
43	PBFZZ	24454	B74143PS8	.GASKET.....	1
44	PBFZZ	98869	BH9039S	.CONNECTOR,PLUG,ELEC.....	1
45	XDFZZ	96906	MS25043-20C	.COVER,ELECTRICAL CO.....	1
46	XDFZZ	97539	SEELSKREWS440X1-	.SCREW,MACHINE.....	4
			2		
46A	PBFZZ	96906	MS21044N04	.NUT,SELF-LOCKING,HE.....	4
47	PBFZZ	77820	10-36675-20	.GASKET.....	1
48	XDDZZ	98869	BH9030S	.CONNECTOR,ELECTRICAL.....	1
49	PBFZZ	96906	MS25043-14D	.COVER,ELECTRICAL CO.....	1
50	XDFZZ	97539	SEELSKREWS440X1-	.SCREW,MACHINE.....	4
			2		
50A	PBFZZ	96906	MS21044N04	.NUT,SELF-LOCKING,HE.....	4
51	PBFZZ	18876	8528783	.GASKET.....	1
52	PBOZZ	71400	KAW20	.FUSE,CARTRIDGE.....	1
53	XDFZZ	71400	FHN23W	.FUSEHOLDER,EXTRACTO.....	1
54	PBFZZ	97539	SEELSKREWR6-32-1	.SCREW,MACHINE.....	2
			-2		
55	PBFZZ	98869	BH9033P	.CONNECTOR,RECEPTACL.....	1
56	PBFZZ	96906	MS25043-16D	.COVER,ELECTRICAL CO.....	1
57	XDFZZ	97539	SEELSKREWS440X1-	.SCREW,MACHINE.....	4
			2		
57A	PBFZZ	96906	MS21044N04	.NUT,SELF-LOCKING,HE.....	4
58	PBFZZ	77820	10-36675-16	.GASKET.....	1
59	PBFZZ	98869	BH9385S	.CONNECTOR,RECEPTACL.....	1
60	PBFZZ	96906	MS3181-14C	.COVER,ELECTRICAL CO.....	1
61	XDFZZ	97539	SEELSKREWS440X1-	.SCREW,MACHINE.....	4
			2		
61A	PBFZZ	96906	MS21044N04	.NUT,SELF-LOCKING,HE.....	4
62	PBFZZ	18876	8528783	.GASKET.....	1
63	PBFZZ	98869	BH799	.STOP ARM SUPPORT.....	1
64	PBFZZ	96906	MS51960-63	.SCREW,MACHINE.....	2
65	PBFZZ	03508	C45H	.SEMICONDUCTOR DEVIC.....	2
66	XDFZZ	98869	BH15189A-2	.DECK.....	1

END OF FIGURE

(1) ILLUSTRATION (A) FIG NO	(2) (B) ITEM NO	(3) SMR CODE	TM55-4920-401-13&P		(6) DESCRIPTION	(7) USABLE ON CODE	(8) QTY INC IN UNIT
			(4) NATIONAL STOCK NUMBER	(5) FSCM PART NUMBER			
13		PBFFF	4920-01-086-1476	98869	BH15835-2	CASE, CARRYING INSTR	EA 1
13	1	XDFZZ		98869	BH14548A-1	.LID	EA 1
13	2	PBFZZ	5340-01-021-9621	96906	MS20253-2-1812	.ROD, STRAIGHT, HEADLE	EA 1
13	3	PBFZZ	5999-00-151-4035	75915	123002	.CLIP, ELECTRICAL	EA 2
13	4	PBFZZ	5305-00-051-6719		SEELSKREWR4-40-5 -16	.SCREW, MACHINE	EA 2
13	14A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA 2
13	5	PBFZZ	5920-01-016-7030	98869	BH15827	.FUSEHOLDER, BLOCK	EA 1
13	6	PAOZZ	5920-00-936-1649	71400	KAW20	.FUSE, CARTRIDGE	EA 2
13	7	PBFZZ	5305-00-054-5655	96906	MS51957-21	.SCREW, MACHINE	EA 2
13	7A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA 2
13	8	PBFZZ	5999-01-016-2711	98869	BH15826	.HEAT SINK, ELECTRICA	EA 2
13	9	PBFZZ	5970-01-020-9631	98869	BH17427	.INSULATOR, PLATE	EA 4
13	10	PBFZZ	5905-00-563-1595	81349	RLR0704702GR	.NUT, SELF-LOCKING, HE	EA 4
13	10A	PBFZZ	5310-00-840-8342	83330	3052	.WASHER, FLAT	EA 4
13	11	PBFZZ	4920-01-086-1466	98869	BH15524	.MOLDING, METAL	EA 2
13	12	PBFZZ	5330-01-104-5959	98869	BH15525	.BUMBER, RUBBER	EA 2
13	13	PBFZZ	5305-00-054-5655	96906	MS51957-21	.SCREW, MACHINE	EA 8
13	13A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA 8
13	14	PBFZZ	5340-01-021-4103	70485	21	.BUMPER, RUBBER	EA 4
13	15	PBFZZ	5305-00-993-9268		SEELSKREWR4-40X3 -4	.SCREW, MACHINE	EA 4
13	15A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA 4
13	16	PBFZZ	5340-00-956-5067	78046	R116	.BUMPER, SPECAIL	EA 6
13	17	PBFZZ	5305-00-855-2996		SEELSKREWR4-40-3 -8	.SCREW, MACHINE	EA 6
13	17A	PBFZZ	5310-00-088-0551	96906	MS20365-440A	.NUT, SELF-LOCKING, HE	EA 6
13	17B	PBFZZ	5310-00-950-1310	96906	MS27183-4	.WASHER, FLAT	EA 6
13	18	PBFZZ	5330-01-021-6894	98869	BH15197	.GASKET	EA 1
13	19	XDFZZ		98869	BH15834	.CASE	EA 1

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
5910-00-007-2001	5	35	5905-00-121-9919	8	35
5905-00-007-3808	8	47	5905-00-126-6703	5	26
5910-00-007-3974	8	24	5905-00-126-6703	6	54
5962-00-008-2701	7	47	5905-00-126-6703	8	45
5910-00-010-8240	6	14	5935-00-137-4669	11	76
5910-00-010-8240	8	31	5935-00-137-4669	12	49
5910-00-010-8666	5	5	5935-00-137-4671	12	56
5910-00-010-8666	6	4	5910-00-144-4381	7	14
5910-00-010-8666	6	28	5910-00-144-4383	3	49
5910-00-010-8666	7	9	5910-00-144-4383	5	64
5910-00-010-8718	4	3	5910-00-144-4383	6	12
5910-00-010-8718	7	34	5910-00-144-4383	7	3
5305-00-050-9229	10	10	5999-00-151-4035	13	3
5305-00-050-9231	10	16	5961-00-156-0570	3	6
5305-00-051-6719	11	61	5962-00-162-7505	4	1
5305-00-051-6719	13	4	5330-00-165-1905	11	59
5305-00-054-5636	11	18	5905-00-168-9287	5	33
5305-00-054-5637	3	55	5905-00-168-9287	6	38
5305-00-054-5639	9	23	5905-00-168-9287	7	20
5305-00-054-5639	12	11	5905-00-168-9287	8	41
5305-00-054-5648	11	27	5962-00-169-4728	7	35
5305-00-054-5651	12	1	5962-00-169-4730	7	45
5305-00-054-5655	13	7	5905-00-174-0346	6	37
5305-00-054-5655	13	13	5905-00-184-7705	3	35
5305-00-054-6651	10	12	5905-00-184-7705	4	4
5305-00-054-6652	11	21	5905-00-184-7705	5	7
5305-00-054-6668	11	51	5905-00-184-7705	6	1
5305-00-054-6672	12	31	5340-00-186-9481	11	84
5961-00-059-2904	8	20	5905-00-189-2380	5	32
5305-00-059-3657	1	12	5905-00-189-2380	6	31
5305-00-059-3657	10	8	5905-00-189-2380	8	40
5305-00-059-5433	3	2	5910-00-192-7180	3	32
5961-00-062-3133	8	29	5962-00-197-3430	5	53
5310-00-063-6717	10	2	5962-00-197-3430	6	51
5961-00-068-6441	8	19	4920-00-204-6457	2	8
5305-00-071-1320	12	64	5905-00-208-4293	5	55
5306-00-080-0680	10	3	5905-00-208-4293	6	22
5310-00-081-8087	12	29	5910-00-211-1976	5	56
5310-00-081-8087	12	33A	5910-00-211-1976	6	18
5905-00-087-0545	8	16	5910-00-211-1976	7	15
5310-00-088-0551	12	42A	5920-00-225-0420	12	53
5310-00-088-0551	12	46A	5935-00-228-4395	11	73
5310-00-088-0551	12	50A	5935-00-228-4395	12	40
5310-00-088-0551	12	57A	5905-00-229-7381	6	43
5310-00-088-0551	12	61A	5905-00-229-7391	5	48
5310-00-088-0551	13	4A	5905-00-229-7391	6	45
5310-00-088-0551	13	7A	5905-00-229-7391	7	29
5310-00-088-0551	13	13A	5905-00-236-6632	3	14
5310-00-088-0551	13	15A	5935-00-238-6419	11	72
5310-00-088-0551	13	17A	5935-00-238-6419	12	41
5961-00-088-8792	3	9	5905-00-240-2726	3	13
5961-00-088-8792	7	42	5905-00-240-2728	3	44
5961-00-088-8792	8	17	5905-00-240-2728	5	51
5961-00-088-8792	12	27	5905-00-240-2728	6	29
5910-00-098-8551	3	8	5905-00-240-2728	7	11
5910-00-098-8551	7	43	5905-00-240-2728	8	13
5910-00-098-8551	8	22	5905-00-240-2734	3	41
5905-00-099-9685	7	30	5905-00-240-2736	5	15
5905-00-099-9690	5	19	5905-00-240-2745	5	37
5905-00-101-1838	8	38	5905-00-240-2745	6	49
5905-00-104-8334	8	21	5905-00-240-2746	8	9
5910-00-105-1924	8	28	5905-00-240-2749	3	58
5961-00-106-5183	3	50	5905-00-240-7950	3	5
5940-00-107-1481	12	5	5905-00-240-7954	7	36
5905-00-107-4872	5	34	5905-00-240-7954	8	18
5962-00-107-4893	5	38	5905-00-240-7958	3	48
5962-00-107-4893	6	36	5905-00-240-7979	3	19
5910-00-111-4811	3	43	CHANGE 1	5	29
5910-00-111-4811	8	10	5905-00-240-7979	6	13
5910-00-113-5276	5	44	5905-00-240-7979	8	46
5910-00-114-5268	3	4	6210-00-244-1994	11	45
5905-00-114-5407	3	45	6210-00-244-1994	11	48
5962-00-118-3868	5	63	6210-00-244-1994	12	18
5962-00-118-3868	6	59	5305-00-253-5603	1	7
5962-00-118-3871	5	61	5305-00-253-5603	1	9
5962-00-118-3871	6	60	5905-00-258-5413	5	3
5961-00-118-4775	5	66	5905-00-264-4148	3	52
5961-00-118-4775	6	9	5340-00-266-0754	11	12
5961-00-118-4775	8	49	5905-00-273-9829	5	36
5905-00-121-9919	7	46	5905-00-273-9829	6	10




Figure 13. Instrument Case Assembly

SECTION II			TM 55-4920-401-13&P			
(1)	(2)	(3)	(4)	(5)	(6)	
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON CODE S(UOC)	QTY	
FIGURE 13. INSTRUMENT CASE ASSEMBLY						
	PBFFD	98869	BH15835-2	CASE, CARRYING, INSTR.....	1	
1	XDFZZ	98869	BH14548A-1	.LID.....	1	
2	XDFZZ	96906	MS20253-2-2400	.ROD, STRAIGHT, HEADLE.....	1	
3	PBFZA	75915	123002	.CLIP, ELECTRICAL.....	2	
4	PBFZZ	97539	SEELSKREWR4-40-5 -16	.SCREW, MACHINE.....	2	
4A	PBFZZ	96906	MS21044N04	.NUT, SELF-LOCKING, HE.....	2	
5	PBFZZ	98869	BH15827	.FUSEHOLDER, BLOCK.....	1	
6	PAOZZ	71400	KAW20	.FUSE, CARTRIDGE.....	2	
7	PBFZZ	96906	MS51957-21	.SCREW, MACHINE.....	2	
7A	PBFZZ	96906	MS21044N04	.NUT, SELF-LOCKING, HE.....	2	
8	PBFZZ	98869	BH15826	.HEAT SINK, ELECTRICAL.....	2	
9	PBFZZ	98869	BH17427	.INSULATOR, PLATE.....	4	
10	PBFZZ	96906	MS21044C08	.NUT, SELF-LOCKING, HE.....	4	
10A	PBFZZ	56232	284202	.WASHER, FLAT.....	4	
11	PBFZZ	98869	BH15524	.MOLDING, SPECIAL.....	2	
12	PBFZZ	98869	BH15525	.SEAL, NONMETALLIC ST.....	2	
13	PBFZZ	96906	MS51957-21	.SCREW, MACHINE.....	8	
13A	PBFZZ	96906	MS21044N04	.NUT, SELF-LOCKING, HE.....	8	
14	PBFZZ	70485	21	.BUMPER, RUBBER.....	4	
15	PBFZZ	97539	SEELSKREWR4-40X3 -4	.SCREW, MACHINE.....	4	
15A	PBFZZ	96906	MS21044N04	.NUT, SELF-LOCKING, HE.....	4	
16	PBFZZ	78046	R116	.BUMPER, RUBBER.....	6	
17	PBFZZ	97539	SEELSKREWR4-40-3 -8	.SCREW, MACHINE.....	6	
17A	PBFZZ	96906	MS21044N04	.NUT, SELF-LOCKING, HE.....	6	
17B	PBFZZ	96906	MS27183-4	.WASHER, FLAT.....	6	
18	PBFZZ	98869	BH15197	.GASKET.....	1	
19	XDFZZ	98869	BH15834	.CASE.....	1	

END OF FIGURE

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	NATIONAL STOCK NUMBER INDEX		STOCK NUMBER	FIG.	ITEM
	FIG.	ITEM			
5910-00-007-2001	5	35	5961-00-088-8792	8	17
5910-00-007-3974	8	24		12	27
5910-00-010-8240	6	14	5961-00-098-8032	6	19
	8	31	5905-00-099-9682	5	69
5910-00-010-8666	5	5	5905-00-099-9683	8	39
	6	4	5905-00-099-9690	5	19
	6	28	5905-00-101-1630	9	6
	7	9	5905-00-101-1838	8	38
5910-00-010-8718	4	3	5905-00-104-8334	8	21
	7	34	5940-00-107-1481	12	5
5961-00-039-8814	3	31	5905-00-107-4872	5	34
5305-00-050-9229	10	10	5962-00-107-4893	5	38
5305-00-050-9231	10	16		6	36
5305-00-051-6719	11	61	5910-00-113-5276	5	44
	13	4	5905-00-114-5407	3	45
5305-00-054-5636	11	18	5961-00-118-4775	5	66
5305-00-054-5637	3	55		6	9
5305-00-054-5639	9	23		8	49
	12	11	5905-00-121-9919	7	46
5305-00-054-5648	11	27		8	35
5305-00-054-5651	12	1	5910-00-124-0659	3	43
5305-00-054-5655	13	7		8	10
	13	13	5905-00-126-6703	5	26
5305-00-054-6651	10	12		6	54
5305-00-054-6652	11	21		8	45
	11	89	5935-00-137-4669	11	76
5305-00-054-6668	11	51		12	49
5305-00-054-6672	12	31	5935-00-137-4671	12	56
5961-00-059-2904	8	20	5910-00-144-4381	7	14
5305-00-059-3657	1	12	5910-00-144-4383	3	49
	10	8		5	64
5305-00-059-5433	3	2		6	12
5961-00-062-3133	8	29		7	3
5310-00-063-6717	10	2	5905-00-150-5256	3	47
5305-00-071-1320	12	64		8	2
5306-00-080-0680	10	3	5999-00-151-4035	13	3
5310-00-081-8087	12	29	5330-00-165-1905	11	59
	12	33A	5962-00-167-6330	3	17
5310-00-088-0551	12	42A		5	46
	12	46A		6	25
	12	50A		7	7
	12	57A		8	5
	12	61A	5905-00-168-9287	7	20
	13	4A		8	41
	13	7A	5905-00-174-0346	6	37
	13	13A	5340-00-186-9481	11	84
	13	15A	5905-00-189-2380	5	32
	13	17A		6	31
5961-00-088-8792	3	9		8	40
	7	42	5910-00-192-7180	3	32

SECTION IV

TM 55-4920-401-13&P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
4920-00-204-6457	2	8	5999-00-402-2485	5	40
5905-00-208-4293	5	55		6	36B
	6	22	5355-00-403-1590	11	15
5910-00-211-1976	5	56		12	7
	6	18		12	12
	7	15	5910-00-405-8395	3	38
5935-00-228-4395	11	73		7	31
	12	40	5961-00-405-8427	3	16
5905-00-229-7391	5	48		5	2
	6	45		6	11
	7	29		7	13
5961-00-231-3169	8	23		8	26
5905-00-236-6632	3	14	5910-00-409-3049	5	43
5935-00-238-6419	11	72	5910-00-410-4178	5	50
	12	41		6	47
6685-00-243-9963	1	13	5935-00-411-7929	5	31
6210-00-244-1994	11	45		6	32
	11	48		7	21
	12	18	5905-00-412-1212	5	22
5905-00-258-5413	5	3		6	40
5905-00-264-4148	3	52	5905-00-415-6576	6	65
5340-00-266-0754	11	12	5905-00-422-5217	6	15
5905-00-273-9829	5	36	5905-00-432-0381	8	25
	6	10	5905-00-432-0429	3	15
	7	12	5961-00-450-3040	3	28
5910-00-280-8393	8	14		5	16
5925-00-283-6513	12	30		6	24
5330-00-292-3958	12	58	5905-00-451-7275	9	24
5365-00-298-6563	10	14	5305-00-455-2638	11	23
5905-00-305-6121	6	17	5935-00-456-4719	11	77
5905-00-312-3806	5	41	5961-00-459-2038	3	3
5962-00-318-2223	5	12	5950-00-470-4200	5	65
	6	62		6	63
4920-00-329-8294	2	2		7	1
5930-00-338-2591	2	1	6210-00-470-7602	11	43
5355-00-340-5152	11	62A		12	16
	12	19	5340-00-477-0807	10	11
	12	24	5905-00-479-3990	3	10
5962-00-348-2541	5	13	5910-00-495-0042	8	33
	6	56	5961-00-496-4643	6	34
5330-00-355-8976	11	78	5910-00-499-7435	3	8
	11	82		7	43
	12	51		8	22
	12	62	4920-00-503-1889	2	3
5961-00-365-6459	7	40	4920-00-503-1890	2	4
	8	27	4920-00-504-3192	2	11
5962-00-369-7607	5	63	5905-00-520-9440	4	6
	6	59	4920-00-539-9260	2	10
5962-00-369-7730	5	61	5310-00-543-2739	11	51A
	6	60	4920-00-548-7118	2	5

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
4920-00-549-6093	2	9	5905-00-865-8932	9	2
4920-00-565-3702	10	4	4920-00-877-3948	12	34
4920-00-565-3710	10	5	5961-00-877-5692	12	65
4920-00-565-3714	10	15	5310-00-877-5797	11	40
5330-00-576-9890	11	74	5935-00-899-9361	11	80
	12	43		12	60
4920-00-589-8409	10	13	5961-00-905-8536	5	9
5330-00-599-9126	12	47		6	48
5930-00-636-2821	11	41	5330-00-914-1916	12	36
5310-00-637-4885	12	10		12	39
	12	15	5905-00-921-4020	6	7
5930-00-655-1582	12	22	5905-00-921-4039	8	34
5905-00-660-7834	9	12	5305-00-922-3506	3	25
4920-00-670-9379	2	12	6240-00-924-6435	11	47
4920-00-670-9410	2	13	6240-00-924-6438	11	44
5905-00-689-2926	6	41		12	17
5905-00-721-3732	7	48	5940-00-926-0015	8	48
4920-00-734-8321	1	11	5905-00-926-2826	9	7
	10	7	5961-00-929-4951	6	33
5935-00-763-5629	12	44	5310-00-938-2013	3	26
5935-00-763-5630	12	55	5940-00-939-7842	3	7
5305-00-764-0068	11	85	5305-00-941-6402	11	138
4920-00-767-2672	2	6	6150-00-941-6503	2	7
5305-00-798-0862	1	3	6625-00-948-1646	12	37
	12	33	5310-00-950-1310	13	178
	12	54	4920-00-953-2370	2	14
5940-00-816-6103	12	29A	5305-00-956-4470	11	24
5930-00-823-0482	11	17		11	53
	11	64	5340-00-956-5067	13	16
	12	9	5305-00-965-5944	11	30A
	12	14	5905-00-974-6426	6	43
	12	21	5905-00-978-4272	7	24
	12	23	5310-00-982-6814	11	11
	12	26		13	10
5905-00-828-2416	9	25	5910-00-983-5388	5	54
5910-00-836-6258	3	51		6	52
5310-00-840-8342	13	10A	5935-00-988-6438	7	22
5961-00-842-9864	5	52	5305-00-993-9268	13	15
	6	23	5905-00-994-7137	7	41
	7	16	5961-01-012-9316	3	24
	8	1	5961-01-013-0081	3	29
5961-00-846-9125	3	37	5910-01-014-1212	3	1
	5	14	5905-01-015-5643	9	3
	8	4	5910-01-016-0112	3	53
5305-00-855-2996	11	19	5999-01-016-2711	13	8
	13	17	5961-01-016-2782	8	11
5905-00-865-7319	9	21	5920-01-016-7030	13	5
5905-00-865-7320	9	19	5905-01-017-4859	6	58
5905-00-865-7325	6	42	6210-01-018-7376	11	46
	7	27	4920-01-019-1684	11	90

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5905-01-019-7294	11	65	5999-01-022-2226	6	30
5905-01-019-7295	11	69		7	37
5905-01-019-7689	5	23	5935-01-022-9628	11	14
	7	17	5340-01-023-5121	5	39
	8	42		6	36A
4920-01-020-0538	7		5905-01-027-3536	7	26
	11	2	5905-01-028-7911	11	58
4920-01-020-0539	12	13	5962-01-029-2899	7	47
5970-01-020-0877	3	56	5340-01-030-0892	1	10
4920-01-020-5360	11	29	5905-01-030-9139	6	20
4920-01-020-5560	3		5905-01-030-9147	5	49
	11	16	5905-01-031-0430	7	25
4920-01-020-5561	8		5905-01-031-0432	5	28
	12	8		7	19
4920-01-020-5563	5			8	43
	11	4	5905-01-031-1398	5	4
4920-01-020-5565	6		5905-01-031-1399	7	28
	11	3	5905-01-031-1401	5	68
5970-01-020-9631	13	9		6	8
5340-01-021-4103	13	14	5365-01-032-7243	10	6
5935-01-021-4605	3	20	5340-01-032-8106	12	63
5935-01-021-4609	11	81	5905-01-033-0007	5	59
5930-01-021-4623	3	34		6	55
5935-01-021-5433	3	22	5905-01-034-4262	9	11
	7	18	5905-01-037-3380	5	17
5935-01-021-5435	3	21	5961-01-042-0416	3	50
	5	24	5905-01-053-5788	5	42
5935-01-021-5437	11	14A		6	5
5935-01-021-5489	9	22	5935-01-065-9763	4	5
5935-01-021-5493	12	59		5	11
5930-01-021-5584	3	39		5	62
5930-01-021-5586	3	23		6	61
5930-01-021-5587	8	30	5905-01-084-9946	11	63
5930-01-021-5588	8	32	5905-01-085-1164	3	13
5930-01-021-5589	9	18	4920-01-085-7942	11	20
5930-01-021-5594	11	71	5905-01-085-8973	9	5
5905-01-021-6816	12	20	4920-01-086-1464	10	1A
5905-01-021-6818	5	45	4920-01-086-1465	12	
	6	39	4920-01-086-1466	13	11
5330-01-021-6894	13	18	4920-01-086-1467	11	66
5950-01-021-6985	11	39	4920-01-086-1468	10	9
5950-01-021-6987	8	8	4920-01-086-1469	1	2
5945-01-021-7183	12	28		12	
5910-01-021-7661	3	11	4920-01-086-1470	10	17
5935-01-021-7728	7	23	4920-01-086-1471	10	18
5330-01-021-9220	11	9	4920-01-086-1472	11	6
5905-01-022-0134	12	25	4920-01-086-1473	1	1
5930-01-022-2061	9	13		11	
5999-01-022-2226	4	12	4920-01-086-1474	2	
	5	25	4920-01-086-1476	1	5

SECTION IV

TM 55-4920-401-13&P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

		NATIONAL STOCK NUMBER INDEX			
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
4920-01-086-1476	13				
4920-01-086-1588	11	13			
4920-01-087-9155	12	32			
4920-01-089-4516	4				
	11	5			
5970-01-095-6353	8	12			
6150-01-095-8229	4	13			
6695-01-096-0647	11	28			
5355-01-096-2471	11	62			
5905-01-097-4612	9	20			
5365-01-097-6836	3	54			
5340-01-097-8868	11	50			
5330-01-097-9433	11	30			
5330-01-104-5959	13	12			
5999-01-111-1451	3	27			
5905-01-112-0117	9	8			
5340-01-114-0163	11	52			
5999-01-114-5395	3	36			
5905-01-137-0108	4	11			
5905-01-137-0109	5	30			
	6	50			
	7	44			
5905-01-148-6092	3	5			
5905-01-151-1186	3	35			
	5	7			
	6	1			
	8	3			
5905-01-157-5608	3	19			
	5	29			
	6	13			
	8	46			
5905-01-157-5612	7	8			
5961-01-197-5920	8	19			
4920-01-223-3758	11	70			

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX STOCK NUMBER	FIG.	ITEM
31589	ACF&504.22&10		8	50
50369	ACF50-0-22-5		6	3
31589	ACF50-2-0-10		8	7
06928	A402-010	5935-01-021-5489	9	22
98869	BH10666-8	5905-01-019-7689	5	23
			7	17
			8	42
98869	BH112JB916		1	
98869	BH12068-1	5340-01-023-5121	5	39
			6	36A
98869	BH123-3	5930-00-338-2591	2	1
98869	BH14548A-1		13	1
98869	BH14978-2	5340-01-030-0892	1	10
98869	BH1504	4920-00-670-9410	2	13
98869	BH15179-2		11	8
98869	BH15180	4920-01-087-9155	12	32
98869	BH15189A-2		12	66
98869	BH15194A-4	4920-01-086-1469	1	2
			12	
98869	BH15195A8	4920-01-086-1473	1	1
			11	
98869	BH15197	5330-01-021-6894	13	18
98869	BH15524	4920-01-086-1466	13	11
98869	BH15525	5330-01-104-5959	13	12
98869	BH15559-1	6695-01-096-0647	11	28
98869	BH15560	5330-01-097-9433	11	30
98869	BH15561	4920-01-020-5360	11	29
98869	BH15712	5950-01-021-6985	11	39
98869	BH15713		12	2
98869	BH15715		5	70
98869	BH15715-1	4920-01-020-5563	5	
			11	4
98869	BH15717		6	66
98869	BH15717-1	4920-01-020-5565	6	
			11	3
98869	BH15719-2	4920-01-085-7942	11	20
98869	BH15720		3	59
98869	BH15720-1	4920-01-020-5560	3	
			11	16
98869	BH15721	5999-01-111-1451	3	27
98869	BH15721-1	5999-01-114-5395	3	36
98869	BH15722	5365-01-097-6836	3	54
98869	BH15801		8	51
98869	BH15801-1	4920-01-020-5561	8	
			12	8
98869	BH15802	4920-01-086-1465	12	
98869	BH15807A		11	88
98869	BH15813-1	4920-01-086-1588	11	13
98869	BH15814	4920-01-086-1472	11	6
98869	BH15826	5999-01-016-2711	13	8
98869	BH15827	5920-01-016-7030	13	5

SECTION IV

TM 55-4920-401-13&P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX STOCK NUMBER	FIG.	ITEM
98869	BH15834		13	19
98869	BH15835-2	4920-01-086-1476	1	5
			13	
98869	BH16295	4920-01-019-1684	11	90
98869	BH16357	6150-01-095-8229	4	13
98869	BH16358		4	15
98869	BH16358-2	4920-01-089-4516	4	
			11	5
98869	BH16365		7	49
98869	BH16365-1	4920-01-020-0538	7	
			11	2
98869	BH16367		9	27
98869	BH16367-3		9	
		4920-01-020-0539	12	13
98869	BH16700-12	4920-01-086-1474	2	
98869	BH16805		1	8
98869	BH16833	5330-01-021-9220	11	9
98869	BH17427	5970-01-020-9631	13	9
98869	BH1773	5905-00-660-7834	9	12
98869	BH17956-1	5340-01-097-8868	11	50
98869	BH17957	5340-01-114-0163	11	52
98869	BH18690-2	5905-01-019-7294	11	65
98869	BH18690-3	5905-01-019-7295	11	69
98869	BH274	5905-00-865-7319	9	21
98869	BH275	5905-00-865-7320	9	19
98869	BH2825	4920-00-877-3948	12	34
98869	BH3274	5905-00-865-7325	6	42
			7	27
98869	BH3506	4920-00-589-8409	10	13
98869	BH361-8	4920-00-329-8294	2	2
98869	BH405	4920-00-503-1889	2	3
98869	BH4098	5905-01-031-1399	7	28
98869	BH437	4920-00-734-8321	1	11
			10	7
98869	BH450	4920-00-503-1890	2	4
98869	BH4548	4920-00-953-2370	2	14
98869	BH472-2		11	10
98869	BH485	4920-00-548-7118	2	5
98869	BH492B3	4920-00-767-2672	2	6
98869	BH499A	6150-00-941-6503	2	7
98869	BH5007	5905-00-312-3806	5	41
98869	BH5058	5905-01-031-0430	7	25
98869	BH5070	5905-00-978-4272	7	24
98869	BH581-1	5330-00-914-1916	12	36
			12	39
98869	BH585	4920-01-086-1464	10	1A
98869	BH6510	6625-00-948-1646	12	37
98869	BH6522	5330-00-165-1905	11	59
98869	BH6551	4920-01-086-1471	10	18
98869	BH6554	4920-01-086-1470	10	17
98869	BH6555		11	86

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
98869	BH723		5365-01-032-7243	10	6
98869	BH727		4920-00-565-3702	10	4
98869	BH760-1			1	6
98869	BH796		4920-00-565-3710	10	5
98869	BH799		5340-01-032-8106	12	63
98869	BH820		4920-00-204-6457	2	8
98869	BH821		4920-00-549-6093	2	9
98869	BH822		4920-00-539-9260	2	10
98869	BH823		4920-00-504-3192	2	11
98869	BH834-1		4920-01-086-1468	10	9
09728	BH834-2		5340-00-477-0807	10	11
98869	BH835		4920-00-565-3714	10	15
98869	BH9020P		5935-00-228-4395	11	73
				12	40
98869	BH9030S			12	48
98869	BH9033P		5935-00-763-5630	12	55
98869	BH9039S		5935-00-763-5629	12	44
98869	BH9140S		5935-00-456-4719	11	77
98869	BH9385P		5935-01-021-4609	11	81
98869	BH9385S		5935-01-021-5493	12	59
98869	BH996-40		4920-00-670-9379	2	12
24454	B74143PS8		5330-00-576-9890	11	74
				12	43
94603	CA10006		4920-01-086-1467	11	66
84171	CCD470		5910-00-410-4178	5	50
				6	47
02735	CD4001AE			7	45
37942	CG872U020V2C3PL		5910-01-014-1212	3	1
81349	CK05BX220K			5	58
				6	46
81349	CK05BX221K			5	57A
81349	CK05BX222K			3	4
81349	CK06BX223K			8	28
81349	CK60BX100K		5910-00-983-5388	5	54
				6	52
81349	CR45U			7	38
56289	C023B501G103M			5	57
				6	53
98869	C05227		5930-01-021-5588	8	32
98869	C05228		5930-01-021-5587	8	30
98869	C05229		5930-01-021-5586	3	23
98869	C05230		5930-01-021-5584	3	39
98869	C05231		5930-01-021-4623	3	34
06928	C404-010			12	4
06928	C406-021		5935-01-022-9628	11	14
				12	3
03508	C45H		5961-00-877-5692	12	65
98869	C4600		5962-00-107-4893	5	38
				6	36
98869	C5218		5945-01-021-7183	12	28
98869	C5225		5930-01-021-5589	9	18

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX STOCK NUMBER	FIG.	ITEM
98869	C933	5961-00-405-8427	3	16
			5	2
			6	11
			7	13
			8	26
82647	D6756-1-1-2		11	25
71400	FHN23W		12	53
81348	GGT318TYPE2	6685-00-243-9963	1	13
88818	G193-064-001		5	53
			6	51
02799	H-1022		6	35
98869	H122		1	14
			10	1
98869	H3318	5905-01-034-4262	9	11
98869	H3394		9	4
98869	H3395	5905-00-865-8932	9	2
98869	H3440	5905-00-921-4039	8	34
98869	H3447	5905-00-921-4020	6	7
98869	H3470	5905-00-689-2926	6	41
98869	H3485	5905-01-030-9139	6	20
98869	H3493	5905-01-097-4612	9	20
98869	H3515	5905-01-017-4859	6	58
98869	H3522	5905-01-015-5643	9	3
98869	H3524	5905-01-033-0007	5	59
			6	55
98869	H3536		5	1
98869	H3564	5905-00-422-5217	6	15
98869	H3627	5905-01-031-1401	5	68
			6	8
98869	H3674	5905-01-031-0432	5	28
			7	19
			8	43
98869	H3697		5	27
98869	H3783	5905-01-037-3380	5	17
98869	H3784		5	18
98869	H3828	5905-01-030-9147	5	49
98869	H3895	5905-01-031-1398	5	4
98869	H3905		5	6
98869	H5600P- 56	5905-01-028-7911	11	58
81349	JANIN3613	5961-00-059-2904	8	20
81349	JANIN4461	5961-00-365-6459	7	40
			8	27
81349	JANIN4471	5961-00-231-3169	8	23
81349	JANIN4486	5961-01-197-5920	8	19
81349	JANIN5524B	5961-01-042-0416	3	50
81349	JANIN914	5961-00-842-9864	5	52
			7	16
			8	1
71400	KAW20		12	52
			13	6
27014	LM725AN/6838		8	36

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
81349	LT10K144		5950-00-470-4200	5	65
				6	63
				7	1
04713	MC4350L			4	4
21207	MMF504K2		5910-00-405-8395	3	38
				7	31
96906	MS18212-5		5305-00-922-3506	3	25
96906	MS20253-2-2400			13	2
96906	MS20659-104		5940-00-107-1481	12	5
96906	MS21044C08		5310-00-982-6814	11	11
				13	10
96906	MS21044N04		5310-00-088-0551	12	42A
				12	46A
				12	50A
				12	57A
				12	61A
				13	4A
				13	7A
				13	13A
				13	15A
				13	17A
		96906		MS21044N06	
				12	33A
96906	MS21044N3		5310-00-877-5797	11	40
96906	MS21318-1			1	7
				1	9
96906	MS25043-12DA		5935-00-238-6419	11	72
				12	41
96906	MS25043-14D		5935-00-137-4669	11	76
				12	49
96906	MS25043-16D		5935-00-137-4671	12	56
96906	MS25043-20C			12	45
96906	MS27183-4		5310-00-950-1310	13	17B
96906	MS3181-14C		5935-00-899-9361	11	80
				12	60
96906	MS35059-23		5930-00-655-1582	12	22
96906	MS35059-24		5930-00-636-2821	11	41
96906	MS35206-208			11	13A
96906	MS35275-206		5305-00-941-6402	11	13B
96906	MS35308-341		5306-00-080-0680	10	3
96906	MS35333-72		5310-00-543-2739	11	51A
96906	MS35426-15		5310-00-063-6717	10	2
96906	MS35649-224		5310-00-938-2013	3	26
96906	MS51957-14		5305-00-054-5648	11	27
96906	MS51957-17		5305-00-054-5651	12	1
96906	MS51957-2		5305-00-054-5636	11	18
96906	MS51957-21		5305-00-054-5655	13	7
				13	13
96906	MS51957-27		5305-00-054-6651	10	12
96906	MS51957-28		5305-00-054-6652	11	21
				11	89

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
96906	MS51957-3		5305-00-054-5637	3	55
96906	MS51957-43		5305-00-054-6668	11	51
96906	MS51957-47		5305-00-054-6672	12	31
96906	MS51957-5		5305-00-054-5639	9	23
				12	11
96906	MS51957-63		5305-00-050-9229	10	10
96906	MS51957-65		5305-00-050-9231	10	16
96906	MS51958-61		5305-00-059-3657	1	12
				10	8
96906	MS51959-45		5305-00-764-0068	11	85
96906	MS51960-62		5305-00-059-5433	3	2
96906	MS51960-63		5305-00-071-1320	12	64
96906	MS77066-2		5940-00-816-6103	12	29A
81349	M38510/00104BCB		5962-00-318-2223	5	12
				6	62
81349	M38510/002048EB		5962-00-369-7730	5	61
				6	60
81349	M38510/00205BCB		5962-00-348-2541	5	13
				6	56
81349	M38510/00401BCB		5962-00-369-7607	5	63
				6	59
81349	M38510/05003BCA			7	32
81349	M38510/05101BCA			7	35
81349	M38510/05605BCB		5962-01-029-2899	7	47
81349	M38510/10101BGC		5962-00-167-6330	3	17
				5	46
				6	25
				7	7
				8	5
81349	M38510/10103BGB			7	4
81349	M39003/01-2966		5910-00-007-2001	5	35
81349	M39003/01-2969		5910-00-010-8240	6	14
				8	31
81349	M39003/01-2979		5910-00-192-7180	3	32
81349	M39003/01-2991		5910-00-007-3974	8	24
81349	M39003/01-3024		5910-00-144-4381	7	14
81349	M39003/01-3026		5910-00-144-4383	3	49
				5	64
				6	12
				7	3
81349	M39003/01-3076		5910-00-495-0042	8	33
81349	M39014/01-1329			7	2
81349	M39014/01-1351		5910-00-113-5276	5	44
81349	M39014/01-1357		5910-00-010-8666	5	5
				6	4
				6	28
				7	9
81349	M39014/01-1575		5910-00-124-0659	3	43
				8	10
81349	M39014/02-1338		5910-00-010-8718	4	3
				7	34

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
81349	M39015/1-C03PP		5905-00-101-1630	9	6
81349	M5423-09-02		5930-00-823-0482	11	17
				12	9
				12	14
				12	23
				12	26
81349	M55155/32-6		5940-00-939-7842	3	7
97539	N-9030-B-1/4			11	42
29907	NMF-K-F		5935-01-021-5433	7	18
29907	NMP-CHAL-F		5935-01-021-5433	3	22
04157	NMP-CHAL-M		5935-01-021-5435	3	21
				5	24
04157	NMP-COCO-F		5935-01-021-5437	11	14A
04157	NMP-COCO-M		5935-01-021-4605	3	20
97539	N9030-1-4		5930-00-823-0482	11	64
				12	21
53507	R-1003-A-2		5999-01-022-2226	4	12
				5	25
				6	30
				7	37
81349	RCR07G106JS		5905-00-121-9919	7	46
				8	35
81349	RCR07G226JS		5905-00-126-6703	5	26
				6	54
				8	45
81349	RCR20G271JS		5905-00-114-5407	3	45
81349	RCR20G331JS		5905-00-104-8334	8	21
98869	RH24765-1		4920-01-223-3758	11	70
81349	RLR07C1000GR			3	42
81349	RLR07C1001GS		5905-01-085-1164	3	13
81349	RLR07C1004GS		5905-01-157-5612	7	8
81349	RLR07C1501GS		5905-01-148-6092	3	5
81349	RLR07C1502GR			7	36
				8	18
81349	RLR07C1503GR			7	10
81349	RLR07C1802GR			5	15
81349	RLR07C2201GS		5905-01-151-1186	3	35
				5	7
				6	1
				8	3
81349	RLR07C2202GR			3	48
81349	RLR07C2203GS			8	47
81349	RLR07C2700GS		5905-01-137-0108	4	11
81349	RLR07C2702GS			5	37
				6	49
81349	RLR07C3303GR			6	27
81349	RLR07C3902GR		5905-00-150-5256	3	47
				8	2
81349	RLR07C47R0GS		5905-01-053-5788	5	42
				6	5
81349	RLR07C4700GS		5905-01-157-5608	3	19

SECTION IV

TM 55-4920-401-13&P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX STOCK NUMBER	FIG.	ITEM
81349	RLR07C4700GS	5905-01-157-5608	5	29
			6	13
			8	46
81349	RLR07C4701GS		3	12
			4	9
			5	8
			6	2
			8	44
81349	RLR07C4702GS	5905-01-137-0109	5	30
			6	50
			7	44
81349	RLR07C5601GR		3	46
81349	RLR07C6801GR		3	58
81349	RNC55H1000FS	5905-00-828-2416	9	25
81349	RNC55K1001FS	5905-00-432-0381	8	25
81349	RNC55K1002FS	5905-00-479-3990	3	10
81349	RNC55K1003FS	5905-00-208-4293	5	55
			6	22
81349	RNC55K2002FS		7	6
81349	RNC55K5761FS	5905-00-264-4148	3	52
81349	RNC55K6650FS	5905-00-721-3732	7	48
81349	RNC55K6811FS	5905-00-451-7275	9	24
81349	RNC55K6980FS	5905-00-258-5413	5	3
81349	RNC55K6981FS	5905-00-236-6632	3	14
81349	RNC55K7870FS	5905-00-273-9829	5	36
			6	10
			7	12
81349	RNC55K8060FS	5905-00-432-0429	3	15
81349	RNC60K4643FS	5905-00-305-6121	6	17
81349	RN55D3321F		3	57
91637	RS-1A12-1W		9	10
91637	RS-1A15-1W		9	26
91637	RS-1A22-1W		9	14
91637	RS-1A30-1W		9	16
91637	RS-1A35-1W		9	15
91637	RS-1A45-1W		9	17
91637	RS-1A7-1W		9	9
81349	RT12C2P100	5905-00-926-2826	9	7
81349	RT12C2P101	5905-01-085-8973	9	5
81349	RW69V360	5905-00-994-7137	7	41
78046	R116	5340-00-956-5067	13	16
97539	SEELSKREWR10-32X 1-2		11	1
97539	SEELSKREWR4-40-3 -8	5305-00-855-2996	11	19
			13	17
97539	SEELSKREWR4-40-5 -16	5305-00-051-6719	11	61
			13	4
97539	SEELSKREWR4-40X3 -4	5305-00-993-9268	13	15

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
97539	SEELSKREWR4-40X7 -16		5305-00-965-5944	11	30A
97539	SEELSKREWR6-32-1 -2		5305-00-798-0862	1	3
				12	33
				12	54
97539	SEELSKREWR8-32X1 -2		5305-00-956-4470	11	24
				11	53
97539	SEELSKREWR8-32X5 -8		5305-00-455-2638	11	23
97539	SEELSKREWS440X1- 2			11	75
				11	79
				11	83
				12	35
				12	38
				12	42
				12	46
				12	50
				12	57
				12	61
81349	SE23XC02		5940-00-926-0015	8	48
04713	SM5365		5961-00-905-8536	5	9
				6	48
01295	SNC5490AJ			4	1
01295	SN5442N			5	10
21604	SSN-70-2 SHORT B LACK		5355-01-096-2471	11	62
21604	SSN70-2		5355-00-340-5152	11	62A
				12	19
				12	24
21604	SS70BL2BLK		5355-00-403-1590	11	15
				12	7
				12	12
37942	TCG122U050N2C3P		5910-01-021-7661	3	11
37942	TCG412U015N1L		5910-01-016-0112	3	53
01295	TIL111		5961-00-098-8032	6	19
37942	TT50X150B			3	33
04386	TZ-17XT		5950-01-021-6987	8	8
18677	US-2-14-160-G-B			4	2
				4	8
				5	12A
				6	57
				7	33
18677	US-2-16-160-G-B		5935-01-065-9763	4	5
				5	11
				5	62
				6	61
12697	VC3D-1K			8	16
80031	1-4-5P10K			3	44

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX STOCK NUMBER	FIG.	ITEM
80031	1-4-5P10K		5	51
			6	29
			7	11
			8	13
80031	1-4-5P100E		6	16
80031	1-4-5P100K		3	41
80031	1-4-5P3K3		8	9
80031	1-4-5P470K		3	40
80131	1N5059	5961-00-088-8792	3	9
			7	42
			8	17
			12	27
80131	1N5624		3	6
80131	1N702A	5961-00-846-9125	3	37
			5	14
			8	4
04713	1N914	5961-00-842-9864	6	23
77820	10-36675-16	5330-00-292-3958	12	58
77820	10-36675-20	5330-00-599-9126	12	47
18876	10015417-054	5910-00-280-8393	8	14
20747	101-127-104	5905-00-174-0346	6	37
99832	101197	5925-00-283-6513	12	30
14752	112A1C104J	5910-00-409-3049	5	43
			6	21
81073	12C1087	5310-00-637-4885	12	10
			12	15
75915	123002	5999-00-151-4035	13	3
71279	1291-1	5340-00-186-9481	11	84
71785	133-98-92-061		5	47
			6	26
			7	5
83330	1415-4		11	26
70485	165A	5340-00-266-0754	11	12
55974	1945708-2	5999-00-402-2485	5	40
			6	368
80131	2N3646	5961-00-062-3133	8	29
80131	2N4352	5961-00-929-4951	6	33
80131	2N4402	5961-00-450-3040	3	28
			5	16
			6	24
04713	2N4852	5961-00-118-4775	5	66
			6	9
			8	49
01295	2N4861		5	60
			6	44
07263	2N4945	5961-00-459-2038	3	3
80131	2N5294	5961-00-039-8814	3	31
80131	2N6109	5961-01-012-9316	3	24
80131	2N6290	5961-01-013-0081	3	29
80131	2N6336	5961-01-016-2782	8	11
88245	2024B		4	14

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
70485	21		5340-01-021-4103	13	14
52599	249E500M90		5905-01-112-0117	9	8
72619	250-1471-500		6210-00-470-7602	11	43
				12	16
72619	250-1473-500		6210-01-018-7376	11	46
72619	250-8758-33-504		6210-00-244-1994	11	45
				11	48
				12	18
56232	284202		5310-00-840-8342	13	10A
81073	30-252 RED		5930-01-021-5594	11	71
71279	3422-1-03		5935-00-988-6438	7	22
13499	352-0840-012		5961-00-496-4643	6	34
04618	35316			12	6
80294	3540-S-1-101		5905-01-022-0134	12	25
80294	3540-S-1-203		5905-01-021-6816	12	20
56289	36D132G050AA2A		5910-00-836-6258	3	51
04454	3800P202		5905-00-229-7391	5	48
				6	45
				7	29
04454	3800P203		5905-00-189-2380	5	32
				6	31
				8	40
02660	3800P502			5	33
				6	38
			5905-00-168-9287	7	20
				8	41
13499	381-0003-100		5905-00-974-6426	6	43
04454	3811P100		5905-01-027-3536	7	26
05591	4H8A14402B		5905-00-099-9682	5	69
05591	4H8A14630B			5	21
05591	4H8A16302B		5905-00-099-9683	8	39
05591	4H8A19301B			7	30
05591	4H8A22001B			6	64
05591	4H8A2300B			5	67
				6	6
				8	37
05591	4H8A23180B		5905-00-099-9690	5	19
05591	4H8A23790B			5	20
05591	4H8A30000B		5905-00-412-1212	5	22
				6	40
05591	4H8A3802B		5905-00-415-6576	6	65
05591	4H8A40001B		5905-00-101-1838	8	38
82389	430		5935-00-411-7929	5	31
				6	32
				7	21
71279	461-2871-01-03-1		5935-01-021-7728	7	23
	2				
63743	5XM225			9	1
56289	500D207G050FF7		5910-00-499-7435	3	8
				7	43
				8	22

SECTION IV

TM 55-4920-401-13&P

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

FSCM	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
72619	507-5821-0747-60 0		6240-00-924-6435	11	47
72619	507-5824-0747-60 0		6240-00-924-6438	11	44
				12	17
50436	5082-7650			4	7
79136	5100-62		5365-00-298-6563	10	14
86928	5203-8		5970-01-095-6353	8	12
12697	53C3-50K		5905-01-084-9946	11	63
94271	533-00HS250K		5905-01-021-6818	5	45
				6	39
86928	5610-9-10		5970-01-020-0877	3	56
14752	625C1C105J		5910-00-211-1976	5	56
				6	18
				7	15
14752	637B1D563K			8	15
81073	71BY23196-1-2N		5930-01-022-2061	9	13
71785	8-ICS			3	18
				8	6
91506	8000-AG9			7	39
94271	830P-50K		5905-00-107-4872	5	34
18876	8528783		5330-00-355-8976	11	78
				11	82
				12	51
				12	62
73138	899-3R150		5905-00-520-9440	4	6

INDEX

Subject	Paragraph Figure, Table Number	Page
A		
Accessories	T3-1	3-1
Accessory Functions	T1-13	
Aircraft Heat Detection Systems Check	2-8	2-12
Aircraft Indicator Check Circuit		
Accuracy Check	4-6h	4-5
Circuit for D'Arsonval Indicators	F1-18	1-17
Circuit for Null-Balance Indicators	F1-19	1-18
Detailed Theory	1-4b(3)(a)	1-4
General Theory	1-4a(7)	1-4
Troubleshooting Table	T4-11	4-13
Aircraft RPM Indicator Check	2-7	2-12
Aircraft Temperature System Check	2-3	2-1
A/D Converters		
Detailed Theory	1-4b(1)	1-4
Troubleshooting	4-7c	4-6
Waveforms	F4-7	4-9
B		
Block Diagram		
A/D Converter	F1-3	1-5
Tester, Described	1-4a(1)	1-1
Tester, Illustrated	F1-2	1-3
Power Flow	F1-25	1-26
C		
CAL ADJ Potentiometers		
Installation	4-16	4-37
Removal	4-10f	4-36
Consumable Materials	T1-16	1-47
Control Functions	T1-12	1-42
D		
Daily Inspection		
Visual	3-4a	3-1
Functional	3-4b	3-3
Display and Counter Board	1-4b(1)(h)	1-10
Display Replacement	3-13	3-4
E		
Engine Trim Check	2-6	2-9

INDEX (Continued)

Subject	Paragraph Figure, Table Number	Page
F		
Federal Supply Code List of Manufacturers	4-19	4-38
Forms and Records	1-2	1-1
Fuse Replacement	3-14	3-4
H		
Heater Probe Control Circuit		
Accuracy Check	4-6d	4-3
Description	1-4b(7)	1-4
Schematic	F FO-1	
Troubleshooting	4-7e	4-7
Troubleshooting Table	T4-8	4-10
Waveforms	T4-14	4-23
Heater Probe Power SCR		
Installation	4-17	4-38
Removal	4-10g	4-36
Heater Probe Temperature Measuring Circuit	1-4b(3)(c)	1-6
Heater Probe Temperature Set Circuit	1-4b(3)(f)	1-8
I		
Indicators		
Digital, Described	1-4a(2)	1-1
Functions	T1-12	1-43
Insulation Check Circuit,		
Accuracy Check	4-6f	4-4
Detailed Theory	1-4b(3)	1-4
General Theory	1-4a(5)	1-4
Simplified Schematic	F1-23	1-23
Troubleshooting Table	T4-9	4-11
L		
Lamp Replacement	3-12	3-4
Leading Particulars	T1-11	1-40
Logic Circuitry		
Definitions	1-4b(11)(c)	1-6
Logic Levels	1-4b(11)(a)	1-4
Pin Locations	F1-26	1-27
Troubleshooting	4-7a(4)	4-6
Lubrication	3-8	3-4
P		
Percent RPM Indicator		
Accuracy Check	4-6b	4-1
Calibration Circuit	1-4b(5)	1-4

INDEX (Continued)

Subject	Paragraph Figure, Table Number	Page
Percent RPM Indicator (Continued)		
Detailed Threw	1-4b(4)	1-4
Troubleshooting Table	T4-6	4-9
Percent RPM Signal Circuits		
Description	1-4b(5)	1-4
Signal Flow Diagram	F1-21	1-20
Periodic Inspection	3-5	3-4
Power Supplies		
Description	1-4b(10)	1-4
Troubleshooting	4-7b	4-6
Voltages	T4-12	4-14
Probe Control and Function Switch Board		
Installation	4-14	4-36
Removal	4-10d	4-35
Probe Controller Assembly		
General Theory	1-4a(4)	1-4
Installation	4-12	4-36
Opening	4-7a(2)(a)	4-6
Removal	F1-41	1-47
Probe Controller Support	F1-41	1-47
R		
Resistance and Insulation Check Board		
Installation	4-15	4-37
Removal	4-10e	4-35
Resistance Check Circuit		
Accuracy Check	4-6g	4-5
Detailed Theory	1-4b(9)	1-4
General Theory	1-4a(6)	1-4
Simplified Schematic	F1-24	1-24
Troubleshooting Table	T4-10	4-12
S		
Schematic Diagrams	4-8	4-26
Shipping of Tester	3-3	3-1
Shipping Pallet	F3-1	3-2
Soldering	4-9	4-35
Special Tools and Test Equipment	T1-15	1-46
Spread Circuit		
Description	1-4b(3)(b)	1-6
Functional Check	4-6e	4-4
Standard Day Correction Circuit		
Accuracy Check	4-6c	4-3
Detailed Theory	1-4b(6)	1-4
General Theory	1-4a(3)	1-1
Schematic Diagram	F1-22	1-22
Troubleshooting Table	T4-7	4-9

INDEX (Continued)

Subject	Paragraph Figure, Table Number	Page
Standard Day Lamp Circuit	1-4b(6)(a)	1-4
Storage of Tests	3-2	3-1
Switch Box		
Function	T1-13	1-44
Illustration	F2-9	2-10
Switch-Power Board		
Installation	4-13	4-36
Removal	4-10c	4-35

T


Temperature Compensator		
Detailed Theory	1-4b(2)(a)	1-4
Troubleshooting	4-7d	4-7
Temperature Indicator		
Accuracy Check	4-6a	4-1
Detailed Theory	1-4b(2)	1-4
Signal Circuits	1-4b(3)	1-4
Troubleshooting Table	T4-5	4-8
Temperature Indicator Calibration Circuit		
Detailed Theory	1-4b(3)(e)	1-8
Temperature Spread Test	2-5	2-9
Test Points	4-7a(3)	4-6
Trimmer Deck Assembly		
Installation	4-11	4-36
Opening	4-7a(2)(b)	4-6
Removal	4-10a	4-35
Trouble Analysis	4-7	4-6
Troubleshooting Aircraft Temperature System		
D'Arsonval Temperature Indicator Check	2-4b	2-4
Insulation Resistance Check	2-4e	2-7
Null-Balance Temperature Indicator Check	2-4c	2-5
Temperature Circuit Resistance Check	2-4d	2-7
Thermocouple and Harness Check	2-4a	2-4
Troubleshooting Table		
Aviation Unit Support	T3-2	3-5
Aviation Intermediate Support	T4-4	4-8


U

Unpacking Tester	3-1	3-1
------------------------	-----	-----


W

Warmup Procedure	4-5	4-1
------------------------	-----	-----






FO-2. Probe Controller Assembly, BH15194A-4, Schematic





NOTES:
 1. RESISTANCE IS IN OHMS AND CAPACITANCE IS IN MICROFARADS UNLESS OTHERWISE NOTED.
 2. RESISTORS ARE 0.25 WATT UNLESS OTHERWISE NOTED.

F0-3. Switch-Power Board, BH15720-3, Schematic




FO-4. Temperature Board, BH15715-1, Schematic




- NOTES:
1. RESISTANCE IS IN OHMS AND CAPACITANCE IS IN MICROFARA UNLESS OTHERWISE NOTED.
 2. RESISTORS ARE 0.25 WATT UNLESS OTHERWISE NOTED.
 3. INDUCTANCE IS IN MICROHENRYS


F0-5. Tachometer Board, BH15717-1, Schematic




F0-6. Calibrator Board, BH16365-1, Schematic



F0-7. BH15195A-8 Trimmer Assembly



FO-8. BH15194A-4 Probe Controller Assembly



F0-9. BH15835-2 Instrument Case Assembly

By Order of the Secretary of the Army:

Official:

J. C. PENNINGTON
Major General, United States Army
The Adjutant General

E. C. MEYER
General, United States Army
Chief of Staff

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31 Operator Maintenance Requirements for All Fixed and Rotor Wing Aircraft.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)
 CDR, 1st Br, 65th ADA
 ATTN: SP4 J. Brown
 Key West, FL 33040

DATE SENT
 10 Jun 79

PUBLICATION NUMBER
 TM 9-1430-550-34-1

PUBLICATION DATE
 7 Sep 72 .

PUBLICATION TITLE
 Unit of Radar Set
 AN/MPQ-50 Tested at the HFC

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PARA-GRAPH	FIGURE NO	TABLE NO
9-19		9-5	
21-2	step 1C	21-2	

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

"B" Ready Relay K11 is shown with two #9 contacts. That contact which is wired to pin 8 of relay K16 should be changed to contact #10.

Reads: Multimeter B indicates 600 K ohms to 9000 K ohms.

Change to read: Multimeter B indicates 600 K ohms minimum.

Reason. Circuit being checked could measure infinity. Multimeter can read above 9000 K ohms and still be correct.

TEAR ALONG PERFORATED LINE

SAMPLE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SP4 J.T. Brown, Jr.

SIGN HERE

SP4 James Brown, Jr.

DA FORM 2028-2
 2 JUL 79

REPLACES DA FORM 2028 2 1 APR 78 WHICH WILL BE USED UNTIL EXHAUSTED
 AMM/V M Overprint 3, 1 Mar 91

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

1 Nov 80

FILL IN YOUR
UNITS ADDRESS
↓

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

COMMANDER
U.S. ARMY AVIATION AND TROOP COMMAND
ATTN: AMSAT-I-MP
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH THIS PUBLICATION?

THEN JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT FOLD IT AND DROP IT IN THE MAIL.

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 55-4920-401-13&P

PUBLICATION DATE

17 NOV 79

PUBLICATION TITLE OPERATOR'S, AVUM & AVIM MAINT MANUAL INCL RPSTL FOR TESTER, EXHAUST GAS TEMPERATURE

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PARA-GRAPH	FIGURE NO	TABLE NO

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2

JUL 79

PREVIOUS EDITIONS ARE OBSOLETE

PS...IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

U.S. G.P.O. 1983-381-646/8515

TEAR ALONG DIMENSIONED LINE

1 Nov 80

FILL IN YOUR
UNITS ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

COMMANDER
U.S. ARMY AVIATION AND TROOP COMMAND
ATTN: AMSAT-I-MP
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT FOLD IT AND DROP IT IN THE MAIL.

SOMETHING WRONG WITH THIS PUBLICATION?

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 55-4920-401-13&P

PUBLICATION DATE

17 NOV 79

PUBLICATION TITLE OPERATOR'S, AVUM & AVIM MAINT MANUAL INCL RPSTL FOR TESTER, EXHAUST GAS TEMPERATURE

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PARA-GRAPH	FIGURE NO	TABLE NO
---------	------------	-----------	----------

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE

P.S. IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

THIS FORM IS PERMANENTLY PRINTED

1 Nov 80

FILL IN YOUR
UNITS ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

COMMANDER
U.S. ARMY AVIATION AND TROOP COMMAND
ATTN: AMSAT-I-MP
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

1 Nov 80

FILL IN YOUR
UNITS ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

COMMANDER
U.S. ARMY AVIATION AND TROOP COMMAND
ATTN: AMSAT-I-MP
4300 GOODFELLOW BOULEVARD
ST. LOUIS, MO 63120-1798

TEAR ALONG PERFORATED LINE

The Metric System and Equivalents

Linear Measure

- 1 millimeter = 10 millimeters = .39 inch
- 1 centimeter = 10 centimeters = 3.94 inches
- 1 decimeter = 10 decimeters = 39.37 inches
- 1 meter = 10 meters = 32.8 feet
- 1 dekameter = 10 dekameters = 328.08 feet
- 1 hectometer = 10 hectometers = 3,280.8 feet
- 1 kilometer = 10 kilometers = 32,808 feet

Weights

- 1 centigram = 10 milligrams = .15 grain
- 1 decigram = 10 centigrams = 1.54 grains
- 1 gram = 10 decigrams = .035 ounce
- 1 dekagram = 10 grams = .35 ounce
- 1 hectogram = 10 dekagrams = 3.52 ounces
- 1 kilogram = 10 hectograms = 2.2 pounds
- 1 quintal = 100 kilograms = 220.46 pounds
- 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

- 1 centiliter = 10 milliliters = .34 fl. ounce
- 1 deciliter = 10 centiliters = 3.38 fl. ounces
- 1 liter = 10 deciliters = 38.82 fl. ounces
- 1 dekaliter = 10 liters = 2.64 gallons
- 1 hectoliter = 10 dekaliters = 26.42 gallons
- 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

- 1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
- 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches
- 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
- 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
- 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
- 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

- 1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
- 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
- 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	2.540	ounce-inches	newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29.573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	4.54	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
foot-pounds	newton-meters	1.365	metric tons	short tons	1.102
foot-inches	newton-meters	.11375			

Temperature (Exact)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
----	------------------------	----------------------------	---------------------	----

