

**TECHNICAL MANUAL**

**OPERATOR'S AND AVIATION INTERMEDIATE  
MAINTENANCE (AVIM) MANUAL INCLUDING  
REPAIR PARTS AND SPECIAL TOOLS LIST FOR**

**SHEET METAL/PAINT SHOP**

**P/N SC-4920-97-CL-A68  
NSN 4920-01-1 39-4547**

CHANGE }  
NO. 2 }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 11 October 1988

OPERATOR'S AND AVIATION INTERMEDIATE  
MAINTENANCE (AVIM) MANUAL INCLUDING  
REPAIR PARTS AND SPECIAL TOOLS LIST

FOR

SHEET METAL/PAINT SHOP  
P/N SC-4920-99-CL-A68  
NSN 4920-01-139-4547

TM 55-4920-435-13&P, 17 July 1984, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-1 and 1-2	1-1 and 1-2
2-30.1/2-30.2	2-30.1/2-30.2
A-1/A-2	A-1/A-2

2. Retain this sheet in front of manual for reference purposes.

**By Order of the Secretary of the Army:**

**CARL E. VUONO**  
*General, United States Army*  
*Chief of Staff*

**Official:**

**WILLIAM J. MEEHAN II**  
*Brigadier General, United States Army*  
*The Adjutant General*

**DISTRIBUTION:**

To be distributed in accordance with DA Form 12-31, Operator and AVIM Maintenance requirements for all Fixed Wing and Rotary Wing Aircraft.

CHANGE }  
NO. 1 }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 27 January 1987

Operator's and Aviation Intermediate Maintenance (AVIM) Manual  
Including Repair Parts and Special Tools List

For

SHEET METAL/PAINT SHOP

P/N SC-4920-99-CL-A68  
NSN 4920-01-139-4547

TM 55-4920-435-13&P, 17 July 1984, is changed as follows:

1. On Cover, P/N SC-4920-97-CL-A68 is changed to read P/N SC-4920-99-CL-A48.
2. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
i/ii	i/ii
1-1 through 1-6	1-1 through 1-8
2-1 and 2-2	2-1 and 2-2
-----	2-2.1/2-2.2
2-3 through 2-8	2-3 through 2-8
2-11 and 2-12	2-11 and 2-12
2-19 and 2-20	2-19 and 2-20
2-23 through 2-30	2-23 through 2-30
-----	2-30.1/2-30.2
2-33 and 2-34	2-33 and 2-34
-----	2-34.1/2-34.2
2-39 through 2-44	2-39 through 2-44
2-47 through 2-56	2-47 through 2-56
3-21 and 3-22	3-21 and 3-22
A-1/A-2	A-1/A-2

3. Retain these sheets in front of manual for reference purposes.

By Order of the Secretary of the Army:

**JOHN A. WICKHAM, JR.**  
*General, United States Army*  
*Chief of Staff*

Official:

**R. L. DILWORTH**  
*Brigadier General, United States Army*  
*The Adjutant General*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, Operator and AVIM Maintenance requirements for all Fixed and Rotary Wing Aircraft.

**WARNING**  
**PRECAUTIONARY DATA**

Personnel performing operations, procedures and practices which are included or implied in this Technical Manual shall observe the following warnings. Disregard of these warnings and precautionary information can cause serious injury, death or destruction of materiel.

**WARNING**

An operating procedure, practice, etc., which, if not correctly followed, could result in personnel injury or loss of life.

**CAUTION**

An operating procedure, practice, etc., which, if not strictly observed, could result in damage to or destruction of equipment.

**NOTE**

An operating procedure, condition, etc. which is essential to highlight.

**WARNING**

Four people are needed when moving or lifting the Environmental Control Units (ECU). Each unit weighs approximately 270 pounds. Trying to move or lift an ECU without sufficient help can cause serious injury to personnel.

**WARNING**

When all equipment and materiel is stored on the stationary side of the shelter, the limited floor space presents a safety hazard to operating personnel. This is most critical during the raising and lowering of the roof panel. Failure to observe supplemental instructions could result in serious injury to personnel. Personnel inside the shelter could become trapped between the roof panel and equipment bolted to the floor.

**WARNING**

The two upper lockout pins must be installed at the cable housing prior to raising the shelter floor from its lower position to its level position. If the lockout pins are not in place, the counterbalance cable will remain under tension. DO NOT attempt to remove cable if the upper lockout pins are not installed. Removing cable while under tension could cause serious injury to personnel.

**WARNING**

To prevent possible personnel injury set screws must be securely tightened to ensure counterweights do not slide out of support holes during operation of the sheet metal brake.

**WARNING**

Perform the following steps only if the shrinking/stretching machine is to be used. Removal of the retainer bar releases the foot pedal. When in operation, the foot pedal extends well out in front of the machine and into the door way of personnel entrance. This extended pedal could result in injury to personnel running into or tripping over the pedal. When not in use the retainer bar, which holds the foot pedal in place, will be installed.

**WARNING**

**HIGH VOLTAGE** exists in the electrical system of the shop. All electrical inspections, repairs or replacement will be performed with the power off and only by qualified electricians. Serious shock hazards exist which could result in injury or even death to personnel.

**WARNING**

Methylethylketone (MEK), used to clean replacement inserts, is flammable and toxic. Use only in well ventilated areas. Breathing vapors can cause headaches and nausea. Repeated contact with skin can cause irritation. If irritation persists see a doctor. Contact with eyes, wash immediately with water for 15 minutes and seek medical attention.

**WARNING**

Safety goggles will be worn when drilling and cleaning holes for insert replacement. Flying chips can cause eye injury or even blindness.

**WARNING**

Make sure compressed air supply is disconnected before attempting any work on the water/oil separator. Do not direct compressed air near eyes or directly against skin. Wear goggles; high pressure air against eye can cause blindness.

**WARNING**

Extreme care must be taken when performing all types of welding operations. Serious health and fire hazards exist. Harmful light rays can cause eye injury or even blindness. Protective face masks and goggles must be used as well as other special clothing to reduce risks. Poisonous fumes, burns, electric shock, fire, and explosion hazards are some of the additional possibilities of injury associated with welding operations. It is essential that all safe practices be strictly observed.

**CAUTION**

Care must be taken to ensure that the proper bolts and washers are available to secure equipment when shop is to be transported. Lack of correct hardware could cause extensive damage to equipment or the shelter when the shop is moved.

**CAUTION**

Torque values provided must be respected to prevent possible damage to equipment or the shelter. Improper procedures could result in extensive damage to Government property.

**CAUTION**

Ensure that the power cable is not twisted, kinked or laid over sharp rocks or projections. Where possible cable should not be routed through any deep ground depressions where water may accumulate.

**HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 17 July 1984**


OPERATOR'S AND AVIATION INTERMEDIATE  
MAINTENANCE MANUAL  
INCLUDING  
REPAIR PARTS AND SPECIAL TOOL LIST  
FOR THE SHEET METAL/PAINT SHOP

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Aviation Systems Command, ATTN: AMSAV- MPSD, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. A reply will be furnished directly to you.

		Page
CHAPTER 1.	INTRODUCTION .....	1-1
SECTION I.	General Information.....	1-1
SECTION II.	Equipment Description and Data .....	1-1
SECTION III.	Principles of Operation .....	1-8
CHAPTER 2.	OPERATOR INSTRUCTIONS.....	2-1
SECTION I.	Initial Shop Setup .....	2-1
SECTION II.	Preparing Shop for Operation .....	2-4
SECTION III.	Preparation for Shipment.....	2-32
CHAPTER 3.	MAINTENANCE INSTRUCTIONS .....	3-1
SECTION I.	Repair Parts, Special Tools, TMDE, and Support Equipment .....	3-1
SECTION II.	Service Upon Receipt .....	3-1
SECTION III.	Maintenance Procedures .....	3-2
APPENDIX A	REFERENCES.....	A-1
APPENDIX B	MAINTENANCE ALLOCATION CHART .....	B-1
APPENDIX C	REPAIR PARTS AND SPECIAL TOOLS LIST.....	C-1
	Functional Group Numbers	
	01 - Insert Fasteners	
	02 - Fixtures	
	03 - Electrical	
	04 - Machine Tool, Equipment, Special Brackets and Fabricated Components	
	05 - Floor Insert Plugs	
APPENDIX D	EXPENDABLE/DURABLE SUPPLIES AND MATERIELS LIST .....	D-1
APPENDIX E	ILLUSTRATED LIST OF MANUFACTURED ITEMS.....	E-1
APPENDIX F	TORQUE LIMITS .....	F-1
ALPHABETICAL INDEX.....		Index 1





## CHAPTER 1 INTRODUCTION

### SECTION I. GENERAL INFORMATION

#### 1-1. Scope.

Type of Manual: Operator and Intermediate Level

Equipment Name: Sheet Metal/Paint Shop, NSN 4920-01-139-4547

Purpose of Equipment: To provide sheet metal repair and fabrication as well as painting support for nondivisional aviation units. This shop is utilized in conjunction with other maintenance shops in the AVIM support unit.

#### 1-2. Maintenance forms, records and reports.

Department of the Army forms and records used to maintain this equipment will be those prescribed by DA PAM 738-751, The Army Maintenance Management System - Aviation (TAMMS-A).

#### 1-3. Reporting equipment improvement recommendations (EIR).

If your Sheet Metal/Paint Shop needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Put it on an SF 368 (Quality Deficiency Report). Mail it to: Commander, U.S. Army Aviation Systems Command, ATTN: AMSAV-MMD, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. We will send you a reply.

#### 1-4. Destruction of Army material to prevent enemy use.

Instructions for destruction of this equipment are contained in TM 750-244-1-4, Procedures for Destruction of Aviation Ground Support Equipment (FSC 4920), to Prevent Enemy Use.

#### 1-5. Preparation for storage or shipment.

For general technical information on preparation for storage and shipment refer to TM 55-1500-204-25/1 and TM 743-200-1. For regulatory requirements pertaining to equipment placed in administrative storage refer to AR 750-1.

### SECTION II. EQUIPMENT DESCRIPTION AND DATA

#### 1-6. Characteristics.

a. The Sheet Metal/Paint Shop is housed in two tactical, one side expandable, shelters (NSN 5411-01-124-1377), designated Unit A and Unit B.

b. Unit, contains the primary sheet metal, cutting, forming, bending, and shrinking machines. Unit B is made up of secondary equipment and hand tools used in sheet metal repair and fabrication. In addition, Unit B also contains all spray painting equipment.

c. Once the two shelters have been erected they form a complete sheet metal shop facility. The additional floor space provides the work area necessary for the Sheet Metal/Paint Shop to perform its maintenance function.

d. The shelters can be transported by highway, rail, marine, or air (C-130, C-141 or C-5 aircraft Army CH-47 and CH-54 helicopter).


e. As designed, the Sheet Metal/Paint Shop can be operated in any geographic area and under any climatic condition in support of Army non-divisional units.

**1-7. Location and description of major components.**

- a. Shelter closed for transport or storage.
- b. Major components in Unit A, during transport/storage mode.


**TRANSPORTATION MODE**

- (1) DRILL PRESS
- (2) SHEARING MACHINE
- (3) BAND SAW
- (4) CABINET, BIN STORAGE
- (5) VISE
- (6) ECU
- (7) BRAKE, SHEET METAL
- (8) SHRINKING/STRETCHING MACHINE
- (9) STENCIL CUTTING MACHINE
- (10) TOOL BOX RACK
- (11) GRINDING MACHINE, DRILL BIT
- (12) FORMING MACHINE
- (13) CABINET, W/DRAWERS
- (14) CABINET, BIN STORAGE W/DRAWERS



c. Major components in Unit A, during operational mode (for shelter P/N 136-0000-101).


OPERATIONAL MODE



- |                          |                                     |
|--------------------------|-------------------------------------|
| (1) DRILL PRESS          | (8) SHRINKING/STRETCHING MACHINE    |
| (2) SHEARING MACHINE     | (9) STENCIL CUTTING MACHINE         |
| (3) BAND SAW             | (10) TOOL BOX RACK                  |
| (4) CABINET, BIN STORAGE | (11) GRINDING MACHINE, DRILL BIT    |
| (5) VISE                 | (12) FORMING MACHINE                |
| (6) ECU                  | (13) CABINET, W/DRAWERS             |
| (7) BRAKE, SHEET METAL   | (14) CABINET, BIN STORAGE W/DRAWERS |

d. Major components in Unit A, during operational mode (for shelter P/N 5-4-2828-1).


**OPERATIONAL MODE**



- |                          |                                     |
|--------------------------|-------------------------------------|
| (1) DRILL PRESS          | (8) SHRINKING/STRETCHING MACHINE    |
| (2) SHEARING MACHINE     | (9) STENCIL CUTTING MACHINE         |
| (3) BAND SAW             | (10) TOOL BOX RACK                  |
| (4) CABINET, BIN STORAGE | (11) GRINDING MACHINE, DRILL BIT    |
| (5) VISE                 | (12) FORMING MACHINE                |
| (6) ECU                  | (13) CABINET, W/DRAWERS             |
| (7) BRAKE, SHEET METAL   | (14) CABINET, BIN STORAGE W/DRAWERS |

e. Major components in Unit B, during transport/storage mode.

TRANSPORTATION MODE




- (1) TOOL BOX RACK
- (2) ECU
- (3) CABINET, BIN STORAGE
- (4) CABINET, W/DRAWERS
- (5) PLATE, BENCH STAKE HOLDER

- (6) AUTOMOTIVE WORK TABLE
- (7) GRINDING MACHINE
- (8) VISE
- (9) THROATLESS SHEARS W/STAND
- (10) STENCIL CUTTING MACHINE

f. Major components in Unit B, during operational mode (for shelter P/N 136-0000-101).

**OPERATIONAL MODE**




- (1) TOOL BOX RACK
- (2) ECU
- (3) CABINET, BIN STORAGE
- (4) CABINET, W/DRAWERS
- (5) PLATE, BENCH STAKE HOLDER

- (6) AUTOMOTIVE WORK TABLE
- (7) GRINDING MACHINE
- (8) VISE
- (9) THROATLESS SHEARS W/STAND
- (10) STENCIL CUTTING MACHINE

g. Major components in Unit B, during operational mode (for shelter P/N 5-4-2828-1).

OPERATIONAL MODE



- (1) TOOL BOX RACK
- (2) ECU
- (3) CABINET, BIN STORAGE
- (4) CABINET, W/DRAWERS
- (5) PLATE, BENCH STAKE HOLDER

- (6) AUTOMOTIVE WORK TABLE
- (7) GRINDING MACHINE
- (8) VISE
- (9) THROATLESS SHEARS W/STAND
- (10) STENCIL CUTTING MACHINE

Change 1 1-7



### SECTION III. PRINCIPLES OF OPERATION

**1-8.** After the shelter has been erected, the operator personnel will unbolt selected items of equipment. These items will be relocated to preselected positions on the expanded side of the shelter. (See para., 17c.,d.,f.,g.). The selected items, when moved, will not be secured, (bolted) in place. This allows the shop personnel a certain flexibility in the event long or bulky materiel must be repaired within the shelter. The recommended locations were selected for proper utilization of floor space and maximum safety for the operating personnel.

#### **WARNING**

**Four people are needed when moving or lifting the Environmental Control Units (ECU). Each unit weighs approximately 270 pounds. Trying to move or lift an ECU without help can cause serious injury to personnel.**

**1-9.** The two ECUs are positioned on special fold-down shelves, when the shop is in the operational mode. Power is provided by a 208V cable located inside the shelter next to each shelf. All ECUs can be easily removed for service or repair.

**1-10.** Detailed instructions for unbolting equipment and the recommended sequence for relocation is contained in Chapter 2, Section II. The procedures for striking the shelter and preparing the Sheet Metal/Paint Shop for transport or storage are contained in Chapter 2, Section III.

**1-11.** Electrical power to operate the Sheet Metal/Paint Shop is provided by an auxiliary generator or a commercial power source. A power distribution panel (PDP) is used between the power source and the power entry; panel of the shelter. Overload protection is by circuit breaker. The circuit breaker panel is located inside the shelter next to the personnel entrance door.

**Change 1 1-8**

**CHAPTER 2  
OPERATOR INSTRUCTIONS**

**SECTION I. INITIAL SHOP SETUP**

**2-1. Setup of Sheet Metal/Paint Shop, Unit A and Unit B, upon initial receipt.** Refer to TM 10-5411-201-14 for specific procedures concerning erection of the tactical, one side expandable, shelter (NSN 5411-01-124-1377).


a. The two units that make up the Sheet Metal/Paint Shop will be positioned as close to each other as possible. In addition, the shelters should be set up with power cable length, tactical deployment, exhaust/inlet of ECUs, and the interaction between related shops kept in mind. The shop's utility power entry panel, next to the personnel door, should be facing toward the power source and distribution panel (see page 1-0).

b. Initial Leveling. Procedures in TM 10-5411-201-14 will be followed to ensure proper operation of all fold out panels.

**WARNING**

**When all equipment and materiel is stored on the stationary side of the shelter, the limited floor space presents a safety hazard to operating personnel. This is most critical during the raising and lowering of the roof panel. Failure to observe Supplemental Instructions could result in serious injury to personnel. Personnel inside the shelter could become trapped between the roof panel and equipment bolted to the floor.**

c. Supplemental Safety Instructions. To prevent possible accidents, the following procedures will be followed:




1. Two personnel, outside the shelter, must lift the roof panel (1) far enough to allow two people inside to release the support struts (2), extend them to full length, and insert the quick-release pins (3).




**Change 1 2-1**

2. As soon as there is enough floor area (4), the personnel inside will move to the expanded side of the shelter raising the roof with extended support struts (2).




3. Once the struts (2) are totally supporting the roof panel (1), the end walls (5) are swung open.




**WARNING**

The fold-out floor counterbalance cables must be secured in the cable housings prior to raising the shelter floor from its lowered position to its level position. If the counterbalance cables are not secured, the counterbalance cables will remain under tension. DO NOT attempt to remove cables if the counterbalance cables are not secured. Removing cables while under tension could cause serious injury to personnel.

4. For shelter P/N 136-0000-101) Raise the upper lockout plates (6) on each end wall and install upper lockout pins (7) into the cable housings.



5. (For shelter P/N 5-4-2828-1) Close slide stops (1) against counterbalance cables (2) on both cable reels (3).
6. Securing the counterbalance cables will allow removal of the counterbalance cables attached to each end of fold-out floor.
7. Continue with remaining procedures outlined in TM 10-5411-201-14 for final erection of the shelter.



Change 1 2-2.1 /(2-2.2 blank)



d. Counterbalance Cable Removal.

1. After shop erection is complete (AND COUNTERBALANCE CABLES ARE SECURED), remove three screws (1) from cable retainer block (2).

2. Let cable (3) and retainer block (2) hang loose next to shelter (4).

3. Reinstall retainer block screws (1) and secure.

e. Shop is now ready for reconfiguration of equipment to operational mode.



**NOTE**

All equipment or tools secured to the floor or walls of the shelter must be carefully tightened to specific torque limits. See Appendix F.

SECTION II. PREPARING SHOP FOR OPERATION


2-2. ECU shelves, lowering procedures.

NOTE


The following procedures apply only if the ECUs are to be installed.

NOTE

(For shelter P/N 136-0000-101)  
 One ECU opening is located in the fold-out end wall and one ECU opening is located in the fold-out side wall. (For shelter P/N 5-4-2828-1) Both ECU openings are located in the fold-out end walls. One ECU opening in each fold-out end wall.




- a. Remove four plugs (1) on outside of each shelf (2).




- b. Inside shelter, on end wall, remove two bolts (3) securing top bar (4) in place. Remove bar (4).


c. Loosen two latch bolts (5). Turn latches (6) clockwise, a quarter turn, to release fold-down shelf (2).




d. Lower shelf (2) to the limit of the support cables (7).




e. Position top bar (4) in old location and install two bolts (3).




f. Remove four bolts (8) securing bars (9) and (10) in place. Remove both bars.



g. Loosen and turn latches (6) and lower the other ECU shelf (2) as in steps c. and d.




h. Position bar (9) across top of other ECU opening and install bolts (8).






- i. Position bar (10) across bottom of other ECU opening and install bolts (8).




**2-3. Positioning shop equipment; Unit A, for operation.** The following procedures and recommended sequence for moving equipment in Unit A will be observed. The new positions, where equipment will be located on the expanded side of the shelter, are also identified.

- a. Positioning bandsaw.

1. Remove four bolts (1) from two brackets (2) located on both sides of bandsaw (3).



2. Position bandsaw (3) by sliding along floor to new location.





3. Obtain eight set screw plugs (4) from storage chest (5) and install in empty floor insert holes (6).

**NOTE**

Shop storage chest is located on the fixed side wall near the ceiling at cargo door entrance. Remove storage chest from mounting bracket for easy access to hardware.



b. Positioning Cabinet No. 1.

1. Remove five bolts (1) from two brackets (2) located on both sides of cabinet (3).



2. Position cabinet (3) sliding along floor to new location.


3. Obtain ten set screw plugs (4) from storage chest and install in empty floor insert holes (5).



c. Positioning Cabinet no. 2.

1. Follow procedures in paragraph b. Locate cabinet (1) by sliding along floor to new location.

2. Obtain setscrew (2) and install in empty floor insert holes (3).




**WARNING**

Four people are needed when moving or lifting the Environmental Control Units (ECU). Each unit weighs approximately 270 pounds. Trying to move or lift an, ECU without sufficient help can cause serious injury to personnel.


d. Positioning ECUs for operation.

1. Loose cargo straps (1) on ECU (2) and (3) (located under sheet metal brake). Unhook cargo straps from ring bolts (4) and remove.




2. For shelter P/N 136-0000-101) Use lift handles (5) to raise ECU (2), from the support frame (6); carry outside and position near side wall shelf (7). (For shelter P/N 5-4-2828-1) Use lift handles (5) to raise ECU (2) from the support frame (6); carry outside and position near end wall shelf (7A).

3. Use lift handles (5) and raise ECU (3) from floor frame (6). Carry outside and position near end wall shelf (8).




Change 1 2-12


4. Lift ECU (2) and (3) onto fold-down shelves (7) and (8) with control panel (9) facing toward inside of shelter.




5. Slide ECU (2) and (3) forward between support cables (10).



6. Align bolt holes (11) in base of ECU with holes (12) in shelves (7) and (8).




7. Mounting hardware is supplied with each ECU. Install IAW TM 54120-369-14.




e. Storing ECU support frames.

1. Remove four ring bolts (1) from both ECU support frames (2). Move frames to expanded side wall.




2. Position frames (2) against wall, align holes in frames with wall inserts and secure each frame with four ring bolts (1).

3. Hook cargo straps (3) to ring bolts (1). Tighten and secure.





4. From shop storage chest obtain eight set screw floor plugs (4) and insert into empty ring bolt holes (5).
5. Repeat step 4 with floor insert holes of second frame.



f. Attaching security bars to ECUs.


1. Before installing ECUs, remove seven screws from face of each ECU and store in storage chest.

**NOTE**


**Standard screws will be reinstalled whenever an ECU is to be evacuated for repair or replacement. Special retainer screws will be used to attach**

2. From shop storage chest remove fourteen special retainer screws.

3. Install four special retainer screws (1) thru top bar (2) into face of ECU (3) and tighten.




4. Install three special retainer screws (4) thru bottom bar (5) into face of ECU (3) and tighten.
5. Repeat steps 1 thru 4 with other ECU.




g. Installing counterweights on sheet metal brake.

1. Remove counterweights (1) from support bracket (2) at rear of sheet metal brake (3).



2. Install counterweights (1) in support holes (4) of brake (3). One on each side.




**WARNING**


To prevent possible injury to personnel set screws must be securely tightened to ensure counterweights do not slide out of support holes during operation of the sheet metal brake.

h. Installing back stop on shearing machine.


1. Remove both support bars (1) from bracket (2) located at rear of shearing machine (3).




2. Install support bars (1) in holes (4) tighten set screws (5).




3. TIGHTEN SET SCREWS (5) SECURELY.



3. Remove nuts and washers (6) from bolts (7) and remove adjustable back stop (8). Replace bolts (7) nuts and washers (6) in bracket, tighten.



4. Slide back stop (8) on support bars (1). Adjust, IAW manual for shearing machine.




**WARNING**


Perform the following steps only if the shrinking/stretching machine is to be used. Removal of the retainer bar releases the foot pedal. When in operation, the foot pedal extends well out in front of the machine and into the door way of personnel entrance. This extended pedal could result in injury to personnel running into or tripping over the pedal. When not in use the retainer bar, which holds the foot pedal in place, will be installed.

i. Preparing the shrinking/stretching machine for operation.

1. Remove nut and washer (1) from stop bar (2) inserted through shrinking/stretching machine base (3). Remove bar (2).



- (4). 2. From cabinet, obtain lower jaw assembly




3. Position lower jaw assembly (4) on shrinking/stretching machine and install retainer screw (5).

**2-4. Positioning shop equipment, Unit B, for operation.** The following procedures and recommended sequence for moving equipment will be observed. The new positions, where equipment will be located on the expanded side of the shelter are also identified.

**WARNING**

Four people are needed when moving or lifting the Environmental Control Units (ECU). Each unit weighs approximately 270 pounds. Trying to move or lift an ECU without sufficient help can cause serious injury to personnel.





a. Positioning ECUs for operation.

1. Loosen cargo straps (1) on ECU (2) and (3). ECU (2) located at personnel door entrance. ECU (3) located at cargo door entrance.


2. Unhook cargo straps (1) from ring bolts (4) and remove.

3. Use lift handles (5) and raise ECU (2) from floor frame (6). Carry outside and position near end wall shelf (7).


4. For shelter P N 136-0000-101) Raise ECU (3) from frame (6); carry outside and position near SIDE WALL shelf (\*). (For shelter P N 5-4-2828-1) Raise ECU (3) from frame (6); carry outside and position near END WALL shelf (8A).




5. Lift ECU (2) and (3) onto fold-down shelves (7) and (8) with control panel (9) facing toward inside of shelter.



6. Slide ECU (2) and (3) forward between support cables (10).



7. Align bolt holes (11) in base of ECUs with holes (12) in shelves (7) and (8).




**SECURE !  
BEFORE !**

8. Mounting hardware is supplied with each ECU. Install IAW TM 5-4120-369-14.


b. Storing ECU support frames is the same as para 2-3-e.

c. Attaching ECU security bars is the same as para 2-3-f.

d. Positioning cabinet, bin storage.




1. Remove five bolts (1) from two brackets (2) located on both sides of cabinet (3).






2. Position cabinet (3) by sliding along floor to new location.




3. Obtain ten set screw plugs (4) from storage chest (5) and install in empty floor insert holes (6).




Change 1 2-23

e. Positioning stake support table.


1. Remove eight bolts (1) (two from each leg) of stake table (2).



2. Position stake table (2) by sliding along floor to new location.



3. Obtain eight set screw plugs (3) from storage chest and install in empty floor insert holes (4).




f. Positioning throatless shear stand.


**NOTE**

**Operating handle should only be installed when throatless shear is in use.**


1. Remove four bolts (1) from base of throatless shear stand (2).



2. Position stand (2) by sliding along floor to new location.



3. Obtain four set screw plugs (3) from storage chest and install in empty floor insert holes (4).




Change 1 2-26

2-5. Safeguarding bolts and washers.

**CAUTION**

Care must be taken to ensure that the proper bolts and washers are available to secure equipment when shop is to be transported. Lack of correct hardware could cause extensive damage to equipment or the shelter when the shop is moved.

All bolts and washers removed from equipment will be collected and placed in cotton mailing bags (see item 2, App D). Bags are kept in the shop storage chest for safekeeping until shelter is to be moved and equipment rebolted to the floor.



2-6. Electric power.

**WARNING**

HIGH VOLTAGE exists in the electrical system of the shop. All electrical inspections, repairs or replacement will be performed with the power off and only by qualified electricians. Serious shock hazards exist which could result in injury or even death to personnel.


a. Main power cable connection. (Procedures apply to both Unit A and Unit B).

1. In Unit A, remove cable from cabinet (1). In Unit B, remove cable from cabinet (2).


2. Unroll power cable (1) and extend it between shop (3) and power distribution panel (4).

**CAUTION**


Ensure that the power cable is not twisted, kinked or laid over sharp rocks or projections. Where possible cable should not be routed through any deep ground depressions where water may accumulate.



3. Before connecting power cable ensure main circuit breaker (5) in breaker panel (6) is in OFF position.




4. Remove dust cap (7) from P1 receptacle at power entry (8); insert female power plug (9) and secure with lock ring (10).





b. Connecting power to ECUs.

1. Inspect installation of ECU (1) and power cable (2).
2. Position MODE SELECTOR switch (3) to OFF.
3. Remove cap (4) from receptacle (6).
4. Push end of connector (5) into power input receptacle (6). Push until seated.
5. Screw connector lock ring (7) on receptacle (6).
6. Repeat steps 1 thru 5 for other ECU.



c. Connecting power distribution to panel to generator.

1. Ensure all circuit breakers on the power distribution panel are in the off position.
2. Ensure pigtail is connected to the power distribution panel.
3. A qualified electrician will connect black wire from pigtail to lug L1 on generator, red wire to L2, green wire to L3, and white wire to LO.




Change 1 2-30



d. Power on to shop.

1. Remove ground rod assembly from storage chest.

2. Install external ground rod IAW TM 10-5411-201-14.



e. Power on to shop.

1. A qualified electrician will make connections of main power cable (1) from shop (2) at power distribution panel (3).

2. Shop personnel will move the main circuit breaker (4) in the circuit breaker panel (5) from OFF to ON.

3. See that all other circuit breaker are in the ON position.

Change 2 2-30.1/(2-30.2 blank)

**2-7. Other shop utilities.**

In addition to electrical power the shops are provided with connections for compressed air and water. (Procedures apply to both Unit A and Unit B).


a. Compressed air connection.

1. Remove protective dust cap (1) from air inlet nipple (2) at the service utility panel (3). Store in shop storage chest.

2. From storage chest remove a quick disconnect coupling (4).

3. Install the quick disconnect coupling (4) on air inlet nipple (2).

4. Tighten coupling (4) securely.



b. Water supply connection.

**NOTE**



**When water is to be supplied to shelter proceed as follows.**

1. Remove protective dust cap (1) from each end of water feed thru connector (2).

2. Install adapters and fittings as required.

**NOTE**

**Reposition storage chest in mounting bracket when no longer required.**



**2-8. Checking shelter level.** Once all equipment is in the recommended operational position recheck leveling of shelter. Use procedures in TM 10-5411-201-14 to verify and adjust level. Correct adjustment is essential to ensure proper operation of machine tools, doors and access panels.


The Sheet Metal/Paint Shop is now operational.

**SECTION III. PREPARATION FOR SHIPMENT**

**2-9. Striking the shelter.** Shop utilities (other than electrical).


a. Disconnecting water supply. (When installed)

1. Obtain two protective dust caps (1) from shop storage chest.
2. Install dust cap on each end of feed thru connector (2), tighten securely.




b. Disconnecting compressed air.

1. Remove male quick disconnect coupling (1) from the air inlet nipple (2). Store in shop storage chest.



2. Obtain a dust cap (3) from storage chest.


3. Install dust cap (3) on air inlet nipple (2), tighten securely.



**2-10. Power shutdown.**

a. See that all electrical tools and shop equipment have been turned OFF.

b. Move main circuit breaker (1) in the circuit breaker panel (2) from ON to OFF.




c. Disconnecting ECUs.

1. Place MODE SELECTOR switch (1) of ECU (2) in OFF position.

2. Unscrew lock ring (3) and pull connector (4) from ECU receptacle (5). Store cable (6) IAW TM 10-5411-201-14.


3. Replace cap (7) on receptacle (5).



d. Disconnecting power distribution panel from generator.

1. Ensure all circuit breakers on the power distribution panel are in the off position.


2. Disconnect color coded wires on pigtail from lugs on generator.





Change 1 2-34

e. Disconnecting main power cable.

1. Unscrew lock rings (1) disconnect power cable connector (2) at power entry (3).
2. Replace dust cap (4) on P1 receptacle (5).
3. After qualified electricians have disconnected male end of cable (6) from power distribution panel (7) inspect, clean cable (8) with rag and roll.



4. For Unit A, replace power cable (8) in cabinet (9). For Unit B, replace cable in cabinet (10).



f. Removal of external ground rod (Unit A and Unit B).

1. Remove external ground rod IAW TM 10-5411-201-14.
2. Store ground rod assembly in storage chest.

**2-11. Bolts and washers for equipment tie down.**

**CAUTION**

Care must be taken to ensure that the proper bolts and washers are used to secure equipment when shop is transported. Lack of correct hardware could cause extensive damage to equipment or the shelter.

- a. Remove cotton bags with tie down bolts and washers from shop storage chest.
- b. Inspect hardware for damage or missing parts.
- c. Check out a torque wrench from tool crib.
- d. All bolts will be tightened to the specific torque value given. See App. F.


**CAUTION**

Torque values provided must be respected to prevent possible damage to equipment or the shelter. Improper procedures could result in extensive damage to government property.


**2-12. Repositioning shop equipment, Unit A, for transport.** The following procedures, and recommended sequence, for moving equipment from the operational mode to the transport or storage mode will be observed.

- a. Removing back stop on shearing machine.


1. Remove adjustable back stop (1) from support bars (2) at rear of shearing machine (3).




2. Remove nuts and washers (4) from bolts (5) in bracket (6).




3. Aline holes in back stop (1) with holes in bracket (6), install bolts (5) with washers and nuts (4). Tighten securely.



4. Loosen set screws (7), remove support bars (2).




5. Position support bars (2) in bracket (6).






b. Removing counterweights on sheet metal brake.


1. Loosen set screws (1) on each counterweight (2).



2. Remove counterweights (2) from support holes (3).




3. Position counterweights (2) on support bracket (4).



c. Preparing shrinking/stretching machine for transport.


1. Loosen retainer screw (1) and remove lower jaw assembly (2) from shrinking/stretching machine (3).

2. Insert retainer screw (1) into lower jaw assembly (2) and store jaw assembly in cabinet.





3. Push pedal (4) toward rear of shrinking/stretching machine (3) and insert stop bar (5) through holes in frame.

4. Replace washer and nut (6) on bar (5), tighten.




d. Installation of ECU support frames.

1. Loosen and remove cargo straps (1).




2. Remove eight set screw plugs (2) from inserts (3) at transport location of ECU frames (see para 1-7-b). Stow plugs in storage chest.


3. Remove eight ring bolts (4) securing frames (5) to wall. Remove frames (5).



4. Position ECU frames (5) over floor inserts and align with holes (3).




5. Install the eight ring bolts (4) and securely tighten.




e. Repositioning ECUs for transport.

1. Remove mounting hardware securing ECU (1) to fold-down shelf (2).



2. Remove four special retainer screws (3) from top bar (4). Remove three special retainer screws (5) from bottom bar (6). Stow screws in storage chest.

3. Repeat steps 1 and 2 with other ECU.




f. Repositioning ECUs in support frames.


**WARNING**

Four people are needed when moving or lifting the Environmental Control Units (ECU). Each unit weighs approximately 270 pounds. Trying to move or lift an ECU without sufficient help can cause serious injury to personnel.


1. Slide ECU (1) off shelf (2) and carry to storage chest (3). (For shelf 2 P/N 136-000-101) Slide ECU (4) off shelf (5) and carry to storage chest (3). (For shelf 5 P/N 136-000-101) Slide ECU (1) off shelf (5A) and carry to cargo door (6). (For shelf 5A P/N 136-000-101) Slide ECU (4) off shelf (5A) and carry to cargo door (6). (For shelf 5A P/N 136-000-101)




2. Using lift handles (7) raise ECU (4) and position in frame (8) toward rear of sheet metal brake (9).



3. Using lift handles (7) raise the second ECU (1) and position it in the outer floor frame (10) (nearest personnel entrance door).




4. Position two cargo straps (11) on each ECU, and hook to ring bolts (12). Tighten cargo straps to secure ECUs in place.




g. Closing ECU shelves.


1. (For shelter P/N 136-0000-101) From side wall ECU opening (1), remove two bolts (2) from top bar (3) and two bolts (4) from bottom Bar (5). Remove bars. (For shelter P,N 5-4-2828-1) ?  end wall ECU opening (1), remove two bolts (2) from top bar (3) and two bolts (4) from bottom bar (5). Remove bars.




2. Position bar (3) and bar (5) between bars (6) and (7) of ECU shelf opening, on end wall, Install bolts (2) and (4) and washers (8).



3. Remove bolts (2) from top bar (6) and remove bar.




4. Close shelf (9), turn latches (10) to the vertical position and tighten latch bolts (11).




5. Position top bar (6) and install two bolts (2) with washers (12).

6. Close other ECU shelf and secure latches as in step 4.




7. Insert four plugs (13) in each ECU shelf.




h. Repositioning cabinet, bin storage, No. 1 for transport.


1. Remove ten set screw plugs (1) from floor inserts (2) at transport location of cabinet. Stow plugs (1) in storage chest.



2. Position cabinet (3) by sliding along floor to transport location.




3. Aline holes (4) in cabinet bracket (5) with floor inserts and install ten bolts (6) with washers (7).






i. Repositioning cabinet, bin storage, No. 2 for transport.

1. Follow procedures in paragraph 2-12-h.  
Locate cabinet (3) by sliding along to transport location.





2. Align holes (4) in cabinet bracket (5) with floor inserts and install bolts (6) with washers (7).




j. Positioning bandsaw for transport.

1. Remove eight set screw plugs (1) from floor in set (2) at transport location of bandsaw. Stow plugs (1) in storage chest.




2. Position bandsaw (3) by sliding along floor to transport location.

3. Aline holes (4) in bandsaw bracket (5) with floor inserts and install bolts (6) with washers (7).





**2-13. Repositioning shop equipment, Unit B, for transport** The following procedures, and recommended sequence, for moving equipment from the operational mode to the transport or storage mode will be observed.

- a. Repositioning throatless shear stand to transport location.



1. Remove four set screw plugs (1) from floor inserts (2) at transport location of stand. Stow plugs (1) in storage chest.


2. Position stand (3) by sliding along floor to transport location.  
2. Position stand (3) by sliding along floor to transport location.




3. Aline holes (4) in throatless shear stand (3) with floor inserts and install four bolts (5) with washers (6).

b. Repositioning stake support table for transport.


1. Remove eight set screw plugs (1) from floor inserts (2) at transport location of table. Stow plugs (1) in storage chest.



2. Position table (3) sliding along floor to transport location.




3. Align holes (4) in stake table (3) with floor inserts (2) at transport location of cabinet. Stow plugs (1) in storage chest.




c. Repositioning cabinet, bin storage for transport location.


c. Repositioning cabinet, bin storage for transport location.  
 1. Remove ten set screw plugs (1) from floor inserts (2) at transport location of cabinet. Stow plugs (1) in storage chest.



2. Position cabinet (3) by sliding along floor to transport location.




3. Aline holes in cabinet bracket (5) with floor inserts and install ten bolts (6) with washers (7).




Change 1 2-51

- d. Installation of ECU floor frames is the same as para 2-12-d. Locate frames IAW floor plan, para 1-7-d (Transport Mode).
- e. Repositioning ECUs for transport.

1. Remove mounting hardware securing ECU (1) to fold-down shelf (2).



2. Remove four special retainer screws (3) from top bar (4). Remove three special retainer screws (5) from bottom bar (6). Stow screws in storage chest.



3. Repeat steps 1 and 2 with other ECU.


- f. Repositioning ECUs in support frames.

**WARNING**


Four people are needed when moving or lifting the Environmental Control Units (ECU). Each unit weighs approximately 270 pounds. Trying to move or lift an ECU without sufficient help can cause serious injury to personnel.




- Slide ECU (1) off shelf (2) and carry to personnel door (3). (For shelter P N 136-0000-101) Slide ECU (4) off shelf (5) and carry to cargo door (6). (For shelter P N 5-4-2828-1) Slide ECU (4) off shelf (5A) and carry to cargo door (6).




- Using lift handles (7) raise ECU (4) and position in frame (8) just inside cargo door (6).



3. Using lift handles (7) raise ECU (1) and position in frame (8) just inside personnel door (3).



4. Attach two cargo straps (9) to each ECU and hook to ring bolts (10). Tighten straps to secure ECUs in place.




g. Closing ECU shelves. Procedures for closing the ECU shelves is the same as page 2-12-g.


**2-14. Storage procedures.** In the event the Sheet Metal/Paint Shop (Unit A and Unit B) is to be placed in storage, the provisions of TM 740-90-1, TM 743-200-1 and applicable shop equipment TM will be followed.

**2-15. Striking the shelter.** Procedures for striking the shelter are contained in TM 10-5411-201-14. In addition, the following "Supplemental Instructions" will be observed.

- a. Remove screws (1) at both corners of fold-out floor.



- b. Install cable (3) and retainer block (2) with screws (1).




**NOTE**


When floor is lowered (to allow roof clearance for folding) the devices securing fold-out floor counterbalance cables can be disengaged.

**WARNING**

When all equipment and materiel is stored on the stationary side of the shelter. The limited floor space presents a safety hazard to operating personnel. This is most critical during the raising and lowering of the roof panel. Failure to observe supplemental instructions could result in serious injury to personnel. Personnel inside the shelter could become trapped between the roof panel and equipment bolted to the floor.



- c. Two people inside the shelter using the support struts (1), will lower the roof panel (2) until two personnel outside can reach and hold the weight of the roof(2).
- d. Inside personnel will shorten the struts (1) and secure to roof brackets (3). They will then move into position to assist outside personnel.
- e. After all personnel are clear allow the roof panel (2) to close to the vertical position.



- f. After the shelter has been folded as detailed in steps a thru e and prepared in accordance with TM 10-5411-201-14, the Sheet Metal/Paint Shop is ready for transport or storage.

## CHAPTER 3

## MAINTENANCE INSTRUCTIONS

SECTION I. REPAIR PARTS, SPECIAL TOOLS,  
TMDE, AND SUPPORT EQUIPMENT

- 3-1. Common tools and equipment.** For authorized common tools and equipment, refer to the Modified Table of Organization and Equipment (MTOE) applicable to the AVIM unit.
- 3-2. Torque values.** All equipment or tools secured to the floor or walls of the shelter must be carefully tightened to specific torque limits. These torque limits are contained in Appendix F of this manual.
- 3-3. Special tools, TMDE, and support equipment** No special tools required.
- 3-4. Repair parts.** Repair parts, hardware and bulk stock are listed in Appendix C of this manual.

## SECTION II. SERVICE UPON RECEIPT

**3-5. Checking equipment.**

- a. Once shelter has been erected, inventory for completeness of shop equipment.
- b. Inspect equipment to ensure that all items are still firmly secured to floor and wall mounts. In the event an item has broken loose and been damaged or has caused damage to other equipment of the shelter a DD Form 6, Packaging, Improvement Report will be submitted.
- c. After equipment has been positioned to the recommended operational floor plan check all items requiring service. Preventive maintenance (PM) and preoperational services will be performed IAW applicable equipment TM.

**SECTION III. MAINTENANCE PROCEDURES**

**3-6. Insert Fasteners and Bolts - Inspect**

**3-6**

**This task covers: Inspection of all insert fasteners and bolts common to the Sheet Metal/P5impop**

**INITIAL SETUP:**

Tools:

Torque wrench, 0-00 inch-pounds range  
 Tool Kit, Airframe, NSN 5180-00-323-4876

Personnel Required:

68G Aircraft Structural Repairer

Reference Information:



TM 55-1500-204-2511

**INSPECTION**

**NOTE**

**Go to step 2 if bolts are serviceable.**

1. Inspect bolts.
  - a. Remove bolt (1) that will not tighten to specific torque (see App F).




- b. Inspect bolt (1) for damaged threads or rounded head.

**GO TO NEXT PAGE**


**3-6. Insert Fasteners and Bolts - Inspect****3-6**

- c. Install new bolt (1) as required.



2. Inspect insert when bolt is not damaged.

- a. Visually inspect insert (2) with flashlight (3).  
b. If insert threads are damaged or insert has broken loose in adhesive potting, replace. See TASK 3-7.

**END OF TASK**

---

**3-7. Insert Fasteners - Replace****3-7**

---

**This task covers: Replacement of insert fasteners**

---

**INITIAL SETUP****Personnel Required:**

68G Aircraft Structural Repairer

**Reference Information:**

TM 10-5411-201-14

**WARNING**

Methylethylketone (MEK), used to clean replacement inserts, is flammable and toxic. Use only in well ventilated areas. Breathing vapors can cause headaches and nausea. Repeated contact with skin can cause irritation. If irritation persists see a doctor. Contact with eyes, wash immediately with water for 15 minutes and seek medical attention.

**WARNING**

Safety goggles will be worn when drilling and cleaning holes for insert replacement. Flying chips can cause eye injury or even blindness.

---

**END OF TASK**





**3-8. Fixtures - Fire Extinguisher - Removal/Installation****3-8****This task covers: Removal and installation of the fire extinguisher****INITIAL SETUP**

Personnel Required:  
68G Aircraft Structural Repairer

**REMOVAL/INSTALLATION**

Release/install clamp (1) securing fire extinguisher (2) in bracket (3) and remove/install fire extinguisher.

**END OF TASK**

**3-9. Fixtures - Fire Extinguisher Mounting - Inspect****3-9****This task covers: Inspection of fire extinguisher mounting****INITIAL SETUP**Tools:

Torque wrench, 0-600 inch-pound range  
Tool Kit, Airframe, NSN 5180-00-323-4876

Personnel Required:

68G Aircraft Structural Repairer

Reference Information:


TM 55-1500-204-25/1

Equipment Condition:


Fire Extinguisher  
Removal/Installation TASK 3-8

**INSPECTION**

1. Check fire extinguisher bracket (1) for looseness.




2. Check torque (App F) on mounting bolts (2) when loose.

**GO TO NEXT PAGE**

**3-9. Fixtures - Fire Extinguisher Mounting - Inspect (Cont)****3-9**


3. Bolt(s) (2) will not tighten to specification, remove bolts (2) and bracket (1). See TASK 3-6.



4. Position fire extinguisher bracket (1) and align bolt holes with wall inserts and install bolts (2) with washers (3).

**NOTE**

Four additional wall inserts, inside cargo door on end wall, have been provided as an alternate fire extinguisher mounting point.

**END OF TASK**

**3-10. Water/Oil Separator Mounting - Inspect****3-10****This task covers: Inspection of water/oil separator mounting****INITIAL SETUP****Tools:**

Torque wrench, 0-600 inch-pound range

Tool Kit, Airframe, NSN 5180-00-323-4876

**Personnel Required:**


68G Aircraft Structural Repairer

**Reference Information:**


TM 55-1500-204-25/1

**INSPECTION**

1. Check water/oil separator bracket (1) for looseness.




2. Check torque (App F) on mounting bolts (2) when loose.

**GO TO NEXT PAGE**


3-10. Water/Oil Separator Mounting - Inspect (Cont)

3-10

3. Bolt(s) (2) will not tighten to specification, remove bolts (2) and water/oil separator (1). See TASK 3-6.



4. Position water/oil separator (1) over inserts and install bolts (2) with washers (3).



END OF TASK

**3-11. Water/Oil Separator Air Hose and Fittings - Inspect****3-11****This task covers: Inspection of air hose and fittings****INITIAL SETUP**Tools:

Tool Kit, Airframe, NSN 5180-00-323-4876


Personnel Required:

68G Aircraft Structural Repairer

**INSPECTION****WARNING**

**Make sure compressed air supply is disconnected before attempting any work on the water/oil separator. Do not direct compressed air near eyes or directly against skin. Wear goggles; high pressure air against eye can cause blindness.**


1. Check air hose (1); replace if checking or cracks are visible. See TASK 3-12.

**GO TO NEXT PAGE**


3-11. Fixtures - Water/Oil Separator Air Hose - Inspect (Cont)

3-11

2. Check threads on nipple (2) outside shelter.



3. Ensure dust cover (3) is available and used as required.



END OF TASK

---

**3-12. Fixtures - Water/Oil Separator Air Hose - Replace**

---

**3-12****This task covers: Replacement of hose assembly**

---

**INITIAL SETUP**Tools:

Tool Kit, Airframe, NSN 5180-00-323-4876

Materiel:

Hose, Non-metallic


Personnel Required:68G Aircraft Structural Repairer

---

**REPLACEMENT****WARNING**

**Make sure compressed air supply is disconnected before attempting any work on the water/oil separator. Do not direct compressed air near eyes or directly against skin. Wear goggles; high pressure air against eyes can cause blindness.**


1. Remove both loop clamps (1) from defective hose (2).

**GO TO NEXT PAGE**




**3-12. Fixtures - Water/Oil Separator Air Hose - Replace (Cont)**


2. With knife (3) slit hose lengthwise from protective cap (4) to end of fitting (5) (approx 1 1/2 inches).



3. Bend hose (2) back over fitting (5) and snap off with quick tug.
4. Repeat steps 2 and 3 at other end of hose.



5. Slide loop clamps (1) over new hose assembly (2).




**GO TO NEXT PAGE**


**3-12. Fixtures - Water/Oil Separator Air Hose - Replace (Cont)****3-12**

6. Push hose (2) on fitting (5) until end bottoms underneath protective cap (4).

Repeat at other end of hose



7. Install loop clamps (1) in original position and secure.




**END OF TASK**

**3-13. Fixtures - Water Feed Thru Connector - Inspect****3-13****This task covers: Inspection of connector****INITIAL SETUP****Personnel Required:**


68G Aircraft Structural Repairer

**INSPECTION**

1. Check condition of threads on both ends of water feed thru connector (1).
2. See that dust caps (2) are available and used as required.



3. Ensure that weld (3) on connector (1) is not cracked or broken. If defective, see TASK 3-14.

**END OF TASK**

**3-14. Fixtures - Water Feed Thru Connector - Replace**

**3-14**

**This task covers: Replacement of connector**

**INITIAL SETUP**

Tools:

Tool Kit, Airframe, NSN 5180-00-323-4876

Materiel:

New feed thru connector - App E


Adhesive, Sealant NSN 8040-00-877-9872

Personnel Required:


68G Aircraft Structural Repairer and Helper

**REPLACEMENT**

1. Have helper hold nut (1) inside shelter.
2. Remove six screws (2), securing connector (3) in place.



3. Remove connector (3) from wall and scrape off old sealant (4).
4. Details for fabrication of new connector are in App E.




**GO TO NEXT PAGE**


3-14. Fixture-Water Feed Thru Connector-Replace (Cont)

3-14


- Apply adhesive on side of collar (5) toward long end of connector (3). (Use adhesive, item 1, App D).



- Install new connector (3) from outside of shelter; long end of nipple thru hole.



- Replace six screws (2), have helper install washers and nuts (1), tighten securely.



END OF TASK

---

**3-15. Ground Rod/Strap-Inspect**

---

**3-15****This task covers: Inspection of ground rod and strap**

---

**INITIAL SETUP:**Tools:

Tool Kit, Electrical Repairer, Army Aircraft, NSN 5180-00-323-4915  
Multimeter

Personnel Required:

68F Aircraft Electrician

Reference Information:


TM 55-1500-204-25/1  
TC 11-6

---

**INSPECTION****WARNING**


**HIGH VOLTAGE** exists in the electrical system of this shop. All electrical inspections, repairs or replacements shall be performed with the power OFF and only by qualified electricians. Serious shock hazards exist which could result in serious injury or death to personnel.

1. Check ground rod (1).
  - a. Ensure rod is firmly driven into ground.
  - b. Ensure that clamp (2) and screw (3) are securely fastened.
  - c. Ensure there is no sign of oxidation around clamp (2) or screw (3).
  - d. Check that ground strap (4) is not frayed or broken.


**GO TO NEXT PAGE**

**3-15. Ground Rod/Strap - Inspect (Cont)****3-15**

2. Check ground strap (4) connection at terminal lug (5) on shelter power entry panel (6).



3. Use multimeter (7), check condition of ground. (Use CT11-6)
  - a. Set for AC voltage
  - b. Red lead on shelter
  - c. Black lead on ground strap
  - d. -05volts - adequate ground
  - e. Over 5volts - poor ground

**END OF TASK**

**NOTE**

The following special brackets and components were fabricated for use in the Sheet Metal/Paint Shop, Unit A. Detailed drawings of the brackets/components are in Appendix E.

- Bracket - Cabinet, Bin Storage
- Bracket - Bandsaw
- Bracket - Shrinking/Stretching Machine
- Bracket - Shearing Machine
- Bracket - Storage Chest
- Bracket - Counterweight, Metal Brake
- Bracket - Support bars and Backstop, Metal Shears
- Book Rack Mounting
- Tool Box Rack Mounting (6)
- Support Frames, ECU
- Security Bars, ECU

The following special brackets and components were fabricated for use in the Sheet Metal/Paint Shop, Unit B. Detailed drawings of the brackets/components are in Appendix E.

- Bracket - Cabinet, Bin Storage
- Bracket - Storage Chest
- Book Rack Mounting
- Tool Box Rack Mounting (18)
- Support Frame, ECU
- Security Bars, ECU
- Stand, Throatless Shear
- Bench, Stake Holder

The task of INSPECTION, REPAIR and REPLACEMENT of all brackets and fabricated components is typical. The book rack is used to show the required maintenance procedures. All other brackets/components will be treated the same.



**3-16. Special Brackets and Fabricated Components, Book Rack-Inspect****3-16****This task covers: Inspection of book rack****INITIAL SETUP:**Tools:

Torque wrench, 0-600 inch-pound range  
Tool Kit, Airframe, NSN 5180-00-323-4876

Personnel Required:


68G Aircraft Structural Repairer

Reference Information:


TM 55-1500-204-25/1

**INSPECTION**

1. Check book rack (1) for looseness.




2. Check torque (App F) on mounting bolts (2) when loose.


**GO TO NEXT PAGE**

**3-16. Special Brackets and Fabricated Components, Book Rack - Inspect (Cont)****3-16**


3. Bolt(s) (2) will not tighten to specification, remove bolts (2) and book rack (1). See TASK 3-6.



4. Check rack (1) for bends, cracks, or breaks in welds.  
 5. Any damage to book rack (1) requires repair. See TASK 3-17.


**6. After repair, in book rack.**

- a. Position rack (1) and align holes (3) in rack (1) with wall inserts.

**GO TO NEXT PAGE**

**3-16. Special Brackets and Fabricated Components, Book Rack -- Inspect (Cont)****3-16**

- b. Install bolts (2) with washers (4).

**END OF TASK**

**3-17. Special Brackets and Fabricated Components, Book Rack-Repair**

**This task covers: Repair of the book rack**

**INITIAL SETUP:**

Tools:

Tool Kit, Airframe, NSN 5180-00-323-4876  
 Welder, elect arc  
 Torque wrench, 0-600 inch-pound range

Materiel:

Rod, welding  
 Primer coating NSN 8010-00-297-0593  
 Enamel, white NSN 8010-00-159-4520

Personnel Required:

44E Machinist  
 68G Aircraft Structural Repairer

Reference Information:


TM 55-1500-204-25/1  
 MIL-W-8604A  
 TM 43-0139

REPAIR

**WARNING**

**Extreme care must be taken when performing all types of welding operations. Serious health and fire hazards exist. Harmful light rays can cause eye injury or even blindness. Protective face masks and goggles must be used as well as other special clothing to reduce risks. Poisonous fumes, burns, electric shock, fire and explosion hazards are some of the additional possibilities of injury associated with welding operations. It is essential that all safe practices be strictly observed.**

1. Remove four bolts (2) holding book rack (1) to wall remove rack.




**GO TO NEXT PAGE**

**3-17. Special Brackets and Fabricated Components, Book Rack - Repair (Cont)**

**3-17**


2. Repair cracks or breaks in rack (1) by welding; IAW TM 55-1500-204-25/1 and MIL-W-8604A. (Use welding rod, item 6; App D or equivalent).



**NOTE**

Replacement of book rack is required when any repair results in a change to the original design or dimensions of the book rack. See TASK 3-18.


3. After repair, install book rack.
  - a. Touch up paint, as required. (Use primer, item 5, and enamel, item 4, App D.)
  - b. Position bookrack (1) on wall and aline holes (3) in rack with wall inserts.



**GO TO NEXT PAGE**

**3-17. Special Brackets and Fabricated Components, Book Rack - Repair (Cont)****3-17**

4. Install four bolts (2) in book rack (1) with washers (4).

**END OF TASK**

**3-18. Special Brackets and Fabricated Components, Book Rack - Replace**

**3-18**

**This task covers: Replacement of the book rack**

**INITIAL SETUP:**

Tools:

Tool Kit, Airframe, NSN 5180-00-323-4876

Torque wrench 0-600 inch-pound range

Material:

Primer, coating NSN 8010-00-297-0593

Enamel, white NSN 8010-00-159-4520

Personnel Required:

68G Aircraft Structural Repairer

Reference Information:


TM 55-1500-204-25/1

TM 43-0139


**REPLACEMENT**

1. Remove four bolts (2) from book rack (1) and remove rack.
2. Details for fabrication of new book rack are in App E.
3. New book rack.

- a. Paint; one coat primer and two coats enamel before installing. (Use primer, item 5, and enamel, item 4, App D.)




- b. Position rack (1), align holes in rack (3) with wall inserts.



**GO TO NEXT PAGE**

**3-18. Special Brackets and Fabricated Components, Book Rack - Replace (Cont****3-18**

4. Install bolts (2) in book rack (1) with washers (4).

**END OF TASK**



**3-19. Floor insert Fasteners and Plugs-Inspect**

**3-19**

**This task covers: Inspection of floor insert fasteners and plugs.**

**INITIAL SETUP:**

Tools:

Tool Kit, Airframe, NSN 5180-00-323-4876

Personnel Required:


68G Aircraft Structural Repairer

**INSPECTION**


**NOTE**

**Go to step 2 if plugs are serviceable.**


1. Inspect floor plugs.
  - a. Remove any floor plug (1) that will not screw into floor insert (2).



- b. Inspect plug (1) for damaged threads.



- c. Install new plug (1) as required.



2. Inspect floor insert when plugs are not damaged.
  - a. Visually inspect floor inserts (2) with flashlight (3).
  - b. If insert threads are damaged or insert has broken loose in adhesive potting, replace. See TASK 3-7.

**END OF TASK**

---

**3-20. Fixed Equipment/Components-Removal/Installation**

---

**3-20**

---

**This task covers: Removal/Installation of fixed equipment/component.**

---

**INITIAL SETUP:**Tools:

Tool Kit, Airframe, NSN 5180-00-323-4876


Personnel Required:68G Aircraft Structural Repairer

---

**REMOVAL/INSTALLATION****NOTE**

Permanently installed equipment or components should not be removed, however, in the event it becomes necessary to remove, reinstall or replace fixed equipment or shop components within the shelter, care must be taken to remove all bolts, nuts, and other fasteners. All cabinets and racks are bolted to the floor and unless isolated, are normally bolted to adjacent cabinets and/or to the wall and ceiling.

1. Remove bolts (1) nuts and washers (2).
2. During reinstallation of fixed equipment or components, the same hardware should be used so as to maintain the original integrity of the shop sets. This is especially critical in regard to items bolted to walls or ceilings.

**END OF TASK**

**APPENDIX A  
REFERENCES**

**A-1. Dictionaries of Terms and Abbreviations.**

AR 310-25.....Dictionary of United States Army Terms  
AR 310-50.....Authorized Abbreviations and Brevity Codes

**A-2. Publication Indexes.**

DA PAM 310-1.....Consolidated Index of Army Publications and Blank Forms

**A-3. Logistics and Storage.**

TM 743-200-1.....Storage and Materiel Handling

**A-4. Maintenance of Supplies and Equipment.**

AR 750-1.....Army Materiel Maintenance Concepts and Policies  
TM 5-4120-369-14.....Air Conditioner, Horizontal Compact, 18,000 BTU  
TM 10-5411-201-14.....Shelter, Tactical, Expandable, One Side NSN 5411-01-124-1377  
  
TM 43-0139.....Painting Operations Instructions for Field Use  
TM 55-1500-204-25/1.....General Aircraft Maintenance Manual

**A-5. Other Publications.**

AR 420-90.....Tire Prevention and Protection  
AR 55-38.....Reporting of Transportation Discrepancies in Shipments  
AR 700-58.....Packaging Improvement Report  
DA PAM 310-13.....Military Publications Posting and Filing  
DA PAM 738-751.....Functional Users Manual for the Army Maintenance Management System  
(TAMMS-A)  
FM 21-11.....First Aid for Soldiers  
MIL-W-8604A.....Welding, Fusion, Aluminum Alloy Process and Performance  
TC 11-6.....Grounding Techniques  
TB 43-180.....Calibration Requirements for the Maintenance Army Materiel  
TM 750-244-1-4.....Procedures for the Destruction of Aviation Ground Support Equipment  
(FSC 4920) to Prevent Enemy Use

\* U.S.G.P.O.: 1989-654-030/00081

## APPENDIX B MAINTENANCE ALLOCATION CHART

### SECTION I. INTRODUCTION

#### **B-1. General.**

- a. This section provides a general explanation of all maintenance and repair functions authorized AVIM personnel.
- b. The Maintenance Allocation Chart (MAC) in Section II designates overall authority and responsibility for the performance of maintenance functions on the Sheet/Metal Paint Shop. The application of the maintenance function to the end item or component will be consistent with the capacities and capabilities of the designated maintenance categories.
- c. Section III lists the tools and equipment required for each maintenance function as referenced from Section II.
- d. Section IV contains supplemental instructions and explanatory notes for a particular maintenance function.

#### **B-2. Maintenance functions.** Maintenance functions will be limited to and defined as follows:

- a. Inspect. To determine the serviceability of an item by comparing its physical and mechanical characteristics with established standards through examination (e.g., by sight, sound, or feel).
- b. Remove/Install. To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.
- c. Replace. To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and is shown as the 3d position code of the SMR code.
- d. Repair. The application of maintenance services, including fault location/troubleshooting, removal/installation, and disassembly/assembly procedures, and maintenance actions to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, or end item.

#### **B-3. Explanation of Columns in the MAC, Section II.**

- a. Column 1, Group Number. Column 1 lists functional group code numbers, the purpose of which is to identify maintenance of significant components, assemblies, and subassemblies, with the next higher assembly. End item group number is "00".
- b. Column 2, Component/Assembly. Column 2 contains the names of components, assemblies, and subassemblies for which maintenance is authorized.
- c. Column 3, Maintenance Function. Column 3 lists functions to be performed on the item listed in Column 2. (For detailed explanation of these functions, see paragraph B-2.)

d. Column 4, Maintenance Category. Column 4 specifies, by listing of a work time figure (hours) in the appropriate subcolumn(s), the category of maintenance authorized to perform the function listed in Column 3. This figure represents the active time required to perform that maintenance function at the indicated category of maintenance. The work time figure represents the average time required to restore an item (assembly, subassembly, component, or end item) to a serviceable condition under typical field operating conditions.

e. Column 5, Tools and Equipment. Column 5 specifies, by code, those common tool sets (not individual tools) and special tools, TMDE, and support equipment required to perform the designated function.

f. Column 6, Remarks. This column, when applicable, contains a letter code, in alphabetic order, which is keyed to the remarks contained in Section IV.

**B-4. Explanation of Columns in Tools and Test Equipment Requirements, Section III.**

a. Column 1, Reference Code. The tool and test equipment reference code correlates with a code in the MAC, Section II, Column 5.

b. Column 2, Maintenance Category. The lowest category of maintenance authorized to use the tool.

c. Column 3, Nomenclature. Name or identification of the tool.

d. Column 4, National Stock Number. The National Stock Number of the tool.

**B-5. Explanation of Columns in Remarks, Section IV.**

a. Column 1, Reference Code. The code recorded in Column 6, Section II.

b. Column 2, Remarks. This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

**SECTION II. MAINTENANCE ALLOCATION CHART  
FOR SHEET METAL/PAINT SHOP**

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
01	Insert Fasteners and Bolts	INSPECT REPLACE		.2 1.5		101 102	A, B & C D
02	Fixtures						
0201	Fire Extinguisher	REMOVE INSTALL		.1 .1			
020101	Fire Extinguisher Mounting	INSPECT		.1		101	
0202	Water/Oil Separator Mounting	INSPECT		.1		101	
020201	Water/Oil Separator Air Hose and Fittings	INSPECT REPLACE		.1 1.0		102 102	
0203	Water Feed Thru Connector	INSPECT REPLACE		.2 1.0		102	
03	Electrical						
0301	Ground Rod/Strap	INSPECT		.2		104	E
04	Machine Tool, Equipment, Special Brackets and Fabricated Components						
0401	Book Rack Mounting	INSPECT REPAIR REPLACE		.1 1.0 .5		101 102 & 103 101 & 102	

**SECTION II. MAINTENANCE ALLOCATION CHART  
FOR SHEET METAL/PAINT SHOP (Cont)**

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
0402	Support Frame, ECU	INSPECT		.2		101	
		REPAIR		1.0		102 & 103	
		REPLACE		.2		101 & 102	
0403	Security Bars, ECU	INSPECT		.2		101	
		REPAIR		1.5		102 & 103	
		REPLACE		.2		101 & 102	
0404	Bracket, Storage Chest	INSPECT		.1		101	
		REPAIR		.5		102 & 103	
		REPLACE		.4		101 & 102	
0405	Tool Box Rack Mounting (6 rack)	INSPECT		.2		101	
		REPAIR		1.0		102 & 103	
		REPLACE		.5		101 & 102	
0406	Bracket, Cabinet Bin Storage	INSPECT		.1		101	
		REPAIR		.5		102 & 103	
		REPLACE		.3		101 & 102	
0407	Bracket, Bandsaw	INSPECT		.1		101	
		REPAIR				102 & 103	
		REPLACE		.3		101 & 102	
0408	Bracket, Shrinking/ Stretching Machine	INSPECT		.1		101	
		REPAIR		.7		102 & 103	
		REPLACE		.3		101 & 102	

**SECTION II. MAINTENANCE ALLOCATION CHART  
FOR SHEET METAL/PAINT SHOP (Cont)**

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
0409	Bracket, Shearing Machine	INSPECT		.1	101		
		REPAIR		.7	102 & 103		
		REPLACE		.3	101 & 102		
0410	Bracket, Counterweight metal brake	INSPECT		.1	101		
		REPAIR		.7	102 & 103		
		REPLACE		.4	101 & 102		
0411	Bracket, Support Bars and Back Stop, Metal Shears	INSPECT		.1	101		
		REPAIR		.7	102 & 103		
		REPLACE		.4	101 & 102		
0412	Tool Box Rack Mounting (18 rack)	INSPECT		.3	101		
		REPAIR		2.0	102 & 103		
		REPLACE		.7	101 & 102		
0413	Stand, Throatless Shear	INSPECT		.2	101		
		REPAIR		1.5	102 & 103		
		REPLACE		.2	101 & 102		
0414	Bench, Stake Holder	INSPECT		.2	101		
		REPAIR		1.7	102 & 103		
		REPLACE		.2	101 & 102		
05	Floor Inserts Plugs	INSPECT		.1	102		



**SECTION III. TOOL AND TEST EQUIPMENT**

(1) TOOL OR TEST EQPT REF CODE	(2) MAINTENANCE CATEGORY	(3) NATIONAL NOMENCLATURE	(4) STOCK NUMBER
101	Intermediate Level	Tool Crib Shop Set	4920-01-139-4548
102	Intermediate Level	Tool Kit, Airframe	5180-00-323-4876
103	Intermediate Level	Machine Welding Shop	4920-01-139-4533
104	Intermediate Level	Tool Kit, Electrical Repairer, Army Aircraft	5180-00-323-4915

**SECTION IV. REMARKS**

(1) REFERENCE CODE	(2) REMARKS
A.	Torque value on 5/16" inserts not to exceed 100-140 inch pounds.
B.	Torque value on 1/4" inserts not to exceed 50-70 inch pounds.
C.	Torque value on 3/8" inserts not to exceed 160-190 inch pounds.
D.	Follow procedures in TM 10-5411-201-14.
E.	Electrical and ground checks to be made by qualified electrician.

## APPENDIX C REPAIR PARTS AND SPECIAL TOOL LIST

### SECTION I. INTRODUCTION

#### C-1. Scope.

This manual lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of Aviation Intermediate Maintenance of the Sheet/Metal Paint Shop. It authorizes the requisitioning, issue, and disposition of spares, repair parts and special tools as indicated by the Source, Maintenance and Recoverability (SMR) codes.

#### C-2. General.

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending numeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in NSN sequence.

b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list in alphanumeric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

#### C-3. Explanation of Columns.

a. Column 1, ILLUSTRATION. Column 1 is divided as follows:

(1) (a) FIG NO.) Figure Number. Indicates the figure number illustrating an exploded view of a functional group.

(2) (b) ITEM NO.) Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:

<b>Source Code</b>	<b>Maintenance Code</b>	<b>Recoverability Code</b>
<b>XX</b>	<b>1st two positions</b>	<b>XX</b>
<b>How you get an item</b>	<b>3rd position</b>	<b>4th position</b>
	<b>Who can install replace or use the item</b>	<b>Who can do complete repair* on the item</b>
		<b>Who determines disposition action on an unserviceable item</b>

\* Complete Rear: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) Source Code. The source code tells you how you get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follow:

<b>Code</b>	<b>Explanation</b>
PA	
PB	
PC	
PD	Stocked items; use the applicable NSN to request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3rd position of the SMR code.
PE	
PF	-----
PG	
KD	
KF	Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3rd position of the SMR code. The complete kit must be requisitioned and applied.
KB	-----
MO - (Made at org AVUM Category)	Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION and USABLE ON CODE (UOC) column and listed in the Bulk Material group of the repair parts list in the RPSTL. If the item is authorized to you by the 3rd position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of
MF - (Made at DS/AVIM Category)	
MH - (Made at GS Category)	
MD - (Made at Depot) maintenance.	

Code	Explanation
AO - (Assembled by org AVUM Category)	Items with these codes are not to be requested/requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the 3rd position code of the SMR code, authorizes you to replace the item, but the source code indicates the items are assembled at a higher level, order the item from the higher level of maintenance.
AF - (Assembled by DS/AVIM Category)	
AH - (Assembled by GS Category)	
AD - (Assembled by Depot)	
XA -	Do not requisition an "XA"-coded item. Order its next higher assembly. (Also, refer to the NOTE below.)
XB -	If an "XB" item is not available from salvage, order it using the CAGE Code and part number given.
XC -	Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number
XD -	Item is not stocked. Order an "XD"-coded item through normal supply channels using the CAGE Code and part number given, if no NSN is available.

**NOTE**

**Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes, except for those source coded "XA" or those aircraft support items restricted by requirements of AR 750-1**

(2) Maintenance Code. Maintenance codes tell you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

(a) The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to the following levels of maintenance.

Code	Application/Explanation
C -	Crew or operator maintenance done within unit/AVUM maintenance.
O -	Unit level VAVUM maintenance can remove, replace, and use the item.
F -	Direct support/AVIM maintenance can remove, replace, and use the item.
H -	General support maintenance can remove, replace, and use the item.

Code	Application/Explanation
L	- Specialized repair activity can remove, replace, and use the item.
D	- Depot can remove, replace, and use the item.

(b) The maintenance code entered in the fourth position tells whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i.e., perform all authorized repair functions). NOTE: Some limited repair may be done on the item at a lower category of maintenance, if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.) This position will contain one of the following maintenance codes.

**NOTE**

Some limited repair may be done on an item at a lower level of maintenance, if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.

Code	Application/Explanation
O	- Organizational or aviation unit is the lowest category that can do complete repair of the item.
F	- Direct support or aviation intermediate is the lowest level that can do complete repair of the item.
H	- General Support is the lowest level that can do complete repair of the item.
L	- Specialized repair activity (designate the specialized repair activity) is the lowest level that can do complete repair of the item.
D	- Depot is the lowest level that can do complete repair of the item.
Z	- Nonreparable. No repair is authorized.
B	- No repair is authorized. No parts or special tools are authorized for the maintenance of a "B" coded item. However, the item may be reconditioned by adjusting, lubricating, etc., at the user level.

(3) Recoverability. Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR Code as follows:

Recoverability Codes	Application/Explanation
Z	-Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in 3rd position of SMR Code.
O	-Reparable item. When uneconomically repairable, condemn and dispose of the item at organizational or aviation unit category..

Recoverability Codes	Application/Explanation
F	-Reparable item. When uneconomically reparable, condemn and dispose of the item at the direct support or aviation intermediate category..
H	-Reparable item. When uneconomically reparable, condemn and dispose of the item at the general support category.
D	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal of item not authorized below depot category.
L	-Reparable item. Condemnation and disposal not authorized below specialized repair activity (SRA).
A	-Item requires special handling or condemnation procedures because of specific reasons (e.g., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. Column 3, NATIONAL STOCK NUMBER. Column 3 lists the National stock number (NSN) assigned to the item. Use the NSN for requests/requisitions.

d. Column 4, FSCM, Column 4, the Federal Supply Code for Manufacturer (FSCM) is a 5-digit numeric code which is used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

e. Column 5, PART NUMBER. Column 5 indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

#### NOTE

**When you use an NSN to requisition an item, the item you receive may have a different part number from the part ordered, but go ahead and use or furnish it as the replacement part**

f. Column 6, DESCRIPTION. Column 6 includes the following information:

(1) The Federal item name and, when required, a minimum description to identify the item.

(2) The physical security classification of the item is indicated by the parenthetical insert applicable physical security classification abbreviation (e.g., Phy Sec C1 (C) Confidential, Phy Sec C1 Secret, Phy Sec C1 (T) Top Secret).

(3) Items included in kits and sets are listed below the name of the kit or set.

(4) Spare/repair parts that make up an assembled item are listed immediately following the assembled item line entry.

(5) NSNs for bulk materials are referenced in the description column in the line item entry for the item to be manufactured/fabricated.

(6) When the part to be used differs between serial numbers of the same model, the effective serial numbers are shown as the last line of the description.

(7) The USABLE ON CODE, when applicable.

(8) In the Special Tools List section, the basis of issue (BOI) appears as the last line(s) in the entry for each special tool, special TMDE, and other special support equipment. When density of equipment's supported exceeds density spread indicated in the basis of issue, the total authorization is increased proportionately.

g. Column 7, U/M. Column 7, Unit of Measure (U/M) indicates the measure (e.g., foot, gallon, pound) or count (e.g., each, dozen, gross) of a listed item. A two-character alpha code (e.g., FT, GL, LB, EA, DZ, GR) appears in this column to indicate the measure or count. If the U/M code appearing in this column differs from the Unit of Issue (U/I) code listed in the Army Master Data File (AMDF), request the lowest U/I that will satisfy your needs.

h. Column 8, QTY INC IN UNIT. Column 8, Quantity Incorporated in Unit (QTY INC IN UNIT) indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable (e.g., shims, spacers).

#### C-4. How to Locate Repair Parts.

a. When National Stock Number or Part Number is Not Known:

(1) First. Using the table of contents, determine the functional group or subfunctional group to which the item belongs. This is necessary since figures are prepared for functional groups and subfunctional groups, and listings are divided into the same groups.

(2) Second. Find the figure covering the functional group or subfunctional group to which the item belongs.

(3) Third. Identify the item on the figure and note the item number of the item.

(4) Fourth. Refer to the Repair Parts List for the figure to find the line item entry for the item number noted on the figure.

b. When National Stock Number or Part Number is Known:

(1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. The NSN index is in National Item Identification Number (NIIN)\* sequence. The part numbers in the Part Number index are listed in ascending alphanumeric sequence. Both indexes cross-reference you to the illustration figure and item number of the item you are looking for.

NSN

\*The NIIN consists of the last 9 digits of the NSN (i.e., 5305-01-674-1467).

NIIN

(2) Second. After finding the figure and item number, verify that the item is the one you're looking for, then locate the item number in the repair parts list for the figure.

C-5. Abbreviations Not Applicable.

SECTION II. REPAIR PARTS LIST




Figure C-1. Insert Fasteners  
C-7

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
C-1	1	PAFZZ		97393	SL601-4-8C	GROUP 01 INSERT FASTENERS INSERT, FASTENER TYPE 1/4".....	EA	V
C-1	2	PAFZZ		97393	SL601-5-10C	INSERT, FASTENER TYPE 5/16".....	EA	V
C-1	3	PAFZZ		97393	SL601-4-8C	INSERT, FASTENER TYPE 3/8x1.....	EA	V
C-1	4	PAFZZ	5340-00-044-5270	97393	SL601-6-12C	INSERT, FASTENER TYPE 3/8x1 1/2.....	EA	V






Figure C-2. Fire Extinguisher Mounting

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
C-2	1	PAFZZ	5306-00-150-9104	88044	ANS-SA	GROUP 02 FIXTURES SUBGROUP 020101 FIRE EXTINGUISHER MOUNTING BOLT, MACHINE.....	EA	4
C-2	2	PAFZZ	5310-00-407-9566	88044	AN935-516	WASHER, LOCK.....	EA	4
C-2	3	PAFZZ	5310-00-187-2399	88044	AN960-PD-516	WASHER, FLAT.....	EA	4




Figure C-3. Water/Oil Separator Mounting

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
C-3	1	PAFZZ	5306-00-151-1427	B8044	AN4-5A	GROUP 02 FIXTURES SUBGROUP 0202 WATER/OIL SEPARATOR MOUNTING BOLT, MACHINE.....	EA	2
C-3	2	PAFZZ	5310-00-582-5965	88044	AN935-416	WASHER, LOCK.....	EA	2
C-3	3	PAFZZ	5310-00-187-2364	88044	AN960-PD-416	WASHER, FLAT.....	EA	2




Figure C-4. Water/Oil Separator Air Hose and Fittings

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 02 FIXTURES SUBGROUP 020201 WATER/OIL SEPARATOR AIR HOSE AND FITTINGS		
C-4	1	PAFZZ	4730-00-932-7511	00624	4738-4-6	FITTING. HOSE.....	EA	2
C-4	2	PAFZZ	4730-00-595-0385	79470	C3409X4	ELBOW, PIPE.....	EA	3
C-4	3	PAFZZ	4730-00-287-1589	03958	896WM	NIPPLE, PIPE .....	EA	1
C-4	4	PAFZZ	4730-00-541-826	88044	AN9102C	COUPLING, PIPE.....	EA	2
C-4	5	PAFZZ	4730-00-203-3168	81348	WW-P-521	CAP, PIPE.....	EA	1
C-4	6	PAFZZ	4730-00-142-1960	14127	SHD 11	COUPLING, HALF QUICK.....	EA	1
C-4	7	PAFZZ	5340-00 565-0004	88044	AN742-12CB	CLAMP, LOOP .....	EA	2
C-4	B	PAFZZ				HOSE, NON-METALLIC (SEE GROUP 99)		
C-4	9	PAFZZ				USE EXISTING SCREW AND WASHERS		




Figure C-5. Water Feed Thru Connector

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 02 FIXTURES SUBGROUP 0203 WATER FEED THRU CONNECTOR SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS. FOR DETAILED DRAWING		
C-5	1	PAFZZ	5310-00-934-9751	19422	BM12297-06	NUT PLAIN, HEX.....	EA	6
C-5	2	PAFZZ	5310-00-187-0834	59875	TX90790-34	WASHER, FLAT .....	EA	6
C-5	3	PAFZZ	5305-00-082-6780	28977	AA52525-24	SCREW, MACHINE.....	EA	6
C-5	4	PAFZZ	4730-00-724-1998	81348	WW-P-480	CAP. PIPE .....	EA	2
C-5	5	PAFZZ	4510-00-142-1619	58536	A-A-232	FAUCET,SINGLE.....	EA	1
C-5	6	PAFZZ	4730-00-547-0941	32938	FIG1620-1	ADAPTER, STRAIGHT.....	EA	1
C-5	7	PAFZZ	5310-00-599-0776		NO REF	WASHER. FLAT.....	EA	1




Figure C-6. Ground Rod Kit

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
C-6	1	PAFZZ	5975-00-878-3791	81349	MIL-R-11461	GROUP 03 ELECTRICAL SUBGROUP 0301 GROUND ROD/STRAP	EA	1
C-6	2	PAFZZ	5120-01-013-1876	45225	P74-144	GROUND ROD/STRAP ..... SLIDE HAMMER,GROUND.....	EA	1




Figure C-7. Book Rack Mounting

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP. SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0401 BOOK RACK MOUNTING SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS, FOR DETAILED DRAWING		
C-7	1	PAFZZ	5306-00-150-9101	88044	AN5-6A	BOLT, MACHINE.....	EA	4
C-7	2	PAFZZ	5310-00-407-9566	88044	AN935-516	WASHER, LOCK.....	EA	4
C-7	3	PAFZZ	5310-00-187-2399	88044	AN960-PD-51	WASHER, FLAT.....	EA	4




Figure C-8. Support Frames, ECU

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
C-8	1	PAFZZ	1670-00-360-0551	81349	MIL-T-7181 TYPE A1A	GROUP 04 MACHINE TOOL EQUIP. SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0402 ECU SUPPORT FRAME SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS, FOR DETAILED DRAWING	EA	4
C-8	2	PAFZZ	5306-00-624-9713	98313	FDA 1658-3	TIE DOWN, CARGO..... BOLT, RING.....	EA	8




Figure C-9. Security Bars, ECU

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
C-9	1	PAFZZ	5306-00-151-1423	88044	AN4-11 A	MACHINE TOOL EQUIP. SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0403 ECU SECURITY BARS SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS, FOR DETAILED DRAWING	EA	8
C-9	2	PAFZZ	5310-00-582-5965	88044	AN935-416	BOLT, MACHINE.....	EA	8
C-9	3	PAFZZ	5310-00-187-2354	88044	AN960-PD-416	WASHER, LOCK.....	EA	8
C-9	4	PAFZZ	5305-00-840-5895	96906	MS27039-0813	WASHER, FLAT..... SCREW, MACHINE.....	EA	8 14






Figure C-10. Bracket, Storage Chest

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0404 BRACKET, STORAGE CHEST SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS, FOR DETAILED DRAWINGS.		
C-10	1	PAFZZ	5306-00-616-1224	88044	AN6-6A	BOLT, MACHINE.....	EA	4
C-10	2	PAFZZ	5310-00-637-9541	96906	MS35338-46	WASHER, LOCK.....	EA	4
C-10	3	PAFZZ	5310-00-187-2400	88044	AN980-PD-616	WASHER, LOCK.....	EA	4




Figure C-11. Tool Box Rack, Unit A

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0405 TOOL BOX RACK MOUNTING 16) SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS, FOR DETAILED DRAWING		
C-11	1	PAZZZ	5308-00-618-1224	88044	AN6-6A	BOLT, MACHINE.....	EA	6
C-11	2	PAFZZ	5310-00-637-9541	96906	MS35338-46	WASHER, LOCK.....	EA	6
C-11	3	PAFZZ	5310-00-187-2400	88044	AN960-PD-616	WASHER, FLAT.....	EA	6




Figure C-12. Bracket, Cabinet Bin Storage

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP. SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0408 BRACKET, CABINET BIN STORAGE SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS FOR DETAILED DRAWINGS		
C-12	1	PAFZZ	5306-00-531-8979	88044	ANB-7A	BOLT, MACHINE.....	EA	5
C-12	2	PAFZZ	5310-00-637-9541	98908	MS36338-46	WASHER, LOCK.....	EA	5
C-12	3	PAFZZ	5310-00-187-2400	88044	AN96O-PD-616	WASHER,FLAT.....	EA	5




Figure C-13. Bracket, Bandsaw

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP. SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0407 BRACKET, BANDSAW SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS FOR DETAILED DRAWINGS		
C-13	1	PAFZZ	5306-00-531-8979	88044	AN6-7A	BOLT, MACHINE.....	EA	3
C-13	2	PAFZZ	5310-00-637-9541	96906	MS35338-46	WASHER, LOCK.....	EA	3
C-13	3	PAFZZ	5310-00-187-2400	88044	AN980-PD-616	WASHER, FLAT.....	EA	3




Figure C-14. Bracket Shrinking/Stretching Machine

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
C-14	1	PAFZZ	5306-00-616-1224	88044	AN6-6A	GROUP 04 MACHINE TOOL EQUIP. SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0408 BRACKET, SHRINKING/ STRETCHING MACHINE SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS FOR DETAILED DRAWINGS	EA	3
C-14	2	PAFZZ	5310-00-637-9541	96906	MS35338-46	BOLT, MACHINE.....	EA	3
C-14	3	PAFZZ	5310-00-187-2400	88044	AN980-PD-616	WASHER, LOCK..... WASHER, FLAT.....	EA	3




Figure C-15. Bracket, Shearing Machine

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0409 BRACKET, SHEARING MACHINE SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS FOR DETAILED DRAWINGS		
C-15	1	PAFZZ	5306-00-206-2885	88044	AN6-14A	BOLT, MACHINE.....	EA	4
C-15	2	PAFZZ	5310-00-637-9541	96906	MS35338-46	WASHER, LOCK.....	EA	4
C-15	3	PAFZZ	5310-00-187-2400	88044	AN960-PD-616	WASHER.FLAT.....	EA	4




Figure C-16. Bracket, Counterweight, Metal Brake

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP. SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0410 BRACKET. COUNTERWEIGHT, METAL BRAKE SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS FOR DETAILED DRAWINGS		
C-18	1	PAFZZ	5308-00-180-1483	88044	AN6-11A	BOLT, MACHINE.....	EA	5
C-18	2	PAFZZ	5310-00-187-2400	88044	AN960-PD-681	WASHER, FLAT.....	EA	10
C-18	3	PAFZZ	5310-00-637-9541	96906	MS35338-46	WASHER, LOCK.....	EA	5
C-16	4	PAFZZ	5310-00-058-1626	96906	MS35650-3282	NUT, PLAIN HEX.....	EA	5




Figure C-17. Bracket, Support Bars and Backstop, Metal Shears

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0411 BRACKET, SUPPORT BARS AND BACK STOP. METAL SHEARS SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS FOR DETAILED DRAWINGS		
C-17	1	PAFZZ	5306-00-206-2865	88044	AN6-14A	BOLT, MACHINE.....	EA	2
C-17	2	PAFZZ	5310-00-187-2400	88044	ANS60-PD-616	WASHER, FLAT.....	EA	8
C-17	3	PAFZZ	6310-00-637-9541	96906	MS35338-46	WASHER, LOCK .....	EA	4
C-17	4	PAFZZ	5310-00-058-1626	96906	MS35650-3282	NUT, PLAIN HEX.....	EA	4
C-17	5	PAFZZ	5306-00-180-1483	88044	AN6-11 A	BOLT, MACHINE.....	EA	2






Figure C-18. Tool Box Rack, Unit B

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL EQUIP. SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0412 TOOL BOX RACK MOUNTING (1) SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS, FOR DETAILED DRAWING		
C-18	1	PAFZZ	5306-00-616-1224	88044	AN6-6A	BOLT, MACHINE .....	EA	10
C-18	2	PAFZZ	5310-00-637-9541	96906	MS35338-46	WASHER, LOCK .....	EA	10
C-18	3	PAFZZ	5310-00-187-2400	88044	AN960-PD-616	WASHER, FLAT.....	EA	10




Figure C-19. Stand, Throatless Shear

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL, EQUIP SPECIAL BRACKETS AND FABRICATED COMPONENTS SUBGROUP 0413 STAND, THROATLESS SHEAR SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS, FOR DETAILED DRAWING		
C-19	1	PAFZZ	5306-00-616-1224	88044	AN6-6A	BOLT, MACHINE.....	EA	4
C-19	2	PAFZZ	5310-00-637-9541	96906	MS3533B-46	WASHER, LOCK.....	EA	4
C-19	3	PAFZZ	5310-00-187-2400	88044	AN980-PD-616	WASHER, FLAT.....	EA	4




Figure C-20. Bench, Stake Holder

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
						GROUP 04 MACHINE TOOL, EQUIP. SPECIAL BRACKETS AND FABRICATED COMONENTS SUBGROUP 0414 BENCH, STAKE HOLDER SEE APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS, FOR DETAILED DRAWING		
C-20	1	PAFZZ	5306-00-616-1224	88044	ANB-6A	BOLT, MACHINE.....	EA	8
C-20	2	PAFZZ	5310-00-837-9541	96906	MS35338-46	WASHER, LOCK.....	EA	8
C-20	3	PAFZZ	5310-00-187-2400	88044	AN980-PD-616	WASHER, FLAT.....	EA	8




Figure C-21. Floor Insert Plugs

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
C-21	1		5305-00-728-8350	98908	MS51988-90	GROUP 05 FLOOR INSERT PLUGS SCREW SET 318.....	EA	86

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	U/M	QTY INC IN UNIT
BULK		PAFZZ	4720-00-402-9511	05415	134MKC1	GROUP 99 BULK MATERIEL HOSE ASSEMBLY .....	FT	V
BULK		PAFZZ	9515-00-141-8066	81348	ASTM A366	METALSHEET.....	SH	V
BULK		PAFZZ	9530-00-228-9315	81348	QQA200/8	METALBAR.....	FT	V
BULK		PAFZZ	9530-00-228-9316	81348	QQA250/8	METALBAR .....	FT	V
BULK		PAFZZ	9535-00-231-8235	81348	QQA250/11	METALPLATE .....	SH	V
BULK		PAFZZ	9540-00-598-2776	81348	QQA200/8	STRUCTURALANGLE.....	FT	V
BULK		PAFZZ	9540-00-197-9846	99237	AND10134-2008	STRUCTURALANGLE.....	FT	V
BULK		PAFZZ	9540-00-197-9850	01834	QQA200/8	STRUCTURALANGLE.....	FT	V

**SECTION III. SPECIAL TOOLS LIST (NOT APPLICABLE)**

**SECTION IV. NATIONAL STOCK  
NUMBER AND PART NUMBER INDEX**

NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5320-01-013-1676	C-6	2	1670-00-360-0551	C-8	1
5340-00-044-5270	C-1	4	4720-00-402-9511	BULK	
5310-00-058-1626	C-16	4	5310-00-407-9566	C-2	1
5310-00-058-1626	C-17	4	5310-00-407-9566	C-7	2
5305-00-082-6780	C-5	3	5306-00-531-8979	C-12	1
9515-00-141-8066	BULK		5306-00-531-8979	C-13	1
4510-00-142-1619	C-5	5	4730-00-541-8286	C-4	4
4730-00-142-1960	C-4	6	4730-00-547-0941	C-5	6
5306-00-150-9101	C-7	1	5340-00-565-0004	C-4	7
5306-00-150-9104	C-2	1	5310-00-582-5965	C-3	2
5306-00-151-1423	C-9	1	5310-00-582-5965	C-9	2
5306-00-151-1427	C-3	1	4730-00-595-0385	C-4	2
5310-00-167-0834	C-5	2	9540-00-596-2776	BULK	
5306-00-180-1483	C-16	1	5310-00-599-0776	C-5	7
5306-00-180-1483	C-17	5	5306-00-616-1224	C-10	1
5310-00-187-2354	C-3	3	5306-00-616-1224	C-11	1
5310-00-187-2354	C-9	3	5306-00-616-1224	C-14	1
5310-00-187-2399	C-2	3	5306-00-616-1224	C-18	1
5310-00-187-2399	C-7	3	5306-00-616-1224	C-19	1
5310-00-187-2400	C-10	3	5306-00-616-1224	C-20	1
5310-00-187-2400	C-11	3	5306-00-624-9717	C-8	2
5310-00-187-2400	C-12	3	5310-00-637-9541	C-10	2
5310-00-187-2400	C-13	3	5310-00-637-9541	C-11	2
5310-00-187-2400	C-14	3	5310-00-637-9541	C-12	2
5310-00-187-2400	C-15	3	5310-00-637-9541	C-13	2
5310-00-187-2400	C-16	2	5310-00-637-9541	C-14	2
5310-00-187-2400	C-17	2	5310-00-637-9541	C-15	2
5310-00-187-2400	C-18	3	5310-00-637-9541	C-16	3
5310-00-187-2400	C-19	3	5310-00-637-9541	C-17	3
5310-00-187-2400	C-20	3	5310-00-637-9541	C-18	2
9540-00-197-9846	BULK		5310-00-637-9541	C-19	2
9540-00-197-9850	BULK		5310-00-637-9541	C-20	2
4730-00-203-3168	C-4	5	4730-00-724-1998	C-5	4
5306-00-206-2865	C-15	1	5305-00-728-6350	C-21	1
5306-00-206-2865	C-17	1	5305-00-840-5895	C-9	4
9530-00-228-9315	BULK		5975-00-878-3791	C-6	1
9530-00-228-9316	BULK		4730-00-932-7511	C-4	1
9535-00-231-8235	BULK		5310-00-934-9751	C-5	1
4730-00-287-1589	C-4	3			

**PART NUMBER INDEX**

FSCM	PART NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
58536	A-A-232	C-5	5,	81346	ASTMA366	BULK	
28977	AA52525	C-5	4	19422	BM12297-06	C-5	1
99237	AND10134-2008	BULK		79470	C3409X4	C-4	2
88044	AN4-5A	C-3	1	98313	FDA1658-3	C-8	2
88044	AN4-11A	C-9	1	32938	FIG1620-1	C-5	6
88044	AN5-5A	C-2	1	05869	MIL-R-1 2644	C-6	1
88044	AN5-6A	C-7	1	81349	MIL-T-7181	C-8	1
88044	AN5-6A	C-14	1		Type A1A		
88044	AN5-6A	C-19	1	96906	MS27039-0813	C-9	4
88044	AN6-6A	C-10	1	96906	MS35338-46	C-10	2
88044	AN6-6A	C-11	1	96906	MS35338-46	C-11	2
88044	AN6-6A	C-18	1	96906	MS35338-46	C-12	2
88044	AN6-6A	C-20	1	96906	MS35338-46	C-13	2
88044	AN6-7A	C-12	1	96906	MS35338-46	C-14	2
88044	AN6-7A	C-13	1	96906	MS35338-46	C-15	2
88044	AN6-11A	C-16	1	96906	MS35338-46	C-16	3
88044	AN6-11A	C-17	5	96906	MS35338-46	C-17	3
88044	AN6-14A	C-15	1	96906	MS35338-46	C-18	2
88044	AN6-14A	C-17	1	96906	MS35338-46	C-19	1
88044	AN742-12CB	C-4	7	96906	MS35338-46	C-20	2
88044	AN9102C	C-4	4	96906	MS35650-3282	C-16	4
88044	AN935-416	C-3	2	96906	MS35650-3282	C-17	4
88044	AN935-416	C-9	2	96906	MS51966-90	C-21	1
88044	AN935-516	C-2	2	45225	P74-144	C-6	2
88044	AN935-516	C-7	2	81348	QQA200/3	BULK	
88044	AN960-416	C-3	3	81348	QQA200/8	BULK	
88044	AN960-416	C-9	3	81348	QQA250/4	BULK	
88044	AN960-516	C-2	3	81348	QQA250/8	BULK	
88044	AN960-516	C-7	3	14127	SHD11	C-4	7
88044	AN960-616	C-10	3	97393	SL601-4-8C	C-1	1
88044	AN960-616	C-11	3	97393	SL601-5-10C	C-1	2
88044	AN960-616	C-12	3	97393	SLB01-6-8C	C-1	3
88044	AN960-816	C-13	3	97393	SL601-6-12C	C-1	4
88044	AN960-616	C-14	3	59875	TW90790-34	C-5	2
88044	AN960-616	C-15	3	81348	WW-P-460	C-5	4
88044	AN960-616	C-16	2	81348	WW-P-521	C-4	5
88044	AN960-616	C-17	2	05415	134MKC1	BULK	
88044	AN960-616	C-18	3	00624	4738-4-6	C-4	1
88044	AN960-616	C-19	3	01634	77P	BULK	
88044	AN960-616	C-20	3	03958	896WM	C-4	3

**C-291(C-30 blank)**

**APPENDIX D  
EXPENDABLE/DURABLE SUPPLIES AND MATERIELS LIST**

**D-1. Scope.**

This listing is for informational purposes only and is not the authority to requisition the listed items. These items are authorized to you by CTA 50-970, Expendable/Durable Items (Except Medical, Class V, Repair Parts, and Heraldic Items), or CTA 8-100, Army Medical Department Expendable/Durable Items.

**D-2. Explanation of Columns.**

- a. Column 1, Item Number. Column 1 is the number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the materiel (e.g., "Use cleaning solvent, Item 1, App D").
- b. Column 2, Level. Column 2 identifies the lowest level of maintenance that requires the listed item.
- c. Column 3, National Stock Number. Column 3 is the National Stock Number assigned to the item; use it to request or requisition the item.
- d. Column 4, Description. Column 4 indicates the Federal item name, and if required, a description to identify the item. The last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.
- e. Column 5, Unit of Measure (U/M). Column 5 indicates the measure used in performing the actual / maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION	(5) U/M
1	AVIM	8040-00-877-9872	ADHESIVE, SEALANT (81349)..... MIL-A-46106	TU
2	AVIM	8105-00-271-1511	BAG, COTTON, MAILING (81348)..... PPP-B-20	BD
3	AVIM	8010-00-852-9034	ENAMEL, GRAY (81348) 16187.....	PT
4	AVIM	8010-00-159-4520	ENAMEL, WHITE (81348) 17773.....	PT
5	AVIM	8010-00-297-0593	PRIMER, COATING (81348) TT-P-1757.....	PT
6	AVIM	3439-00-063-5200	ROD, WELDING (81348) 5356.....	LB

## APPENDIX E ILLUSTRATED LIST OF MANUFACTURED ITEMS

### E-1.- Scope

This Appendix includes simplified line drawing illustrations for all specially manufactured connectors, braces, brackets and stands used in the Sheet/Metal Paint Shop. The special tie down brackets are designed to prevent damage to equipment or to the shelter during transport.


### E-2. General

- a. Supporting text, consisting of instructional data and a list of bulk materiel is included on each illustration.
- b. Dimensions are given in U.S. Standard measures.
- c. Part numbers have been assigned to each special connector, brace, bracket and stand for ease of recognition and a basis of uniformity between other AVIM manuals.

### E-3. Reference Index.

PART NUMBER	NOMENCLATURE	FIG NO.
20083250	Water Feed thru Connector	1
20083251	Book Rack	2
20083253	ECU Support Frame	3
20083254	ECU Security Bar, Upper	4
20083255	ECU Security Bar, Lower	5
20083256	Storage Chest Bracket, RH	6
20083257	Storage Chest Bracket, LH	7
20083258	Cabinet, Bracket	8
20083263	Bandsaw Bracket	9
20083264	Stake Support Table	10
20083265	Counterweight Bracket, Metal Break	11
20083266	Support Bar and Back Stop Bracket, Shears	12
20083267-1	Tool Box Rack (6)	13
20083267-4	Tool Box Rack (18)	14
20083270	Shearing Machine Bracket	15
20083271	Shrinking Machine Bracket	16
20083278	Throatless Shear Stand	17





**NOTES:**

1. FABRICATE FROM:
  - A. SHEET STEEL, 18 GAUGE,  
NSN91515-00-141-8066
  - B. NIPPLE, PIPE, 1/2" X 2"
2. ALL DIMENSIONS ARE IN INCHES

Figure 1. Water Feed thru Connector Part No. 20083250




Figure 2. Book Rack Part No. 20083251






Figure 3. ECU Support Frame Part No. 20083253



- NOTES:
1. FABRICATE FROM:  
METAL BAR, 6061-T6  
AL ALLOY, 2.00 X .25,  
NSN 9530-00-228-9315
  2. TWO REQUIRED.
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 4. ECU Security Bar, Upper Part No. 20083254



- NOTES:
1. FABRICATE FROM:  
 METAL BAR, 6061-T6  
 AL ALLOY, 4.00 X .25  
 NSN 9530-00-228-9316
  2. TWO REQUIRED
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 5. ECU Security Bar, Lower Part No. 20083255




Figure 6. Storage Chest Bracket, RH Part No. 20083256






Figure 7. Storage Chest Bracket, LH Part No. 20083257



- NOTES:
1. FABRICATE FROM:  
 STRUCTURAL ANGLE, 6061-T6  
 AL ALLOY, 2.00 x 1.50 x .25,  
 NSN 9540-00-197-9846.
  2. TWO REQUIRED
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.


Figure 8. Cabinet, Bracket Part No. 20083258





- NOTES:
1. FABRICATE FROM:  
STRUCTURAL ANGLE, 6061-T6  
AL ALLOY 2.00 X 2.00 X .25,  
NSN 9540-00-197-9850
  2. TWO REQUIRED.
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 9. Bandsaw Bracket Part No. 20083263



- NOTES:
- FABRICATE FROM:
    - A. STRUCTURAL ANGLE, 6061-T6 AL ALLOY, 2.00 X 2.00 X .25, NSN 9540-00-197-9850
    - B. METAL PLATE, 6061-T6 AL ALLOY, NSN 9535-00-231-8235
  - WELD WITH 5356 ROD OR EQUAL.
  - ALL DIMENSIONS ARE IN INCHES.

\*1072-2-02  
3 NET\*

Figure 10. Stake Support Table Part No. 20083264




Figure 11. Counterweight Bracket, Metal Break Part No. 20083265





Figure 12. Support Bar and Back Stop Bracket, Shears Part No. 20083266 (Sheet 1 of 3)



- NOTES:
1. FABRICATE FROM:
    - A. STRUCTURAL ANGLE, 6061-T6 AL ALLOY, 2.00 X 2.00 X .25, NSN 9540-00-197-9850
    - B. METAL BAR, 6061-T6 AL ALLOY, 2.00 X .25, NSN 9530-00-228-9315
  2. WELD WITH 5356 ROD OR EQUAL.
  3. ALL DIMENSIONS ARE IN INCHES.

Figure 12. Support Bar and Back Stop Bracket, Shears Part No. 20083266 (Sheet 2 of 3) P/N 20083266-1




Figure 12. Support Bar and Back Stop Bracket, Shears Part No. 20083266 (Sheet 3 of 3)




Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 1 of 10)







Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 2 of 10)






- NOTES:
1. FABRICATE FROM:  
METAL BAR 6061-T6  
AL ALLOY, 2.00 X .25  
NSN 9530-00-228-9315
  2. FOUR REQUIRED; TWO  
WITH HOLES AS SHOWN,  
TWO W/O HOLES.
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 3 of 10)





- NOTES:
1. FABRICATE FROM:  
STRUCTURAL ANGLE 6061-T6  
AL ALLOY, 2.00X 2.00 X .25  
NSN 9546-00-197-9850
  2. SIX REQUIRED.
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 4 of 10)




- NOTES:
1. FABRICATE FROM:  
STRUCTURAL ANGLE, 6061-T6  
AL ALLOY, 2.00 X 2.00 X .25  
NSN 9540-00-197-9850
  2. TWO REQUIRED; ONE AS SHOWN  
ONE OPPOSITE
  3. WELD WITH 5356 ROD OR EQUAL
  4. ALL DIMENSIONS ARE IN INCHES

Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 5 of 10)



- NOTES:
1. FABRICATE FROM:  
 STRUCTURAL ANGLE, 6061-T6  
 AL ALLOY, 2.00 x 2.00 x .25,  
 NSN 9540-00-197-9850
  2. THREE REQUIRED.
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.


Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 6 of 10)



NOTES:

1. FABRICATE FROM:  
METAL BAR, 6061-T6  
AL ALLOY, 2.00 X .25,  
NSN 9530-00-228-9315
2. THREE REQUIRED; ONE  
WITH HOLES AS SHOWN,  
TWO W/O HOLES.
3. WELD WITH 5356 ROD OR EQUAL
4. ALL DIMENSIONS ARE IN INCHES.


Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 7 of 10)



NOTES:


1. FABRICATED FROM:  
METAL BAR, 6061-T6  
AL ALLOY, 2.00 X .25,  
NSN 9530-00-228-9315
2. SIX REQUIRED
3. WELD WITH 5356 ROD OR EQUAL
4. ALL DIMENSIONS ARE IN INCHES.

Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 8 of 10)



- NOTES:
1. FABRICATED FROM:  
METAL BAR, 6061-T6  
AL ALLOY, 2.00X.25,  
NSN 9530-00-228-9315
  2. SIX REQUIRED;
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 9 of 10)



- NOTES:
1. FABRICATE FROM:  
METAL BAR 6061-T6,  
AL ALLOY, 2.00x.25  
NSN 9530-00-228-9315
  2. THREE REQUIRED
  3. WELD WITH 5356 OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 13. Tool Box Rack (6) Part No. 20083267-1 (Sheet 10 of 10)








Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 1 of 10)





- NOTES:
1. FABRICATE FROM METAL PLATE, 6061-T6 AL ALLOY, NSN 9535-00-231-8230
  2. WELD WITH 5356 ROD OR EQUAL
  3. ALL DIMENSIONS ARE IN INCHES.

Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 2 of 10)




- NOTES:
1. FABRICATE FROM:  
METAL BAR, 6061-T6  
AL ALLOY, 2.00 X .25  
NSN 9530-00-228-9315
  2. TWELVE REQUIRED; SIX WITH  
HOLES AS SHOWN, SIX W/O HOLES.
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 3 of 10)




- NOTES
1. FABRICATE FROM:  
STRUCTURE ANGLE, 6061-T6  
AL ALLOY 2.00X2.00X.25,  
NSN 9540-00-197-9850
  2. SIX REQUIRED
  3. WELD WITH 5356 RDD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 4 of 10)




- NOTES:
1. FABRICATE FROM:  
STRUCTURAL ANGLE, 6061-T6  
AL ALLOY, 2.00 x 2.00 x .25,  
NSN 9540-00-197-9850
  2. TWO REQUIRED, ONE AS  
SHOWN, ONE OPPOSITE.
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 5 of 10)




- NOTES:
1. FABRICATE FROM:  
STRUCTURAL ANGLE, 6061-T6  
AL ALLOY, 2.00 x 2.00 x .25,  
NSN 9540-00-197-9850
  2. THREE REQUIRED.
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 6 of 10)



NOTES:  
 1. FABRICATE FROM:  
 METAL BAR 6061-T6  
 AL ALLOY 2.00 x .25  
 NSN 9530-00-228-9315  
 2. THREE REQUIRED  
 3. WELD WITH 5356 ROD OR EQUAL.  
 4. ALL DIMENSIONS ARE IN INCHES.

Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 7 of 10)




NOTES:

1. FABRICATE FROM:  
METAL BAR, 6061-T6  
AL ALLOY, 2.00 X .25,  
NSN 953D-00-228-9315
2. TWELVE REQUIRED
3. WELD WITH 5356 ROD OR EQUAL.
4. ALL DIMENSIONS ARE IN INCHES.


Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 8 of 10)





- NOTES:  
1.FABRICATE FROM:  
METAL BAR 6061-T6,  
AL ALLOY, 2.00x.25  
NSN 9530-00-229-9315  
2. THIRTY REQUIRED  
3. WELD WITH 5356 OR EQUAL.  
4. ALL DIMENSIONS ARE IN INCHES.

Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 9 of 10)



- NOTES:
1. FABRICATE FROM:  
METAL BAR, 6061-T6  
AL ALLOY, 2.00 X .25,  
NSN 9530-00-228-9315
  2. THREE REQUIRED
  3. WELD WITH 5356 ROD OR EQUAL.
  4. ALL DIMENSIONS ARE IN INCHES.

Figure 14. Tool Box Rack (18) Part No. 20083268-4 (Sheet 10 of 10)






Figure 15. Shearing Machine Bracket Part No. 20083270



- NOTES:
1. FABRICATE FROM:
    - A. METAL BAR, 6061-T6  
AL ALLOY, 4.00 X .25,  
NSN 9530-00-228-9316
    - B. METAL BAR, 6061-T6  
AL ALLOY, 5.00 X .25,  
NSN 9530-00-228-9322
  2. TWO REQUIRED
  3. WELD WITH 5356 ROD OR EQUAL
  4. ALL DIMENSIONS ARE IN INCHES

Figure 16. Shrinking Machine Bracket Part No. 20083271



- NOTES:
1. FABRICATE FROM:
    - A. STRUCTURAL ANGLE, 6061-T6 AL ALLOY, 2.00 x 2.00 x .25, NSN 9540-00-197-9850
    - B. METAL PLATE, 6061-T6 AL ALLOY, NSN 9535-00-231-9235
  2. WELD WITH 5356 ROD OR EQUAL.
  3. ALL DIMENSIONS ARE IN INCHES.

Figure 17. Throatless Shear Stand Part No. 20083278

**APPENDIX F  
TORQUE LIMITS**

Bolt Size	Tension Loading
1/4-28	50-70 inch pounds
5/16-24	100-140 inch pounds
3/8-24	160-190 inch pounds

The above torque loads may be used on all cadmium-plated fine thread steel bolts which have approximately equal number of threads and equal face bearing areas. Size refers to bolt shank diameter or inside diameter of nut and thread indicates number of threads per inch.

**F-1/(F-2 blank)**

**ALPHABETICAL INDEX**

Subject	Paragraph No.	Subject	Paragraph No.
<b>A</b>			
Allocation Chart, Maintenance (MAC)		Cable, Main Power	
Column Explanation		Connecting .....	2-6.a
MAC, Section II .....	B-3	Disconnecting .....	2-10.d
Remarks, Section IV .....	B-5	Characteristics .....	1-6
Tools and Test Equipment		Chart, Maintenance Allocation (MAC)	
Requirements, Section III .....	B-4	Column Explanation	
Functions, Maintenance .....	B-2	MAC, Section II .....	B-3
		Remarks, Section IV .....	B-5
		Tools and Test Equipment	
		Requirements, Section III .....	B-4
		Functions, Maintenance.....	B-2
		Checking Equipment .....	3-5
		Circuit Breaker Panel .....	2-10.b
		Components, Location and Description	
		of Major Ones .....	1-7
		Compressed Air	
		Connection .....	2-7.a
		Disconnecting .....	2-9.b
		Counterbalance Cable Removal .....	2-1.d
		Counterweights on Sheet Metal Break	
		Installing .....	2-3.g
		Removing .....	2-12.b
		<b>D</b>	
		Destruction of Army Materiel to	
		Prevent enemy use.....	1-4
		<b>E</b>	
		ECU Shelves	
		Closing, Unit A .....	2-12.g
		Closing, Unit B .....	2-13.g
		Lowering Procedures .....	2-2
		ECUs	
		Connecting Power .....	2-6.b
		Disconnecting .....	2-10.c
		Positioning for Operation, Unit A .....	2-3.d
		Positioning for Operation, Unit B.....	2-4.a
		Repositioning for Transport, Unit A .....	2-12.e
		Repositioning for Transport, Unit B .....	2-13.e
		Electric Power .....	2-6
		Connecting to ECU .....	2-6.b
		Main Power Cable Connection .....	2-6.a
		Power On to Shop .....	2-6.d
<b>B</b>			
Bandsaw			
Positioning for Operation .....	2-3.a		
Repositioning for Transport .....	2-12.j		
Bin Storage Cabinet, No.....	1, Unit A		
Positioning for Operation .....	2-3.b		
Repositioning for Transport.....	2-12.h		
Bin Storage Cabinet, No.....	2, Unit A		
Positioning for Operation .....	2-3		
Repositioning for Transport .....	2-12.i		
Bin Storage Cabinet, Unit B			
Positioning for Operation .....	2-4.d		
Repositioning for Transport .....	2-13.c		
Bolts and Washers			
For Equipment Tie Down- .....	2-11		
Safeguarding .....	2-5		
Book Rack			
Inspect .....	3-16		
Repair .....	3-17		
Replace .....	3-18		
<b>C</b>			
Cabinet, Bin Storage, No.....	1, Unit A		
Positioning for Operation .....	2-3.b		
Repositioning for Transport .....	2-12.h		
Cabinet, Bin Storage, No.....	2, Unit A		
Positioning for Operation .....	2-3.c		
Repositioning for Transport .....	2-12.i		
Cabinet, Bin Storage, Unit B			
Positioning for Operation .....	2-4.d		
Repositioning for Transport .....	2-13.c		
Cable Removal, Counterbalance .....	2-1.d		

ALPHABETICAL INDEX (Cont)

Subject	Paragraph No.	Subject	Paragraph No.
Equipment Improvement Recommendations (EIR), Reporting .....	1-3	External Ground Rod Installation .....	2-6.d
Equipment, Checking .....	3-5	Removal .....	2-10.e
Equipment, Shop, Positioning for Operation, Unit A .....	2-3		
Bandsaw .....	2-3.a	<b>F</b>	
Cabinet, Bin Storage, No.1 .....	2-3.b	Fire Extinguisher Mounting - Inspect .....	3-9
Cabinet, Bin Storage, No.2 .....	2-3.c	Fire Extinguisher - Removal/Installation .....	3-8
Counterweights on Sheet Metal Break, Installing .....	2-3.g	Fixed Equipment/Components - Removal/ Installation .....	3-20
ECUs .....	2-3.d	Floor Insert Fasteners and Plugs - Inspect .....	3-19
Security Bars, ECU, Attaching .....	2-3.f	Forms, Maintenance .....	1-2
Shearing Machine, Installing Backstop .....	2-3.h		
Shrinking/Stretching Machine .....	2-3.i	<b>G</b>	
Support Frames, ECU, Storing .....	2-3.e	Ground Rod/Strap - Inspect .....	3-15
Equipment, Shop, Positioning for Operation, Unit B .....	2-4		
Cabinet, Bin Stowage .....	2-4.d	<b>I</b>	
ECUs .....	2-4.a	Insert Fasteners and Bolts - Inspect .....	3-6
Security Bars, ECU, Attaching .....	2-4.c	Insert Fasteners - Replace .....	3-7
Stand, Throatless Shear .....	2-4.f	Instructions, Maintenance	
Support Frames, Storing, ECU .....	2-4.b	Fire Extinguisher Mounting - Inspect .....	3-9
Table, Stake Support .....	2-4.e	Fire Extinguisher - Removal/ Installation .....	3-8
Support Frames, ECU, Storing .....	2-3.e	Fixed Equipment/Components Removal/ Installation .....	3-20
Equipment, Shop, Repositioning for		Floor Insert Plugs - Inspect .....	3-19
Transport, Unit A .....	2-12	Ground Rod/Strap - Inspect .....	3-15
Bandsaw .....	2-12.j	Insert Fasteners and Bolts - Inspect .....	3-6
Cabinet, Bin Storage, No.1 .....	2-12.h	Insert Fasteners - Replace .....	3-7
Cabinet, Bin Storage, No.2 .....	2-12.i	Special Brackets and Fabricated Components, Book Rack	
Counterweights on Sheet Metal Break, Removing .....	2-12.b	Inspect .....	3-16
ECU Shelves, Closing .....	2-12.g	Repair .....	3-17
ECUs .....	2-12.e	Replace .....	3-18
Replacing ECU's in Support Frames .....	2-12.f	Water Feed Thru Connector - Inspect .....	3-13
Shearing Machine, Removing Backstop .....	2-12.a	Water Feed Thru Connector - Replace .....	3-14
Shrinking/Stretching Machine .....	2-12.c	Water/Oil Separator Air Hose and Fittings - Inspect .....	3-11
Support Frames, ECU, Installation .....	2-12.d	Water/Oil Separator Air Hose - Replace .....	3-12
Equipment, Shop, Positioning for		Water/Oil Separator Mounting - Inspect .....	3-10
Transport, Unit B .....	2-13		
Cabinet, Bin Storage .....	2-13.c		
ECU Shelves, Closing .....	2-13.g		
ECUs .....	2-13.e		
Replacing ECUs in Support Frames .....	2-13.f		
Stand, Throatless Shear .....	2-13.a		
Support Frames, ECU, Installation .....	2-13.d		
Table, Stake Support .....	2-13.b		
Expendable/Durable Supplies and Materials List			
Column Explanation .....	D-2		



**ALPHABETICAL INDEX**

Subject	Paragraph No.	Subject	Paragraph No.
<b>L</b>		<b>P</b>	
Leveling		Part Number Index .....	Appendix C
Checking .....	2-8	Power On to Shop .....	2-6.d
Initial Shop Setup .....	2-1.b	Power, Electric .....	2-6
Location and Description of Major		Connecting to ECU .....	2-6.b
Components .....	1-7	Main Power Cable Connection .....	2-6.a
Lowering Procedures, ECU Shelves .....	2-2	Power On to Shop .....	2-6.d
<b>M</b>		Power Shutdown.....	2-10
Maintenance Allocation Chart (MAC)		Circuit Breaker Panel .....	2-10.b
Column Explanation		ECUs .....	2-10.c
MAC, Section II .....	B-3	Main Power Cable .....	2-10.d
Remarks, Section IV .....	B-5	Preparation for Storage and Shipment .....	1-5
Tools and Test Equipment		<b>R</b>	
Requirements, Section III .....	B-4	Records, Maintenance.....	1-2
Functions, Maintenance .....	B-2	References	
Maintenance Instructions		Dictionaries .....	A-1
Fire Extinguisher Mounting - Inspect ...	3-9	Logistics and Storage .....	A-3
Fire Extinguisher - Removal/		Maintenance .....	A-4
Installation .....	3-8	Other Publications .....	A-5
Fixed Equipment/Components Removal/		Publication Indexes .....	A-2
Installation .....	3-20	Repair Parts .....	3-4
Floor Insert Plugs - Inspect .....	3-19	Repair Parts and Special Tools	
Ground Rod/Strap - Inspect .....	3-15	List	
Insert Fasteners and Bolts - Inspect ....	3-6	Column Explanation .....	C-3
Insert Fasteners - Replace .....	3-7	Locating Repair Parts .....	C-4
Special Brackets and Fabricated		National Stock Number and	
Components, Book Rack		Part Number List .....	Appendix C
Inspect .....	3-16	Reports, Maintenance .....	1-2
Repair .....	3-17	<b>S</b>	
Replace .....	3-18	Safety Instructions, Supplemental .....	2-1.c
Water Feed Thru Connector - Inspect .	3-13	Security Bars, ECU	
Water Feed Thru Connector - Replace	3-14	Attaching for Operation, Unit A .....	2-3.f
Water/Oil Separator Air Hose and		Attaching for Operation, Unit B .....	2-4.c
Fittings - Inspect .....	3-11	Shearing Machine, Unit A	
Water/Oil Separator Air Hose -		Installing Backstop .....	2-3.h
Replace .....	3-12	Removing Backstop .....	2-12.a
Water/Oil Separator Mounting -		Sheet Metal/Paint Shop Characteristics .....	1-6
Inspect .....	3-10	Sheet Metal/Paint Shop, Setup of	
Manufactured Items, Illustrated List		Upon Initial Receipt .....	2-1
Reference Index .....	E-3	Counterbalance Cable Removal .....	2-1.d
<b>N</b>		Leveling, Initial .....	2-1.b
National Stock Number Index .....	Appendix C	Safety Instructions, Supplemental .....	2-1.c

ALPHABETICAL INDEX (Cont)

Subject	Paragraph No.	Subject	Paragraph No.
Shelves, ECU		Table, Stake Support .....	2-13.b
Closing, Unit A .....	2-12.g	Support Frames, ECU, Installation .....	2-13.d
Closing, Unit B .....	2-13.g	Shrinking/Stretching Machine, Unit A	
Lowering Procedures .....	2-2	Positioning for Operation .....	2-3.i
Shipment/Storage, Preparation .....	1-5	Repositioning for Transport .....	2-12.c
Shop Equipment, Positioning for Operation,		Stake Support Table, Unit B	
Unit A .....	2-3	Positioning for Operation .....	2-4.e
Bandsaw .....	2-3.a	Repositioning for Transport .....	2-13.b
Cabinet, Bin Storage, No.1 .....	2-3.b	Stand, Special, Throatless Shear, Unit B	
Cabinet, Bin Storage, No.2 .....	2-3.c	Positioning for Operation .....	2-4.f
Counterweights on Sheet Metal Break,		Repositioning for Transport .....	2-13.a
Installing .....	2-3.g	Storage Procedures .....	2-14
ECUs .....	2-3.d	Striking Shelter Shop Utilities (Other	
Security Bars, ECU, Attaching .....	2-3.f	Than Electrical) .....	2-9
Shearing Machine, Installing Backstop .....	2-3.h	Disconnecting Compressed Air .....	2-9.b
Shrinking/Stretching Machine .....	2-3.i	Disconnecting Water Supply .....	2-9.a
Support Frames, ECU, Storing .....	2-3.e	Striking the Shelter .....	2-15
Shop Equipment, Positioning for Operation,		Supplies and Materiels List, Expendable/	
Unit B .....	2-4	Durable	
Cabinet, Bin Stowage .....	2-4.d	Column Explanation .....	D-2
ECUs.....	2-4.a	Scope .....	D-1
Security Bars, ECU, Attaching .....	2-4.c	Support Frames, ECU	
Stand, Throatless Shear .....	2-4.f	Installation .....	2-11.d
Support Frames, Storing ECU .....	2-4.b	Storing, Unit A .....	2-3.e
Table, Stake Support .....	2-4.e	Storing, Unit B .....	2-4.b
Shop Equipment, Repositioning for			
Transport, Unit A .....	2-12	<b>T</b>	
Bandsaw .....	2-12.j	Table, Stake Support, Unit B	
Cabinet, Bin Storage, No.1 .....	2-12.h	Positioning for Operation .....	2-4.e
Cabinet, Bin Storage, No.2 .....	2-12.i	Repositioning for Transport .....	2-13.b
Counterweights on Sheet Metal Break,		Throatless Shear Stand, Unit B	
Removing .....	2-12.b	Positioning for Operation .....	2-4.f
ECU Shelves, Closing .....	2-12.g	Repositioning for Transport .....	2-13.a
ECUs .....	2-12.e	Tools and Equipment, Common .....	3-1
Replacing ECUs in Support Frames .....	2-12.f	Tools and Equipment, Special .....	3-3
Shearing Machine, Removing Backstop .....	2-12.a	Torque Limits .....	Appendix F
Shrinking/Stretching Machine .....	2-12.c	Torque Values .....	3-2
Support Frames, ECU, Installation .....	2-12.d		
Shop Equipment, Positioning for Transport,		<b>U</b>	
Unit B .....	2-13	Utilities, Other Shop .....	2-7
Cabinet, Bin Storage .....	2-13.c	Compressed Air Connection .....	2-7.a
ECU Shelves, Closing .....	2-13.g	Water Supply Connection .....	2-7.b
ECUs .....	2-13.e		
Replacing ECU's in Support Frames .....	2-13.f		
Stand, Throatless Shear .....	2-13.a		

**ALPHABETICAL INDEX (Cont)**

Subject	Paragraph No.	Subject	Paragraph No.
<b>W</b>			
Water Feed Thru Connector		Air Hose - Replace .....	3-12
Inspect .....	3-13	Mounting - Inspect .....	3-10
Replace .....	3-14	Water Supply	
Water/Oil Separator		Connection .....	2-7.b
Air Hose and Fittings - Inspect .....	3-11	Disconnection .....	2-8.a

**Index 5/(Index 6 blank)**

By Order of the Secretary of the Army:

**JOHN A. WICKHAM, JR.**  
*General, United States Army*  
*Chief of Staff*

Official:


**ROBERT M. JOYCE**  
*Major General, United States Army*  
*The Adjutant General*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31, Operator Maintenance Requirements for All Fixed and Rotor Wing Aircraft.

\* U.S. GOVERNMENT PRINTING OFFICE: 1984-764-028/1179

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

 <p style="font-size: small; margin: 0;"><i>THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.</i></p>		SOMETHING WRONG WITH PUBLICATION	
		FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)	
		DATE SENT	
PUBLICATION NUMBER		PUBLICATION DATE	PUBLICATION TITLE
IN THIS SPACE, TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT.			
BE EXACT PIN-POINT WHERE IT IS			
PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER		SIGN HERE	

## The Metric System and Equivalents

### Linear Measure

1 centimeter = 10 millimeters = .39 inch  
 1 decimeter = 10 centimeters = 3.94 inches  
 1 meter = 10 decimeters = 39.37 inches  
 1 decameter = 10 meters = 32.8 feet  
 1 hectometer = 10 decameters = 328.08 feet  
 1 kilometer = 10 hectometers = 3,280.8 feet

### Weights

1 centigram = 10 milligrams = .15 grain  
 1 decigram = 10 centigrams = 1.54 grains  
 1 gram = 10 decigrams = .035 ounce  
 1 decagram = 10 grams = .35 ounce  
 1 hectogram = 10 decagrams = 3.52 ounces  
 1 kilogram = 10 hectograms = 2.2 pounds  
 1 quintal = 100 kilograms = 220.46 pounds  
 1 metric ton = 10 quintals = 1.1 short tons

### Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce  
 1 deciliter = 10 centiliters = 3.38 fl. ounces  
 1 liter = 10 deciliters = 33.81 fl. ounces  
 1 deciliter = 10 liters = 2.64 gallons  
 1 hectoliter = 10 deciliters = 26.42 gallons  
 1 kiloliter = 10 hectoliters = 264.18 gallons

### Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch  
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches  
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet  
 1 sq. decameter (are) = 100 sq. meters = 1,076.4 sq. feet  
 1 sq. hectometer (hectare) = 100 sq. decameters = 2.47 acres  
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

### Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch  
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches  
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

## Approximate Conversion Factors

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	2.540	ounce-inches	Newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29.573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	Newton-meters	1.356	metric tons	short tons	1.102
pound-inches	Newton-meters	.11296			

## Temperature (Exact)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
----	---------------------------	-------------------------------	------------------------	----

PIN: 056092-000