

TECHNICAL MANUAL

**OPERATOR'S, UNIT, DIRECT SUPPORT AND
GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND
SPECIAL TOOLS LIST)**

**POWER UNIT
PU-751/M (NSN 6115-00-033-1373)
MEP-002A 5 KW 60 HZ GENERATOR SET
M116A1 2-WHEEL, 2-TIRE,
MODIFIED TRAILER**

*This manual supersedes Chapter 12 of TM 5-6115-594-14&P dated 25 September 1984.

Approved for public release; distribution is unlimited

CHANGE
NO. 4

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 30 September 1996

Operator's, Unit, Direct Support and
General Support Maintenance Manual
(Including Repair Parts and Special Tools List)

POWER UNIT
PU-751/M (NSN 6115-00-033-1373)
MEP-002A 5 KW 60 HZ GENERATOR SET
M11 6A1 2-WHEEL, 2-TIRE,
MODIFIED TRAILER

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 5-6115-630-14&P, 5 October 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

i and ii
1-1 and 1-2
3-21/(3-22 blank)
B-3/(B-4 blank)
D-5 and D-6/(D-7 blank)
D-9 through D-14/(D-15 blank)
D-17 through D-20

Insert pages


i and ii
1-1 and 1-2
3-21/(3-22 blank)
B-3/(B-4 blank)
D-5 and D-6/(D-7 blank)
D-9 through D-14/(D-15 blank)
D-17 through D-20

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

DENNIS J. REIMER
General, United States Army
Chief of Staff

Official:



JOEL B. HUDSON
Administrative Assistant to the
Secretary of the Army
02504

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 4421, requirements for TM 5-6115-630-14&P.

CHANGE
NO. 3

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C, 31 July 1996

Operator's, Unit, Direct Support and
General Support Maintenance Manual
(Including Repair Parts and Special Tools List)

POWER UNIT
PU-751/M (NSN 6115-00-033-1373)
MEP-002A 5 KW 60 HZ GENERATOR SET
M116A1 2-WHEEL, 2-TIRE,
MODIFIED TRAILER

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 5-6115-630-14&P, 5 October 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

D-19 and D-20

D-19 and D-20

2. Retain this sheet in front of manual for reference purposes.,

By Order of the Secretary of the Army:

Official:

DENNIS J. REIMER
General, United States Army
Chief of Staff

JOEL B. HUDSON
Administrative Assistant to the
Secretary of the Army
01999

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 4421, requirements for TM 5-6115-630-14&P.

CHANGE

NO. 2

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 3 APRIL 1992

Operator's, Unit, Direct Support and
General Support Maintenance Manual
(Including Repair Parts and Special Tools List)

POWER UNIT,
PU-751/M (NSN 6115-00-033-1373)
MEP-002A, 5KW, 60 HZ GENERATOR SET
M116A1 2-WHEEL, 2-TIRE,
MODIFIED TRAILER

Approved for public release; distribution is unlimited

TM 5-6115-630-14&P, dated 5 October 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages


3-11 and 3-12

3-11 and 3-12

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:



MILTON H. HAMILTON
*Administrative Assistant to the
Secretary of the Army*

00905

GORDON R. SULLIVAN
*General, United States Army
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25E, (qty rqr block no. 4421)

CHANGE

NO. 1

HEADQUARTERS,
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 29 November 1990

**Operator's, Unit, Direct Support and
General Support Maintenance Manual
(Including Repair Parts and
Special Tools List)**

**POWER UNIT,
PU-751/M (NSN 6115-00-033-1373)
MEP-002A 5KW 60 HZ GENERATOR SET
M116A1 2-WHEEL, 2-TIRE,
MODIFIED TRAILER**

Approved for public release; distribution is unlimited

TM 5-6115-630-14&P, dated 5 October 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages	Insert pages
1-1 through 1-4	1-1 through 1-4
3-15 and 3-16	3-15 and 3-16
3-19 and 3-20	3-19 and 3-20
4-1 and 4-2	4-1 and 4-2
4-13 through 4-15/(4-16 blank)	4-13 through 4-15/(4-16 blank)
5-7 through 5-10	5-7 through 5-10
D-9 and D-10	D-9 and D-10

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

THOMAS F. SIKORA
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25E, (qty rqr block no. 4421)



5

SAFETY STEPS TO FOLLOW IF SOMEONE IS THE VICTIM OF ELECTRICAL SHOCK

1

DO NOT TRY TO PULL OR GRAB THE INDIVIDUAL

2

IF POSSIBLE, TURN OFF THE ELECTRICAL POWER

3

IF YOU CANNOT TURN OFF THE ELECTRICAL POWER, PULL, PUSH, OR LIFT THE PERSON TO SAFETY USING A DRY WOODEN POLE OR A DRY ROPE OR SOME OTHER INSULATING MATERIAL

4

SEND FOR HELP AS SOON AS POSSIBLE

5

AFTER THE INJURED PERSON IS FREE OF CONTACT WITH THE SOURCE OF ELECTRICAL SHOCK, MOVE THE PERSON A SHORT DISTANCE AWAY AND IMMEDIATELY START ARTIFICIAL RESUSCITATION

WARNING

All specific cautions and warnings contained in this manual shall be strictly adhered to. Otherwise, severe injury, death and/or damage to the equipment may result.

HIGH VOLTAGE

is produced when this power unit is in operation.

DEATH

or severe burns may result if personnel fail to observe safety precautions. Do not operate this power unit until the ground terminal stud has been connected to a suitable ground. Disconnect the battery ground cable on the generator set before removing and installing components on the engine or in the electrical control panel system. Remove all rings, watches, and other jewelry when performing maintenance on this equipment. Loose fitting clothing should be secured to prevent it catching moving parts. Do not attempt to service or otherwise make any adjustments, connections or reconnection of wires or cables until generator set is shut down and completely de-energized.

DANGEROUS GASES

Batteries generate explosive gas during charging: therefore, utilize extreme caution. Do not smoke, or use open flame in the vicinity of the generator set when servicing batteries.

Exhaust discharge contains noxious and deadly fumes. Do not operate power generator set in enclosed areas unless exhaust discharge is properly vented to the outside.

To avoid sparking between filler nozzle and fuel tank, always maintain metal to metal contact between filler nozzle and fuel tank when filling generator set fuel tank.

Do not smoke or use open flame in the vicinity of the generator set while refueling.

LIQUIDS UNDER HIGH PRESSURE

are generated as a result of operation of the power unit generator set. Do not expose any part of the body to a high pressure leak in the fuel injection system.

NOISE

Operating noise level of the generator set can cause hearing damage. Ear protectors, as recommended by the medical or safety officer, must be worn when working near this power unit.

WARNING

Clean parts in a well-ventilated area. Avoid inhalation of solvent fumes and prolonged exposure of skin to cleaning solvent. Wash exposed skin thoroughly. Dry cleaning solvent (P-D-680) used to clean pads is potentially dangerous to personnel and property. Do not use near open flame or excessive heat. Flash point of solvent is 100°F to 138°F (38°C to 59°C).

TECHNICAL MANUAL

NO. 5-6115-630-14&P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 5 October 1989

Operator's, Unit, Direct Support and
General Support Maintenance Manual
(Including Repair Parts and Special Tools List)

**POWER UNIT
PU-751/M (NSN 6115-00-033-1373)
MEP-002A 5 KW 60 HZ GENERATOR SET
M116A1 2-WHEEL, 2-TIRE,
MODIFIED TRAILER**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Blvd., St. Louis, MO 63120-1798. You may also submit your recommended changes by E-mail directly to <mpmt%/avma28@st-louis-emh7.army.mil>. A reply will be furnished directly to you. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TABLE OF CONTENTS

			PAGE
CHAPTER	1	INTRODUCTION	
Section	I	General	1-1
Section	II	Description and Data	1-2
CHAPTER	2	OPERATING INSTRUCTIONS	
Section	I	Operating Procedures.....	2-1
Section	II	Operation of Auxiliary Equipment	2-1
Section	III	Operation Under Unusual Conditions	2-2
CHAPTER	3	OPERATOR/CREW MAINTENANCE INSTRUCTIONS	
Section	I	Consumable Operating and Maintenance Supplies	3-1
Section	II	Lubrication Instructions.....	3-1
Section	III	Preventive Maintenance Checks and Services (PMCS).....	3-1
Section	IV	Troubleshooting	3-17
Section	V	Operator/Crew Maintenance Instructions	3-17

*This manual supersedes Chapter 12 of TM 5-6115-594-14&P dated 25 September 1984.

TM 5-6115-630-14&P

CHAPTER	4	UNIT MAINTENANCE	
Section	I	Service Upon Receipt of Equipment.....	4-1
Section	II	Movement to a New Worksite.....	4-6
Section	III	Repair Parts, Special Tools, Special Test, Measurement and Diagnostic Equipment (TMDE)	4-7
Section	IV	Lubrication Instructions.....	4-7
Section	V	Preventive Maintenance Checks and Services	4-8
Section	VI	Troubleshooting	4-13
Section	VII	Radio Interference Suppression	4-13
Section	VIII	Maintenance of Power Plant Trailer.....	4-13
CHAPTER	5	DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS	
Section	I	Introduction	5-1
Section	II	Maintenance of Power Unit Trailer	5-1
Section	III	Generator Set	5-8
CHAPTER	6	TEST AND INSPECTION AFTER REPAIR	
Section	I	General Requirements.....	6-1
Section	II	Inspection.....	6-1
Section	III	Operational Tests	6-1
APPENDIX	A	REFERENCES	A-1
APPENDIX	B	COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS	B-1
APPENDIX	C	MAINTENANCE ALLOCATION CHART	C-1
APPENDIX	D	UNIT, DIRECT SUPPORT AND GENERAL SUPPORT AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST	D-1

ii Change 4

LIST OF ILLUSTRATIONS

Figure	Title	Page
1-1	Power Unit, Roadside Front, Three-Quarter View	1-2
1-2	Power Unit, Curbside Rear, Three-Quarter View	1-3
3-1	Fitted Cover installed on Power Unit	3-18
3-2	Fitted Cover Rolled Up for Removal	3-19
3-3	Tarpaulin Support Replacement.	3-20
3-4	Bow Assembly Replacement	3-20
4-1	Uncrating Generator Set.....	4-1
4-2	Unpacking Fitted Cover, Bows and Tarpaulin Support	4-2
4-3	Installing Power Unit	4-4
4-4	External Fuel Line Connection.	4-6
4-5	Fuel Can Bracket Replacement.	4-13
4-6	Accessory Box Replacement	4-14
4-7	Fire Extinguisher Bracket Replacement	4-15
5-1	Leg Prop Assembly Replacement	5-2
5-2	Fender and Bed Replacement.	5-4
5-3	Accessory Box Repair	5-7
5-4	Power Unit Markings	5-7
5-5	Detaching Generator Set from Traiier	5-8
5-6	Lifting Generator Set	5-9
	Components of End Item	B-2
	Basic Issue Items	B-3
D-1	Enclosure	D-8
D-2	Generator Set	D-10
D-3	Trailer Body	D-12
D-4	Accessory Box	D-16
D-5	Leg Prop Assembly	D-18

LIST OF TABLES

Number	Title	Page
3-1	Consumable Operating and Maintenance Supplies	3-1
3-2	Operator/Crew Preventive Maintenance Checks and Services (PMCS)	3-4
4-1	Unit Preventive Maintenance Checks and Services(PMCS)	4-9

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. **Scope.** This manual is for your use in operating and maintaining the Power Unit, PU-751/M. The PU-751/M is a mobile power unit used to supply power to any system or equipment requiring up to 5 kW of 60 Hz input operating power. In addition to operating instructions and operator, unit, and intermediate direct support and general support maintenance procedures, this manual contains a Repair Parts and Special Tools List for the power unit.

1-2. **Maintenance Forms and Records.** Maintenance forms and records used by Army personnel are prescribed by DA Pam 738-750.

1-3. **Reporting of Errors.** Reporting of errors and omissions and recommendations for improvement of this publication by the individual user is encouraged. Submit DA Form 2028 directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MT, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798.

1-4. **Reporting Equipment Improvement Recommendations (EIR).** EIR's will be prepared using SF 368, Product Quality Deficiency Report. Instructions for preparing EIR's are provided in DA PAM 738-750, The Army Maintenance Management System. EIR's should be mailed directly to: Commander, US Army Aviation and Troop Support Command, ATTN: AMSAT-I-MDO, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798.

1-5. **Levels of Maintenance Accomplishment.** Army users shall refer to the Maintenance Allocation Chart (MAC) for tasks and levels of maintenance to be performed.

1-6. **Destruction of Army Materiel.** Destruction of Army materiel to prevent enemy use shall be in accordance with TM 750-244-3.

1-7. **Administrative Storage.**

a. Placement of equipment in administrative storage should be for short periods of time when a shortage of maintenance efforts exists. Items should be in mission readiness within 24 hours or within the time factors as determined by the directing authority. During the storage period appropriate maintenance records will be kept.

b. Before placing equipment in administrative storage, current maintenance services and equipment serviceable criteria (ESC) evaluations should be completed, shortcomings and deficiencies should be corrected, and all modification work orders (MWO's) should be applied.

c. Storage site selection. Inside storage is preferred for items selected for administrative storage. If inside storage is not available, trucks vans, conex containers and other containers may be used.

1-8. **Preparation for Shipment and Storage.** Refer to TB 740-97-2.

Section II. DESCRIPTION AND DATA

1-9. **Description.** Power Unit PU-751/M is made up of one Tactical Utility Generator Set, DOD Model MEP-002A, mounted on a modified M116A1 trailer. The generator set is an air-cooled diesel engine-driven unit with a load capacity of 5 KW at 60 Hz. The trailer is a two-wheeled unit with a 3/4-ton carrying capacity. The modifications to the basic trailer provide stowage for the accessories and all equipment necessary for mobile operation as well as providing a work platform for the operator and maintenance personnel. Figures 1-1 and 1-2 illustrate the power unit with the fitted cover removed to show the generator set.




Figure 1-1. Power Unit, Roadside Front, Three-Quarter View.




Figure 1-2. Power Unit, Curbside Rear, Three-Quarter View.

1-10. **Tabulated Data.** The tabulated data provides operator and unit level personnel with the dimensions and weights for Power Unit, PU-751/M. These specifications are computed from the combined dimensions and weights of the generator set and trailer as modified for use with the power unit. Specifications of the individual components can be found in their respective technical publications. For additional information concerning Generator Set, DOD Model MEP-002A, refer to TM5-6115-584-12 and -34. For additional information on the M116A1 trailer, refer to TM 9-2330-202-14&P. The tabulated data also includes the location and content of all data plates unique to the power unit.

a. Identification and Instruction Plates.

(1) *Identification plate.*

(a) *Location.* This plate is located on the front curbside frame between the trailer body and the drawbar ring.

(b) *Content.*

US
POWER UNIT
PU 751/M
KW 5
HERTZ 60
NSN 6115-00-033-1373

(2) *Instruction plate.*

(a) *Location.* This plate is located near the ground stud on the rear, curbside corner of the trailer body.

(b) *Content.*

GROUND TERMINAL

b. Tabulated Data for Power Unit.

Overall Length	142 inches (360.7 centimeters)
Overall Width	73 inches (185.4 centimeters)
Overall Height	79 inches (200.6 centimeters)
Net Weight (empty)	2200 pounds (998.8 kilograms)
Net Weight (filled)	2390 pounds (1084 kilograms)
Shipping Weight	2520 pounds (1144 kilograms)
Cubage	413 cubic feet (11.56 cubic meters)

1-11. **Differences Between Models.** There are no differences between models, serial numbers, or serial number groups applicable to this equipment.

CHAPTER 2

OPERATING INSTRUCTIONS

Section I. OPERATING PROCEDURES

2-1. Operating Procedures. The typical mission for any mobile power generating equipment can be described in three steps or phases. In the first phase, the power unit is towed to the worksite and installed by unit level technicians (paragraph 4-2). In the second phase of the mission, the operator starts the generator set, runs it to power a system or equipment, and eventually shuts it down. In the final phase, the power unit is dismantled, packed up and either moved to a new work site or returned to standby status (paragraph 4-3). This final phase is also accomplished by unit level technicians.

WARNING

Do not operate generator set until it is properly grounded (paragraph 4-2, b.) Serious injury or death by electrocution can result from operating an ungrounded generator set.

Operating noise level of generator can cause hearing damage. Ear protectors, as recommended by medical or safety officer, must be worn when working near power unit.

CAUTION

To avoid damage to equipment, make certain of voltage, frequency, and phase requirements of load connected to generator set.

NOTE

Before starting generator set, do your Before PMCS as described in table 3-2.

In order to perform the operator's tasks during the mission, refer to the data plate located on the right-hand side of the generator set control cubicle. Follow the operating instructions on the data plate to start and run the generator set. Monitor and adjust generator set power output as required during operation. At the end of the mission, shut down the generator set in accordance with the operating instructions on the data plate. For a copy of the information on the data plate, as well as more detailed operating procedures for the generator set, refer to TM 5-6115-584-12. For trailer operating procedures, refer to TM 9-2330-202-14&P.

Section II. OPERATION OF AUXILIARY EQUIPMENT

2-2. Operation of Auxiliary Equipment. There is no auxiliary equipment supplied with the power unit.

Section III. OPERATION UNDER UNUSUAL CONDITIONS

2-3. **Operation Under Unusual Conditions.** When operating the power unit under unusual conditions such as extremes in temperature or difficult terrain, there are steps that must be taken to protect the equipment.

- a. Refer to TM 5-6115-584-12 for special procedures when operating the generator set under unusual conditions.
- b. Refer to TM 9-2330-202-14&P for special procedures when operating the trailer under unusual conditions.

CHAPTER 3

OPERATOR/CREW MAINTENANCE INSTRUCTIONS

Section I. CONSUMABLE OPERATING AND MAINTENANCE SUPPLIES

3-1. **Consumable Supplies.** Consumable supplies used in the maintenance and operation of the power unit are listed in Table 3-1.

Table 3-1. Consumable Operating and Maintenance Supplies.

(1)	(2)	(3)	(4)	(5)	(6)
Component application	National stock number	Description	Qty required for initial operation	Qty required 8 hours operation	Notes
General Cleaning	6850-00-664-5685	Solvent, Drycleaning, PD-680	1 quart	As required	
Leg Prop Assembly	9150-00-190-0904	Grease, Automotive and Artillery, GAA	1 pound	As required	
Leg Prop Assembly	9150-00-186-6681	Oil, Lubricating, OE/HDO-30	1 quart	As required	
Leg Prop Assembly	9150-00-402-4478	Oil, Lubricating, OEA	1 quart	As required	

Section II. LUBRICATION INSTRUCTIONS

3-2. **General.** Detailed instructions for the lubrication of the major components of the power unit are contained in the applicable Lubrication Orders (LO's). Refer to DA Pam 25-30 to ensure the latest editions of the LO's are used.

3-3. **Generator Lubrication.** Refer to TM 5-6115-584-12 for generator set Lubrication Order.

3-4. **Trailer Lubrication.** There are no operator/crew lubrication requirements for the power unit trailer. However, the operator shall assist unit maintenance.

Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

NOTE

The PMCS chart in this section contains all necessary Operator/Crew preventive maintenance checks and services for this equipment.

3-5. **General.** The preventive maintenance checks and services listed in Table 3-2 are grouped according to stages of equipment operation or time intervals. Using the following as a guide, do the checks and services at the intervals shown.

- a. Before you operate, perform your before (B) PMCS. Observe all CAUTIONS and WARNINGS.
- b. While you operate, perform your during (D) PMCS. Observe all CAUTIONS and WARNINGS.
- c. After you operate, be sure to perform your after (A) PMCS.
- d. Do (W) PMCS weekly.
- e. Do (M) PMCS monthly.
- f. If equipment fails to operate, refer to Section IV Troubleshooting. If the problem cannot be corrected, see paragraph 3-8, Reporting Deficiencies.

3-6. **Purpose of PMCS Table.** The purpose of the PMCS table is to provide a systematic method of inspecting and servicing the equipment. In this way, small defects can be detected early before they become a major problem causing the equipment to fail to complete its mission. The PMCS table is arranged with the individual PMCS procedures listed in sequence under assigned intervals. The most logical time (before, during, or after operation) to perform each procedure determines the interval to which it is assigned. Make a habit of doing the checks and services in the same order each time and anything wrong will be seen quickly. See paragraph 3-7 for an explanation of the columns in table 3-2.

3-7. **Explanation of Columns.** The following is a list of the PMCS table column headings with a description of the information found in each column.

- a. Item No. This column shows the sequence in which the checks and services are to be performed, and is used to identify the equipment area on the Equipment Inspection and Maintenance Worksheet, DA Form 2404.
- b. Interval. This column shows when each check is to be done.
- c. Item to be Inspected/Procedures. This column identifies the general area or specific part where the check is or service is to be done, lists the checks or services to be done and explains how to do them.
- d. Equipment is Not Ready/Available If. This column lists conditions that make the equipment unavailable for use because it is unable to perform its mission or because it would represent a safety hazard. Do not accept or operate equipment with a condition in the "Equipment is Not Ready/Available If" column.

3-8. **Reporting Deficiencies.** If you discover any problem with the equipment during PMCS or while operating it that you are unable to correct, it must be reported. Refer to DA Pam 738-750 and report the deficiency using the proper forms.

3-9. **Special Instructions.** Preventive maintenance is not limited to performing the checks and services listed in the PMCS table. Covering unused receptacles, stowing unused equipment and other routine procedures such as equipment inventory, cleaning components, and touch-up painting are not listed in the PMCS table. These are things you should do any time you see they need to be done. If a routine check is listed in the PMCS table it is because other operators have reported problems with this item. Take along tools and cleaning cloths

needed to perform the required checks and services. Use the information in the following paragraphs to help you identify problems at any time.

a. Routine Inspections. Use the following information to help identify potential problems before and during checks and services.

WARNING

Drycleaning solvent PD-680 is both toxic and flammable. Wear safety goggles and gloves and use in a well-ventilated area. Avoid prolonged breathing of vapors and avoid skin contact. Do not use near open flame or excessive heat. Flash point of solvent is 100°F to 138°F (38°C to 59°C). If you become dizzy while using PD-680, get fresh air immediately and get medical aid. If PD-680 contacts eyes, flush with water and get medical aid immediately.

- (1) Keep it clean. Dirt, grease, and oil get in the way and may cover up a serious problem. Use drycleaning solvent PD-680, to clean metal surfaces. Use soap and water to clean rubber or plastic parts and material.
- (2) Bolts, nuts, and screws. Check them all to make sure they're not loose, missing, bent, or broken. Don't try to check them all with a tool, but look for chipped paint, bare metal, or rust around bolt heads. If you find one loose, tighten it or report it to unit maintenance.
- (3) Welds. Look for loose or chipped paint, rust, or gaps where parts are welded together. If a broken weld is found, report it to higher level of maintenance.
- (4) Electrical wires connectors, terminals and receptacles. Look for cracked or broken insulation, bare wires, and loose or broken connectors. Tighten loose connectors and make sure the wires are in good condition. Examine terminals and receptacles for serviceability.
- (5) Hoses and fluid lines. Look for wear, damage, and leaks. Make sure clamps and fittings are tight. Wet spots and stains around a fitting or connector can mean a leak. If a leak comes from a loose connector, tighten it. If something is broken or worn out, report it to unit maintenance.

b. Leakage Definitions. It is necessary for you to know how fluid leakage affects the status of your equipment. The following are definitions of the types/classes of leakage you need to know to be able to determine the status of your equipment. Learn and be familiar with them. When in doubt, NOTIFY YOUR SUPERVISOR!

Leakage Definitions:

Class I	Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.
Class II	Leakage of fluid great enough to form drops but not enough to cause drops to drip from item being checked/inspected.
Class III	Leakage of fluid great enough to form drops that fall from the item being checked/inspected.

CAUTION

Equipment operation is allowable with minor leakage (Class I or II) of any fluid except fuel. Of course, consideration must be given to the fluid capacity in the item being checked/inspected. When in doubt, notify your supervisor.

When operating with Class I or II leaks, continue to check fluid level more often than required in the PMCS. Parts without fluid will stop working and/or cause equipment damage.

Class III leaks should be reported to your supervisor or unit maintenance.

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS).

NOTE

If the equipment must be kept in continuous operation, check and service only those items that can be checked and serviced without disturbing operation. Make the complete checks and services when the equipment can be shut down.

Within designated interval, these checks are to be performed in the order listed.

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS).

B - Before D - During A - After W - Weekly M - Monthly

Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
						<p style="text-align: center;"><u>WARNING</u></p> <p>Before performing any maintenance that requires climbing on or under trailer, set trailer handbrakes, chock wheels, and lower rear leg prop. Injury to personnel could result from trailer suddenly rolling or tipping.</p> <p style="text-align: center;">NOTE</p> <p>Perform weekly as well as before PMCS if you are the assigned operator but have not operated the equipment since the last weekly inspection.</p>	

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).


B – Before

D – During

A – After

W - Weekly

M – Monthly

Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
1	•					<p>NOTE</p> <p>Perform weekly as well as before PMCS if you are operating the equipment for the first time.</p> <p>GENERATOR SET EXTERIOR</p> <p>a. Check on, around, and beneath the generator set (1) for fuel or oil leaks.</p> <p>b. Check that generator set (1) grounds are properly installed and grounding connections are tight.</p>	<p>A Class III lubrication oil or any class fuel leak is detected.</p> <p>Not properly grounded.</p>
2	•					<p>FUEL GAGE</p> <p>Check fuel gage (2) for sufficient fuel for continuous operation.</p> 	

4874-003

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).



Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
3	•		•			<p>ENGINE OIL LEVEL</p> <p>Check oil filler dipstick (3) for proper oil level. Add oil as required.</p>  <p style="text-align: right;">4874-004</p>	
4	•	•				<p>AIR CLEANER INDICATOR</p> <p>Check indicator (4) for a restricted air cleaner. If red warning indicator becomes visible, notify unit maintenance for cleaning or replacement.</p>  <p style="text-align: right;">4874-005</p>	

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
5	•					<p>ACCESSORIES</p> <p>Check that the following accessories are not missing.</p> <p>a. Sledge hammer</p> <p>b. Fire extinguisher</p> <p>c. Slide hammer</p> <p>d. Ground rods.</p> <p>e. Fuel drum adapter</p>	<p>Fire extinguisher is missing.</p> <p>Ground rods are missing.</p>
6	•					<p>BRACKETS</p> <p>Check fire extinguisher and fuel can mounting brackets for loose hardware or broken fittings.</p>	
7	•					<p>TIRES</p> <p>a. Check tires (5) for cuts, foreign objects, or unusual tread wear. Remove any stones from between the treads.</p> <p>b. Check that tire pressure is 35 psi (241.22 kPa) when tires are cool.</p>	<p>One tire is flat, missing, or unserviceable.</p>
8	•					<p>WHEELS</p> <p>Check for damage and for missing or loose stud nuts (6).</p>	<p>One or more wheels are damaged. One or more stud nuts are loose or missing.</p>

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B - Before D – During A – After W – Weekly M – Monthly


Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
8	•					<p>WHEELS (cont)</p>  <p style="text-align: right;">4874-006</p>	
9	•					<p>DRAWBAR RING</p> <p>Check drawbar ring (7) for insecure mounting and obvious damage.</p>	Ring is loose or bent.
10	•					<p>INTERVEHICULAR CABLE</p> <p>Check cable (8) and connector for cuts and breaks.</p>	Intervehicular cable is broken or missing.
11	•					<p>SAFETY CHAINS</p> <p>Check safety chains (9) for insecure mounting and obvious damage.</p>	Safety chains are missing or unsecured.

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B – Before

D – During

A – After

W – Weekly

M – Monthly


Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
11	•					<p>SAFETY CHAINS (cont)</p>  <p style="text-align: right;">4874-007</p>	
12	•					<p>BOW ASSEMBLIES AND TARPAULIN SUPPORT</p> <p>Inspect for damaged bow assemblies (10) or tarpaulin support (11).</p>	
13				•		<p>FITTED COVER</p> <p>a. Check fitted cover (12) for missing and defective tiedown straps and snap fasteners (13).</p> <p>b. Check for missing and defective ropes (14).</p> <p>c. Check for missing and defective straps and buckles (15).</p> <p>d. Check for ripped seams and tears.</p>	

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B - Before D - During A - After W - Weekly M - Monthly



Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
13						<p>FITTED COVER (cont)</p>  <p style="text-align: right;">4874-008</p>	
14	•					<p>LIGHTS</p> <p>a. With intervehicular cable connected to towing vehicle, operate vehicle light switch through all settings and check lights.</p> <p style="text-align: center;">NOTE</p> <p>An assistant is required while checking brake lights.</p> <p>b. Step on brake pedal of towing vehicle and check brake lights (16).</p>  <p style="text-align: right;">4874-009</p>	Lights do not function properly.

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).



Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
15	•	•				<p>HYDRAULIC HOSES AND TUBES</p> <p>Check brake system hoses and tubes, and check under vehicle for signs of brake fluid leaks.</p>	Any brake fluid leaks are detected.
16		•				<p>SUPPORT LEG ASSEMBLY</p> <p>With trailer connected to towing vehicle, check support leg assembly (17) for ease of operation.</p>  <p style="text-align: right;">4874-010</p>	Support leg assembly is seized.
17		•				<p>REAR LEG PROP ASSEMBLY</p> <p>Inspect leg prop assembly (18) for broken or missing parts</p>  <p style="text-align: right;">4874-011</p>	Leg prop assembly is unserviceable.

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B - Before D - During A - After W - Weekly M - Monthly


Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
18		•				<p>BRAKE SYSTEM</p> <p>Test brake system by hooking trailer to towing vehicle and applying brakes.</p>	Service brakes fail to operate.
19		•				<p>TRAILER OPERATION</p> <p>a. Be alert for any unusual noises while towing trailer. Stop and investigate any unusual noises.</p> <p>b. Ensure that trailer is tracking/following correctly behind towing vehicle with no side pull.</p>	
20		•				<p>GENERATOR SET GAGES AND INSTRUMENTS</p> <p>a. Check that battery indicator (19) is in yellow area while batteries are charging and in green area when batteries are fully charged.</p> <p>b. Check that frequency meter (20) indicates 60 Hz (red line) when generator is operating under load.</p> <div style="text-align: center;">  </div> <p>c. Check that ammeter (21) reading does not exceed 100% or more than 5% load difference between phases.</p>	

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B – Before D – During A – After W – Weekly M – Monthly



Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
20						<p>GENERATOR SET GAGES AND INSTRUMENTS (cont)</p> <p>d. Check that voltmeter (22) indicates desired output voltage as determined by load connections and amps-volts transfer switch.</p>  <p style="text-align: right;">4874-013</p> <p>e. Check engine oil pressure gage (23) for 25 psi indication.</p>  <p style="text-align: right;">4874-014</p>	<p>Desired voltage cannot be obtained and maintained.</p> <p>Oil pressure drops below 15 psi.</p>

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B - Before D – During A – After W – Weekly M - Monthly


Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
21			•			<p>FUEL TANK</p> <p>a. Fill tank (24) upon completion of operation.</p> <p style="text-align: center;">NOTE</p> <p>Fuel system temperature must be above freezing when draining water and sediment.</p> <p>b. Open drain (25) and drain water and sediment from fuel tank into a suitable container. Allow to drain until fuel runs clean.</p>  <p style="text-align: right; font-size: small;">4874-015</p>	
22			•			<p>FUEL STRAINER AND FILTERS</p> <p>Drain water and sediment from strainer (26), primary (27) and secondary (28) filters. Allow to drain until fuel runs clean.</p>	

Table3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B - Before D - During A - After W - Weekly M - Monthly



Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
22						<p>FUEL STRAINERS AND FILTERS (cont)</p>  <p style="text-align: right;">4874-016</p>	
23			•			<p>HANDBRAKES</p> <p>With trailer hooked to towing vehicle, set handbrakes (29). Move trailer slightly to see if handbrakes hold wheels.</p>  <p style="text-align: right;">4874-017</p>	

Table3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B - Before D - During A- After W - Weekly M - Monthly


Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
24			*			<p>BRAKE DRUMS AND HUBS</p> <p style="text-align: center;"><u>WARNING</u></p> <p>A defect in the operation of the brakes or hub can cause these parts to get hot enough to cause serious burns. Use extreme caution when attempting to detect heat in this area.</p> <p>Feel for overheating to detect dragging or binding.</p>	Brakes or hub are dragging or binding.
25					<ul style="list-style-type: none"> • REFLECTORS <p>Check for damaged or missing reflectors.</p>		
26					<ul style="list-style-type: none"> • BATTERIES <p>Check battery (30) electrolyte level. Level should be about 3/4 inch above top of plates. Add water if level is low. Use clean water (distilled water if available).</p> 		

Table 3-2. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (cont).

B – Before D – During A – After W – Weekly M - Monthly

Item no.	Interval					Item to be inspected. Procedure: check for and have repaired, filled, or adjusted as needed	Equipment is not ready/available if:
	B	D	A	W	M		
27					•	FIRE EXTINGUISHER Inspect and weight fire extinguisher. (See paragraph 3-12.)	Frame is obviously broken broken or cracked.
28					•	TRAILER FRAME Inspect entire chassis frame for damage, cracks, and broken welds.	

Section IV. TROUBLESHOOTING

3-10. Power **Unit Troubleshooting.** There are no troubleshooting procedures authorized at operator level for the power unit end item. Troubleshooting procedures for the individual generator set and trailer are contained in their respective technical manuals referenced below.

- a. Generator Set Troubleshooting. Refer to TM 5-6115-584-12 for troubleshooting procedures.
- b. Trailer Troubleshooting. Refer to TM 9-2330-202-14&P for troubleshooting procedures.

Section V. OPERATOR/CREW MAINTENANCE

3-11. **Enclosure Maintenance.** Maintenance of the enclosure at operator level is limited to replacement of the fitted cover and/or the bows.

- a. Fitted Cover Replacement .(See figures 3-1 and 3-2.)
 - (1) *Removal.*
 - (a) Untie 27 ropes (1, figure 3-1) fastening fitted cover to trailer body (2).
 - (b) Unfasten six straps and buckles (3) securing rear curtain (4). Roll up curtain, and secure with three rollup straps (5) provided.
 - (c) Unfasten six straps and buckles (3) securing front curtain (6). Roll up curtain, and secure with three rollup straps (5) provided.
 - (d) Roll up each side (7) of fitted cover, in turn, and secure each side with four rollup straps (5) provided.


- (e) Working under fitted cover (1, figure 3-2), unfasten eight straps (2) securing fitted cover to bow assemblies (3). Remove fitted cover.

(2) Installation.

NOTE


Front curtain is provided with three tie-down ropes. Rear curtain only has two ropes.

- (a) Position fitted cover (1, figure 3-2) on top of bows (3) making certain front of fitted cover is at front of trailer.
- (b) Secure fitted cover (1) to bow assembly (3) with eight straps (2) provided.
- (c) Unfasten rollup straps (5, figure 3-1) securing sides of fitted cover and lower both sides (7).
- (d) Unfasten rollup straps (5) securing front and rear curtains (4, 6) and lower both curtains.
- (e) Secure front and rear curtains (4, 6) to sides (7) with six straps and buckles (3) provided on each curtain.
- (f) Secure fitted cover to trailer body (2) with 27 ropes (1) provided.



4874-019

Figure 3-1. Fitted Cover Installed on Power Unit.



4874-020

Figure 3-2. Fitted Cover Rolled Up for Removal.

b. Tarpaulin Support and Bow Assembly Replacement. (See figures 3-3 and 3-4.)

(1) *Removal.*

(a) Remove fitted cover (paragraph 3-11, a.(1)).

(b) Remove one screw (1, figure 3-3), two flat washers (2), one lockwasher (3) and one wing nut (4) securing tarpaulin support (5) to each of four bow assemblies (6) and remove tarpaulin support.

(c) Remove two quick release pins (1, figure 3-4) securing each bow assembly (2) in pocket (3) on trailer body (4). Lift each bow out of pocket and off trailer body.

(2) *Installation.*

(a) Lift each bow (2, figure 3-4) onto trailer, align bow ends with pockets (3) in trailer body (4) and drop bow in place. Secure each bow assembly with two quick release pins (1) provided.

(b) Position tarpaulin support (5, figure 3-3) on bows (6) and secure tarpaulin support to each bow with one screw (1), two flat washers (2), one lockwasher (3) and one wing nut (4).

(c) Install fitted cover on trailer (paragraph 3-11, a.(2)).




Figure 3-3. Tarpaulin Support Replacement.




Figure 3-4. Bow Replacement.

3-12. **Fire Extinguisher Maintenance.** The PU-751/M Power Unit is equipped with a 5 lb Halon fire extinguisher. Maintenance is limited to weighing the fire extinguisher monthly to insure that it is sufficiently charged. Fully charged, the fire extinguisher (with head and horn attached) weighs 5 lb. Send the unit to specialized activity for recharging if it weighs 4 lb 12 oz or less.

WARNING

Monobromotrifluoroethane liquid or gas (Halon 1301) can cause death or serious injury if personnel fail to observe safety precautions. Inhalation of monobromotrifluoroethane gas at concentrations of 5% to 6% for more than 4 or 5 minutes may result in serious cardiac or central nervous system effects. Liquid Halon 1301 (including the spray in the immediate vicinity of the discharge) may freeze the skin on contact. In the event of frostbite, warm the affected area quickly to body temperature. Immerse hands in warm water or place hands in armpits. Get medical attention promptly.

CAUTION

Do not attempt to verify readiness of fire extinguisher by partially discharging unit. Any discharge of contents will require refilling.

Change 4 3-21/(3-22 blank)


CHAPTER 4

UNIT MAINTENANCE

Section I. SERVICE UPON RECEIPT OF EQUIPMENT

4-1. **Inspecting and Servicing Equipment.** The power unit is unpacked, inspected, and serviced as described in the following paragraphs. Unpacked equipment must be checked against the Components of End Item and Basic Issue Items Lists to ensure completeness. Discrepancies must be reported in accordance with instructions in DA Pam 738-750.

a. Unpacking Power Unit. (See figures 4-1 and 4-2.) The generator set is packed in place on the trailer body. Before beginning the unpacking procedure, locate, remove, and save the waterproof envelopes marked Depreservation Guide.



4874-023

Figure 4-1. Uncrating Generator Set.

WARNING

Steel banding used in packaging of power unit has sharp edges. Care should be taken when cutting and handling banding to avoid injury to personnel.

- (1) Remove lag screws securing plywood box cover over generator set and lift cover off generator. Remove wooden wedges positioned around base of generator.

- (2) Remove and save package of technical manuals secured to barrier material covering generator.
- (3) Remove barrier material surrounding inner container.
- (4) Remove inner, half-slotted container from around generator set.
- (5) Remove coiled ground cable from within base of generator set.
- (6) Remove packaged fire extinguisher taped to generator set. Unpack and secure fire extinguisher in bracket on roadside fender.
- (7) Unpack and inventory contents of accessory box.
- (8) Install ground wire between generator set ground stud and power unit ground terminal.




Figure 4-2. Unpacking Fitted Cover, Bows and Tarpaulin Support.

- (9) Remove box containing fitted cover.

NOTE

Inspection and servicing of equipment will be easier to perform before fitted cover is put in place on power unit.

- (10) Remove protective film from fitted cover and set fitted cover aside.
- (11) Remove strapping and wood blocking securing bows and tarpaulin support from trailer.
- (12) Refer to DA Form 2258, Depreservation Guide for Vehicles and Equipment, packed with power unit and follow instructions given for putting unit in service.
- (13) Stow all authorized accessories in the accessory box.
- (14) Install bows and tarpaulin support on power unit (paragraph 3-11, b (2)).
- (15) Install fitted cover on power unit (paragraph 3-11, a(2)).

b. Inspection and Servicing of Generator Set. Refer to Servicing Upon Receipt of Material in TM 5-6115-584-12 for initial inspection and servicing procedures.

c. Inspection and Servicing of Trailer. Refer to Servicing Upon Receipt of Material in TM 9-2330-202-14&P for initial inspection and servicing procedures.

4-2. **Installation.** (See figure 4-3.) Installation of the power unit at a worksite involves positioning the trailer and grounding the power unit.

a. Positioning Power Unit. Position the power on the worksite as follows:

- (1) Select an area as level as possible to install power unit and position trailer.
- (2) Set trailer handbrakes and lower trailer support leg.
- (3) Chock both wheels and lower rear leg prop assembly. Adjust leg prop assembly by turning inner leg until leg base makes firm contact with ground
- (4) Lift and secure fitted cover in raised position away from generator set exhaust.


WARNING

Remove fire extinguisher and fuel cans from power unit when generator set is in operation. This will insure that, in the event of fire, extra fuel will not be involved and extinguisher will remain accessible.

- (5) Locate fuel cans and fire extinguisher on ground away from power unit.

WARNING

Do not operate generator set until power unit is properly grounded (paragraph 4-2, b.). Serious injury or death by electrocution can result from operating an ungrounded power unit.



4874-025

Figure 4-3. Installing Power Unit.

CAUTION

To avoid damage to equipment, make certain of voltage, frequency, and phase requirements of load being connected to generator set.

(6) Refer to data plate on load terminal board cover and to TM 5-6115-584-12. Connect power unit to system or equipment to be powered.

b. Grounding. Check that generator set is grounded to GROUND TERMINAL stud on trailer body. Using ground wire supplied with power unit, connect power unit to a suitable ground as described below. The following sources of good ground are listed in order of preference.

NOTE

As a substitute for the supplied ground wire, any copper wire of a least No. 6 AWG may be used.

- (1) *Underground water system.* Ground power unit to one of the accessible pipes in an underground water system. Make certain underground pipe is made of metal and there is no insulation, such as a water meter, between ground wire and earth.
- (2) *Ground rod.* Drive ground rod a minimum of eight feet into earth. A ground rod must have a minimum diameter of 5/8-inch, if solid, or 3/4-inch if pipe.

NOTE

It may be necessary to saturate the area around ground rod with water if soil conditions are dry.


- (3) *Ground plate.* Ground power unit to a metal plate buried four feet deep. Ground plate should cover a minimum area of nine square feet.

c. *External Fuel Line Connection.* (See figure 4-4.) The power unit generator set can be fueled from an external source such as a five-gallon fuel can or 55 gallon drum. This eliminates the need for frequent refilling of the generator's fuel tank during long intervals of operation.

- (1) Remove fuel can adapter and fuel pickup tube from storage locations on generator set and assemble by threading pickup tube into adapter.
- (2) Thread one end of auxiliary fuel line onto fuel can adapter fitting and tighten.
- (3) Connect free end of auxiliary fuel line to AUXILIARY FUEL CONNECTION. This connection is located immediately below control cubicle on right-hand side of generator set.
- (4) Insert fuel can adapter in external fuel source and secure by pressing down on lever.
- (5) Set MASTER SWITCH on control panel to PRIME AND RUN AUX FUEL POSITION.

NOTE

When generator set is run on auxiliary fuel, as described above, fuel is first pumped into generator set fuel tank by auxiliary fuel pump. Fuel is then fed to generator set engine from fuel tank.



4874-026

Figure 4-4. External Fuel Line Connection.

Section II. MOVEMENT TO A NEW WORKSITE

4-3. **Dismantling for Movement.** Because the power unit is designed to be mobile, a minimum amount of effort is required to relocate to a new worksite. Procedures are as follows:

- a. Disconnect power unit from system or equipment being powered.
- b. Disconnect ground cable from source of ground and from power unit GROUND TERMINAL stud. Roll up cable and store in accessory box.
- c. Using slide hammer, remove ground rod. Disassemble, clean, and stow ground rod in accessory box.
- d. Disconnect power unit from external fuel source, if applicable.
- e. Stow any remaining authorized equipment in accessory box.
- f. Secure fire extinguisher and fuel cans in their respective mounting brackets.
- g. Lower and secure fitted cover in place on power unit.

h. Remove locking pin from leg prop assembly on rear of trailer. Swing leg prop back and up into traveling position and secure with pin.

i. Attach power unit to towing vehicle. (Refer to TM 9-2330-202-14&P.)

j. Release trailer handbrakes.

4-4. **Reinstallation After Movement.** After movement to a new worksite, install power unit in accordance with paragraph 4-2.

Section III. REPAIR PARTS, SPECIAL TOOLS, SPECIAL TEST, MEASUREMENT AND DIAGNOSTIC EQUIPMENT (TMDE)

4-5. **Tools and Equipment.** There are no special tools or equipment required to maintain the PU-751/M power unit.

4-6. **Maintenance Repair Parts.** Repair parts and equipment for maintenance of this power unit are listed and illustrated in the repair parts and special tools list in Appendix D of this manual.

Section IV. LUBRICATION INSTRUCTIONS

4-7. **General.** Detailed instructions for the lubrication of the major components of the power unit are contained in the applicable Lubrication Orders (LO's). Refer to DA Pam 25-30 to ensure that the latest editions of the L.O.'S are used. This section contains lubrication instructions that are not included in the Lubrication Orders.

4-8. **General Lubrication.** Refer to TM 5-6115-584-12 for generator set Lubrication Order.

4-9. **Trailer Assembly Lubrication.**

a. Trailer Assembly Lubrication. Refer to TM 9-2330-202-14&P for trailer Lubrication Order.

b. Leg Prop Assembly Lubrication. The rear leg prop assembly is a modification to the standard M116A1 trailer and, as such, does not appear in the associated LO. Semiannually lubricate leg prop assembly as follows:

WARNING

Clean parts in a well-ventilated area. Avoid inhalation of solvent fumes and prolonged exposure of skin to cleaning solvent. Wash exposed skin thoroughly. Dry cleaning solvent (PD-680) used to clean parts is potentially dangerous to personnel and property. Do not use near open flame or excessive heat. Flash point of solvent is 100°F to 138°F (38°C to 59°C).

(1) Clean hydraulic lubrication fitting and area around lubrication points with PD-680 or equivalent.

(2) Inject sufficient GAA grease into hydraulic fitting to lubricate screw threads inside leg prop assembly

NOTE

Refer to Lubrication Order in TM 9-2330-202-14&P for lubricating oils specified for use with different anticipated temperature ranges.

- (3) Apply OE lubricating oil to both ends of leg prop assembly pivot shaft.

Section V. PREVENTIVE MAINTENANCE CHECKS AND SERVICES

NOTE

The PMCS chart in this section contains all necessary unit preventive maintenance checks and services for this equipment.

4-10. **General.** The trailer assembly and generator set must be inspected and serviced systematically to insure that the power unit is ready for operation at all times. Inspection will allow defects to be discovered and corrected before they result in serious damage or failure. Table 4-1 contains a tabulated list of preventive maintenance checks and services to be performed by unit maintenance personnel. All of the unit PMCS on the trailer is scheduled to be performed semiannually. Unit PMCS on the generator set is scheduled weekly or on a per-hours-of-operation basis. The running time meter on the control panel is used to determine the generator set operating time. Using the following as a guide, do the checks and services at the intervals shown. Observe all CAUTIONS and WARNINGS.

- a. For PMCS performed on an operating time basis, perform your hourly (H) PMCS as close as possible to the time intervals indicated.

NOTE

For units in continuous operation, perform PMCS before starting operation if continuous operation will extend service interval past that which is shown.

- b. Perform your weekly (W) PMCS every week or 40 hours of generator set operating time.
- c. Perform your monthly (M) PMCS every month or 100 hours of generator set operating time.
- d. Do your semiannual (S) PMCS once every six months or 500 hours of operating time.
- e. Do your annual (A) PMCS once every year or 1000 hours of operating time.
- f. If you discover a problem with the equipment, refer to Section VI, Troubleshooting. If you cannot correct the problem, refer to paragraph 4-12, Reporting Deficiencies.

4-11. **Explanation Of Columns.** The following is a list of the PMCS table column headings with a description of the information found in each column.

a. Item No. This column shows the sequence in which to do the checks and services, and is used to identify the equipment area on the Equipment Inspection and Maintenance Worksheet, DA Form 2404.

b. Interval. This column shows when each check is to be done.

c. Item to be Inspected. This column identifies the general area or specific part where the check or service is to be done.

d. Procedures. This column lists the checks or service you have to do and explains how to do them.

4-12. **Reporting Deficiencies.** If you discover any problem with the equipment during PMCS that you are unable to correct, it must be reported. Refer to DA Pam 738-750 and report the deficiency using the proper forms.

Table 4-1. Unit Preventive Maintenance Checks and Services (PMCS).

H - Hours of operation
(As indicated)

M - Monthly
(100 hours)

S – Semiannually
(500 hours)

A – Annually
(1000 hours)

Item no.	Interval				Item to be inspected	Procedures
	H	M	S	A		
1		•			Generator Set	<p style="text-align: center;"><u>WARNING</u></p> <p>Before performing any maintenance that requires climbing on or under trailer, set trailer handbrakes, chock wheels, and lower rear leg prop. Injury to personnel could result from trailer suddenly rolling or tipping.</p> <p>Inspect generator set for fuel and oil leaks, loose or missing components and hardware, and unusual wear or deterioration. Clean generator set.</p>
2		•			Fuel Strainer and Filters	<p style="text-align: center;">NOTE</p> <p>Fuel system must be above freezing temperature when draining water and sediment from strainer, filters, and tank.</p> <p>Open drains on fuel strainer, and primary and secondary filters. Drain water and sediment into a suitable container (table 3-2, TM 5-6115-584-12). Allow to drain until fuel runs clean.</p>
3		•			Fuel Tank	<p>Open drain on fuel tank and drain water and sediment into a suitable container (table 3-2, TM 5-6115-584-12). Allow to drain until fuel runs clean.</p>
4			•		Fuel Pumps	<p>Clean or replace, as necessary, fuel strainer in bottom of fuel pump (table 4-1, TM 5-6115-584-12).</p>

Table 4-1. Unit Preventive Maintenance Checks and Services (PMCS) (cont).

H - Hours of operation
(As indicated)

M – Monthly
(100 hours)

S - Semiannually
(500 hours)

A - Annually
(1000 hours)

Item no.	Interval				Item to be inspected	Procedures
	H	M	S	A		
5	100				Lubricating Oil and Filter	Change lubricating oil and filter every 100 hours of operation (LO. 5-6115-584-12).
6	300				Fuel Strainer	Clean fuel strainer every 300 hours of operation (para 3-20, TM 5-6115-584-12).
7	500				Primary Fuel Filter	Service primary filter every 500 hours of operation (table 4-1, TM 5-6115-584-12).
8	1000				Secondary Fuel Filter	Service secondary filter every 1000 hours (table 4-1, TM 5-6115-584-12).
9	300				Batteries	Perform a hydrometer test on batteries every 300 hours, or quarterly. Refer to para 4-25, TM 5-6115-584-12 for test procedures.
10	500				Crankcase Breather	Inspect breather tube every 500 hours. Clean as necessary (para 4-45, TM 5-6115-584-12).
11	100				Dust Caps on Air Cleaner	Clean out dust caps on air cleaner assembly every 100 operating hours (more frequently under unusual conditions).
12	1000				Air Cleaner	Clean every 1000 operating hours or as conditions dictate. Replace air cleaner every 2000 operating hours.
13			•		Taillights	Replace any broken or cracked lenses or defective bulbs (page 4-52, TM 9-2330-202-14&P).
14			•		Intervehicular Cable	Check for cuts, breaks, frayed wires, or damaged plug.
15			•		Drawbar Ring	Check security of mounting. Inspect ring for excessive wear.
16			•		Safety Chains	Inspect for broken links or missing chain(s).
17			•		Reflectors	Replace any cracked, broken, or missing reflectors (page 4-232, TM 9-2330-202-14&P).

Table 4-1. Unit Preventive Maintenance Checks and Services (PMCS) (cont).

H - Hours of operation
(As indicated)

M – Monthly
(100 hours)

S – Semiannually
(500 hours)

A – Annually
(1000 hours)

Item no.	Interval				Item to be inspected	Procedures
	H	M	S	A		
18			•		Data Plates and Markings	Make sure data plates are legible and secure. Replace illegible data plates (page 4-236, TM 9-2330-202-14&P).
19			•		Support Leg Assembly	Inspect brackets and leg for bent or broken parts.
20			•		Rear Leg Prop Assembly	Inspect bracket and leg prop for bent or broken parts.
21			•		Suspension Assemblies	<ul style="list-style-type: none"> a. Inspect shackles, bearings, pins, leaf springs and spring eyes for damage or broken parts. b. Inspect mounting brackets for cracks or loose or missing hardware. c. Inspect shock absorbers for damage or leaks.
22			•		Axle	<ul style="list-style-type: none"> a. Check for damaged axle tube. b. Check for loose or missing U-bolts or nuts.
23			•		Wheels and Tires	<ul style="list-style-type: none"> a. Check serviceability of tires as indicated in TM 9-2610-200-24. b. Tighten wheel stud nuts.
24			•		Brakes	<ul style="list-style-type: none"> a. Inspect brake linings for wear. Replace if brake shoe lining is less than 1/8-inch (3.2 mm) thick (page 4-140, TM 9-2330-202-14&P). b. Inspect brake adjusting screw, retaining screw, retaining pins, springs, and clips for corrosion and wear. c. Inspect hydraulic wheel cylinders for leaks. d. Adjust brake (page 4-154, TM 9-2330-202-14&P).

Table 4-1. Unit Preventive Maintenance Checks and Services (PMCS) (cont).

Item no.	Interval				Item to be inspected	Procedures
	H	M	S	A		
25				•	Wheel Bearings	Clean and repack. (page 4-180, TM 9-2330-202-14&P).
26			•		Trailer – Road Test	Perform road test paying special attention to items that were repaired or adjusted, in accordance with TM 9-2330-202-14&P).

Section VI. TROUBLESHOOTING

4-13. **Power Unit Troubleshooting.** There are no troubleshooting procedures authorized at unit level for the power unit end item. Troubleshooting procedures for the individual generator set and trailer are contained in their respective technical manuals referenced below.

a. Generator Set Troubleshooting. Refer to TM 5-6115-584-12 for troubleshooting procedures applicable to the generator set.

b. Trailer Troubleshooting. Refer to TM 9-2330-202-14&P for troubleshooting procedures applicable to the trailer.

Section VII. RADIO INTERFERENCE SUPPRESSION

4-14. **General Methods Used to Attain Proper Suppression.** Essentially, suppression is attained by providing a low resistance path to ground for stray currents. The methods used include shielding ignition and high-frequency wires, grounding the frame with bonding straps, and using filtering systems.

4-15. **Radio Interference Suppression Components.** All component parts on the power unit end item, whose primary or secondary function is radio interference suppression, are on the generator set. Refer to TM 5-6115-584-12 for location of radio interference suppression components.

Section VIII. MAINTENANCE OF POWER UNIT TRAILER

4-16. **General.** This section of the manual contains unit level maintenance procedures for components of the M116A1 trailer added when the trailer is used as part of the PU-751/M power unit. These components are not covered in the overall trailer maintenance manual. For all other unit maintenance procedures on the trailer, refer to TM 9-2330-202-14&P.


WARNING

Before performing any maintenance that requires climbing on or under trailer, set trailer handbrakes, chock both wheels, and lower rear leg prop. Injury to personnel could result from trailer suddenly rolling or tipping.

4-17. **Fuel Can Bracket Replacement.** (See figure 4-5.) There are four fuel can brackets supplied with the PU-751/M. Two brackets are mounted on top of each fender. Replacement procedures described below are typical for all four.

a. Removal.

- (1) Remove four screws (1, figure 4-5), four self-locking nuts (2) and four lockwashers (3) securing bracket (4) to fender (5).
- (2) Remove bracket (4) from fender (5).



4874-027

Figure 4-5. Fuel Can Bracket Replacement.

b. Installation.

- (1) Position fuel can bracket (4) on fender (5).
- (2) Insert four screws (1) down through bracket (4) and through fender (5).
- (3) Install one washer (3) and one self-locking nut (2) on each screw (1). Tighten hardware to secure bracket (4).

4-18. **Accessory Box Replacement.** (See figure 4-6.) The accessory box is mounted to the trailer bed forward of the generator set.

a. Removal.

- (1) Remove four screws (1, figure 4-6), four flat washers (2), and four nuts (3) securing accessory box (4) to trailer bed (5).
- (2) Lift accessory box (4) off trailer (5).

b. Installation.

- (1) Position accessory box (4) on trailer bed (5).
- (2) Insert four screws (1) through accessory box mounting brackets and trailer bed (5).
- (3) Working under trailer, install one flat washer (2) and one nut (3) on each screw (1). Tighten hardware to secure accessory box (4).




Figure 4-6. Accessory Box Replacement.

4-19. Fire Extinguisher Bracket Replacement. (See figure 4-7.) The fire extinguisher supplied with the power unit is carried in a bracket mounted on the rear of the trailer roadside fender.

a. Removal.

- (1) Remove four screws (1, figure 4-7), four self-locking nuts (2), and four flat washers (3) securing bracket (4) to fender (5).
- (2) Remove bracket (4) from fender (5).

b. Installation.

- (1) Position fire extinguisher bracket (4) on fender (5).




Figure 4-7. Fire Extinguisher Bracket Replacement.

- (2) Insert four screws (1) down through bracket (4) and through fender (5).
- (3) Install one flat washer (3) and one self-locking nut (2) on each screw (1). Tighten hardware to secure bracket (4).

4-20. Leg Prop Assembly Servicing. Servicing of the leg prop assembly is limited to semiannual lubrication (paragraph 4-9, b.).

CHAPTER 5

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS

Section I. INTRODUCTION

5-1. General. This chapter contains Direct Support and General Support level maintenance procedures for components of the M116A1 trailer added when the trailer is used as part of the PU-751/M power unit. These components are not covered in the overall trailer maintenance manual. For all other direct and general support maintenance procedures on the trailer, refer to TM 9-2330-202-14&P. For direct and general support maintenance procedures on the generator set, refer to TM 5-6115-584-34.

WARNING

Before performing any maintenance that requires climbing on or under trailer, set trailer handbrakes, chock wheels and lower rear leg prop. Injury to personnel could result from trailer suddenly rolling or tipping.

Section II. MAINTENANCE OF POWER UNIT TRAILER

5-2. Leg Prop Assembly Maintenance. Maintenance of the leg prop assembly at the Intermediate Direct Support and General Support level consists of repairing or replacing the assembly as required.

a. Leg Prop Assembly Replacement (See figure 5-1.)

(1) *Removal.*


- (a) While supporting leg prop assembly, pull out angled bar (1, figure 5-1) and lower leg from traveling position.
- (b) Line up boss (2) on upper leg (3) with holes in bracket (4) and insert angled bar(1) to lock leg in support position.
- (c) Remove either one of two cotter pins (5) from leg prop assembly pivot shaft (6).
- (d) While steadying leg prop assembly, remove shaft (6) with remaining cotter pin (5) in place.

WARNING

When angled bar is removed in step (e), leg prop assembly will fall from bracket if not supported. To prevent injury to personnel or damage to equipment, do not permit leg assembly to drop.

- (e) Lift leg assembly slightly to take weight off angled bar (1) and remove bar.
- (f) Lower leg assembly from bracket (4).

- (g) Remove three screw (7), three flat washers (8), three lockwashers (9), and three nuts (10) and remove bracket (4) from trailer frame (11).



4874-030

Figure 5-1. Leg Prop Assembly Replacement.

(2) *Installation.*

- (a) Position bracket (4) on trailer frame (11) and install three screws (7), three flat washers (8), three lockwashers (9) and three nuts (10). Tighten hardware to secure bracket.
- (b) Lift leg prop assembly into bracket (4) and secure by inserting angled bar(1) through holes in bracket and boss (2) on upper leg (3).
- (c) Position leg prop assembly to line up boss (2) on top of leg with pivot holes in bracket (4). Insert pivot shaft (6).
- (d) Insert cotter pin (5) in pivot shaft (6) and bend cotter pin legs in opposite directions.
- (e) Pull out angled bar (1) to unlock leg prop assembly.
- (f) Swing leg prop assembly up into traveling position and secure by inserting angled bar (1) through holes in bracket (4) and boss (2) on upper leg (3).

b. Leg Prop Assembly Repair. Repair of the leg prop assembly is limited to welding and repainting. However, partial disassembly is possible to facilitate repair. If required, repaint in accordance with MIL-T-704 and MIL-C-46168.

(1) *Disassembly.*

- (a) Remove leg prop assembly from trailer (paragraph 5-2, a.(1)).
- (b) Clamp leg prop assembly in vise with spring pin facing up.
- (c) Using suitable drift, drive spring pin out of upper leg and remove leg base.

(2) *Assembly.*

- (a) Clamp upper leg in vise with spring pin hole facing up.
- (b) Insert leg base into upper leg and turn leg base until hole in screw lines up with hole in upper leg.
- (c) Install spring pin to secure leg base to upper leg.
- (d) Install leg prop assembly on trailer (paragraph 5-2, a.(2)).

5-3. **Trailer Bed and Fenders Repair and Replacement.** (See figure 5-2.) The body of the modified trailer consists of a single weldment that includes both fenders and the bed of the trailer.

a. Removal.

- (1) Remove fitted cover (paragraph 3-11, a.(1)).
- (2) Remove tarpaulin support and four bow assemblies (paragraph 3-11, b.(1)).
- (3) Remove accessory box (paragraph 4-18, a.).
- (4) Remove generator set (paragraph 5-7, a.).
- (5) Remove 10 screws (1, figure 5-2), 10 flat washers (2), and 10 nuts (3) securing trailer body (4) to trailer chassis (5).

NOTE

Observe position of screws securing rear braces on trailer body to trailer chassis.

- (6) Remove 16 screws (6), 16 flat washers (7) and 16 nuts (8) securing trailer body (4) to trailer chassis (5).

NOTE

Removal of the trailer body requires the removal and disassembly of both handbrake lever assemblies. The handbrake lever assemblies are symmetrical and this procedure is typical for both.




Figure 5-2. Fender and Bed Replacement.

4874-031

- (7) Remove two screws (9), two spacers (10), and two nuts (11) and remove roadside handbrake lever assembly (12) from trailer chassis (5).
- (8) Remove cotter pin (13), washer (14), shaft (15), and pulley (16) from handbrake lever assembly (12).
- (9) Working under trailer, pull handbrake cable clevis (17) back through holes in front two braces on trailer body.
- (10) Repeat steps (7) through (9) to remove and disassemble curbside handbrake lever assembly.

WARNING

When lifting trailer body, use lifting equipment with a minimum lifting capacity of 500 lb. Do not stand under trailer body while it is being lifted. Failure to observe these precautions can cause injury to personnel or damage to equipment.

- (11) Using suitable lifting equipment with a minimum lifting capacity of 500 lb, lift trailer body (4) off of trailer chassis (5).

b. Repair. Repair of the trailer bed and fenders is limited to replacement of strap fastener loops and straightening, welding, and repainting the bed and fender weldment. If required, repaint in accordance with MIL-T-704 and MIL-C-46168. There is one strap fastener loop mounted to the top of each fender. Replace as follows:

- (1) Remove two screws (18), two flat washers (19) and two self-locking nuts (20) securing strap fastener loop (21) to fender and take off strap fastener loop.
- (2) Position new strap fastener loop (21) on fender and secure with two screws (18), two flat washers (19) and two self-locking nuts (20).

c. Installation.

WARNING

When lifting trailer body, use lifting equipment with a minimum lifting capacity of 500 lb. Do not stand under trailer body while it is being lifted. Failure to observe these precautions can cause injury to personnel or damage to equipment.

- (1) Using suitable lifting equipment with a minimum lifting capacity of 500 lb, lift trailer body (4) onto trailer chassis (5) and align mounting holes.
- (2) Insert 10 screws (1) with flat washers (2) through trailer bed and through trailer chassis frame rails.
- (3) Working under trailer, install one nut (3) on each screw (1).
- (4) Insert 16 screws (6) with 16 flat washers (7) through trailer body braces into trailer chassis.
- (5) Working under trailer, install one nut (8) on each screw (6). Tighten hardware to secure trailer body to trailer chassis.

- (6) Feed roadside handbrake cable clevis (17) forward through holes in front two braces on trailer body.
- (7) Wrap handbrake cable around pulley (16), position pulley in handbrake lever assembly (12) and insert shaft (15).
- (8) Install washer (14) and cotter pin (13) to secure shaft (15).
- (9) Assemble handbrake lever assembly (12) using two screws (9) and two spacers (10). Make certain top screw goes through spacer (22) and bottom screw goes through handbrake cable clevis.
- (10) Position assembled handbrake lever assembly(12) on trailer chassis (5) and install two nuts (11). Tighten hardware.
- (11) Repeat steps (6) through (10) to assemble and install curbside handbrake lever assembly.
- (12) Install generator set (paragraph 5-7, b.).
- (13) Install accessory box (paragraph 4-18, b.).
- (14) Install tarpaulin support and four bow assemblies (paragraph 3-11, b.(2)).
- (15) Install fitted cover (paragraph 3-11, a.(2)).

5-4. **Fitted Cover Repair.** Repairs to fitted cover shall be made in accordance with FM 10-16, Fabric Repairing.


5-5. **Accessory Box Repair.** (See figure 5-3.) The accessory box is repaired by replacing the hasp, the catches and the footmans loops, as required. The box itself may be straightened, welded, and repainted. If required, repaint in accordance with MIL-T-704 and MIL-C-46168.

a. Catch and Hasp Replacement.

- (1) Grind off or drill out solid rivets (1, figure 5-3) securing catch or hasp (2) to accessory box (3).
- (2) Position new catch or hasp (2) on accessory box and secure with solid rivets (1).
- (3) Touch up with paint as required.

b. Strap Fastener Loop Replacement.


- (1) Remove two screws (4, figure 5-3), two flat washers (5), and two self-locking nuts (6) securing footmans loop (7) to accessory box lid.
- (2) Position new footmans loop (7) on accessory box (3) and install with two screws (4) two washers (5), and two self-locking nuts (6).



4874-032

Figure 5-3. Accessory Box Repair.

5-6. Marking. (See figure 5-4.) The power unit four-digit registration number, preceded by the prefix "VC" and the words "U.S. ARMY," is marked in three places on the trailer. Marking is done in accordance with MIL-STD-642. On the fender, over each wheel, "T.P. 35 PSI" is marked in 1.00±.12 inch high characters in accordance with MIL-STD-130. Figure 5-4 shows the approximate location of markings on the power unit. If required, touch-up painting of the base color is done in accordance with MIL-T-704 and MIL-C-46168.



4874-033

Figure 5-4. Power Unit Markings.

Section III. GENERATOR SET

5-7. Generator set Replacement. (See figures 5-5 and 5-6).


a. Removal.

- (1) Remove fitted cover (paragraph 3-11, a.(1)).
- (2) Remove tarpaulin support and four bow assemblies (paragraph 3-11, b.(1)).
- (3) Disconnect ground wire (1, figure 5-5) from generator set (2) to GROUND TERMINAL stud (3) on trailer bed (4).

NOTE

The washers (6) may have been welded in place.

- (4) Remove four cap screws (5), eight flat washers (6), and four nuts (7) securing generator set (2), to trailer (4).
- (5) Remove engine oil drain hose (8) from grommet in trailer bed.



4874-034

Figure 5-5. Detaching Generator Set from Trailer.

WARNING

When lifting generator set, use lifting equipment with a minimum lifting capacity of 1500 lb. Do not stand under generator while it is being lifted. Failure to observe these precautions can cause injury to personnel or damage to equipment.

- (6) Attach lifting equipment with a minimum lifting capacity of 1500 lb (1, figure 5-6) to lifting eye (2) on top of generator set (3) and remove generator set from trailer.

b. Installation.

WARNING

When lifting generator set, use lifting equipment with a minimum lifting capacity of 1500 lb. Do not stand under generator while it is being lifted. Failure to observe these precautions can cause injury to personnel or damage to equipment.




Figure 5-6. Lifting Generator Set.

- (1) Attach lifting equipment with a minimum lifting capacity of 1500 lb (1, figure 5-6) to lifting eye (2) on top of generator set (3) and lift generator.
- (2) Lower generator set (2, figure 5-5) onto trailer bed (4) and align mounting holes.

- (3) Insert four cap screws (5) with flat washers (6) down through generator set skid and trailer bed (4).
- (4) Working under trailer, install one flat washer (6) and one nut (7) on each bolt (5). Tighten hardware.
- (5) Insert engine oil drain hose (8) through grommet in trailer bed.
- (6) Install tarpaulin support and four bows assemblies (paragraph 3-11, b.(2)).
- (7) Install fitted cover (paragraph 3-11, a.(2)).

CHAPTER 6

TEST AND INSPECTION AFTER REPAIR

Section I. GENERAL REQUIREMENTS

6-1. General Requirements. The activity performing the repair is responsible for the performance of all applicable tests and inspections specified in the technical manuals referenced below. Activities performing maintenance on any component of the power unit must perform those tests and inspections required by the applicable component or system repair instruction.

Section II. INSPECTION

6-2. Generator Set Inspections. Refer to TM 5-6115-584-12 and -34 for inspections required following repair of the generator set.

6-3. Trailer Inspections. Refer to TM 9-2330-202-14&P for inspections required following repair of the trailer.

Section III. OPERATIONAL TESTS

6-4. Generator Set Operational Tests. Refer to TM 5-6115-584-12 and -34 for operational tests required to verify satisfactory performance of the generator set.

6-5. Trailer Operational Tests. Refer to TM 9-2330-202-14&P for operational tests required to verify satisfactory performance of the trailer.

APPENDIX A

REFERENCES

A-1. **Scope.** This appendix lists all pamphlets, forms, technical manuals, specifications and miscellaneous publications referenced in this manual.

A-2. Forms and Records.

Recommended Changes to Publications and Blank Forms	DA Form 2028
Depreservation Guide for Vehicles and Equipment	DA Form 2258
Equipment Inspection and Maintenance Worksheet	DA Form 2404
Maintenance Request	DA Form 2407
Consolidated Index of Army Publications	DA PAM 25-30
The Army Maintenance Management System (TAMMS)	DA PAM 738-750
Product Quality Deficiency Report	SF368

A-3. Military Specifications.

Chemical Agent Resistant Aliphatic Polyurethane Coating	MIL-C-46168
Identification Marking of U.S. Military Property	MIL-STD-130
Identification Marking of Combat and Tactical Transport	MIL-STD-642
Treatment and Painting of Materiel.	MIL-T-704

A-4. Technical Manuals.

Fabric Repairing, Tents, Canvas, Webbing	FM10-16
Operator and Organizational Maintenance Manual for Generator Set, Diesel Engine Driven, Tactical Skid Mounted, 5KW, 1 Phase, 2 Wire; 1 Phase, 3 Wire and 3 Phase, 4 Wire; 120, 120/240 and 120/208V (DOD Model MEP-002A) Utility Class 60HZ(6115-00-465-1044)	TM5-6115-584-12
Organizational, Intermediate (Field) Direct and General Support and Depot Level Maintenance Repair Parts and Special Tools List: Generator Set, Diesel Engine Driven, Tactical Skid Mounted, 5 KW, 1 Phase, 2 Wire; 1 Phase, 3 Wire; 3 Phase, 4 Wire, 120, 120/240 and 120/208 V (DOD Model MEP-002A) Utility Class, 60 HZ (NSN 6115-00-465-1044)	TM5-6115-584-24P
Intermediate (Field) (Direct and General Support) and Depot Level Maintenance Manual for Generator Set, Diesel Engine Driven, Tactical Skid Mounted, 5 KW, 1 Phase, 2 Wire; 1 Phase, 3 Wire; 3 Phase, 4 Wire, 120, 120/240 and 120/208 V (DOD Model MEP-002A), Utility Class, 60 HZ (NSN 6115-00-465-1044)	TM 5-6115-584-34
Procedures for Destruction of Equipment to Prevent Enemy Use (Mobility Equipment Command)	TM 750-244-3
Operator's, Organizational, Direct Support and General Support Maintenance Manual Including Repair Parts and Special Tools List for Trailer, Cargo: 3/4-Ton, 2-Wheel, M101 (NSN 2330-00-738-9509), M101A1 (2330-00-898-6779), M101A2 (2330-01-101-4697) and Chassis, Trailer: 3/4-Ton, 2-Wheel, M116 (2330-00-542-5987), M116A1 (2330-00-898-6780) and M116A2 (2330-01-101-8434)	TM9-2330-202-14&P

TM 5-6115-630-14&P

Organizational, Direct Support, and General Support Care Maintenance
and Repair of Pneumatic Tires and Inner Tubes TM 9-2610-200-24

A-5. Technical Bulletins.

Preservation of USAMECOM Mechanical Equipment for Shipment and Storage TB 740-97-2

APPENDIX B

COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS

Section I. INTRODUCTION

B-1. **Scope.** This appendix lists components of end item and basic issue items for the power unit to help you inventory items required for safe and efficient operation.

B-2. **General.** The Components of End Item and Basic Issue Items Lists are divided into the following sections.

a. Section II. Components of End Item. This listing is for informational purposes only, and is not authority to requisition replacements. These items are part of the end item, but are removed and separately packaged for transportation or shipment. As part of the end item, these items must be with the end item whenever it is issued or transferred between property accounts. Illustrations are furnished to assist you in identifying the items.

b. Section III. Basic Issue Items. These are the minimum essential items required to place the power unit in operation, to operate it, and to perform emergency repairs. Although shipped separately packaged, BII must be with the power unit during operation and whenever it is transferred between property accounts. The illustrations will assist you with hard-to-identify items. This manual is your authority to request/requisition BII, based on TOE/MTOE authorization of the end item.

B-3. **Explanation Of Columns.** The following provides an explanation of columns found in the tabular listings:

a. Column (1). Illustration Number (Illus No.). This column indicates the number assigned to the item.


b. Column (2). National Stock Number. Indicates the National stock number assigned to the item.

c. Column (3). Description. Indicates the federal item name and, if required, a minimum description to identify and locate the item. The last line for each item indicates the FSCM (in parentheses) followed by the part number. If item needed differed for different models of this equipment, the model would be shown under the "Usable on Code" heading in this column. The Usable on Code is not applicable for this equipment.

d. Column (4). Unit of Measure (U/M). Indicates the measure used in performing the actual operational/maintenance function. This measure is expressed by a two-character alphabetical abbreviation (eg, ea, in, pr).

e. Column (5). Quantity Required (Qty Req'd). Indicates the quantity of the item authorized to be used with/on the equipment.


Section II. COMPONENTS OF END ITEM



4874-036-1

(1) Illus no.	(2) National stock number	(3) Description FSCM and part number	Usable on code	(4) U/M	(5) Qty req'd
1	5120-00-243-2957	Hammer, Hand, Engineers 8 lb. (3.6 kg) (81348) GGG-H-86		ea	1
2	5975-00-878-3791	Rod, Ground, Driven, Sectional 9 ft (2.7 m) (81349) MIL-R-11461		ea	2
3	5120-01-013-1676	Hammer, Slide (97403) 13226E7741		ea	1

Section III. BASIC ISSUE ITEMS



4874-036-2

(1) Illus no.	(2) National stock number	(3) Description FSCM and part number	(4) Usable on code	(5) Qty req'd
1	4210-00-270-4512	Extinguisher, Fire, 5 lbs (2.03 kg) O-E-910	ea	1
2		Manual, Technical TM 5-6115-630-14&P	ea	1

Change 4 B-3/(B-4 blank)

A P P E N D I X C

MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

C-1. General.

a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance levels.

b. Section II designates overall responsibility for the performance of maintenance functions on the identified end item or component. The implementation of the maintenance functions upon the end item or component will be consistent with the assigned maintenance functions.

c. Section III lists the tools and test equipment required for each maintenance function as referenced from Section II.

d. Section IV contains supplemental instructions, explanatory notes and/or illustrations required for a particular maintenance function.

C-2. Explanation of Columns in Section II.

a. Group Number, Column 1. The assembly group is a numerical group assigned to each assembly in a top down breakdown sequence. The applicable assembly groups are listed on the MAC in disassembly sequence beginning with the first assembly removed in a top down disassembly sequence.

b. Assembly Group, Column 2. This column contains a brief description of the components of each assembly group.

c. Maintenance Functions, Column 3. This column lists the various maintenance functions (A through K) and indicates the lowest maintenance category authorized to perform these functions. The symbol designations for the various maintenance categories are as follows:

- C – Operator or crew
- O – Unit maintenance
- F - Direct support maintenance
- H – General support maintenance
- D – Depot maintenance

The maintenance functions are defined as follows:

A - Inspect. To determine serviceability of an item by comparing its physical, mechanical, and electrical characteristics with established standards.

B - Test. To verify serviceability and to detect electrical or mechanical failure by use of test equipment.

C – Service. To clean, to preserve, to charge, and to add fuel, lubricants, cooling agents, and air. If it is desired that elements, such as painting and lubricating, be defined separately, they may be so listed.

D - Adjust. To rectify to the extent necessary to bring into proper operating range.

E - Align. To adjust specified variable elements of an item to bring to optimum performance.

F – Calibrate. To determine the corrections to be made in the readings of instruments or test equipment used in precise measurement. Consists of the comparison of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared with the certified standard.

G - Install. To setup for use in an operational environment such as emplacement, site, or vehicle.

H - Replace. To replace unserviceable items with serviceable like items.

I - Repair. Those maintenance operations necessary to restore an item to serviceable condition through correction of material damage to a specific failure. Repair may be accomplished at each category of maintenance.

J - Overhaul. Normally, the highest degree of maintenance performed by the Army in order to minimize time work in process is consistent with quality and economy of operation. It consists of that maintenance necessary to restore an item to completely serviceable condition as prescribed by maintenance standard in technical publications for each item of equipment. Overhaul normally does not return an item to like new, zero mileage, or zero hour condition.

K - Rebuild. The highest degree of material maintenance. It consists of restoring equipment as nearly as possible to new conditions in accordance with original manufacturing standards. Rebuild is performed only when required by operational considerations or other paramount factors and then only at the depot maintenance category. Rebuild reduces to zero the hours or miles of the equipment, or component thereof, has been in use.

d. Symbols. The uppercase letter placed in the appropriate column indicates the lowest level at which that particular maintenance function is to be performed.

e. Tools and Equipment, Column 4. This column is provided for referencing by code, the special tools and test equipment, (Section III) required to perform the maintenance functions (Section II).

f. Remarks, Column 5. This column is provided for referencing by code, the remarks (Section IV) pertinent to the maintenance functions.

C-3. Explanation of Columns in Section III. Section III, Tools, Test, and Support Equipment Requirements is not applicable.

C-4. Explanation of Columns in Section IV. Section IV, Remarks, is not applicable.

Section II. MAINTENANCE ALLOCATION CHART

(1) Group no.	(2) Assembly group	(3) Maintenance functions											(4) Tools and equipment	(5) Remarks			
		A	B	C	D	E	F	G	H	I	J	K					
		Inspect	Test	Service	Adjust	Align	Calibrate	Install	Replace	Repair	Overhaul	Rebuild					
01	ENCLOSURE																
	Fitted Cover	C 0.1							C 0.5	F 1.0							
	Bows	C 0.1							C 0.1								
02	GENERATOR SET	C 0.2		C 2.0						F 3.0							See TM 5-6115-584-12, -34 for generator maintenance.
03	ACCESSORIES																
	Sledge Hammer	C 0.1							C 0.1								
	Fire Extinguisher	C 0.1							C 0.1								
	Slide Hammer	C 0.1							C 0.1								
	Ground Rods	C 0.1							C 0.1								
04	TRAILER ASSEMBLY																See TM 9-2330-202-14&P for trailer maintenance.
	Accessory Box								O 0.5	F 2.0							
	Fuel Can/Fire Extinguisher Brackets	C 0.1							O 0.5								
	Bed/Fenders								F 4.0	F 4.0							
	Reflectors	C 0.1							O 0.5								
	Data Plates								F 0.2								
	Leg Prop Assembly	C 0.1		O 0.2					F 0.5	F 0.7							
	Lighting	C 0.1	O 0.3						O 1.0	O 0.5							
	Handbrake	C 0.1															

APPENDIX D

UNIT, DIRECT SUPPORT AND GENERAL SUPPORT AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

Section I. INTRODUCTION

D-1. **Scope.** This Army manual lists repair parts and special tools required for the performance of unit, direct and general support and depot maintenance of the power unit. The following paragraphs are keyed to applicable users. All users should read paragraph D-4, Special Information, prior to using this manual.

D-2. **General.** The Repair Parts and Special Tools List is divided into the following sections:

a. Repair Parts - Section II. A list of repair parts authorized for the performance of maintenance at the unit, intermediate (field) (direct and general support) and depot level in figure and item number sequence.

b. Special Tools. Test and Support Equipment - Section III. A list of special tools, test and support equipment authorized for the performance of maintenance at the unit, direct and general support and depot level.

c. National Stock Number and Reference Number Index - Section IV. A list of National stock numbers in numerical sequence, followed by a list of reference numbers appearing in all the listings, in alphanumeric sequence, cross-referenced to the illustration figure number and item number.

d. Reference Designator Index - Section V. The reference Designator Column includes all assigned reference designators arranged first in alphabetical order, second in numerical order. Opposite each symbol is listed the figure and item number of the part in Section II and the reference number.

D-3. **Explanation Of Columns.** The following provides an explanation of columns in the tabular lists in Sections II and III.

a. Illustrations. (Column 1). This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* Indicates the number used to identify the item on the illustration.

b. Source, Maintenance, and Recoverability Codes (SMR), (Column 2).

(1) *Uniform source codes applicable to all military services.*

GENERAL: Source Codes are assigned to support items to indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentially dictates that a minimum quantity be available in the supply systems.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfittings to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at unit or direct support/general support levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at unit level.

Code	Definition
MF	Item to be manufactured or fabricated at general support maintenance levels.
MD	Item to be manufactured or fabricated at depot maintenance level.
AO	Item to be assembled at unit level.
AF	Item to be assembled at direct support maintenance levels.
AH	Item to be assembled at general support maintenance levels.
AD	Item to be assembled at depot maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.
XC	Installation drawings, diagram, instruction sheet, field service drawing, that is identified by manufacturers part number.
XD	A support item that is not stocked. When required, item will be procured through normal supply channels.

(2) *Uniform maintenance codes applicable to all military services:* GENERAL: Maintenance Codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The Maintenance Codes are in the third and fourth position of the Uniform SMR Code Format.

(a) *Use (third position):* The Maintenance Code entered in the third position indicates the lowest level maintenance level authorized to remove, replace, and use the support item. The Maintenance Code entered in the third position indicates one of the following levels of maintenance.

Code	Application/Explanation
O	Support item is removed, replaced, used at the unit level of maintenance
F	Support item is removed, replaced, used at direct support level.
H	Support item is removed, replaced, used at the general support level.

Code	Definition
	Support items that are removed, replaced, used at Depot only: Depot, Mobile Depot and Specialized Repair Activity.

(b) *Repair (fourth position):* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions).

Code	Application/Explanation
O	The lowest maintenance level capable of complete repair of the support item is the unit level.
F	The lowest maintenance level capable of complete repair of the support item is direct support.
H	The lowest maintenance level capable of complete repair of the support item is general support.

Code	Definition
D	The lowest maintenance level capable of complete repair of the support item is the depot level: Depot, Mobile Depot, and Specialized Repair Activity.

Code	Application/Explanation
L	Repair restricted to designated Specialized Repair Activity.
Z	Nonreparable. No repair is authorized.
B	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Uniform recoverability codes applicable to all military services:* GENERAL: Recoverability Codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows:

Recoverability Codes	Definition
Z	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in column 3.
O	Reparable item. When uneconomically repairable, condemn and dispose at unit level.
F	Reparable item. When uneconomically repairable, condemn and dispose at direct support.
H	Reparable item. When uneconomically repairable, condemn and dispose at general support level.

Recoverability Codes	Definition
D	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L	Reparable item. Repair, condemnation and disposal not authorized below depot/Specialized Repair Activity level.
A	Item requires special handling or condemnation procedure because of specific reasons (i.e., precious metal content, high-dollar value, critical material or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. National Stock Number (Column 4). Indicates the National Stock Number assigned to the item and will be used for requisitioning purposes.

d. Description (Column 5). Indicates the Federal item name and any additional descriptions of the item required. The abbreviation "w/e" when used as a part of the nomenclature, indicates that the National Stock Number includes all armament, equipment, accessories and repair parts issued with the item. A part number or other reference number is followed by the applicable five digit Federal Supply Code for Manufacturer in parentheses. If two reference numbers and Federal Supply Codes for Manufacturer are listed, the first listing refers to the Department of Defense Drawing Number, the second listing refers to the actual part manufacturer. Items that are included in kits and sets are listed below the name of the kit or set with the quantity of each item in the kit or set indicated in the quantity incorporated in unit column.

e. Unit of Measure (U/M) (Column 6). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr. etc.). When the unit of measure differs from the unit issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

f. Quantity Incorporated in Unit (Column 7). Indicates the quantity of the item used in the assembly group. A "V" appearing in this column in lieu of a quantity indicates that a definite quantity cannot be indicated (e.g., shims, spacers, etc.).

D-4. **Special Information.**

a. Identification of Usable On Codes for this Manual is not applicable.

b. Army unit maintenance personnel will extract the items which they require from Section II, 3rd or 4th position of column 2 of the intermediate direct and general support RPSTL. Parts which are manufactured or assembled at a higher level than that authorized to install the part are indicated by the use of higher level code in the source column.

c. Stockage Information. Army stockage is demand based in accordance with AR 710-2. Repair pads listed in this publication represent those authorized for use at indicated maintenance levels and will be requisitioned on an as-required basis until stockage is justified in accordance with AR 710-2.

d. In the parts list, some items are indented to show that they are a component of the item under which they are indented.

D-5. How to Locate Repair Parts.

a. When National Stock Number or Reference Number is Unknown:

- (1) Using the table of contents, determine the functional group; i.e., batteries and related parts, exhaust and breather pipes, within which the repair part belongs. This is necessary since illustrations are prepared for functional groups.
- (2) Find the illustration covering the functional group to which the repair part belongs.
- (3) Identify the repair part on the illustration and note the illustration figure and item number of the repair part.
- (4) Using the Repair Part Listing, find the figure and item number on the illustration.

b. When National Stock Number or Reference Number is known:

- (1) Using the Index of National Stock Numbers and Reference Numbers, find the pertinent national stock number or reference number. This index is in ascending NSN sequence followed by a list of reference numbers in alphanumeric sequence, cross-referenced to the illustration figure number and item number.
- (2) After finding the figure and item number, locate the figure and item number in the repair parts list.

D-6. Abbreviations.


Not Applicable

D-7. Federal Supply Codes for Manufacturers.

Not Applicable

D-8. Recommendation for Maintenance Publication Improvements. Report of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted as follows: Army DA Form 2028, directly to: Commander, US Army Aviation and Troop Command, ATTN: AMSAT-I-MT, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798.

1
2 THRU 9



4874-037

Figure D-1. Enclosure.

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		NATIONAL STOCK NUMBER	(4) DESCRIPTION		(5)	(6)	(7)
a FIG NO.	b ITEM NO.	a ARMY	b AIR FORCE	c NAVY	e USMC	a SSI	b REPL FACTOR		REF NUMBER & MFR CODE	USABLE ON CODE	U/M	QTY INC IN UNIT	USMC QTY PER EQUIP
									Group 01 - ENCLOSURE				
D-1	1	PAOFF						2540-00-926-0993	FITTED COVER 13214E1219	97403	EA	1	
D-1	2	PAOZZ							.ROPE, SISAL T-R-605B	81394	EA	27	
D-1	3	PAFZZ						5325-01-875-3182	.GROMMET METALLIC MIL-G-16491	81349	EA	27	
D-1	4	PAFZZ						5340-00-078-7029	.CLIP, END STRAP MS51926-3	96906	EA	20	
D-1	5	PAFZZ						5340-00-057-6956	.BUCKLE, SPRING ACTION MS51929-2	96906	EA	8	
D-1	6	MFFFF							.CHAFE ASSEMBLY 13214E1392	97403	EA	12	
D-1	7	PAFZZ						5340-00-057-6956	.BUCKLE, SPRING ACTION MS51929-9	96906	EA	12	
D-1	8	PAFZZ						5365-01-031-9674	.RING, DEE MS51925-1	97403	EA	14	
D-1	9	XBFZZ							.HOOK, TEE 13226E0953		EA	22	
D-1	10	XBOZZ						2510-01-198-2885	SUPPORT TARPULIN 13221E4799	97403	EA	1	
D-1	11	PAOZZ						5305-00-984-6215	SCREW, MACHINE MS35206-268	96906	EA	4	
D-1	12	PAOZZ						5310-00-014-5859	WASHER, FLAT MS27183-42	96906	EA	8	
D-1	13	PAOZZ						5310-00-933-8121	LOCKWASHER MS35338-139	96906	EA	4	
D-1	14	PAOZZ						5310-00-515-9267	NUT, PLAIN, WING MS35425-37	96906	EA	4	
D-1	15	PAOZZ						2540-00-926-0994	BOW, VEHICULAR, TOP 13214E1218	97403	EA	4	





Figure D-2. Generator Set:

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		NATIONAL STOCK NUMBER	(4) DESCRIPTION		(5)	(6)	(7)
a FIG NO.	b ITEM NO.	a ARMY	b AIR FORCE	c NAVY	e USMC	a SSI	b REPL FACTOR		REF NUMBER & MFR CODE	USABLE ON CODE	U/M	QTY INC IN UNIT	USMC QTY PER EQUIP
D-2	1	PDFHZ						6115-00-465-1044	Group 02 - GENERATOR GENERATOR SET DIESEL MEP-002A	30554	EA	1	
D-2	2	PAOZZ						5305-00-719-5235	SCREW, CAP, HEX MS90727-114	96906	EA	4	
D-2	3	PAOZZ						5310-00-809-5998	WASHER, FLAT MS27183-18	96906	EA	8	
D-2	4	PAOZZ						5310-00-067-9507	NUT, SELF-LOCKING MS51922-37	96906	EA	4	




4874-039

Figure D-3. Trailer Body.

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		NATIONAL STOCK NUMBER	(4) DESCRIPTION		(5)	(6)	(7)
a FIG NO.	b ITEM NO.	a ARMY	b AIR FORCE	c NAVY	e USMC	a SSI	b REPL FACTOR		REF NUMBER & MFR CODE	USABLE ON CODE	U/M	QTY INC IN UNIT	USMC QTY PER EQUIP
D-3	1	XBOZZ							Group 04 - TRAILER 04--Body				
D-3	2	PAOZZ						5305-00-269-3213	BRACKET ASSEMBLY, LIQUID CONTAINER MS53052-1 96906	EA	4		
D-3	3	PAOZZ						5310-00-080-6004	SCREW, CAP, HEX MS90725-62 96906	EA	16		
D-3	4	PAOZZ						5310-00-087-4652	WASHER, FLAT MS27183-14 96906	EA	32		
D-3	5	PAOZZ						4210-00-223-4857	NUT, SELF-LOCKING MS51922-17 96906	EA	16		
D-3	6	PAOZZ						5305-00-068-0502	BRACKET ASSEMBLY, FIRE EXTINGUISHER 13214E1235 97403	EA	1		
D-3	7	PAOZZ						5305-00-068-0502	SCREW, CAR HEX MS90725-6 96906	EA	4		
D-3	8	PAOZZ						5310-00-809-4058	WASHER, FLAT MS27183-10 96906	EA	20		
D-3	9	PAOZZ						5310-00-088-1251	NUT, SELF-LOCKING MS51922-1 96906	EA	16		
D-3	10	PAOZZ						9905-00-205-2795	REFLECTOR MS35387-1 96906	EA	4		
D-3	11	PAOZZ						9905-00-202-3639	REFLECTOR MS35387-2 96906	EA	2		
D-3	12	MDFZZ						5305-00-068-0500	SCREW, CAP HEX MS90725-3 96906	EA	12		
D-3	13	MDFZZ						9906-01-085-7703	PLATE, IDENTIFICATION 13205E4918 97403	EA	1		
D-3	14	PAOZZ						5305-00-253-5614	PLATE, IDENTIFICATION 13216E7604-43 97403	EA	1		
D-3	15	PAOZZ						5340-00-229-0340	SCREW, DRIVE MS21318-20 96906	EA	4		
D-3	16	PAOZZ						5303-00-957-7086	LOOP, STRAP FASTENER MS51939-3 96906	EA	2		
D-3	17	PAOZZ						5310-00-014-5850	SCREW, MACHINE MS24893-S273 96906	EA	4		
D-3	18	PAOZZ						5310-00-877-5797	WASHER, FLAT MS27183-42 96906	EA	8		
D-3	19	PAOZZ						5310-00-877-5797	NUT, SELF-LOCKING MS21044N3 96906	EA	2		
D-3	20	PAOZZ						5305-0-989-7435	CLAMP LOOP MS21333-68 96906	EA	2		
D-3	21	PAOZZ						5307-00-227-1741	SCREW, MACHINE MS35207-264 96906	EA	2		
									STUD 13214E1223 97403	EA	1		

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		NATIONAL STOCK NUMBER	(4) DESCRIPTION		(5) U/M	(6) QTY INC IN UNIT	(7) USMC QTY PER EQUIP
a FIG NO.	b ITEM NO.	a ARMY	b AIR FORCE	c NAVY	e USMC	a SSI	b REPL FACTOR		REF NUMBER & MFR CODE	USABLE ON CODE			
									04 - Body (cont)				
D-3	22	PAOZZ						5310-01-026-5824	NUT, PLAIN MS16203-39	96906	EA	3	
D-3	23	PAOZZ						5310-00-913-9776	LOCKWASHER MS35335-91	95905	EA	2	
D-3	24	PAOZZ						5310-00-187-2413	WASHER, FLAT AN961-616T	88044	EA	4	
D-3	25	PAOZZ						5310-00-543-4717	NUT, PLAIN, WING MS35425-28	96906	EA	1	
D-3	26	PAOZZ						4730-00-908-3194	CLAMP, HOSE MS353842-11	96906	EA	1	
D-3	27	MOOOO						4720-01-260-2572	HOSE, RUBBER MIL-H-6000	81349	EA	1	
D-3	28	PAOZZ						5325-00-903-5909	GROMMET MS35489-112	96906	EA	1	
D-3	29	PAOZZ						4730-00-809-9703	ELBOW MS24519-9	96906	EA	1	
D-3	30	XAFFF							BODY, TRAILER (FENDERS AND BED) 13221E7326	97403	EA	1	
D-3	31	PAOZZ						5340-00-087-5269	.PIN, QUICK RELEASE MS17990-C613	96906	EA	8	
D-3	32	PAOZZ						4010-00-188-9011	.CHAIN, WELDLESS RR-C-271	81348	EA	8	
D-3	33	MOOOO							.WIRE, GROUND 13221E7329	97403	EA	2	
D-3	34	PAOZZ						6145-00-578-6594	.WIRE, ELECTRICAL M5086/2-6-9	81349	FT	5	
D-3	35	PAOZZ						5940-00-115-4992	.TERMINAL LUG MS20659-110	96906	EA	1	
D-3	38	PAOZZ						5305-00-269-3211	SCREW, CAP, HEX MS90725-60	96906	EA	26	
D-3	37	PAOZZ						5310-00-080-6004	WASHER, FLAT MS27183-14	96906	EA	26	
D-3	38	PAOZZ						5310-00-087-4652	NUT, SELF-LOCKING MS51922-17	96906	EA	26	

1
2 THRU 9



4874-040

Figure D-4. Accessory Box.

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		NATIONAL STOCK NUMBER	(4) DESCRIPTION		(5)	(6)	(7)
a FIG NO.	b ITEM NO.	a ARMY	b AIR FORCE	c NAVY	e USMC	a SSI	b REPL FACTOR		REF NUMBER & MFR CODE	USABLE ON CODE	U/M	QTY INC IN UNIT	USMC QTY PER EQUIP
D-4	1	XDOFF						6115-01-230-0677	04 - Accessory Box BOX, ACCESSORY 13226E7737	97403	EA	1	
D-4	2	PAOZZ						5340-00-229-0340	.LOOP, STRAP FASTENER MS51939-3	96906	EA	2	
D-4	3	PAOZZ						5305-00-957-7086	.SCREW, MACHINE MS24693-S273	96906	EA	4	
D-4	4	PAOZZ						5310-00-014-5850	.WASHER, FLAT MS27183-42	96906	EA	4	
D-4	5	PAOZZ						5310-00-059-9263	.NUT, SELF-LOCKING MS21046C3	96906	EA	4	
D-4	6	PAOZZ						5340-00-234-8422	.HASP, HINGED MS27969-4	96906	EA	1	
D-4	7	PAOZZ						5310-01-18-3097	.RIVET, SOLID MS9460-102	96906	EA	8	
D-4	8	PAOZZ						5340-00-975-2126	.CATCH, CLAMPING AND STRIKE MS18015-1	96906	EA	2	
D-4	9	PAOZZ						5320-00-753-3830	.RIVET, SOLID MS20613-4P5	96906	EA	8	
D-4	10	PAOZZ						5306-00-225-8496	BOLT, MACHINE MS90725-31	96906	EA	4	
D-4	11	PAOZZ						5310-00-407-9566	LOCKWASHER MS353385	96906	EA	4	
D-4	12	PAOZZ						5310-00-880-7744	NUT, PLAIN, HEX MS51967-5	96906	EA	4	
D-4	13	MFFFF							STRAP ASSEMBLY 13220E5288-2	97403	EA	2	




Figure D-5. Leg Assembly.

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		NATIONAL STOCK NUMBER	(4) DESCRIPTION		(5)	(6)	(7)
a FIG NO.	b ITEM NO.	a ARMY	b AIR FORCE	c NAVY	e USMC	a SSI	b REPL FACTOR		REF NUMBER & MFR CODE	USABLE ON CODE	U/M	QTY INC IN UNIT	USMC QTY PER EQUIP
D-5	1	XBFFF						2950-00-420-8929	04 - Frame LEG PROP ASSEMBLY 13214E1206	97403	EA	1	
D-5	2	PAOZZ						5315-00-839-5822	.PIN, COTTER MS2465-353	96906	EA	2	
D-5	3	XBOFF						5315-01-162-0143	.SHAFT 13214E1209	97403	EA	1	
D-5	4	XBOFF						6115-01-220-1548	.BRACKET 13214E1207	97403	EA	1	
D-5	5	XBOFF						2590-00-453-8977	.LEG, UPPER 13214E1208-1	97403	EA	1	
D-5	6	PAOZZ						4730-00-172-0049	.FITTING, LUBRICATION MS15006-1	96906	EA	1	
D-5	7	PAOZZ						5315-00-838-4584	.PIN, SPRING MS16562-66	96906	EA	1	
D-5	8	XBOFF						5315-01-158-2144	.SCREW 13214E1210	97403	EA	1	
D-5	9	XBOZZ						5310-01-149-0869	.NUT 13214E1211	97403	EA	1	
D-5	10	XBOZZ						2590-01-167-8596	.BASE, LEG 13214E1212-1	97403	EA	1	
D-5	11	PAOZZ						5305-00-269-3213	SCREW, CAP, HEX MS90725-62	96906	EA	3	
D-5	12	PAOZZ						5310-00-080-8004	WASHER, FLAT MS27183-14	96906	EA	3	
D-5	13	PAOZZ						5310-00-087-4652	NUT, SELF-LOCKING MS51922-17	96890	EA	3	

SECTION III. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT

NOT APPLICABLE

SECTION IV. NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX

NSN	FIGURE NO.	ITEM NO.	NSN	FIGURE NO.	ITEM NO.
2510-01-198-2885	D-1	10	5310-00-187-2413	D-3	24
2540-00-926-0993	D-1	1	5310-00-407-9566	D-4	11
2540-00-926-0994	D-1	15	5310-00-515-9267	D-1	14
2590-00-420-8929	D-5	1	5310-00-543-4717	D-3	25
2590-00-453-8977	D-5	5	5310-00-806-4058	D-3	7
2590-00-167-8596	D-5	10	5310-00-809-5998	D-2	3
4010-00-188-9011	D-3	32	5310-00-877-5797	D-3	18
4210-00-223-4857	D-3	5	5310-00-880-7744	D-4	12
4720-01-260-2572	D-3	27	5310-00-913-9776	D-3	23
4730-00-172-0049	D-5	6	5310-00-933-8121	D-1	13
4730-00-809-9703	D-3	29	5310-01-149-0869	D-5	9
4730-00-908-3194	D-3	26	5310-01-026-5824	D-3	22
5305-00-068-0500	D-3	11	5315-00-838-4584	D-5	7
5305-00-068-0502	D-3	6	5315-00-839-5822	D-5	2
5305-00-253-5614	D-3	14	5315-01-158-2144	D-5	8
5305-00-269-3211	D-3	36	5315-01-162-0143	D-5	3
5305-00-269-3213	D-3	2	5320-00-753-3830	D-4	9
5305-00-269-3213	D-5	11	5320-01-168-3097	D-4	7
5305-00-719-5235	D-2	2	5325-00-903-5909	D-3	28
5305-00-957-7086	D-3	16	5325-01-875-3182	D-1	3
5305-00-957-7086	D-4	3	5340-00-057-6956	D-1	5
5305-00-984-6215	D-1	11	5340-00-057-6956	D-1	7
5305-00-989-7435	D-3	20	5340-00-078-7029	D-1	4
5306-00-225-8496	D-4	10	5340-00-087-5269	D-3	31
5307-00-227-1741	D-3	21	5340-00-229-0340	D-3	15
5310-00-014-5850	D-1	12	5340-00-229-0340	D-4	2
5310-00-014-5850	D-3	17	5340-00-234-8422	D-4	6
5310-00-014-5850	D-4	4	5340-00-975-2126	D-4	8
5310-00-059-9263	D-4	5	5365-01-031-9674	D-1	8
5310-00-067-9507	D-2	4	5940-00-115-4992	D-3	35
5310-00-080-6004	D-3	3	6115-00-465-1044	D-2	1
5310-00-080-6004	D-3	37	6115-01-220-1548	D-5	4
5310-00-080-6004	D-5	12	6115-01-230-0677	D-4	1
5310-00-087-4652	D-3	4	6145-00-578-6594	D-3	34
5310-00-087-4652	D-3	38	9905-00-202-3639	D-3	10
5310-00-087-4652	D-5	13	9905-00-205-2795	D-3	9
5310-00-088-1251	D-3	8	9905-01-085-7703	D-3	12

SECTION IV. NATIONAL STOCK NUMBER AND REFERENCE NUMBER INDEX (CONT)

REFERENCE NUMBER	FSCM	FIG. NO.	ITEM NO.	REFERENCE NUMBER	FSCM	FIG. NO.	ITEM NO.
AN961-616T	88044	D-3	24	MS51922-17	96906	D-5	13
MEP-002A	30554	D-2	1	MS51922-37	96906	D-2	4
MIL-G-16491	81349	D-1	3	MS51925-1	96906	D-1	8
MIL-H-6000	81349	D-3	27	MS51926-3	96906	D-1	4
MS15006-1	96906	D-5	6	MS51929-2	96906	D-1	5
MS16203-39	96906	D-3	22	MS51929-2	96906	D-1	7
MS16562-66	96906	D-5	7	MS51939-3	96906	D-3	15
MS17990-C613	96906	D-3	31	MS51939-3	96906	D-4	2
MS18015-1	96906	D-4	8	MS51967-5	96906	D-4	12
MS20613-4P5	96906	D-4	9	MS53052-1	96906	D-3	1
MS20659-110	96906	D-3	35	MS90725-3	96906	D-3	11
MS21044N3	96906	D-3	18	MS90725-31	96906	D-4	10
MS21046C3	96906	D-4	5	MS90725-6	96906	D-3	6
MS21318-20	96906	D-3	14	MS90725-60	96906	D-3	36
MS21333-68	96906	D-3	19	MS90725-62	96906	D-3	2
MS24519-9	96906	D-3	29	MS90725-62	96906	D-5	11
MS24665-353	96906	D-5	2	MS90727-114	96906	D-2	2
MS24693-S273	96906	D-3	16	MS9460-102	96906	D-4	7
MS24693-S273	96906	D-4	3	M5086/2-6-9	81349	D-3	34
MS27183-10	96906	D-3	7	RR-C-271	81348	D-3	32
MS27183-14	96906	D-3	3	T-R-605B	81348	D-1	2
MS27183-14	96906	D-3	37	13205E4918	97403	D-3	12
MS27183-14	96906	D-5	12	13214E1206	97403	D-5	1
MS27183-18	96906	D-2	3	13214E1207	97403	D-5	4
MS27183-42	96906	D-1	12	13214E1208	97403	D-5	5
MS27183-42	96906	D-3	17	13214E1209	97403	D-5	3
MS27183-42	96906	D-4	4	13214E1210	97403	D-5	8
MS27969-4	96906	D-4	6	13214E1211	97403	D-5	9
MS35206-268	96906	D-1	11	13214E1212	97403	D-5	10
MS35207-264	96906	D-3	20	13214E1218	97403	D-1	15
MS35335-91	96906	D-3	23	13214E1219	97403	D-1	1
MS35338-45	96906	D-4	11	13214E1223	97403	D-3	21
MS35338-139	96906	D-1	13	13214E1235	97403	D-3	5
MS35387-1	96906	D-3	9	13214E1392	97403	D-1	6
MS35387-2	96906	D-3	10	13216E7604-43	97403	D-3	13
MS35425-28	96906	D-3	25	13220E5888-2	97403	D-4	13
MS35425-37	96906	D-1	14	13221E4799	97403	D-1	10
MS35489-112	96906	D-3	28	13221E7325	074-3	D-3	30
MS35842-11	96906	D-3	26	13221E7329	97403	D-3	33
MS51922-1	96906	D-3	8	13266E0953	97403	D-1	9
MS51922-17	96906	D-3	4	13226E7737	97403	D-4	1
MS51922-17	96906	D-3	38				

Section V. REFERENCE DESIGNATOR INDEX

Not Applicable

By Order of the Secretary of the Army:

Official:

WILLIAM J. MEEHAN, II
Brigadier General, United States Army
The Adjutant General

CARL E. VUONO
General, United States Army
Chief of Staff

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A, Operator, Unit, and Direct Support and General Support Maintenance Requirements for Generator Set, Diesel Engine Driven, Trailer Mounted.

The Metric System and Equivalents

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimeter = 10 centimeters = 3.94 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.08 feet
 1 kilometer = 10 hectometers = 3,280.8 feet

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram = 10 decigrams = .035 ounce
 1 dekagram = 10 grams = .35 ounce
 1 hectogram = 10 dekagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 liter = 10 deciliters = 33.81 fl. ounces
 1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	2.540	ounce-inches	newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square meters	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29.573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-foot	newton-meters	1.356	metric tons	short tons	1.102
pound-inches	newton-meters	.11296			

Temperature (Exact)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
----	------------------------	----------------------------	---------------------	----

