

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

---

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS  
AND SPECIAL TOOLS LISTS  
INVERTER-VIBRATOR PP-1703/U  
FSN 6130-889-1207**

---

Headquarters, Department of the Army, Washington, D.C.  
22 November 1974

---

Current as of 13 September 1974

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope.....	1-1	2
General .....	1-2	2
Explanation of columns .....	1-3	2
Special information.....	1-4	4
Location of repair parts. . . . .	1-5	4
Abbreviation (Not applicable).....	1-6	4
Reporting of equipment publication improvements .....	1-7	4
II. PRESCRIBED LOAD ALLOWANCE (Not applicable)		
III. REPAIR PARTS LIST .....		6
IV. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
V. INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS- REFERENCE TO FIGURE AND ITEM NUMBER .....		7

THIS PUBLICATION IS A COURTESY QUICK COPY FROM THE UNITED STATES ARMY PUBLICATIONS DISTRIBUTION CENTER, ST. LOUIS, MISSOURI. TO MEET YOUR NEEDS WHILE WE REPLENISH OUR REGULAR STOCK.

# SECTION I INTRODUCTION

---

## 1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational maintenance of the PP- 1703/U. The PCCN for the PP-1703/U is GTBAAS for all models.

## 1-2 General

This repair parts and special tools list is divided into the following sections:

- a. Prescribed Load Allowance (PLA) - *Section II*. Not applicable.
- b. Repair Parts List - *Section III*. A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is *arranged* in alphabetical order.
- c. Special *Too/s, Test and Support* Equipment-*Section IV*. Not applicable
- d. Index - *Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number-Section V*. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

## 1-3. Explanation of Columns

The following provides an explanation of columns in the tabular lists -

a Source, Maintenance, and Recoverability Codes (SMR).

(1) Source code. Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are-

Code	Explanation
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance Purposes because essentiality dictates that a minimum quantity be <b>available</b> in the supply Systems.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.

## Code

## Explanation

PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
P G	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides <i>items required</i> at the time of overhaul or repair.
K F	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level
MF	item to be manufactured or fabricated at direct support maintenance level
MH	Item to be manufactured or fabricated at general support maintenance level
MD	Item to be manufactured or fabricated at depot maintenance level
AO	Item to be assembled at organizational level
A F	Item to be assembled at direct support maintenance level
A H	Item to be assembled at general support maintenance level
AD	Item to be assembled at depot <i>maintenance level</i> .
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available <i>through salvage, requisition</i> .
xc	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number
XD	Support items can be requisitioned with

**Code**                      **Explanation**

justification.

NOTE

Cannibalization or salvage may be used as a source of supply for *any* items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) Maintenance code Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows —

(a) *Use(third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

code	Application/Explanation
O—	Support item is removed, replaced, used at the organizational level of maintenance.
	NOTE
	A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.
F—	Support item is removed, replaced, used at the direct support maintenance level.
H—	Support item is removed, replaced, used at the general support maintenance.
D—	Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems *or* when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code —

Code	Application/Explanation
O—	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F—	The lowest maintenance level capable of complete repair of the support item is direct support
H—	The lowest maintenance level capable of complete repair of the support item is general support.

Code	Application/Explanation
D —	The lowest maintenance level capable or complete repair of the support item is the depot level.
L—	Repair restricted to designated Specialized Repair Activity.
Z—	Non-repairable. No repair is authorized.
B—	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability~ code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows —

Code	Explanation
Z —	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O—	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F—	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H—	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D—	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L—	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A—	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

*b. Federal Stock Number.* Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

*c. Description.* Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

*d. Unit of Measure (UIM).* Indicates the standard

or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc, and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned

e. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the equipment.

f. 15-Day Organizational Maintenance Allowance.

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSEL-MA-TMDE, Fort Monmouth, NJ., 07703. Any changes approved will be reflected in a revision to the RPSTL.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other equipment.

g. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown in TM 11-6125-238-12.

(2) *Item number.* Indicates the item number or reference designation used to reference the item in the illustration.

#### 1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are —

<i>Code</i>	<i>Used on</i>
<b>A7D</b>	<b>PP-1703/U</b>

b. The following publication pertains to the PP-1703/U and its components:

TM 11-6125-238-12 *Operator and Organizational Maintenance Manual: Inverter, Vibrator PP-1703/U.*

#### 1-5. Location of Repair Parts

a This manual contains one cross-reference index (sec V) to be used to locate a repair part when either the Federal stock number or *reference number* (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (see V) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (see III) and locate the figure number (col 7a) and item number or reference designation (col 7b) as noted in the FSN index

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b of the repair parts list (see III) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (see III), which is arranged in alphabetical order.

#### 1-6. Abbreviations

Not applicable.

#### 1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSEL-MA-TMDE, Fort Monmouth, NJ, 07703.

(Next printed page is 6)



SECTION II											
(1)	(2)	(3)		(4)	(5)	(6)				(7)	
SMR	FEDERAL	DESCRIPTION		UNIT	QTY	15-DAY ORGANIZATIONAL				ILLUSTRATION	
CODE	STOCK	REFERENCE NUMBER & MFR CODE	USABLE ON CODE	OF	INC	MAINTENANCE ALW				(A)	(B)
	NUMBER			MEAS	IN	(A)	(B)	(C)	(D)	FIGURE	ITEM
					UNIT	1-5	6-20	21-50	51-100	NO	NO
PAOZZ	5999-583-5057	CAP, ELECTRICAL NO-REF-DESIG 342003SA2 (75915)		EA	1	*	*	*	*		
PAOZZ	6130-961-4294	VIBRATOR, INTERRUPTER G1 24 V DC. 4 AMP SINGLE REED 5-3/16 IN. LG X 2-1/8 IN. W 2-1/2 IN. H PA6101 (16783)		EA	1	*	*	*	*	4	G1
XDCZZ		FUSE, CARTRIDGE F1 7-1/2 AMP 250V AGC71-2 (71400)		EA	1	*	*	*	*	1	
XDOZZ		CLIP, ELECTRONICAL NO-REF-DESIG BATTERY TYPE 1.140 IN. X 2.610 IN. X 0.6333 IN.		EA	2	*	*	*	*	1	

SECTION V

INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER  
 CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

NOTE: LATEST FEDERAL STOCK NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
			6130-961-4294	4	G1

REFERENCE NO	MFG CODE	FIG NO	ITEM NO	REFERENCE NO	MFG CODE	FIG NO	ITEM NO
AGC71-2	71400	1		24C	76545	1	
PA6101	16783	4	G1	342003SA2	75915		

LATEST FEDERAL STOCK NUMBER ASSIGNMENTS

STOCK NUMBER	FIGURE NO.	ITEM NO.
5999-583-5057		

By Order of the Secretary of the Army:

**FRED C. WEYAND**  
*General, United States Army*  
*Chief of Staff*

**Official:**

**VERNE L. BOWERS**  
*Major General, United States Army*  
*The Adjutant General*

**Distribution:**

**Active Army:**

**USASA (2)**  
**CNGB (1)**  
**Dir of Trans (1)**  
**COE (1)**  
**TSG (1)**  
**USAARENBD (1)**  
**USAMB (10)**  
**AMC (1)**  
**TRADOC (2)**  
**ARADCOM (2)**  
**ARADCOM Rgn (2)**  
**OS Maj Comd (4)**  
**LOGCOMDS (3)**  
**MICOM (2)**  
**TECOM (2)**  
**USMC (4)**  
**MDW (1)**  
**Armies (2)**  
**Corps (2)**  
**HISA (Ft Monmouth) (18)**  
**Svc Colleges (1)**  
**USASESS (5)**  
**USAADS (2)**  
**USAFAS (2)**  
**USAARMS (2)**  
**USALS (2)**  
**USAES (2)**  
**USAINTCS (3)**  
**WRAMC (1)**

**ATS (1)**  
**Fort Gordon (10)**  
**Fort Huachuca (10)**  
**WSMR (1)**  
**Fort Canon (5)**  
**Ft Richardson (ECOM Ofc) (2)**  
**Army Dep (1) except**  
**LBAD (14)**  
**SAAD (30)**  
**TOAD (14)**  
**ATAD (10)**  
**USA Dep (2)**  
**Sig Sec USA Dep (2)**  
**Sig Dep (2)**  
**Sig FLDMS (1)**  
**USAERDAA (1)**  
**USAERDAW (1)**  
**MAAG (1)**  
**USARMIS (1)**  
**Units org under fol TOE:**  
**(1 copy each unit)**  
**11-16**  
**11-97**  
**11-98**  
**11-117**  
**11-302**  
**11-500(AA-AC)**  
**29-134**  
**29-136**

**NG: State AG (3); Units-Same as Active Army**

**USAR: None**

**For explanation of abbreviations used, see AR 310-60.**