ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS CHARGERS, BATTERY PP-1660/G AND PP-1660A/G FSN 6130-669-6659

Headquarters Department of the Amy, Washington, DC. 28 June 1974

Current as of November 1973

	Paragraph	Pag
SECTION I. INTRODUCTION		
Scope.	1-1	2
Scope General General	1-2	2
Explanation of columns	1-3	2
Special information	1-4	4
Location of repair parts	1-5	4
Abbreviations (Not applicable)	1-6	4
Reporting of equipment publication improvements	1-7	4
III. REPAIR PARTS LIST		6
IV. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
V. INDEX — FEDERAL NUMBER AND REFERENCE NUMBER CROSS-		
DEFEDENCE TO FIGURE AND ITEM NUMBER		7

SECTION I

1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational maintenance of the PP-1660/G and PP-1660A/G. The PCCN for the equipment is GTBAAR for all models.

1-2. General

This repair parts and special tools list is divided into the following sections:

- a. *Prescribed Load Allowance (PLA) Section II.* Not applicable.
- b. Repair Parts List Section III. A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.
- c. Special Tools, Test and Support Equipment Section IV. Not applicable.
- d. Index Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number Section V. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns in the tabular lists —

- a. Source, Maintenance, and Recoverability Codes (SMR).
- (1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are —

code Explanation

- PA Item procured and stocked for anticipated or known usage.
- PB Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
- PC- Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
- PD- Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional

Code Explanation

- initial issues or out fittings. Not subject to automatic replenishment.
- PE Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
- PF Support equipment which will not be stocked but which will be centrally procured on demand.
- PG Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
- KD An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
- KF An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
- KB Item included in both a depot overhaul/repair kit and a maintenance kit.
- MO Item to be manufactured or fabricated at organizational level.
- MF Item to be manufactured or fabricated at direct support maintenance level.
- MH Item to be manufactured or fabricated at general support maintenance level.
- MD Item to be manufactured or fabricated at depot maintenance level.
- AO Item to be assembled at organizational level.
- AF Item to be assembled at direct support maintenance level.
- AH Item to be assembled at general support maintenance level.
- AD Item to be assembled at depot maintenance level.
- XA Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
- XB Item is not procured or stocked. If not available through salvage, requisition.

- Code Explanation
- XC Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.
- XD Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 70042.

- (2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Cede Format as follows —
- (a) *Use(third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

code Application/Explanation

O - Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

- F Support item is removed, replaced, used at the direct support maintenance level.
- H Support item is removed, replaced, used at the general maintenance.
- D Support items that are removed, replaced, used at depot only.
- (b) Repair (fourth position). The maintenance de entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions} When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code —

Code Application/Explanation

- O The lowest maintenance level capable of complete repair of the support item is the organizational level.
- F The lowest maintenance level capable of

Code Application/Explanation
complete repair of the support item is
direct support.

- H The lowest maintenance level capable of complete repair of the support item is general support.
- D The lowest maintenance level capable of complete repair of the support item is the depot level.
- L Repair restricted to designated Specialized Repair Activity.
- Z Non-repairable. No repair is authorized.
- B No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.
- (3) *Recoverability code*. Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows —

Code Explanation

- Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code
- O Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
- F Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
- H Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
- D Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
- Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
- A Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).
- *b. Federal Stock Number.* Indicates the Federal stuck number assigned to the item and will be used for requisitioning purposes.
- c. Description. Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number

followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

- d. Unit of Measure (UIM). Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., e.a, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.
- e. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".
 - f. 15-Day Organizational Maintenance Allowance.
- (1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.
- (2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSEL-MA-TMDE, Fort Monmouth, N.J., 07703. Any changes approved will be reflected in a revision to the RPSTL.
- (3) Allowance quantities are indicated in the special tools list section for special tools, TM DE, and other equipment.
 - g. Illustration. This column is divided as follows:
- (1) *Figure number.* Indicates the figure number of the illustration on which the item is shown in TM TM 11-6130-227-12.
- (2) *Item number*. Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are -

Code	Used on
A7C	PP-1660/G
B29	PP-1660A/G

b. The following publication pertains to the equipment and its components:

TM 11-6130-227-12 Operator and Organizational Maintenance Manual:
Charger, Battery
PP-1660/G.

1-5. Location of Repair Parts

- a. This manual contains one cross-reference index (sec V) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.
- *b.* When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.
- (1) Refer to the index of Federal stock numbers (sec V) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.
- (2) Refer to the repair parts list (sec III) and locate the figure number (col 7a) and item number or reference designation (col 7b) as noted in the FSN index.
- c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b of the repair parts list (sec III) until the item is located.
- *d.* When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec III), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSEL-TMDE, Fort Monmouth, N.J., 07703.

	• • • •						11122	0170-	221-2	O P
(1)	(2)	(3)	(4)	(5)		•	5)		(7)
SMR	FEDERAL	DESCRIPTION	JNI	QTY INC	MA	Y ORGA	ANCE A	\L\		RATION
CODE	STOCK NUMBER	REFERENCE NUMBER & MFR CODE USABLE ON CODE	OF LEA	IN	(a) 1-5	(b) 6-20	(c) 21.50	(a) (a)	(a) FIGUR NO.	(b) ITEM NO
'AD22	5940-884-0094	LIP, ELECTRICAL BATTERYCLIP ALLIGATOR TYPE 2 IN H X 5 IN LG X 1-1/16 IN W	EA	2	•	*	•	*	1	P2
'AD22	5935-888-7319	LIA (76545) ; JNNECTOR, PLUG, ELECTRICAL PLUGCONNECTOR 3 ; ONT 1-1/21V DIA X 1-5/8IN LG O/A	EA	1	*	*	*	*	1	PI
'AD22	5935-201-8467	1277 (74543) 30NNECTOR, PLUG, ELECTRICAL PL3 CONT 1-112 INDIA X 1-5/8 IN LG O/A 15AMP, 125V 0.562 IN 11A O/A	EA	1	*	*	*	×		PI
AOZZ	5935-802-6046	5264 (74545) B29 IACK, TIP E6 P/O CABLE ASSEMBLY	EA	ı	*	*	*	*		E6
ZZOA	5935-802-8043	1ACK, TIP E2P/OCABLE ASSEMBLY	EA	1	*	*	*	*		E 2
'AD22	5335-813-Y 107	(NOB MP12 RD PHENCLIC L-I/a IN OD X 9/16 IN THK	EA	2	*	*	*			IP 12
'AOZZ	5355-813-9107	NOB MP13 RD PHENOLIC 1-1/8 IN OD X 9/16 IN THE	IA	:EF	*	*	*	*		P 13
'AD22	5355-823-9888	RB200 (86797) ATC RDB MP11 RD PHENOLIC 1-5/8 IN O D x 7/8 IN T H K	=A	1	*	*	*			P11
AOZZ	5316-834-2409	.901 (823861 •JT• SPECIAL H14	ΞĄ	1	*	*	*	•		H14
'A022	5316-804-2410	2558-002 (82386) NUT. SPECIAL H15	EA	1	*	*	*			H15
PAOZZ	5940-884-0094	2.558-001 (82386) 2.LIP, ELECTRICAL BATTERYCLIP ALLIGATOR TYPE 2 IN H X 5: N LG X 1-1/16 IN W .1A(76545) 6	EA	2		*	*	*	1	P3

INUEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE A N D ITEM NUMBER

STUCK NUMBER	FIGURE NU.	! T € N D		STOCK NUMBER	FIGURE NO.		TEM NO.
5310-804-2409 5310-804-2410 5355-813-9107 5355-313-9107 5355-323-9868		H1 H1 MP1 MP1	5 2 3	5935-201-8467 5935-802-8046 5935-802-8048 5935-888-7319 5940-884-0094	1 1 1		P1 E6 E2 P1 P3 P2
REFERENCE Nu.		MFR FIG.	1 T E M N 0 .	REFERENCE NO.	MER CODE	FIG. I	TEM NO.
RB200 RB200 11A 1901 2543-002		86797 86797 76545 1 82386 82386	MP12 MP13 P2P3 MP11 E b	2543-004 2558-001 2558-002 5264 5277	82386 82386 82386 74545 74545		E2 H15 H14 P1 P1

CREIGHTON W. ABRAMS General, United States Army Chief of Staff

Official:

VERNE L. BOWERS

Major General, United States Army The Adjutant General

DISTRIBUTION:

Active Army:

USASA (2) USAINTCS (3) CNGB (1) WRAMC (1) Dir of Trans (1) ATS (1) COE (1) Ft Gordon (10) TSG (1) Ft Huachuca (10) USAARENBD (1) WSMR (1) **USAMB (10)** Ft Carson (5) AMC (1) Ft Richardson (ECOM Ofc) (2) TRADOC (2) Army Dep (1) except ARADCOM (2) LBAD (14) ARADCOM Rgn (2) **SAAD (30)** OS Maj Comd (4) TOAD (14) LOGCOMDS (3) ATAD (10) MICOM (2) GENDEP (2) TECOM (2) Sig Sec GENDEP (2) USACC (4) Sig Dep (2) MDW (1) SigFLDMS (1) Armies (2) USAERDAA (1) Corps (2) USAERDAW (1) HISA (18) MAAG (1) Svc Colleges (1) USARMIS (1) USASESS (5) Units org under fol TOE: USAADS (2) (1 cy each) USAFAS (2) 11-500 (AA-AC) USAARMS (2) 29-134 USAIS (2) 29-136

NG & USAR: None

USAES (2)

For explanation of abbreviations used, see AR 310-50.

*U.S. Government PRINTING OFFICE 1993- 388-421/41149

8

PIN: 020653-000

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

	SOMETHING WRONG WITH PUBLICATION FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS) THENJOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL. DATE SENT									
	PUBLICATION NUMBER PUBLICATION DATE PUBLICATION TITLE									
╏┠╌	E EXAC PAGE NO.	T PIN-PC PARA- GRAPH	FIGURE NO.	TABLE NO.				AT IS WRONG DONE ABOUT IT.		
PF	RINTED I	NAME, GRA	DE OR TITL	E AND TELE	EPHONE NU	JMBER	SIGN HE	ERE		

DA 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE. P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.