
DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS
DECIBEL METERS ME-22/PCM AND ME-22A/PCM
FSN 6625-498-3469

Headquarters, Department of the Army, Washington, D.C.
28 June 1974

Current as of November 1973

		Paragraph	Page
SECTION I.	INTRODUCTION		
	Scope	1-1	2
	General	1-2	2
	Explanation of columns	1-3	2
	Special information	1-4	4
	Location of repair parts.....	1-5	4
	Abbreviations (Not applicable.....	1-6	5
	Reporting of equipment publication improvements	1-7	5
II.	PRESCRIBED LOAD ALLOWANCE (Not applicable)		
III.	REPAIR PARTS LIST		6
IV.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
V.	INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER		7

'This manual supersedes TM 11-6625-251-20P, 20 September 1963.

SECTION I

INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational maintenance of the ME-22/PCM and ME-22A/PCM. The PCCN for the equipment is GTEAHU for all models.

1-2. General

This repair parts and special tools list is divided into the following sections:

- a. *Prescribed Load Allowance (PLA) Section II.* Not applicable.
- b. *Repair Parts List-Section III.* A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.
- c. *Special Tools, Test and Support Equipment-Section IV.* Not applicable.
- d. *Index-Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number Section V.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns in the tabular lists-

- a. *Source, Maintenance, and Recoverability Codes (SMR).*

- (1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are -

<i>Code</i>	<i>Explanation</i>
PA -	Item procured and stocked for anticipated or known usage.
PB -	Item procured and stocked for insurance purposes because essentially dictates that a minimum quantity be available in the supply systems.
PC -	Item procured and stocked and which otherwise could be coded PA except that it is deteriorative in nature.
PD -	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE -	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF -	Support equipment which will not be stocked but which will be centrally procured on demand.
PG -	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD -	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF -	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB -	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO -	Item to be manufactured or fabricated at organizational level.
MF -	Item to be manufactured or fabricated at direct support maintenance level.
MH -	Item to be manufactured or fabricated at general support maintenance level.
MD -	Item to be manufactured or fabricated at depot maintenance level.
AO -	Item to be assembled at organizational level.
AF -	Item to be assembled at direct support maintenance level.
AH -	Item to be assembled at general support maintenance level.
AD -	Item to be assembled at depot maintenance level.
XA -	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.

- XB - Item is not procured or stocked. If not available through salvage, requisition.
- X - Installation drawing, diagram instruction sheet. field service drawing, that is identified by manufacturers' part number.
- XD - Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows -

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the fourth position indicates one of the following levels of maintenance.

<i>Code</i>	<i>Application/Explanation</i>
O -	Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

- F - Support item is removed, replaced, used at the direct support maintenance level.
- H - Support item is removed, replaced, used at the general support maintenance.
- D - Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi- service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code -

- O - The lowest maintenance level capable of complete repair of the support item is the organizational level.
- F - The lowest maintenance level capable of complete repair of the support item is direct support.
- H - The lowest maintenance level capable of complete repair of the support item is general support.
- D - The lowest maintenance level capable of complete repair of the support item is the depot level.
- L - Repair restricted to designated Specialized Repair Activity.
- Z - Non-repairable. No repair is authorized.
- B - No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows -

<i>Code</i>	<i>Explanation</i>
Z -	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O -	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F -	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H -	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D -	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L -	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A -	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. *Federal Stock* . Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. *Description*. Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

d. *Unit of Measure (U/M)*. Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Incorporated in Unit*. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f. *15-Day Organizational Maintenance Allowance*.

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, U.S. Army Electronics Command, ATTN: AMSEL-MA-TMDE, Fort Monmouth, N.J., 07703. Any changes approved will be reflected in a revision to the RPSTL.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE. and other equipment.

g. *Illustration*. This column is divided as follows:

(1) *Figure number*. Indicates the figure number of the illustration on which the item is shown in TM 11-6625-251-15.

(2) *Item number*. Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are -

Code	Used on
BWW	ME-22/PCM
BWX	ME-22A/PCM

b. The following publication pertains to the equipment and its components:

TM 11-662-251-15
Organizational, DS, GS, and Depot Maintenance Manual: Test Set TS-140/PCM,
Signal Generator SG-15/ PCM, and SG-15A/PCM and Decibel Meter ME-22/PCM
and ME-22A/PCM.

1-5. Location of Repair Parts

a. This manual contains one cross-reference index (sec V) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part-number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec V) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec III) and locate the figure number (col 7a) and item number or reference designation (col 7b) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b of the repair parts list (sec III) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec III), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMISEL-MA-TMDE, Fort Monmouth, N.J. 07703. (Next printed page is 6)

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION USABLE ON CODE REF NUMBER & MFR CODE		(4) UNIT OF MEAS	(5) QTY INC IN UNIT	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUS- TRATION	
						(a)	(b)	(c)	(d)	(a)	(b)
						1-5	6-20	21-50	51-100	FIG NO.	ITEM NO.
PAOZZ	5920-568-5866	CAP, ELECTRICAL	XFA1	EA	2	°	°	°	°		XFA1
		9226-1-2 (71400)BWX								
PAOZZ	5920-258-8644	CAP, ELECTRICAL	XFA1	EA	2	°	°	°	°		XF
		9327 (71400)BWW								
PAOZZ	5960-188-0968	ELECTRON TUBE	V6.....	EA	1	°	°	°	°	7-5	V6
		OC3W (81349)									
PAOZZ	5960-262-0218	ELECTRON TUBE	V8.....	EA	1	°	°	°	°	7-5	V8
		5Y3WGTA (81349)									
PAOZZ	5960-188-8499	ELECTRON TUBE	V4.....	EA	1	°	°	°	°	7-5	V4
		6H6 (81349)									
PAOZZ	5960-262-0161	ELECTRON TUBE	V5.....	EA	1	°	°	°	°	7-5	V5
		6L6WGB (81349)									
PAOZZ	5960-188-3574	ELECTRON TUBE	V1.....	EA	3	°	°	°	°	7-5	V1
		6SJ7WGT (81349)									
PAOZZ	5960-188-3574	ELECTRON TUBE	V2.....	EA	REF	°	°	°	°	7-5	V2
		6SJ7WGT (81349)									
PAOZZ	5960-188-3574	ELECTRON TUBE	V3.....	EA	REF	°	°	°	°	7-5	V3
		6SJ7WGT (81349)									
PAOZZ	5960-100-5273	ELECTRON TUBE	V7.....	EA	1	°	°	°	°	7-5	V7
		6SQ7 (81349)									
PAOZZ	5920-280-4465	FUSE, CARTRIDGE	F1	EA	1	°	°	°	°	7-5	F1
		F02A250V1A (81349)BWX								
PAOZZ	5920-284-4153	FUSE,CARTRIDGE	F1 1 AMP, 250V.....	EA	1	°	°	°	°	7-5	F1
		AGS1 (71400)									
PAOZZ	5355-644-4194	KNOB 01 BLACK PLASTIC, SETSCREW TYPE		EA	1	°	°	°	°		01
		W/SKIRT, OCTAGON SHAPE, ACCOM 1/4 IN DIA SHAFT									
		SCB86087 (80063)									
PAOZZ	6240-155-8706	LAMP, INCANDESCENT (USED ON ORDER									
		16880-PP-6210-67		EA	1	°	°	°	°		
		B1-101-47 (82679)									
PAOZZ	6240-011-5273	LAMP, INCANDESCENT AMP		EA	1	°	°	°	°		
		DX4478A (505131)									
PAOZZ	6210-983-5155	LENS, INDICATOR LIGHT GLASS, CLEAR, RED		EA	1	°	°	°	°		
		L015RD (72619)									

**INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER
CROSS-REFERENCE TO FIGURE AND ITEM NUMBER**

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5355-644-4194		1	5960-188-3574	7-5	V2
5920-258-8644		XFA1	5960-188-3574	7-5	V3
5920-280-4465	7-5	F1	5960-188-8499	7-5	V4
5920-284-4153	7-5	F1	5960-262-0161	7-5	V5
5920-568-5866		XFA1	5960-262-0218	7-5	V8
5960-100-5273	7-5	V7	6210-983-5155		
5960-188-0968	7-5	V6	6240-011-5273		
5960-188-3574	7-5	V1	6240-155-8706		

REFERENCE NO.	MFR CODE	FIG NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG NO.	ITEM NO.
AGS1	71400	7-5	F1	6H6	81349	7-5	V4
81-101-47	82679			6L6WGB	81349	7-5	V5
DX4478A	50513			6S07WGT	81349	7-5	V1
F02A250V1A	81349	7-5	F1	6S07WGT	81349	7-5	V2
L015R0	72619			6S07WGT	81349	7-5	V3
SCB86087	80063		01	6SQ7	81349	7-5	V7
OC3W	81349	7-5	V6	9226-1-2	71400		XFA1
5Y3WGTA	81349	7-5	V8	9327	71400		XFA1

By Order of the Secretary of the Army:

CREIGHTON W. ABRAMS
General, United States Army
Chief of Staff

Official:

VERNE L. BOWERS
Major General, United States Army
The Adjutant General

Distribution:

Active Army

	Units org under fol TOE: (1 cy each)
CNGB (1)	6-615
TSG (1)	6-616
ACSC-E (2)	7
USAMB (10)	11-97
USAARENBD (1)	11-98
USASA (2)	11-117
TRADOC (2)	11-127
AMC (1)	11-147
MICOM (1)	11-225
TECOM (2)	11-226
ARADCOM (2)	11-237
ARADCOM Rgn (1)	11-303
OS Maj Comd (2)	11-347
USACC (2)	11-357
HISA (Ft Monmouth) (18)	11-377
Armies (1)	11-500(AA-AC)
USASESS (5)	17
Svc Colleges (1)	29-1
Ft Huachuca (5)	29-11
WSMR (1)	29-15
Fort Carson (5)	29-16
USAERD.AA (1)	29-21
USAERDAW (1)	29-25
Army Dep (1) except	29-26
LBAD (10)	29-35
TOAD (14)	29-36
ATAD (10)	29-41
SAAD (30)	29-85
USA Dep (1)	29-86
Sig Sec USA Dep (2)	37
Sig Dep (2)	39-51
Sig FLDMS (1)	47
Ft Richardson (ECOM Ofc) (1)	29-134
	29-136


NG None

USAR None

For explanation of abbreviations used, see AR 310-50.

GPO 675 659

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

SOMETHING WRONG WITH PUBLICATION

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS				IN THIS SPACE, TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT.
PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.	

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

TEAR ALONG PERFORATED LINE

DA FORM 1 JUL 79 **2028-2**

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

