

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS
SIGNAL GENERATORS SG-299/U, SG-299A/U,
SG-299B/U, AND SG-299C/U
FSN 6625-624-3516

Headquarters, Department of the Army, Washington, D.C.
31 August 1973

Current as of February 1973

SECTION		Paragraph	Page
I.	INTRODUCTION		
	Scope	1-1	2
	General	1-2	2
	Explanation of columns	1-3	2
	Special information	1-4	4
	Location of repair parts	1-5	4
	Abbreviations (Not applicable)	1-6	4
	Reporting of equipment publication improvements	1-7	4
II.	PRESCRIBED LOAD ALLOWANCE (Not applicable)		
III.	REPAIR PARTS LIST		6
IV.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
V.	INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER		7

*This manual supersedes TM 11-6625-258-20P, 24 November 1964.

SECTION I. INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational maintenance of the SG-299/U, SG-299A/U, SG-299B/U, and SG-299C/U. The PCCN for the equipment is GTEAAS for all models.

1-2. General

This repair parts and special tools list is divided into the following sections:

a. Prescribed Load Allowance (PLA)-Section II. Not applicable.

b. Repair Parts List-Section III. A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.

c. Special Tools, Test and Support Equipment-section IV. Not applicable.

d. Index-Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number-Section V. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns in the tabular lists-

a. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are-

Code	Explanation
PA-	Item procured and stocked for anticipated or known usage.
PB-	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC-	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD-	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.

Code	Explanation
PE-	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF-	Support equipment which will not be stocked but which will be centrally procured on demand.
PG-	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD-	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF-	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support levels of maintenance.
KB-	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO-	Item to be manufactured or fabricated at organizational level.
MF-	Item to be manufactured or fabricated at direct support maintenance level.
MH-	Item to be manufactured or fabricated at general support maintenance level.
MD-	Item to be manufactured or fabricated at depot maintenance level.
AO-	Item to be assembled at organizational level.
AF-	Item to be assembled at direct support maintenance level.
AH-	Item to be assembled at general support maintenance level.
AD-	Item to be assembled at depot maintenance level.
XA-	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB-	Item is not procured or stocked. If not available through salvage, requisition.
XC-	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturer's part number.
XD-	Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source

coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows-

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

<i>Code</i>	<i>Application/Explanation</i>
O-	Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

<i>Code</i>	<i>Application/Explanation</i>
F-	Support item is removed, replaced, used at the direct support maintenance level.
H-	Support item is removed, replaced, used at the general support maintenance.
D-	Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code-

<i>code</i>	<i>Application/Explanation</i>
O-	The lowest maintenance level capable of complete repair of the support item is the organizational level.
F-	The lowest maintenance level capable of complete repair of the support item is direct support.
H-	The lowest maintenance level capable of complete repair of the support item is general support.

<i>Code</i>	<i>Application/Explanation</i>
D-	The lowest maintenance level capable of complete repair of the support item is the depot level.
L-	Repair restricted to designated Specialized Repair Activity.
Z-	Non-repairable. No repair is authorized.
B-	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows-

<i>Code</i>	<i>Explanation</i>
Z-	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O-	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F-	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H-	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D-	Repairable item; When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L-	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A-	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. Federal Stock Number. Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. Description. Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification. to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

d. Unit of Measure (U/M). Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. Quantity Incorporated in Unit. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f. 15-Day Organizational Maintenance Allowance.

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSELMACRA, Fort Monmouth, N.J., 07703. Any changes approved will be reflected in a revision to the RP-STL.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other equipment.

g. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown in TM 11-5134-15.

(2) *Item number.* Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are-

<i>Code</i>	<i>Used on</i>
AF5	SG-299/U
AF6	SG-299A/U (Order No. 39108-PP-58)
AWW	SG;299A/U (Order No. 4502 -PP-60)
AF7	SG;299B/U
AF8	SG-299C/U

b. The following publication pertains to the equipment and its components:

TM 11-5134-15	Organizational, DS, GS, and Depot Maintenance Manual: Signal Generators SG-299/U, SG-299A/U, SG-299B/U, and SG-299C/U.
---------------	--

1-5. Location of Repair Parts

a. This manual contains one cross-reference index (see V) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

b. When the Federal stock number or reference number is known, follow procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec V) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (sec III) and locate the figure number (col 7a) and item number or reference designation (col 7b) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b of the repair parts list (see III) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec III), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to publications) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSELMACRA, Fort Monmouth, .J., 07703.

(Next printed page is 6.)

SECTION III

TM 11-6625-258-20P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION REFERENCE NUMBER & MFR CODE USABLE ON CODE		(4) INI OF EA	(5) QTY. INC IN UNIT	(6) 15-DAY ORGANIZATIONAL				(7) ILL LATION	
						M	ITE	ICE	W	(a) INC NO.	(b) ITEM NO.
						(a) 1-5	(b) 6-20	(c) 21-5	(d) 1-10		
PAOZZ		CAP, ELECTRICAL NO-R EF-DESIG FOR FUSE HOLDER . SC B136552 (75915)		EA	1						
PAOZZ	5960-642-8341	ELECTRON TUBE 5J4GB (81349)	V12.....	EA	1					10.	V1
PAOZZ	5960-188-3602	ELECTRON TUBE 6BH6 (81349)	V14.....	EA	1					10.	V1
PAOZZ	5960-262-3781	ELECTRON TUBE 6BQ7A (81349)	V1.....	EA	1					10	V
PAOZZ	5960-615-0243	ELECTRON TUBE 6CL6 (81349)	V2.....	EA	8					10.	V
PAOZZ	5960-615-0243	ELECTRON TUBE 6CL6 (81349)	V3.....	EA	REF					10.	V
PAOZZ	5960-6	ELECTRON TUBE 6CL6 (81349)	V6.....	EA	REF					10.	V
PAOZZ	5960-615-0243	ELECTRON TUBE 6CL6 (81349)	V7.....	EA	REF					10.	V
PAOZZ	5960-615-0243	ELECTRON TUBE 6CL6 (81349)	V8.....	EA	REF					10.	V
PAOZZ	5960-615-0243	ELECTRON TUBE 6CL6 (81349)	V9.....	EA	REF					10.	V
PAOZZ	5960-615-0243	ELECTRON TUBE 6CL6 (81349)	V10.....	EA	REF					10.	V1
PAOZZ	5960-615-0243	ELECTRON TUBE 6CL6 (81349)	V11.....	EA	REF					10.	V1
PAOZZ	5960-557-6780	ELECTRON TUBE 6C4WA (81349)	V5.....	EA	1					10.	V
PAOZZ	5960-262-0286	ELECTRON TUBE 5651WA (81349)	V15.....	EA	1					10.	V1
PAOZZ	5960-262-0185	ELECTRON TUBE 5726-6AL5W (81349)	V4.....	EA	1					10.	V
PAOZZ	5960-543-1001	ELECTRON TUBE 6080WA (81349)	V13.....	EA	1					10.	V1
PAOZZ	5920-280-3178	FUSE, CARTRIDGE F1 2.5 AMP 125 V		EA	1					14.	F
PAOZZ	5355-667-5971	9954778 (21450) KNOB NO-REF-DESIG BAR W-POINTER 1-13-32 X 7- X 13-16 IN		EA	5						
PAOZZ	5355-579-6390	11500 (74330) AF6 KNOB MP3 RD W-SKIRT 0-906 IN DIA X 1-015 IN THK		EA	5						MP:
PAOZZ	5355-579-6390	MS91528-2F2D (81349) AF6,AWW,AF7,AF8 KNOB MP4 RD W-SKIRT 0-906 IN DIA X 1-015 IN THK		EA	REF						MP:
PAOZZ	5355-579-6390	MS91528-2F2D (81349) AF6,AWW,AF7,AF8 KNOB MP19 RD W-SKIRT 0-906 IN DIA X 1-015 IN THK		EA	REF						1P1:
PAOZZ	5355-579-6390	MS91528-2F2D (81349) AF6,AWW,AF7,AF8 KNOB MP20 RD W-SKIRT 0-906 IN DIA X 1-015 IN THK		EA	REF						1P2:
PAOZZ	5355-579-6390	MS91528-2F2D (81349) AF6,AWW,AF7,AF8 KNOB MP21 RD W-SKIRT 0-906 IN DIA X 1-015 IN THK		EA	REF						1P2:
PAOZZ	5355-667-9295	MS91528-2F2D (81349) AF6,AWW,AF7,AF8 KNOB MP2 RD W-SKIRT AC COM 3-8 IN DIA SHAFT		EA	2						MP:
PAOZZ	5355-667-9295	KNS12 (24655) KNOB E5 RD W-SKIRT ACCOM 3-8 IN DIA SHAFT		EA	REF						E:
PAOZZ	6240-	KNS12 (24655) LAMP, INCANDESCENT LM-52 DS1 6-8V 0-15 AMP		EA	1					14.	DS:
		MS15571-2 (80058)									

INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER
 CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

STOCK NUMBER	FIGURE NO.	ITEM No.	STOCK NUMBER	FIGURE No.	ITEM NO.
5355-579-6390		MP3	5960-262-3781	10.1	V1
5355-579-6390		MP4	5960-543-1001	10.1	V13
5355-579-6390		MP19	5960-557-6780	10.1	V5
5355-579-6390		MP20	5960-615-0243	10.1	V2
5355-579-6390		MP21	5960-615-0243	10.1	V3
5355-667-5971	1		5960-615-0243	10.1	V6
5355-667-9295	1	E5	5960-615-0243	10.1	V7
5355-667-9295		MP2	5960-615-0243	10.1	V8
5920-280-3178	24.1	F1	5960-615-0243	10.1	V9
5940-186-8960			5960-615-0243	10.1	V10
5960-188-3602	10.1	V14	5960-615-0243	10.1	V11
5960-262-0185	10.1	V4	5960-642-8341	10.1	V12
5960-262-0286	10.1	V15	6240-155-8706	24.3	DS1

REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.
KNS12	24655	1	E5	6BH6	81349	10.1	V14
KNS12	24655	1	MP2	6BQ7A	81349	10.1	V1
MS15571-2	80058	24.3	DS1	6CL6	81349	10.1	V2
MS91528-2F2D	81349		MP3	6CL6	81349	10.1	V3
MS91528-2F2D	81349		MP4	6CL6	81349	10.1	V6
MS91528-2F2D	81349		MP19	6CL6	81349	10.1	V7
MS91528-2F2D	81349		MP20	6CL6	81349	10.1	V8
MS91528-2F2D	81349		MP21	6CL6	81349	10.1	V9
SCB136552	75915			6CL6	81349	10.1	V10
11500	74330	1		6CL6	81349	10.1	V11
5U4GB	81349	10.1	V12	6C4WA	81349	10.1	V5
5651WA	81349	10.1	V15	6080WA	81349	10.1	V13
5726-6AL 5W	81349	10.1	V4	9954778	21450	24.1	F1

By Order of the Secretary of the Army:

CREIGHTON W. ABRAMS,
General, United States Army,
Chief of Staff

Official:

VERNE L. BOWERS
Major General, United States Army,
The Adjutant General.

Distribution:

Active Army:

USASA (2)
CNGB (1)
ACSC-E (3)
USAARENBD (2)
USAMB (10)
AMC (1)
TROSCOM (5)
ARADCOM (2)
ARADCOM Rgn (2)
OS Maj Comd (4)
LOGCOMDS (5)
MICOM (2)
TECOM (2)
USASTRATCOM (4)
HISA (ECOM) (21)
MDW (1)
Armies (2)
Corps (2)
Svc Colleges (2)
USASESS (5)
USAADS (2)
USAFAS (2)
USAARMS (2)
USAIS (2)
USAES (2)
USAINTS (3)
USACDCEC (5)
Instl (2) except
 Fort Gordon (10)
 Fort Huachuca (10)
 Fort Carson (10)
 Ft Richardson (ECOM Ofc) (2)
 WSMR (2)

Army Dep (2) except
 LBAD (14)
 SAAD (30)
 TOAD (14)
 LEAD (7)
 ATAD (10)
USA Dep (2)
Sig See USA Dep (2)
Sig Dep (5)
Sig FLDMS (1)
USA ERDAA (1)
USAERDAW (1)
MAAG (1)
USARMIS (1)
WRAMC (1)
Units org under fol TOE: (1 cy)
 7 44-235
 11-16 44-236
 11-97 44-237
 11-98 44-568
 11-117
 11-500 (AA-AC)
 17
 29-1
 29-11
 29-15
 29-16
 29-21
 29-25
 29-35
 29-36
 32-56
 37

NG: State AG (3); Units - Same as Active Army.

USAR: *None*

For explanation of abbreviations used, see AR 310-50.