

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS
AND SPECIAL TOOLS LISTS
GENERATOR, PULSE SG-366/U
FSN 8825-682-9498**

Headquarters, Department of the Army, Washington, D.C.
19 April 1974

Current as of September 1973

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1-1	2
General	1-2	2
Explanation of columns	1-3	2
Special information	14	4
Location of repair parts	1-5	4
Abbreviations (Nonapplicable)..	1-6	4
Reporting of equipment publication improvements	1-7	4
II. PRESCRIBED LOAD ALLOWANCE (Not applicable)		
III. REPAIR PARTS LIST		6
IV. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
V. INDEX—FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS REFERENCE TO FIGURE AND ITEM NUMBER		7

This manual supersedes TM 11-6625-435-20P, 3 July 1962.

SECTION I INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of organizational maintenance of the SG-366/U. The PCCN for the SG-366/U is GRRACO for all models.

1-2 General

This repair parts and special tools list is divided into the following sections:

a. *Prescribed Load Allowance (PLA) - Section II.* Not applicable.

b. *Repair Parts List - Section III.* A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.

c. *Special Tools, Test and Support Equipment - Section IV.* Not applicable.

d. *Index - Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number - Section V.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns in the tabular lists —

a. *Source, Maintenance, and Recoverability Codes (SMR).*

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are —

<i>Code</i>	<i>Explanation</i>
PA —	Item procured and stocked for anticipated or known usage.
PB —	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC —	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD —	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.

<i>Code</i>	<i>Explanation</i>
PE —	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF —	Support equipment which will not be stocked but which will be centrally procured on demand.
PG —	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD —	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF —	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB —	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO —	Item to be manufactured or fabricated at organizational level.
MF —	Item to be manufactured or fabricated at direct support maintenance level.
MH —	Item to be manufactured or fabricated at general support maintenance level.
MD —	Item to be manufactured or fabricated at depot maintenance level.
AO —	Item to be assembled at organizational level.
AF —	Item to be assembled at direct support maintenance level.
AH —	Item to be assembled at general support maintenance level.
AD —	Item to be assembled at depot maintenance level.
XA —	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB —	Item is not procured or stocked. If not available through salvage, requisition.
XC —	Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.
XD —	Support items can be requisitioned with justification.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows —

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

<i>Code</i>	<i>Application/Explanation</i>
O—	Support item is removed, replaced, used at the organizational level of maintenance.

NOTE

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

F—	Support item is removed, replaced, used at the direct support maintenance level.
H—	Support item is removed, replaced, used at the general support maintenance.
D—	Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code —

<i>Code</i>	<i>Application/Explanation</i>
O—	The lowest maintenance level capable of complete repair of the support item is the organizational level.
	The lowest maintenance level capable of complete repair of the support item is direct support.
H—	The lowest maintenance level capable of complete repair of the support item is general support.
D—	The lowest maintenance level capable of

complete repair of the support item is the depot level.

L—	Repair restricted to designated Specialized Repair Activity.
Z—	Non-repairable. No repair is authorized.
B—	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows —

<i>Code</i>	<i>Explanation</i>
Z—	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O—	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F—	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H—	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D—	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L—	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
.A—	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. Federal Stock Number. Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. Description Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 708-42.

d. *Unit of Measure (UIM)*. Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Incorporated in Unit*. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f. *15-Day Organizational Maintenance Allowance*.

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at the organizational category, and will be requisitioned on an "as required" basis, until stockage is based on demand in accordance with AR 710-2.

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSEL-MA-SMV, Fort Monmouth, NJ., 07703. Any changes approved will be reflected in a revision to the RPSTL.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other equipment

g. *Illustration*. This column is divided as follows:

(1) *Figure number*. Indicates the figure number of the illustration on which the item is shown in TM 11-662543512.

(2) *Item number*. Indicates the item number or reference designation used to reference the item in the illustration.

1-4. Special information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models. Identification of the usable on codes used in this publication are —

<i>code</i>	<i>Used on</i>
AZJ	SG-366/U

b. The following publication pertains to the SG-366/U and its components:

TM 11-6625-435-12 operator and Organizational Maintenance Manual:
Generator, Pulse SG-366/U.

1-5. Location of Repair Parts

a. This manual contains one cross-reference index (see V) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers.

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec V) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable figure and item number or reference designation.

(2) Refer to the repair parts list (see III) and locate the figure number (col 7a) and item number or reference designation (col 7b) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b of the repair parts list (sec III) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize columns of the repair parts list (See III), which is arranged in alphabetical order.

1-6. Abbreviations

Not applicable.

1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forwarded direct to Commander, US Army Electronics Command, ATTN: AMSEL-MA-SR, Fort Monmouth, NJ, 07703.

(Next printed page is 6)

SECTION III

(1)	(2)	(3)	(4)	(5)	(6)				(7)		
SMR	FEDERAL STOCK NUMBER	DESCRIPTION	USABLE ON CODE	UNIT OF MEAS	QTY INC IN UNIT	15-DAY ORGANIZATIONAL MAINTENANCE ALW				ILLUS-TRATION	
CODE	NUMBER	REF NUMBER & MFR CODE				(A)	(B)	(C)	(D)	(A)	(B)
						1-5	1-20	21-50	51-100	NO.	NO.
		GROUP 0001 END ITEM GROUP									
PCOZZ	5340-864-3336	BUMPER, RUBBER NO-REF-DESIG 1611 (73734)		EA	8	*	*	*	*		
PAOZZ	5960-108-0261	ELECTRON TUBE V3 2D21 (81349)		EA	2	*	*	*	*	4	V3
PAOZZ	5960-108-0261	ELECTRON TUBE V5 2D21 (81349)		EA	REF	*	*	*	*	4	V5
PAOZZ	5960-262-1357	ELECTRON TUBE V2 6AK5 (81349)		EA	3	*	*	*	*	4	V2
PAOZZ	5960-262-1357	ELECTRON TUBE V8 6AK5 (81349)		EA	REF	*	*	*	*	4	V8
PAOZZ	5960-262-1357	ELECTRON TUBE V9 6AK5 (81349)		EA	REF	*	*	*	*	4	V9
PAOZZ	5960-879-5078	ELECTRON TUBE V4 5726 (81349)		EA	1	*	*	*	*	4	V4
PAOZZ	5960-669-6861	ELECTRON TUBE V6 6AQ5 (81349)		EA	1	*	*	*	*	4	V6
PAOZZ	5960-188-3602	ELECTRON TUBE V10 6BH6 (81349)		EA	2	*	*	*	*	4	V10
PAOZZ	5960-188-3602	ELECTRON TUBE V11 6BH6 (81349)		EA	REF	*	*	*	*	4	V11
PAOZZ	5960-166-7663	ELECTRON TUBE V1 12AU7 (81349)		EA	1	*	*	*	*	4	V1
PAOZZ	5355-284-5886	KNOB NO-REF-DESIG 2300A (72512)		EA	1	*	*	*	*		
PAOZZ	5355-059-9162	KNOB NO-REF-DESIG 1426D (80138)		EA	3	*	*	*	*		
PAOZZ	5355-889-3368	KNOB NO-REF-DESIG 2961 (80138)		EA	1	*	*	*	*		
PAOZZ	5355-889-3377	KNOB NO-REF-DESIG 2962 (80138)		EA	1	*	*	*	*		
PAOZZ	5960-295-7652	SHIELD, ELECTRON TUBE NO-REF-DESIG TS102U03 (81349)		EA	1	*	*	*	*		
PAOZZ	5960-264-3004	SHIELD, ELECTRON TUBE NO-REF-DESIG TS103U02 (81349)		EA	1	*	*	*	*		
PAOZZ	5960-262-0015	SHIELD, ELECTRON TUBE NO-REF-DESIG S0S3 (91662)		EA	4	*	*	*	*		
PAOZZ	5960-262-0347	SHIELD, ELECTRON TUBE NO-REF-DESIG S0S6 (91662)		EA	5	*	*	*	*		
PAOZZ	5960-503-4880	ELECTRON TUBE V104 0A2WA (81349)		EA	2	*	*	*	*	4	V104
PAOZZ	5960-503-4880	ELECTRON TUBE V106 0A2WA (81349)		EA	REF	*	*	*	*	4	V106
PAOZZ	5960-166-7648	ELECTRON TUBE V105 0B2 (81349)		EA	1	*	*	*	*	4	V105
PAOZZ	5960-642-8341	ELECTRON TUBE V101 5U4GB (81349)		EA	1	*	*	*	*	4	V101
PAOZZ	5960-166-7661	ELECTRON TUBE V102 6X4 (81349)		EA	2	*	*	*	*	4	V102
PAOZZ	5960-166-7661	ELECTRON TUBE V103 6X4 (81349)		EA	REF	*	*	*	*	4	V103

INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER
CROSS-REFERENCE TO FIGURE AND ITEM NUMBER

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5340-864-3336			5960-188-3602	4	V11
5355-059-9162			5960-262-0015		
5355-284-5886			5960-262-0347		
5355-889-3368			5960-262-1357	4	V2
5355-889-3377			5960-262-1357	4	V8
5960-108-0261	4	V3	5960-262-1357	4	V9
5960-108-0261	4	V5	5960-264-3004		
5960-166-7648	4	V105	5960-295-7652		
5960-166-7661	4	V102	5960-503-4880	4	V104
5960-166-7661	4	V103	5960-503-4880	4	V106
5960-166-7663	4	V1	5960-642-8341	4	V101
5960-166-7667	4	V7	5960-669-6861	4	V6
5960-188-3602	4	V10	5960-879-5078	4	V4

REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.
S0S3	91662			2961	80138		
S0S6	91662			2962	80138		
TS102U03	81349			5U4GB	81349	4	V101
TS103U02	81349			5726	81349	4	V4
0A2WA	81349	4	V104	6AH6	81349	4	V7
0A2WA	81349	4	V106	6AK5	81349	4	V2
0B2	81349	4	V105	6AK5	81349	4	V8
12AU7	81349	4	V1	6AK5	81349	4	V9
1426D	80138			6AQ5	81349	4	V6
1611	73734			6BH6	81349	4	V10
2D21	81349	4	V3	6BH6	81349	4	V11
2D21	81349	4	V5	6X4	81349	4	V102
2300A	72512			6X4	81349	4	V103

By Order of the Secretary of the Army:

CREIGHTON W. ABRAMS
General, *United States Army*
Chief of Staff

Official:

VERNE L. BOWERS
Major General, United States Army
The Adjutant General

Distribution:

Active Army:

USASA (2)	Ft Huachuca (10)
CNGB (1)	WSMR (1)
ACSC-E (2)	Ft Carson (5)
Dir of Trans (1)	Ft Richardson (ECOM Ofc) (2)
COE (1)	Army Dep (1) except
TSG (1)	LBAD (14)
USAARENBD (1)	SAAD (30)
USAMB (10)	TOAD (14)
AMC (1)	ATAD (10)
TRADOC (2)	GENDEP (2)
ARADCOM (2)	Sig Sec GENDEP (2)
ARADCOM Rgn (2)	Sig Dep (2)
OS Maj Comd (4)	Sig FLDMS (1)
LOGCOMDS (3)	USAERDAA (1)
MICOM (2)	USAERDAW (1)
TECOM (2)	MAAG (1)
USACC (4)	USARMIS (1)
MDW (1)	Harry Diamond Labs (2)
Armies (2)	Units org under fol TOE
Corps (2)	(1 cy each):
HISA (18)	11-97
Svc Colleges (1)	11-98
USASCS (10)	11-117
USASESS (20)	11-500(AA-AC)
USAADS (2)	29-41
USAFAS (2)	29-56
USAARMS (2)	29-134
USAIS (2)	29-136
USAES (2)	29-437
USAINTS (3)	29-500
WRAMC (1)	55-405
USACDCEC (10)	55-406
ATS (1)	55-406
Ft Gordon (10)	55-458
	67

NG - USAR: None.

For explanation of abbreviations used, see AR 310-50.

☆U.S. GOVERNMENT PRINTING OFFICE : 1984 0 - 421-302 (10427)