

# TM 11-6625-820-45

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

---

**GS AND DEPOT MAINTENANCE MANUAL**  
**TEST SET, RADIO AN/ARM-92**



HEADQUARTERS, DEPARTMENT OF THE ARMY

SEPTEMBER 1966

**WARNING**

**Be careful when working on the 115-volt, 400-cps circuit. Serious injury or death may result from contact with this circuit.**

**DON'T TAKE CHANCES!**

**CAUTION**

**Do not make resistance measurements with power applied to the test set. Do not make resistance measurements that would place the ohmmeter across a microampere meter in the test set.**

CHANGE }  
No. 2 }

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D. C., 21 January 1972

**General Support and Depot Maintenance Manual  
Including Repair Parts and Special Tool Lists  
TEST SETS, RADIO AN/ARM-92 AND AN/ARM-92A**

TM 11-6625-820-45, 22 September 1966, is changed as follows:

1. Remove and insert pages as indicated below.

<i>Insert pages</i>	<i>Remove pages</i>
i and ii	i and ii
1-1 and 1-2	1-1 and 1-2
	1-2.1 and 1-2.2
1-3 and 1-4	1-3 and 1-4
	1-4.1 (1.4.2 blank)
1-5 through 1-8	1-5 through 1-8
2-1 through 2-4	2-1 through 2-4
	2-4.1 and 2-4-2
2-5 and 2-6	2-5 and 2-6
	2-6.1 and 2-6.2
2-11 and 2-12	2-11 and 2-12
2-17 through 2-20	2-17 through 2-22
3-1 through 3-6	3-1 through 3-8
4-1 and 4-2	4-1 and 4-2
	4-2.1 (4-2.2 blank)
4-3 and 4-4	4-3 and 4-4
4-7 and 4-8	4-7 and 4-8
4-11 through 4-14	4-11 through 4-14
4-15 through 4-24	4-15 through 4-24
	4-24.1/(4.24.2 blank)
	Figure 4-9.1 (Sheet 1 of 2)
	Figure 4-9.1 (Sheet 2 of 2)
Appendix A-1 and A-2	Appendix A-1 and A-2
Index I-1 and I-2	Index I-1 and I-2

2. File this change sheet in front of the manual for future reference.



CHANGE

No. 1



HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 3 December 1968

**G5 and Depot Maintenance Manual**  
**Including Repair Parts and Special Tools List**  
**TEST SET, RADIO AN/ARM-92**

TM 11-6625-820-45, 22 September 1966, is changed as follows:

1. The title of the manual is changed as shown above.
2. Remove old pages and insert new pages as indicated below.

Remove pages  
1-1 and 1-2  
A-1

Insert pages  
1-1 and 1-2  
A-1  
B-1 through B-38

3. File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

W. C. WESTMORELAND,  
*General, United States Army,*  
*Chief of Staff.*

Official:

KENNETH G. WICKHAM,  
*Major General, United States Army,*  
*The Adjutant General.*

Distribution:

To be distributed in accordance with DA Form 12-36 (Unclassified) requirements for Direct and General Support Maintenance Literature for the OV-1A, OV-1B, OV-1C, U-8F, U-10A, CH-47A, UH-1B, UH-1D and OH-6A Aircrafts.

★ U.S. GOVERNMENT PRINTING OFFICE: 1968-344430/605

---

\* This change supersedes TM 11-6625-820-25P, 7 April 1966.



TECHNICAL MANUAL }  
 No. 11-6625-820-45 }

HEADQUARTERS,  
 DEPARTMENT OF THE ARMY  
 WASHINGTON, D.C., 22 September 1966.

GS AND DEPOT MAINTENANCE MANUAL

TEST SETS, RADIO AN/ARM-92 AND AN/ARM-92A

	Paragraph	Page
CHAPTER I. FUNCTIONING		
SECTION I. General functioning of Test Sets, Radio AN/ARM-92 and AN/ARM-92A_	1-1, 1-2	1-1,1-1
II. Detailed circuit functioning -----	1-3--1-8	1-3--1-6
CHAPTER 2. TROUBLESHOOTING		
SECTION I. General troubleshooting techniques -----	2-1--2-3	2-1--2-2
II. Troubleshooting procedures -----	2-4--2-9	2-2--2-21
CHAPTER 3. REPAIR AND ALIGNMENT		
SECTION I. Repairs -----	3-1--3-6	3-1--3-5
II. Alignment -----	3-7--3-12	3-5--3-8
CHAPTER 4. GENERAL SUPPORT TESTING PROCEDURES AND DEPOT OVERHAUL STANDARDS -----	4-1--4-16	4-1--4-22 A-1
APPENDIX. REFERENCES -----		I-1
INDEX -----		I-1

\*This manual supersedes TM 11-6625-820-45, 15 February 1966.





## CHAPTER 1

### FUNCTIONING

#### Section I. GENERAL FUNCTIONING OF TEST SETS, RADIO AN/ARM-92 AND AN/ARM-92A

##### 1-1. Scope

*a. General.* This manual contains general support and depot maintenance instructions for Test Sets, Radio AN/ARM-92 and AN/ARM-92A. It includes instructions appropriate to these categories of maintenance for troubleshooting, testing, aligning, and repairing the equipment. The manual also lists tools, materials, and test equipment for maintenance. Detailed functions of the equipment are also covered.

*b. Reporting of Equipment Manual Improvements.* The direct reporting of errors, omissions, and recommendations for improving this equipment manual by the individual user is authorized and encouraged. DA Form 2028 (Recommended Changes to DA Publications) will be used for reporting these improvements. This form may be completed using pencil, pen, or typewriter and forwarded direct to Commanding General, U. S. Army Electronics Command, ATTN: AMSEL-MR-NMP-AD, Fort Monmouth, N. J. 07703.

*Note:* For other applicable forms and records, see paragraph 1-3, TM 11-6625-820-12.


*c. Index of Equipment Publication.* Refer to the latest issue of DA Pam 310-4 to determine whether there are new editions, changes or additional publications pertaining to the equipment. DA Pam 310-4 is a current index of technical bulletins, supply bulletins, lubrication orders, and modification work orders available through publications channels. The index lists the individual parts (-10, -20, -35P, etc) and the latest changes and revisions of each equipment publications.

##### 1-2. Block Diagram Functioning of Test Set, Radio AN/ARM-92

*a. General.* Test Set Radio, AN/ARM-92 provides for the complete testing of Radio Receiving Set AN/ARN-82 (receiving set) when used with external test equipment. The test set can also be used to test a glide-slope receiver, and provides for flag and deviation loading. The glide-slope test requires a special cable that is not supplied with this unit. The functions of Test Set, Radio AN/ARM-92 are:

- (1) Power distribution.
- (2) Phase shifting.
- (3) Current measuring.
- (4) Compass simulation.
- (5) Self-test of control unit and functions of the test set.

*b. Power Distribution Circuits.* Control, Radio Set C-6873/ARM-82 (control unit), power relay K1, and power transformer T1 comprise the power distribution circuits. The test set connects 27.5 volts direct current (dc) from an external power source to the control unit which applies or removes the 27.5 volts dc from the remaining power circuits. When the control unit applies this voltage to the remaining power circuits, 27.5 volts dc is applied to Radio Receiver R-1388/ARN-82 (radio receiver), or to the glide-slope receiver, and to power relay K1. The relay then energizes and connects 115 volts, 400 cycles per second (cps) to power transformer T1. Transformer T1 steps the voltage down to 26 volts, 400 cps, which is applied to the radio receiver. The control unit also supplies the tuning information required by the radio receiver, or the glide-slope receiver.



TM6625-820-45-A

Figure 1-1. Test Set, Radio AN/ARM-92, block diagram.

c. *Phase Shifting Circuits.* The phase shifting circuits (comprised of precision bearing transformer T2; Indicator, Course ID-1347/ARN-82, OBS (omni bearing switch) indicator; BEARING switch S3; and BRG-OBS switch S2) are used to shift the phase of the

30-cycle reference signal obtained from the radio receiver. Either the OBS resolver or precision bearing transformer T2 performs the phase shifting, and BRG-OBS switch S2 selects the one to be used. The OBS resolver shifts the phase of the 30-cycle reference signal

anywhere from 0 to 360°, but precision bearing transformer T2 shifts the phase of the signal in precise 30° increments. The exact 30° increment is selected by BEARING switch S3.

*d. Current Measuring Circuits.* TO-FROM meter M3 connects directly to the radio receiver and measures its to-from current. DEVIATION meter M1 and FLAG meter M2 are connected either to the radio receiver or to the glide-slope receiver, depending on the position of VOR/LOC-GLIDE SLOPE switch S1. These two meters measure the deviation current and flag current from either receiver. The FLAG meter also measures the output of the RMI servoamplifier in the radio receiver. When SERVO AMP TEST pushbutton switch S4 is pressed, it connects 27.5 volts dc to the RMI servoamplifier and to flag meter relay K2. The flag meter relay energizes and connects FLAG meter M2 to the RMI servoamplifier output of the radio receiver.

*e. Compass Simulator Circuit.* COMPASS SIMULATOR DS4 simulates a magnetic heading signal which is applied to the radio receiver. The simulated magnetic heading signal is also applied to Indicator, RMI ID-250A/ARN on the test set to drive the RMI card.

*f. Aid Box.* The aid box checks the wiring harness in an aircraft installation of Radio Receiving Set AN/ARN-82, and checks the control unit installed in the test set or aircraft. It also provides a quick check of the accuracy of the meters in the test set. The aid box receives frequency information from the control unit in the test set or aircraft. This frequency information lights the lamps on the aid box in specific combinations. The aid box also receives 26 volts, 400 cps from the test set or from the aircraft. A portion of this voltage is rectified, and then divided to specific levels. Specific levels of dc voltage are applied to the meter circuits in the test set or to the aircraft indicators. A portion of the 26 volts, 400 cps is also used to check the audio wiring.

### **1-2.1. Block Diagram Functioning of Test Set, Radio AN/ARM-92A (fig 1-1.1)**

*a. General.* Test Set Radio, AN/ARM-92A provides for the complete testing of Radio

Receiving Sets AN/ARN-82 and AN/ARN-82A (receiving set) when used with external test equipment. The test set can also be used to test a glide-slope receiver, and provides for flag and deviation loading. The glide-slope test requires a special cable that is not supplied with this unit. The functions of Test Set, Radio AN/ARM-92A are:

- (1) Power distribution.
- (2) Phase shifting.
- (3) Resolver signal transmission.
- (4) Current measuring.
- (5) Compass simulation.
- (6) Self-test of control unit and functions of the test set.

*b. Power Distribution Circuits.* Control, Radio Set C-6873/ARM-82 (control unit), power relay K1, and power transformer T1 comprise the power distribution circuits. The test set connects 27.5 volts direct current (dc) from an external power source to the control unit which applies or removes the 27.5 volts dc from the remaining power circuits. When the control unit applies this voltage to the remaining power circuits, 27.5 volts dc is applied to Radio Receiver R-1388/ARN-82 (radio receiver), or to the glide-slope receiver, and to power relay K1. The relay then energizes and connects 115 volts, 400 Hz to power transformer T1. Transformer T1 steps the voltage down to 26 volts, 400 Hz, which is applied to the radio receiver. The control unit also supplies the tuning information required by the radio receiver, or the glide-slope receiver.

*c. Phase Shifting Circuits.* The phase shifting circuits (consists of precision bearing transformers T2 and T3; Indicator, Course ID-1347/ARN-82 (OBS); RECEIVER MODEL switch S5; BEARING switch S3; and BRG-OBS switch S2. These circuits are used to shift the phase of the 30-Hz reference signal obtained from Radio Receiver R-1388/ARN-82. Either the OBS resolver or precision bearing transformer T2 performs the phase shifting; BRG-OBS switch S2 selects the one to be used. The OBS resolver shifts the phase of the 30-Hz reference signal anywhere from 0 to 360°, precision bearing transformer T2 shifts the phase of the signal in precise 30° increments. The




Figure 1-1.1. Test Set, Radio AN/ARM-92A, block diagram.

1-2.2 Change 2

exact 30° increment is selected by BEARING switch S3. RECEIVER MODEL switch S5 removes transformer T3 from the circuit and adjusts the remaining circuits for phase shifting.

*d. Resolver Transmitter Circuit.* The resolver transmitter circuit consists of precision bearing transformers T2 and T3; Indicator, Course ID-1347A/ARN-82 (OBS); RECEIVER MODEL switch S5; BEARING switch S3; and BRG-OBS switch S2. This circuit supplies 400-Hz bearing information to Radio Receiver R-1388A/ARN-82. BRG-OBS switch S2 selects either the OBS resolver or the simulated resolver comprised of transformers T2 and T3. RECEIVER MODEL switch S5 connects transformers T2 and T3 to form a simulated resolver and switches the input to 400-Hz input. BEARING switch S3 selects the 30° increment equivalent to the OBS resolver position.

*e. Current Measuring Circuits.* TO-FROM meter M3 connects directly to the radio receiver and measures its to-from current. DEVIATION meter M1 and FLAG meter M2 are connected either to the radio receiver or to the glide-slope receiver, depending on the position of VOR/LOC-GLIDE SLOPE switch S1. These two meters measure the deviation current and flag current from either receiver. The FLAG meter also measures the output of the RMI servoamplifier in the radio receiver. When SERVO

AMP TEST pushbutton switch S4 is pressed, it connects 27.5 volts dc to the RMI servoamplifier and to flag meter relay K2. The flag meter relay energizes and connects FLAG meter M2 to the RMI servoamplifier output of the radio receiver.

*f. Compass Simulator Circuit.* COMPASS SIMULATOR DS4 simulates a magnetic heading signal that is applied to the radio receiver. The simulated magnetic heading signal is also applied to Indicator, RMI ID-250A/ARN on the test set to drive the RMI card.

*g. Aid Box.* The aid box checks the wiring harness in an aircraft installation of Radio Receiving Set AN/ARN-82 or AN/ARN-82A and checks the control unit installed in the test set or aircraft. It also provides a quick check of the accuracy of the meters in the test set. The aid box receives frequency information from the control unit in the test set or aircraft. This frequency information lights the lamps on the aid box in specific combinations. The aid box also receives 26 volts, 400 Hz from the test set or from the aircraft. A portion of this voltage is rectified, and then divided to specific levels. Specific levels of dc voltage are applied to the meter circuits in the test set or to the aircraft indicators. A portion of the 26 volts, 400 Hz is also used to check the audio wiring.

## Section II. DETAILED CIRCUIT FUNCTIONING

### 1-3. Power Distribution Circuits

The test set supplies all the necessary power connections for the operation of Radio Receivers R-1388/ARN-82 or R-1388A/ARN-82 or a glide-slope receiver. The operation of these power circuits is described below. Refer to test set schematic diagram (fig. 4-9 or 4-9.1) while reading the description in *a*, *b*, and *c* below.

*a.* The external sources of power are connected to J5 by Cable Assembly, Power, Electrical CX-11568/ARM-92 (power cable)

(fig. 1-2). The 27.5 volts dc is applied between pins A and B, the positive side to pin A, ground to pin B. The 115 volts, 400 cps is applied with the low side to pin C and the high side to pin D. The connection from pin A of J5 is made through fuse F1 to pin Z of connector P5 of the control unit (fig. 4-9). When the control unit power switch is in the PWR or TEST position, the 27.5-volt dc circuit is completed in pin M or H of P5. The 27.5 volts is then routed to TB1, tie point 18. From tie point 18, the voltage is routed to relay K1. This voltage energizes the relay K1, and the cir-




Figure 1-2. Cable Assembly, Power, Electrical CX-11568/ARM-92, schematic diagram.

cuits is completed for the 115 volts, 400 cps from pin D of J5 through fuse F3 to transformer T1. Transformer T1 steps down the 115 (volts, 400 cps to 26 volts, 400 cps. The 26 volts, 400 cps is routed to RMI connector P4, the compass simulator connector P1, and to connector P3 of the radio receiver. The RMI servoamplifier input is supplied with 26 volts, 400 cps from transformer T1 through resistors R6 and R7.

b. From tie point 18 of TB1, the 27.5 volts dc is routed to connector P2 of the radio receiver, and also through fuse F2 to connector J4 of the glide-slope receiver.

c. Tuning information from the control unit is routed to TB1, and branches off to both connectors P2 and J4, For further information on the control unit, refer to TM 11-5826-226-35 for Radio Receiving Set AN/ARN-82. A schematic diagram of the control unit is in figure 4-10.

#### 1-4. Phase Shifting Circuits


(fig. 4-9 and 4-9.1 )

In the test set the two circuits that shift the phase of the 30-cycle reference signal are the OBS resolver and precision bearing transformer T2. Their operation is described below. In Test Set, Radio TS-2500A/ARM-92, RECEIVER MODEL switch S5 disables precision bearing transformer T3 and adjusts the circuit of transformer T2 whenever

the phase shifting mode is needed (switch position A).

a. BRG-OBS switch S2 determines which phase shifting circuit is used. When switch S2 is in the OBS position, the OBS resolver is used to produce the desired phase shift. The OBS indicator is the same type as used in an aircraft installation. The 30-cycle reference signal is applied to the rotor of the resolver in the OBS indicator. When the rotor is turned, the phase of the signal at stator output is shifted. A compass card is attached to the rotor, providing an indication of the number of degrees of phase shift. This voltage is routed to the radio receiver. For more information on the OBS indicator, refer to TM 11-5826-226-35 for Radio Receiving Sets AN/ARN-82 and AN/ARN-82A. A schematic diagram of the OBS indicator is shown in figure 1-3.

b. A resolver has the same electrical characteristics as a transformer. Therefore, a transformer can be used to simulate a resolver. When switch S2 is in the BRG position, precision bearing transformer T2 and its switching circuits are used to produce the desired phase shift. The 30-cycle reference signal from the radio receiver is applied through switch S2 to the primary of transformer T2. This primary winding and resistor R3 simulate the rotor of a resolver. The phase shift through the secondary winding of the transformer must be the same as the phase shift in the stator windings of the resolver. This phase shift through transformer T2 is adjusted to 83° at a dial setting of 300° by the loading on the tertiary winding. The design of the transformer is such that the phase shift it produces is stable with variations in alternating current (ac) or direct current through the primary winding. The combination of the precisely tapped secondary windings of transformer T2 and the switching arrangement (S3) produces the various voltage ratios that correspond to the stator output of a standard resolver. Each clockwise position of switch S3 simulates a clockwise rotation of a resolver rotor in precise 30° increments. With switch S2 in the BRG position, the output voltage path from transformer T2 is through switch S3, through switch S5 in Test Set, Radio TS-2500A/ARM-92, through switch S2,



TM6625-820-45-16

Figure 1-3. Indicator, Course ID-1347/ARN-82 or ID-1347A/ARN-82, schematic diagram.

and out to the radio receiver through pins F and D of connector P2. In Test Set, Radio TS-2500A/ARM-92, terminals 8 and 9 (stators E and G) of transformer T2 are common and connect to E of P6 and E of P2. In Test Set, Radio TS-2500A/ARM-92, stators E and G connect to P2, pins E and G, through switches S3, S5, and S2.

**1-4.1. Resolver Transmitter Circuit**

(Contained in Test Set, Radio TS-2500A/ARM-92 only, fig. 4-9.1. )

Radio Receiver R-1388A/ARN-82 requires 400-Hz resolver signals to derive course deviation and to-from outputs. The

test set produces these signals either by energizing the OBS resolver or by energizing the precision bearing transformers.

a. BRG-OBS switch S2 determines which resolver circuit is used. When switch S2 is in the OBS position, the OBS resolver is used to produce the desired course. The OBS indicator is the same type as used in an aircraft installation. The 400-Hz reference signal is applied to the rotor of the resolver in the OBS indicator. When the rotor is turned, the voltage of the signal at stator output is varied. A compass card is attached to the rotor, providing an indication of the course selected. The voltage is routed to the radio receiver. For more information on the OBS indicator, refer to TM 11-5826-





226-35 for Radio Receiving Sets AN/ARN-82 and AN/ARN-82A. A schematic diagram of the OBS indicator is shown in figure 1-3.

*b.* A resolver has the same electrical characteristics as a transformer. Therefore, a transformer can be used to simulate a resolver. When switch S2 is in the BRG position and RECEIVER MODEL switch S5 is in the B position, precision bearing transformers T2 and T3 and their switching circuits are used to produce the desired stator voltages. The 400-Hz reference signal from the radio receiver is applied through switches S2, S5, and S3 to the primaries of transformers T2 and T3. These primary windings simulate the rotor of a resolver.

The combination of the precisely tapped secondary windings of transformers T2 and T3 and the switching arrangement (S3) produces the various voltage ratios that correspond to the stator output of a standard resolver. Each clockwise position of switch S3 simulates a clockwise rotation of a resolver rotor in precise 30° increments. With switch S2 in the BRG position, the output voltage path from transformers T2 and T3 is through switches S5 and S2 to the radio receiver on pins D, E, F, and G of connector P2.

### 1-5. Current Measuring Circuits

(fig. 4-9 and 4-9.1)

The outputs of four circuits in the radio receiver are measured in the test set. These measuring circuits are described below.

*a.* To-from current from the radio receiver is read on meter M3. TO-FROM meter M3 indicates the direction and amplitude of the current. Resistor R8 is a shunt resistor to extend the range of the meter.

*b.* Deviation current from either the radio receiver or the glide-slope receiver is read on meter M1. With the switch S1 in the VOR/LOC position, pins P, B, and M of connector P2 connect through switch S1 to the DEVIATION meter. The return path from meter M1 is through switch S1 back to connector P2. When switch S1 is in the GLIDE SLOPE position, meter M1 connects through switch S1 to pin T

of GLIDE SLOPE connector J4. The completed path of meter M1 is through switch S1 to pin V of J4.

*c.* Flag current from either the radio receiver or the glide-slope receiver is read on FLAG meter M2. When switch S1 is in the VOR/LOC (very high-frequency omni-directional radio range/localizer) position, meter M2 is connected through switch S1 to pin b of P2 by the contacts of relay K2. The completed path from the meter is through the other set of contacts of relay K2, through switch S1 to pins c and a of P2. With the switch S1 in the GLIDE SLOPE position, meter M2 is connected to pin v of J4 by switch S1 through the contacts of relay K2. The completed path of meter M2 is through the other contacts of relay K2, through switch S1 to pin J on J4. FLAG meter M2 can also be used to measure the output current of the RMI servoamplifier in the radio receiver. When the SERVO AMP TEST switch S4 is pressed, 27.5 volts dc from tie point 18 of TB1 is routed to the RMI (radio magnetic indicator) servoamplifier of the radio receiver and relay K2. When relay K2 is energized, FLAG meter M2 is placed across RMI servoamplifier load resistor R5. Resistor R4 is a current-limiting resistor and diode CR1 rectifies the RMI servoamplifier output current that is applied to meter M2. Diode CR2 is used to short out any voltage caused by the collapsing field of relay K2 when switch S4 is opened.

### 1-6. Compass Simulator Circuits

(fig. 4-9 and 4-9.1)

The COMPASS SIMULATOR indicator contains a synchro transmitter of the same type used with the compass in an aircraft installation. As the dial is turned, the synchro generates a varying voltage from the 26 volts, 400 Hz that is applied to the COMPASS SIMULATOR indicator. The output voltage from the synchro transmitter is routed to the radio receiver and the RMI card to simulate a magnetic heading. The pointer simulates the pointer of the compass in the aircraft.

### 1-7. RMI Circuits

The RMI card gives an indication of simulated magnetic heading. The simulated magnetic

heading signal originates in the compass simulator, and is routed to the RMI card. The RMI needles give an indication of the direction of a very high-frequency omnirange (vor) station. In the test set, two needles are electrically jumpered together. This makes the two needles track together. The vor signals are routed from the radio receiver to the needle connections on P4. If the RMI card rotates to indicate a magnetic heading, the needles will follow the card rotation to keep in the direction of the vor station. For more information on the RMI refer to TM 11-5826-211-50 for Indicator, Course ID-250A/ARN. The RMI is shown in figure 1-4.

**1-8. Aid Box**  
(fig. 1-5)

The aid box is primarily intended for testing a new AN/ARN-82 or AN/ARN-82A installation wiring harness, but it can be used for a quick check on the test set. The main circuits are as follows:

*a. Light Circuitry.* The light circuitry is provided to indicated when a circuit is made complete or when it is energized. Frequency control information is given in a code by the lamps. The lamps that check the power circuits glow when a current flows through them, indicating an energized circuit.

*b. Meter Circuitry.* The 26 volts, 400 cps is applied to pin G of J1 and is routed to Zener diode CR1. Resistor R8 and Zener diode CR1 form the 10-volt dc power supply for the meter circuits. Resistor R6 is a current-limiting resistor for the TO-FROM meter. Resistor R5 is a current-limiting resistor for the DEVIATION meter. Resistor R3 (a 511-ohm load) and resistor R4 (a 1,000-ohm load) are the loading resistors for the DEVIATION meter. Resistor





Figure 1-4. Indicator, Course ID-250A/ARN, schematic diagram.

R2 is the current-limiting resistor for the FLAG meter, and resistor R1 is a 1,000-ohm load for the FLAG meter.



*c. Audio Circuit.* Resistor R7 drops the 26 volts, 400 cps to the voltage level desired, and this 400-cycle tone is fed to pin L of J2.

*d. Compass RMI circuit.* The signal from the compass simulator at pins C and D of J1 is connected to the RMI needle circuit through pins H and K of J1. This makes needle number 1 (needle number 2 is not used) of the RMI follow the rotation of the RMI card when the aid box is used to check the test set.



- NOTES:**
1. UNLESS OTHERWISE INDICATED, RESISTANCES ARE IN OHMS.
  2. INDICATES EQUIPMENT MARKINGS.
  3. NONSTANDARD ABBREVIATION:  
LOC-LOCALIZER
  4. RECEPTICAL VIEWED FROM PIN OR RECEPTICAL SIDE.

J2  
CONNECTS TO  
P2 OF RADIO  
TEST SET



J1  
CONNECTS TO  
P3 OF RADIO  
TEST SET

TM6625-820-45-2

Figure 1-5. Test Set, Wiring Harness, Aircraft TS-2501/ARM-92, schematic diagram.



## CHAPTER 2

### TROUBLESHOOTING

---

#### Section I. GENERAL TROUBLESHOOTING TECHNIQUES

**Warning:** Be careful when working on the 115-volt, 400-cps circuit. Serious injury or death may result from contact with this circuit.

##### 2-1. General

The general support and depot maintenance procedures in this manual supplement the procedures in the organizational maintenance manual. The systematic troubleshooting procedure, which begins with the operational and sectionalization checks that can be performed at an organizational category, is carried to a higher category in this manual. Sectionalizing, localizing, and isolating techniques used in the troubleshooting procedures are more advanced.

##### 2-2. Organization of Troubleshooting Procedures

*a. General.* The first step in servicing a malfunctioning test set is to sectionalize the fault. Sectionalization means tracing the fault to a unit or circuit. The second step is to localize the fault. Localization means tracing the fault to a defective part responsible for the abnormal condition. Some faults, such as burned-out resistors and arcing and shorted transformers can often be located by sight, smell, and hearing. The majority of faults, however, must be isolated by checking voltages and resistance.

*b. Sectionalization.* Listed below is a group of tests arranged to reduce unnecessary work and to aid in tracing trouble in a malfunctioning test set. Test Sets, Radio AN/ARM-92 and AN/ARM-92A consist of five units; the test set, the control unit, the RMI the OBS indicator and the aid box. The first step is

to locate the unit or units at fault by the following methods:

- (1) *Visual inspection.* The purpose of visual inspection is to locate faults without testing or measuring circuits. Indications on the RMI meters, or other visual signs should be observed during all operating modes, and an attempt should be made to sectionalize the fault to a particular unit.
- (2) *Operational tests.* Operational tests frequently indicate the general location of trouble. In many instances, the tests will help in determining the exact nature of the fault. The intermediate preventive maintenance checks and services chart (TM 11-6625-820-12) contains a list of operational checks which helps to sectionalize troubles to a unit.

*c. Localization.* After the trouble has been sectionalized (b above), the methods listed below will aid in localizing the trouble to a circuit in the suspected unit. See the troubleshooting chart for help in finding the trouble. RMI and meter indications or lack of indications and operational checks provides a systematic method of localizing trouble to a circuit. The procedures provided in the troubleshooting charts (para 2-5 through 2-9) will provide additional information for localizing trouble.

*d. Isolation.* After the trouble has been localized (c above), the methods in (1) through (4) below will help in isolating the trouble to a defective circuit element.

- (1) *Resistance measurements.* Resistance measurements are used to

check for continuity and to check the value of resistance in a circuit. For these checks, use Multimeter ME-26 (\*) /U, or equivalent.

**Caution:** Be sure that the multimeter is not placed across a meter in the test set. The current from the ohmmeter might damage the micro-ampere movement of a meter of the test set.

- (2) *Voltage measurements.* Voltage measurements are used to check to see if the proper amount of voltage is being routed through the test set and aid box. For these measurements, use Multimeter ME-26(\*)/U, or equivalent.
- (3) *Intermittent troubles.* In all these tests, the possibility of intermittent troubles should not be overlooked. If present, this type of trouble may often be made to appear by tapping or jarring the equipment. Make a visual in-

spection of the wiring and connections.

- (4) *Resistor color code.* The resistor color code diagram (fig. 4-8) is provided to aid maintenance personnel in determining the value and tolerance of resistors.

**2-3. Test Equipment Required**

The following chart lists equipment required for troubleshooting Test Set, Radio AN/ARM-92 or AN/ARM-92A. It also lists the associated technical manuals.

a. Make test equipment connections with care so that shorts will not be caused by exposed test equipment connectors. Tape or sleeve (spaghetti) test prods or clips as necessary to leave as little exposed metal as needed to make contact to the circuit under test.

b. Observe polarity; a negative ground is required on the 27.5-volt dc line. The low side of the ac line is also grounded.

c. The following test equipment is required:

Test Equipment	Technical manual	Common name
Modulator MD-83A/ARN Output Meter TS-585(*)/U <sup>a</sup> Multimeter ME-26(*)/U <sup>b</sup> Oscilloscope AN/USM-140A Voltmeter, Meter ME-30A/U and Voltmeters, Electronic ME-30(*)/U <sup>c</sup> Test Set, Resolver AN/ASM-101 Test Set, Indicator Course AN/ASM-110 Meter Test Set TS-682A/GSM-1 Bridge, Resolver, Gertsch model RB-4C-4R; Singer Company, Los Angeles, California	TM 11-6625-588-15 TM 11-5017 TM 11-6625-200-12 TM 11-6625-535-15 TM 11-6625-320-12  TM 11-6625-492-12  TM 11-2535B	Vor modulator Output meter Multimeter Oscilloscope Vtvm  Resolver test set Indicator test set Meter calibrator Resolver bridge

a Indicates Output Meters TS-585A/U, TS-585B/U, TS-585C/U, and Audio Level Meter TS-585D/U.

b Indicates Multimeter ME-26A/U, ME-26B/U, and ME-26C/U.

c Indicates Voltmeter, Meter ME-30A/U and Voltmeters, Electronic ME-30B/U and ME-30C/U.

**Section II. TROUBLESHOOTING PROCEDURES**

**2-4. General**

The troubleshooting procedures are divided into two parts. The first part (paras 2-5 and 2-6) gives procedures to troubleshoot the aid box. The second part (paras 2-7 through 2-9) gives procedures to troubleshoot the control unit, the RMI the OBS indicator, and the test set.

2-2 Change 2

**2-5. Troubleshooting Aid Box**

Because of the simplicity of the aid box circuitry, any trouble may be quickly isolated by the following checks:

- a. Remove the bottom of the aid box by removing the six screws on the bottom of the aid box.

b. Connect P2 and P3 of the test set to the aid box.

c. Connect the test set to a 27.5 volt dc power source, and a 115-volt, 400-cps power source.

d. Set the power switch on the control unit to PWR.

e. Connect the dc lead of the multimeter to the junction of Zener diode CR1 and resistor R8. Connect the COMMON lead to the anode of Zener diode CR1.

f. The multimeter should indicate 10 volts dc  $\pm 0.05$ . If the indication is improper, replace the defective Zener diode CR1.

g. All other circuits in the aid box may be checked by using the resistance chart in paragraph 2-6. Remove all equipment connected to the aid box before attempting resistance measurements. When an improper resistance reading is obtained, refer to the schematic diagram in figure 1-5 to isolate the trouble.

**2-6. Resistance Chart for Aid Box**

Multimeter connection		Proper indication (ohms)
From	To	
A of J2	a of J2	22,900 $\pm$ 2,290
J of J2	X of J2	0
J of J2	n of J2	0
J of J2	Y of J2	0
J of J2	b of J2	0
J of J2	C of J2	1,000 $\pm$ 100
J of J2	B of J2	511 $\pm$ 51
J of J2	P of J2	1,000 $\pm$ 100
J of J2	N of J2	0
J of J2	E of J2	0
A of J2	m of J2	36,500 $\pm$ 3,650
A of J2	Z of J2	42,500 $\pm$ 4,250
L of J2	G of J1	1,500 $\pm$ 160
D of J1	H of J1	0
C of J1	K of J1	0
A of J2	t of J2	160 $\pm$ 20
A of J2	k of J2	160 $\pm$ 20
A of J2	p of J2	160 $\pm$ 20
A of J2	f of J2	160 $\pm$ 20

Multimeter connection		Proper indication (ohms)
From	To	
A of J2	W of J2	160 $\pm$ 20
A of J2	g of J2	160 $\pm$ 20
A of J2	V of J2	160 $\pm$ 20
A of J2	h of J2	160 $\pm$ 20
A of J2	U of J2	160 $\pm$ 20
A of J2	i of J2	160 $\pm$ 20
A of J2	T of J2	160 $\pm$ 20
A of J2	j of J2	160 $\pm$ 20
A of J2	S of J2	160 $\pm$ 20
A of J2	X of J2	160 $\pm$ 20
R of J2	X of J2	160 $\pm$ 20
K of J2	X of J2	160 $\pm$ 20
G of J1	E of J1	160 $\pm$ 20

**2-7. Troubleshooting Control Unit, RMI OBS Indicator, and Test Set**

a. Perform the general support testing procedures for the aid box in paragraph 4-7. If the general support testing procedures indicate trouble, perform the troubleshooting procedures described in paragraph 2-5.

b. Connect the test set to the aid box and external power as shown in figure 2-1.

c. Set the power switch on the test set control unit to OFF.

d. Set the VOR/LOC-GLIDE SLOPE switch on the test set to VOR/LOC. (All other switches and controls may be set in any position.)

e. Perform the procedures in the troubleshooting chart in paragraph 2-8. This chart gives various operational procedures for the test set. The proper indication for each operational procedure is then given. If the equipment produces an improper indication, the chart lists the probable trouble and, in the *Correction* column, suggests how to isolate the trouble.






Figure 9-1. Equipment setup to test control unit, RMI OBS indicator, and test set.






TM6625-820-45-12

Figure 2-2. Test Set, Radio TS-2500/ARM-92, front panel.




EL6625-820-45-C1-TM-32

Figure 2-2.1 Test Set, Radio TS-2500A/ARM-92, front panel.



*Figure 2-3. Rear side of Test Set, Radio TS-2500/ARM-92, front panel.*



6L8825-820-45-C1-TM-29

Figure 2-3.1 Rear side of Test Set, Radio TS-2500A/ARM-92, front panel.




Figure 2-4. Bottom view of Test Set, Radio TS-2500/ARM-92, front panel.




Figure 2-4.1 Bottom view of Test Set, Radio TS-2500A/ARM-92, front panel.






Figure 2-5. Terminal board number 2 (TB2).



TM6625-820-45-13

Figure 2-6. Aid box, front panel.



TM6625-820-45-11

Figure 2-7. Parts location of aid box.






Figure 2-8. Power cable.

## 2-8. Troubleshooting Chart

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
1	Connect the multimeter to the test point located in the center of the VOR/LOC 2A fuse cap.	The multimeter should indicate 27.5 volts dc.	VOR/LOC 2A fuse (F1) is blown.	Replace F1 with a 2-ampere fuse.
2	Set the megacycle and kilocycle selectors on the control unit to 108.00. Set the power switch on the control unit to PWR.	<p>The following lamps should light:</p> <p>a. The LOC PWR lamp on the aid box.</p> <p>b. The VOR/LOC DC lamp on the test set.</p> <p>c. The 26 VAC PWR lamp on the aid box.</p> <p>d. The VOR/LOC AC lamp on the test set.</p> <p>e. The GS DC lamp on the test set.</p>	<p>a. If the LOC PWR lamp on the aid box does not light, either a break in the circuit is present between M of P5 and A of P2, or switch S6A in the control unit is defective.</p> <p>b. If the VOR/LOC DC lamp on the test set does not light, DS1 is faulty.</p> <p>c. If the 26 VAC PWR lamp on the aid box does not light, VOR/LOC 1A fuse is brown, relay K1 is defective, or transformer T1 is defective.</p> <p>d. If the VOR/LOC AC lamp on the test set does not light, DS3 is faulty.</p> <p>e. If the GS DC lamp on the test set does not light, either GS 1A fuse (F2) is blown or GS DC lamp (DS2) is burned out.</p>	<p>a. If a break in the circuit is present between M of P5 and A of P2, make resistance measurements to find the break. If no breaks are present, troubleshoot the control unit as described in TM 11-5826-226-35.</p> <p>b. Replace DS1.</p> <p>c. Measure the ac voltage at the test point located at the center of the VOR/LOC 1A fusecap. If 26 volts ac is not present, replace fuse F3. If 26 volts ac is present, check for a defective relay K1 by measuring its coil resistance (para 2-9). If defective, replace relay K1. Check for a defective transformer by measuring its resistances (para 2-9). Replace if defective.</p> <p>d. Replace DS3.</p> <p>e. Measure the dc voltage at the test point located at the center of the GS 1A fusecap. If 27.5 volts dc is not present, replace fuse F2. If 27.5 volts dc is present, replace lamp DS2.</p>

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
		<p><i>f.</i> The 1.0 FREQ SELECT (MC) lamp A on the aid box.</p> <p><i>g.</i> The 1.0 FREQ SELECT (MC) lamp D on the aid box.</p> <p><i>h.</i> The 0.1 FREQ SELECT (MC) lamp B on the aid box.</p> <p><i>i.</i> The 0.1 FREQ SELECT (MC) lamp E on the aid box.</p> <p><i>j.</i> The 0.01 FREQ SELECT (MC) lamp B on the aid box.</p> <p><i>k.</i> The FLAG meter should indicate 250 microamperes <math>\pm 15.0</math>.</p> <p><i>l.</i> The DEVIATION meter should indicate 75 microamperes <math>\pm 5.0</math> to the right of 0.</p>	<p><i>f.</i> If 1.0 FREQ SELECT (MC) lamp A does not light, either a break in the circuit is present between W of P2 and V of P5, or the megacycle selector in the control unit is defective.</p> <p><i>g.</i> If 1.0 FREQ SELECT (MC) lamp D does not light, either a break in the circuit is present between T of P2 and F of P5, or the megacycle selector in the control unit is defective.</p> <p><i>h.</i> If 0.1 FREQ SELECT (MC) lamp B does not light, either a break in the circuit is present between g of P2 and D of P5, or the kilocycle selector in the control unit is defective.</p> <p><i>i.</i> If 0.1 FREQ SELECT (MC) lamp E does not light, either a break in the circuit is present between j of P2 and B of P5, or the kilocycle selector in the control unit is defective.</p> <p><i>j.</i> If 0.01 FREQ SELECT (MC) lamp B does not light, either a break in the circuit is present between p of P2 and g of P5, or the kilocycle selector in the control unit is defective.</p> <p><i>k.</i> If the FLAG meter does not indicate 250 microamperes <math>\pm 15.0</math>, switch S1, relay K2, or FLAG meter M2 is defective.</p> <p><i>l.</i> If the DEVIATION meter does not indicate 75 microamperes <math>\pm 5.0</math> to the right of 0, switch S1 or DEVIATION meter M1 is defective.</p>	<p><i>f.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.</p> <p><i>g.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.</p> <p><i>h.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in T M11-5826-266-35.</p> <p><i>i.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-266-35.</p> <p><i>j.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-266-35.</p> <p><i>k.</i> Refer to figure 4-9 or 4-9.1 and make continuity checks on the circuit comprised of S1, K2, and M2 to isolate the trouble.</p> <p><i>l.</i> Refer to figure 4-9 or 4-9.1 and make continuity checks on the circuit comprised of S1 and M1 to isolate the trouble.</p>

Change 2 2-11

TM 11-6625-820-45

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
		<i>m.</i> The TO-FROM meter should indicate 500 microamperes $\pm 25.0$ to the left of 0.	<i>m.</i> If the TO-FROM meter does not indicate 500 microamperes $\pm 25.0$ to the left of zero, resistor R8 or TO-FROM meter M3 is defective.	<i>m.</i> Disconnect resistor R8 from meter M3, and measure the resistance of R8. If the value of R8 is not between 180 and 220 ohms, replace R8. If the value is between 180 and 220 ohms, replace meter M3.
3	Set the power switch on the control unit to TEST.	The TEST lamp on the aid box should light in addition to the lamps lighted in step 2 above.	Either a break in the circuit is present between t of P2 and L of P5, or switch S6C in the control unit is defective.	If a break in the circuit is present between t of P2 and L of P5, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.
4	Set the power switch on the control unit to PWR. Set the megacycle and kilocycle selectors to 108.05.	<i>Note.</i> The 1.0 FREQ SELECT (MC) lamps A and D should remain lighted in step 4 through 22 below.  The 0.1 FREQ SELECT (MC) lamps B and E should light.	If either one, or both, of the lamps do not light, the kilocycle selector on the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-36.
5	Set the megacycle and kilocycle selectors to 108.10.	The 0.1 FREQ SELECT (MC) lamps A and B should light. The 0.01 FREQ SELECT (MC) lamp B should light. The GS/LOC ON lamp should light.	<i>a.</i> If 0.1 FREQ SELECT (MC) lamp A does not light, either a break in the circuit is present between f of P2 and C of P5, or the kilocycle selector in the control unit is defective.  <i>b.</i> If 0.1 FREQ SELECT (MC) lamp B does not light, the kilocycle selector on the control unit is defective.  <i>c.</i> If GS/LOC ON lamp does not light, either a break in the circuit is present between k of P2 and Y or P5, or the kilocycle selector in the control unit is defective.	<i>a.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.  <i>b.</i> Troubleshoot the control unit as described in TM 11-5826-226-35.  <i>c.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
6	Set the megacycle and kilocycle selectors to 108.15.	The 0.1 FREQ SELECT (MC) lamps A and B should light.	If either one, or both, of the lamps do not light, the kilocycle selector on the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-35.
7	Set the megacycle and kilocycle selectors to 108.20.	The 0.1 FREQ SELECT (MC) lamps A and C should light.  The 0.01 FREQ SELECT (MC) lamp B should light.	a. If 0.1 FREQ SELECT (MC) lamp A does not light, the kilocycle selector on the control unit is defective.  b. If 0.1 FREQ SELECT (MC) lamp C does not light, either a break in the circuit is present between h of P2 and E of P5, or the kilocycle selector in the control unit is defective.  c. If 0.01 FREQ SELECT (MC) lamp B does not light, the kilocycle selector in the control unit is defective.	a. Troubleshoot the control unit as described in TM 11-5826-226-35.  b. If a break in the circuit is present, make resistance measurements to find the break. If no break is present troubleshoot the control unit as described in TM 11-5826-226-35.  c. Troubleshoot the control unit as described in TM 11-5826-226-35.
8	Set the megacycle and kilocycle selectors to 108.25.	The 0.1 FREQ SELECT (MC) lamps A and C should light.	If either one, or both, of the lamps do not light, the kilocycle selector in the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-35.
9	Set the megacycle and kilocycle selectors to 108.30.	The 0.1 FREQ SELECT (MC) lamps B and C should light. The 0.01 FREQ SELECT (MC) lamp B should light, The GS/LOC ON lamp should light.	If any one of these lamps does not light, the kilocycle selector in the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-35.
10	Set the megacycle and kilocycle selectors to 108.35.	The 0.1 FREQ SELECT (MC) lamps B and C should light.	If either of the lamps does not light, the kilocycle selector in the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-35.
11	Set the megacycle and kilocycle selectors to 108.40.	The 0.1 FREQ SELECT (MC) lamps B and D should light. The 0.01 FREQ SELECT (MC) lamp B should light.	a. If the 0.1 FREQ SELECT (MC) lamp B does not light, the kilocycle selector in the control unit is defective.	a. Troubleshoot the control unit as described in TM 11-5826-226-35.

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
			<p>b. If the 0.1 FREQ SELECT (MC) lamp D does not light, either a break in the circuit is present between i of P2 and f of P5, or the kilocycle selector in the control unit is defective.</p> <p>c. If 0.01 FREQ SELECT (MC) lamp B does not light, the kilocycle selector in the control unit is defective.</p>	<p>b. If a break in the control circuit is not present, make resistance measurements to find the break. If no break is present troubleshoot the control unit as described in TM 11-5826-226-35.</p> <p>c. Troubleshoot the control unit as described in TM 11-5826-226-35.</p>
12	Set the megacycle and kilocycle selectors to 108.45.	The 0.1 FREQ SELECT (MC) lamps B and D should light.	The kilocycle selector in the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-35.
13	Set the megacycle and kilocycle selectors to 108.50.	The 0.1 FREQ SELECT (MC) lamps C and D should light. The 0.01 FREQ SELECT (MC) lamp B should light. The GS/LOC ON lamp should light.	Same as step 12 above.	Same as step 12 above.
14	Set the megacycle and kilocycle selectors to 108.55.	The 0.1 FREQ SELECT (MC) lamps C and D should light.	Same as step 12 above.	Same as step 12 above.
15	Set the megacycle and kilocycle selectors to 108.60.	The 0.1 FREQ SELECT (MC) lamps C and E should light. The 0.01 FREQ SELECT (MC) lamp B should light.	Same as step 12 above.	Same as step 12 above.
16	Set the megacycle and kilocycle selectors to 108.65.	The 0.1 FREQ SELECT (MC) lamps C and E should light.	Same as step 12 above.	Same as step 12 above.
17	Set the megacycle and kilocycle selectors to 108.70.	The 0.1 FREQ SELECT (MC) lamps D and E should light. The 0.01 FREQ SELECT (MC) lamp B should light. The GS/LOC ON lamp should light.	Same as step 12 above.	Same as step 12 above.
18	Set the megacycle and kilocycle selectors to 108.75.	The 0.1 FREQ SELECT (MC) lamps D and E should light.	Same as step 12 above.	Same as step 12 above.
19	Set the megacycle and kilocycle selectors to 108.80.	The 0.1 FREQ SELECT (MC) lamps A and D should light. The 0.01 FREQ SELECT (MC) lamp B should light.	Same as step 12 above.	Same as step 12 above.

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
20	Set the megacycle and kilocycle selectors to 108.85.	The 0.1 FREQ SELECT (MC) lamps A and D should light.	Same as step 12 above.	Same as step 12 above.
21	Set the megacycle and kilocycle selectors to 108.90.	The 0.1 FREQ SELECT (MC) lamps A and E should light. The 0.01 FREQ SELECT (MC) lamp B should light. The GS/LOC ON lamp should light.	Same as step 12 above.	Same as step 12 above.
22	Set the megacycle and kilocycle selectors to 108.95.	The 0.1 FREQ SELECT (MC) lamps A and E should light.	Same as step 12 above.	Same as step 12 above.
23	Set the megacycle and kilocycle selectors to 109.00.	<i>Note.</i> The 1.0 FREQ SELECT (MC) lamps B and E, and the 0.01 FREQ SELECT (MC) lamp B should remain lit in steps 23 through 40 below. The 1.0 FREQ SELECT (MC) lamps A and E should light.	<p>a. If 1.0 FREQ SELECT (MC) lamp A does not light, the megacycle selector in the control unit is defective.</p> <p>b. If 1.0 FREQ SELECT (MC) lamp E does not light, either a break in the circuit is present between S of P2 and W of P5, or the megacycle selector in the control unit is defective.</p>	<p>a. Troubleshoot the control unit as described in TM 11-5826-226-35.</p> <p>b. If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.</p>
24	Set the megacycle and kilocycle selectors to 110.00.	The 1.0 FREQ SELECT (MC) lamps B and E should light.	<p>a. If 1.0 FREQ SELECT (MC) lamp B does not light, either a break in the circuit is present between V of P2 and X of P5, or the megacycle selector in the unit is defective.</p> <p>b. If 1.0 FREQ SELECT (MC) lamp E does not light, the megacycle selector in the control unit is defective.</p>	<p>a. If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.</p> <p>b. Troubleshoot the control unit as described in TM 11-5826-226-35.</p>
25	Set the megacycle and kilocycle selectors to 111.00.	The 1.0 FREQ SELECT (MC) lamps A and B should light.	The megacycle selector in the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-35.
26	Set the megacycle and kilocycle selectors to 112.00.	The 1.0 FREQ SELECT (MC) lamps A and C should light.	a. If 1.0 FREQ SELECT (MC) lamp A does not light, the megacycle selector in the control unit is defective.	a. Troubleshoot the control unit as described in TM 11-5826-226-35.

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
			<i>b.</i> If 1.0 FREQ SELECT (MC) lamp C does not light, either a break in the circuit is present between U of P2 and G of P5, or the megacycle selector in the control unit is defective.	<i>b.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.
27	Set the megacycle and kilocycle selectors to 113.00.	The 1.0 FREQ SELECT (MC) lamps B and C should light.	The megacycle selector in the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-35.
28	Set the megacycle and kilocycle selectors to 114.00.	The 1.0 FREQ SELECT (MC) lamps B and D should light.	Same as step 27 above.	Same as step 27 above.
29	Set the megacycle and kilocycle selectors to 115.00.	The 1.0 FREQ SELECT (MC) lamps C and D should light.	Same as step 27 above.	Same as step 27 above.
30	Set the megacycle and kilocycle selectors to 116.00.	The 1.0 FREQ SELECT (MC) lamps C and E should light.	Same as step 27 above.	Same as step 27 above.
31	Set the megacycle and kilocycle selectors to 117.00.	The 1.0 FREQ SELECT (MC) lamps D and E should light.	Same as step 27 above.	Same as step 27 above.
32	Set the megacycle and kilocycle selector to 118.00.	The 1.0 FREQ SELECT (MC) lamps A and D should light. COMM lamp should light.	<i>a.</i> If either one, or both, of the 1.0 FREQ SELECT (MC) lamps A or D do not light, the megacycle selector in the control unit is defective. <i>b.</i> If the COMM lamp does not light, either a break in the circuit is present between K of P2 and a of P5, or the megacycle selector in the control unit is defective.	<i>a.</i> Troubleshoot the control unit as described in TM 11-5826-226-35. <i>b.</i> If a break in the circuit is present, make resistance measurements to find the break. If no break is present, troubleshoot the control unit as described in TM 11-5826-226-35.
33	Set the megacycle and kilocycle selectors to 119.00.	The 1.0 FREQ SELECT (MC) lamps A and E should light. COMM lamp should light.	The megacycle selector in the control unit is defective.	Troubleshoot the control unit as described in TM 11-5826-226-35.
34	Set the megacycle and kilocycle selectors to 120.00.	The 1.0 FREQ SELECT (MC) lamps B and E should light. COMM lamp should light.	Same as step 33 above.	Same as step 33 above.



Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
35	Set the megacycle and kilocycle selectors to 121.00.	The 1.0 FREQ SELECT (MC) lamps A and B should light. COMM lamp should light.	Same as step 33 above.	Same as step 33 above.
36	Set the megacycle and kilocycle selectors to 122.00.	The 1.0 FREQ SELECT (MC) lamps A and C should light. COMM lamp should light.	Same as step 33 above.	Same as step 33 above.
37	Set the megacycle and kilocycle selectors to 123.00.	The 1.0 FREQ SELECT (MC) lamps B and C should light. COMM lamp should light.	Same as step 33 above.	Same as step 33 above.
38	Set the megacycle and kilocycle selectors to 124.00.	The 1.0 FREQ SELECT (MC) lamps B and D should light. COMM lamp should light.	Same as step 33 above.	Same as step 33 above.
39	Set the megacycle and kilocycle selectors to 125.00.	The 1.0 FREQ SELECT (MC) lamps C and D should light. COMM lamp should light.	Same as step 33 above.	Same as step 33 above.
40	Set the megacycle and kilocycle selectors to 126.00.	The 1.0 FREQ SELECT (MC) lamps C and E should light. COMM lamp should light.	Same as step 33 above.	Same as step 33 above.
41	Rotate the COMPASS SIMULATOR from N (0°) to E (90°).	The RMI card should follow the rotation of the COMPASS SIMULATOR. The RMI card should indicate within 1° of the COMPASS SIMULATOR when the RMI is tapped lightly on the bezel.	<ul style="list-style-type: none"> <li>a. COMPASS SIMULATOR out of alignment.</li> <li>b. Defective RMI.</li> <li>c. Defective RMI circuitry in the test set.</li> </ul>	<ul style="list-style-type: none"> <li>a. Align the COMPASS SIMULATOR as described in paragraph 3-10.</li> <li>b. Troubleshoot the RMI as described in TM 11-5826-211-50.</li> <li>c. Refer to figure 4-9 or 4-9.1 and make continuity checks on the RMI circuitry in test set.</li> </ul>
42	Rotate the COMPASS SIMULATOR needle one complete revolution (360°).	The RMI needle number 1 should indicate 180° ±2, and stay at this position as the COMPASS SIMULATOR is rotated.	Defective RMI.	Troubleshoot the RMI as described in TM 11-5826-211-50.
43	Connect the equipment as shown in figure 2-9. Indicator, Course ID-1347/ARN-82 must be used. On Test Set, Radio TS-2500A/ARN-82, RECEIVER MODEL switch must be in A position.	Minimum null should appear on the oscilloscope with the OBS indicator set to 300°.	Indicator, Course ID-1347/ARN-82 is defective or misaligned.	Troubleshoot the OBS indicator as described in TM 11-5826-226-35.

Change 2 2-17

TM 11-6625-820-45

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
	<p>A schematic diagram of the fabricated cable is shown in figure 4-1. Calibrate the resolver test set. (Refer to FM 11-6625-492-12 for calibration of the resolver test set.) Disconnect the MOD OUTPUT of the VOR modulator from the VAR connector on the resolver test set. Connect the INPUT lead of the vtm to the VOLTMETER connector on the resolver test set. Set the function switch on the resolver test set to ORZ. Adjust the INPUT LEVEL control on the resolver test set for a 4.25-volt indication on the vtm. Remove the INPUT lead of the vtm from the VOLTMETER connector, and connect it to the OUTPUT connector on the resolver test set. Set the test set BRG-OBS switch to OBS. Set the SWEEP TIME on the oscilloscope to 20 milliseconds. Adjust the oscilloscope vertical gain until the pattern fills the grid. Rotate the OBS control on the test set and the AMP BAL control on the resolver test set until the least possible signal amplitude (minimum null) is observed on the oscilloscope.</p> <p><i>Note.</i> As the null is approached, increase the oscilloscope vertical gain.</p>			

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction
44	Set the BRG-OBS switch on the test set to BRG.	The indication of the oscilloscope should not change from the indication obtained in step 43 above.	<ul style="list-style-type: none"> <li>a. Resistor R1 out of adjustment.</li> <li>b. The precision bearing circuit in the test set is defective.</li> </ul>	<ul style="list-style-type: none"> <li>a. Adjust resistor R1 (Para 3-9).</li> <li>b. Refer to figures 4-9 and 4-9.1. Make continuity checks on the precision bearing circuit. Refer to paragraph 2-9 for the resistance of the transformer winding for T2.</li> </ul>
45 (This test for Test Set, Radio TS-2500A/ARM-92 only.)	<ul style="list-style-type: none"> <li>a. Connect test set pendant cable P2 to indicator test set jack J2 using cable fabricated per instructions in paragraph 4-4 (fig. 4-1.1). Use Indicator, Course ID-1347A/ARN-82 with test set. Set SYNCHRO SELECTOR switch on indicator test set to EZ. Set the test set BRG-OBS switch to OBS. Set the test set RECEIVER MODEL switch to B position. Adjust course index on course indicator around 300 degrees for zero reading on indicator test set SYNCHRO METER.</li> <li>b. Rotate course index on course selector counterclockwise.</li> <li>c. Set SYNCHRO SELECTOR switch on indicator test set to RW2. Adjust course index on course indicator around 30 degrees for zero reading on indicator test set SYNCHRO METER.</li> </ul>	<ul style="list-style-type: none"> <li>a. Course index on course indicator should read <math>300 \pm 3</math> degrees when indicator test set SYNCHRO METER reads zero.</li> <li>b. Indicator test set SYNCHRO METER deflects to the right.</li> <li>c. Course index on course indicator should read <math>30 \pm 3</math> degrees when indicator test set SYNCHRO METER reads zero.</li> </ul>	<ul style="list-style-type: none"> <li>a. Indicator, Course ID-1347A/ARN-82 is defective or misaligned.</li> <li>b. Same as step a above.</li> <li>c. Same as step a above.</li> </ul>	<ul style="list-style-type: none"> <li>a. Troubleshoot the OBS indicator as described in TM 11-5826-226-35.</li> <li>b. Same as step a above.</li> <li>c. Same as step a above.</li> </ul>

Change 2 2-19

TM 11-6625-820-45

Step	Procedure	Proper indication	Probable trouble for improper indication	Correction																																							
	d. Rotate course index on course indicator counterclockwise.	d. Indicator test set SYN-CHRO METER deflects to the left.	d. Same as step a above.	d. Same as step a above.																																							
46 (This test for Test Set, Radio TS-2500A/ARM-92 only.)	<p>Connect test set pendant cable plugs P2 and P3 to the cable fabricated per instructions in paragraph 4-4 (fig. 4-1.2).</p> <p>Set test set controls as follows:</p> <p>BRG-OBS: BRG BEARING: 300 RECEIVER MODEL: B</p> <p>Measure the ac voltage from J1 to J2 on the fabricated cable. This voltage is V1 max.</p> <p>Set test set BEARING switch to 30.</p> <p>Measure the ac voltage from J3 to J4 on the fabricated cable. This voltage is V2 max.</p> <p>Measure the ac voltage from J1 to J2 and J3 to J4 for each setting of the test set BEARING switch.</p>	<table border="1"> <thead> <tr> <th>Bearing</th> <th>J1 to J2</th> <th>J3 to J4</th> </tr> </thead> <tbody> <tr> <td>300</td> <td>V1 max</td> <td>0</td> </tr> <tr> <td>330</td> <td>.86(V1 max)</td> <td>.5(V2 max)</td> </tr> <tr> <td>0</td> <td>.5(V1 max)</td> <td>.86(V2 max)</td> </tr> <tr> <td>30</td> <td>0</td> <td>V2 max</td> </tr> <tr> <td>60</td> <td>.5(V1 max)</td> <td>.86(V2 max)</td> </tr> <tr> <td>90</td> <td>.86(V1 max)</td> <td>.5(V2 max)</td> </tr> <tr> <td>120</td> <td>V1 max</td> <td>0</td> </tr> <tr> <td>150</td> <td>.86(V1 max)</td> <td>.5(V2 max)</td> </tr> <tr> <td>180</td> <td>.5(V1 max)</td> <td>.86(V2 max)</td> </tr> <tr> <td>210</td> <td>0</td> <td>V2 max</td> </tr> <tr> <td>240</td> <td>.5(V1 max)</td> <td>.86(V2 max)</td> </tr> <tr> <td>270</td> <td>.86(V1 max)</td> <td>.5(V2 max)</td> </tr> </tbody> </table> <p>(Tolerance of 10% is allowed on readings above)</p>	Bearing	J1 to J2	J3 to J4	300	V1 max	0	330	.86(V1 max)	.5(V2 max)	0	.5(V1 max)	.86(V2 max)	30	0	V2 max	60	.5(V1 max)	.86(V2 max)	90	.86(V1 max)	.5(V2 max)	120	V1 max	0	150	.86(V1 max)	.5(V2 max)	180	.5(V1 max)	.86(V2 max)	210	0	V2 max	240	.5(V1 max)	.86(V2 max)	270	.86(V1 max)	.5(V2 max)	Broken part or connection. Defective transformer T2 or T3.	Check for defective parts or connections.
Bearing	J1 to J2	J3 to J4																																									
300	V1 max	0																																									
330	.86(V1 max)	.5(V2 max)																																									
0	.5(V1 max)	.86(V2 max)																																									
30	0	V2 max																																									
60	.5(V1 max)	.86(V2 max)																																									
90	.86(V1 max)	.5(V2 max)																																									
120	V1 max	0																																									
150	.86(V1 max)	.5(V2 max)																																									
180	.5(V1 max)	.86(V2 max)																																									
210	0	V2 max																																									
240	.5(V1 max)	.86(V2 max)																																									
270	.86(V1 max)	.5(V2 max)																																									




Figure 2-9. Equipment setup to test precision BEARING circuit.

**2-9. Dc Resistances of Transformers and Relay Coils**

Transformer or relay coil	Terminals	Ohms
T2 in Test Set, Radio TS-2500/ARM-92	11 to 12	13 ±3
	11 to 10	36 ±7
	10 to 9	51 ±10
	9 to 8	0
	8 to 7	52 ±10
	7 to 6	36 ±7
	6 to 5	12 ±2
	1 to 2	30 ±6
	3 to 4	195 ±39

T2 and T3 in Test Set, Radio TS-2500A/ARM-92	11 to 12	13 ±3
	11 to 10	36 ±7
	10 to 9	51 ±10
	8 to 7	52 ±10
	7 to 6	36 ±7
	6 to 5	12 ±2
	1 to 2	30 ±6
T1	3 to 2	9 ±2
	2 to 1	1
K1	1 to 6	280 ±28
K2	1 to 8	280 ±28



## CHAPTER 3

### REPAIR AND ALIGNMENT

---

#### Section I. REPAIRS

#### 3-1. General Parts Replacement Techniques

The following general precautions should be observed when replacing parts in this equipment.

*a.* When soldering or unsoldering components, solder quickly to allow as little heat conduction as possible. Whenever wiring permits, use a heat sink (such as a long-nosed pliers) between the solder joint and the component. Use approximately the same length and dress of leads as used originally.

*b.* Use a pencil-type iron with a 25-watt maximum capacity. If the iron must be used with ac, use an isolation transformer between the iron and the line. Check soldering irons for shorts to the iron tip before using.

*c.* Whenever an electrical part such as a resistor or diode is to be removed, note the exact position of the component before removing it. Replace the component in the same position.

#### 3-2. Removal and Replacement Techniques

The procedures for removal and disassembly of the units in the test set are described in paragraph 3-3. The corresponding replacement, reassembly, and lubrication techniques are described in paragraph 3-4. The procedures for disassembly of the aid box are described in paragraph 3-5. The corresponding reassembly techniques are described in paragraph 3-6.

#### 3-3. Removal and Disassembly Techniques for Test Sets, Radio TS-2500/ARM-92 and TS-2500A/ARM-92

##### *a.* Removal of Test Set Front Panel

- (1) Remove the 13 screws from the perimeter of the front panel.

- (2) Lift the front panel away from the test set.
- (3) Disconnect the power cable from the chassis.

*Note.* To allow enough slack to conveniently work on the test set, the pendant cables may be pulled through the porthole in the bottom of test set.

##### *b.* Removal of Control Unit.

- (1) Loosen the four Dzus fasteners.
- (2) Pull the control unit away from the front panel of the test set.
- (3) Disconnect the cable attached to the control unit.

*c.* *Disassembly of Control Unit.* Refer to TM 11-5826-226-35 for disassembly procedures of Control, Radio Set C-6873/ARN-82.

##### *d.* Removal of OBS Indicator.

- (1) Remove the four screws that hold the OBS indicator to the front panel of the test set.
- (2) Pull the OBS indicator away from the front panel of the test set.
- (3) Disconnect the cable attached to the OBS indicator.

*e.* *Disassembly of OBS Indicator.* Refer to TM 11-5826-226-35 for disassembly procedures of Indicator, Course ID-1347/ARN-82, or ID-1347A/ARN-82.

##### *f.* Removal of RMI

- (1) Remove the four screws that hold the RMI to the front panel of the test set.
- (2) Pull the RMI away from the front panel of the test set.
- (3) Disconnect the cable attached to the RMI

*g. Disassembly of RMI.* Refer to TM 11-5826-211-50 for disassembly procedures for Indicator, Course ID-250A/ARN.

*h. Removal of COMPASS SIMULATOR indicator.*

- (1) Remove the test set front panel (a above).
- (2) Remove the three screws that hold the COMPASS SIMULATOR indicator to the front panel of the test set.
- (3) Pull the COMPASS SIMULATOR indicator away from the front panel.
- (4) Disconnect the cable attached to the COMPASS SIMULATOR indicator.

*i. Disassembly of COMPASS SIMULATOR indicator (fig. 3-1).*

- (1) Remove four screws (30) and four lockwashers (29) from connector P1 (28).
- (2) Pull connector P1 (28) away from rear housing (23) to allow enough space to unsolder leads attached to connector. Label these leads to identify them for reassembly. Remove gasket (27).
- (3) Set COMPASS SIMULATOR indicator down on a flat surface.
- (4) Remove eight screws (25) and eight lockwashers (24).
- (5) Pull front cover (5) away from rear housing (23).
- (6) Remove gasket (22).
- (7) Separate front cover (5) from synchro housing (17).

*Note.* To remove dial window (9), push carefully on front side of dial window (9) to remove it from front cover (5) and windowseal (8).

- (8) Loosen two setscrews (2 and 3). Remove knob (1) and spring washer (4).
- (9) Pull out drive gear (7). Remove shaft sleeve (6).
- (10) Pull needle (11) straight off shaft of synchro B1 (21).
- (11) Rotate synchro gear (13) until setscrew (14) lines up with hole in smaller rim of synchro housing (17). Loosen this setscrew.
- (12) Repeat step in (11) above to loosen setscrew (14).

- (13) Remove dial retainer (10) and dial (12).
- (14) Remove synchro gear (13) and idler gear (16).
- (15) Remove three screws (20), three lockwashers (19), and three synchro clamps (18).
- (16) Pull synchro B1 (21) off synchro housing (17).

*j. Removal of FLAG Meter.*

- (1) Remove the test set front panel ( a above).
- (2) Disconnect the two wires attached to the meter. Label these wires for identification when replacing the meter.
- (3) Remove the four nuts that hold the meter to the test set.
- (4) Pull the meter out of the front panel.

*k. Removal of DEVIATION Meter.*

- (1) Remove the test set front panel ( a above).
- (2) Disconnect the two wires attached to the meter. Label these wires for identification when replacing the meter.
- (3) Remove the four nuts that hold the meter to the test set.
- (4) Pull the meter out of the front panel.

*l. Removal of TO-FROM Meter.*

- (1) Remove the test set front panel ( a above).
- (2) Disconnect the two wires attached to the meter. Label these wires for identification when replacing the meter.
- (3) Remove the four nuts that hold the meter to the test set.
- (4) Pull the meter out of the front panel.

### **3-4. Replacement, Reassembly, and Lubrication Techniques for Test Sets, Radio TS-2500/ARM-92 and TS-2500A/ARM-92**

*a. Replacement of TO-FROM Meter.*

- (1) Place the meter back in the front panel.
- (2) Replace the four nuts to hold the meter to the front panel.
- (3) Connect the two wires to their proper terminal on the meter.
- (4) Replace the test set front panel ( l below).



*b. Replacement of Deviation Meter.*

- (1) Place the meter back in the front panel.
- (2) Replace the four nuts to hold the meter to the front panel.
- (3) Connect the two wires to their proper terminal on the meter.
- (4) Replace the test set front panel ( 1 above).

*c. Replacement of FLAG Meter.*

- (1) Place the meter back in the front panel.
- (2) Replace the four nuts to hold the meter to the front panel.
- (3) Connect the two wires to their proper terminals on the meter.
- (4) Replace the test set front panel ( 1 above).

*d. Reassembly of COMPASS SIMULATOR Indicator (fig. 3-1).*

- (1) Replace synchro B1 (21) to synchro housing (17).
- (2) Replace three synchro clamps (18), three lockwashers (19), and three screws (20).
- (3) Replace synchro gear (13).
- (4) Rotate synchro gear (13) until the setscrew (15) lines up with the hole in the smaller rim of synchro housing (17). Tighten this setscrew.
- (5) Repeat step in (4) above to tighten setscrew (14).
- (6) Replace idler gear (16).
- (7) Replace dial (12) and retainer (10).
- (8) Push needle (11) straight on the shaft of synchro B1 (21) until it is properly in place. Align the COMPASS SIMULATOR indicator (para 3-10).
- (9) Replace shaft sleeve (6). Lubricate inside of shaft sleeve (6) with Dow Corning Stopcock grease Replace drive gear (7).
- (10) Replace spring washer (4). Replace knob (1) and tighten two setscrews (2 and 3).
- (11) Replace front cover (5) to synchro housing (17).

*Note.* If dial window (9) has been removed, replace the window by very carefully pushing it back into the front cover (5) before replacing the front cover.

- (12) Replace gasket (22) to rear housing (23).
- (13) Replace front cover (5) to rear housing (23).
- (14) Replace eight lockwashers (24) and tighten eight screws (25).
- (15) Replace gasket (27).
- (16) Solder the leads to the proper points on connector P1 (28).
- (17) Replace four lockwashers (29) and tighten four screws (30).

*e. Replacement of COMPASS SIMULATOR Indicator.*

- (1) Connect P1 to the COMPASS SIMULATOR Indicator.
- (2) Replace the COMPASS SIMULATOR Indicator in the front panel.
- (3) Replace the three screws and nuts, to hold the COMPASS SIMULATOR Indicator to the front panel.
- (4) Replace the test set front panel ( 1 below).

*f. Reassembly and Lubrication of RMI.* Refer to TM 11-5826-211-50 for reassembly and lubrication procedures for Indicator, Course ID-250A/ARN.


*g. Replacement of RMI.*

- (1) Connect P4 to the RMI connector.
- (2) Replace the RMI in the front panel.
- (3) Replace the four screws to hold the RMI to the front panel.
- (4) Replace the test set front panel ( 1 below).

*h. Reassembly and Lubrication of OBS Indicator.* Refer to TM 11-5826-226-35 for reassembly and lubrication procedures for Indicator, Course ID-1347/ARN-82 or ID-1347A/ARN-82.

*i. Replacement of OBS Indicator.*

- (1) Connect P6 to the OBS connector.
- (2) Replace the OBS indicator in the front panel.
- (3) Replace the four screws, to hold the OBS indicator to the front panel.
- (4) Replace the test set front panel ( 1 below).



TM6625-820-45-15

- |                   |   |   |
|-------------------|---|---|
| 1 Knob            | 11 Needle                               | 21 Synchro B1                           |
| 2 Setscrew, No. 2 | 12 Dial                                 | 22 Gasket                               |
| 3 Setscrew, No. 2 | 13 Gear, synchro                        | 23 Housing, rear                        |
| 4 Washer, spring  | 14 Setscrew, No. 2                      | 24 Lockwasher                           |
| 5 Cover, front    | 15 Setscrew, No. 2                      | 25 Screw, machine, No. 2, 5/16 in. lg   |
| 6 Sleeve, shaft   | 16 Gear, idler                          | 26 Plate, identification                |
| 7 Gear, drive     | 17 Housing, synchro                     | 27 Gasket                               |
| 8 Seal, window    | 18 Clamp, synchro                       | 28 Connector P1                         |
| 9 Window, dial    | 19 Lockwasher                           | 29 Lockwasher                           |
| 10 Retainer, dial | 20 Screw, machine, No. 4, 5/16 in. long | 30 Screw, machine, No. 4, 5/16 in. long |

Figure 3-1. COMPASS SIMULATOR Indicator, exploded view.

*j. Reassembly and Lubrication of Control Unit.* Refer to TM 11-5826-226-35 for reassembly and lubrication procedures for Control, Radio Set C-6873/ARN-82.

*k. Replacement of Control Unit.*

- (1) Connect P5 to the control unit connector.
- (2) Replace the control unit in the front panel.
- (3) Tighten the four Dzus fasteners.

*l. Replacement of Front Panel.*

- (1) Connect the power cable to J5.
- (2) Place the front panel back in the lower carrying case. Be sure no cables are pinched between the chassis and the carrying case.
- (3) Replace the 13 screws in the perimeter of the front panel.

### **3-5. Disassembly Techniques for Test Set, Wiring Harness, Aircraft TS-2501/ARM-92**

Remove the bottom panel of the aid box as follows:

- a.* Remove the six screws that hold the bottom panel in place.
- b.* Lift the bottom panel away.

### **3-6. Reassembly Techniques for Test Set, Wiring Harness, Aircraft TS-2501/ARM-92**

Replace the bottom panel of the aid box as follows :

- a.* Place the bottom panel on the aid box.
- b.* Replace the six screws, to hold the bottom panel in place.

## **Section II. ALIGNMENT**

### **3-7. General**

Alignment procedures for Test Sets, Radio AN/ARM-92 and AN/ARM-92A are given in paragraphs 3-9 through 3-13. The precision bearing alignment is given in paragraph 3-9. Alignment of the COMPASS SIMULATOR indicator is given in paragraph 3-10. References to the alignment procedures are given for the OBS indicator, RMI and control unit in paragraphs 3-11 through 3-13. References to the test equipment required are given in paragraph 3-8.

### **3-8. Test Equipment Required for Alignment**

Refer to paragraph 2-3 for a list of the test equipment required for alignment procedures.

### **3-9. Precision Bearing Alignment**

*a.* Remove the test set front panel (para 3-3(a)).

*b.* A special cable is required for precision bearing alignment. Refer to paragraph 4-4 for construction details of this cable.

*c.* Connect the equipment as shown in figure 2-9, and calibrate the resolver test set. (Refer to TM 11-6625-492-12 for calibration of Test Set, Resolver AN/ARM-101.)

*d.* Disconnect the MOD OUTPUT connector of the vor modulator from the VAR connector of the resolver test set.

*e.* Connect the INPUT of the vacuum-tube voltmeter (vtvm) to the VOLTMETER connector on the resolver test set.

*f.* Set the function switch on the resolver test set to SET ORZ.

*g.* Adjust the INPUT LEVEL control on the resolver test set for 4.25-volt indication of the vtvm.

*h.* Remove the INPUT of the vtvm from the VOLTMETER connector, and connect it to the OUTPUT connector on the resolver test set.

*i.* Set the VOR/LOC-GLIDE SLOPE switch on the test set the VOR/LOC.

*j.* Set the BEARING selector switch on the test set to 300.

*k.* Unlock potentiometer R1 located behind the front panel of the test set.

*l.* Alternately adjust the AMP.BAL. control on the resolver test set and potentiometer R1 in the test set to obtain the least possible signal amplitude (minimum null) as observed on the oscilloscope.

*Note.* As the null is approached, increase the vertical gain of the oscilloscope.

- m. Lock potentiometer R1 shaft.
- n. If aligning Test Set, Radio TS-2500/ARM-92, disconnect the equipment and replace the test set front panel. Omit steps o through z.
- o. Disconnect the test set from the resolver test setup (fig. 2-9). Connect the test set and the resolver bridge as shown in figure 3-2. Use the cable fabricated in paragraph 4-4 (fig. 4-1.2).
- p. Disconnect the wire to the wiper connection of wafer H of switch S3 (fig. 3-3).
- q. Connect jack J7 of the fabricated cable to the pin from which the wire was removed in step p.

- r. Set the test set BEARING switch to 300 and the resolver bridge angle switch to 0 degree.
- s. Adjust the oscilloscope gain controls to obtain a line of approximately 20 degrees slope from the horizontal (disregard any ballooning).
- t. With grease pencil or equivalent, draw the slope line on the oscilloscope face; this is the maximum negative angle. Draw a line of the same slope but the opposite direction from the horizontal line; this is the maximum positive angle.
- u. Disconnect the jumper from J7 of the fabricated cable to the test set.




Figure 3-2. TS-2500A/ARM-92 precision BEARING alignment.

- v. Reconnect the wire disconnected in step *p*.
- w. Rotate the test set BEARING switch and the resolver bridge angle switch simultaneously in 30-degree steps and note the amount of error and the direction the line on the oscilloscope slopes.
- x. If the error exceeds the limit set in step *t*, refer to the transformer error correction chart in paragraph 3-9.1.
- y. Repeat steps *c* through *y* until all error limits are met.
- z. Disconnect the equipment and replace the front panel.




Figure 3-3. TS-2500A/ARM-92 switch S3 wafer and pin designation.

### 3-9.1. Transformer Error Correction Chart

Symptom	Corrective action
Positive error at 90 degrees	
Positive error at 60 degrees greater than error at 90 degrees.	Add resistance between terminals 9 and 10 of T2 to reduce error at 60 degrees; then add resistance between terminals 10 and 11 of T2 to reduce error at 90 degrees.
Positive error at 60 degrees less than error at 90 degrees.	Add resistance between terminals 10 and 11 of T2 to reduce error at 90 degrees; then add resistance between terminals 9 and 10 of T2 to reduce error at 60 degrees.
No or small negative error at 60 degrees.	Add resistance between terminals 10 and 11 of T2 to reduce error at 90 degrees; then add resistance between terminals 10 and 11 of T1 to reduce error at 60 degrees.
Negative error at 60 degrees greater than error at 90 degrees.	Add resistance between terminals 10 and 11 of T1 to reduce error at 60 degrees; then add resistance between terminals 10 and 11 of T2 to reduce error at 90 degrees.
Negative error at 90 degrees	
Negative error at 60 degrees greater than error at 90 degrees.	Add resistance between terminals 10 and 11 of T1 to reduce error at 60 degrees; then add resistance between terminals 9 and 10 of T1 to reduce error at 90 degrees.
Negative error at 60 degrees less than error at 90 degrees.	Add resistance between terminals 9 and 10 of T1 to reduce error at 90 degrees; then add resistance between terminals 10 and 11 of T1 to reduce error at 60 degrees.

Symptom	Corrective action
No or small positive error at 60 degrees.	Add resistance between terminals 9 and 10 of T1 to reduce error at 90 degrees; then add resistance between terminals 9 and 10 of T2 to reduce error at 60 degrees.
Positive error at 60 degrees greater than error at 90 degrees.	Add resistance between terminals 9 and 10 of T2 to reduce error at 60 degrees; then add resistance between terminals 9 and 10 of T1 to reduce error at 90 degrees.
No error at 90 degrees	
Positive error at 60 degrees.	Add resistance between terminals 9 and 10 of T2 to reduce error at 60 degrees; then add resistance between terminals 9 and 10 of T1 to correct error induced at 90 degrees.
Negative error at 60 degrees.	Add resistance between terminals 10 and 11 of T2 to reduce error at 60 degrees; then add resistance between terminals 10 and 11 of T1 to correct error induced at 90 degrees.

**3-10. COMPASS SIMULATOR Indicator Alignment**

- a. Remove the test set front panel (para 3-3a).
- b. Connect the test set to a 27.5-volt dc power source, and a 115-volt, 400-cps power source.
- c. Set the power switch on the control unit to PWR. (All other controls and switches on the control unit and test set may be in any position.)

**Caution:** In the following steps, remove the vtm power cord from ground to eliminate the possibility of shorting across the external power source.

- d. Connect the vtm between pins C and D of connector P3 of the test set pendant cable.
- e. With the compass simulator control, rotate the COMPASS SIMULATOR indicator for a null indication on the vtm.

*Note.* A 360° rotation of the COMPASS SIMULATOR indicator will produce two nulls on the vtm. To determine the correct null, measure the ac voltage between pins C and G of connector P3. This ac voltage will be less than 26 volts ac when the correct null is found.

- f. With the COMPASS SIMULATOR indicator set to the correct null, perform the fol-

lowing procedure to zero the COMPASS SIMULATOR indicator needle.

- (1) Remove the rear housing of the COMPASS SIMULATOR indicator.
- (2) Loosen the three screws that hold synchro B1 to the housing.
- (3) Rotate the entire synchro until the COMPASS SIMULATOR indicator needle points exactly to N.
- (4) Tighten the three screws that hold synchro B1 to the housing.
- (5) Set the power switch on the control unit to OFF.
- (6) Replace the rear housing of the COMPASS SIMULATOR indicator.
- g. Disconnect the equipment, and replace the front panel on the test set.

**3-11. OBS Indicator Alignment**

Refer to TM 11-5826-226-35 for alignment procedures of Indicator, Course ID-1347/ARN-82, and ID-1347A/ARN-82.

**3-12. RMI Alignment**

Refer to TM 11-5826-211-50 for alignment procedures of Course Indicator ID-250A/ARN.

## CHAPTER 4

### GENERAL SUPPORT TESTING PROCEDURES AND DEPOT OVERHAUL STANDARDS

#### 4-1. General

*a.* Testing procedures are prepared for use by general support and depot maintenance shops responsible for general support and depot maintenance of electronic equipment to determine the acceptability of repaired electronic equipment. These procedures set forth specific requirements that repaired electronic equipment must meet before it is returned to the using organization. The testing procedures are to be used for both general support testing procedures and depot overhaul standards. Applicable procedures of the Army depots performing these tests and the general standards for repaired electronic equipment given in TB SIG 355-1, TB SIG 355-2, and TB SIG 355-3 form a part of the requirements for testing this equipment. A summary of the performance standards is given in paragraph 4-16.

*b.* Comply with the instructions preceding the body of each chart before proceeding to the chart. Perform each test in sequence. Do not vary the sequence. For each step, perform all the actions required in the *Control settings* columns; then perform each specific test procedure, and verify it against its performance standard.

#### 4-2. Test Equipment, Tools, and Materials

All test equipment, tools, materials, and other equipment required to perform the testing procedures given in this section are listed in the following charts and are authorized under TA-11-17, Signal Field Maintenance Shops, and TA-11-100(11-17), Allowances of Signal Corps Expendable Supplies for Field Maintenance Shop, Continental United States.

Nomenclature	Federal stock number	Technical manual
Modulator MD-83A/ARN	6625-539-8563	TM 11-6625-588-15
Output Meter TS-585(*)/ U	6625-244-0501	TM 11-5017
Voltmeter, Meter ME- 30A/U and Voltmeter, Electronic ME-30(*)/ U	6625-669-0742	TM 11-6625-320-12
Multimeter ME-26(*)/U	6625-542-6407	TM 11-6625-200-12
Test Set, Resolver AN AN/ASM-101	6625-086-7844	TM 11-6625-492-12
Oscilloscope AN/USM- 140A	6625-987-6603	TM 11-6625-535-15
Meter Test Set TS-682A/ GSM-1	6625-669-0747	TM 11-2535B

b. *Tools.* All tools required are contained in Tool Kit, Electronic Equipment TK-105/G, Federal Stock No. 5180-610-8177.

c. *Materials.*

- (1) 1/4-inch barrel diameter.
- (2) Telephone plug (1/4-inch diameter barrel).
- (3) Wire, copper, insulated, stranded # 22 AWG (40 feet long).
- (4) Connectors (3), Bendix PTO1A-20-40P(SR).
- (5) Connector, Bendix PTO1A-12-10P (SR).
- (6) Clamp MS3057-10A.
- (7) Connector MS3106A-18S-1S.
- (8) Connector MS3116A-18-32SW.
- (9) Binding posts (7) Superior Electric Company DF 30RC.
- (10) Spaghetti, 3/4-inch diameter (5.5 feet long).
- (11) Small enclosed metal box 3 x 4 x 5 inches.

ASM-110. Refer to figures 4-1, 4-1.1, and 4-1.2 and construct the cables as described below.

a. *Resolver Test Set and Indicator Test Set Cables.*

- (1) Solder six 2-foot lengths of # 22 AWG stranded, insulated wire to pins C, D, E, F, G, and H of each male connector P1.
- (2) Label the loose ends of the six wires with the pin number to which each wire is connected.
- (3) Slip a 2-inch length of spaghetti over the loose ends of the six wires.
- (4) Place clamp MS3057-10A over the end of the spaghetti on the resolver test set cable.
- (5) Connect the loose ends of the six wires to the pins of the J1 female connectors as shown in figures 4-1 and 4-1.1.

### 4-3. Test Facilities

Primary power requirements are 27.5 volts dc at 33 watts and 115 volts, 400 cps at 92 watts. Temperature, humidity, and atmospheric pressure are not critical.

### 4-4. Fabricated Cable Construction Details

Fabricated cables are required to connect the test set to Test Set, Resolver AN/ASM-101 and Test Set, Indicator, Course AN/




Figure 4-1. Fabricated cable to resolver test set, construction details.




Figure 4-1.1. Fabricated cable to indicator test set, construction details.




- (6) Tighten the clamps around the J1 connectors on each cable.
- b. *Resolver Bridge Cable.*
- (1) Solder six 2-foot lengths of # 22 AWG stranded insulated wire to pins C, D, E, F, G, and H of male connector P1.
  - (2) Solder two 2-foot lengths of # 22 AWG stranded insulated wire to pins G and E of male connector P2.
  - (3) Label the loose ends of the six wires with the pin number to which each wire is connected.
  - (4) Slip a 2-inch length of spaghetti over the loose end of the eight wires.
  - (5) Mount and label seven binding posts on a small enclosed metal box (fig. 3-2).

- (6) Connect a 21.5-kilohm,  $\pm 1\%$ , 1/2-watt resistor from binding post J6 to binding post J7.
- (7) Connect a 21.5-ohm,  $\pm 1\%$ , 1/2-watt resistor from binding post J5 to binding post J7.
- (8) Connect the loose ends of the eight wires to the binding posts as shown in figure 4-1.2.

#### 4-5. Modification Work Orders

The performance standards listed in the tests (paras 4-6 through 4-15) assume that the modification work orders, if any, have been performed. A listing of current modification work orders will be found in DA Pam 310-4.



**NOTE:**  
 J1 THROUGH J7 ARE BINDING POSTS,  
 SUPERIOR ELECTRIC COMPANY PART  
 NO. DF 30RC OR EQUIVALENT.

EL6625-820-45-C1-TM-31

Figure 4-1.2. Fabricated cable to resolver bridge, construction details.




#### 4-6. Test Set, Wiring Harness, Aircraft TS-2501/ARM-92 Physical Tests and Inspection

a. *Test Equipment and Materials.* None required.


b. *Test Connections and Conditions.* Remove the cover from the bottom of the aid box.

c. *Procedure.*

Step	Control settings		Test procedure	Performance standard
	Test equipment	Equipment under test		
1	N/A	N/A	<p>a. Inspect for loose or missing screws, nuts, or bolts.</p> <p>b. Inspect insulation of wiring for cuts, pinches, and signs of burning.</p> <p>c. Check resistors for cracks and signs of burning.</p> <p>d. Inspect connector for bent pins and cracked insulation material.</p> <p>e. Inspect for cold-soldered connections.</p> <p>f. Check for loose or missing lamps.</p> <p>g. Inspect the chassis for the condition of the finish and panel lettering.</p> <p><i>Note.</i> Touchup painting is recommended instead of refinishing whenever practicable. Screwheads, binding posts, connectors, and plated fastener parts will not be painted or polished with abrasives.</p> <p>Check the aid box for applicable modification work orders (para 4-5).</p>	<p>a. Screws, nuts, and bolts will be tight; none missing.</p> <p>b. No cuts, pinches, or signs of burning evident.</p> <p>c. No signs of cracks or burning evident.</p> <p>d. No bent pins or cracked insulation evident.</p> <p>e. No cold-soldered connections evident.</p> <p>f. Lamps should be tight; none missing.</p> <p>g. External surfaces intended to be painted will not show bare metal. Panel lettering will be legible.</p>
2	N/A	N/A	Check the aid box for applicable modification work orders (para 4-5).	



A. VOLTAGE MEASUREMENTS TEST CONNECTIONS.



NOTE  
□ INDICATES EQUIPMENT MARKINGS


B. RESISTANCE MEASUREMENTS TEST CONNECTIONS.

Figure 4-2. Aid box test.

#### 4-8. Control, Radio Set C-6873/ARN-82 Physical Tests and Inspection

- a. Test Equipment and Materials.* None required.
- b. Test Connections and Conditions.* Remove the control unit from the test set, and remove the rear cover from the control unit.
- c. Procedure.*

Step	Control settings		Test procedure	Performance standard
	Test equipment	Equipment under test		
1	N/A	Controls may be set to any position.	<p><i>a.</i> Inspect all controls and mechanical assemblies for loose or missing screws, bolts, or nuts.</p> <p><i>b.</i> Inspect dial lights and rear connector for looseness and damage.</p> <p><i>c.</i> Inspect cover and chassis for damage, missing parts, and condition of finish. Inspect condition of finish and lettering on front panel.</p> <p><i>Note.</i> Touchup painting is recommended instead of refinishing whenever practicable. Screwheads, binding posts, and plated fastener parts will not be painted or polished with abrasives.</p>	<p><i>a.</i> Screws, bolts, and nuts will be tight; none missing.</p> <p><i>b.</i> No looseness or damage evident.</p> <p><i>c.</i> No damage or missing parts evident. External surfaces intended to be painted will not show bare metal. Panel lettering will be legible.</p>
2	N/A	Controls may be set to any position.	<p><i>a.</i> Rotate the VOL control through its limits of travel.</p> <p><i>b.</i> Rotate the power switch from OFF to PWR, then to TEST.</p> <p><i>c.</i> Rotate the kilocycle selector through its 20 positions.</p> <p><i>d.</i> Rotate the megacycle selector through its 19 position.</p>	<p><i>a.</i> Control will rotate freely without binding or excessive looseness.</p> <p><i>b.</i> Operates freely without binding and rubbing against the panel. Switch should have positive detent action.</p> <p><i>c.</i> Operates freely without binding or excessive looseness. Switch should have positive detent action.</p> <p><i>d.</i> Same as <i>c</i> above.</p>
3	N/A	N/A	Check the control unit for applicable modification work orders (para 4-5).	None.



**NOTE:**

— INDICATES EQUIPMENT MARKINGS.

EL6625-820-45-CI-TM-20

Figure 4-3. Control unit test.

**4-10. Course Indicator ID-1347/ARN-82 Physical Tests and Inspection**

*a. Equipment and Materials.* Not required.

*b. Test Connections and Conditions.* Remove the OBS indicator from the test set. Disconnect P6 from the OBS indicator

*c. Procedure.*

Step	Control settings		Test procedure	Performance standard
	Test equipment	Equipment under test		
1	N/A	The OBS indicator may be set to any position.	<p><i>a.</i> Inspect the connector for bent pins and cracked insulation.</p> <p><i>b.</i> Inspect the meter glass for cracks or scratches.</p> <p><i>c.</i> Inspect the meter housing for the condition of the finish. Inspect the condition of the lettering on the front knob.</p> <p><i>d.</i> Rotate the OBS indicator knob.</p>	<p><i>a.</i> No bent pins or cracked insulation evident.</p> <p><i>b.</i> No cracks or scratches evident.</p> <p><i>c.</i> Surfaces intended to be painted will not show bare metal. Lettering will be legible.</p> <p><i>d.</i> Knob operates freely without binding or excessive looseness.</p>
2	N/A	N/A	Check the OBS indicator for applicable modification work orders (para 4-5).	




Figure 4-4. OBS indicator and test set precision bearing test.



#### 4-12. Test Set, Radio TS-2500/ARM-92 and TS-2500A/ARM-92 Physical Tests and Inspection

*a. Test Equipment and Materials.* None required.

*b. Test Connections and Conditions.* Remove the test set front panel.

*c. Procedure.*

Control settings			Test procedure	Performance standard
Step	Test equipment	Equipment under test		
1	N/A	Controls may be set in any position.	<ul style="list-style-type: none"> <li><i>a.</i> Inspect all controls and switches for loose or missing screws, bolts, or nuts.</li> <li><i>b.</i> Inspect insulation of wiring for cuts or pinches.</li> <li><i>c.</i> Inspect soldered connections for cold-soldered connections.</li> <li><i>d.</i> Inspect terminal board for cracks.</li> <li><i>e.</i> Inspect all connectors for pins and cracked insulation.</li> <li><i>f.</i> Inspect the case and chassis for damage, missing parts, and condition of finish. Inspect the condition of the lettering on the front panel.</li> </ul>	<ul style="list-style-type: none"> <li><i>a.</i> Screws, bolts, and nuts will be tight; none missing.</li> <li><i>b.</i> No cuts or pinches evident.</li> <li><i>c.</i> No soldered connections evident.</li> <li><i>d.</i> No cracks evident.</li> <li><i>e.</i> No bent pins or cracked insulation evident.</li> <li><i>f.</i> No damage or missing parts evident. External surfaces intended to be painted will not show bare metal. Panel lettering will be legible.</li> </ul>
2	N/A	Controls may be in any position.	<ul style="list-style-type: none"> <li><i>a.</i> Set the VOR/LOC-GLIDE SLOPE switch to VOR/LOC and to GLIDE SLOPE.</li> <li><i>b.</i> Set the BRG-OBS switch to BRG and to OBS.</li> <li><i>c.</i> Set the BEARING switch to each of its 12 positions.</li> <li><i>d.</i> Rotate the compass simulator control on the COM-PASS SIMULATOR.</li> <li><i>e.</i> On Test Set, Radio TS-2500A/ARM-92 only, set the RECEIVER MODEL switch to A and B positions.</li> </ul> <p>Check test set for applicable modification work orders (para 4-5)</p>	<ul style="list-style-type: none"> <li><i>a.</i> Switch operates freely without binding or excessive looseness. Switch should have positive detent action.</li> <li><i>b.</i> Same as a above.</li> <li><i>c.</i> Same as a above.</li> <li><i>d.</i> Control operates freely without binding and rubbing against the panel. Operates with no excessive looseness.</li> <li><i>e.</i> Same as a above.</li> </ul>
3	N/A	N/A		None.

Change 2 4-15

TM 11-6625-820-45




Figure 4-5. Test set compass simulator and Indicator, RMI ID-250A/ARN test.

#### 4-14. Glide-Slope Frequency Information Test

- a. Test Equipment and Materials.* Multimeter ME-26(\*)/U is required for the following procedure.
- b. Test Connections and Conditions.* Remove all power from the test set. Connect the equipment as shown in figure 4-6 with the COMMON lead of the ME-26(\*)/U connected to pin J of P2.
- c. Procedure.*

Step	Control settings		Test procedure	Performance standard
	Test equipment	Equipment under test		
	ME-26(*)/U SELECTOR switch: OHMS RANGE switch: RX10	C-6873/ARN-82 Power switch: OFF  Megacycle and kilocycle selectors: 108.00	<p><i>a.</i> Connect the OHMS lead of ME-26(*)/U to pin P of GLIDE SLOPE connector J4 on the test set.</p> <p><i>b.</i> Connect the OHMS lead of ME-26(*)/U to pin G of J4.</p> <p><i>c.</i> Connect the OHMS lead of ME-26(*)/U to pin D of J4.</p> <p><i>d.</i> Connect the OHMS lead of ME-26(*)/U to pin A of J4.</p> <p><i>e.</i> Set the megacycle and kilocycle selectors on the control unit to 110.20. Connect the OHMS lead of ME-26(*)/U to pin B of J4.</p> <p><i>f.</i> Connect the OHMS lead of ME-26(*)/U to pin E of J4.</p> <p><i>g.</i> Connect the OHMS lead of ME-26(*)/U to pin F of J4.</p> <p><i>h.</i> Connect the OHMS lead of ME-26(*)/U to pin S of J4.</p> <p><i>i.</i> Set the megacycle and kilocycle selectors on the control unit to 110.40. Connect the OHMS lead of ME-26(*)/U to pin R of J4.</p>	<p><i>a.</i> ME-26(*)/U should indicate 0 ohm.</p> <p><i>b.</i> ME-26(*)/U should indicate 0 ohm.</p> <p><i>c.</i> ME-26(*)/U should indicate 0 ohm.</p> <p><i>d.</i> ME-26(*)/U should indicate 0 ohm.</p> <p><i>e.</i> ME-26(*)/U should indicate 0 ohm.</p> <p><i>f.</i> ME-26(*)/U should indicate 0 ohm.</p> <p><i>g.</i> ME-26(*)/U should indicate 0 ohm.</p> <p><i>h.</i> ME-26(*)/U should indicate 0 ohm.</p> <p><i>i.</i> ME-26(*)/U should indicate 0 ohm.</p>




Figure 4-7. Meter movement accuracy test.

Checkpoint	Performance standard	Checkpoint	Performance standard
kilocycle selectors to 108.00 VOL control on control unit set fully clockwise.	light. The 26 VAC PWR and LOC PWR lamps on the aid box light. The control unit panel lamps light. The 1.0 FREQ SELECT (MC) lamps A and D on the aid box light. The 0.1 FREQ SELECT (MC) lamps B and E on the aid box light. The 0.01 FREQ SELECT (MC) lamp B on the aid box lights. The FLAG meter indicates 250 microamperes $\pm 15$ . The DEVIATION meter indicates 75 microamperes $\pm 5$ to the right of 0. The TO-FROM meter indicates 500 microamperes $\pm 25$ to the left of 0. TS-585A/U indicates 100 milliwatts $\pm 15$ .	(8) Megacycle and kilocycle selectors set to 114.30.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps B and D, 0.1 FREQ SELECT (MC) lamps B and C, and 0.01 FREQ SELECT (MC) lamp B, and lamp lights.
(3) Megacycle and kilocycle selectors set to 109.05.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps A and E, and 0.1 FREQ SELECT (MC) lamps B and E light.	(9) Megacycle and kilocycle selectors set to 115.36.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps C and D, 0.1 FREQ SELECT (MC) lamps B and C light.
(4) Megacycle and kilocycle selectors set to 110.10.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps B and E, 0.1 FREQ SELECT (MC) lamps A and B, and 0.01 FREQ SELECT (MC) lamp B light.	(10) Megacycle and kilocycle selectors set to 116.40.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps C and E, 0.1 FREQ SELECT (MC) lamps B and D, and 0.01 FREQ SELECT (MC) lamp B light.
(6) Megacycle and kilocycle selectors set to 111.15.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps A and B, and 0.1 FREQ SELECT (MC) lamps A and B light.	(11) Megacycle and kilocycle selectors set to 117.45.	The LOC PWR, 1.0 FREQ SELECT (MC) lamps D and E, and 0.1 FREQ SELECT (MC) lamps B and D. light.
(6) Megacycle and kilocycle selectors set to 112.20.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps A and C, 0.1 FREQ SELECT lamps (MC) A and C, and 0.01 FREQ SELECT lamp (MC) B light.	(12) Megacycle and kilocycle selectors set to 118.50.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps A and D, 0.1 FREQ SELECT (MC) lamps B, C, and D, 0.01 lamp B, and COMM lamp light.
(7) Megacycle and kilocycle selectors set to 113.25.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps B and C, 0.1 FREQ SELECT lamps (MC) A and C light.	(13) Megacycle and kilocycle selectors set to 119.56.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps A and E, 0.1 FREQ SELECT (MC) lamps C and D, and COMM lamp light.
		(14) Megacycle and kilocycle selectors set to 120.60.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps B and E, 0.1 FREQ SELECT (MC) lamps C and E, 0.01 FREQ SELECT (MC) lamp B, and COMM lamp light.
		(15) Megacycle and kilocycle selectors set to 121.65.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps A and B, 0.1 FREQ SELECT (MC) lamps C and E, and COMM lamp light.

Checkpoint	Performance standard
(16) Megacycle and kilocycle selectors set to 122.70.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps A and C, 0.1 FREQ SELECT (MC) lamps D and E, 0.01 FREQ SELECT (MC) lamp B, GS/LOC ON lamp, and COMM lamp light.
(17) Megacycle and kilocycle selectors set to 123.76.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps B and C, 0.1 FREQ SELECT (MC) lamps D and E, and COMM lamp light.
(18) Megacycle and kilocycle selectors set to 124.80.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps B and D, 0.1 FREQ SELECT (MC) lamps A and D, 0.01 FREQ SELECT (MC) lamp B, and COMM lamp light.
(19) Megacycle and kilocycle selectors set to 125.86.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps C and D, 0.1 FREQ SELECT (MC) lamps A and D, and COMM lamp light.
(20) Megacycle and kilocycle selectors set to 126.90.	The LOC PWR, 26 VAC PWR, 1.0 FREQ SELECT (MC) lamps C and E, 0.1 FREQ SELECT (MC) lamps A and E, 0.01 FREQ SELECT (MC) lamp B, GS/LOC ON lamp, and COMM lamp light.
(21) Megacycle and kilocycle selectors set to 126.95.	The LOC PWR, 26 VAC, PWR, 1.0 FREQ SELECT (MC) lamps C and E, 0.1 FREQ SELECT (MC) lamps A and E, and COMM lamp light.
(22) TS-585A/U connected to the AUDIO terminals on the test ret.	No less than 25 milliwatts indicated on TS-585A/U.
(23) VOL control on the control unit set fully counterclockwise	Zero Milliwatts indicated on TS-585A/U.

Checkpoint	Performance standard
(24) Power switch on the control unit set to TEST.	TEST lamp on the aid box lights.

*c. OBS Indicator and Test Set Precision BEARING Test.*

Checkpoint	Performance standard
(1) OBS indicator adjusted for a null indication on AN/USM-140A.	300° should be indicated on the OBS indicator.
(2) BRG-OBS switch set to BRG, and the BEARING switch set to 300.	The null indication on AN/USM-140 will not change.
(3) TS-2500A/ARM-92 only.	
(a) Indicator test set SYNCHRO SELECTOR on EZ SYNCHRO METER zeroed.	(a) 297 to 300° indicated on the OBS indicator.
(b) OBS course index rotated counterclockwise.	(b) Indicator test set SYNCHRO METER deflects to the right.
(c) Indicator test set SYNCHRO SELECTOR on EZ, SYNCHRO METER zeroed.	(c) 27 to 33° indicated on OBS indicator.
(d) OBS course index rotated counterclockwise.	(d) Indicator test set SYNCHRO METER deflects to the left
(4) TS-2500A/ARM-92 only.	
(a) AC voltages read for each setting of test set BEARING switch.	Voltage within limits set in test procedure,

*d. Test Set COMPASS SIMULATOR and Indicator, RMI ID-250A/ARN Test.*

Checkpoint	Performance standard
(1) VOR/LOC-GLIDE SLOPE switch set to VOR/LOC, megacycle and kilocycle selectors set to 108.00, and the power	The VOR/LOC DC, VOR/LOC AC, and GS DS lamps on the test set light. The 26 VAC PWR, LOC PWR, 1.0 FREQ SELECT (MC) lamps A and D, 0.1 FREQ SE-

Checkpoint	Performance standard
<p>switch set to PWR.</p> <p>(2) Rotate the COMPASS SIMULATOR.</p> <p>(3) Set the COMPASS SIMULATOR to N.</p> <p>(4) Press, and then release, the SERVO AMP TEST pushbutton switch.</p>	<p>LECT (MC) lamps B and E, and 0.1 FREQ SELECT (MC) lamp B on the aid box light. The FLAG meter indicates 250 microamperes <math>\pm 15</math>. The DEVIATION meter indicates 75 microamperes <math>\pm 5</math> to the right of 0. The TO-FROM meter indicates 500 microamperes <math>\pm 25</math> to the left of 0.</p> <p>RMI card follows the COMPASS SIMULATOR within <math>2^\circ</math>.</p> <p>RMI needle number 1 indicates <math>180^\circ \pm 1</math>. RMI card indicates <math>0^\circ \pm 1</math>.</p> <p>The FLAG meter indicates 0 with the SERVO AMP TEST pushbutton switch pressed, and 250 microampere <math>\pm 15</math> with the SERVO AMP TEST pushbutton released.</p>






*e. Glide-Slope Frequency Information Test.*

Checkpoint	Performance standard
(1) Power switch set to OFF. Megacycle and kilocycle selectors set to 108.00. Resistance between J of P2 and P of J4.	0 ohm.
(2) Resistance between J of P2 and G of J4.	0 ohm.
(3) Resistance between J of P2 and D of J4.	0 ohm.
(4) Resistance between J of P2 and A of J4.	0 ohm.
(5) Megacycle and kilocycle selectors set to 110.20. Resistance between J of P2 and B of J4.	0 ohm.
(6) Resistance between J of P2 and E of J4.	0 ohm.
(7) Resistance between J of P2 and F of J4.	0 ohm.
(8) Resistance between J of P2 and S of J4.	0 ohm.
(9) Megacycle and kilocycle selectors set to 110.40. Resistance between J of P2 and R of J4.	0 ohm.

*f. Meter Movement Accuracy Tests.*

Checkpoint	Performance standard
(1) The COMMON post of TS-682A/GSM-1 connected to b of P2, and the 500 UA current jack connected to a of P2. Output of the TS-682A/GSM-1 set to 500 microampere.	The FLAG meter indicates 500 microamperes $\pm 10$ .
(2) The COMMON post of TS-682A/GSM-1 connected to Z of P2, and the 1MA current jack connected to Y of P2. output of the TS-682A/GSM-1 is set to 1 milliampere.	The TO-FROM meter indicates 1,000 microamperes $\pm 20$ .
(3) The COMMON post of TS-682A/GSM-1 connected to m of P2, and the 200 UA current pack connected to n of P2. Output of the TS-682A/GSM-1 set to 150 microamperes.	The DEVIATION meter indicates 150 microamperes $\pm 3$ to the left of 0.
(4) The COMMON post of TS-682A/GSM-1 connected to n of P2 and the 200 UA current jack connected to m of P2. Output of the TS-682A/GSM-1 set to 150 microamperes.	The DEVIATION meter indicates 150 microamperes $\pm 3$ to the right of 0.


### COLOR CODE MARKING FOR MILITARY STANDARD RESISTORS



### COLOR CODE TABLE

BAND A		BAND B		BAND C		BAND D*	
COLOR	FIRST SIGNIFICANT FIGURE	COLOR	SECOND SIGNIFICANT FIGURE	COLOR	MULTIPLIER	COLOR	RESISTANCE TOLERANCE (PERCENT)
BLACK	0	BLACK	0	BLACK	1		
BROWN	1	BROWN	1	BROWN	10		
RED	2	RED	2	RED	100		
ORANGE	3	ORANGE	3	ORANGE	1,000		
YELLOW	4	YELLOW	4	YELLOW	10,000	SILVER	± 10
GREEN	5	GREEN	5	GREEN	100,000	GOLD	± 5
BLUE	6	BLUE	6	BLUE	1,000,000		
PURPLE (VIOLET)	7	PURPLE (VIOLET)	7				
GRAY	8	GRAY	8	SILVER	0.01		
WHITE	9	WHITE	9	GOLD	0.1		

### EXAMPLES OF COLOR CODING



\*If Band D is omitted, the resistor tolerance is ± 20%, and the resistor is not Mil-Std.

STD-R2

Figure 4-8. Color-code marking for MIL-STD resistors.

## APPENDIX

### REFERENCES

Following is a list of applicable references available to general support and depot maintenance personnel of Test Set, Radio AN/ARM-92 and AN/ARM-92A.

TB Sig 355-1	Depot Inspection Standard for Repaired Signal Equipment.
TB Sig 355-2	Depot Inspection Standard for Refinishing Repaired Signal Equipment.
TB Sig 355-3	Depot Inspection Standard for Moisture and Fungus Resistant Treatment.
TM 11-2535B	Meter Test Set TS-682A/GSM-1.
TM 11-5017	Output Meters TS-585A/U, TS-585B/U, TS-585C/U, and TS-585D/U.
TM 11-5826-211-50	Depot Maintenance Manual: Radio Magnetic Indicator ID-250A/ARN.
TM 11-5826-226-35	Direct Support, General Support, and Depot Maintenance Manual: Radio Receiving Sets AN/ARN-82 and AN/ARN-82A.
TM 11-6625-200-12	Operator and Organizational Maintenance Manual: Multimeters ME-26A/U, ME-26B/U, and ME-26C/U.
TM 11-6625-320-12	Organizational Maintenance Manual: Voltmeter, Meter ME-30A/U and Voltmeters, Electronic ME-30B/U, ME-30C/U, and ME-30E/U.
TM 11-6625-492-12	Operator and Organizational Maintenance Manual: Test Set, Resolver AN/ASM-101.
TM 11-6625-535-15	Organizational, DS, GS, and Depot Maintenance Manual: Oscilloscope AN/USM-140A.
TM 11-6625-588-15	Organizational, DS, GS, and Depot Maintenance Manual: Modulator MD-83A/ARN, Including Repair Parts and Special Tool Lists.
TM 11-6625-820-12	Organizational Maintenance Manual: Test Set, Radio AN/ARM-92 and AN/ARM-92A.



**APPENDIX B**

**DIRECT SUPPORT, GENERAL SUPPORT, AND**

**DEPOT REPAIR PARTS**

---

**Section I. INTRODUCTION**

**B-1. General**

This appendix lists the quantities of repair parts, Section II, for general support and depot maintenance and is a basis for requisitioning authorized parts. It is also a guide for depot maintenance in establishing initial categories of spare parts.

*Note.* No special tools, test, and support equipment are required.

**B-2. Explanation of Columns**

An explanation of the columns is given below.

*a. Sequence Number Column.* This column is for sequential line item control, commencing with the first line item on the first page of the list, and continuing numerically to the last item on the page of the list.

*b. For Authorized Allowance See Sequence Number Column.* This column lists the numerical sequence number for items that have more than one occurrence throughout the list and refers to the first occurrence for authorized allowances.

*c. Source, Maintenance, and Recoverability Code Column.* Source, maintenance, and recoverability codes indicate the commodity command responsible for supply, the maintenance category at which an item is stocked, categories at which an item is installed or repaired, and whether an item is repairable or salvageable. The source code column is divided into four parts.

(1) *Column A.* This column indicates the materiel code and designates the area of responsibility for supply. AR 310-1 defines the

basic numbers used to identify the materiel code. If the part is electronic materiel responsibility, the column is left blank.

(2) *Column B.* This column indicates the point within the maintenance system where the part is available. Source codes and their explanations are as follows:

Code	Explanation
<i>P</i>	Applies to repair parts that are stocked in or supplied from the GSA/DSA, or Army supply system, and authorized for use at indicated maintenance categories.
<i>X1</i>	Applies to repair parts that are not procured or stocked, the requirement for which will be supplied by the use of next higher assembly or component.
<i>X2</i>	Applies to repair parts that are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.

*Note.* "AH" and "MD" applies to parts that require manufacture or assembly at a category higher than that authorized for installation will indicate in the source code column the higher category.

(3) *Column C.* This column indicates the lowest maintenance category authorized to install the part.

Code	Explanation
<i>O</i>	Organizational Maintenance
<i>H</i>	General Support Maintenance

(4) *Column D.* The symbol in this column indicates whether the item is repairable or salvageable. Recoverability code and its explanation is as follows:

Code	Explanation
------	-------------

R — Applies to repair parts and assemblies that are economically repairable at DSU and GSU activities and normally are furnished on an exchange basis.

d. *Federal Stock Number Column.* This column lists the 11-digit Federal stock number.

e. *Indent Code Column.* This column indicates the breakdown of each given part or assembly. Components, assemblies, and subassemblies are listed in top-down order. That is, the assemblies which are part of a component are listed immediately below that component, and the subassemblies which are part of an assembly are listed immediately below that assembly.

f. *Description Column.* The Federal item name, a five-digit manufacturer's code, and a part number are included in this column.

g. *Unit of Issue Column.* The unit of issue is the supply term by which the individual item is counted for procurement, storage, requisitioning, allowances, and issue purposes.

h. *Expendability Column.* Nonexpendable items are indicated by NX. Expendable items are not annotated.

i. *Quantity in Use Column.* This column lists the quantity of each part found in a given assembly or component. "A/R" indicates that the item may be requisitioned "as required"; however, estimated minimum quantities may be stocked to cover immediate needs.

j. *Quantity Per Equipment Column.* This column lists the total quantity of each part, assembly, or component required for use in the overall equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF". "A/R" indicates that the item may be requisitioned "as required"; however, estimated minimum quantities may be stocked to cover immediate needs.

k. *Direct Support Column.* No parts authorized for stockage at this category.

l. *General Support Column.* This column indicates quantities of repair parts authorized for initial stockage for use in general support maintenance. The quantities are based on 100 equipments to be maintained for a 15-day period.

m. *Depot Column.* The numbers in this column indicate quantities of repair parts au-

thorized for depot maintenance and for initial stockage for maintenance, and for supply support to lower categories. The entries are based on the quantity required for rebuild of 100 equipments.

n. *Illustrations Column.*

(1) *Figure number.* This column lists the figure number used for the identification of the items in the illustration or text of the technical manual.

(2) *Item Number.* This column lists the item number used for the identification of the items in the illustration or text of the technical manual.

(3) *Reference symbol.* This column lists the reference symbols used for the identification of the items in the illustration or text of the technical manual.

### B-3. Parts for Maintenance

When this equipment is used for electronic service organizations organic to the theater headquarters or communication zones to provide theater communications, those repair parts authorized up to and including general support are authorized for stockage by the organization operating this equipment

### B-4. Requisitioning Information

a. The allowance factors are based on 100 equipments. In order to determine the number of parts authorized for initial stockage for the specific number of equipments supported, the following formula will be used and carried out to two decimal places.

$$\text{Specific number of equipments supported} \times \frac{\text{allowance factor}}{100} =$$

Number of parts authorized for initial dockage.

b. Fractional values obtained from above computation will be rounded to whole numbers as follows :

(1) When the total number of parts authorized is less than 0.5, the quantity authorized will be zero.

(2) When the total number of parts authorized is between 0.5 and 1.0, the quantity authorized will be one.

(3) For all values above one, fractional values below 0.5 will revert to the next lower whole number and fractional value 0.5 and above will advance to the next higher whole number.

c. The quantities determined in accordance with the above computation represent the initial stockage for a 15-day period.

#### **B-5. Location of Repair Parts**

Follow the procedures given in a through c below.

a. Use the table of contents to locate the appropriate appendix of the repair parts list.

b. If the figure number, item number and/or reference designation is available, locate the item by scrutiny of columns 14, 15, and/or 16 of the repair parts list.

c. If the figure number, item number and/or reference designation is not known, check the description column (column 6) in the repair parts list to locate the part.

## SECTION 11. REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE

B-4

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SOURCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A001					6625-999-5118	A	TEST SET, RAD AN/ARM-92 13499: 522-1459-001 (This Item is nonexchangeable)									2-2		
A002			AH	H	R	6625-944-9750	B	CASE ASSY, TOP CW-878/ ARM-92 13499: 762-1492-001	EA	NX	1	1						
A003			X2	H			C	CASE, TOP 74284: 021-0381-020	EA		1	1						
A004			AH	O	R	6625-930-8064	C	WIRING HARNESS AIRCFT TS-2501/ARM-92 13499: 758-5434-001	EA	NX	1	1						
A005			X2	H			D	PANEL ASSY 13499: 758-5434-003	EA		1	1				2-6		
A006			X2	H			E	PANEL 13499: 762-1663-003	EA		1	1				2-6		
A007			P	O		6240-155-7836	E	LAMP 96906: MS25237-327	EA		17	26	5.6	300.0	2-6		DS1 thru DS17	
A008			P	H		6210-995-4297	E	HOLDER, LAMP 72619: 162-8430-9	EA		17	20	4.6	60.0	2-7		XDS1 thru XDS17	
A009			P	O		6210-892-4386	E	LENS, RED 72619: 162-931	EA		17	20	1.4	60.0	2-6			
A010			P	H		5935-685-9661	E	CONNECTOR 77820: PT02A12-10P	EA		1	1	0.5	3.0	2-6		J1	
A011			P	H		5935-617-5387	E	CONNECTOR 09922: BT02A20-41P	EA		1	2	0.8	6.0	2-6		J2	
A012			X2	H			E	VARNISH, OIL-BLUE 08800: 7526	GA		AR	AR						
A013			MD	H			E	BOARD ASSY, WIRED 13499: 758-5434-004	EA		1	1			2-7			
A014			P	H		5961-079-1698	F	DIODE 07688: 1N961B	EA		1	1	0.5	3.0	2-7		CR1	
A015			P	H		5905-965-5558NJ	F	RESISTOR 81349: RN55D1962F	EA		1	1	0.5	3.0	2-7		R2	



1	2	3				4	5	6	7	8	9	10	11	12	13	14	15	16	
SEQUENCE NUMBER	FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	SOURCE MAINTENANCE AND REC CODE				FEDERAL STOCK NUMBER	IDENT CODE	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY IN USE	QTY PER EQUIP	DIRECT SUPPORT	GENERAL SUPPORT	DEPOT	ILLUSTRATIONS			
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL	
A016	A019	P	H			5905-965-9116	F	RESISTOR 81349; RN55D3322F	EA		1	1		0.5	3.0	2-7		R5	
A017		P	H			5905-965-9052AU	F	RESISTOR 81349; RN55D1002F	EA		1	1		0.5	3.0	2-7		R6	
A018		P	H			5905-681-9969	E	RESISTOR 81349; RC07GF332J	EA		1	1		0.5	3.0	2-7		R8	
A019		X2	H			5940-204-8298	F	TERMINAL BOARD 88245; 1180	EA		1	2					2-7		TB1
A020		MD	H				E	BOARD ASSY, WIRED 13499; 758-5434-005	EA		1	1					2-7		
A021		P	H			5905-988-2317	F	RESISTOR 81349; RN60D1001F	EA		2	2		0.8	6.0	2-7			R1, R4
A022		P	H			5905-965-9118AU	F	RESISTOR 81349; RN55D5110F	EA		1	1		0.5	3.0	2-7			R3
A023		P	H			5905-279-1757	F	RESISTOR 81349; RC20GF152J	EA		1	1		0.5	3.0	2-7			R7
A024		X2	H			5940-204-8298	F	TERMINAL BOARD 88245; 1180	EA		1	Ref					2-7		TB2
A025		X2	H			5305-054-5648	E	SCREW 96906; MS51957-14	EA		8	20					2-6		
A026		X2	H			5310-042-9609	E	WASHER, LOCK 96906; MS35338-78	EA		8	16					2-7		
A027		X2	H				E	SCREW 77250; P343-0386-00	EA		4	6					2-6		
A028		X2	H			5310-685-2791	E	NUT 77250; P313-0132-00	EA		8	33					2-7		
A029		X2	H			4020-656-1257	E	TAPE 82110; 18H	FT		AR	AR					2-7		
A030		X2	H			5970-729-3351	E	TUBING, ELEC 81851; TEFTW22B	FT		1	1					2-7		
A031		X2	H			6145-623-7224	E	WIRE, ELEC 90484; WTE730A2	FT		2	38					2-7		

B-6

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEQUENCE NUMBER	3 SOURCE MAIN. TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A032		X2	H			E	WIRE, ELEC 90484; WTE730A915	FT		1	20					2-7		
A033		X2	H		6145-754-8057	E	WIRE, ELEC 90484; WTE730A0	FT		2	41					2-7		
A034		X2	H			E	WIRE, ELEC 90484; WTE730A902	FT		1	18					2-7		
A035		X2	H			E	WIRE, ELEC 90484; WTE730A926	FT		1	10					2-7		
A036		X2	H			E	WIRE, ELEC 90484; WTE730A916	FT		1	10					2-7		
A037		X2	H			E	WIRE, ELEC 90484; WTE730A93	FT		1	18					2-7		
A038		X2	H			E	WIRE, ELEC 90484; WTE730A92	FT		1	18					2-7		
A039		X2	H			E	WIRE, ELEC 90484; WTE730A91	FT		1	19					2-7		
A040		X2	H			E	WIRE, ELEC 90484; WTE730A90	FT		1	19					2-7		
A041		X2	H		6145-548-0969	E	WIRE, ELEC 90484; WTE730A9	FT		1	16					2-7		
A042		X2	H			E	WIRE, ELEC 90484; WTE730A905	FT		1	18					2-7		
A043		X2	H			E	WIRE, ELEC 90484; WTE730A925	FT		1	10					2-7		
A044		X2	H			E	WIRE, ELEC 90484; WTE730A913	FT		1	21					2-7		
A045		X2	H			E	WIRE, ELEC 90484; WTE730A906	FT		1	15					2-7		
A046		X2	H			E	WIRE, ELEC 90484; WTE730A912	FT		1	20					2-7		
A047		X2	H		6145-754-8058	E	WIRE, ELEC 90484; WTE730A3	FT		1	23					2-7		

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A048		X2	H		6145-557-3591	E	WIRE, ELEC 90484; WTE730A4	FT		1	18				2-7			
A049		X2	H		6145-623-7225	E	WIRE, ELEC 90484; WTE730A5	FT		1	18				2-7			
A050		X2	H		6145-578-6824	E	WIRE, ELEC 90484; WTE730A6	FT		1	18				2-7			
A051		X2	H		6145-578-6975	E	WIRE, ELEC 90484; WTE730A7	FT		1	18				2-7			
A052		X2	H			E	WIRE, ELEC 90484; WTE730A95	FT		1	18				2-7			
A053		X2	H			E	WIRE, ELEC 90484; WTE730A923	FT		1	10				2-7			
A054		X2	H			E	WIRE, ELEC 90484; WTE730A903	FT		1	18				2-7			
A055		X2	H		6145-581-9324	E	WIRE, ELEC 90484; WTE730A1	FT		1	21				2-7			
A056		X2	H			E	WIRE, ELEC 90484; WTE730A96	FT		1	17				2-7			
A057		X2	H			E	WIRE, ELEC 90484; WTE730A935	FT		1	10				2-7			
A058		X2	H			E	WIRE, ELEC 90484; WTE730A936	FT		1	10				2-7			
A059		X2	H		6145-578-6978	E	WIRE, ELEC 90484; WTE730A8	FT		1	25				2-7			
A060		X2	H		6145-160-4775	E	WIRE, ELEC 70567; 00702-1322	FT		2	3				2-7			
A062		X2	H			D	BOX, MOD 13499; 762-1663-001	EA		1	1				2-6			
A067		X2	H			D	COVER, MOD 13499; 762-1663-002	EA		1	1							
A072	A026				5310-042-9609	D	WASHER, LOCK 96909; MS35338-78	EA		6	Ref				2-6			

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14 ILLUSTRATIONS			15	16
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL		
A073			MD	H		D	PLATE, IDENT 13499; 762-1711-002	EA		1	1					2-6				
A074			X2	H	5305-054-5635	D	SCREW 96906; MS51957-1	EA		2	4					2-6				
A075			X2	H	5340-264-7182	D	BUMPER, RUBBER 75543; 747R	EA		4	4									
A076			X2	H	5305-054-6653	D	SCREW 96906; MS51957-29	EA		4	4									
A077			X2	H	5310-262-6105	D	NUT, HEX 77250; P313-0045-00	EA		4	16									
A078			X2	H	5310-616-3555	D	WASHER, LOCK 96906; MS35333-71	EA		4	9									
A081			X2	H	5305-054-5647	D	SCREW 96906; MS51957-13	EA		6	14					2-6				
A084			X2	H		C	HOLDER 13499; 762-1559-001	EA		1	1									
A100			X2	H		C	ADHESIVE 71984; RTV732 TRANSLUCENT	EA		AR	AR									
A101			MD	H		C	NAMEPLATE 13499; 762-1712-001	EA		1	1									
A102			MD	H		C	NAMEPLATE 13499; 762-1711-001	EA		1	1									
A103			X2	H	5320-817-0728	C	RIVET, TUBULAR 96906; MS16535-53	EA		4	4									
A104			X2	H		B	CASE ASSY, BOTTOM 13499; 762-1555-001	EA		1	1					2-2				
A105			X2	H		C	BRACKET 13499; 762-1553-001	EA		1	2					2-2				
A109	A100					C	ADHESIVE 71984, RTV732 TRANSLUCENT	EA		AR	Ref									
A110			X2	H		C	CASE, BOTTOM 13499; 762-1555-004	EA		1	1					2-2				

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS			
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL	
A111	A106		X2	H		C	COVER, STOWAGE 13499; 762-1565-002	EA		1	1					2-2			
A118			X2	H		C	BRACKET DIVIDER 13499; 762-1564-002	EA		1	1						2-2		
A119			X2	H		D	BRACKET 13499; 762-1564-001	EA		1	1						2-2		
A120			X2	H		5325-587-8476	D	GROMMET 96906; MS21266-2N	EA		AR	AR					2-2		
A121			P	H		5325-171-4365	C	RECEPTACLE 71286; 212-12N	EA		1	1		0.4	2.0		2-2		
A122			X2	H		5320-584-0672	C	RIVET 96906; MS20426AD3-6	EA		2	2					2-2		
A123			X2	H		5310-857-5547	C	NUT 96906; MS21044D06	EA		11	11					2-2		
A124			X2	H		5305-054-6652	C	SCREW 96906; MS51957-28	EA		11	11					2-2		
A126			AH	O	R	6625-926-4420	B	TEST SET TS-2500/ARM-92 13499; 762-1676-001	EA	NX	1	1					2-3		
A127			X2	H			C	PANEL 13499; 762-1554-002	EA		1	1					2-3		
A129			P	H		5325-937-4382	D	RECEPTACLE 13499; 762-1556-001	EA		2	2		0.8	6.0		2-3		
A130						5310-866-3506	D	NUT, CLINCH 72962; F12NC FMA2-62	EA		8	Ref					2-3		
A131			AH	O	R	6625-944-9758	C	CABLE ASSY CX-11568 ARM-92 13499; 762-1493-001	EA	NX	1	1					2-3		
A132			P	H		5935-539-2659	D	CONNECTOR 96906; MS3106A14S5S	EA		1	2		0.8	6.0		2-3		P1
A133			X2	H		5935-666-4860	D	CLAMP 96906; MS3057-6	EA		1	1					2-3		

B-10

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE TO USE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A134		X2	H		5970-840-4813	D	TUBING, ELEC 75037; 3003TEMFLEX105CLR12	FT		1	1					2-3		
A135		X2	H		5970-856-1463	D	SLEEVING, ELEC 81851; VS3-0	FT		8	8					2-3		
A136	A134					D	TUBING, ELEC 75037; 3003TEMFLEX105CLR12	FT		1	Ref					2-3		
A137		X2	H			D	WIRE, ELEC 90484; BUB728N8	FT		9	9					2-3		
A138		X2	H		6145-542-6194	D	WIRE, ELEC 90484; BUB728N0	FT		9	9					2-3		
A139		X2	H		6145-669-6710	D	WIRE, ELEC 90484; BUB728N9	FT		9	9					2-3		
A140		X2	H		6145-803-0663	D	WIRE, ELEC 90484; BUB728N2	FT		9	9					2-3		
A144		X2	H			C	BRACKET ASSY 13499; 762-1707-001	EA		1	1					2-3		
A145		X2	H		5305-054-6651	D	SCREW, MACH 96906; MS51957-27	EA		1	8					2-3		
A146		MD	H			D	BRACKET 13499; 762-1661-000	EA		1	1					2-3		
A147		P	H		5935-149-3427	D	CONNECTOR 96906; MS3102A14S5P	EA		1	1		0.5	3.0		2-3		J5
A148		X2	H		5305-054-5649	D	SCREW, MACH 96906; MS51957-15	EA		4	4					2-3		
A149	A028				5310-685-2791	D	NUT, HEX 77250; P313-0132-00	EA		14	Ref					2-3		
A150		X2	H		5310-208-4662	D	NUT, HEX 77250; P313-0062-00	EA		1	6					2-3		
A151		X2	H		5310-595-7154	D	WASHER, LOCK 78189; 1720-02	EA		1	7					2-3		
A152	A027					D	SCREW, MACH 77250; P343-0386-00	EA		2	Ref					2-4		

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A153	A077					5310-262-6105	D	NUT, HEX 77250; P313-0045-00	EA		5	Ref				2-3		
A154		X2	H			5310-167-0874	D	WASHER, LOCK 81350; AN936A3	EA		2	2				2-4		
A155		X2	H				D	POST, AL 13499; 540-9041-000	EA		2	2				2-4		
A156	A081					5305-054-5647	D	SCREW, MACH 96906; MS51957-13	EA		5	Ref				2-4		
A157		X2	H				D	WASHER, LOCK 96906; MS35333-70	EA		17	28				2-4		
A158		X2	H			5940-061-0050	D	STANDOFF 91663; RTMT16M	EA		1	1				2-4		
A159		P	H			5950-903-4357	D	TRANSFORMER 97315; BC3258	EA		1	1		0.5	3.0	2-3		T1
A160		P	H			5950-738-9448	D	TRANSFORMER 73386; 36747	EA		1	1		0.5	3.0	2-3		T2
A161		P	H			5945-500-7924	D	RELAY 77523; 22700-20	EA		1	1		0.5	3.0	2-3		K1
A162		P	H			5945-685-9205	D	RELAY 77523; 22700-19	EA		1	1		0.5	3.0	2-3		K2
A163		X2	H			5940-171-0156	D	TERMINAL BOARD 71785; 1513	EA		1	1				2-4		TB2
A164		X2	H				D	TERMINAL BOARD 13499; 762-1677-000	EA		1	1				2-4		TB1
A165		X2	H				E	TERMINAL STRIP 13499; 762-1677-001	EA		1	1				2-4		
A166		X2	H				E	TERMINAL 95264; 45503	EA		26	26				2-4		
A167		P	H			5905-681-1197	D	RESISTOR, VAR 81349; RA20LASB102A	EA		1	1		0.5	3.0	2-4		R1
A168		P	H			5905-577-7504	D	RESISTOR 81349; RN60D1211F	EA		1	1		0.5	3.0	2-4		R2

1	2	3				4	5	6	7	8	9	10	11	12	13	14			15	16										
		SOURCE DESCR. VOLUME AND DOC CODE														FEDERAL STOCK NUMBER	IDENT CODE	DESCRIPTION			UNIT OF MEAS.	RESPONSIBILITY	QTY IN USE	QTY PUS REQD	IMPACT SUPPORT	GENERAL SUPPORT	DEPOT	ILLUSTRATIONS		
		A	B	C	D																							FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A100		P	H			5905-000-0897	D	RESISTOR 81349; RN60D3740F	EA		1	1		0.5	3.0	2-4			R3											
A170		P	H			5905-683-2238	D	RESISTOR 81349; RC07GF103J	EA		1	1		0.5	3.0	2-4			R4											
A171		P	H			5905-905-9356	D	RESISTOR 81349; RL32S271G	EA		1	1		0.5	3.0	2-5			R5											
A172		P	H			5905-573-1489	D	RESISTOR 81349; RL07S472J	EA		2	2		0.8	6.0	2-5			R6, R7											
A173A		P	H			5961-892-0889	D	DIODE 81349; JAN-1N938	EA		1	1		0.5	3.0	2-5			CR1											
A174		P	H			5961-617-4347	D	DIODE 07688; 1N645	EA		1	1		0.5	3.0	2-4			CR2											
A175		X2	H			5340-598-0296	D	CLAMP 09922; HP7N	EA		1	1				2-3														
A177	A078					5310-616-3555	D	WASHER, LOCK 96906; MS35333-71	EA		5	Ref				2-3														
A178		X2	H				D	TERMINAL LUG 78189; 2104-04-01-2520N	EA		2	2				2-3														
A179	A029					4020-656-1257	C	TAPE 82110; 18H	FT		AR	Ref				2-4														
A180		AH	O	R		5826-920-7107	C	CONTROL C-6873/ARN-82 13499; 522-4408-001	EA	NX	1	1				2-2														
A186		P	H			3020-944-8084	D	PLATE, GEAR-FR 13499; 761-8803-001	EA		1	1		0.4	2.0	5-8														
A187		X1					E	PLATE, GEAR-FR 13499; 763-6120-001	EA		1	1				5-8		33												
A188		X1				5325-281-6331	E	STUD 72794; PF3 1-2CADPL	EA		4	4				5-8														
A189		X1				5340-201-0272	E	SPRING, HEL. 72794; PS3 1-2CADPL	EA		4	4				5-8														
A190		X1				5325-291-9360	E	CUP 72794; PC3 1-2CADPL	EA		4	4				5-8														



1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A191		X1				E	BEARING, BALL 13499; 553-8762-002	EA		2	2				5-8			
A192		X2	H		5310-894-0226	E	NUT, SELF-LKG 72962; F22NCFMA2-40	EA		1	3				5-8			
A193		P	H		5355-926-5294	D	KNOB ASSY 13499; 553-8755-002	EA		2	2		0.5	6.0	5-8			
A194		X1				E	KNOB-COAXIAL 13499; 553-8748-002	EA		1	2				5-8	4, 12		
A195		X1				E	SKIRT, KNOB 13499; 553-8754-002	EA		1	2				5-8			
A196		X1			8040-877-9872	E	ADHESIVE 71984; SILASTICRTV731-50Z	EA		AR	AR				5-8			
A197		X2	H			D	PLATE 13499; 761-8804-001	EA		1	1				5-8			
A198		X2	H			E	PLATE, RETAINING 13499; 763-6118-001	EA		1	1				5-8	181		
A199	A192				5310-894-0226	E	NUT, SELF-LKG 72962; F22NCFMA2-40	EA		2	REF				5-8			
A200		P	H		3020-945-0022	D	GEAR, SPUR 13499; 761-8805-001	EA		2	2		0.5	6.0	5-8			
A201		X1				E	SHAFT, GEAR 13499; 761-0217-002	EA		1	2				5-8	126, 127		
A202		X1				E	GEAR, SPUR 13499; 763-6104-001	EA		1	2				5-8			
A203		P	H		5930-947-6156	D	SWITCH, ROTARY 15909; 38KM3C500M	EA		1	1		0.7	5.0	5-8	38		
A204	A007				6240-155-7836	D	LAMP, INCAND 96906; MS25237	EA		2	REF				5-8	8, 18	DS1, 2	
A205		P	H		6210-083-8503	D	LAMPHOLDER 08817; 855029-0	EA		2	2		0.8	6.0	5-8	6, 16	XDS1, 2	

B-14

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SITE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A206		P	H			D	LIGHT, INDICATOR 08817; 855890R	EA		2	2		0.8	6.0	5-8	191		
A207		X2	H		5940-682-9416ZX	D	TERMINAL LUG 77147; SPL4040-4HOTTINNED	EA		1	1				5-8	192		
A208		X2	H		5310-261-7549	D	WASHER, LOCK 79807; 310-3340-000	EA		12	12				5-8	193		
A209		X2	H		5310-622-1724	D	NUT, SELF-LKG 72962; 68-1660-26	EA		1	1				5-8	48		
A210		X2	H		5310-840-2658	D	NUT, SELF-LKG 72962; 68-1660-40	EA		4	10				5-8	134, 174		
A211		X2	H			D	NUT, HEX 77250; P334-0257-00	EA		2	2				5-8	41, 52		
A212		X2	H			D	SETSCREW 08664; 335-0021-00	EA		8	8				5-8	2, 3, 5, 11, 13, 15		
A213		X2	H		5305-705-3934	D	SETSCREW 96906; MS51053-412	EA		4	4				5-8	42, 43, 49, 50		
A214		X2	H		5305-770-2533	D	SCREW, MACH 96906; MS51959-13	EA		4	5							
A215		X2	H		5305-764-2966	D	SCREW, MACH 96906; MS51959-2	EA		1	1				5-8	26		
A216		X2	H			D	SCREW, MACH 77250; P343-0020-00	EA		1	1				5-8	9		
A217	A025				5305-054-5648	D	SCREW, MACH 96906; MS51957-14	EA		6	REF							
A218		X2	H		5305-879-2366	D	SCREW, MACH 77250; P347-0006-00	EA		8	8							
A219		X2	H		5305-687-6267	D	SCREW, MACH 77250; P347-0020-00	EA		6	6				5-8	21		

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A220	A151	X2	H		5305-802-2456	D	SCREW, MACH 77250; P347-0033-00	EA		4	4				5-8	27, 29	R1	
A221								5310-595-7154	D	WASHER, LOCK 78189; 1720-02	EA		2	REF				
A222		X2	H		5905-933-3471	D	WASHER, LOCK 78189; 1214-05	EA		2	2				5-8	40, 53		
A223		P	H			D	RESISTOR, VAR 01121; GA2G032S501TZ	EA		1	1		0.2	3.0	5-8	55		
A224		X2	H		5310-684-9760	D	POST, ELEC-MECH 13499; 540-9041-003	EA		4	4				5-8	35, 58		
A225		X2	H			D	POST, ELEC-MECH 13499; 544-3428-002	EA		4	4				5-8	34, 61		
A226		X2	H		D	WASHER 13499; 548-9537-003	EA		1	1					5-8	10		
A227		X2	H		D	KNOB-BAR 13499; 549-3468-002	EA		2	2					5-8	1, 14		
A228		X2	H		D	GEAR, SPUR-POT 13499; 553-8749-002	EA		2	2					5-8	44, 51		
A229		X2	H		D	MASK, DIAL 13499; 553-9588-002	EA		1	1					5-8	23		
A230		X2	H		D	SHIELD, MASK 13499; 553-9605-002	EA		1	1					5-8	47		
A231		X2	H		D	PANEL, LIGHTING 13499; 763-6101-001	EA		1	1					5-8	19		
A232		X2	H		D	PLATE, GEAR 13499; 763-6109-001	EA		2	2					5-8	39, 54		
A233	X2	H		D	COVER, CONTROL 13499; 763-6119-001	EA		1	1					5-8	189			
A234	A012				D	VARNISH 08800; 7526	GA		AR	REF				5-8				
A235		AH	H	R	D	CONTROL SUBASSY 13499; 761-8806-001	EA		1	1				5-8				

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14 ILLUSTRATIONS			15 FIGURE NUMBER	16 ITEM NUMBER	REFERENCE SYMBOL
		A	B	C	D																
A236		P	H			5355-944-8081	E	DIAL, CONTROL 13499; 761-8807-001	EA		1	1		0.2	2.0	5-8					
A237		X1					F	DIAL, CONTROL 13499; 756-2431-002	EA		1	1				5-8					
A238		X1					G	GEAR, SPUR 13499; 553-9616-003	EA		1	1				5-8	101				
A239		X1					G	DRUM, LT-DIAL 13499; 756-2449-005	EA		1	1				5-8		93			
A240		X1					G	PLATE, DRIVE 13499; 757-4536-001	EA		1	6				5-8		92			
A241		X1					F	DIAL, CONTROL 13499; 756-2433-002	EA		1	1				5-8					
A242		X1					G	BUSHING, SLV 13499; 553-9581-002	EA		1	1				5-8		90			
A243		X1					G	DRUM, LTD DIAL 13499; 756-2471-005	EA		1	1				5-8		89			
A244	A240						G	PLATE, DRIVE 13499; 757-4536-001	EA		2	REF				5-8		84, 87			
A245		X1					F	GEAR, CLUSTER 13499; 761-8808-001	EA		1	1				5-8					
A246		X1					G	GEAR, SPUR 13499; 763-6107-001	EA		1	1				5-8		104			
A247		X1					G	GEAR, SPUR 13499; 549-3430-002	EA		1	1				5-8		102			
A248		X1					G	PLATE, LKG 13499; 549-3431-002	EA		1	1				5-8		103			
A249		X2	H				E	PLATE, GEAR-LEFT 13499; 761-8809-001	EA		1	1				5-8					
A250		X2	H				F	PLATE, GEAR-LEFT 13499; 763-6116-001	EA		1	1				5-8		107			
A251		X2	H				F	PIN, SHOULDERED 13499; 549-3471-002	EA		1	1				5-8					

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A252		X2	H			F	STRAP, DIAL 13499; 549-3475-002	EA		1	1				5-8			
A253		X2	H		5320-828-3304	F	RIVET, TUBULAR 96906; MS16535-56	EA		1	1				5-8			
A254		X2	H			E	PLATE, GEAR-R 13499; 761-8810-001	EA		1	1				5-8			
A255		X2	H			F	PLATE, GEAR 13499; 763-6115-001	EA		1	1				5-8	70		
A256		X2	H			F	PIN, SHOULDERED 13499; 549-3470-002	EA		1	1				5-8			
A257		P	H		5355-944-9935	E	DIAL, CONTROL 13499; 761-8811-001	EA		1	1		0.2	2.0	5-8			
A258		X1				F	GEAR, SPUR-DIAL 13499; 549-3443-002	EA		1	1				5-8	77		
A259		X1				F	DIAL, CONTROL 13499; 761-8812-001	EA		1	1				5-8			
A260		X1				G	GEAR, CLUSTER 13499; 761-8813-001	EA		1	1				5-8			
A261		X1				H	GEAR, SPUR 13499; 549-3438-002	EA		1	1				5-8	78		
A262		X1				H	GEAR, SPUR 13499; 763-6105-001	EA		1	1				5-8	80		
A263		X1				H	PLATE, LOCKING <del>13499; 549-3439-002</del>	EA		1	1				5-8	79		
A264		X1				G	BRUM, LT. DIAL <del>13499; 756-2473-006</del>	EA		1	1				5-8	82		
A265		X1				G	SPACER, SLV. <del>13499; 757-4536-001</del>	EA		1	1				5-8			
A266		X1				G	WASHER, SPRING <del>13499; 757-4537-001</del>	EA		1	1				5-8	81		
A267	A240					G	PLATE, DRIVE <del>13499; 757-4538-001</del>	EA		1	REF				5-8	83		

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A268		X1				F	DIAL, CONTROL 13499; 756-2435-002	EA		1	1				5-8			
A269		X1				G	BUSHING, SLV 13499; 756-2436-002	EA		1	1				5-8	86		
A270		X1				G	DRUM, LT. DIAL 13499; 756-2470-005	EA		1	1				5-8	85		
A271	A240					G	PLATE, DRIVE 13499; 757-4536-001	EA		2	REF				5-8	88, 91		
A272		X2	H			E	PLATE, GEAR 13499; 761-8814-001	EA		1	1				5-8	135		
A273		X2	H			F	EYELET 90030; SE38CADPL	EA		2	2				5-8			
A274		X2	H			F	WASHER, FLAT 13499; 543-5613-003	EA		4	4				5-8			
A275		X2	H			F	BEARING 13499; 549-3482-002	EA		2	2				5-8			
A276		X2	H			F	PLATE, GEAR 13499; 763-6121-001	EA		1	1				5-8			
A277		X2	H			F	INSULATOR, BUSH 13499; 549-3484-002	EA		4	4				5-8			
A278		X2	H			F	CLIP, ELEC-LAMP 13499; 549-3483-002	EA		2	2				5-8			
A279		X2	H			F	PIN, STOP 13499; 763-6108-001	EA		1	2				5-8			
A280		X2	H			E	WHEEL, DETENT 13499; 761-8815-001	EA		1	1				5-8	141		
A281		X2	H			F	WHEEL, DETENT 13499; 763-6114-001	EA		1	1				5-8			
A282	A279					F	PIN, STOP 13499; 763-6108-001	EA		1	REF				5-8			
A283		X2	H			E	LUB. OIL 54527; 4254	EA		AR	AR				5-8			

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A284	A012					E	VARNISH 08800; 7526	GA		AR	REF				5-8			
A285		X2	H			E	GREASE 80805; BCN325	EA		AR	AR				5-8			
A286		P	O		6240-272-8601	E	LAMP, INCAND. 96906; MS25237-327R	EA		2	2		2.1	100.0	5-8	138, 166	DS5, 6	
A287		P	H		5930-945-0020	E	SWITCH SECTION 82104; 96804-720LR	EA		1	1		0.7	5.0	5-8	147	S2A	
A288		P	H		5930-945-0019	E	SWITCH SECTION 13499; 269-2452-00	EA		1	1		0.7	5.0	5-8	160	S1	
A289		P	H		5930-945-7585	E	SWITCH SECTION 76854; 253330RK	EA		1	1		0.7	5.0	5-8	149	S2B	
A290		P	H		5930-945-7586	E	SWITCH SECTION 76854; 253331RK	EA		1	1		0.7	5.0	5-8	156	S1B	
A291	A081				5305-054-5647	E	SCREW, MACH 96906; MS51957-13	EA		3	REF				5-8	137, 171		
A292		P	H		5930-945-0079	E	SWITCH SECTION 76854; 253341RK	EA		1	1		0.7	5.0	5-8	151	S2C	
A293		P	H		5930-945-0080	E	SWITCH SECTION 76854; 253342RK	EA		1	1		0.7	5.0	5-8	158	S1A	
A294		P	H		3110-100-6176	E	BALL, BEARING 43991; 309-5200-00	EA		2	2		0.8	6.0	5-8	144, 163		
A295		X2	H			E	WASHER, LOCK 96906; MS35338-77	EA		6	6				5-8	31, 119, 66		
A296	A026				5310-042-9609	E	WASHER, LOCK 96906; MS35338-78	EA		2	REF				5-8			
A297		X2	II		5310-966-5689	E	WASHER, FLAT 79807; 310-6340-00	EA		4	4				5-8			
A298	A210				5310-840-2658	E	NUT, SELF-LKG 72962; 68-1660-10	EA		6	REF				5-8	133, 179, 180		

B-20

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A299			X2	H		E	NUT, HEX 95548: 334-1124-00	EA		2	2				5-8	96, 100		
A300			X2	H		E	SETSCREW 08664; 335-0010-00	EA		4	4				5-8	142, 167		
A301			X2	H	5305-638-5629	E	SETSCREW 08664; 335-0033-00	EA		4	4				5-8	123, 124, 128, 129		
A302			X2	H		E	RING, RETAINING 96906: MS16624-12	EA		4	4				5-8	74, 105, 122, 131		
A303			X2	H	5340-282-0782	E	RING, RETAINING 89462: 5100-25C	EA		2	2				5-8	62, 111		
A304			X2	H	5340-663-1245	E	RING, RETAINING 96906: MS16632-1031	EA		4	4				5-8	69, 71, 95, 108		
A305	A214				5305-770-2533	E	SCREW, MACH 96906: MS51959-13	EA		1	REF				5-8			
A306			X2	H	5305-054-5636	E	SCREW, MACH 96906: MS51957-2	EA		4	4				5-8	120, 65		
A307			X2	H		E	SCREW, MACH 77250: P343-0439-00	EA		4	4				5-8	153, 154		
A308			X2	H	5305-515-7087	E	SCREW, MACH 88044: AN500C2-10	EA		1	1				5-8	113		
A309	A025				5305-054-5648	E	SCREW, MACH 96906: MS51957-14	EA		2	REF				5-8	190		
A310			X2	H		E	SCREW, MACH 13499: 347-0267-00	EA		1	1				5-8	110		
A311			X2	H	5310-540-8275	E	SLEEVE, SPACING 13499: 541-5983-002	EA		8	8				5-8	148, 150, 157, 159		



1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A312		X2	H			E	SLEEVE, SPACING 13499; 541-5985-002	EA		4	4				5-8	146, 161		
A313		X2	H			E	WASHER, FLAT 13499; 545-7536-003	EA		4	8				5-8	118, 67		
A314		X2	H			E	WASHER, FLAT 13499; 545-7548-003	EA		3	3				5-8	63, 76, 112		
A315		P	H		5820-941-6838	E	GEAR, SPUR 13499; 549-3436-002	EA		2	2		0.8	6.0	5-8	106, 75		
A316		X2	H			E	SHAFT, STRAIGHT 13499; 549-3437-002	EA		1	1				5-8	64		
A317		P	H		5930-917-9866	E	DETENT, COUNTER 13499; 768-1027-001	EA		1	1		0.4	2.0	5-8	68		
A318		P	H		5826-944-8083	E	DETENT, DIAL 13499; 549-3498-003	EA		1	1		0.4	2.0	5-8	115		
A319		X2	H			E	DIAL, SCALE 13499; 553-9345-003	EA		1	1				5-8	97		
A320		X2	H			E	SPACER, SLEEVE 13499; 553-9598-002	EA		2	2				5-8	98, 99		
A321		X2	H			E	SHAFT, STRAIGHT 13499, 763-6112-001	EA		1	1				5-8	73		
A322		P	H		3020-944-9940	E	GEAR, SPUR 13499, 763-6103-001	EA		2	2		0.8	6.0	5-8	125, 130		
A323		X2	H			E	HOUSING, DETENT 13499; 763-6110-001	EA		1	1				5-8	165		
A324		X2	H			E	SHAFT, SHOULDERED 13499; 763-6117-001	EA		2	2				5-8	145, 162		
A325		X2	H			E	SPRING, HEL 13499; 763-6113-001	EA		1	1				5-8	143		
A326		P	H		5826-945-7587	E	WHEEL, DETENT 13499; 763-6114-002	EA		1	1		0.4	2.0	5-8	168		

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A327		P	H			3020-852-6414	E	GEAR, CLUSTER 13499; 761-8816-001	EA		1	1		0.4	2.0	5-8	72	
A328		X1					F	GEAR 13499; 763-6102-001	EA		1	2				5-8		
A329		X1					F	BUSHING, SLV 13499; 763-6111-001	EA		1	2				5-8		
A330		X1					F	GEAR, SPUR 13499; 763-6106-001	EA		1	2				5-8		
A331		X2	H				F	WASHER, FLAT 13499; 761-5316-007	EA		1	2				5-8		
A332		P	H			3020-944-8087	E	GEAR, CLUSTER 13499; 761-8817-001	EA		1	1		0.4	2.0	5-8	94	
A333	A328						F	GEAR 13499; 763-6102-001	EA		1	REF				5-8		
A334	A329						F	BUSHING, SLV 13499; 763-6111-001	EA		1	REF				5-8		
A335	A331						F	WASHER, FLAT 13499; 761-5316-007	EA		1	REF				5-8		
A336	A330						F	GEAR, SPUR 13499; 763-6106-001	EA		1	REF				5-8		
A337		MD	H				D	WIRING HARNESS 13499; 761-8818-001	EA		1	1				5-8		
A338	A011					5935-617-5387	E	CONNECTOR 09922; BT02A20-41P	EA		1	REF				5-8	187	J1
A339		X2	H				E	WIRE, ELEC 90484; LTE734ACW0	FT		1	1						
A340		X2	H				E	WIRE; ELEC 90484; LTE734ACW1	FT		2	2						
A341		X2	H				E	WIRE, ELEC 90484; LTE734ACW2	FT		1	1						

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A342		X2	H			E	WIRE, ELEC 90484; LTE734ACW3	FT		1	1							
A343		X2	H			E	WIRE, ELEC 90484; LTE734ACW4	FT		1	1							
A344		X2	H			E	WIRE, ELEC 90484; LTE734ACW5	FT		1	1							
A345		X2	H			E	WIRE, ELEC 90484; LTE734ACW6	FT		1	1							
A346		X2	H			E	WIRE, ELEC 90484; LTE734ACW9	FT		1	1							
A347		X2	H			E	WIRE, ELEC 90484; LTE734ACW90	FT		1	1							
A348		X2	H			E	WIRE, ELEC 90484; LTE734ACW91	FT		1	1							
A349		X2	H			E	WIRE, ELEC 90484; LTE734ACW92	FT		1	1							
A350		X2	H			E	WIRE, ELEC 90484; LTE734ACW93	FT		1	1							
A351		X2	H			E	WIRE, ELEC 90484; LTE734ACW95	FT		1	1							
A352		X2	H			E	WIRE, ELEC 90484; LTE734ACW96	FT		1	1							
A353		X2	H			E	WIRE, ELEC 90484; LTE734ACW902	FT		1	1							
A354		X2	H			E	WIRE, ELEC 90484; LTE734ACW903	FT		1	1							
A355		X2	H			E	WIRE, ELEC 90484; LTE734ACW905	FT		1	1							
A356		X2	H			E	WIRE, ELEC 90484; LTE734ACW906	FT		1	1							

B-24

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A357		X2	H			E	WIRE, ELEC 90484; LTE734ACW912	FT		1	1							
A358		X2	H			E	WIRE, ELEC 90484; LTE734ACW913	FT		1	1							
A359		X2	H			E	WIRE, ELEC 90484; LTE734ACW915	FT		1	1							
A360		X2	H			E	WIRE, ELEC 90484; LTE734ACW916	FT		1	1							
A361		X2	H			E	WIRE, ELEC 90484; LTE734ACW923	FT		1	1							
A362		X2	H			E	WIRE, ELEC 90484; LTE734ACW925	FT		1	1							
A363		X2	H			E	WIRE, ELEC 90484; LTE734ACW926	FT		1	1							
A364		X2	H			E	WIRE, ELEC 90484; LTE734ACW935	FT		1	1							
A365		X2	H			E	WIRE, ELEC 90484; LTE734ACW936	FT		1	1							
A366		X2	H			E	WIRE, ELEC 90484; LTE734ACW956	FT		1	1							
A367		X2	H			E	WIRE, ELEC 90484; LTE734ACW7	FT		1	1							
A368		X2	H			E	WIRE, ELEC 90484; LTE734ACW8	FT		1	1							
A369		X2	H		6145-822-3481	E	WIRE, ELEC 90484; WTE22A	FT		1	1							
A370	A029				4020-656-1257	E	TAPE 82110; 18H	FT		12	REF							
A371		X2	H			D	WASHER 13499; 553-5130-003	EA		2	2				5-8	7, 17		

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SOURCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A372	A313					D	WASHER, FLAT 13499, 545-7536-003	EA		4	REF				5-8			
A373		P		H	5826-985-9171	C	INDICATOR, ID-1347/ARN-82 13499; 522-4414-001	EA		1	1		0.7	5.0	2-2			
A378		X1				D	COURSE, SEL IND 65092; 253528	EA		1	1				2-2			
A379		X1				D	FILLER, ENGRAV 08854; LAQSTIKBLK	EA		AR	AR				2-2			
A380		X1				D	PLATE, INSTR 13499; 280-3441-00	EA		1	1				2-2			
A381		X2		H		D	RIVET, BLIND 07707; AD32AB5	EA		2	2				2-2			
A382		MD		H		D	PLATE, IDENT 13499; 767-0556-00	EA		1	1				5-8	184		
A383		P		H	5826-305-3094	C	INDICATOR, ID-250A/ARN 19315; 36109-1L11A2	EA		1	1		0.7	5.0	2-2			
A384		P		H	6625-966-1958	C	SIMULATOR, COMP 24363; EI-1001-1	EA		1	1		0.7	5.0	2-2		DS4	
A385		X1				D	SYNCHRO 24363; 100121	EA		1	1				3-1	21	B1	
A386		X1				D	HOUSING, REAR 24363; 100102	EA		1	1				3-1	23		
A387		X2		H		D	SCREW 24363; 110104-4	EA		7	7				3-1	20, 30		
A388		X2		H		D	LOCK WASHER 24363; 210104-4	EA		7	7				3-1	19, 29		
A389		X2		H		D	CLAMP, SYNCHRO 24363; 100122	EA		3	3				3-1	18		
A390		X1				D	DIAL 24363; 100118	EA		1	1				3-1	12		

B-26

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SOURCE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14 ILLUSTRATIONS			15	16
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL		
A391		X2	H			D	SCREW 24363; 110102-2	EA		8	8					3-1	25			
A392		X2	H			D	LOCK WASHER 24363; 210102	EA		8	8					3-1	24			
A393		X2	H			D	GREASE 24363; 100137	EA		AR	AR					3-1				
A394		X1				D	GASKET 24363; 100127	EA		1	1					3-1	22			
A395		X1				D	COVER, FRONT 24363; 100104	EA		1	1					3-1	5			
A396		X1				D	SEAL, WINDOW 24363; 100116	EA		1	1					3-1	8			
A397		X1				D	GLASS 24363; 100123	EA		1	1					3-1	9			
A398		X2	H			D	SETSCREW 24363; 100108	EA		4	4					3-1	2, 3, 14, 15			
A399		X1				D	POINTER 24363, 100126	EA		1	1					3-1	11			
A400		X1				D	RETAINER, DIAL 24363; 100124	EA		1	1					3-1	10			
A401		X2	H			D	WASHER, SPRING 24363; 100114	EA		1	1					3-1	4			
A402		X1				D	KNOB 24363; 100113	EA		1	1					3-1	1			
A403		X1				D	SLEEVE, SHAFT 24363; 100125	EA		1	1					3-1	6			
A404		X1				D	GEAR, DRIVE 24363; 100110	EA		1	1					3-1	7			
A405		X1				D	GEAR, IDLER 24363, 100109	EA		1	1					3-1	16			

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A406		X2	H			D	STUD GEAR 24363; 100115	EA		1	1				3-1			
A407		X1				D	GASKET 24363; 100106	EA		1	1				3-1	27		
A408		X2	H			D	SLEEVING 24363; 500100-3	EA		AR	AR							
A409		X1				D	CONNECTOR 24363; 100105	EA		1	1				3-1	28	P1	
A410		X2	H			D	SOLDER 24363; 600100-1	EA		AR	AR							
A411		X1				D	HOUSING, SYNCHRO 24363; 100103-1	EA		1	1				3-1	17		
A412		X1				D	GEAR, SYNCHRO 24363; 100107	EA		1	1				3-1	13		
A413		MD	H			D	NAMEPLATE 24363; 100120-1	EA		1	1				3-1	26		
A414		X2	H		5305-637-1125	C	SCREW, MACHINE 96906; MS35214-29	EA		11	11				2-2			
A415	A077				5310-262-6105	C	NUT, HEX 77250; P313-0045-00	EA		4	REF				2-2			
A416		X2	H		5305-763-7822	C	SCREW, MACH 96906; MS51959-14	EA		3	3				2-2			
A417		X2	H		5305-770-2579	C	SCREW, MACH 96906; MS51959-15	EA		4	4				2-2			
A418		P	H		6625-842-9720	C	METER 13499; 458-0572-00	EA		1	1		0.6	4.0	2-2		M1	

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEQUENCE NUMBER	3 SOURCE MAINTENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A419		P	H		6625-966-1933	C	METER 55026; 8185	EA		1	1		0.6	4.0	2-2		M2	
A420		P	H		6625-966-1932	C	METER 55026; 8186	EA		1	1		0.6	4.0	2-2		M3	
A421		P	H		5930-966-0859	C	SWITCH 76854; 164680H2	EA		1	1		0.7	5.0	2-2		S3	
A422		P	H		5930-615-1383	C	SWITCH 81073; 30-1	EA		1	1		0.7	5.0	2-2		S4	
A423		P	H		5930-966-0846	C	SWITCH 81073; 440001-4-2N	EA		2	2		0.7	5.0	2-2		S1, 2	
A424	A009				6210-892-4386	C	LENS, RED 72619; 162-931	EA		3	REF				2-2			
A425	A008				6210-995-4297	C	HOLDER, LAMP 72619; 162-8430-9	EA		3	REF				2-2		XDS1-3	
A426		P	H		5920-284-7144	C	FUSE HOLDER 71400; HKPH	EA		6	6		2.0	20.0	2-2		XF1-6	
A427		P	H		5935-815-4623	C	JACK, PHONE 70674; D3649-4	EA		1	1		0.5	3.0	2-2		J3	
A428		P	H			C	BINDING POST 58474; DF30BC	EA		1	1		0.5	3.0	2-2		J2	
A429		P	H		5940-615-9110	C	BINDING POST 58474; DF30RC	EA		1	1		0.5	3.0	2-2		J1	
A430		MD	H			C	PLATE, IDENT 13499; 762-1713-001	EA		1	1				2-2			
A431	A074				5305-054-5635	C	SCREW, MACH 96906; MS51957-1	EA		2	REF				2-2			



1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A432			P	H		C	CONNECTOR 08051; KPT02A14-19P	EA		1	1		0.5	3.0	2-2		J4	
A433	A025				5305-054-5648	C	SCREW, MACH 96906; MS51957-14	EA		4	REF				2-2			
A434	A028				5310-685-2791	C	NUT, HEX 77250; P313-0132-00	EA		11	REF				2-2			
A437			X2	H		C	LUG, TERMINAL 77147; 4012HOTTINNED	EA		2	4							
A438			X2	H	5305-763-6963	C	SCREW, MACH 96906; MS51959-28	EA		1	1							
A439			P	H	5905-988-2314	C	RESISTOR 81349; RN60D200F	EA		1	1		0.5	3.0	2-3		R8	
A440	A007				6240-155-7836	C	LAMP 96906; MS25237-327	EA		3	REF				2-2		DS1-3	
A441			P	O	5920-280-4960	C	FUSE 81349; F02A250V2AS	EA		2	7		5.2	280.0	2-2		F1, 4	
A442			P	O	5920-280-8342	C	FUSE 81349; F02A250V1AS	EA		4	14		8.9	560.0	2-2		F2, 3, 5, 6	
A443			P	O	5355-680-1357	C	KNOB 96906; MS91528-1F2B	EA		2	2		0.8	6.0	2-2		O2 and O3	
A444			P	O	5355-579-6390	C	KNOB 96906; MS91528-3F2B	EA		1	1		0.5	3.0	2-2		O4	
A445			X2	H		C	CAD, DUST 77820; 10-101960-143	EA		1	1				2-2			

B-30

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14 ILLUSTRATIONS			15	16
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL		
A446		AH	H	R		C	CABLE ASSY 13499: 762-1708-001	EA		1	1				2-3					
A447		P	II		5935-866-2255	D	CONNECTOR 77820: PT06A20-41SSR	EA		1	2		0.8	6.0	2-3		P5			
A448		X2	H		5970-828-6411	D	TUBING, ELEC 81851: TEFTW24B	FT		1	4				2-3					
A449		X2	H			D	SLEEVING, ELEC 81851: VSO-O	FT		3	3				2-3					
A450	A029				4020-656-1257	D	TAPE S2110: 18H	FT		AR	REF				2-3					
A452	A051				6145-578-6975	D	WIRE, ELEC 90484: WTE730A7	FT		5	REF				2-3					
A453	A038					D	WIRE, ELEC 90484: WTE730A92	FT		5	REF				2-3					
A454		X2	H			D	WIRE, ELEC 90484: WTE730A9126	FT		5	23				2-3					
A455	A041				6145-548-0969	D	WIRE, ELEC 90484: WTE730A9	FT		5	REF				2-3					
A456	A040					D	WIRE, ELEC 90484: WTE730A90	FT		5	REF				2-3					
A457	A034					D	WIRE, ELEC 90484: WTE730A902	FT		5	REF				2-3					
A458	A056					D	WIRE, ELEC 90484: WTE730A96	FT		5	REF				2-3					

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											14 FIGURE NUMBER	15 ITEM NUMBER	16 REFERENCE SYMBOL
A459	A031					6145-623-7224	D	WIRE, ELEC 90484; WTE730A2	FT	10	REF				2-3			
A460	A049					6145-623-7225	D	WIRE, ELEC 90484; WTE730A5	FT	5	REF				2-3			
A461	A042						D	WIRE, ELEC 90484; WTE730A905	FT	5	REF				2-3			
A462	A037						D	WIRE, ELEC 90484; WTE730A93	FT	5	REF				2-3			
A463	A054						D	WIRE, ELEC 90484; WTE730A903	FT	5	REF				2-3			
A464	A052						D	WIRE, ELEC 90484; WTE730A95	FT	5	REF				2-3			
A465	A047					6145-754-8058	D	WIRE, ELEC 90484; WTE730A3	FT	5	REF				2-3			
A466	A032						D	WIRE, ELEC 90484; WTE730A915	FT	5	REF				2-3			
A467	A055					6145-581-9324	D	WIRE, ELEC 90484; WTE730A1	FT	5	REF				2-3			
A468	A046						D	WIRE, ELEC 90484; WTE730A912	FT	5	REF				2-3			
A469	A044						D	WIRE, ELEC 90484; WTE730A913	FT	5	REF				2-3			
A470	A039						D	WIRE, ELEC 90484; WTE730A91	FT	5	REF				2-3			

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE ALL SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14 ILLUSTRATIONS			15 ITEM NUMBER	16 REFERENCE SYMBOL
		A	B	C	D											FIGURE NUMBER	REFERENCE SYMBOL			
																		FIGURE NUMBER		
A471	A050					6145-578-6824	D	WIRE, ELEC 90484; WTE730A6	FT	5	Ref				2-3					
A472	A033					6145-754-8057	D	WIRE, ELEC 90484; WTE730A0	FT	5	Ref				2-3					
A473			X2	H			D	WIRE, ELEC 90484; STE730A9023	FT	5	22				2-3					
A476			AH	H	R		C	CABLE ASSY 13499; 762-1708-002	EA	1	1				2-3					
A477	A448					5970-828-6411	D	TUBING, ELEC 81851; TEFTW24B	FT	1	Ref				2-3					
A478	A029					4020-656-1257	D	TAPE 82110; 18H	FT		AR	Ref			2-3					
A480			P	H		5935-729-8683	D	CONNECTOR 77820; PT06A14-19SSR	EA	1	1		0.5	3.0	2-3			P6		
A481			X2	H			D	SLEEVING, ELEC 81851; VS2-0	FT	3	3				2-3					
A482	A047					6145-754-8058	D	WIRE, ELEC 90484; WTE730A3	FT	5	Ref				2-3					
A483	A055					6145-581-9324	D	WIRE, ELEC 90484; WTE730A1	FT	5	Ref				2-3					
A484			X2	H			D	WIRE, ELEC 90484; WTE730A956	FT	5	14				2-3					
A485	A473						D	WIRE, ELEC 90484; WTE730A9023	FT	5	Ref				2-3					
A486	A048					6145-557-3591	D	WIRE, ELEC 90484; WTE730A4	FT	5	Ref				2-3					
A487			X2	H			D	WIRE, ELEC 90484; WTE730A9025	FT	5	14				2-3					
A490			AH	O	R		C	CABLE ASSY 13499; 762-1664-001	EA	1	1				2-3					

1	2	3				4	5	6	7	8	9	10	11	12	13	14	15	16
SEQUENCE NUMBER	FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	SOURCE MAIN. TENANCE AND REC CODE				FEDERAL STOCK NUMBER	IDENT CODE	DESCRIPTION	UNIT OF ISSUE	EXPENDABILITY	QTY IN USE	QTY PER EQUIP	DIRECT SUPPORT	GENERAL SUPPORT	DEPOT	ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A491	A447					5935-866-2255	D	CONNECTOR 77820; PT06A20-41SSR	EA		1	Ref			2-3		P2	
A492	A448					5970-828-6411	D	TUBING, ELEC 81851: TEFTW24B	FT		2	Ref			2-3			
A493			P	H		5935-729-8688	D	CONNECTOR 77820; PT06A12-10SSR	EA		1	1	0.5	3.0	2-3		P3	
A494			X2	H		5970-284-9770	D	SLEEVING, ELEC 81851: VS7-160	FT		1	1			2-3			
A495			X2	H		5970-543-1136	D	SLEEVING, ELEC 81851: SVHC2-20-1	FT		1	1			2-3			
A496	A029					4020-656-1257	D	TAPE 82110: 18H	FT		AR	Ref			2-3			
A497			X2	H			D	TUBING 08795: RNF100-1BLK	EA		1	1			2-3			
A498			X2	H			D	SLEEVING, ELEC 81851: VS1-20	FT		7	7			2-3			
A499	A031					6145-623-7224	D	WIRE, ELEC 90484; WTE730A2	FT		18	Ref			2-3			
A500	A036						D	WIRE, ELEC 90484; WTE730A916	FT		9	Ref			2-3			
A501	A484						D	WIRE, ELEC 90484; WTE730A956	FT		9	Ref			2-3			
A502			X2	H			D	WIRE, ELEC 90484; WTE730A9123	FT		9	9			2-3			
A503	A473						D	WIRE, ELEC 90484; WTE730A9023	FT		9	Ref			2-3			
A504			X2	H			D	WIRE, ELEC 90484; WTE730A9125	FT		9	9			2-3			
A505	A487						D	WIRE, ELEC 90484; WTE730A9025	FT		9	Ref			2-3			

B-34

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14 ILLUSTRATIONS			15	16
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL		
A506			X2	H		D	WIRE, ELEC 90484; WTE730A9026	FT		9	9					2-3				
A507	A042					D	WIRE, ELEC 90484; WTE730A905	FT		9	Ref					2-3				
A508	A047				6145-754-8058	D	WIRE, ELEC 90484; WTE730A3	FT		9	Ref					2-3				
A509	A454					D	WIRE, ELEC 90484; WTE730A9126	FT		18	Ref					2-3				
A510	A055				6145-581-9324	D	WIRE, ELEC 90484; WTE730A1	FT		9	Ref					2-3				
A511	A054					D	WIRE, ELEC 90484; WTE730A903	FT		9	Ref					2-3				
A512	A034					D	WIRE, ELEC 90484; WTE730A902	FT		9	Ref					2-3				
A513	A056					D	WIRE, ELEC 90484; WTE730A96	FT		9	Ref					2-3				
A514	A052					D	WIRE, ELEC 90484; WTE730A95	FT		9	Ref					2-3				
A515	A037					D	WIRE, ELEC 90484; WTE730A93	FT		9	Ref					2-3				
A516	A033				6145-754-8057	D	WIRE, ELEC 90484; WTE730A0	FT		18	Ref					2-3				
A517	A058					D	WIRE, ELEC 90484; WTE730A936	FT		9	Ref					2-3				
A518	A057					D	WIRE, ELEC 90484; WTE730A935	FT		9	Ref					2-3				
A519	A043					D	WIRE, ELEC 90484; WTE730A925	FT		9	Ref					2-3				
A520	A035					D	WIRE, ELEC 90484; WTE730A926	FT		9	Ref					2-3				

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A521	A051					6145-578-6975	D	WIRE, ELEC 90484; WTE730A7	FT		9	Ref				2-3		
A522			X2	H			D	WIRE, ELEC 90484; WTE730A9256	FT		18	18				2-3		
A523			X2	H			D	WIRE, ELEC 90484; WTE730A9236	FT		9	9				2-3		
A524	A044						D	WIRE, ELEC 90484; WTE730A913	FT		9	Ref				2-3		
A525	A041					6145-548-0969	D	WIRE, ELEC 90484; WTE730A9	FT		9	Ref				2-3		
A526	A040						D	WIRE, ELEC 90484; WTE730A90	FT		9	Ref				2-3		
A527	A039						D	WIRE, ELEC 90484; WTE730A91	FT		9	Ref				2-3		
A528	A038						D	WIRE, ELEC 90484; WTE730A92	FT		9	Ref				2-3		
A529	A048					6145-557-3591	D	WIRE, ELEC 90484; WTE730A4	FT		9	Ref				2-3		
A530	A059					6145-578-6978	D	WIRE, ELEC 90484; WTE730A8	FT		9	Ref				2-3		
A531	A053						D	WIRE, ELEC 90484; WTE730A923	FT		9	Ref				2-3		
A532	A050					6145-578-6824	D	WIRE, ELEC 90484; WTE730A6	FT		9	Ref				2-3		
A533	A049					6145-623-7225	D	WIRE, ELEC 90484; WTE730A5	FT		9	Ref				2-3		
A534	A046						D	WIRE, ELEC 90484; WTE730A912	FT		9	Ref				2-3		
A535	A045						D	WIRE, ELEC 90484; WTE730A906	FT		9	Ref				2-3		

1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN- TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14 ILLUSTRATIONS			15	16
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL		
A536	A032					D	WIRE, ELEC 90484; WTE730A915	FT		9	Ref				2-3					
A537			X2	H		D	WIRE, ELEC 90484; WTE730A9235	FT		9	9				2-3					
A541			P	H	5935-201-7018	C	CONNECTOR 96906; MS3106A22-14S	EA		1	1		0.5	3.0	2-3			P4		
A542			X2	H	5935-280-2352AU	C	CLAMP 96906; MS3057-12A	EA		1	1				2-3					
A543	A150				5310-208-4662	C	NUT, HEX 77250; P313-0062-00	EA		5	Ref									
A544	A151				5310-595-7154	C	WASHER, LOCK 78189; 1720-02	EA		4	Ref									
A546	A077				5310-262-6105	C	WASHER, LOCK 77250; P313-0045-00	EA		3	Ref									
A547	A157					C	WASHER, LOCK 96906; MS35333-70	EA		11	Ref									
A549	A132				5935-539-2659	C	CONNECTOR 96906; MS3106A14S5S	EA		1	Ref				2-3			P1		
A550			X2	H	5935-280-2195	C	CLAMP 96906; MS3057-6A	EA		1	1				2-3					
A551	A037					C	WIRE, ELEC 90484; WTE730A93	FT		3	Ref				2-3					
A552	A052					C	WIRE, ELEC 90484; WTE730A95	FT		3	Ref				2-3					
A553	A034					C	WIRE, ELEC 90484; WTE730A902	FT		3	Ref				2-3					
A554	A054					C	WIRE, ELEC 90484; WTE730A903	FT		3	Ref				2-3					



1 SEQUENCE NUMBER	2 FOR AUTHORIZED ALLOWANCE SEE SEQUENCE NUMBER	3 SOURCE MAIN. TENANCE AND REC CODE				4 FEDERAL STOCK NUMBER	5 IDENT CODE	6 DESCRIPTION	7 UNIT OF ISSUE	8 EXPENDABILITY	9 QTY IN USE	10 QTY PER EQUIP	11 DIRECT SUPPORT	12 GENERAL SUPPORT	13 DEPOT	14-16 ILLUSTRATIONS		
		A	B	C	D											FIGURE NUMBER	ITEM NUMBER	REFERENCE SYMBOL
A555	A059					6145-578-6978	C	WIRE, ELEC 90484; WTE730A8	FT		15	Ref				2-3		
A556	A041					6145-548-0969	C	WIRE, ELEC 90484; WTE730A9	FT		1	Ref				2-3		
A557	A044						C	WIRE, ELEC 90484; WTE730A913	FT		6	Ref				2-3		
A558	A033					6145-754-8057	C	WIRE, ELEC 90484; WTE730A0	FT		16	Ref				2-3		
A559	A031					6145-623-7224	C	WIRE, ELEC 90484; WTE730A2	FT		8	Ref				2-3		
A560	A038						C	WIRE, ELEC 90484; WTE730A92	FT		3	Ref				2-3		
A561	A039						C	WIRE, ELEC 90484; WTE730A91	FT		4	Ref				2-3		
A562	A040						C	WIRE, ELEC 90484; WTE730A90	FT		4	Ref				2-3		
A563	A045						C	WIRE, ELEC 90484, WTE730A906	FT		5	Ref				2-3		
A564	A046						C	WIRE, ELEC 90484; WTE730A912	FT		5	Ref				2-3		
A565	A042						C	WIRE, ELEC 90484; WTE730A905	FT		1	Ref				2-3		
A566	A032						C	WIRE, ELEC 90484; WTE730A915	FT		5	Ref				2-3		
A567	A060					6145-160-4775	C	WIRE, ELEC 70567; 00702-1322	FT		1	Ref				2-3		
A568	A056						C	WIRE, ELEC 90484; WTE730A96	FT		2	Ref				2-3		
A569	A042						C	WIRE, ELEC 90484; WTE730A905	FT		2	Ref				2-3		



**4-7. Aid Box Test**

- a. *Test Equipment and Materials.* Multimeter ME-26(\*)/U is required for the following procedure.  
 b. *Test Connections and Conditions.* Connect the equipment as shown in A, figure 4-2.  
 c. *Procedure.*

Step	Control settings		Test procedure	Performance standard
	Test equipment	Equipment under test		
1	ME-26(*)/U SELECTOR switch: + RANGE switch: 30 v	TS-2500/ARM-92 VOR/LOC-GLIDE SLOPE: VOR/LOC BRG-OBS: OBS BEARING: C-6873/ARN-82 Megacycle and kilocycle selectors: 108.00 VOL control: maximum ccw Power switch: PWR	Connect the COMMON lead of ME-26(*)/U to the anode of CR1 in the aid box. Connect the dc lead of ME-26(*)/U to the cathode of CR1.	ME-26(*)/U should indicate 10 volts dc $\pm 0.05$ .
2	ME-26(*)/U SELECTOR switch: ohms RANGE switch: As required	C-6873/ARN-82 Power switch: OFF	<p>a. Connect the equipment as shown in figure 4-2. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin a of J2.</p> <p>b. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin X of J2.</p> <p>c. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin n of J2.</p> <p>d. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin Y of J2.</p> <p>e. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin b of J2.</p> <p>f. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin c of J2.</p> <p>g. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin B of J2.</p> <p>h. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin P of J2.</p> <p>i. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin N of J2.</p> <p>j. Connect the COMMON lead of ME-26(*)/U to pin J of J2 and the OHMS lead to pin E of J2.</p> <p>k. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin M of J2.</p> <p>l. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin Z of J2.</p> <p>m. Connect the COMMON lead of ME-26(*)/U to pin L of J2 and the OHMS lead to pin G of J1.</p> <p>n. Connect the COMMON lead of ME-26(*)/U to pin D of J1 and the OHMS lead to pin H of J1.</p> <p>o. Connect the COMMON lead of ME-26(*)/U to pin C of J1 and the OHMS lead to pin K of J1.</p> <p>p. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin t of J2.</p> <p>q. Connect the COMMON lead of ME-26(*)/U to pin of J2 and the OHMS lead to pin k of J2.</p> <p>r. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin p of J2.</p> <p>s. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin f of J2.</p> <p>t. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin W of J2.</p> <p>u. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin g of J2.</p> <p>v. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin V of J2.</p> <p>w. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin h of J2.</p> <p>x. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin U of J2.</p> <p>y. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin i of J2.</p> <p>z. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin T of J2.</p> <p>aa. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin j of J2.</p> <p>ab. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin S of J2.</p> <p>ac. Connect the COMMON lead of ME-26(*)/U to pin A of J2 and the OHMS lead to pin X of J2.</p> <p>ad. Connect the COMMON lead of ME-26(*)/U to pin K of J2 and the OHMS lead to pin X of J2.</p> <p>ae. Connect the COMMON lead of ME-26(*)/U to pin G of J1 and the OHMS lead to pin E of J1.</p> <p>af. Connect the COMMON lead of ME-26(*)/U to pin R of J2 and the OHMS lead to pin X of J1.</p>	<p>a. ME-26(*)/U should indicate 22,900 ohms <math>\pm 2,290</math>.</p> <p>b. ME-26(*)/U should indicate 0 ohm.</p> <p>c. ME-26(*)/U should indicate 0 ohm.</p> <p>d. None.</p> <p>e. ME-26(*)/U should indicate 0 ohm.</p> <p>f. ME-26(*)/U should indicate 1,000 ohms <math>\pm 100</math>.</p> <p>g. ME-26(*)/U should indicate 511 ohms <math>\pm 51</math>.</p> <p>h. ME-26(*)/U should indicate 1,000 ohms <math>\pm 100</math>.</p> <p>i. ME-26(*)/U should indicate 0 ohm.</p> <p>j. ME-26(*)/U should indicate 0 ohm.</p> <p>k. ME-26(*)/U should indicate 36,500 ohms <math>\pm 3,650</math>.</p> <p>l. ME-26(*)/U should indicate 42,500 ohms <math>\pm 4,250</math>.</p> <p>m. ME-26(*)/U should indicate 1,500 ohms <math>\pm 150</math>.</p> <p>n. ME-26(*)/U should indicate 0 ohm.</p> <p>o. ME-26(*)/U should indicate 0 ohm.</p> <p>p. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>q. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>r. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>s. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>t. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>u. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>v. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>w. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>x. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>y. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>z. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>aa. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>ab. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>ac. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>ad. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>ae. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p> <p>af. ME-26(*)/U should indicate 160 ohms <math>\pm 20</math>.</p>








Figure 4-9. Test Set, Radio TS-2500/ARM-92, schematic diagram.

- NOTES:
1. UNLESS OTHERWISE INDICATED, RESISTANCES ARE IN OHMS.
  2. ROTARY SWITCH VIEWED FROM DRIVEN END.
  3. CHASSIS GROUNDS ARE CONNECTED TO TERMINALS E1 AND E2.
  4. INDICATES EQUIPMENT MARKINGS.
  5. RECEPTACLE VIEWED FROM PIN OR RECEPTACLE SIDE.



6. ALL SWITCHES VIEWED IN OFF POSITION OR LOWEST FREQUENCY SETTING.










Figure 4-9.1. Test Set, Radio TS-2500A/ARM-92. schematic diagram (Sheet 2 of 2).

- NOTES:
1. UNLESS OTHERWISE INDICATED, RESISTANCES ARE IN OHMS.
  2. CHASSIS GROUNDS ARE CONNECTED TO TERMINALS E1 AND E2.
  3. INDICATES EQUIPMENT MARKINGS.
  4. RECEPTACLE VIEWED FROM PIN OR RECEPTACLE SIDE.






Figure 4-10. Control, Radio Set C-6873/ARN-82, schematic diagram.



**4-11. OBS Indicator and Test Set, Precision Bearing Test**

**a. Test Equipment and Materials.**

- (1) Modulator MD-83A/ARN.
- (2) Voltmeter, Meter ME-30(\*)/U.
- (3) Test Set, Resolver AN/ASM-101.
- (4) Test Set, Indicator
- (5) Oscilloscope AN/USM-140A.
- (6) Fabricated cables.

**b. Test Connections and Conditions.** Remove all power from the test set. In steps 1 and 2, connect the equipment as shown in figure 4-4. In step 3, connect the indicator test set jack J2 to test set plug P2 using cable fabricated in paragraph 4-4 (fig. 4-1.1). In step 4, apply power to test set and connect cable fabricated in paragraph 4-4 (fig. 4-1.2) to test set pendant cable plugs P2 and P3.


**c. Procedure.**

Control settings			Test procedure	Performance standard																																							
Step	Test equipment	Equipment under test																																									
1	<p>MD-83A/ARN POWER: ON 1000: OFF TONE LOCALIZER: 0 FUNCTION SELECTOR: SPECIFIC SIGNAL SPECIFIC SIGNAL SE- LECTOR: 30 VAR</p> <p>MASTER ATTENUATOR: midrange AN/ASM-101 Function switch: SET ORZ ME-30(*)/U Range: 10 v Power: ON AN/USM-140A POWER: ON</p> <p>Vertical selector: CHANNEL A Vertical AC-DC selector: AC calibrated SENSITIVITY: 5 VERNIER SENSITIVITY: maximum clockwise POLARITY: +UP VERTICAL POSITION: midrange Horizontal AC-DC selector: AC SWEEP TIME: 20 milli- seconds/cm VERNIER SWEEP TIME: maximum clockwise INTENSITY MODULA- TION: NORMAL SWEEP OCCURENCE: NORMAL HORIZONTAL DISPLAY: INTERNAL SWEEP X1 SWEEP MODE: FREE RUN TRIGGER SOURCE: INT TRIGGER LEVEL: midrange TRIGGER SLOPE: mid- range HORIZONTAL POSITION: midrange</p>	<p>C-6873/ARN-82 Power switch: OFF TS-2500/ARM-92 BRG-OBS: OBS BEARING: 300 TS-2500A/ARM-92 BRG-OBS: OBS BEARING: 300 RECEIVER MODEL: A</p>	<p>a. Adjust the INPUT LEVEL control on AN/ASM-101 for a 4.25-volt indication on ME-30(*)/U. Disconnect the ME-30(*)/U INPUT lead from the VOLTMETER connector on AN/ASM-101, and connect it to the OUTPUT connector on AN/ASM-101. Rotate the knob on the OBS indicator and the AMP BAL control on AN/ASM-101 until a minimum null is obtained on AN/USM-140A.</p> <p><i>Note.</i> For easier observation of the minimum null, increase the AN/USM-140A vertical gain as the null is approached.</p>	<p>a. The OBS indicator should be set to 300° with a minimum null indicated on AN/USM-140A.</p>																																							
2	No change from step 1.	No change from step 1.	<p>Set the BRG-OBS switch on the test set to BRG.</p>	<p>The indications on the AN/USM-140A should not change.</p>																																							
3 (This step for Test Set, Radio TS-2500A/ARM-92 only.)	<p>AN/ASM-110 POWER: ON SYNCHRO SELECTOR: EZ</p>	<p>C-6873/ARN-82 Power switch: OFF TS-2500A/ARM-92 BRG-OBS: OBS BEARING: 300 RECEIVER MODEL: B</p>	<p><i>Note.</i> Use Indicator, Course ID-1347A/ARN-82.</p> <p>a. Adjust course index card on course indicator around 300 degrees for zero reading on indicator test set SYNCHRO METER.</p> <p>b. Rotate course indicator course index card counterclockwise.</p> <p>c. Set indicator test set SYNCHRO SELECTOR to RW2. Adjust course indicator course index card around 30 degrees for zero reading on indicator test set SYNCHRO METER.</p> <p>d. Rotate course indicator course index card counterclockwise.</p>	<p>a. Course indicator course index card reads 297 to 303 degrees.</p> <p>b. Indicator test set SYNCHRO METER deflects to the right.</p> <p>c. Course indicator course index card reads 27 to 33 degrees.</p> <p>d. Indicator test set SYNCHRO METER deflects to the left.</p>																																							
4 (This test for Test Set, Radio TS-2500A/ARM-92 only.)	N/A	<p>C-6873/ARN-82 Power switch: ON TS-2500A/ARM-92 BRG-OBS: BRG BEARING: 300 RECEIVER MODEL: B</p>	<p>a. Measure ac voltage from J1 to J2 on fabricated cable. This voltage is V1 max. Set test set BEARING switch to 30. Measure ac voltage from J3 to J4 on fabricated cable. This voltage is V2 max.</p> <p>b. Measure the ac voltages from J1 to J2 and from J3 to J4 for each setting of the test set BEARING switch.</p>	<table border="1"> <thead> <tr> <th>Bearing</th> <th>J1 to J2</th> <th>J3 to J4</th> </tr> </thead> <tbody> <tr> <td>300</td> <td>V1 max</td> <td>0</td> </tr> <tr> <td>330</td> <td>.86(V1 max)</td> <td>.5(V2 max)</td> </tr> <tr> <td>0</td> <td>.5(V1 max)</td> <td>.86(V2 max)</td> </tr> <tr> <td>30</td> <td>0</td> <td>V2 max</td> </tr> <tr> <td>60</td> <td>.5(V1 max)</td> <td>.86(V2 max)</td> </tr> <tr> <td>90</td> <td>.86(V1 max)</td> <td>.5(V2 max)</td> </tr> <tr> <td>120</td> <td>V1 max</td> <td>0</td> </tr> <tr> <td>150</td> <td>.86(V1 max)</td> <td>.5(V2 max)</td> </tr> <tr> <td>180</td> <td>.5(V1 max)</td> <td>.86(V2 max)</td> </tr> <tr> <td>210</td> <td>0</td> <td>V2 max</td> </tr> <tr> <td>240</td> <td>.5(V1 max)</td> <td>.86(V2 max)</td> </tr> <tr> <td>270</td> <td>.86(V1 max)</td> <td>.5(V2 max)</td> </tr> </tbody> </table> <p>Voltage tolerance ±10%.</p>	Bearing	J1 to J2	J3 to J4	300	V1 max	0	330	.86(V1 max)	.5(V2 max)	0	.5(V1 max)	.86(V2 max)	30	0	V2 max	60	.5(V1 max)	.86(V2 max)	90	.86(V1 max)	.5(V2 max)	120	V1 max	0	150	.86(V1 max)	.5(V2 max)	180	.5(V1 max)	.86(V2 max)	210	0	V2 max	240	.5(V1 max)	.86(V2 max)	270	.86(V1 max)	.5(V2 max)
Bearing	J1 to J2	J3 to J4																																									
300	V1 max	0																																									
330	.86(V1 max)	.5(V2 max)																																									
0	.5(V1 max)	.86(V2 max)																																									
30	0	V2 max																																									
60	.5(V1 max)	.86(V2 max)																																									
90	.86(V1 max)	.5(V2 max)																																									
120	V1 max	0																																									
150	.86(V1 max)	.5(V2 max)																																									
180	.5(V1 max)	.86(V2 max)																																									
210	0	V2 max																																									
240	.5(V1 max)	.86(V2 max)																																									
270	.86(V1 max)	.5(V2 max)																																									

**4-13. Test Set, Compass Simulator and Indicator, RMI ID-250A/ARN Test**

- a. *Test Equipment and Materials.* None required.  
 b. *Test Connections and Conditions.* Connect the equipment as shown in figure 4-5.  
 c. *Procedure.*

Step	Control settings		Test procedure	Performance standard
	Test equipment	Equipment under test		
	N/A	TS-2500/ARM-92 or TS-2500A/ARM-92 VOR/LOC-GLIDE SLOPE. VOR/LOC C-6873/ARN-82 Power switch: OFF Megacycle and kilocycle selectors: 108.00.	<p>a. Set the power switch on the control unit to PWR.</p> <p>b. Rotate the COMPASS SIMULATOR with the compass simulator control.</p> <p>c. Set the COMPASS SIMULATOR needle to N (0°).</p> <p>d. Press the SERVO AMP TEST pushbutton switch, and then release it.</p>	<p>a. The following lamps should light, and the following indications should be observed:</p> <ol style="list-style-type: none"> <li>(1) VOR/LOC DC, VOR/LOC AC, and GS DC lamps on the test set should light.</li> <li>(2) 26 VAC PWR and LOC PWR lamps on the aid box should light.</li> <li>(3) The 1.0 FREQ SELECT (MC) lamps A and D on the aid box should light.</li> <li>(4) The 0.1 FREQ SELECT (MC) lamps B and E on the aid box should light.</li> <li>(5) The 0.01 FREQ SELECT (MC) lamp B on the aid box should light.</li> <li>(6) The FLAG meter on the test set should indicate 250 microamperes <math>\pm 15</math>.</li> <li>(7) The DEVIATION meter on the test set should indicate 75 microamperes <math>\pm 5</math> to the right of 0.</li> <li>(8) The TO-FROM meter on the test set should indicate 500 microamperes <math>\pm 25</math> to the left of 0.</li> </ol> <p>b. The RMI card should follow COMPASS SIMULATOR needle within 2°.</p> <p>c. RMI needle number 1 should indicate <math>180^\circ \pm 1</math>. The RMI card should indicate <math>0^\circ \pm 1</math>.</p> <p>d. The FLAG meter on the test set should indicate 0 microampere with the SERVO AMP TEST pushbutton switch pressed, and 250 microamperes <math>\pm 15</math> with the SERVO AMP TEST pushbutton switch released.</p>



**NOTE:**

▭ INDICATES EQUIPMENT MARKINGS.  
EL6625-820-45-C1-TM-22

Figure 4-6. Glide-slope frequency information test.

**4-15. Meter Movement Accuracy Tests**

- a. *Test Equipment and Material.* Meter Test Set TS-682A/GSM-1 is required for the following procedure.
- b. *Test Connections and Conditions.* Remove all power from the test set. Set the AC LINE and BATTERY switches on TS-682A/GSM-1 to OFF. Connect the equipment as shown in figure 4-7 with the COMMON binding post of the TS-682A/GSM-1 connected to b of P2, and the 500 UA current jack connected to a of P2. Rotate the DIRECT CURRENT COURSE control and the DIRECT CURRENT FINE control to their fully counterclockwise positions. Set the AC LINE switch to ON, and allow a 1-minute warmup period.
- c. *Procedure.*

Control settings				
Step	Test equipment	Equipment under test	Test procedure	Performance standard
1	<p>TS-682A/GSM-1</p> <p>Set the BATTERY switch to ON.</p> <p>Adjust the meter zero-adjusting knobs until the AC MILLIAMPERES, DC MICROAMPERES, and DC MILLIVOLTS meters all indicate 0.</p> <p>Set the left-hand selector switch to ALL OTHER AC &amp; DC SCALES.</p> <p>Set the center selector switch to DC MA &amp; UA.</p> <p>Set the right-hand selector switch to AC &amp; DC MA &amp; UA.</p>	<p>C-6873/ARN-82</p> <p>Power switch: OFF</p> <p>TS-2500/ARM-92 or TS-2500A/ARM-92</p> <p>VOR/LOC-GLIDE SLOPE: VOR/LOC</p>	<p>Rotate the DIRECT CURRENT COURSE control cw until the DC MICROAMPERE meter indicates 500 microamperes. Press and hold the BUZZER switch while adjusting the DIRECT CURRENT FINE control for a 500-microampere indication on the DC MICROAMPERE meter. Release the BUZZER switch.</p>	<p>The FLAG meter on the test set should indicate 500 microamperes <math>\pm 10</math>.</p>
2	No change from step 1.	No change from step 1.	<p>Rotate the DIRECT CURRENT COURSE control and the DIRECT CURRENT FINE control fully ccw. Connect the COMMON binding post of TS-682A/GSM-1 to Z of P2, and the 1 ma current jack to Y of P2. Rotate the DIRECT CURRENT COURSE control cw until the DC MICROAMPERE meter indicates 1 milliampere. Press and hold the BUZZER switch while adjusting the DIRECT CURRENT FINE control for a 1-milliampere indication on the DC MICROAMPERE meter. Release the BUZZER switch.</p>	<p>The TO-FROM meter on the test set should indicate 1,000 microamperes <math>\pm 20</math> on the left side of 0.</p>
3	No change from step 1.	No change from step 1.	<p>Rotate the DIRECT CURRENT COURSE control and the DIRECT CURRENT FINE control fully ccw. Connect the COMMON binding post of TS-682A/GSM-1 to m of P2. Disconnect the cable from the 1-ma current jack and plug it into the 200 UA current jack. Connect the other end of this cable to n of P2. Rotate the DIRECT CURRENT COURSE control cw until the DC MICROAMPERE meter indicates 150 microamperes. Press and hold the BUZZER switch while adjusting the DIRECT CURRENT FINE control for a 150-microampere indication on the DC MICROAMPERE meter. Release the BUZZER switch.</p>	<p>The DEVIATION meter on the test set should indicate 150 microamperes <math>\pm 3</math> on the left side of 0.</p>
4	No change from step 1.	No change from step 1.	<p>Rotate the DIRECT CURRENT COURSE control and the DIRECT CURRENT FINE control fully ccw. Connect the COMMON binding post of TS-682A/GSM-1 to n of P2, and the 200 UA current jack to m of P2. Rotate the DIRECT CURRENT COURSE control cw until the DC MICROAMPERE meter indicates 150 microamperes. Press and hold the BUZZER switch while adjusting the DIRECT CURRENT FINE control for a 150-microampere indication on the DC MICROAMPERE meter. Release the BUZZER switch.</p>	<p>The DEVIATION meter on the test set should indicate 150 microamperes <math>\pm 3</math> on the right side of 0.</p>

**4-16. Summary of GS and Depot Overhaul Standards Test Data**

Personnel may find it convenient to arrange a checklist in a manner similar to that shown below:

a. *Test Set, Wiring Harness, Aircraft TS-2501/ARM-92 Test.*

Checkpoint	Performance standard
(1) Voltage across CR1	10 volts dc $\pm 0.5$
(2) Resistance between A of J2 and a of J2	22,900 ohms $\pm 2,290$
(3) Resistance between J of J2 and X of J2	0 ohm
(4) Resistance between J of J2 and n of J2	0 ohm
(5) Resistance between J of J2 and Y of J2	0 ohm
(6) Resistance between J of J2 and b of J2	0 ohm
(7) Resistance between J of J2 and c of J2	1,000 ohms $\pm 100$
(8) Resistance between J of J2 and B of J2	511 ohms $\pm 51$
(9) Resistance between J of J2 and P of J2	1,000 ohms $\pm 100$
(10) Resistance between J of J2 and N of J2	0 ohm
(11) Resistance between J of J2 and E of J2	0 ohm
(12) Resistance between A of J2 and M of J2	36,500 ohms $\pm 3,650$
(13) Resistance between A of J2 and Z of J2	42,500 ohms $\pm 4,250$
(14) Resistance between L of J2 and G of J1	1,500 ohms $\pm 150$
(15) Resistance between D of J1 and H of J1	0 ohm
(16) Resistance between C of J1 and K of J1	0 ohm
(17) Resistance between A of J2 and t of J2	160 ohms $\pm 20$

Checkpoint	Performance standard
(18) Resistance between A of J2 and k of J2	160 ohms $\pm 20$
(19) Resistance between A of J2 and p of J2	160 ohms $\pm 20$
(20) Resistance between A of J2 and f of J2	160 ohms $\pm 20$
(21) Resistance between A of J2 and W of J2	160 ohms $\pm 20$
(22) Resistance between A of J2 and g of J2	160 ohms $\pm 20$
(23) Resistance between A of J2 and V of J2	160 ohms $\pm 20$
(24) Resistance between A of J2 and h of J2	160 ohms $\pm 20$
(25) Resistance between A of J2 and U of J2	160 ohms $\pm 20$
(26) Resistance between A of J2 and i of J2	160 ohms $\pm 20$
(27) Resistance between A of J2 and T of J2	160 ohms $\pm 20$
(28) Resistance between A of J2 and j of J2	160 ohms $\pm 20$
(29) Resistance between A of J2 and S of J2	160 ohms $\pm 20$
(30) Resistance between A of J2 and X of J2	160 ohms $\pm 20$
(31) Resistance between K of J2 and X of J2	160 ohms $\pm 20$
(32) Resistance between G of J1 and E of J1	160 ohms $\pm 20$
(33) Resistance between R of J2 and X of J2	160 ohms $\pm 20$

b. *Control, Radio Set C-6873/ARN-82 Test.*

Checkpoint	Performance standard
(1) Control unit power switch to OFF.	No lamps light.
(2) Control unit power switch to PWR. Megacycle and	The VOR/LOC AC, VOR/LOC DC, and GS DC lamps on the test set

INDEX

	Paragraph	Page
Alignment:		
Compass simulator_-----	3-10	3-6
General_-----	3-7	3-5
OBS indicator_-----	3-11	3-6
Precision bearing_-----	3-9	3-5
RMI_-----	3-12	3-6
Test equipment required_-----	3-8	3-5
Compass simulator:		
Alignment_-----	3-10	3-6
Detailed functioning_-----	1-6	1-5
General support and depot testing_-----	4-13	4-17
Control unit, schematic diagram, fig. 4-1:		
Physical tests and inspection_-----	4-8	4-6
Test_-----	4-9	4-9
Troubleshooting procedure_-----	2-7	2-3
Depot overhaul standards_-----	4-1	4-1
Fabricated cable, construction details_-----	4-4	4-2
Functioning, detailed:		
Aid box_-----	1-8	1-6
Compass simulator_-----	1-6	1-5
Resolver transmitter_-----	1-4.1	1-3
Current measuring circuits_-----	1-5	1-4
Phase shifting_-----	1-4	1-3
Power distribution circuits_-----	1-3	1-3
RMI_-----	1-7	1-6
Functioning, general, Test Set, Radio AN/ARM-92_-----	1-2	1-1
Functioning, general, Test Set, Radio AN/ARM-92A_-----	1-2.1	1-1
General support and depot testing:		
Aid box physical tests and inspection_-----	4-6	4-3
Aid box tests_-----	4-7	4-5
Control unit physical tests and inspection_-----	4-8	4-6
Control unit tests_-----	4-8	4-6
Fabricated cable construction details_-----	4-4	4-2
General_-----	4-1	4-1
Glide-slope frequency information test_-----	4-14	4-19
Meter movement accuracy tests_-----	4-15	4-21
Modification work orders_-----	4-5	4-2
OBS indicator physical tests and inspection_-----	4-10	4-10
OBS indicator tests_-----	4-11	4-13
Precision bearing test_-----	4-11	4-13
RMI tests_-----	4-13	4-17
Summary of test data_-----	4-16	4-22
Test equipment, tools, and materials_-----	4-2	4-1
Test facilities_-----	4-3	4-2
Test set, compass simulator test_-----	4-13	4-17
Test set, physical tests and inspection_-----	4-12	4-14

**TM 11-6625-820-45**

	Paragraph	Page
Meter circuitry:		
Detailed functioning -----	1-5	1-4
General support and depot testing -----	4-15	4-21
Modification work orders -----	4-5	4-2
OBS indicator, schematic diagram, fig. 1-3:		
Alignment -----	3-11	3-6
General support and depot testing -----	4-11	4-13
Physical tests and inspection -----	4-10	4-10
Troubleshooting procedures -----	2-7	2-3
Power cable, schematic diagram, fig. 1-2		
Precision bearing:		
Alignment -----	3-9	3-5
General support and depot testing -----	4-11	4-13
RMI, schematic diagram, fig. 1-4:		
Alignment -----	3-12	3-6
Detailed functioning -----	1-7	1-6
General support and depot testing -----	4-13	4-17
Troubleshooting procedures -----	2-7	2-3
Repairs:		
Disassembly techniques for aid box -----	3-5	3-5
General parts replacement techniques -----	3-1	3-1
Reassembly techniques for aid box -----	3-6	3-5
Removal and disassembly techniques for test set -----	3-3	3-1
Removal and replacement techniques -----	3-2	3-1
Replacement, reassembly, and lubrication techniques for Test Sets, Radio TS-2500/ARM-92 and TS-2500A/ARM-92 -----	3-4	3-2
Scope -----	1-1	1-1
Summary of test data -----	4-16	4-22
Test Set, Radio AN/ARM-92, schematic diagram, fig. 4-9;		
Test Set, Radio AN/ARM-92A, schematic diagram, fig. 4-9.1		
General functioning, Test Set, Radio, AN/ARM-92 -----	1-2	1-1
General functioning, Test Set, Radio, AN/ARM-92A -----	1-2.1	1-3
General parts replacement -----	3-1	3-1
Removal and disassembly -----	3-3	3-1
Removal and replacement techniques -----	3-2	3-1
Replacement, reassembly, and lubrication techniques -----	3-4	3-2
Troubleshooting procedures -----	2-7	2-3
Disassembly techniques -----	3-5	3-5
General support testing -----	4-7	4-5
Isolating trouble -----	2-7	2-3
Physical tests and inspection -----	4-6	4-3
Reassembly techniques -----	3-6	3-5
Resistance chart -----	2-6	2-3
Troubleshooting procedures -----	2-5	2-2
Troubleshooting procedures:		
Aid box -----	2-5	2-2
Control unit -----	2-7	2-3
Dc resistances of transformers and relay coils -----	2-9	2-20
General -----	2-4	2-2
OBS indicator -----	2-7	2-3
Resistance chart -----	2-6	2-3
RMI -----	2-7	2-3
Test set -----	2-7	2-3
Troubleshooting chart -----	2-8	2-10
Troubleshooting techniques:		
General -----	2-1	2-1
Organization of troubleshooting procedures -----	2-2	2-1
Test equipment required -----	2-3	2-2





