

## DEPARTMENT OF THE ARMY TECHNICAL MANUAL

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS  
AND SPECIAL TOOLS LISTS**  
**PRINT WASHERS, PHOTOGRAPHIC EK-1 (1), EK-1 (2),  
EK-1 (3), EK-1 (4), AND WASHER PH-240-B**  
**FSN 6740-242-9175**

**Headquarters, Department of the Army, Washington, DC**  
**13 December 1974**

*Current as of 23 September 1974*

		PARAGRAPH	PAGE
<b>SECTION I. INTRODUCTION</b>			
Scope.....	1-1	2	
General .....	1-2	2	
Explanation of columns.....	1-3	2	
Special information .....	1-4	4	
Location of repair parts .....	1-5	4	
Abbreviations (Not applicable) .....	1-6	4	
Reporting of equipment publication improvements .....	1-7	4	
II. PRESCRIBED LOAD ALLOWANCE (Not applicable)			
III. REPAIR PARTS LIST .....		6	
IV. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)			
V. INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS- REFERENCE TO FIGURE AND ITEM NUMBER.....			9

---

\*This manual supersedes TM 11-6740-228-20P, 4 June 1964.

## SECTION I. INTRODUCTION

---

### **1-1. Scope**

This manual lists repair parts and special tools required for the performance of organizational maintenance of the EK-1 (1), EK-1 (2), EK-1 (3), EK-1 (4), and PH-240-B. The PCCN for the equipment is GRNACO for all models.

### **1-2. General**

This repair parts and special tools list is divided into the following sections:

- a. *Prescribed Loan Allowance (PLA)* -Section II. Not applicable.
- b *Repair Parts Lists*-Section III. A list of repair parts authorized for the performance of maintenance at the organizational level. This repair parts list is arranged in alphabetical order.
- c. *Special Tools, Test and Support Equipment - Section IV*. Not applicable.
- d. Index - Federal Stock Number and Reference Number Cross-Reference to Figure and Item Number - Section V. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphanumeric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

### **1-3. Explanation of Columns**

The following provides an explanation of columns in the tabular lists:

- a. *Source, Maintenance, and Recoverability Codes (SMR)*.
- (1) *Source code*. Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are:

#### *Code                  Explanation*

- PA - Item procured and stocked for anticipated or known usage.
- PB - Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
- PC - Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
- PD - Support item, excluding support equipment,

<i>Code</i>	<i>Explanation</i>
	procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD	An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB	Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at direct support maintenance level.
MH	Item to be manufactured or fabricated at general support maintenance level.
MD	Item to be manufactured or fabricated at depot maintenance level.
AO	Item to be assembled at organizational level.
AF	Item to be assembled at direct support maintenance level.
AH	Item to be assembled at general support maintenance level.
AD	Item to be assembled at depot maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not

<i>Code</i>	<i>Explanation</i>
available through salvage, requisition.	
XC - Installation drawing, diagram instruction sheet, field service drawing, that is identified by manufacturers' part number.	
XD - Support items can be requisitioned with justification.	

**NOTE**

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code Format as follows:

(a) *Use (third position).* The maintenance code entered in the third position indicates the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position indicates one of the following levels of maintenance.

*Code Application/Explanation*

O - Support item is removed, replaced, used at the organizational level of maintenance.

**NOTE**

A code "C" may be used in this position to denote crew or operator maintenance performed within organizational maintenance.

F - Support item is removed, replaced, used at the direct support maintenance level.

H - Support item is removed, replaced, used at the general support maintenance.

D - Support items that are removed, replaced, used at depot only.

(b) *Repair (fourth position).* The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). When a maintenance code is not used a dash (-) sign is entered. For multi-service equipment/systems or when a code is entered, this position will contain one of the following maintenance codes as assigned by the service(s) that require the code:

*Code Application/Explanation*

O - The lowest maintenance level capable of complete repair of the support item is the organizational level.

<i>Code</i>	<i>Application/Explanation</i>
F -	The lowest maintenance level capable of complete repair of the support item is direct support.
H -	The lowest maintenance level capable of complete repair of the support item is general support
D -	The lowest maintenance level capable of complete repair of the support item is the depot level.
L -	Repair restricted to designated Specialized Repair Activity.
Z -	Non-repairable. No repair is authorized.
B -	No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) *Recoverability code.* Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the uniform SMR Code Format as follows:

<i>Code</i>	<i>Explanation</i>
Z -	Nonrepairable item. When unserviceable, condemn and dispose at the level indicated in the first digit of the maintenance code.
O -	Repairable item. When uneconomically repairable, condemn and dispose at organizational level.
F -	Repairable item. When uneconomically repairable, condemn and dispose at the direct support level.
H -	Repairable item. When uneconomically repairable, condemn and dispose at the general support level.
D -	Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
L -	Repairable item. Repair, condemnation, and disposal not authorized below depot/Specialized Repair Activity level.
A -	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material).

b. *Federal Stock Number.* Indicates the Federal stock number assigned to the item.

**NOTE**

For requisitioning purposes, the Federal stock number must be converted to the National stock number by adding "-00-

after the Federal stock classification (FSC) code (first four digits For example, FSN 6625-553-0142 converts to NSN 66256-00-553-0142.

c. *Description*. Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal Supply Code for Manufacturer (FSCM) in parentheses The FSCM is used as an element in item identification to designate manufacturer or distributor or Government agency, etc., and is identified in SB 70842.

d. *Unit of Measure (UIM)*. Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation; e.g., ea, in, pr, etc., and is the basis used to indicate quantities and allowances in subsequent columns. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Incorporated in Unit*. This column indicates the quantity of the item used in the equipment. Subsequent appearances of the same item in the same assembly are indicated by the letters "REF".

f 15-Day Organizational Maintenance Allowance.

(1) The repair parts indicated by an asterisk in the allowance column represent those authorized for use at, the organizational category, and will be requisitioned on an "as required" basis, until stock age is based on demand in accordance with AR 710-2

(2) Major Army commanders are authorized to approve reduction in the range of support items authorized for use in units within their commands. Recommendations for increase in range of items authorized for use will be forwarded to Commander, US Army Electronics Command, ATTN: AMSEL MA-SNV, Fort Monmouth, NJ 07708. Any changes approved will be reflected in a revision to the RPSTL.

(3) Allowance quantities are indicated in the special tools list section for special tools, TMDE, and other equipment.

g. *Illustration*. This column is divided as follows:

(1) *Figure number*. Not applicable.

(2) *Item number*. Indicates the item number or reference designation used to reference the item.

#### 1-4. Special Information

a. Usable on codes are included in column 3. Uncoded items are applicable to all models Identification of the usable on codes used in this publication are:

CodeUsed on	
AØS .....	EK-1 (1)
AØT .....	EK-1 (2)
AØU .....	EK-1 (3)
AØV .....	EK-1 (4)
AØW .....	PH-240-B

b. The following publication pertains to the equipment and its components:

TM 1I-2399A      Washer PH-240-B and Print Washers, Photographic EK-1 (1), EK-1 (2), EK-1 (3), and EK-1 (4).

#### 1-5. Location of Repair Parts

a This manual contains one cross-reference index (sec V) to be used to locate a repair part when either the Federal stock number or reference number (manufacturer's part number) is known. The first column in the index is prepared in numerical or alphanumeric sequence in ascending order. The reference numbers (manufacturer's part numbers) are listed immediately following the last listed Federal stock number in the index of Federal stock numbers

b. When the Federal stock number or reference number is known, follow the procedures given in (1) and (2) below.

(1) Refer to the index of Federal stock numbers (sec V) and locate the Federal stock number or reference number. The FSN and reference number are cross-referenced to the applicable fissure and item number or reference designation.

(2) Refer to the repair parts list (sec III) and locate the figure number (col 7a) and item number or reference designation (col 7b) as noted in the FSN index.

c. When the figure and item number or reference designation are known, scrutinize columns 7a and 7b of the repair parts list (sec III) until the item is located.

d. When the FSN, reference number, figure number, item number and reference designation are not known, scrutinize column 3 of the repair parts list (sec III), which is arranged in alphabetical order.

#### 1-6. Abbreviations

Not applicable.

#### 1-7. Reporting of Equipment Publication Improvements

The reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publica-

tions and Blank Forms) and forwarded direct to  
Commander, US Army Electronics Command, **ATTN:**

**AMSEIMA-SNV**, Fort Monmouth, NJ. 07703.

## SECTION III

TM 11-6740-228-20P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION  REF NUMBER & MFR CODE	(4) USABLE ON CODE	(5) UNIT OF MEAS  QTY INC IN UNIT	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUS- TRATION	
					(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG NO.	(b) ITEM NO.
XDOZZ		ADAPTER A4 156-7-00-06 (05690)	A0V	EA 1	*	*	*	*	8-2	A4
PAOZZ	6740-242-9175	ASPIRATOR MP2 10W76 (81349)	A0S	EA 1	*	*	*	*	8	MP2
XDOZZ		BEARING 05 8-17 (00466)	A0V	EA 1	*	*	*	*	8-2	05
PAOZZ	6740-053-3818	BEARING, CYLINDER MP3 156-0-00-12 (05690)	A0V	EA 2	*	*	*	*	7-8	MP3
XDOZZ		BEARING, ROLLER, SHAFT 05 156-7-00-11 (05690)	A0V	EA 1	*	*	*	*	8	05
XDOZZ		BEARING, SLEEVE MP14 FF703-3 (75292)	A0U	EA 2	*	*	*	*	10-1	MPI4
PAOZZ	6740-980-7256	BEARING, SLEEVE MP-9 AA628 (752922)	A0U	EA 1	*	*	*	*	8-2	MP9
PAOZZ	3030-528-4451	BELT V MPS 1280 (24161)	A0V	EA 1	*	*	*	*	7-2	MP5
PAOZZ	3030-528-4450	BELT V MP5 1290 (24161)	A0V	EA 1	*	*	*	*	7-2	MP5
PAOZZ	3030-356-7142	BELT V MP5 BROWNING SUPERCORD FHP0255 (24161)	A0S,A0T,A0W	EA 2	*	*	*	*	7-1	MP5
PAOZZ	3030-356-7142	BELT V 02 BROWNING SUPERCORD FHP0255 (24161)	A0S-A0T,A0W	EA REF	*	*	*	*	7-1	02
PAOZZ	3030-180-2162	BELT V MP-5 4L280 (16327)	A0V	EA 2	*	*	*	*	7-2	MP5
PAOZZ	6740-338-3283	BLOCK. BEARING MP3 W601 (45721)	A0U,A0T,A0U,A0W	EA 2	*	*	*	*	7-2	MP3
XDOZZ		BLOCK. BEARING 05 W600	A0T,A0W	EA 1	*	*	*	*	8-1	05
XDOZZ		BRACKET, VALVE MP1 8-1 (00466)	A0U	EA 1	*	*	*	*	8-2	MP1
PAOZZ	6145-504-1015	CABLE POWER ELECTRICAL W1 6 FEET LONG C003MGF3-16-0360 (81349)	A0V	EA 1	*	*	*	*	10-2	W1
XDOZZ		CABLE ASSEMBLY, POWER ELECTRICAL W1 7-19 (00466)	A0U	EA 1	*	*	*	*	7-2	W1
PAOZZ	6145-284-0087	CABLE POWER ELECTRICALW1 6 FEETLONG, WIRE WD-10/U 2 NO. AWG CORD	A0S,A0T,A0W	EA 1	*	*	**	10	W1	
PAOZZ	6740-319-1036	CAP, STUFFING. BOX 010 340 (99483)	A0S	EA 1	*	*	*	*	8	010
PAOZZ	6740-351-9038	CASTING. STUFFING BOX A4 A56RI (45472)	A0T,A0W	EA 1	*	*	*	*	8	A4
XDOZZ		CATCH, FRICTION HK 39 (57068)	A0S	EA 1	*	*	*	*	10	HK
PAOZZ	4730-629-6482	CLAMP H19 5 (66295)	A0T,A0W	EA 2	*	*	*	*	3	H19
XDOZZ		CLAMP, HOSE H19 32 (81646)	A0V	EA 4	*	*	*	*	3	H19
XDOZZ		CLAMP. HOSE H19 C24 (66295)	A0U	EA 2	*	*	*	*	3-2	HL9
XDOC.Z		CONNECTOR, PLUG, ELECTRICAL P1 MS91184 (96906)	A0S,A0T,A0W	EA 1	*	*	*	*		P1
PAOZZ	5936-7145	CONNECTOR, PLUG, ELECTRICAL P1 MS1185 (96906)	A0V	EA 1	*	*	*	*		Pt
PAOZZ	6740-356-7145	COVER A2 AXE1197 (45472)	A0T,A0W	EA 1	*	*	*	*	8	A2
XDOZZ		CUP,OIL 012 R7ACAD (24981)	A0S,A0T,A0W	EA 1	*	*	*	*	10	012
PAOZZ	4730-277-7010	CUP. OIL, LUBRICATING 012 OIL CUP STYLE NO 1	A0S,-A0T,A0W	EA 1	*	*	*	*	10	012
PAOZZ	6740-053-3819	1219 (24981) DIAPHRAGM, VALVE 0QI 156-7-00-01 (05690)	A0V	EA 1	*	*	*	*	8	Q1
PAOZZ	6740-356-7145	DIAPHRAGM, VALVE Q1 AXE1189 (45472)	A0T,A0W	EA 1	*	*	*	*	8	Q1
XDOZZ		ELBOW, PLASTIC, PIPE MP11 8-25 (00466)	A0U	EA 1	*	*	*	*	3-2	MP11
XDOZZ		FITTING MP2 8-24 (00466)	A0U	EA 1	*	*	*	*	8-2	MP2
XDOZZ		FITTING. STUFFING, SEAL A-4 8-10 (00466)	A0U	EA 1	*	*	*	*	8-2	A4
XDOZZ		GASKET NO-REF-DESIG W702 (45472)	A0T,A0W	EA 1	*	*	*	*		
PAOZZ	5330-298-5813	GASKET NOREF-DESIG 105A (45472)	A0T,A0W	EA 1	*	*	*	*		
PAOZZ	5330-599-5888	GASKET NO-REF-DESIG DS1.1-2X1.1-4X1.* 16 (70227)	A0T,A0W	EA 1	*	*	*	*		
PAOZZ	5330-980-7257	GASKET NPL3 W251A (75345)	A0U	EA 1	*	*	*	*	8-2	MP13

## SECTION III

TM 11-6740-228-20P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION  REF NUMBER & MFR CODE GLAND STUFFING BOX H23	(4) USABLE ON CODE	(5) UNIT OF MEAS  EA	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUS- TRATION (a) FIG. (b) ITEM. NO. NO. 8 H23	
					(a) 1-5 *	(b) 6-20 *	(c) 21-50 *	(d) 51-100 *		
PAOZZ	6740-053-3820	156-7-00-05 (05690) GLIDE, FURNITURE H1 L180XTS (06004)	A0V	EA	4	*	*	*	*	7-1 H1
XDOZZ		GROMMET NO-REF-DESIG AN931-16-22 (88044)	A0S	EA	1	*	*	*	*	8
XDOZZ		GROMMET, RUBBER NO-REF-DESIG FM839 (45472)	A0S,A0V	EA	1	*	*	*	*	8
XDOZZ		HOSE H-5 W700 (45472)	A0T,A0W	EA	1	*	*	*	*	8 H25
PAOZZ	4820-273-9094	HOSE H25 W701 (45472)	A0T,A0W	EA	1	*	*	*	*	8 H25
PAOZZ	4720-978-0690	HOSE, PREFORME MP-7 CH54 (24161)	A0U	EA	1	*	*	*	*	8-2 MP7
XDOZZ		HOSE, ROBBER H25 P340-1-1-2 (61463)	A0V	EA	1	*	*	*	*	8-2 H25
XDOZZ		INLET, PIPE 018 8-23 (00466)	A0U	EA	1	*	*	*	*	8 018
XDOZZ		LATCH, ARM 01 10-11 (00466)	A0U	EA	1	*	*	*	*	10-1 01
XDOZZ		LATCH, FITTING MP15 10-8 (00466)	A0U	EA	1	*	*	*	*	10-1 MP15
XDOZZ		LEG, CAP 09 7-14 (00466)	A0U	EA	2	*	*	*	*	7-2 09
XDOZZ		LEG, CAP RIGHT HAND 08 7-15 (00466)	A0U	EA	2	*	*	*	*	7-2 08
XDOZZ		LIFT, ARM 014 10-6 (00466)	A0U	EA	2	*	*	*	*	10-1 014
XDOZZ		LIFT, CHANNEL H1 7-3 (0046)	A0U	EA	2	*	*	*	*	7-2 H1
PAOZZ	6740-977-1008	LIFT, ROD) 022 7-9 (00466)	A0U	EA	2	*	*	*	*	7-2 022
PAOZZ	6740-313-7584)	LIFT, ROD, VALVE MP12 420 (99483)	A0S	EA	1	*	*	*	*	7-1 MP12
XDOZZ		LOCKNUT, ELECTRICAL, CONDUIT H3 143 (59130)	A0U	EA	1	*	*	*	*	*8-2 H3
PAOZZ	6105-051-7294	MOTOR, ALTERNATING CURRENT B1 316P0018 (79500)	A0V	EA	1	*	*	*	*	10-2 B1
XDOZZ		MOTOR, ALTERNATING CURRENT B1 1172701 (00466)	A03	EA	1	*	*	*	*	10 B1
PAOZZ	6105-199-5047	MOTOR, ALTERNATING CURRENT B1 5KH23AC347 (03510)	A0T,A0W	EA	1	*	*	*	*	10 B1
XDOZZ		MOTOR, ALTERNATING CURRENT B1 4K265 (30187)	A0U	EA	1	*	*	*	*	10 B1
PAOZZ	5310-978-7461	NUT, PLAIN, HEXAGON H2 8-8 (00466)	A0U	EA	2	*	*	*	*	10-1 H2
XDOZZ		NUT, PLAIN, HEXAGON NO-REF DESIG 300 (99483)	A0S	EA	1	*	*	*	*	10
XDOZZ		PACKING, FIBRE MS1 A78 (45472)	A0T,A0W	EA	1	*	*	*	*	8 MS1
XDOZZ		PACKING, MATERIAL MS1 Y577 (76155)	A0V	EA	1	*	*	*	*	8 MS1
XDOZZ		PACKING, MATERIAL MS1 10000 (72902)	A0S	EA	1	*	*	*	*	8 MS1
XDOZZ		PACKING, PERFORMED H7 9772 (92088)	A0S	EA	2	*	*	*	*	H7
PAOZZ	5330-350-9013	PACKING, PREFORMED MP10 AN6227810 (96906)	A0U	EA	1	*	*	*	*	*8-2 MP10
XDOZZ		PAD, LUBRICATING 010 W705 (45472)	A0U	EA	1	*	*	*	*	8 010
PAOZZ	6740-053-3822	PIPE, INLET 018 1567-00-12 (05690)	A0T,A0W	EA	1	*	*	*	*	8 018
XDOZZ		PULLEY, GROOVE 019 CA150 (80320)	A0V	EA	1	*	*	*	*	10 019
XDOZZ		PULLEY, GROOVE 021 A700 (80320)	A0U	EA	1	*	*	*	*	10 021
XDOZZ		RETAINER 011 C1583-0125 (78553)	A0U	EA	2	*	*	*	*	10-1 011
PAOZZ	730-142-2044	RETAINER, PACKING 010 A54R1 (45472)	A0T,A0W	EA	1	*	*	*	*	8 010
XDOZZ		RING, RETAINING MP8 510-50 (79136)	A0U	EA	2	*	*	*	*	*8-2 MP8
XDOZZ		ROLLER, DRIVE 024 270 (99483)	A0S	EA	2	*	*	*	*	8 024
PAOZZ	6740-356-715	ROLLER DRIVE 020 AW18 (45472)	A0T,A0W	EA	2	*	*	*	*	8 020
PAOZZ	3110-051-8042	ROLLER, DRIVE 024 11-3-18 (45472)	A0V	EA	2	*	*	*	*	8 024
PAOZZ	6740-973-0937	ROLLER, DRIVE 024 8-13 (00466)	A0U	EA	2	*	*	*	*	8-2 024

## SECTION III

TM 11-6740-228-20P

(1) SMR CODE	(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) USABLE ON CODE	(5) UNIT QTY INC IN	(6) 15-DAY ORGANIZATIONAL MAINTENANCE ALW				(7) ILLUS- TRATION		
					(a)	(b)	(c)	(d)	(a) FIG	(b) ITEM NO.	
REF NUMBER & MFR CODE				UNIT	1	5	6-20	21-50	51-100		
PAOZZ	6740-319-1038	ROLLER, SHAFT, BEARING 05 260 (99483)		EA	1	*	*	*	*	8	05
XDOZZ		SHAFT 027 10-1 (00466)		A0S	1	*	*	*	*	10-1	027
PAOZZ	6740-973-0938	SHAFT 028 8-15 (00466)		A0U	1	*	*	*	*	8	028
XDOZZ		SPACER NO-REF-DESIG 10-5 (00466)		A0U	2	*	*	*	*	8-2	
XDOZZ		SPACER, TUBE 026 8-12 (00466)		A0U	1	*	*	*	*	8-2	026
PAOZZ	6740-537-9467	STUD, PULLEY H82 50 (99483)		A0S	1	*	*	*	*	10	H82
PAOZZ	6740-537-9468	STUFFING, B0X, CASTING A4 320 (99483)		A0S	EA	1	*	*	*	8	A4
PAOZZ	5330-202-4549	STUFFING, BOX GLAND H23 330 (99483)		A0S	EA	1	*	*	*	8	H23
PAOZZ	5330-202-4549	STUFFING, BOX, GLAND H23 55R1 (45472)		A0T, A0W	EA	1	*	*	*	8	H23
XDOZZ		WASHER, FLAT NO-REF-DESIG 156-7-00-08 (05690)		A0V	EA	1	*	*	*	10-2	
PAOZZ	5310-292-2403	WASHER, FLAT NO-REF-DESIG PM219R1 (45472)		A0T,A0W	EA	1	*	*	*	10	
XDOZZ		WASHER, NONMETALLIC H8 1-1-4X1-3-4X1-8 (87030)		A0S	EA	1	*	*	*		H8
PAOZZ	5310-599-I275	WASHER, NONMETALLIC H9 2-1-8X2-7-8X1-16 (87030)		A0S	EA	2	*	*	*		H9
XDOZZ		WASHER, NONMETALLIC H10 1-7-8X2-3-4X3-16		A0S	EA	2	*	*	*		H10
XDOZZ		WASHER, NONMETALLIC NO-REF-DESIG 156-7-00-13 (05690)		A0V	EA	2	*	*	*		

**INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER**  
**CROSS - REFERENCE TO FIGURE AND ITEM NUMBER**

**NOTE: LATEST FRDERAL STOCK NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX**

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
3030-180-2162	7-2	MPS	6145-284-0087 6145-504-1015 6740-053-3818	10 10-2 7-8	W1 W1 MP3
3030-356-7142	7-1	MP5	6740-053-3819	8	Q1
3030-356-7142	7-1	02	6740-053-3820	8	H23
3110-05L-8042	8	024	6740-053-3822	8	018
4730-142-2044	8	010	6740-242-9175	8	MP2
4730-277-7010	10	012	6740-313-7584	7-1	MP12
4730-629-6482	3	H19	6740-319-1036 6740-319-1038 6740-351-9038	8 8 8	010 05 A4
5310-292-2403	10		6740-356-7145 6740-356-7145	8 8	A2 Q1
5310-599-1275		H9	6740-356-7151 6740-537-9467 6740-537-9468	8 10 8	020 H82 A4
5310-978-7461	10-1	H2			
5330-202-4549	8	H23	6740-973-0937 6740-973-0938	8-2 8	024 028
5330-298-5813					
5330-350-9013	8-2	MP10			
5330-599-5888					
5330-980-7257	8-2	MP13			
5935-636-7145	8-2	P1	6740-977-1008	7-2	022
6105-051-7294	10	B1	6740-980-7256	8-2	HP9
6105-199-5047	10	B1			

REFERENCE ITEM NO.	MFR CODE	FIG. NO.	ITEM NO.	REFERENCE NO.	MFR CODE	FIG. NO.	ITEM NO.
AA628	75292	8-2	MP9	P34-1-1-2	61463	8-2	H25
AN6227810	96906	8-2	MP10	R7ACAD	24981	10-1	012
AN931-16-22	88044	8	W251A	75345	8-2	MP13	
AW18	45472	8	020	W600	45472	8-1	05
AXE1189	45472	8	Q1	W601	45472	7-2	MP3
AXE1197	45472	8	A2	W700	45472	8	H25
A54R1	45472	8	010	W701	45472	8	H25
A56R1	45472	8	A4	W702	45472		
A700	80320	10	021	W705	45472	8	010
A78	45472	8	MS1	Y577	76155	8	MS1
CA150	80320	10	019	1-1-4X1-3-4X1-8	87030		H8
CH54	24161	8-2	MP7	I-7-8X2-3-4X3-16	87030		H10
C003MGF3-16-0360	81349	10-2	W1	10-1	00466	10-1	027
C1583-0125	78553	10-1	011	10-11	00466	10-1	01
C24	66295	3-2	H19	10-5	00466	8-2	
DS1-1-2X1-1-4X1-16	70227			10-6	00466	10-1	014
FF703-3	75292	10-1	MP14	10-8	00466	10-1	MP15
FHP0255	24161	7-1	02	10W76	81349	8	MP2
FHPO255	24161	7-1	MP5	10000	72902	8	MS1
FM839	45472	8		105A	45472		
JC901	81348	10	W1	11-3-18	45472	8-2	024
L180XTS	06004	7-1	H1	1172701	00466	10	B1
MS91184	96906		P1	1219	24981	10	012
MS91185	96906		P1	1280	24161	7-2	MP5
PM219R1	45472	10		1290	24161	7-2	MP5

## SECTION V

TM11-6740-228-20P

**INDEX - FEDERAL STOCK NUMBER AND REFERENCE NUMBER  
CROSS - REFERENCE TO FIGURE AND ITEM NUMBER**

**NOTE: LATEST FREDERAL STOCK NUMBER ASSIGNMENTS ARE INCLUDED AT END OF INDEX**

<b>ITEM NO.</b>	<b>MFR</b>	<b>FIG.</b>	<b>ITEM</b>	<b>REFERENCE</b>	<b>MFR</b>	<b>FIG.</b>	
	<b>CODE</b>	<b>NO.</b>	<b>NO.</b>	<b>NO.</b>	<b>CODE</b>	<b>NO.</b>	
143	59730	8-2	H3	5	66295	3	H19
156-0-00-12	05690	7-8	MP3	5KH23AC347	03510	10	B1
156-7-00-01	05690	8	Q1	50	99483	10	H82
156-7-00-05	05690	8	H23	5100-50	79136	8-2	MP8
156-7-100-06	05690	8-2	A4	55R1	45472	8	H23
156-7-00-08	05690	10-2		7-14	00466	7-2	09
156-7-00-11	05690	8	05	7-15	00466	7-2	08
156-7-00-13	05690			7-19	00466	7-2	W1
1567-00-12	05690	8	018	7-3	00466	7-2	H1
2-1-8X2-7-8X1-16	87030	H9		7-9	00466	7-2	022
260	99483	8	05	8-1	00466	8-2	MP1
270	99463	8	024	8-10	00466	8-2	A4
300	99483	10		8-12	00466	8-2	026
316P0018	79500	10-2	B1	8-13	00466		024
32	81646	3	H19	8-15	00466	8	028
320	99483	8	A4	8-17	00466	8-2	05
330	99483	8	H23	8-23	00466	8	018
340	99483	8	010	8-24	00466	8-2	MP2
39	57068	10	HK	8-25	00466	3-2	MP11
4K265	30187	10	B1	8-8	00466	10-1	H2
4L280	16327	7-3	MP5	9772	92088		H7
420	99483	7-1	MP12				

**LATEST FEDERAL STOCK NUMBER ASSIGNMENTS**

<b>STOCK NUMBER</b>	<b>FIGURE NO.</b>	<b>ITEM NO.</b>
3030-528-4450	7-2	MP5
3030-528-4451	7-2	MP5
4720-978-0690	8-2	MP7
4820-273-9094	8	H25
6740-838-3283	7-2	MP3

By Order of the Secretary of the Army:

FRED C. WEYAND  
*General, United States Army*  
*Chief of Staff*

Official:

VERNE L. BOWERS  
*Major General, United States Army*  
*The Adjutant General*

Distribution:

*Active Army:*

USASA (2)	USAIS(2)
CNGB (1)	USAES(2)
Dir of Trans (1)	WRAMC (1)
COE (1)	AD (1) except
TSG(1)	SAAD (30)
USAARENBD (1)	LBAD (14)
AMC (1)	TOAD (14)
MICOM (2)	ATAD (10)
TECOM (2)	USA Dep (2)
TRADOC (2)	Sig Sec USA Dep (2)
ARADCOM(2)	Sig Dep(2)
ARADCOM Rgn (2)	ATS (1)
OS Maj Comd (4)	MAAG (1)
LOGCOMD (3)	USARMIS (1)
USACC (4)	USAERDA (1)
USAINTC (2)	USAERDAW (1)
MDW (1)	USARDL (2)
Armies (2)	GENMISH (2)
Corps (2)	Sig FLDMS (!)
HISA (Ft Monmouth) (18)	Ft Richardson (ECOM Ofc) (2)
Ft Gordon (10)	Units org under fol TOE (1 ea.):
Ft Huachuca (10)	11-16
Ft Carson (5)	11-95
WSMR (1)	11-96
Svc Colleges (1)	11-97
USATC Inf(2)	11-98
USACES(15)	11-117
USASESS(10)	11500(AA-AC)
USAINTCS (3)	30-25
USAADS(2)	30-26
USAFFAS (2)	32-500
USAARMS (2)	

ARNG & USAR: None.

For explanation of abbreviations used, see AR 310-50.

U.S. GOVERNMENT PRINTING OFFICE: 1974-665136/374  
903-762