


# TM 11-7025-208-23

## ORGANIZATIONAL AND DIRECT SUPPORT MAINTENANCE MANUAL

### DISK MEMORY UNIT MU-705/MYQ-4



DESCRIPTION  
AND DATA  
PAGE 1-2

PMCS  
PAGE 3-2

TROUBLESHOOTING  
PAGE 4-2

MAINTENANCE  
PROCEDURES  
PAGE 4-56

This copy is a reprint which includes current  
pages from Change 1., 2

**(NSN 7025-01-092-2745)**

HEADQUARTERS DEPARTMENT OF THE ARMY

MARCH 1984

## **WARNING**

HIGH VOLTAGE

is used in the operation of this equipment

ELECTROCUTION

may result if personnel fail to observe safety precautions.

Never work on electronic equipment unless there is another person nearby. He/she should be familiar with the operation and hazards of the equipment. He/she should also be competent in giving first aid. When you are helped by operators, you must warn them about dangerous areas.

Whenever possible, the power supply to the equipment must be shut off before beginning work on the equipment. If it is necessary to work on the equipment with power on, do not touch anything in the power supply area. Take special care to ground every capacitor likely to hold a dangerous potential. When working inside the equipment after the power has been turned off, always ground every part before touching it.

Be careful not to contact high-voltage connections when installing or operating this equipment.

Whenever possible, keep one hand away from the equipment to reduce the hazard of current flowing through vital organs of the body.

## **WARNING**

Do not be misled by the term "low voltage". Voltages as low as 50 volts may cause death.

For artificial respiration, refer to FM 21-11.

## **WARNING**

Remove rings, bracelets, wristwatches, and neck chains before working around electronic equipment. Jewelry can catch on equipment and cause injury, or may short across an electrical circuit and cause severe burns or electrical shock.



Change

No. 2

HEADQUARTERS  
DEPARTMENT OF THE ARMY  
Washington, DC, 15 September 1991

Organizational and Direct Support Maintenance Manual

Disk Memory Unit

MU-705\MYQ-4

(NSN 7025-01-092-2745) (EIC: N/A)

TM 11-7025-208-23, 8 March 1984, is changed as follows:

1. New or changed material is indicated by a vertical bar in the margin of the page. Added or revised illustrations are indicated by a vertical bar in front of the figure captions and by a pointing hand on the illustration pages.

Remove pages

1-5 through 108  
4-1 and 4-2  
4-7 and 4-8  
4-11 through 4-24  
4-27 and 4-28  
4-39 and 4-40  
None  
4-47 through 4-50  
4-53 and 4-54  
4-79 through 4-82  
4-93 through 4-96  
4-149 and 4-150  
4-159 and 4-160  
4-165 through 4-168  
4-217 and 4-218  
4-227 and 4-228  
4-233 through 4-236  
Index-1 through Index-4  
F0-1  
F0-2 (1 of 2)  
F0-3 (1 of 2)  
F0-3 (2 of 2)  
F0-4  
F0-5  
F0-6  
F0-7  
F0-8  
F0-9  
None

Insert pages

1-5 through 1-8  
4-1 and 4-2  
4-7 and 4-8  
4-11 through 4-24  
4-27 and 4-28  
4-39 and 4-40  
4-42.1/(4-42.2 blank)  
4-47 through 4-50  
4-53 and 4-54  
4-79 through 4-82  
4-93 through 4-96  
4-149 and 4-150  
4-159 and 4-160  
4-165 through 4-168  
4-217 and 4-218  
4-227 and 4-228  
4-233 through 4-236  
Index-1 through Index-4  
F0-1  
F0-2 (1 of 2)  
F0-3 (1 of 2)  
F0-3 (2 of 2)  
F0-4  
F0-5  
F0-6  
F0-7  
F0-8  
F0-9  
F0-10

2. File this change sheet in the front of the publication for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO  
*General, United States Army*  
*Chief of Staff*

Official:

PATRICIA P. HICKERSON  
*Colonel, United States Army*  
*The Adjutant General*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-36-E,  
block 5185, Unit and Direct Support/General Support  
Maintenance requirements for TM 11-7025-208-23.

CHANGE  
NO. 1

TM 11-7025-208-23  
cl  
HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, DC, 2 May 1985

ORGANIZATIONAL AND DIRECT SUPPORT  
MAINTENANCE MANUAL

DISK MEMORY UNIT  
MU-705/MYQ-4

(NSN 7025-01-092-2745)

TM 11-7025-208-23, 8 March 1984, is changed as follows:

1. New or changed illustrations are indicated by a miniature pointing hand. New or changed text is indicated by a vertical bar in the margin.
2. Remove old pages and insert new pages as indicated below.

Remove

4-1 and 4-2

Index-3 and Index-4  
FO-2 (2 of 2)

Insert

4-1 and 4-2

4-239 thru 4-243/(4-244 blank)  
Index-3 and Index-4  
FO-2 (2 of 2)

3. File this change sheet in front of the publication for reference purposes.

---

Change 1 adds a maintenance procedure for the spindle assembly and corrects an error in the power supply schematic diagram.

By Order of the Secretary of the Army:

Official:

JOHN A. WICKHAM JR.  
*General, United States Army*  
*Chief of Staff*

DONALD J. DELANDRO  
*Brigadier General, United States Army*  
*The Adjutant General*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-51 literature requirements for AN/IIYQ-4.

## CHAPTER 4 DIRECT SUPPORT MAINTENANCE INSTRUCTIONS

### Index of Maintenance Procedures

Paragraph No.	Title	Page No.
4-11	Remove/Replace Cover for Maintenance	4-59
4-12	Raise/Lower Deck for Maintenance	4-64
4-13	Remove/Replace Blower Motor	4-69
4-14	Remove/Replace Terminal Board	4-72
4-15	Remove/Replace AC Transformer	4-74
4-16	Remove/Replace Run Triac	4-78
4-17	Remove/Replace Interlock Switch	4-80
4-18	Remove/Replace Power Supply Assembly	4-82
4-19	Adjust Plus/Minus 5 Volts	4-87
4-20	Remove/Replace Servo Starting Capacitors	4-98
4-21	Remove/Replace Blower or Transformer Tuning Capacitor	4-100
4-22	Remove/Replace Elapsed Time Meter	4-102
4-23	Remove/Replace AC or DC Circuit Breaker	4-105
4-24	Remove/Replace Line Filter	4-109
4-25	Raise/Lower Logic Cage for Maintenance	4-113
4-26	Remove/Replace Logic Cage Boards	4-117
4-27	Remove/Replace Backplane	4-119
4-28	Remove/Replace/Adjust Heads Loaded Switch	4-123
4-29	Remove/Replace Read/Write Heads	4-128
4-30	Check/Align Read/Write Heads	4-133
4-31	Remove/Replace Servo Head	4-155
4-32	Clean Heads	4-160
4-33	Remove/Replace Drive Belt	4-162
4-34	Adjust Drive Belt	4-164
4-35	Remove/Replace Solid State Switch	4-166
4-36	Remove/Replace Drive Motor Capacitor	4-169
4-37	Remove/Replace Static Ground Spring	4-171
4-38	Adjust Static Ground Spring	4-173
4-39	Remove/Replace Spindle Motor	4-174
4-40	Remove/Replace Brake Assembly	4-179
4-41	Remove/Replace Read/Write Board Assembly	4-181
4-42	Remove/Replace Track Servo Preamp	4-187
4-43	Remove/Replace Power Amplifier Assembly	4-191
4-44	Remove/Replace Speed Transducer	4-194
4-45	Check and Adjust Speed Transducer	4-198
4-46	Remove/Replace Velocity Transducer	4-201
4-47	Adjust Velocity Gain	4-210
4-48	Manually Position Carriage Coil	4-222
4-49	Remove/Replace Control Panel	4-225
4-50	Remove/Replace Deck Interlock Switch	4-227
4-51	Remove/Replace Absolute Filter	4-229
4-52	Remove/Replace Adjust Pack Cover Solenoid	4-231
4-53	Install/Test Field Test Unit	4-233
4-54	Remove/Replace Spindle Lockshaft	4-237

## Section 1. REPAIR PARTS, SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

### 4-1. COMMON TOOLS AND EQUIPMENT

For authorized common tools and equipment, refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

### 4-2. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

Refer to TM 11-7010-203-23P for a complete listing and description of special tools, TMDE and support equipment required by organizational maintenance. Also refer to appendix B for a list of tools pertaining to the disk drive assembly.

### 4-3. SPARES AND REPAIR PARTS

Refer to TM 11-7010-203-23P for a complete listing and description of spares and repair parts required for direct support maintenance of this equipment.

## Section II. TROUBLESHOOTING

### 4-4. GENERAL

The most effective way to troubleshoot a fault in this equipment is to follow a routine which guides you through the five phases of troubleshooting (fig. 4-1). By following this routine you assure accurate use of fault isolation and fix procedures. You also improve your troubleshooting skills.

#### 4-5. TROUBLESHOOTING PHASES

Each of the five phases in this routine is designed to accomplish a specific goal.

a. Fault Discovery. Usually, the operators or supervisor will notice faulty performance first. They must report the fault on the proper form so you will have the facts you need for the next phase.

b. Failure Confirmation. Based on the facts provided by the operator or supervisor, you must confirm the failure and define the symptom. The symptom is the first clue you will use in the troubleshooting process.

c. Troubleshooting Entry. Using the symptom defined during phase two, find the troubleshooting flow chart which will help you isolate the fault in the equipment. The checkout and symptom index chart (chart-00) will help you do this.

d. Trouble Isolation. Follow the step-by-step procedures in the flow charts to isolate and correct the cause of the equipment failure.

SUBJECT	M	PARAGRAPH
Machi ne Cl ock Functi ons . . . . .		2-9
Mai ntenance		
Forms, Records and Reports. . . . .		1-3
Procedures . . . . .		4-9
Major Components, Locati on and Descri pti on of . . . . .		1-12
Manu ally Posi ti on Carri age Coin . . . . .		4-48
	N	
Nom encl ature Cross Reference Li st . . . . .		1-8
	O	
Operati on, Head . . . . .		2-10
	P	
Pack Cover Sol enoi d, Remove/Repl ace/Adj ust . . . . .		4-52
Pl us/Mi nus 5 Vol ts, Adj ust . . . . .		4-19
PMCS Procedures . . . . .		3-7
Power Ampl i fi er Assembl y, Remove/Repl ace . . . . .		4-43
Power Suppl y Assembl y, Remove/Repl ace . . . . .		4-18
Power System Functi ons . . . . .		2-3
Precauti ons, Equi pment Handl i ng . . . . .		4-9
Procedures		
Al ternati ve Troubl eshooti ng . . . . .		4-6
Mai ntenance. . . . .		4-9
PMCS . . . . .		<b>3-7</b>
Troubl eshooti ng. . . . .		4-7
	R	
Rai se/Lower Deck for Mai ntenance . . . . .		4-12
Rai se/Lower Logi c Cage for Mai ntenance . . . . .		4-25
Read/Wri te Board Assembl y, Remove/Repl ace . . . . .		4-41
Read/Wri te Functi ons . . . . .		2-11
Read/Wri te Heads, Check/Al i ne . . . . .		4-30
Read/Wri te Heads, Remove/Repl ace . . . . .		4-29
Records, Mai ntenance . . . . .		1-3
Reference Informati on . . . . .		1-7
Remove/Repl ace		
Absol ute Fil ter. . . . .		4-51
AC or DC Ci rcui t Breaker . . . . .		4-23
AC Transformer . . . . .		4-15
Backpl ane. . . . .		4-27
Bl ower Motor . . . . .		4-13
Bl ower or Transformer Tuning Capaci tor . . . . .		4-21
Brake Assembl y . . . . .		4-40
Control Panel . . . . .		4-49
Cover for Mai ntenance . . . . .		4-11
Deck Interlock Swi tch . . . . .		4-50
Dri ve Bel t . . . . .		4-33

SUBJECT	R (CONT)	PARAGRAPH
Drive Motor Capacitor . . . . .		4-36
Elapsed Time Meter . . . . .		4-22
Interlock Switch . . . . .		4-17
Line Filter . . . . .		4-24
Logic Cage Boards . . . . .		4-26
Pack Cover Solenoid . . . . .		4-52
Power Amplifier Assembly . . . . .		4-43
Power Supply Assembly . . . . .		4-18
Read/Write Board Assembly . . . . .		4-41
Read/Write Heads . . . . .		4-29
Run Triac . . . . .		4-16
Servo Head . . . . .		4-31
Servo Starting Capacitors . . . . .		4-20
Solid State Switch . . . . .		4-35
Speed Transducer . . . . .		4-44
Spindle Motor . . . . .		4-39
Spindle Lockshaft . . . . .		4-54
Static Ground Spring . . . . .		4-37
Terminal Board . . . . .		4-14
Track Servo Preamp . . . . .		4-42
Velocity Transducer . . . . .		4-46
Remove/Replace/Adjust Heads Loads Switch . . . . .		4-28
Remove/Replace/Adjust Pack Cover Solenoid . . . . .		4-52
Repair Parts, Spares and . . . . .	3-3,	4-3
Reporting Equipment Improvement Recommendations (EIR) . . . . .		1-6
Reports, Maintenance . . . . .		1-3
Run Triac, Remove/Replace . . . . .		4-16

S

Seek, Functions . . . . .		2-6
Servo Head, Remove/Replace . . . . .		4-31
Servo Starting Capacitor, Remove/Replace . . . . .		4-20
Solenoid, Remove/Replace/Adjust Pack Cover . . . . .		4-52
Solid State Switch, Remove/Replace . . . . .		4-35
Spares and Repair Parts . . . . .	3-3,	4-3
Special Tools, TMDE and Support Equipment . . . . .	3-2,	4-2
Speed Transducer, Check and Adjust . . . . .		4-45
Speed Transducer, Remove/Replace . . . . .		4-44
Spindle Motor, Remove/Replace . . . . .		4-39
Spindle Lockshaft, Remove/Replace . . . . .		4-54
Static Ground Spring, Adjust . . . . .		4-38
Static Ground Spring, Remove/Replace . . . . .		4-37
Storage, Administrative . . . . .		1-5
Support Equipment . . . . .	3-2,	4-2



**5**

SAFETY STEPS TO FOLLOW IF SOMEONE  
IS THE VICTIM OF ELECTRICAL SHOCK

**1**

DO NOT TRY TO PULL OR GRAB THE INDIVIDUAL

**2**

IF POSSIBLE , TURN OFF THE ELECTRICAL POWER

**3**

IF YOU CANNOT TURN OFF THE ELECTRICAL  
POWER, PULL, PUSH, OR LIFT THE PERSON TO  
SAFETY USING A WOODEN POLE OR A ROPE OR  
SOME OTHER INSULATING MATERIAL

**4**

SEND FOR HELP AS SOON AS POSSIBLE

**5**

AFTER THE INJURED PERSON IS FREE OF  
CONTACT WITH THE SOURCE OF ELECTRICAL  
SHOCK, MOVE THE PERSON A SHORT DISTANCE  
AWAY AND IMMEDIATELY START ARTIFICIAL  
RESUSCITATION



ORGANIZATIONAL AND DIRECT SUPPORT  
MAINTENANCE MANUAL  
DISK MEMORY UNIT  
Mu-705/MYQ-4

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in back of this manual, direct to: Commander, US Army Communications and Electronics Command and Fort Monmouth, ATTN: DRSEL-ME-MP, Fort Monmouth, New Jersey 07703. A reply will be furnished to you.

	Page
	v
HOW TO USE THIS MANUAL . . . . .	
CHAPTER 1 INTRODUCTION . . . . .	1-1
Section I General Information . . . . .	1-1
Section II Equipment Description and Data . . . . .	1-2
CHAPTER 2 TECHNICAL PRINCIPLES OF OPERATION . . . . .	2-1
CHAPTER 3 ORGANIZATIONAL MAINTENANCE INSTRUCTIONS . . . . .	3-1
Section I Repair Parts, Special Tools, TMDE, and Support Equipment . . . . .	3-1
Section 11 Service Upon Receipt . . . . .	3-1
Section 111 Preventive Maintenance Checks and Services . . . . .	3-2
CHAPTER 4 DIRECT SUPPORT MAINTENANCE INSTRUCTIONS . . . . .	4-1
Section I Repair Parts, Special Tools, TMDE, and Support Equipment . . . . .	4-2
Section II Troubleshooting . . . . .	4-2
Section III Maintenance Procedures . . . . .	4-56
APPENDIX A REFERENCES . . . . .	A-1
APPENDIX B MAINTENANCE ALLOCATION CHART . . . . .	B-1
APPENDIX C EXPENDABLE SUPPLIES AND MATERIALS LIST . . . . .	C-1
APPENDIX D SCHEMATIC DIAGRAMS . . . . .	D-1
GLOSSARY . . . . .	Glossary-1
INDEX . . . . .	Index-1



## HOW TO USE THIS MANUAL

This manual tells you how to troubleshoot and maintain the Disk Memory Unit MU-705/MYQ-4.

---

### LOCATION OF SUBJECTS IN MANUAL

---

In this manual, paragraphs are numbered in order by chapter. For example, paragraph 2-3 is the third paragraph in chapter 2. Pages are also numbered this way. Using this numbering system, there are three easy ways to locate the information you need in this manual.

- Front cover locators
- Alphabetical index
- Index of maintenance procedures

Use the front cover locators and marked pages to quickly find the parts of the manual shown on the cover. These locators mark portions of the manual which are used often. If the information you need is not listed on the front cover, use the alphabetical index at the back of this manual. It lists all subjects covered in the manual and directs you to the subject by paragraph number. When you need a specific maintenance procedure, use the index at the start of chapter 3 or 4. This index lists all the maintenance procedures in the chapter and directs you to each procedure by page number.

MAINTENANCE PROCEDURES

Maintenance procedures in this manual have two features which help you perform them more easily:

- initial setup boxes
- First-time performance aids

An initial setup box is used at the start of any procedure which requires setup items before you perform it. This box lists items needed to perform the procedure. If the box does not appear at the start of a procedure, no setup items are needed.

If you are using this manual to perform a procedure for the first time, always read through the entire procedure before you start. Always perform the task steps in the order given. This will help assure correct performance. Use the illustrations beside the task steps to find the parts of the equipment called out in the steps. Some steps include a reference to another paragraph. Go to that paragraph if you are not sure how the step is done.




Figure 1-0. Disk Memory Unit MU-705/MYQ-4

# CHAPTER 1 INTRODUCTION

## Section 1. GENERAL INFORMATION

---

### 1-1 SCOPE

---

Disk Memory Unit MU-705/MYQ-4 (fig. 1-0) is an auxiliary memory storage unit used to support a minicomputer. It stores data on interchangeable disk packs. In the rest of this manual it will be called the disk drive. Use this manual for organizational and/or direct support maintenance of the disk drive.

---

### 1-2. INDEX OF PUBLICATIONS

---

Refer to the latest issue of DA Form 310-1 to determine whether there are new editions, changes or additional publications pertaining to the disk drive.

### 1-3. MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by TM 38-750, The Army Maintenance Management System (TAMMS).

### 1-4. DESTRUCTION OF ARMY ELECTRONICS MATERIEL

Destruction of Army electronics materiel to prevent enemy use shall be in accordance with TM 750-244-2.

### 1-5. ADMINISTRATIVE STORAGE

Administrative storage of equipment issued to and used by Army activities will have PMCS performed before storing. When removing the equipment from administrative storage, the PMCS checks should be performed to assure operational readiness. Disassembly and repacking of equipment for limited storage are covered in TM 740-90-1.

### 1-6. Reporting EQUIPMENT Improvement RECOMMENDATIONS (EIR)

If your disk drive needs improvement, let us know. Send us an EIR. you, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at Commander, U. S. Army Communications and Electronics Command and Fort Monmouth, Attn: DRSEL-ME-MP, Fort Monmouth, NJ 07703. We'll send you a reply.

1-7. REFERENCE INFORMATION
----------------------------

This listing includes the nomenclature cross reference list, the list of abbreviations and an explanation of terms (glossary) used in this manual.

## 1-8. NOMENCLATURE CROSS-REFERENCE LIST

Common names are used throughout this manual, but you must use the official nomenclature when filling out report forms, sending an EIR, or finding referenced technical manuals.

<u>Common Name</u>	<u>Official Nomenclature</u>
Disk Drive	Disk Memory MU-705/MYQ-4

## 1-9. LIST OF ABBREVIATIONS

EDAC	Error detection and correction
MSU	Mass storage unit

## 1-10. GLOSSARY

A complete glossary of unusual terms is given in the back of this manual. (Glossary-1)

## Section II. EQUIPMENT DESCRIPTION AND DATA

### 1-11. EQUIPMENT PURPOSE, CAPABILITIES AND FEATURES

The disk drive is a high speed, random access, digital data storage device. The disk drive provides auxiliary memory storage for a central processor. It is connected to the central processor through a memory controller. The capabilities and features are as follows:

- Removable magnetic disk pack for storing and retrieving data. Inside the pack, five disk surfaces are used for reading/writing data. The sixth surface, the servo surface, provides position information and timing signals.
- Write protect circuitry to prevent writing over permanent data that must be saved
- Speed detection circuitry which detects loss of speed or power
- Error detection and correction circuitry for validity check
- Power detection circuitry for ac/dc fault check
- Check indicator circuitry to warn of fault occurrence
- Major assemblies are designed for ease of fault isolation and repair



---

**1-12. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS**

---

The disk drive houses all major components within one drawer (fig. 1-1). The components are divided into three major assemblies; base assembly (fig. 1-2), deck assembly (fig. 1-5) and logic cage assembly (fig. 1-3).





Figure 1-1. Disk Drive Major Components



ABSOLUTE FILTER - Removes dirt from air before air is forced into pack area.


BLOWER MOTOR - Blows clean air into pack area and cooling air into logic chassis.

POWER CONTROL - Controls application of ac and dc power. Panel contains an elapsed time meter and circuit breakers.

DC POWER SUPPLY - Rectifies ac power and provides eight dc output voltages, as well as emergency retract control.

AC POWER SUPPLY - Filters and controls ac power and provides power to drive, blower motors, and to dc power supply. Includes all shaded components in illustration.

Figure 1-2. Base Assembly Components



**LOGIC BOARDS** - Contain most of the integrated and discrete circuitry which make up the functional logic. (See figure 1-4)

**TERMINATOR BOARDS** - Contains termination resistors for receivers and transmitters. (Used only on last drive in a daisy chain string. )

**I/O BOARDS** - Interface I/O cable with backpanel.

**BACKPLANE** - Contains all wiring which interconnects logic boards, I/O boards, terminator boards, and other cables attached to logic chassis.

**MAINTENANCE SWITCHES AND INDICATORS** - Used during test and diagnostic procedures. (See figure 1-6).

Figure 1-3. Logic cage assembly Components




Figure 1-4. Logic Cage Board Locations




Figure 1-5. Deck Assembly Components (1 of 2)

ACTUATOR - Used to position servo and read/write heads. Made up of rail bracket, rails, carriage coil assembly, magnet assembly; also contains velocity transducer.

POWER AMPLIFIER - Provides final amplifications of servo positioning signal before it is applied to carriage coil.

TRACK SERVO PREAMPLIFIER - Provides first stage of amplification for track servo signal which is read from magnetic disk pack by servo head.

DRIVE MOTOR AND BRAKE - Drive motor drives spindle which in turn drives magnetic disk pack. Brake is used to slow and stop magnetic disk pack after drive motor is turned off.

SPEED TRANSDUCER - Magnetic pickup which provides information to logic on relative speed of magnetic disk pack.

PACK COVER SOLENOID - Locks pack cover on loss of power or when disk pack is spinning. Releases cover 30 seconds after drive motor shuts off.

CONTROL PANEL - Used by operator to control operation of drive. Contains three switches and indicators and the logical address plug.

SHROUD - Provides protection and ventilation for magnetic disk pack.


PACK COVER INTERLOCK SWITCH - Prevents drive motor from starting when pack access cover is opened.

PARKING BRAKE - Prevents spindle from turning while magnetic disk pack is being installed or removed.

SPINDLE - Provides surface to secure disk pack and means of transmitting drive motor rotational motion to pack.

HEADS - Servo head reads data from magnetic disk pack servo surface to control actuator positioning. Read/write heads record and read back data on magnetic disk pack data surfaces.

Figure 1-5. Deck Assembly Components (2 of 2)



- |   |  |  |
|---|--|--|
| ① | Local /Remote Switch                       | LOCAL position prevents control of power sequencing by controller. Drive is powered on and off by START switch assuming circuit breakers are set to ON. REMOTE position allows controller to command power sequencing. Drive cannot be started until a ground is applied via subsystem Power Sequence Pick and Hold lines. |
| ② | Fault Clear Switch                         | CLEAR position clears out Fault Latch and five Fault Status Latches. When switch is actuated, fault indicators on edge of fault beard go out and remain out unless condition causing fault still exists. NORM is normal operating position for switch and position to which it returns when released (spring loaded).      |
| ③ | Voltage Fault Indicator                    | Lights to indicate a below normal voltage existed.   |
| ④ | Write Fault Indicator                      | Lights to indicate a write fault existed.  |
| ⑤ | Head Select Indicator                      | Lights to indicate a multiple head select occurred.  |
| ⑥ | Read/Write Indicator                       | Lights to indicate that both write and read were selected simultaneously.  |
| ⑦ | $\overline{\text{oc}}$ ● (W + R) Indicator | Lights to indicate that a write or read was selected during a seek operation (not on cylinder).  |
| ⑧ | Disable Switch                             | DISABLE position prevents Unit Selected from being sent to controller and disables transmitters and receivers. NORM is normal operating position.  |

Figure 1-6. Maintenance Switches and Indicators

## 1-13. EQUIPMENT IDENTIFICATION PLATE

An equipment identification plate (fig. 1-7) is installed on the right front of the disk drives located under the pack cover.





Figure 1-7. Location of Identification Plate

1-14. DIFFERENCES BETWEEN DISK DRIVE MODELS

There are two variations of ac power cord installations (fig. 1-8) a permanent cord mount in serial numbers 25 thru 108 and a removable power cord starting on serial numbers 109 and up.



**NOTE:**  
USED ON EQUIPMENT  
SERIAL NO. 25 THRU 108.

**NOTE:**  
USED ON EQUIPMENT STARTING  
WITH SERIAL NO. 109.

Figure 1-8. Disk Drive Power Cord Installations

**1-15. EQUIPMENT DATA**

**Weight and dimensions:**

Weight 340.0 lb (154.5 kg)  
 Height 36.2 in. (92.0 cm)  
 Width 23.0 in. (58.4 cm)  
 Depth 36.0 in. (91.4 cm)

**Operating environment:**

Temperature 50°F to 100°F (10°C to 38°C)  
 Relative humidity 10% to 90% (noncondensing)

**Electrical requirements:**

Voltage 102 V ac to 132 V ac  
 Frequency 60 Hz



## Altitude:

Operating 1000 ft (305 m) to 6500 ft (2000 m)  
 Transit (packed for 1000 ft (305 m) to 15,000 ft (4572 m)  
 shipment)

## Disk Pack:

Type M4130  
 Disks/Pack 3 (Top and bottom disks are for protection only.)  
 Data Surfaces 5  
 Servo Surfaces 1  
 Usable Tracks/Surface 823  
 Tracks/Inch 384  
 Track Spacing (center  
 to center) 0.0026 (.66 mm)  
 Coating Magnetic Oxide

## Data Capacity:

Bytes/Track 20,160  
 Bytes/Cylinder 100,800  
 Bytes/Spindle 82,958,400  
 Cylinders/Spindle 823

## Recording Characteristics:

Mode Modified Frequency Modulation (MFM)  
 Density (nominal)  
 Outer Track 4038 bits/in. (1590 bits/cm)  
 Inner Track 6038 bits/in. (2377 bits/cm)  
 Rate (nominal) 9.67 MHz (1,209,600 bytes/see)

## Heads

Read/write 5  
 Servo 1  
 Read/Write Width 0.002 in. (0.051 mm)

## Seek Characteristics:

Mechanism Voice Coil, Driven By Servo Loop  
 Max Seek Time (411 or  
 823 Tracks) 55 ms  
 Max Track Seek Time 6 ms  
 Average Seek Time 30 ms

## Latency:

Average 8.33 ms (at 3600 r/rein)  
 Maximum 17.3 ms (at 3474 r/rein)

Spindle Speed: 3600 r/rein

Drives Per Controller: 4 maximum (0 through 3)



## CHAPTER 2 TECHNICAL PRINCIPLES OF OPERATION

### 2-1. GENERAL

This chapter tells you how the disk drive works. This information will help you perform troubleshooting and corrective maintenance procedures.

### 2-2. FUNCTIONAL DESCRIPTION

The disk drive is an electromechanical device. Operation involves nine interrelated functions:

- Power system functions
- Electromechanical functions
- Interface functions
- Unit selection
- Seek functions
- Track orientation
- Machine clock functions
- Head operation
- Read/write functions
- Fault detection

A functional block diagram (fig. 2-1) shows the interrelationship of these functions which are explained in subsequent paragraphs.

### 2-3. POWER SYSTEM FUNCTIONS

Power system functions (fig. 2-2) include the power system functional areas; power distribution, power on/off, and emergency heads retract.

a. Power Distribution. Consists of routing primary power to the power supply and other primary power operated components of the disk drive. Power is also applied by the ac power circuit breaker to the blower which provides filtering and ventilation. With the circuit breaker on, power is available to the start and run triacs which will start the drive motor during the power-on sequence. The power supply circuit breaker energizes the power supplies which provide operating voltages for the disk drive circuitry.




Figure 2-1. Disk Drive Functional Block Diagram

b. Power On Sequence. Starts and runs the drive motor and extends the heads over the disk surface. The drive motor is started by the start triac while the brake is disabled. After initial start, the run triac supplies power to the drive motor. When operating speed is reached, power is applied to the voice coil and the heads extend; the start triac goes off.

c. Power Off Sequence. Unloads the heads, powers off the drive motor and applies the brake.

d. Emergency Retract Relay. Operates automatically during an equipment failure. The heads automatically retract to prevent damage to the heads or the disk pack. When a power failure occurs, the emergency retract relay is deenergized and voltage is applied to the voice coil to retract the heads.

2-4. ELECTROMECHANICAL FUNCTIONS

Electromechanical functions (fig. 2-3) consists of; disk pack rotation, head positioning, filtering and ventilation.

Disk Pack Rotation. The disk pack must be rotated fast enough to create a cushion of air on which the heads will fly. This allows the heads to move over the disk surfaces without touching them. The drive motor provides the rotary motion for the disk pack. A spindle, driven by the motor, is the mechanical mounting for the disk pack. A canister actuated parking brake stops spindle rotation during disk pack loading and unloading. Spindle speed is monitored by a speed transducer. An interlock is provided to ensure that the pack access cover is closed before disk pack rotation can occur.




Figure 2-2. Power System Functional Block Diagram

b. Head Positioning. The heads read from and write data on magnetic disks. The heads must be positioned over a specific track on the disk prior to performing the read/write operation. Head positioning is done by a carriage and voice coil assembly which is controlled by servo signals. The carriage and voice coil assembly is mounted on the deck assembly and, extends the head into the disk pack. The heads are electromagnetic devices which perform the read/write functions. There are five read/write heads and a servo head. The servo head provides positioning data to position control circuits.

c. Filtering and Ventilation. The air flow system provides ventilation for the electronic components and filtered air in the disk pack area. A blower assembly, and absolute filter are the main components of the air flow system. Air is drawn through the absolute filter, which removes all particles which might cause damage on the heads or disk pack. The blower pulls the air in and forces it through the disk pack area. Air is also vented into the electronic component area.

2-5. INTERFACE FUNCTIONS

Interface functions (fig. 2-4) include I/O signals from the CPU which initiate and control all disk drive operations except power on. All the signal lines are contained in two I/O cables, the A cable and the B cable. The A cable carries command and control information to the disk drive and status information to the CPU. Read/write signals and timing information between the disk drive and the CPU are carried on the B cable. Interrupt signals from the disk drive to the CPU are also carried on the B cable.




Figure 2-3. Electromechanical Functions Block Diagram

## 2-6. UNIT SELECTION

The disk drive must be selected before it will respond to commands from the controller or transmit certain I/O signals to it. The Tag/Bus Out decode and certain transmitters are not enabled until the Module Addressed signal is active.

The unit select sequence is initiated by a select tag (000) accompanied by an address in its Bus Out bits 24 thru 27. Because the tag and Bus Out receivers are enabled by the Drive Select Hold signal, this signal must be active when the Unit Select tag and logical address are sent.

When the drive recognizes the Unit Select tag, it compares its own logical address to the address sent by the controller. The logical address of the drive is determined by the logical address plug which is installed in the control panel. Depending on the plug used, this address can be any number from 1 thru 15. If no plug is installed the address is 15.

If the address sent by the controller is the same as that of the drive, the drive enables its Module Addressed signal. This signal is sent to the controller and is also used by the drive to enable certain transmitters and the Tag/Bus Out function decode to decode other commands.

## 2-7. SEEK FUNCTIONS

The seek functions (fig. 2-5) move the heads to the required position over the disk pack. This must be done for any read/write operation.

The basic circuit of the seek functions is the servo loop. This consists of the position control circuits, position signal amplifiers, head positioning mechanism and velocity and position feedback circuits. The position control circuits are return-to-zero/load/unload coarse control, direct seek coarse control and fine control. The circuit used depends on how close the heads are to the desired position and which type of seek is being performed. The position control signal is processed by the position control amplifier and used to generate current for the voice coil. As the heads move, feedback signals indicate head velocity and position. Both velocity and position feedback signals are used to vary the




Figure 2-4. Interface Functions Block Diagram

position control signal as the desired head position is reached. The feedback signals also determine when the system switches from coarse to fine control. Fine control accurately positions the heads over the correct track and maintains it during read/write operations. The seek end and seek error detection circuits sense when the seek is complete and whether or not it was successful.

2-8. TRACK ORIENTATION

Before any write or read operation takes place, the CPU must instruct the disk drive to position the heads over the desired track. This is called seek logic. At the same time, the CPU must instruct the disk drive to use the head located over the surface where the operation is to be performed. This is called head selector logic.

After selecting a head and commanding it to seek a specific data track, the CPU must still locate that segment of the track on which the data is to be written or read. This is called track orientation logic. Track orientation is done by using the index signal and the sector signals generated by the disk drive. The index signal indicates the logical beginning of each track. The sector signals are used by the CPU to determine the position of the head on the track with respect to the index.




Figure 2-5. Seek Functions Block Diagram



When the desired data track location is found, the CPU commands the disk drive to write or read data. During a write operation, the disk drive receives digital data from the CPU, processes it, and writes it on the magnetic disk pack. During a read operation, the disk drive recovers digital data from the magnetic disk pack and sends it to the CPU.

2-9. MACHINE CLOCK FUNCTIONS

The machine clock circuits generate the clock signals necessary for drive operation. The circuits are the servo clock multiplier and the write clock multiplier.

a. Servo Clock Multiplier. Figure 2-6 is a block diagram of the servo clock multiplier circuit. This circuit generates clock pulses used by the sector




Figure 2-6. Servo Clock Multiplier

detection, index detection and read phase lock oscillator (PLO) circuits. It also generates the 9.67 mHz servo clock signal that is sent to the CPU. The phase lock loop is the main element in the servo clock multiplier circuit. The function of the loop is to adjust itself until its output is identical in phase and frequency to its input. The input consists of the dibit signals from the track servo circuit. The actual frequency is a function of and varies directly with disk pack speed. The output of the loop also varies with disk pack speed. The phase and frequency detection circuit makes the comparison between the input dibits and the output of the loop. The outputs from the detector are fixed amplitude pulses which are a function of the time (phase) difference between the positive going edges of the two inputs. These outputs are applied to the error amplifier which integrates them and generates a voltage proportional to the phase difference between them.

This voltage controls the voltage controlled oscillator. When the VCO output is 9.67 mHz, the feedback will equal the output equivalent to disk pack speeds, and the loop will be synchronized.

b. Write Clock Frequency Multiplier. The write clock frequency multiplier generates the frequencies used during write operations. This circuit consists of a phase lock loop operating in a similar manner to the servo clock loop operating in a similar manner to the servo clock multiplier. The input signal is the write clock signal for the CPU. The phase lock loop synchronizes with these signals and produces outputs used by the write compensation circuits during write operations.

2-10. HEAD OPERATION

Information is recorded on and read from the disk by the read/write heads (fig. 2-7). The disk drive has five read/write heads, one for each recording surface on the disk pack. Data is written by passing a current through a read/write coil within the selected head. A flux field is generated across the gap in the head and magnetizes the iron oxide particles in the disk surface. Erasing old data is done by writing over the data already on the disk. During read operation, disk motion beneath the head causes stored flux to induce a voltage in the head coil. The read circuit analyzes this voltage to define the data written on the disk.




Figure 2-7. Read/Write Heads

## 2-11. READ/WRITE FUNCTIONS

During a read operation, the disk drive reads data from a disk and transfers it to the CPU. In a write operation, the disk drive receives data from the CPU and writes it on a disk. Figure 2-8 is a block diagram of the read/write circuits.

a. Write Circuits. The write circuits operation is initiated by the proper **signal** from the CPU. This allows the drive to start processing data. The write data is sent to the converter/write compensation circuits. These circuits convert the data to modified frequency modulation and compensate for variations in data frequency. The compensated data is then processed by the write drive circuit and written on the disk.

b. Read Circuits. When the read operations are initiated, the analog data detection circuits are energized. These circuits sense the data written on the disk and generate analog read data signals. The read data goes to the analog-to-digital converter which converts it into digital modified frequency modulation data. The read circuits also detect the address mark area and send the program signal to the CPU.




Figure 2-8. Read/Write Circuits Block Diagram

## 2-12. FAULT DETECTION

The following conditions are interpreted by the fault detection circuit as errors. All of these conditions either light an indicator on the disk drive and/or send a signal to the CPU indicating that an error has occurred. The errors are divided into two categories. Those errors indicated by fault latch and register, and those not indicated by fault latch and register.

a. Errors Indicated by Fault Latch. Certain errors set the disk drive fault latches associated with the error condition. Setting the latches does four things:

- I Enables the fault line to the CPU
- I Lights the CHECK indicator on the disk drive control panel
- I Inhibits the write and load circuitry
- I Causes the check diagnostic bit to be true

The errors indicated by fault latch are write fault, head select fault, read and write fault, read or write and off cylinder fault and voltage fault.

b. Errors Not Indicated By Fault Latch. These errors are detected by the disk drive but are not stored in the fault latches. However, they do cause the drive to give other fault indications. The errors are low speed or low voltage, no servo track fault and seek error.

## CHAPTER 3 ORGANIZATIONAL MAINTENANCE INSTRUCTIONS

### Section 1. REPAIR PARTS, SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

#### 3-1. COMMON TOOLS AND EQUIPMENT

For authorized common tools and equipment refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

#### 3-2. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

Refer to TM 11-7010-203-23P for a complete listing and description of special tools, TMDE and support equipment required by organizational maintenance. Also refer to appendix B for a list of tools pertaining to the disk drive.

#### 3-3. SPARES AND REPAIR PARTS

Refer to TM 11-7010-203-23P for a complete listing and description of spares and repair parts required for organizational maintenance of this equipment.

### Section II. SERVICE UPON RECEIPT

#### 3-4. UNPACKING

Upon receipt of new equipment, check packing list and instructions for any precautions or specific unpacking procedures.

#### 3-5. CHECKING UNPACKED EQUIPMENT

Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on SF 364, Discrepancy in Shipment Report.

Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with the instructions of TM 38-750.

Check the equipment to ensure that required Modification Work Orders have been applied to accordance with DA PAM 310-1.

## Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES

### 3-6. GENERAL

Organizational maintenance PMCS is the required inspection and care of the equipment necessary to keep it in good operating condition. Routine checks like equipment inventory, cleaning, dusting, washing, checking for frayed cables, storing items not in use, covering unused receptacles and checking for loose nuts and bolts are not listed in your PMCS. They are things you should do anytime you see they must be done. If you find a routine check like one of these listed in your PMCS, it was listed because operators reported problems with this item.

### 3-7. PMCS PROCEDURES

PMCS procedures are done at fixed intervals for the following purposes:

- Make sure that the equipment is operable
- Prevent equipment problems in future operation
- Identify and resolve minor problems in the equipment before they become major problems
- Scheduled cleaning of the equipment

### 3-8. ITEM NUMBER COLUMN

The checks/services in the PMCS table are numbered in order of performance. Use this ITEM number when filling out DA Form 2404 (Equipment Inspection and Maintenance Worksheet).

### 3-9. ITEM TO BE INSPECTED COLUMN

The items listed in this column are based on the major components of the equipment and use common names of these components.

### 3-10. PROCEDURE COLUMN

This column gives you the check or service procedure which you must perform on the item.

### 3-11. EQUIPMENT WILL BE REPORTED NOT READY/AVAILABLE IF COLUMN

This column tells you under what conditions the equipment will be unable to perform its primary mission. When you notice this condition during PMCS you must report it on the proper form and tell your supervisor.

Table 3-1. Organizational Preventive Maintenance Checks and Services

Legend

M - Monthly

S - Semi annual

Item No.	Interval		Item To Be Inspected	Procedures	Equipment Will Be Reported Not Ready/ Available If:
	M	S			
1	●		Pack area and spindle	<p>NOTE</p> <p>Before you perform any of the PMCS, look to see if the READY indicator is lit. If it is, press START switch to cycle down disk drive. Wait one minute before you begin any PMCS.</p> <p>Clean pack area and spindle as follows:</p> <ol style="list-style-type: none"> <li>1. Slide drawer out.</li> <li>2. At rear of disk drive set AC POWER switch to OFF.</li> <li>3. Raise pack access cover.</li> </ol> <p><u>CAUTION</u></p> <p>Do not bump read/write heads with vacuum nozzle.</p> <ol style="list-style-type: none"> <li>4. Carefully vacuum entire pack area.</li> <li>5. Push in disk drive drawer,</li> </ol>	
2	●		Disk drive	<p>Clean disk drive as follows:</p> <ol style="list-style-type: none"> <li>1. Slide drawer out.</li> <li>2. At rear of disk drive, set AC POWER switch to OFF.</li> <li>3. Raise and remove cover.</li> </ol>	

Table 3-1. Organizational Preventive Maintenance Checks and Services -- Continued

Legend

M - Monthly

s - Semi annual

Item No.	Interval		Item To Be Inspected	Procedures	Equipment Will Be Reported Not Ready/ Available If:
	M	S			
				<p style="text-align: center;"><u>CAUTION</u></p> <p>Components, wiring, or brackets damage easily. Use vacuum nozzle carefully.</p> <p>4. Vacuum inside cover. Make sure you get dust out of all corners.</p> <p>5. Vacuum outside surface of logic cage.</p> <p>6. Vacuum all flat surfaces.</p> <p>7. Raise deck to maintenance position.</p> <p style="padding-left: 20px;">a. On back of drive, locate bolt and use 3/16 in. hex key, remove bolt and spacer from keeper hole.</p> <p style="padding-left: 20px;">b. Slide spacer under deck and line up with hole.</p> <p style="padding-left: 20px;">c. Push bolt through spacer and tighten bolt.</p> <p style="text-align: center;"><u>CAUTION</u></p> <p>Do not lift drive at pack access cover.</p> <p style="padding-left: 20px;">d. At front of drive, lift deck until support arm is fully extended.</p> <p style="padding-left: 20px;">e. Loosen knob and pull it out of storage hole.</p> <p style="padding-left: 20px;">f. Insert knob in locking hole. Tighten knob.</p>	



Table 3-1. Organizational Preventive Maintenance Checks and Services -- Continued

Legend

M - Monthly                      s - Semi annual

Item No.	Interval		Item To Be Inspected	Procedures	Equipment Will Be Reported Not Ready/ Available If:
	M	s			
3	●		Lockshaft	<p>8. Vacuum underside of deck assembly.</p> <p>9. Vacuum base assembly</p> <p>10. Lower deck to normal operating position.</p> <p>    a. Loosen knob. Pull it out of locking hole.</p> <p>    b. Insert knob in storage hole. Tighten knob.</p> <p>    c. With one hand, firmly grasp deck and lift.</p> <p>    d. With other hand, grasp arm and push forward towards front of drive, lower deck.</p> <p>11. Replace cover.</p> <p>12. Push in disk drive drawer.</p> <p>Clean and lubricate lockshaft as follows:</p> <p>1. Slide drawer out.</p> <p>2. At rear of disk drive, set AC POWER switch to OFF.</p> <p>3. Raise pack access cover.</p> <p>4. Use cotton swab to wipe old lubricant from threads of lockshaft.</p> <p>5. Dampen lint-free gauze with cleaning solution and wipe spindle.</p>	

Table 3-1. Organizational Preventive Maintenance Checks and Services -- Continued

Legend

M - Monthly                      s - Semi annual

Item No.	Interval		Item To Be Inspected	Procedures	Equipment Will Be Reported Not Ready/ Available If:
	M	s			
4		●	Absolute filter	<p>6. Using swab stick, put thin coat of new grease paste on threads.</p> <p>7. Close pack access cover.</p> <p>8. Push in disk drive drawer.</p> <p>Remove and replace absolute filter as follows:</p> <p>1. Slide drawer out. Remove cover.</p> <p>2. Remove bracket holding filter in place.</p> <p>3. Slide filter out of slot.</p> <p>4. Slide in new filter.</p> <p>5. Insert bracket in slot and position it over filter.</p> <p>6. Replace bracket screw and washer.</p> <p>7. Using small strip of masking tape, note date of installation on filter.</p> <p>8. Lower deck.</p> <p>9. Replace cover.</p>	

## CHAPTER 4 DIRECT SUPPORT MAINTENANCE INSTRUCTIONS

### Index of Maintenance Procedures

Paragraph No.	Title	Page No.
4-11	Remove/Replace Cover for Maintenance	4-59
4-12	Raise/Lower Deck for Maintenance	4-64
4-13	Remove/Replace Blower Motor	4-69
4-14	Remove/Replace Terminal Board	4-72
4-15	Remove/Replace AC Transformer	4-74
4-16	Remove/Replace Run Triac	4-78
4-17	Remove/Replace Deck Interlock Switch	4-80
4-18	Remove/Replace Power Supply Assembly	4-82
4-19	Adjust Plus/Minus 5 Volts	4-87
4-20	Remove/Replace Servo Starting Capacitors	4-98
4-21	Remove/Replace Blower or Transformer Tuning Capacitor	4-100
4-22	Remove/Replace Elapsed Time Meter	4-102
4-23	Remove/Replace AC or DC Circuit Breaker	4-105
4-24	Remove/Replace Line Filter	4-109
4-25	Raise/Lower Logic Cage for Maintenance	4-113
4-26	Remove/Replace Logic Cage Boards	4-117
4-27	Remove/Replace Backplane	4-119
4-28	Remove/Replace/Adjust Heads Loaded Switch	4-123
4-29	Remove/Replace Read/Write Heads	4-128
4-30	Check/Align Read/Write Heads	4-133
4-31	Remove/Replace Servo Head	4-155
4-32	Clean Heads	4-160
4-33	Remove/Replace Drive Belt	4-162
4-34	Adjust Drive Belt	4-164
4-35	Remove/Replace Solid State Switch (Start Triac)	4-166
4-36	Remove/Replace Drive Motor Capacitor	4-169
4-37	Remove/Replace Static Ground Spring	4-171
4-38	Adjust Static Ground Spring	4-173
4-39	Remove/Replace Spindle Motor	4-174
4-40	Remove/Replace Brake Assembly	4-179
4-41	Remove/Replace Read/Write Board Assembly	4-181
4-42	Remove/Replace Track Servo Preamp	4-187
4-43	Remove/Replace Power Amplifier Assembly	4-191
4-44	Remove/Replace Speed Transducer	4-194
4-45	Check and Adjust Speed Transducer	4-198
4-46	Remove/Replace Velocity Transducer	4-201
4-47	Adjust Velocity Gain	4-210
4-48	Manually Position Carriage Coil	4-222
4-49	Remove/Replace Control Panel	4-225
4-50	Remove/Replace Pack Cover Interlock Switch	4-227
4-51	Remove/Replace Absolute Filter	4-229
4-52	Remove/Replace Adjust Pack Cover Solenoid	4-231
4-53	Install/Test Field Test Unit	4-233
4-54	Remove/Replace Spindle Lockshaft	4-237
4-55	Remove/Replace/Adjust Spindle Assembly	4-239

## Section 1. REPAIR PARTS, SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

### 4-1. COMMON TOOLS AND EQUIPMENT

For authorized common tools and equipment, refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

### 4-2. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

Refer to TM 11-7010-203-23P for a complete listing and description of special tools, TMDE and support equipment required by organizational maintenance. Also refer to appendix B for a list of tools pertaining to the disk drive assembly.

### 4-3. SPARES AND REPAIR PARTS

Refer to TM 11-7010-203-23P for a complete listing and description of spares and repair parts required for direct support maintenance of this equipment.

## Section II. TROUBLESHOOTING

### 4-4. GENERAL

The most effective way to troubleshoot a fault in this equipment is to follow a routine which guides you through the five phases of troubleshooting (fig. 4-1). By following this routine you assure accurate use of fault isolation and fix procedures. You also improve your troubleshooting skills.

### 4-5. TROUBLESHOOTING PHASES

Each of the five phases in this routine is designed to accomplish a specific goal.

a. Fault Discovery. Usually, the operators or supervisor will notice faulty performance first. They must report the fault on the proper form so you will have the facts you need for the next phase.

b. Failure Confirmation. Based on the facts provided by the operator or supervisor, you must confirm the failure and define the symptom. The symptom is the first clue you will use in the troubleshooting process.

c. Troubleshooting Entry. Using the Symptom defined during phase two, find the troubleshooting flow chart which will help you isolate the fault in the equipment. The checkout and symptom index chart (chart-00) will help you do this.

d. Trouble Isolation. Follow the step-by-step procedures in the flow charts to isolate and correct the cause of the equipment failure.

e. After Maintenance. When you have made the fix recommended in the troubleshooting procedure, you must check your work. Use the chart titled After Maintenance Check. It tells you how to test your repair and make sure the equipment now works as it should.

#### 4-6. ALTERNATIVE TROUBLESHOOTING TECHNIQUES

When a failure causes a symptom which is not covered in the symptom index or not corrected by the troubleshooting procedure in the flow chart, you must try alternative techniques.

a. Understand Principles of Operation. Sometimes the symptom may have no specific procedure given to troubleshoot it. When this happens, remember that the equipment always operates the same way. By comparing the faulty operation with expected or normal operation you may find the cause of the failure and be able to fix it.

b. Check the Circuits. All electronic equipment uses circuits to route power through the components. Any break in continuity will cause some type of failure. By running continuity checks on suspect circuits you may find the cause of the failure. Use the schematic diagrams in appendix D to check the circuits in this equipment.

c. Check Past Maintenance Records. If the unusual failure occurred before, it should appear in the maintenance records for the equipment. The records should also tell you how the failure was corrected. Use the same fix this time.

d. Trial and Error Repair. Usually trial and error repairs should be avoided. They are costly and can induce additional symptoms. However, when your experience with the equipment leads you to suspect a definite cause, you should try the repair as a last resort before shipping the equipment to depot for maintenance.



#### 4-7. TROUBLESHOOTING PROCEDURES

The troubleshooting procedures are arranged as flow charts. The charts consist of background information, specific instructions and decision points. Symbols (table 4-1) are used to organize the charts and guide you through a step-by-step trouble isolation procedure for each known failure symptom.


















Figure 4-1. Troubleshooting Phases

Table 4-1. Troubleshooting Flow Chart Symbols

SYMBOL	MEANING
	<p>This is a <b>STARTING POINT</b> symbol. This is where you enter a troubleshooting flow chart.</p>
	<p>This is a <b>NOTE</b> symbol. It contains information you need to do your work, but which is not a procedural step.</p>
	<p>This is a <b>CAUTION</b> symbol. It alerts you to the possible danger of breaking equipment in the steps that follow.</p>
	<p>This is a <b>WARNING</b> symbol. It alerts you to possible danger in the steps that follow.</p>
	<p>This is an <b>INFORMATION</b> symbol. It contains information that helps you make a test or understand the troubleshooting process.</p>
	<p>This is a <b>TEST/DECISION SYMBOL</b>. It contains a test you must do and a question you must answer. If the results of a test tell you the answer is YES, you will follow the YES arrow to the next symbol. If your answer is NO, you will follow the NO arrow.</p>
	<p>These are <b>CONNECTING POINT</b> symbols. They are used in pairs. If the arrow points to the circle, it is the point where you leave a branch of the flow chart. If the arrow points away from the circle, it is the point where you go back into the flow chart. For example, you would go from  on one page to  on the next page.</p>
	<p>This is a <b>CORRECTIVE ACTION</b> symbol. It tells you what to do to correct the problem. It will also refer you to the paragraph that contains the needed repair or adjustment procedure.</p>
	<p>This is a <b>GO TO</b> symbol. It tells you to go to another flow chart. The X's in the symbol at the left stand for a chart code.</p>
	<p>Other forms for <b>GO TO</b> symbol: This symbol tells you to go to the system Technical Manual for further troubleshooting, such as running a T&amp;V program.</p>
	<p>This symbol tells you to go back to the <b>START</b> point of the same flow chart.</p>


**DD-TS-00 DISK DRIVE CHECKOUT/SYMPTOM INDEX 1 OF 5**






**DD-TS-00 DISK DRIVE CHECKOUT/SYMPION INDEX 2 OF 5**


FAULT SYMPTOMS



**DD-TS-00 DISK DRIVE CHECKOUT/SYMPATOM INDEX 3 OF 5**



**DD-TS-00 DISK DRIVE CHECKOUT/SYMPTOM INDEX 4 OF 5**



DD-TS-00	DISK DRIVE CHECKOUT SYMPTOM INDEX	5 OF 5
----------	-----------------------------------	--------

**E CHECK & VOLTAGE FAULT INDICATORS LIT**

FAULT SYSTEMS

VOLTAGE FAULT INDICATOR LIT

WHENEVER VOLTAGE FAULT INDICATOR IS LIT, START WITH DD-TS-15, THEN GO TO OTHER CHARTS. AS DIRECTED.

GO TO DD-TS-15

IS THERE A FAULT IN  $\pm 5$  VOLT LOAD CIRCUIT?

YES

GO TO DD-TS-16

FAULT IN  $\pm 5$  VOLT LOAD CIRCUITS

NO

IS THERE A FAULT IN  $\pm 12$  VOLT LOAD CIRCUIT?

YES

GO TO DD-TS-17

FAULT IN  $\pm 12$  VOLT LOAD CIRCUITS

NO

IS THERE A FAULT IN  $\pm 20$  VOLT LOAD CIRCUITS?

YES

GO TO DD-TS-18

FAULT IN  $\pm 20$  VOLT LOAD CIRCUITS

NO

IS THERE A FAULT IN  $\pm 42$  VOLT LOAD CIRCUITS?

YES

GO TO DD-TS-19


FAULT IN  $\pm 42$  VOLT LOAD CIRCUITS

NO


GO TO DD-TS-20

VOLTAGE FAULT IN LOGIC CIRCUITS


**DD-TS-01 BLOWER WILL NOT SPIN**




DD-TS-02 POWER SUPPLY CIRCUIT BREAKER TRIPS 1 OF 2



DD-TS-02 POWER SUPPLY CIRCUIT BREAKER TRIPS 2 OF 2




**DD-TS-03 AC POWER OR DRIVE MOTOR (THERMAL) BREAKER TRIPS**








DD-TS-04 SPINDLE WILL NOT SPIN 1 OF 3




DD-TS-04 SPINDLE WILL NOT SPIN 2 OF 3




**DD-TS-04 SPINDLE WILL NOT SPIN 3 OF 3**




**DD-TS-05 READY WON'T LIGHT (CYCLE UP SEEK ERROR)**






DD-TS-06 CARRIAGE WON'T MOVE FORWARD 1 OF 3




DD-TS-06 CARRIAGE WON'T MOVE FORWARD 2 OF 3



**DD-TS-06 CARRIAGE WON'T MOVE FORWARD 3 OF 3**




**DD-TS-07 SEEK ERROR DUE TO NO + HEADS LOAD VOLTAGE**







**DD-TS-08 HEADS MOVE FORWARD AND STOP 1 OF 2**




DD-TS-08 HEADS MOVE FORWARD AND STOP 2 OF 2




**DD-TS-09 HEADS LOAD, HESITATE, THEN CREEP TO FORWARD EOT**



DD-TS-10 SEEK ERROR AFTER CYCLE UP 1 of 2




**DD-TS-10    SEEK ERROR AFTER CYCLE UP    2 of 2**



**DD-TS-11 UNSCHEDULED HEAD RETRACTION**


**CAUTION**  
 A TYPICAL CAUSE OF SUDDEN, UNSCHEDULED HEAD RETRACTION IS LOSS OF  $\pm 5$  VOLTS. IMMEDIATELY PULL DRIVE OUT OF CABINET AND SET DC POWER BREAKER TO OFF TO PREVENT POSSIBLE CARRIAGE COIL BURNOUT.




**DD-TS-12 READ ERROR PROBLEMS 1 of 4**

**NOTE**  
FOR WRITE ERROR  
PROBLEMS USE  
DD-TS-14.

CODE APPEARS  
ON CONTROL PANEL  
REGISTER.




DD-TS-12 READ ERROR PROBLEMS 2 OF 4







DD-TS-12 READ ERROR PROBLEMS 3 OF 4




DD-TS-12 READ ERROR PROBLEMS 4 OF 4




DD-TS-13 WRITE ERROR PROBLEMS 1 OF 5




DD-TS-13 WRITE ERROR PROBLEMS 2 of 5




DD-TS-13 WRITE ERROR PROBLEMS 3 OF 5




**DD-TS-13 WRITE ERROR PROBLEMS 4 OF 5**



**DD-TS-13 WRITE ERROR PROBLEMS 5 OF 5**




**DD-TS-14 OVERHEATING OR BLOWER STARVATION**






**DD-TS-15 VOLTAGE FAULT INDICATOR LIT 1 OF 5**


- START**
1. SET POWER SUPPLY BREAKER TO OFF.
  2. REMOVE SCREW & PLASTIC COVER.
  3. RAISE LOGIC CHASSIS TO MAINTENANCE POSITION (PARA 4-25).
  4. MAKE SURE P2/J2 ON LOGIC CHASSIS IS CONNECTED.
  5. SET POWER SUPPLY BREAKER TO ON.
  6. USING VOLTMETER, MEASURE VOLTAGES (SEE 5V & 20V FASTONS ON LOGIC CHASSIS BACK PANEL IN DD-TS-04).




NORMAL LOAD VOLTAGES			
VOLTAGE TO BE CHECKED	VOLT-OHMMETER CONNECTIONS		VOLTAGE READINGS ± (TOLERANCE)
	+ PROBE	- PROBE	
+5	+5 FASTON	EITHER END	+5.1 (±0.05)
-5	-5 FASTON	FASTON ON	-5.1 (±0.05)
+12	U9-PIN 2	LOGIC CHASSIS	+12 (±2)
-12	U8-PIN 2	OR GND (FOIL)	-12 (±2)
+20	+20 FASTON	OF -XKV	+20 (±2)
-20	-20 FASTON	CARD	-20 (±2)
+42	FUSE F3	(FIG. T5-1)	+42 (±2)
-42	FUSE F4		-42 (±2)



**DD-TS-15 VOLTAGE FAULT INDICATOR LIT 2 OF 5**



DD-TS-15 VOLTAGE FAULT INDICATOR LIT 3 OF 5



G

FAULT CAN APPEAR TO BE IN TUNING TRANSFORMER, BUT MIGHT BE IN BOARD OF POWER SUPPLY. VERIFY WITH SCOPE.



1. RECONNECT P1/J1. (SEE SHEET 1).
2. SET UP SCOPE
3. SET POWER SUPPLY BREAKER TO ON.
4. CONNECT PROBE OF SCOPE TO ONE LEAD OF C1
5. SET TIME/DIV CONTROL FOR SQUARE WAVE
6. MEASURE & WRITE DOWN VOLTAGE E FROM SCOPE GROUND REFERENCE LINE TO TOP & BOTTOM PLATEAUS OF SQUARE WAVE. (2 READINGS).
7. MOVE PROBE TO OTHER CAPACITOR LEAD. REPEAT STEP 6.
8. REPEAT STEPS 6 & 7 FOR C7.
9. REPEAT STEPS 6 & 7 FOR C11.
10. REPEAT STEPS 6 & 7 FOR C16.

**OSCILLOSCOPE SETTINGS**  
 CM 1 VOLTS/DIV: ±5V E=11V  
 ±20V E= 2V  
 ±42V E=44V  
 SET TIME/DIV FOR BEST TRACE  
 CM 1 TRIGGERING: (X1 PROBE) — LINE

**SCOPE CONNECTIONS & READINGS**

SUPPLY TO BE CHECKED FOR AC INPUT	SCOPE CONNECTIONS		AC INPUT VOLTAGES (CHECK EACH SIDE OF INPUT CAPACITOR)
	- PROBE (AC INPUT)	- PROBE (GROUND)	
+5V	C1	GROUND-PLANE FOIL OF XKV BOARD	11 V ± 1 V
-5V	C7		11 V ± 2 V
±20V	C11		22 V ± 1 V
±42V	C16		44 V ± 2 V

ARE WAVEFORMS IN STEPS 6 THRU 10 SYMMETRICAL ABOUT GROUND REFERENCE LINE; AND ARE VOLTAGES WITHIN TOLERANCE? (IF IN DOUBT, PROCEED TO D.)



SQUARE WAVE DIAGRAM






Figure 4-1.1. Power Supply Connection Diagram



## DD-TS-15 VOLTAGE FAULT INDICATOR LIT 5 OF 5




**DD-TS-16 FAULT IN ±5 VOLT LOAD CIRCUITS 1 OF 2**







DD-TS-16	FAULT IN $\pm 5$ VOLT LOAD CIRCUITS	2 OF 2
----------	-------------------------------------	--------




**DD-TS-17 FAULT IN ±12 VOLT LOAD CIRCUITS**




**DD-TS-18 FAULT IN ± 20 VOLT LOAD CIRCUITS**




**DD-TS-19 FAULT IN ±42 VOLT LOAD CIRCUITS 1 OF 2**




**DD-TS-19    FAULT IN ± 42 VOLT LOAD CIRCUITS    2 OF 2**




**DD-TS-20 VOLTAGE FAULT IN LOGIC CIRCUITS 1 OF 2**




DD-TS-20 VOLTAGE FAULT IN LOGIC CIRCUITS 2 OF 2



**DD-TS-21 WRITE FAULT INDICATOR LIT**




**DD-TS-22 HEAD SELECT FAULT INDICATOR LIT**








**DD-TS-23 WRITE OR READ FAULT INDICATOR LIT**




**DD-TS-24 NOT ON CYLINDER AND (WRITE OR READ) INDICATOR LIT**



**DD-TS-25 MISSING AC VOLTAGES**



**DD-TS-26 AFTER MAINTENANCE CHECK**



## Section III. MAINTENANCE PROCEDURES

### 4-8. GENERAL

The individual maintenance procedures in this section contain the corrective actions required to fix a failure which was isolated during troubleshooting.

#### 4-9. EQUIPMENT HANDLING PRECAUTIONS

As with most data processing equipment, the disk drive is very sensitive to dirt, dust, and even smoke. Follow the rules below to avoid damage to the equipment.

- a. Make sure hands, clothing, and shoes are clean before working with the disk drive.

#### CAUTION

Never touch the recording surface of a magnetic disk pack. Since the head-to-disk flying distance is so small, surface dust, tool nicks, fingerprints, or moisture could cause a head crash. Do not try to clean a magnetic disk pack in any way.

- b. Store magnetic disk packs in a closed canister or in a disk drive with the access cover closed. Keep containers closed except when transferring a magnetic disk pack to or from a disk drive.
- c. Do not smoke in rooms where magnetic disk packs are handled or stored. Smoke particles are larger than the head-to-disk flying distance (figure 4-2) and may cause a head crash.
- d. Do not allow food or beverages on disk drive or near magnetic disk packs. Greasy food residues and finger marks collect dirt, crumbs cause contamination, and fluid spills cause contamination and corrosion.
- e. Keep magnetic disk packs away from electric motors, electric solenoids, magnets, and other magnetic fields. Magnetic fields from these devices will erase or distort data recorded on a magnetic disk pack.

#### NOTE

Motors on disk drives are shielded to prevent magnetic field distortion.

- f. Do not drop or bump a magnetic disk pack. Avoid bumping a magnetic disk pack on the spindle of a drive. Avoid bumping magnetic disk packs together. Bump shock can distort recorded magnetic data fields.
- g. Do not expose magnetic disk packs to direct sunlight. Oxide separation will result.

CAUTION

In order to avoid a head crash, observe minimum warmup conditions.

- h. Magnetic disk packs must be thoroughly dry before you cycle them up on the disk drive. This is most important when the humidifier has been in operation or when the disk packs are cold.




Figure 4-2. Head Flying Distance vs. Contamination Size

- i. Do not touch board connector terminals with any tool, bare hands, or a dirty cloth. Tools will physically damage the fragile connector. Dirt or body moisture (which contains salt and other chemicals) will cause destructive corrosion. These problems will result in data processing faults.
- j. Hold boards by their edges when they are out of the disk drive and are not in a storage container.
- k. If a board is to be transported, place it in a sturdy box to protect it. Pack it carefully with clean packing material that will prevent physical damage and will not cause corrosion on connector terminals.
- l. Ground your body to discharge static electricity by touching the metal chassis or cabinet before touching a board. A static discharge from you to a board can destroy integrated circuits on the board.
- m. Keep spare boards in antistatic bags in which new boards are shipped from the factory.

- n. Keep hands away from actuator during seek operations and when reconnecting leads to the carriage coil. Under certain conditions, emergency retract voltage may be present, causing sudden reverse motion and head unloading.
- o. Use caution while working near heads. If the heads are touched, fingerprints can damage them. Clean heads immediately if they are touched.
- p. Keep pack access cover closed unless it must be open for maintenance. This prevents entrance of dust into pack area. Do not open pack access cover while disk is spinning or attempt to slow disks by hand.
- q. Keep all watches, magnetic disk packs, meters, and other test equipment at least two feet away from the carriage coil magnet.
- r. Do not remove or install boards while power is on. Boards are easily damaged by transient voltage spikes which may be generated by removing or installing boards when power is on.
- s. Make sure the logic cage is in the normal operating position before raising the deck. Since the logic cage cannot be secured in the maintenance position, it may fall and be damaged as deck is raised.
- t. Do not open the acoustic top case when a drawer-mounted drive has the logic cage in the maintenance position. The top case and drawer unit's logic cage will collide and damage will occur.
- u. Do not use the CE alignment magnetic disk pack unless specifically directed to do so. These packs contain prerecorded alignment data that can be destroyed if the test procedure requires the disk drive to write. This alignment data cannot be generated in the field.
- v. If the disk drive fails to cycle down when the START switch is pressed (to turn off indicator), disconnect the carriage coil leadwire (para. 4-48) and manually retract heads before troubleshooting a malfunction.
- w. Make certain that the heads are retracted before turning off power.
- x. If power to the drive motor is lost while the heads are loaded and not under servo control (during manual carriage positioning), immediately retract the carriage. Otherwise, the heads will crash when the disk speed is too slow to let the heads fly.
- y. Keep all metal tools away from flex leads while power is applied in order to prevent damage to the power amplifier.

#### 4-10. MAINTENANCE PROCEDURES


Before you start a corrective maintenance procedure, you should gather all the items or help listed in the initial setup box for that procedure. Read the procedure carefully and do only what each step tells you to do. Some steps are followed by a reference. Use the reference any time you are not sure what you must do for that step. Always do the steps in the order they are given unless the procedure requires decision steps. When decision steps are involved, go in the order indicated by the decision.

## 4-11. REMOVE/REPLACE COVER FOR MAINTENANCE


## INITIAL SETUP

Common Tools

- Tool kit


Remove

1. If ready indicator is lit, press START switch to stop drive motor. Wait one minute for disk pack to stop spinning.




2. Slide drawer out.
3. Remove disk pack.

4-11. REMOVE/REPLACE COVER FOR MAINTENANCE (CONT)



4. At rear of drive, set power to OFF.



5. Find two release latches. There is one on each side of cover.

NOTE

Some disk drives have manual release latches. On other disk drives there is a hex socket latch on one side.




6. Release latches.


- If both latches are like the one shown, press both as you lift cover
- If one latch is the hex socket type, press catch and turn socket with 7/32-inch hex key as you lift cover



4-11. REMOVE/REPLACE COVER FOR MAINTENANCE (CONT)




7. Lift cover.



8. Pull ground strap connector from post on cover.

9. Release hinges.




10. Holding cover firmly against you, press in pins as shown.


11. Remove cover. Set it aside.

4-11. REMOVE/REPLACE COVER FOR MAINTENANCE (CONT)


Replace



1. Get cabinet cover. Holding cover against you, line up pins with locking holes.




2. To connect cover to drive, press in pins one at a time as shown.




3. Connect hinges.
4. Push ground strap/spade connector on post.

4-11. REMOVE/REPLACE COVER FOR MAINTENANCE (CONT)



5. Lower cover. To make sure release catches lock, press down on cover.



6. From rear of drive, set power to ON.


4-12. RAISE/LOWER DECK FOR MAINTENANCE

INITIAL SETUP

Common Tools

- Tool kit


Raise



1. Remove cover (para 4-11).
2. Press release latch and lift pack access cover.


NOTE

Some drives have a pack cover solenoid which locks latch when power is off to drive. If latch will not release, power on disk drive, lift access cover than power off drive.




3. Remove deck hold-down screws.
4. Close pack access cover.


4-12. RAISE/LOWER DECK FOR MAINTENANCE (CONT)



5. On back of drive, locate bolt. Using 3/16-in. hex key, remove bolt and spacer from keeper hole.



6. Slide spacer under deck as shown. Line up spacer with hole.




7. Push bolt through spacer. Tighten bolt.

4-12. RAI SE/LOWER DECK FOR MAINTENANCE (CONT)


CAUTION

Do not lift drive at pack access cover.

8. From front of drive, lift deck until support arm is fully extended. Lower deck onto arm.




9. Loosen knob and pull it out of storage hole.




10. Insert knob in locking le. Tighten knob.


## 4-12. RAISE/LOWER DECK FOR MAINTENANCE (CONT)

Lower

1. Loosen knob. Pull it out of locking hole.




2. Insert knob in storage hole. Tighten knob.




3. With one hand, firmly grasp deck and lift.
4. With other hand, grasp arm and push forward towards front of drive. Lower deck.

4-12. RAISE/LOWER DECK FOR MAINTENANCE (CONT)



5. From rear of drive, locate bolt and spacer. Using 3/16-in. hex key wrench, remove bolt. Pull off spacer.



6. Push bolt through spacer. Tighten bolt in keeper hole.
7. Replace deck hold-down screws.
8. Close pack access cover.
9. Replace cover (para 4-11).



## 4-13. REMOVE/REPLACE BLOWER MOTOR

## INITIAL SETUP

## Common Tools



- Tool kit
- Torque screwdriver

## Materials/Spare Parts

- Paper
- Pen or pencil


Remove

1. Remove disk drive. (See your system manual.)
2. Raise deck (para 4-12).
3. Remove screws.
4. Pull out air plenum.



5. Pull apart P301.
6. On a piece of scratch paper, note position of three capacitor wires. Pull apart connector. Disconnect wires from capacitor.

## 4-13. REMOVE/REPLACE BLOWER MOTOR (CONT)



7. From underneath assembly, remove six screws and washers.

8. Pull out blower motor.

REPLACE

1. Replace blower motor. Center it over mounting holes.

2. From underneath assembly, insert 1/8 in. hex key up through one mounting hole. This hole should be aligned. If key wrench won't go into hole, move blower slightly.

3. When blower is aligned, remove hex key.

4. Replace blower screws and washers. Tighten screws to a torque of 9 inch-pounds.

5. Connect P301.

6. Using your notes, connect capacitor wires.

7. Place air plenum snugly against blower.

8. Replace air plenum screws.


9. Lower deck (para 4-12).

10. Replace disk drive. (See your system manual. )

11. Power on disk drive.

12. Lift pack access cover.

## 4-13. REMOVE/REPLACE BLOWER MOTOR (CONT)



13. Place hand in front of opening to make sure blower is operating.
14. Power off disk drive.
15. Close pack access cover.
16. Slide drawer in.

4-14. REMOVE/REPLACE TERMINAL BOARD

INITIAL SETUP


Common Tools

- Tool kit


Materials/Spare Parts

- Tags
- Pen or pencil

Remove




1. Raise deck (para 4-12).
2. Find terminal board.




3. Remove plastic shields from terminal board.


## 4-14. REMOVE/REPLACE TERMINAL BOARD (CONT)



4. Tag and remove all wires.
5. Remove two screws holding terminal board to bottom of drive.
6. Remove terminal board.

Replace

1. Mount terminal board in place.
2. Replace two screws holding terminal board to base assembly.



3. Replace all wires.
4. Replace plastic shields.
5. Lower deck (para 4-12).

4-15. REMOVE/REPLACE AC TRANSFORMER

INITIAL SETUP

Common Tools

- Tool kit

Materials/Spare Parts



- Paper
- Pen or pencil
- Tie wraps

Personnel Required

- Two


Remove

1. Remove disk drive. (See your system manual.)
2. Raise deck (para 4-12).
- 3\* Disconnect connectors P1 and P2.
4. Pull snap ring from support arm hinge pin.
5. While partner supports weight of deck, pull hinge pin from support arm.




6. Have your partner lift deck to vertical position while you work on transformer.
7. Cut wire ties holding wires to P1 and to P2.


## 4-15. REMOVE/REPLACE AC TRANSFORMER (CONT)



8. Trace three wires from transformer to terminal block.
9. Note position of three wires on terminal board.
10. Remove plastic covers from terminal board.




11. Loosen the terminal screws, pull the three wires from the terminals.
12. Remove wire ties from bundle on bottom of drive as needed to separate two wires that run from the transformer to transformer tuning capacitor.
13. Tag and disconnect transformer wires from capacitor.




14. Remove rubber terminal cover. Save it for reuse.
15. Remove four mounting screws from transformer base.
16. Lift transformer from drive.

4-15. REMOVE/REPLACE AC TRANSFORMER (CONT)




Replace

1. Place transformer in drive.
2. Aline mounting holes in transformer base with holes in bottom of drive.
3. Install four mounting screws.




4. Route two transformer wires with slide connectors to the tuning capacitor.
5. Push wires through holes in the rubber capacitor terminal cover.
6. Push slide connectors onto capacitor terminals.
7. Position rubber terminal cover over terminals.




8. Route three colored transformer wires with stripped ends to terminal block.
9. Using notes made during removal, match each wire with its terminal number.
10. Insert each wire into its terminal and, while holding the wire in place, tighten the terminal screw.
11. Install plastic cover over each of the terminals.



## 4-15. REMOVE/REPLACE AC TRANSFORMER (CONT)



12. Put tie wraps on three wire bundles.



13. While your partner lowers the deck and supports its weight, align the support arm hinge with the hinge on the drive.

14. Insert the hinge pin.

15. Install the snap ring. Be sure it snaps into the hinge pin groove.

16. Plug connectors P1 and P2 into jacks J1 and J2.

17. Lower deck (para 4-12).

18. Replace disk drive. (See system manual.)

4-16. REMOVE/REPLACE RUN TRIAC

INITIAL SETUP

Common Tools


- Tool kit

Materials/Spare Parts


- Dielectric grease
- Lags
- Pen or pencil

Remove

1. Remove disk drive. (See your system manual.)
2. Raise deck (para 4-12).
3. Locate run triac.




4. Tag wires as shown.
5. Pull off wires.




6. From underneath disk drive, remove two screws holding triac to bottom of drive.

4-16. REMOVE/REPLACE RUN TRIAC (CONT)




7. Pull out triac.

Replace



1. With swab, apply light coat of dielectric grease to triac base.
2. Mount triac in place.
3. From underneath disk drive, replace two screws securing triac to bottom of drive.



4. Push on wires.
5. Remove tags.
6. Lower deck (para 4-12).
7. Replace disk drive. (See your system manual.)

4

4-17. REMOVE/REPLACE DECK INTERLOCK SWITCH

INITIAL SETUP

Common Tools

- Tool kit

Materials/Spare Parts


- Tags
- Pen or pencil
- Tie wraps

Personnel Required


- Two

Remove

1. Remove disk drive. (See your system .
2. Raise deck (para 4-12).
3. Pull snap ring from support arm hinge pin.
4. While partner supports weight of deck, pull hinge pin from support arm.



3 4




6 7 8


5. Have your partner lift deck to vertical position and hold it in that position while you work on interlock switch.
6. Find interlock switch.
7. Tag and disconnect the wires from switch.
8. Remove two switch mounting screws from the hinge plate.
9. Lift switch from drive.

4-17. REMOVE/REPLACE DECK INTERLOCK SWITCH (CONT)

**Replace**



1. Place switch on the back side of hinge plate so that plunger is to the left and side terminal is to the right.
2. Align mounting holes and install screws.
3. Attach both wires.



4. While your partner lowers deck and supports its weight, align support arm hinge with hinge on drive.
5. Insert hinge pin.
6. Install snap ring. (Be sure it snaps into the hinge pin groove.)
7. Lower deck (para 4-12).
8. Replace disk drive. (See your system manual.)

4-18. REMOVE/REPLACE POWER SUPPLY ASSEMBLY

INITIAL SETUP



- Common Tools  
● Tool kit

**WARNING**

Electrocution may result if this procedure is done with power ON.


**Remove**

1. Remove cover (para 4-11).
2. At side of drive, find power supply.




3. Remove screw and washer.
4. Pull off cover.
5. Pry off J1 and J2.


4-18. REMOVE/REPLACE POWER SUPPLY ASSEMBLY (CONT)



6. Remove five screws securing power supply to base. There are two on each side and one in back.




7. Grasp power supply at corners of board and lift half way up.




8. Remove bolts and nuts.
9. Pull off panel.

4-18. REMOVE/REPLACE POWER SUPPLY ASSEMBLY (CONT)




10. Pull out emergency retract relay.



11. Pull off P-3 and free emergency retract relay from power supply assembly.

12. Remove power supply board.



Repl ace


1. Set power supply assembly in posi ti on.

2. Push on P-3.


3. Push emergency retract relay into power supply assembly.




## 4-18. REMOVE/REPLACE POWER SUPPLY ASSEMBLY (CONT)



4. Replace panel .
5. Replace bolts and nuts.




6. Lower power supply assembly in place. Line up holes in base with holes in power supply assembly.



7. Using long screwdriver and wand magnet, replace five screws securing power supply to base.

4-18. REMOVE/REPLACE POWER SUPPLY ASSEMBLY (CONT)



8. Push on J1 and J2.

NOTE

If you are installing a new power supply you must adjust plus/minus 5 volts (para 4-19) before you do steps 9-11 below.

9. Push on cover.
10. Replace screw and washer.
11. Close cover (para 4-11).

4-19. ADJUST PLUS/MINUS 5 VOLTS

INITIAL SETUP

Common Tools

- Tool kit

Test, Measurement and Diagnostic Equipment

- Multimeter
- Field test unit (FTU)

Supplies

- Scratch pack

CAUTION



Loss of cooling air causes drive to overheat. When logic cage is in maintenance position, do not operate drive for more than 20 minutes at a time.

NOTE


Your field test unit (FTU) may be model TB216 or TB303. This procedure covers each model under its respective heading.

MODEL TB303


1. Remove cover (para 4-11).
2. Install FTU (para 4-53).
3. Set these toggle switches in center position.
  - ACC/RD/WR
  - POS/NEG
  - EARLY/LATE STROBE
  - REV/FWD/OFF-SET
  - RTZ
4. Set these toggle switches in up position.
  - R/W SERVO
  - I/O ENABLE-DISABLE
  - SEQ PWR ON/OFF
- 5\* Set all remaining switches in down position.
6. Install scratch pack.
7. Raise logic cage (para 4-25).
8. Set up multimeter to measure dc voltage.




4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)



9. At bottom of cage, connect black lead to ground faston as shown.
10. Connect red lead to + 5 V faston.
11. From rear of drive, set ac circuit breaker ON.
12. Power ON drive.
13. Make sure PROTECT light is on.
14. Cycle up drive.




15. On FTU push down then release RTZ.
16. Turn AUTO FUNC selector to SGL.
17. If at disk drive 0400 or 0600 start at step 19. If at drive 0680 start at step 18.




18. Set BUS OUT switch 1 up.

4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)




19. Set SELECT HOLD up.
20. Set START/STOP up and then down.
21. Push down then release RTZ. Only MOD ADDR should be lit.




22. Turn AUTO FUNC selector to CONT.
23. Set BUS OUT switch 1 down.
24. Set BUS OUT switch 32 up. All remaining BUS OUT switches should be down.
25. Set START/STOP down then up.
26. Set multimeter to ON.
27. Look at multimeter. +5 V output should be +5.10 +/- 0.05 volts.

- If it is, go to step 31
- If not, go to step 28




28. From side of drive, locate power supply. Remove screw.
29. Pull off cover.


4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)



30. On power supply unit, locate +5 V potentiometer. Using potentiometer adjustment tool, turn potentiometer until output is  $+5.10 \pm 0.05$  volts.




31. Disconnect red lead from plus +5 V faston.



32. Connect red lead to -5 V faston.
33. Look at multimeter. -5 v output should be  $-5.10 \pm 0.05$  volts.
  - o If it is, go to step 37
  - o If not, go to step 34


## 4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)



34. On power supply unit, locate -5 V potentiometer. Using potentiometer adjustment tool, turn potentiometer until output is  $-5.10 \pm 0.05$  volts.

35. Put on cover.

36. Replace screw.



37. Set FTU to stop continuous seeks.

38. Cycle down drive.

39. Power OFF drive.

40. Disconnect red and black leads.

41. Lower logic cage (para 4-25).



42. Remove FTU. Replace communication cables on disk drive.

43. Remove magnetic disk pack.

44. Replace cover (para 4-11).

4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)

MODEL TB216



1. Remove cover (para 4-11).
2. Install and test FTU (para 4-53).
3. Power on FTU circuit breaker.

4) In sequence, set FTU switches listed to positions shown:


<u>SWITCH</u>	<u>POSITION</u>
PROCESSOR START/RESET	RESET
PROCESSOR RUN/HALT	HALT
SINGLE/CONT	CONT
-/+ OFFSET	CENTER (OFF)
LATE/EARLY	CENTER (NORMAL)
WRT FLAG	OFF
WRT PROT	ON
AM/SECTOR	EITHER
EOT STOP	OFF
ERROR OVERRIDES:	
DATA-OFF	OFF
ADDR-OFF	OFF
SHIFT PATT/DATA PATT	DATA PATT
RD/WRT SELECT	ACCESS ONLY
ACCESS SELECT	DIRECT SEEK
PROCESSOR START/RESET	START
PROCESSOR RUN/HALT	RUN
SEQ PWR/OFF	SEQ PWR

5. Look to see that the following FTU indicators light:


ON CYCL	SEEK ERRO
RDY	FLT
WT PROT	BUSY
SELD	RUN
+5	-5




4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)



6. Power ON disk drive.
7. Load scratch disk pack.
8. Cycle up disk drive.
9. Turn DATA ENTRY switch to DEVICE TYPE.
10. Enter device code 3105 at keyboard.
  - Corresponding ROW 2 indicators will light.
  - If you key incorrectly, press CLR ENT, then enter code again.



11. Press LOAD key.
  - Code will transfer to ROW 1 indicators.
  - If code does not transfer press CLR ENT, then repeat step 10.
12. Be sure that ROW 3 indicators 1/0 RDY are lit.
13. Press SEL DRV key.



14. Look to see that SELD indicator lights and that logical address for selected disk drive appears in row 1.
  - If SELD is flashing or incorrect logical address lights, selection was unsuccessful.
  - Press CLR and repeat from step 10.



4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)

15. Raise logic cage (para 4-25).
16. Set up multimeter to read dc voltage.
17. At bottom of logic cage, connect black lead to ground terminal.


CAUTION

Do not touch multimeter lead across + 5V and + 20V or damage to board will result. Connect lead carefully.


18. Connect red lead to +5V terminal.
19. Turn RD/WRT SELECT switch to ACCESS ONLY.
20. Turn ACCESS SELECT switch to DIRECT SEEK.
21. Turn DATA ENTRY switch to DESTINATION.



4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)




25. Press STOP key.
26. Turn ACCESS SELECT switch to DIRECT CONT.



27. Key in 32.
28. Press LOAD key.
29. Press GO key.

30. Set multimeter to ON.
31. Look at multimeter. +5 volt output must be  $-5.10 \pm 0.05V$ .
  - If it is, go to step 37.
  - If it is not, go to step 32.


4-190 ADJUST PLUS/MINUS 5 VOLTS (CONT)



32. On power supply, locate +5V adjustment. Use potentiometer adjustment tool to bring output to  $+5.10 \pm 0.05V$  on the multimeter.

CAUTION


Do not touch multimeter lead across -5V and -25V or damage to board will result. Connect lead carefully.




33. On bottom of logic cage, move red multimeter lead to -5V terminal.

34. Look at multimeter. -5 volts output must be  $-5.10 \pm 0.05 V$ .
- If it is, go to step 36.
  - If it is, not go to step 35.

## 4-19. ADJUST PLUS/MINUS 5 VOLTS (CONT)



35. On power supply, locate -5 v adjustment. Use potentiometer adjustment tool to bring output to  $-5.10 \pm 0.05$  V on the multimeter.



36. On FTU, press STOP key.
37. Press CLR key.
38. Press RTZ key.
39. Set multimeter to OFF.
40. Remove meter leads.
41. Lower logic cage (para 4-25).
42. Cycle down disk drive. Set processor switches START RUN to RESET HALT.
43. Power OFF drive.
44. Power OFF FTU circuit breaker.
45. Remove FTU cables.
46. Reconnect disk drive cables at rear of logic cage.
47. Remove disk pack.
48. Replace drive cover (para. 4-11).

4-20. REMOVE/REPLACE SERVO STARTING CAPACITORS

INITIAL SETUP

Common Tools

- Tool kit

Materials/Spare Parts

- Tags (for wires)
- Pen or pencil


Remove

1. Raise deck (para 4-12)

NOTE

There are three servo starting capacitors. If you are removing top capacitor, do steps 2-5. If you are removing bottom capacitor, do steps 2-91


2. Find capacitor you will remove.




WARNING

Capacitors may hold high voltage charge. Test with voltmeter before handling.

3. Loosen clamp.
4. Slide out top capacitor. Remove and retain metal shield.
5. Tag and remove wires from top capacitor. Lift out top capacitor.



## 4-20. REMOVE/REPLACE SERVO STARTING CAPACITORS (CONT)



6. Remove two screws and washers holding bracket to base assembly.
7. Note positions of wires and buss bar on bottom capacitors.
8. Raise capacitors. Remove wires and buss bar from bottom capacitor.

## NOTE


If you are removing both bottom capacitors, retain buss bar.

Replace

## NOTE

If you are replacing a bottom capacitor, do steps 1-7. If you are replacing the top capacitor, do steps 4-7.

1. Using your notes attach wires and buss bar to capacitor.
2. Set capacitor in place on brackets and align holes in bracket with holes in base assembly.
3. Replace screws and washers which hold capacitor bracket on base assembly. Tighten screws.
4. Attach wires to top capacitor. Set shield in place on capacitor.
5. Slide capacitor into position under clamp.
6. Tighten clamp.
7. Lower deck (para 4-12).



4-21. REMOVE/REPLACE BLOWER OR TRANSFORMER TUNING CAPACITOR

INITIAL SETUP

Common Tools

- Tool kit

Materials/Spare Parts

- Tags (for wires)
- Pen or pencil

NOTE

This procedure may be used for either capacitor.


Remove

1. Raise deck (para 4-12).


WARNING

Capacitors may hold high voltage charge. Test with voltmeter before handling.

2. Find defective capacitor.
3. Tag and remove wires from capacitor.




4. Remove two screws from holding clamp.
5. Remove holding clamp.
6. Lift capacitor from disk drive.





## 4-21. REMOVE/REPLACE BLOWER OR TRANSFORMER TUNING CAPACITOR (CONT)

**Replace**

1. Place capacitor on disk drive.
2. Place clamp over capacitor.
3. Replace two screws holding clamp.
4. Replace wires on capacitors.
5. Lower deck (para 4-12).

4-22. REMOVE/REPLACE ELAPSED TIME METER

---

INITIAL SETUP

Common Tools



- Tool kit

Materials/Spare Parts

- Tags (for wires)
  - Pen or pencil
- 


Remove

1. Remove disk drive. (See your system manual.)
2. Set disk drive on work table with access to rear.




3. Remove six screws. Carefully pull plate out of mounting.


4-22. REMOVE/REPLACE ELAPSED TIME METER (CONT)



4. Turn plate around.
5. Tag and remove wires from meter to breakers.




6. Remove three screws holding meter to plate.
7. Lift meter from plate.



Replace

1. Set meter into position on plate.
2. Replace screws holding meter to plate.

4-22. REMOVE/REPLACE ELAPSED TIME METER (CONT)




3. Connect wires to plate.
4. Set plate into position on disk drive.
5. Replace screws holding plate to disk drive.
6. Replace disk drive. (See your system manual. )

## 4-23. REMOVE/REPLACE AC OR DC CIRCUIT BREAKER

## INITIAL SETUP

Common Tools


- Tool kit



- Remove
1. Remove disk drive. (See your system manual).
  2. Remove six screws. Carefully pull plate out of mounting.


## NOTE

Illustration shows removal of ac circuit breaker. Use same procedure for dc circuit breaker.




3. Pull off insulation caps. You may need to pry them off with needle nose pliers.

4-23. REMOVE/REPLACE AC OR DC CIRCUIT BREAKER (CONT)



4. Remove screws holding circuit breaker to plate.




5. Lift out old circuit breaker.

Replace


NOTE

Illustration shows replacement of ac circuit breaker. Use same procedure for dc circuit breaker.



1. Insert new circuit breaker.
2. Using 5/16-in. wrench, loosen nuts on old circuit breaker.

4-23. REMOVE/REPLACE AC OR DC CIRCUIT BREAKER (CONT)



6. Carefully push circuit breaker into mounting. Replace screws.
7. Replace disk drive. (See your system manual.)

## 4-24. REMOVE/REPLACE LINE FILTER

## INITIAL SETUP

## Common Tools



- Tool kit

## Materials/Spare Parts

- Tie wraps
- Tags
- Paper
- Pen or pencil

Remove


1. Remove disk drive. (See your system manual).
2. Remove cover (para 4-11).
3. Find plug P200 and disconnect it from power amplifier board.
4. Cut two tie wraps holding P200 to power amplifier.




5. Disconnect P1 and P2 from side of power supply.




4-24. REMOVE/REPLACE LINE FILTER (CONT)



6. From bottom of drive, remove four screws holding power supply mounting bracket to bottom.
7. Cut tie wrap. Remove screw holding wiring harness to power supply bracket.
8. Moving wiring harnesses as needed, lift power supply from the drive base.
9. Lay power supply aside carefully without disconnecting more wires.




10. On back face of drive base. Look at line filter power connection.
  - If it is a jack for a plug, use steps 11 thru 15
  - If there is no jack and the power cord is present, use steps 16 thru 21



11. Note position of line filter wires on terminal board.
12. Remove plastic shields from terminals.
13. Loosen terminal screws and pull line filter wires out of terminals. (Do not disturb wires on other side of terminal board.)
14. Remove two screws holding line filter to back of drive.
15. Lift line filter from drive base.

4-24. REMOVE/REPLACE LINE FILTER (CONT)




16. Remove screws holding both covers to line filter. Remove both covers.
17. On note paper, identify each wire and terminal to which it connects. Record connections for both ends.
18. Disconnect wires from terminals in both ends.
19. At both ends, loosen and remove nut holding connector to line filter.
20. Pull filter away from connectors.
21. Pass wires through connector holes in filter.

**Replace**

NOTE


If line filter has jack for a removable power cord, use steps 1 thru 6.

If line filter does not have jack, use steps 7 thru 12.



1. Place line filter in drive base.
2. Align filter mounting holes with holes in rear of drive base. Install mounting screws.
3. Using notes made during removal, match each filter wire with its terminal number.
4. Insert each wire into its terminal and, while holding wire in place, tighten terminal screw.
5. Install plastic covers over terminals.
6. Go to steps 13-22.

4-24. REMOVE/REPLACE LINE FILTER (CONT)



7. Look at line filter to see which end is line side and which is load side.
8. Insert power cord wires into connector hole on line side.
9. Insert wires from drive terminal load into connector hole on load side.
10. On each end, pass connector nut over wires, seat connector, then tighten nut.
11. Using notes made during removal, connect wires to terminals.
12. Position covers and insert screws.
13. Moving wiring harnesses as needed, place power supply in position on drive base.
14. Replace tie wrap.
15. Align power supply mounting holes with holes in drive base.
16. From below, install power supply mounting screws.
17. Reconnect plug P200.
18. Secure wiring harness P200 to two harness clamps with new tie wraps.
19. Reconnect plugs P1 and P2 to jacks J1 and J2.
20. If removed, replace ac power cord.
21. Replace cover (para 4-11).
22. Replace disk drive (See system manual.)

## 4-25. RAISE/LOWER LOGIC CAGE FOR MAINTENANCE

## INITIAL SETUP

## Common Tools

- Tool kit


Raise

1. Remove cover (para 4-11).


## NOTE

On some units, bracket may have only two screws.


2. Loosen screws enough to free cage.



3. From rear of drive, loosen fastener as shown.




4-25. RAISE/LOWER LOGIC CAGE FOR MAINTENANCE (CONT)




4. Carefully pull logic cage out of mount.

CAUTION

Logic cage can fall if not secured.



5. Swing up cage.




6. Lay cage on its side as shown.


4-25. RAISE/LOWER LOGIC CAGE FOR MAINTENANCE (CONT)

Lower


1. Swing cage down as shown.




2. Slide cage into mount.



3. From rear of drive, tighten fastener as shown.



4-25. RAISE/LOWER LOGIC CAGE FOR MAINTENANCE (CONT)



4. Tighten screws.
5. Replace cover (para 4-11).



## 4-26. REMOVE/REPLACE LOGIC CAGE BOARDS

## INITIAL SETUP

Special Tools  
Card extraction tool

Remove


1. Remove cover (para 4-11).



2. Using card extraction tool, pull board straight up. If board does not slide out, wiggle it loose.



4-26. REMOVE/REPLACE **LOGIC CAGE BOARDS** (CONT)



Repl ace

1. Using side guides, carefully slide board back into slot. Make sure it is seated evenly in cage.
2. Repl ace cover (para 4-11).

## 4-27. REMOVE/REPLACE BACKPLANE

## INITIAL SETUP

## Common Tools

- Tool kit

## Materials/Spare Parts



- Tags
- Pen or pencil

## NOTE

The backplane and logic cage are removed and replaced as one assembly.


## Remove

1. Remove cover (para 4-11).
2. Remove all boards from logic cage (para 4-26).
3. Tag, then remove all cables from rear of cage.



4. Loosen screws enough to free cage.

1-27. REMOVE/REPLACE BACKPLANE (CONT)




5. From rear of drive, loosen fastener as shown.
6. Carefully pull logic cage out of mount.


CAUTION

Logic cage can fall if not secured.

7. Swing up cage.



8. Tag, then remove all cables and wires from bottom of cage.
9. Lower cage.






10. Remove two screws holding logic cage to carriage coil assembly.
11. Lift backplane and logic cage from drive.

## 4-27. REMOVE/REPLACE BACKPLANE (CONT)


Repl ace

1. Repl ace all logi c boards (para 4-26).
2. Mount logi c cage i nto posi ti on on dri ve.



5. Repl ace all cabl es and wi res to bot tom of cage.
6. Lower cage (para 4-25).

4-27. REMOVE/REPLACE BACKPLANE (CONT)



7. Replace all cables on rear of drive.
8. Replace cover (para 4-11).

## 4-28. REMOVE/REPLACE/ADJUST HEADS LOADED SWITCH

## INITIAL SETUP

## Common Tools


- Tool kit

## Materials/Spare Parts

- Paper
- Pen or pencil

## TMDE

- Multimeter


Remove

1. Raise cover (para 4-11).
2. On piece of paper, note position of wires. Using needle nose pliers, pull off wires.

## NOTE

Some disk drives may have a protective shield over the heads loaded switch. If your drive has one, discard it. It cannot be used once switch has been readjusted.


3. Remove screws and washers.



4-28. REMOVE/REPLACE/ADJUST HEADS LOADED SWITCH (CONT)



5. Remove screws and nuts.




6. Remove switch and stop bracket from mounting bracket.


Repl ace

1. Assemble swi tch and stop bracket to mounting bracket. Repl ace swi tch screws.
2. Put swi tch back in dri ve. Repl ace mounting bracket screws.
3. Go to Adj ust step 1.

## 4-28. REMOVE/REPLACE/ADJUST HEADS LOADED SWITCH (CONT)


**Adjust**

1. Pull cover off actuator assembly.



2. Make sure carriage is fully retracted.

3. Set up multimeter to measure resistance.



4. Connect leads as shown.

5. Set multimeter to read 2 ohms.


6. Check meter. It should read zero ohms.




4-28. REMOVE/REPLACE/ADJUST HEADS LOADED SWITCH (CONT)



7. Using machinist's rule, measure distances between rear of coil and edge of assembly, as shown. On piece of paper, write down the distance.




8. Move coil forward until meter switches from zero ohms to one ohm.



9. Again, measure distance between coil and edge of assembly, as shown. Write it down.

## 4-28. REMOVE/REPLACE/ADJUST HEADS LOADED SWITCH (CONT)

10. The difference between distance measured in step 7 and step 9 must be 1/16 to 1/8 inch. If measurement is off, go to step 11. If measurement is correct, go to step 12.
11. Loosen mounting bracket screws enough to slide heads loaded switch forward or backward. Move switch and repeat steps 8 thru 10 until distance is correct.
12. Tighten mounting bracket screws.
13. Using your notes, reconnect red wires to switch.
14. Manually move carriage to fully retracted position.
15. Replace coil cover.



16. Replace cover (para 4-11).

## 4-29. REMOVE/REPLACE READ/WRITE HEADS

## INITIAL SETUP

## Common Tools

- Tool kit
- Torque screwdriver

Remove

## NOTE


There are five read/write heads. Follow the same steps for each head. This task shows read/write head number zero.

1. Remove cover (para 4-11).
2. Press release latch and lift pack access cover.

## NOTE


Some disk drives have a pack cover solenoid which will not release latch when power is off. If latch will not release, power on drive, open pack access-cover and power off.

3. If installed, remove disk pack.
4. Raise logic cage (para 4-25).




5. Locate head connectors.


4-29. REMOVE/REPLACE READ/WRITE HEADS (CONT)



- 6. Take out screws.
- 7. Pull off bracket.



- 8. Unplug connector.




- 9. Remove screw.


4-29. REMOVE/REPLACE READ/WRITE HEADS (CONT)

CAUTION


Heads scratch easily. Pull head out carefully. Don't let one head rub another.



10. From inside pack area, find head. Grasp edge of arm only. Gently pull out head about 1/4 inch.




11. Go to rear. Make sure connector isn't caught on anything. Push head forward another 1/2 inch as shown.




12. From pack area, pull head and connector out all the way.

## 4-29. REMOVE/REPLACE READ/WRITE HEADS (CONT)


## Replace



1. Hold head arm by edge as shown. From pack area, slide connector and head in slot as shown.




2. From rear, grasp head and slide it back until it lines up with other heads.




3. Replace screw. Using torque screwdriver, tighten to a torque of 4 to 8 inch-pounds.

4-29. REMOVE/REPLACE READ/WRITE HEADS (CONT)



- 4. Plug in connector.
- 5. Aline heads (para 4-30).



- 6. Replace bracket.
- 7. Replace screws.
- 8. Lower logic cage (para 4-25).
- 9. Replace cover (para 4-11).

4-30. CHECK/ALINE READ/WRITE HEADS

INITIAL SETUP

Common Tools

- Tool kit
- Torque screwdriver

Special Tools

- Head alignment tool

Test, Measurement and Diagnostic Equipment

- Field test unit
- Oscilloscope
- CE alignment pack

Materials/Spare Parts

- Paper
- Pen or pencil

Check


1. Remove cover (para 4-11).
2. Raise logic cage. Check servo head alignment (para 4-31, Replace steps 4-5) |

NOTE

Your field test unit (FTU) may be model TB216 or TB303. This procedure covers each model under its respective heading. Continue with step 3 under correct model heading.

MODEL TB303

3. Install FTU (para 4-53).




4. Set these toggle switches in center position.

- ACC/RD/WR
- POS/NEG
- EARLY/LATE STROBE
- REV/FWD/OFF-SET
- RTZ



4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



5. Set these toggle switches in up position.

- I R/W SERVO
- I I/O ENABLE-DISABLE
- I SEQ PWR ON/OFF

6. Set all remaining switches in down position.

7. Set up oscilloscope. Use these settings for X10 probe:

VOLTS/DIV

- CH 1 - 0.1 v
- CH 2 - not used

TIME/DIV

1 usec.

TRIGGERING

CH 1 - INTERNAL POSITIVE

8. Attach channel 1 probe to red di bits jack of FTU.
9. Attach, probe ground lead to the black di bits jack of FTU.
10. Power on drive.
11. Load CE alinement pack.

CAUTION


Make sure PROTECT indicator is lit.

12. Cycle up disk drive.
13. On FTU push down then release RTZ.

CAUTION

Wait 30 minutes before doing step 15. This will ensure stabilization of disk drive temperatures.

4-30. CHECK/ALINE READ/WRITE HEADS (CONT)




14. Turn AUTO FUNCT selector to SGL.

NOTE


When there are two disk drives per channel, use step 15 for second drive. For all other disk drives, start at step 16. See your system manual to determine disk drives per channel.

15. Set BUS OUT switch 1 up to address second drive.
16. Set SELECT/HOLD up.
17. Set START/STOP up then down.
18. Push down then release RTZ. Only MOD ADDR indicator should be lit.
19. Set AUTO FUNCT selector to DIR.
20. If up, set BUS OUT switch 1 down.



21. Set BUS OUT switches 128, 64, 32, and 16 up. All remaining BUS OUT switches must be down.
22. Set START/STOP switch up then down. BUS IN light will display the switches in step 21.
23. Turn AUTO FUNCT selector to CONT.


4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



24. Set BUS OUT switches 128, 64, 32, 16, 4, and 1 up. All remaining BUS OUT switches must be down.
25. Set START/STOP switch up. Leave switch in the up position for at least 30 seconds.
26. Set START/STOP switch down.
27. Push down then release RTZ.
28. Turn AUTO FUNCT selector to DIR.
29. Set START/STOP switch up then down.
30. Turn AUTO FUNCT selector switch to SGL.
31. Set all BUS OUT switches down.


NOTE

Set meter sensitivity switch to center position (500).




32. Set MAN/SEQ up.
33. Set TAG switches 1 and 2 up.
34. Set START/STOP switch up then down. (Head zero is selected.)


4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



35. Look at scope. Di bit pattern will be similar to that shown.



36. Look at head alignment meter. It is now showing the positive di bit reading. Since meter sensitivity is set at 500, count 10 mV for each scale marker on the plus or minus side from zero. Write down the amount.



37. Press down and hold the POS/NEG switch. Observe head alignment meter. It is now showing the negative di bit reading. Make the same calculation as done in step 36. Write down the amount.

4-30. CHECK/ALINE READ/WRITE HEADS (CONT)

**Example:** P = +20      N = +15  
 (P) - (N) = (+20) - (+15) = +5  
**Example:** P = +20      N = -15  
 (P) - (N) = (+20) - (-15) = +35  
**Example:** P = -20      N = +15  
 (P) - (N) = (-20) - (+15) = -35

38. Using the formula below, calculate offset.

$$\text{OFFSET} = (P) - (N)$$

where: P = positive dibit reading  
 (step 36)  
 N = negative dibit reading  
 (step 37)

39. Write down the result of OFFSET calculation.

40. If OFFSET calculation is:

| Equal to or greater than 300 mV, you must locate all packs written by the drive. The data on those packs must be saved to another disk or to tapes before head can be aligned. Check SOP

| Greater than 150 mV but less than 300 mV, head must be aligned

| Less than 150 mV, head is within specification. No alignment is required

41. Set START/STOP down.

NOTE

You have just finished check read/write head zero. Now, you will check the remaining heads (1, 2, 3, 4) by following the steps below, observing the scope dibit pattern, and calculating OFFSET. (See steps 35 thru 39.) DO NOT go on to the aline part of mask until you find out which, if any, heads must be aligned.


42. Set all BUS OUT switches down.

## 4-30. CHECK/ALINE READ/WRITE HEADS (CONT)


43. Check remaining heads one at a time by selecting BUS OUT switches as follows:
  - Head 1: set BUS out switch 1 up, then do steps 44 and 45.
  - Head 2: set BUS OUT switch 2 up, then do steps 44 and 45.
  - Head 3: set BUS OUT switches 1 and 2 up, then do steps 44 and 45.
  - Head 4: set BUS OUT switch 4 up, then do step 45.
44. Set START/STOP up.
45. Repeat steps 35 thru 43 until heads 1, 2, 3 and 4 have been checked.
46. If any head is out of the specification described in step 40, perform the Aline part of this task. If all heads are within specification, do step 47.
47. Push down then release RTZ.
48. Set START/STOP down.
49. Cycle down disk drive.
50. Unload CE alignment pack.
51. Power off drive.
52. Unplug FTU.
53. Remove head alignment board and cable.
54. Remove field test unit 1/0 cables.
55. Install disk drive 1/0 cables.
56. Replace cover (para 4-11).

4-30. CHECK/ALINE READ/WRITE HEADS (CONT)


Align



1. From logic chassis side of drive, find head carriage.




2. Find head connector hold-down bracket.
3. Remove screws. Pull off bracket.




4. Find lock screw for the head to be aligned.


## 4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



5. Set torque screwdriver at 10 inch-pounds. Turn counter-clockwise enough to break loose lock screw (1/8 to 1/4 turn).




6. Retighten screw, as shown.




7. On FTU, select head to be aligned by using BUS OUT switches as follows:
  - Head 0: set all BUS OUT switches down, then do step 8
  - Head 1: set BUS CUT switch 1 up, then do step 8
  - Head 2: set BUS OUT switch 2 up, then do step 8
  - Head 3: set BUS OUT switches 1 and 2 up, then do step 8
  - Head 4: set BUS OUT switch 4 up, then do step 8



4-30. CHECK/ALINE READ/WRITE HEADS (CONT)




8. Set START/STOP UP.
9. Find access slot for head you will align.



10. If head connector cables are in the way, bend them up or down so alignment tool can be inserted.

CAUTION

Alignment tool must be seated.  
Failure to do so will damage head slot\*





11. Carefully insert alignment tool.  
Make sure it is seated.

4-30. CHECK/ALINE READ/WRITE HEADS (CONT)

NOTE


Very small movements of alinement tool are required. Make sure movements are slight.

12. While looking at FTU meter, carefully move tool until needle is within 100 mV of zero.




13. Look at scope. Waveform will be similar to this.
14. On FTU, set meter sensitivity switch to the up position (100).

15. While looking at FTU meter, carefully move tool until needle is within 10 mV of zero.




4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



16. Look at scope. Waveform will be similar to this.
17. On FTU, press down and hold POS/NEG switch. Look at meter. Needle should be in same range as in step 15.
  - If in 10 mV range, release POS/NEG and go to step 18
  - If not, release POS/NEG and repeat steps 15 thru 17


NOTE

Head alinement tool must be removed carefully. Failure to do so will disturb alinement.




18. Remove head alinement tool.
19. Look at FTU meter
  - If in 10 mV range, go to step 20
  - If not, insert alinement tool and repeat steps 15 thru 19
20. Press down and hold POS/NEG switch.
  - If in 10 mV range, go to step 21
  - If not, insert alinement tool and repeat steps 15 thru 19
21. If other heads are to be alined, set 500/100 switch to center position (500). Start at step 4 for each . . . If all heads are alined, set START/STOP=down.
22. Set torque screwdriver at 12 inch-pounds.


4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



23. Find lock screw(s) of head(s) just aligned.



24. Tighten each lock screw as shown.



25. Replace head connector hold down bracket.

26. Replace screws.

27. Check head alignment (steps 36 thru 44).

4-30. CHECK/ALINE READ/WRITE HEADS (Cont)



MODEL TB216

3. Install and test FTU (para 4-53).

CAUTION

I/O Connectors from FTU must be installed correctly. If installed in wrong location damage to pins or connectors may result.

4. Make sure I/O connectors from FTU are properly installed on logic cage.




5. Connect plug P104 of FTU head alignment cable to 3-pin connector on second read/write board.
6. Connect plug P8P2 to pins 8-11 on slot A02 on underside of logic cage.
7. Lower logic cage.
8. Make sure head alignment board is correctly installed in logic cage.
9. On back of disk drive, power ON circuit breakers.
10. Power ON FTU circuit breaker. Check that +5 and -5 indicators light.

4-30. CHECK/ALINE READ/WRITE HEADS (CONT)

11. Set FTU switch listed to positions shown:

<u>SWITCH</u>	<u>POSITION</u>
PROCESSOR START/RESET	RESET
PROCESSOR RUN/HALT	HALT
SINGLE/CONT	CONT
-/+ OFFSET	CENTER (OFF)
LATE/EARLY	CENTER (NORMAL)
WRT FLAG	OFF
WRT PROT	ON
AM/SECTOR	EITHER
EOT STOP	OFF
ERROR OVERRIDES:	
DATA-OFF	OFF
ADDR-OFF	OFF
SHIFT PATT/DATA PATT	DATA PATT
RD/WRT SELECT	ACCESS ONLY
ACCESS SELECT	DIRECT SEEK
PROCESSOR START/RESET	START
PROCESSOR RUN/HALT	RUN
SEQ PWR/OFF	SEQ PWR



12. Look to see that the following FTU indicators light:

ON CYCL	SEEK ERR
RDY	FLT
WT PROT	BUSY
SELD	RUN

13. Power ON disk drive.

14. Load CE alignment pack.


15. Cycle up disk drive.

4-30. CHECK/ALINE READ/WRITE HEADS (CONT)

16. Allow drive to stabilize for at least 30 minutes before accessing cylinder (steps 28-32).

NOTE

Steps 17-26 may be done while you are waiting for disk drive to stabilize.



17. Connect head alignment test leads between FTU head alignment panel jacks and head alignment board jacks. Connect (+) to (+) and (-) to (-).
18. On head alignment board, set toggle switches as follows:

<u>SWITCH</u>	<u>POSITION</u>
xI /x. I	xI
RW/S	RW
N/P	N

19. set up oscilloscope. Use these settings for X10 probe.

VOLTS/DIV

CH 1 - 0.1V  
 CH 2 - not used


TIME/DIV

1 usec.


TRIGGERING

CH 1 - INTERNAL POSITIVE


4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



20. Connect X10 probe to head alignment board test point READ SIG (Y).
21. connect X10 ground probe to head alignment board test point METER (-z).




22. Turn DATA ENTRY switch to DEVICE TYPE.
23. Enter device code 3105 at keyboard.
  - Corresponding ROW 2 indicators will light.
  - If you key incorrectly, press CLR ENT, then enter code again.



24. Press LOAD key.
  - Code will transfer to ROW 1 indicators.
  - If code does not transfer, press CLR ENT then repeat step 23.
25. Be sure that ROW 3 indicator 1/0 RDY is lit.
26. Press SEL DRV key.



4-30. CHECK/ALINE READ/WRITE HEADS (CONT)




27. Make sure SELD indicator lights and that logical address for selected disk drive lights in ROW 1.
  - If SELD is flashing or incorrect logical address lights, selection was unsuccessful.
  - Press CLR ENT, then repeat from step 23.
  - If second attempt to select is unsuccessful, troubleshoot the disk drive.

NOTE


Before performing step 28, one hour must have passed since step 15 was performed.

28. Set RD/WRT SELECT switch to ACCESS ONLY.
29. Set ACCESS SELECT switch to DIRECT SEEK.
30. Set DATA ENTRY switch to DESTINATION.




31. Key in cylinder address 240 and press LOAD key.
32. Press GO, STOP, and CLR keys.
33. Key in cylinder address 245. Press LOAD and GO keys.

4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



34. Look at oscilloscope. Waveform will be as shown.



35. Set RD/WRT SELECT switch to ALIGNMENT.

36. Set DATA ENTRY switch to HEAD.

37. Set HEAD toggle switch to MAN.

38. Key in number of head to be checked and aligned. Head numbers, from top to bottom, are:


- 0
- 1
- SERVO
- 2
- 3
- 4

39. Press LOAD key.

40. Press one key (BIT, HEX, or DEC) to select the type of display desired.

41. Press GO key.


4-30. CHECK/ALINE READ/WRITE HEADS (CONT)



42. Look at the oscilloscope. Waveform should be as shown.

LED Designation	Representation (in mV)		
	HEX Mode	DEC Mode	BIT Mode
0	1	1	10
1	2	2	20
2	4	4	30
3	8	8	40
4	16	10	50
5	32	20	60
6	64	60	70
7	128	80	80
8	256	100	90
9	512	200	100
A	1024	400	200
B	Not Used	800	300
C	Not Used	1000	400
D	Not Used	Not Used	500
E	Not Used	Not Used	600 And Above
F	- Sign	- Sign	- Sign

43. Use head alinement chart to interpret and record indication of ROW 2 lights (negative di bit side in mV).



44. On head alinement board, set N/P toggle switch to P.


45. Use head alinement chart to interpret and record indication of ROW 2 lights (positive di bit side in mV).

## 4-30. CHECK/ALINE READ/WRITE HEADS (CONT)


46. Look at (-) and (+) di bit readings taken in steps 43 and 45 for the following conditions:
  - Each reading must be less than 75 mV (total di bit offset less than 150 mV)
  - Both readings must be within 5 mV of each other
  - If both conditions above are met, alinement of this head is not needed. Go to step 51
  - If only one or none of the conditions are met, go to step 47

CAUTION

Alinement tool must seat in slot.  
Failure to seat will damage slot.





47. Remove head connector hold-down bracket. Loosen locking screws. Aline heads to 10 in/lb torque (with heads retracted).
48. Insert alinement tool in head slot. Using very small movements, turn tool small amounts and watch scope for pattern movement.
49. With heads retracted, tighten screw to 11.5 - 12.5 in/lb.
50. Repeat steps 35 thru 49 for each head alinement.



51. Press STOP key.
52. Press CLR key.

4-30. CHECK/ALINE READ/WRITE HEADS (CONT)

53. Cycle down disk drive.
54. Unload CE disk pack.
55. Pull out disk drive drawer.
56. On back of disk drive, power OFF circuit breakers.
57. Power OFF FTU circuit breaker.
58. Remove and stow FTU test leads.
59. Power OFF oscilloscope. Remove and stow its test leads.
60. Unplug and stow oscilloscope.
61. Remove and stow FTU head alignment cable.



62. Lower logic cage (para 4-25).
63. Remove FTU head alignment board from logic cage slot A02. Stow it.
64. Stow FTU.
65. Reconnect drive cables at rear of logic cage.
66. Replace disk drive cover (4-11).

## 4-31. REMOVE/REPLACE SERVO HEAD

## INITIAL SETUP

## Common Tools



- Tool kit
- Torque screwdriver

## Special Tools

- Head adjustment tool


Remove

1. Remove cover (para 4-11).
2. Press release catch and lift pack access cover.
3. If installed, remove disk pack.
4. From side of deck, locate servo preamp cover.
5. Loosen screw enough to free cover. Pull off cover. It should rest on connecting wires.




6. Find and unplug servo head connector.

4-31. REMOVE/REPLACE SERVO HEAD (CONT)




7. Next to spindle motor, find cable clip.
8. Pull out head cable.
9. Pull out PA connector.



10. Raise logic cage (para 4-25).
11. Remove servo head screw.



CAUTION

Servo head is fragile. Pull head out carefully. Don't let head touch other heads.




12. From inside pack area, find servo head. Grasp outer edge of arm as shown. Gently pull out head about 1/4 inch.

4-31. REMOVE/REPLACE SERVO HEAD (CONT)



14. From pack area, grasp edge of head arm as shown. Pull head and connector out all the way.




Replace

1. Hold arm by edge as shown. From pack area, **slide** connector and head in slot as shown.







4-31. REMOVE/REPLACE SERVO HEAD (CONT)



2. From rear, grasp head and slide it back until it lines up with other heads.





3. Replace screw. Using torque screwdriver, tighten to a torque of 4 to 8 inch-pounds.
4. Look through servo head adjustment slot.




5. Compare servo head adjustment slot with illustration. Slot should be centered in carriage alignment hole as shown.
  - If it is, go to step 8
  - If it isn't, go to step 6

4-31. REMOVE/REPLACE SERVO HEAD (CONT)



18



21

6. With torque screwdriver, loosen screw.
7. With head adjustment tool, center slot as shown in step 5.
8. Tighten screw to a torque of 12 inch-pounds.
9. Push in PA connector.
10. Connect head cable to cable clip.
11. Push in servo head connector.
12. With CE pack installed and oscilloscope connected to the read and ground jacks, load heads to cylinder 000 (00) and perform thermal stabilization.
13. When thermal stabilization is completed command continuous seek between cylinder 240 and 245 for 30 seconds minimum. This allows head gimbal springs to settle.
14. Stop continuous seek.
15. Loosen servo-head to 6 inch pound torque.
16. Command a direct seek to cylinder 245.
17. Set servo - R/W switch to servo position.
18. Balanced dibit pattern should be observed on oscilloscope.
19. If balanced dibits pattern was observed in previous steps, calculate head offset for servo head. Servo head offset must be  $0 \pm 30\text{mv}$ . If offset is greater than 30 mv. terminate procedure and troubleshoot servo system.
20. Replace shield.
21. Tighten screw.
22. Aline read/write heads (para. 4-30).

4-32. CLEAN HEADS

INITIAL SETUP

Materials/Spare Parts

- Isopropyl alcohol
- Gauze or lint-free cloth


CAUTION

Head cleaning is a delicate procedure. Clean a head only when absolutely necessary.


NOTE

There are six heads. Follow these steps for any head.


1. Remove disk pack.
2. Raise deck (para 4-12).
3. Pull off coil cover




4. Slowly push carriage as shown until you feel a slight release in pressure.
5. Open pack access cover.




4-32. CLEAN HEADS (CONT)



6. Moisten strip of gauze with isopropyl alcohol.
7. Insert gauze strip beneath bottom head as shown.
8. Gently slide cloth back and forth.
9. Repeat steps 6 thru 8 for each of the remaining heads.



10. Push carriage back all the way.



11. Push on coil cover.
12. Lower deck (para 4-12).
13. Power on.

NOTE

The next step is used to purge the pack area of lint and dust.

14. Allow drive to run for 1 to 3 minutes without disk pack installed.

4-33. REMOVE/REPLACE DRIVE BELT

INITIAL SETUP

Common Tools


- Tool kit

Materials/Spare Parts

- Drive belt

Remove


1. Raise deck (para 4-12).
2. From underneath deck, locate spring guide.




CAUTION

You must let tension off spring or motor shaft can bend.


3. With screwdriver, hold motor adjusting rod in place. With 7/16-inch open end wrench, loosen nut all the way to take tension off spring.




## 4-33. REMOVE/REPLACE DRIVE BELT (CONT)



4. While turning motor pulley by hand, slip belt off.
5. Pull other end of belt off pulley. Slip it out from around brake.

Repl ace

1. Slip belt onto pulley.



2. While turning spindle pulley by hand, slip belt onto pulley.
3. To make sure drive belt is centered on pulley, turn pulley by hand several times.
4. Adjust drive belt (para 4-34, steps 2-13).

4-34. ADJUST DRIVE BELT


INITIAL SETUP

Common Tools


- Tool kit

Supplies

- Scratch pack




1. Raise deck (para 4-12).
2. From underneath deck, locate spring guide.



3. Using machinist's rule, measure gap between spring guide and stop nut. Gap must be:
  - 0.25 +/- 0.05 in. (6.35 +/- 1.27 mm)
4. Using screwdriver, hold motor adjusting rod in place. Using 7/16-inch open end wrench, adjust nut until gap is correct.
5. Lower deck (para 4-12).
6. Install scratch pack.
7. Power on drive.



## 4-34. ADJUST DRIVE BELT (CONT)



8. Cycle up drive. When READY indicator lights, cycle down drive.
9. Raise deck (para 4-12).
10. From side of deck, check belt to make sure it is in center of motor pulley.
  - If belt is centered, go to step 14.
  - If belt is not centered, go to step 11.
11. Remove brake assembly (para 4-40, Remove steps 2-5).
12. Using machinist's rule, adjust pulley alignment gap. Gap should be  $13/16 \pm 1/32$  inch (para 4-39, Replace step 13).
13. Replace brake assembly (para 4-40, Replace steps 2-6).
14. Power off drive. Lower deck.
15. Remove scratch pack.
16. Slide drawer in.

4-35. REMOVE/REPLACE SOLID STATE SWITCH (START TRIAC)

INITIAL SETUP

Common Tools


- Tool kit

Materials/Spare Parts


- Dielectric grease
- Tags (for wires)
- Swab
- Pen or pencil

Remove


1. Raise deck (para 4-12).
2. Find solid state switch.



3. Tag wires.
4. Pull off wires.




4-35. REMOVE/REPLACE SOLID STATE SWITCH (START TRIAC) (CONT)




5. Remove two screws securing switch and ground wire to deck.
6. Remove switch.

Replace




1. With swab, apply light coat of dielectric grease to switch base.



2. Mount switch and ground wire.
3. Replace two screws.

4-35. REMOVE/REPLACE SOLIDSTATE SWITCH (START TRIAC) (CONT)



4. Push on wires. Remove tags.
5. Lower deck (para 4-12).

## 4-36. REMOVE/REPLACE DRIVE MOTOR CAPACITOR


## INITIAL SETUP

Common Tools

- Tool kit

Remove


1. Raise deck for maintenance (para 4-12).
2. Find drive motor capacitor.



## NOTE

You may have to pry retaining clamp away from capacitor with screwdriver.

3. Push capacitor in direction shown to free bottom from retaining clamp.
4. Pull bottom as shown and free top from retaining clamp.
5. Remove cap from capacitor.




4-36. REMOVE/REPLACE DRIVE MOTOR CAPACITOR (CONT)

WARNING


Capacitor may hold high voltage charge. Test with voltmeter before removing connectors.

6. Remove wire connectors.



Replace


1. Remove cap from capacitor.
2. Push on wire connectors.
3. Replace cap on capacitor.



CAUTION

Do not pinch capacitor wires in cap or retaining clamp.

4. Insert top of capacitor into retaining clamp.
5. Push bottom of capacitor into retaining clamp. Make sure capacitor is secured on top and bottom. If necessary, use screwdriver to pry open retaining clamp and seat capacitor.
6. Lower deck (para 4-12).



## 4-37. REMOVE/REPLACE STATIC GROUND SPRING


## INITIAL SETUP

Common Tools


- Tool kit

Remove


1. Raise deck (para 4-12).
2. Find spring.



3. Remove screws and washers.
4. Pull ground strap aside.




4-37. REMOVE/REPLACE STATIC GROUND SPRING (CONT)



5. Remove spring.

Replace



1. Set static ground spring in place.
2. Hold ground strap and spring in place.
3. Replace screws and washers.
4. Adjust static ground spring (para 4-38, steps 2-10).



## 4-38. ADJUST STATIC GROUND SPRING

## INITIAL SETUP

## Common Tools

- Tool kit
- Belt tension gauge

1. Raise deck (para 4-12).
2. Hook gage to end of spring as shown.
3. Pull down on gage until spring is free of spindle end.
  
4. Look at gauge. Force measurement must be 80 to 100 grams to free spring from spindle.
  - If it is, go to step 10
  - If it is not, go to step 5
  
5. Loosen screws enough to free mounting block.
6. To increase tension, slide block up as shown.
7. To decrease tension, slide block down as shown.
8. Tighten screws.
9. Repeat until force measurement is 90 +/- 10 grams. If after several tries you don't get correct measurement, replace static ground spring (para 4-37).
10. Lower deck (para 4-12).

4-39. REMOVE/REPLACE SPINDLE MOTOR



INITIAL SETUP

Common Tools

- Tool kit


Remove

1. Raise deck (para 4-12).
2. Remove drive belt (para 4-33).
3. Remove brake assembly (para 4-40).
4. Remove screw, bracket.
5. Remove screw and ground strap.
6. Remove screws and wire.




7. Lower deck (para 4-12).
8. From side of deck, remove screws.
9. Remove plate.


4-39. REMOVE/REPLACE SPINDLE MOTOR (CONT)



10. Pull apart P304.



11. Lift out motor.



12. Using hex key, loosen screw enough to free collar and pulley.


13. Pull off collar.

14. Pull off pulley.


4-39. REMOVE/REPLACE SPINDLE MOTOR (CONT)

Repl ace

1. Repl ace motor.




2. Connect P304.




3. Repl ace pl ate.


4. Repl ace screws.




## 4-39. REMOVE/REPLACE SPINDLE MOTOR (CONT)



5. Raise deck (para 4-12).
6. Install screw and bracket. Tighten screw just enough to hold bracket in place.
7. Install screw and ground strap. Hand-tighten screw.
8. Install screws and wire.
9. Tighten all four screws.




10. Slide on pulley.




11. Slide on collar as shown.
12. Tighten screw just enough to hold collar and pulley in place.

4-39. REMOVE/REPLACE SPINDLE MOTOR (CONT)



13. Using machinist's rule, measure alignment gap. Gap must be  $\frac{13}{16} + \frac{1}{32}$  inch.

- If gap is correct, go to step 15
- If gap is not correct, go to step 14



14. Loosen screw enough to move collar and pulley. Position pulley until gap is correct.

15. Tighten screw.

16. Install brake assembly (para 4-40, Replace steps 1-5).

17. Install drive belt (para 4-33, Replace steps 1-4).

## 4-400 REMOVE/REPLACE BRAKE ASSEMBLY

## INITIAL SETUP

## Common Tools



- Tool kit
- Torque screwdriver

## Materials/Spare Parts

- Tie wraps

Remove

1. Raise deck (para 4-12).
2. Unplug connector on brake. Cut tie wraps.




Using hex key loosen setscrew.

With one hand, hold brake from underneath. Remove screw holding wire lead to brake assembly. Remove wire lead.

Slide brake off motor shaft.



4-40. REMOVE/REPLACE BRAKE ASSEMBLY (CONT)



6. Lift off collar.

Replace

1. Put collar on new brake.
2. Slide brake onto motor shaft.
3. Replace wire lead and screw.
4. Tighten screw. Using torque screwdriver, tighten to 30' +/- 2 inch-pounds.



5. Push connectors together. Install tie wraps.
6. Lower deck (para 4-12).



## 4-41. REMOVE/REPLACE READ/WRITE BOARD ASSEMBLY

## INITIAL SETUP

## Common Tools



- Tool kit

## Materials/Spare Parts

- Paper
- Pen or pencil


## Remove

1. Remove cover (para 4-11).
2. Raise logic cage (para 4-25, Raise, steps 2-6).
3. Remove screw.




4. Pull out plate. Push to side.


4-41. REMOVE/REPLACE READ/WRITE BOARD ASSEMBLY (CONT)



- 5. Remove screws.
- 6. Remove bracket.




- 7. Unplug cables one at a time.




- 8. Remove screws and plate.
- 9. Remove screws, spacers, and nuts.

4-41. REMOVE/REPLACE READ/WRITE BOARD ASSEMBLY (CONT)




10. Pull out assembly.




11. Remove nylon screw and spacer.

12. Pull off air plenum.



13. On scratch paper, note how P101 is installed. Pull P101 from board.


4-41. REMOVE/REPLACE READ/WRITE BOARD ASSEMBLY (CONT)



14. Pull boards apart.

Replace


1. Line up spacers. Mount boards together.




CAUTION

Incorrect installation of P101 will cause damage to boards.


2. Connect P101 using notes made during removal.




4-41. REMOVE/REPLACE READ/WRITE BOARD ASSEMBLY (CONT)



3. Replace air plenum.
4. Replace spacer and nylon screw.




5. Gently push assembly back in place.
6. Replace screws and plate.
7. Replace screws, spacers, and nut. Do not tighten screws until you have completed step 11.




8. Carefully plug in cables one at a time.

4-41. REMOVE/REPLACE READ/WRITE BOARD ASSEMBLY (CONT)



- 9. Replace bracket.
- 10. Replace screws.



- 11. Push plate in place.
- 12. Replace screw. Tighten all screws.
- 13. Lower logic cage (para 4-25).
- 14. Replace cover (para 4-11).

## 4-42. REMOVE/REPLACE TRACK SERVO PREAMP

## INITIAL SETUP

## Common Tools


- Tool kit

## Materials/Spare parts


- Tie wraps

Remove


1. Raise deck (para 4-12).
2. From underneath deck, reach behind servo preamp and find P8. Cut tie wraps and pull off P8.




3. Lower deck (para 4-12 Lower steps 1-7).
4. Remove power supply (para 4-18).




4-42. REMOVE/REPLACE TRACK SERVO PREAMP (CONT)



5. Remove screws.
6. Slide cover off shield and let it hang on cable.
7. Pull off shield.



8. Turn shield around as shown.
9. Pull off head connector.




10. Using 3/16-in. nut driver, remove screws.
11. Lift out board.




4-42. REMOVE/REPLACE TRACK SERVO PREAMP (CONT)

Repl ace

1. Set board into shield as shown.
2. Using 3/16-in. nut driver, repl ace screws.




3. Push in head connector. Push on P8.




4. Put shield in place.
5. Insert screws. Tighten bottom screw only.
6. Slide cover under top screw as shown. Tighten top screw.

4-42. REMOVE/REPLACE TRACK SERVO PREAMP (CONT)



7. Replace power supply (para 4-18, Replace steps 1-10).
8. Raise deck (para 4-12).



9. From underneath deck, push in J8. Replace tie wraps.
10. Lower deck (para 4-12).

## 4-43. REMOVE/REPLACE POWER AMPLIFIER ASSEMBLY


## INITIAL SETUP

Common Tools

- Tool kit


Remove

1. Raise cover (para 4-11).
2. Pull apart PA connector.
3. Loosen screw enough to free assembly.
4. Raise deck (para 4-12).




5. Disconnect P200. If necessary, use small screwdriver to pry plug apart.


4-43. REMOVE/REPLACE POWER AMPLIFIER ASSEMBLY (CONT)



6. Remove screws.




7. Slide power amplifier out of mounting.




**Replace**

1. With deck in raised position, slide power amplifier back in place. Line it up under screw.

4-43. REMOVE/REPLACE POWER AMPLIFIER ASSEMBLY (CONT)



2. Replace screws.
3. Connect P200.



4. Lower deck (para 4-12).
5. Tighten screw.
6. Connect PA connector.

4-44. REMOVE/REPLACE SPEED TRANSDUCER

INITIAL SETUP

Common Tools

- Tool kit

Materials/Spare Parts



- Tie wraps

Supplies

- Scratch pack


Remove

1. Raise deck (para 4-12).
2. Locate P202.




3. Unplug P202.
4. Cut tie wrap to free J202 wires.


4-44. REMOVE/REPLACE SPEED TRANSDUCER (CONT)



5. Using a 9/16-inch open-end wrench, loosen nylon lock nut. Slip nut off transducer. (It should rest on connecting wires.)



6. Unscrew and remove speed transducer as shown.




Replace

1. With deck raised, install scratch pack.

4-44. REMOVE/REPLACE SPEED TRANSDUCER (CONT)




2. Loosen nylon nut. Slip nut off new transducer as shown.



3. Slowly screw transducer up through bottom of deck. Turn until transducer stops.
4. Unscrew transducer one full turn.
5. Replace nylon nut. Turn until it stops. Do not over-tighten.

CAUTION

Do not touch recording surface of disk pack.



6. Turn pack by hand. Listen for scraping sound. This indicates transducer is hitting bottom of pack.
  - If scraping sound, go to step 7
  - If no scraping sound, go to step 9
7. Loosen nylon lock nut. Slide nut over wires. Unscrew transducer half turn.
8. Turn nylon lock nut back on transducer. Do not over-tighten lock nut.



## 4-44. REMOVE/REPLACE SPEED TRANSDUCER (CONT)

9. Connect P202.
10. Tie J202 wires with new tie wrap.
11. Lower deck (para 4-12).

## NOTE

If seek errors occur during operation, finer adjustment of speed transducer is required (para 4-45, steps 2-10).

4-45. CHECK AND ADJUST SPEED TRANSDUCER

INITIAL SETUP

Common Tools

- Tool kit

Test, Measurement and Diagnostic Equipment

- Oscilloscope

1. Remove cover (para 4-11).
2. Install scratch pack.
3. Power on drive.
4. Cycle up drive.
5. Set up oscilloscope. Use standard probe. Settings should be:


VOLTS/DIV

CH 1 - 5 V

CH 2 - NOT USED


TIME DIV

1 ms




6. Locate board in slot A-10.

4-450 CHECK AND ADJUST SPEED TRANSDUCER (CONT)



7. Find test point B.
8. Find cage connection closest to test point. Attach ground clamp.
9. Attach probe to test point B.




10. Look at oscilloscope. Waveform should look like this.
  - If it does, go to step 21.
  - If waveform pulses are dropping out, or there are no pulses, or if waveform noise pulses are in between speed pulses, go to step 11

NOTE

If adjustment is required, perform steps 11 through 19. If waveform pulses are dropping out or there are no pulses, then do adjustments as indicated in step 17. If waveform noise pulses are in between speed pulses, do adjustment as indicated in step 18.

4-450 CHECK AND ADJUST SPEED TRANSDUCER (CONT)



11. Raise deck (para 4-12).
12. Find speed transducer.

NOTE

To perform this task you will lower deck and cycle up drive repeatedly. It is not necessary to install hex head bolts in deck until task is completed.


- 130 Using a 9/16-inch open-end wrench, loosen nylon nut.

14. Lower deck (para 4-12).


15. Cycle up drive.

16. Observe scope.

17. If waveform pulses are dropping out or there are no pulses, turn speed transducer 1/2 turn as shown. Repeat adjustment as required. Go to step 19 after adjustment is completed.



18. If waveform noise pulses are in between speed pulses, turn speed transducer 1/2 turn as shown.



19. Tighten nylon lock nut. Turn until it stops. Do not over-tighten.

20. Go back to step 10.

21. Disconnect scope.

22. Press start to cycle down drive.

23. Power off drive.

24. Remove scratch pack.

25. Replace cover (para 4-11).

## 4-46. REMOVE/REPLACE VELOCITY TRANSDUCER

## INITIAL SETUP

## Common Tools

- Tool kit

## Materials/Spare Parts

- Screw-thread locking compound

## NOTE


Velocity transducer assembly consists of transducer coil, transducer core and extension rod. You must replace all parts at same time.

1. Remove cover (para 4-11).
2. At rear of drive, find magnet assembly.


CAUTION

Wires to P-22 break off easily. Handle connector carefully.


3. Disconnect P-22.
4. Remove screw and washer.




5. Slowly pull out coil.




4-46. REMOVE/REPLACE VELOCITY TRANSDUCER (CONT)



6. Slowly push in new transducer coil.




7. Choose one of these three slots. Line up slot with mounting hole.




8. Pull off coil cover.

## 4-46. REMOVE/REPLACE VELOCITY TRANSDUCER (CONT)



9. Slowly push carriage coil as shown until you feel slight release in pressure.




10. At same time, look inside pack area. Make sure heads do not extend more than 1 1/2 inches. If they do, move carriage coil back until you feel pressure on carriage coil.




11. Gently slide carriage coil back and forth. Listen for rubbing sound.


4-46. REMOVE/REPLACE VELOCITY TRANSDUCER (CONT)



12. For each remaining slot, repeat steps 9 and 13.



13. Choose slot which produced the least amount of rubbing. Line up that slot with mounting hole.




14. Replace screw and washer.


15. Connect P-22.




## 4-46. REMOVE/REPLACE VELOCITY TRANSDUCER (CONT)



16. Gently slide carriage coil back and forth. Listen for rubbing sound. If sound is about the same, go to step 17. If you feel carriage dragging, select another mounting slot for the transducer coil and check again. Use slot which produces least drag and rubbing.




17. Slowly push carriage coil as shown until you feel slight, release in pressure.




18. At the same time, look inside pack area. Make sure heads do not extend more than 1 1/2 inches. If they do move carriage coil back until you feel pressure on carriage coil.

4-46. REMOVE/REPLACE VELOCITY TRANSDUCER (CONT)


19. Raise logic cage (para 4-25).
20. From logic cage side of drive, locate carriage assembly.




21. Using 1/8-inch open-end wrench, turn rod as shown, until rod is off threads.




22. Using your finger, push core through coil.




4-46. REMOVE/REPLACE VELOCITY TRANSDUCER" (CONT)



23. Go to rear of assembly. Pull out core.




24. On replacement rod, put light coat of screw thread locking compound on these threads only.



25. Screw rod into end of replacement core. Wipe off leftover locking compound.


4-46. REMOVE/REPLACE VELOCITY TRANSDUCER (CONT)




26. Slide core back through coil.

CAUTION

Do not get locking compound on bearings.




27. Carefully put light coat of locking compound on threads.




28. Using 1/8-in. open-end wrench, turn rod until it's back in place. Do not overtighten.

29. Wipe away leftover locking compound.

## 4-46. REMOVE/REPLACE VELOCITY TRANSDUCER (CONT)



30. Lower logic cage (para 4-25).
31. Slowly move carriage back and forth. If carriage moves freely, go to step 32. If you feel carriage dragging, select another mounting slot for the transducer coil and check again. Use slot which produces least drag and rubbing.



32. Slide carriage back to retracted position.
33. Replace coil cover.
34. Lower deck (para 4-12).

4-47. ADJUST VELOCITY GAIN

INITIAL SETUP

Common Tools

- Tool kit

Test, Measurement and Diagnostic Equipment

- Oscilloscope
- Field test unit (FTU)

Supplies

- Scratch pack

1. Remove cover (para 4-11).
2. Remove disk drive communication cables.

NOTE

Your field test unit (FTU) may be model TB216 or TB303. This procedure covers each model under its respective heading. Continue with step 3 under correct model heading.

MODEL TB303

3. Install FTU I/O cables (para 4-53).
4. Set FTU toggle switches as follows:

Center position


- ACC/RD/WR
- POS/NEG
- EARLY/LATE STROBE
- REV/FWD/OFF-SET

Up position

- R/W SERVO
- I/O ENABLE-DISABLE
- SEQ PWR ON/OFF

Down position

- All other switches on panel




4-47. ADJUST VELOCITY GAIN (CONT)

5. Load scratch pack.

NOTE

The LOCAL/REMOTE switch on board A10 in logic cage must be set to REMOTE for this procedure.


6. Power on disk drive.
7. Cycle up disk drive. Make sure PROTECT light is on.



8. On the FTU, push down then release RTZ.

NOTE

When there are two disk drives per channel, use step 9 for second drive. For all other disk drives, start at step 10. See your system manual to determine disk drives per channel.



9. Set AUTO FUNCT selector to SGL. Set BUS OUT switch 1 up to address second drive.
10. Set SELECT HOLD up.
11. Set START/STOP up.
12. Push down then release RTZ. Only MOD ADDR should be lit.


4-47. ADJUST VELOCITY GAIN (CONT)

13. Turn AUTO FUNCT selector to RAND.
14. Set START/STOP down, then up.

NOTE

Drive will perform random seeks. Wait 10 minutes before doing step 15 to allow the heads to stabilize. You may set up oscilloscope (step 22) while you are waiting.

15. Set START/STOP down.
16. Push down, then release RTZ.
17. Cycle down disk drive.
18. At rear of drive, set power off.
19. Raise logic cage (para 4-25).



20. Remove screws.
21. Pull off cover.
22. Set up oscilloscope:

VOLT/DIV

CH 1 - 0.2 V (use X 10 probe)  
 CH 2 - not used

TRIGGER

A - EXTERNAL POSITIVE  
 B - not used

TIME/DIV


10 ms

MODE TRIGGER

CH 1



## 4-47. ADJUST VELOCITY GAIN (CONT)



23. Locate B side of Logic cage.

## NOTE

You may have to move wire to the side in order to see row numbers.

24. Find row 9.

25. Find column A.


26. In column A, find the 3rd pin. Attach CH 1 oscilloscope probe to this pin point.

27. In column A, find the 7th pin. Attach trigger probe to this pin point.

28. At rear of drive, set power to ON.

29. Cycle up drive.

4-47. ADJUST VELOCITY GAIN (CONT)




30. On FTU, push down, then release RTZ.

31. Turn AUTO FUNCT selector to SGL.

NOTE

When there are two disk drives per channel, use step 32 for second drive. For all other disk drives, start at step 33. See your system manual to determine disk drives per channel.

32. Set BUS OUT switch 1 up to address second drive.




33. Set SELECT HOLD up.

34. Set START/STOP up.

35. Push down, then release RTZ. Only MOD ADDR light should be lit.

36. Turn AUTO FUNCT selector to CONT.

37. If up, set BUS OUT switch 1 down.




38. Set BUS OUT switches up as follows:

512, 256, 32, 16, 4 and 2. Make sure remaining BUS OUT switches are down.

39. Set START/STOP down, then up.

4-47. ADJUST VELOCITY GAIN (CONT)




40. Adjust oscilloscope trigger level until you see these pulses.

NOTE

Measurement is from trailing edge of pulse A to leading edge of pulse B.

41. Between pulses, measure full length seek time. Time between On Cylinder pulses should be 52 to 54 milliseconds.

- If it is, go to step 45
- If not, go to step 42



42. With logic cage on its side, locate board A2A07.

43. Find velocity gain potentiometer E2R6 .


44. " Using potentiometer adjustment tool , slowly turn potentiometer until time between On Cylinder pulses is 52 to 54 milliseconds.

45. On FTU, set START/STOP down. Push down, then release RTZ.

46. Cycle down drive.

47. Power off drive.

48. Remove oscilloscope probes from logic chassis.



49. Replace protective cover on underside of logic cage.

50. Replace screws.

51. Lower logic cage (para 4-25).


52. Remove FTU cables. Replace disk drive I/O cables.

53. Remove scratch pack.


54. Replace cover (para 4-11).

4-47. ADJUST VELOCITY GAIN (CONT)

MODEL TB216



3. Install and test FTU (para 4-53). Power ON FTU circuit breaker. Check that +5 and -5 indicators light.





4. In sequence, set FTU switches listed to positions shown:

<u>SWITCH</u>	<u>POSITION</u>
PROCESSOR START/RESET	RESET
PROCESSOR RUN/HALT	HALT
SINGLE/CONT	CONT
-/+ OFFSET	CENTER (OFF )
LATE/EARLY	CENTER (NORMAL)
WRT FLAG	OFF
WRT PROT	ON
AM/SECTOR	EITHER
EOT STOP	OFF
ERROR OVERRIDES:	
DATA-OFF	OFF
ADDR-OFF	OFF
SHIFT PATT/DATA PATT	DATA PATT
RD/WRT SELECT	ACCESS ONLY
ACCESS SELECT	DIRECT SEEK
PROCESSOR START/RESET	START
PROCESSOR RUN/HALT	RUN
SEQ PWR/OFF	OFF

5. Look to see that the following FTU indicators light:


ON CYCL	SEEK ERR
RDY	FLT
WT PROT	BUSY
SELD	RUN

4-47. ADJUST VELOCITY GAIN (CONT)



6. Power ON disk drive.
7. Place A10 board LOCAL/REMOTE switch in REMOTE.
8. Load scratch disk pack.
9. Place SEQ PWR/OFF switch in SEQ/PWR and cycle up disk drive.
10. Turn DATA ENTRY switch to DEVICE TYPE .
11. Enter device code 3105 at keyboard.
  - Corresponding ROW 2 indicators will light.
  - If you key incorrectly, press CLR ENT, then enter code again.
12. Press LOAD key.
  - Code will transfer to ROW 1 indicators.
  - If code does not transfer press CLR ENT, then repeat step 11.
13. Be sure that ROW 3 indicators 1/0 RDY is lit.
14. Press SEL DRV key.
15. Look to see that SELD indicator lights and that logical address for selected disk drive appears in ROW 1.
  - If SELD is flashing or incorrect logical address lights, selection was unsuccessful .
  - Press CLR and repeat from step 11.
16. Turn ACCESS SELECT switch to RANDOM SEEK.
17. Turn DATA/ENTRY switch to STATUS BYTES .
18. Press key 1.

4-47. ADJUST VELOCITY GAIN (CONT)




19. Set SINGLE/CONT switch to CONT.
20. Set EOT STOP/OFF switch to OFF.
21. Press GO key.

NOTE

Drive will perform random seeks. Wait 10 minutes before doing step 23 to allow heads to stabilize. You may set up oscilloscope (step 31) while you wait.

22. Allow drive to cycle for at least 10 minutes.
23. Press STOP key.
24. Press CLR key.
25. Press RTZ key.
26. Cycle down disk drive.
27. At rear of drive, power OFF circuit breakers.



28. Raise logic cage (para 4-25).
29. Remove screws.
30. Remove cover.
31. Set up oscilloscope. Use these settings for normal probe:


A TRIGGER	VOLTS/DIV
A +/-EXTERNAL	CH 2- 2V (X10 probes)
B not used	CH 1 - not used
TRIG MODE - NORM	Push INVERT BUTTON

TIME/DIV

HORZ DISPLAY - A LOCK KNOBS

10 ms

4-47. ADJUST VELOCITY GAIN (CONT)






32. Locate B side of logic cage.

NOTE

You may have to move wire to the side in order to see row numbers.

- 33. Find row 9.
- 34. Find column A.
- 35. In column A, find the 3rd pin. Attach CH 2 oscilloscope probe to this pin point (position B09-03A).
- 36. In column A, find 7th pin. (B09-07A). Attach trigger probe to this pin point.
- 37. At rear of drive, set power to ON.
- 38. Cycle up drive.



4-470 ADJUST VELOCITY GAIN (CONT)



39. Turn ACCESS SELECT switch to DIRECT SEEK . 0
40. Turn DATA ENTRY switch to DESTINATION.
41. Key in 0.
42. Press LOAD. Press GO.
43. Turn ACCESS SELECT to DIRECT CONT.
44. Key in 822.
45. Press LOAD key.
46. Press GO key.
47. Adjust oscilloscope trigger lever until you see these pulses.
48. Between pulses, measure full length seek time. Time between On Cylinder pulses should be 52 to 54 milliseconds.
  - If it is, go to step 52
  - If not, go to step 49
49. With logic cage on its side, locate card A2A07.
50. Find velocity gain potentiometer E2R6 .
51. Using potentiometer adjustment tool, slowly turn Potentiometer until time between On Cylinder pulses is 52 to 54 milliseconds.



## 4-47. ADJUST VELOCITY GAIN (CONT)



52. Press STOP key.
53. Press CLR key, then RTZ key.
54. Cycle down drive. Unload disk pack.
55. Power OFF drive.
56. Power OFF oscilloscope. Remove and stow test leads.

57. Replace logic cage bottom cover.
58. Replace screws.
59. Lower logic cage (para 4-25). On board A10, set LOCAL/REMOTE switch to LOCAL.
60. Power OFF FTU.
61. Remove and stow FTU cables.
62. Stow FTU.
63. Reconnect disk drive cables at rear of logic cage.
64. Replace disk drive cover (4-11).

4-48. MANUALLY POSITION CARRIAGE COIL

INITIAL SETUP



Supplies

- Scratch pack

NOTE

Certain troubleshooting tests require moving carriage coil assembly by hand. Do this only when a specific test directs you to.


1. Remove cover for maintenance (para 4-11).
2. Load scratch pack.
3. Pull connector PA from power supply board.



## 4-48. MANUALLY POSITION CARRIAGE COIL (CONT)



5. Make sure carriage coil is in retracted position as shown.




6. From rear of drive, set ac power to ON. Power ON drive.
7. Cycle up drive. Wait 30 seconds for drive motor to come up to speed.

CAUTION

Heads damage easily. Use extreme care when moving carriage coil.

- a. Move coil at about same speed it moves under drive control.
- b. Do not push down on carriage.
- c. Do not allow coil to contact FORWARD STOP when moving forward.

4-48. MANUALLY POSITION CARRIAGE COIL (CONT)



8. Carefully press coil as shown. Move coil forward about 2 inches. It should release and move back and forth freely.

9. Push coil back as shown.

NOTE

Move carriage coil back and forth as required until test is completed.



10. After you complete test, push coil back to retracted position.

11. Cycle down drive.

12. Power OFF drive.

13. Unload scratch pack.


14. Push connector PA on power supply board.




15. Push on coil cover.

16. Replace cover (para 4-11).


## 4-49. REMOVE/REPLACE CONTROL PANEL

Remove

1. Raise deck (para 4-12).
2. Pull connector P201 from control panel.




3. Press in on each side of panel to release tabs. Gently push panel forward.



4. Pull panel out of mounting cutout as shown.

4-49. REMOVE/REPLACE CONTROL PANEL (CONT)

Replace




1. Insert control panel into mounting cutout as shown. Press panel to lock in place.

2. Push connector P201 on control panel.
3. Lower deck (para 4-12).


## 4-50. REMOVE/REPLACE PACK COVER INTERLOCK SWITCH

## INITIAL SETUP

Common Tools  
I Tool kit



Remove

1. Raise deck (para 4-12).
2. Find the deck interlock switch.
3. Note position and disconnect wires. Raise pack access cover.



4. Remove screws holding deck interlock switch to deck.
5. Pull out deck interlock switch.

4-50. REMOVE/REPLACE PACK COVER INTERLOCK SWITCH (CONT)



Replace

1. Mount switch into position.
2. Replace screws holding switch on deck assembly.

3. Replace wires.
4. Close pack access cover.
5. Lower deck (para 4-12).




## 4-51. REMOVE/REPLACE ABSOLUTE FILTER


## INITIAL SETUP

Common Tools

- Tool kit


Remove

1. Raise deck (para 4-12).
2. Remove bracket screw and washer.




3. To remove bracket, pivot it toward front of drive until bracket end lifts out of slot.

4-51. REMOVE/REPLACE ABSOLUTE FILTER (CONT)




4. Slide filter out.

Repl ace



1. Slide filter in.



2. Insert bracket in slot, then position it.

3. Replace bracket screw and washer.

4. Lower deck (para 4-12).

## 4-52. REMOVE/REPLACE/ADJUST PACK COVER SOLENOID

## INITIAL SETUP

## Common Tools


- Tool kit

## Materials/Spare parts

- Tags
- Pen or pencil


## NOTE

The pack cover solenoid is an optional item which may be installed on some disk drives. Its purpose is to lock pack access cover for 30 seconds after spindle motor is shut off or when power is off to drive. It is basically a safety device. Use this procedure to remove/replace/adjust the pack cover solenoid.

Remove

1. Raise deck (para 4-12).
2. Find solenoid.
3. Remove two screws holding solenoid to mounting bracket.
4. Tag and remove wires from solenoid.
5. Carefully work solenoid away from interlock latch.

4-52. REMOVE/REPLACE/ADJUST PACK COVER SOLENOID (CONT)




Replace

1. Carefully work solenoid into interlock latch.
2. Align holes in solenoid with holes in mounting bracket.
3. Install and hand tighten screws.
4. Push on wires.
5. Adjust solenoid position. (Go to Adjust. )

Adjust




NOTE

The pack cover solenoid adjustment is required whenever the solenoid is changed or if the pack access cover does not lock when power is removed from drive.



1. Slip a 0.035 inch feeler gauge between the pack cover latch and the solenoid latch.
2. Tighten screws to solenoid.
3. Test adjustment by trying to open pack cover with power off.  
 | If it opens, repeat steps 1-3  
 | If it does not open, go to step 4
4. Lower deck (para 4-12).

4-53. INSTALL/TEST FIELD TEST UNIT




NOTE

Your field test unit (FTU) may be model TB216 or TB303. This procedure covers each model under its respective heading.

MODEL TB216


1. Open FTU carrying case, release catch on left side of chassis, raise front panel and lock in place.
2. Connect power cord to FTU and ac power outlet.
3. Set circuit breaker ON. +5 and -5 LED indicators should be lit.
4. Set ACCESS SELECT switch to LAMP TEST position.
5. Set PROCESSOR switches to START and RUN positions. All LED indicators in row 3 will light except for I/O RDY and UNIT RUN.
6. Press GO key. All LED indicators should blink and continue to blink except for PROCESSOR LEDs which should stay lit. If any LED does not light, the FTU is not working properly.
7. Press STOP key and PROCESSOR switches to RESET and HALT position.

4-53. INSTALL/TEST FIELD TEST UNIT (CONT)



8. Set following switches:

<u>SWITCH</u>	<u>POSITION</u>
ACCESS SELECT	SELF TEST
ERROR OVERRIDE	OFF
DATA/OFF	OFF
ADDR/OFF	OFF
DATA ENTRY	DEVICE TYPE
RD/WRT SELECT	WRT FORMAT
HEAD SEQ	SEQ
RECORD	SEQ
SINGLE/CONT	CONT
-/+ OFFSET	CENTER (OFF )
EARLY/LATE	CENTER (OFF )
WRT FLAG	OFF
WRT PROT	ON
AM/SECTOR	SECTOR
EOT STOP	OFF
SHIFT PATT	DATA PATT
SEQ PWR	OFF



9. Set processor START and RUN switches to START and RUN position.

10. Press GO key. If LED indicators RUN, +5, -5, RD and in row 2, 29 and 211 are all lit, FTU is operating properly. If any of these do not light, FTU is not working properly.


11. Test all keys and switches. Each should show a lit LED when pressed.

NOTE


Rows 1 and 3 LEDs do not light during this test.

12. Set PROCESSOR switches START and RUN to RESET and HALT positions.

4-53. INSTALL/TEST FIELD TEST UNIT (CONT)



13. Set FTU circuit breaker OFF.




14. Connect FTU cable assemblies A2, A4, B5 and A8 cable assembly.

NOTE


All cable assemblies are keyed and have a colored orientation strip on right hand side of cable.

15. Disconnect top disk drive cable assemblies at rear of logic cage assembly.

16. Plug cable assemblies A8 and B5 to connector at rear of logic cage assembly. Check pin location and orientation (colored orientation strip is pin 1) to make sure cable assemblies are properly connected.




4-53. INSTALL/TEST FIELD TEST UNIT (CONT)




MODEL TB303

1. Open FTU carrying case.
2. Loosen tie-down screws. Raise front panel and lock in place.



3. Plug in ac power cord.
4. Check FAULT indicator:
  - If lit, push down RTZ switch. If FAULT indicator stays lit, the FTU is defective.
  - If not lit, FTU is okay.



5. Install FTU cables to disk drive.
  - If you will align heads, install head alignment board in slot A02 and I/O cable.
  - If you will adjust drive, install I/O cable only.



## 4-54. REMOVE/REPLACE SPINDLE LOCKSHAFT


## INITIAL SETUP

## Common Tools

- Tool kit

## Materials/Spare parts

- Screw-thread locking compound

Remove

1. Remove static ground spring (para 4-37).
2. Using two screw drivers, pry shaft end seal from shaft.
3. Reach in from bottom of spindle and remove shoulder screw, washers and spring. Lock spindle by pressing end of brake plate.
4. Lift lockshaft out from top of spindle.

## NOTE

If smaller compression spring came out of spindle with lockshaft, retain it for use on new lockshaft.

4-54. REMOVE/REPLACE SPINDLE LOCKSHAFT (CONT)

Replace

NOTE


If smaller compression spring came out with old lockshaft, you must assemble it on new lockshaft before replacement.

1. Slide lockshaft in from top of spindle.
2. Place two washers and larger compression spring on screw as shown.

CAUTION

Do not apply any screw-thread locking compound to spring or washers.

3. Apply thin coat of screw-thread locking compound to last four threads of screw.
4. Install screw into bottom of lockshaft and tighten to a torque of  $40 \pm 5$  lb/in.
5. Press shaft end seal into position on bottom of spindle.
6. Allow screw-thread locking compound to cure for at least three hours.
7. Replace static ground spring (para 4-37).



4-55. REMOVE/REPLACE/ADJUST SPINDLE ASSEMBLY

INITIAL SETUP

Common Tools

- Tool kit


Special Tools

- Spindle alignment kit


CAUTION

When spindle assembly is removed from drive or shipping container, do not allow it to rest on pulley end of assembly. When it must be set down, lay it on its side or on spindle face plate. Improper handling of spindle assembly may cause damage to spindle bearings which could result in premature failure of spindle or even damage to disks and heads.

Remove



1. Raise deck (para 4-12).
2. Remove screw and lockwashers securing ground cable to static ground spring block.
3. Remove drive belt (para 4-33, Remove, steps 2-5).
4. Lower deck (para 4-12, Lower, steps 1-4).
5. Rotate spindle to align holes in top of spindle with mounting hardware.
6. Remove screws and lockwashers securing spindle assembly to deck.




CAUTION


Take care not to damage static ground spring when removing spindle assembly.

7. Lift spindle assembly from deck.


4-55 REMOVE/REPLACE/ADJUST SPINDLE ASSEMBLY (CONT)




8. Remove screws and washers securing static ground block to spindle assembly, and remove static ground spring assembly.



REPLACE



1. Install static ground spring assembly on spindle assembly, and secure in place with screw and washers.



2. Lower spindle assembly through deck opening in shroud, passing static ground spring through slot.

3. Orient spindle assembly so that static ground spring block faces drive motor.

4. Using screws without lockwashers, secure spindle assembly to deck. Turn screws in fully, but do not tighten.

5. Raise deck (para 4-12, Raise, steps 8-10).


6. Replace ground cable on static ground spring block, and secure in place with screw and washers.

7. Replace drive belt (para 4-33. Replace, steps 1-4).

4-55. REMOVE/REPLACE/ADJUST SPINDLE ASSEMBLY (CONT)

Adjust

1. Remove head arm number 3, second from bottom (para 4-29).
2. Install spindle alignment tool in slot on carriage from which head arm number 3 was removed.
3. Secure alignment tool to carriage with screw; using torque screwdriver, tighten to a torque of  $4 \pm 1/2$  inch pounds.



CAUTION

When extending carriage, move it slowly to avoid damage to heads.

4. Extend carriage to position alignment tool as shown.

NOTE

Two feeler gauges are provided. One gauge is 0.002 inch and the other is 0.004 inch. Use each as required to adjust the spindle.


5. Insert either feeler gauge between alignment arm and spindle as shown.
6. Check if dimension between alignment arm and spindle is not less than 0.002 or not more than 0.004 each.

- If it is, go to step 15
- If adjustment is required, go to step 7

NOTE

If screws were previously replaced without lockwashers, go to step 11.


7. Retract carriage sufficiently to align holes in spindle with mounting screws.
8. Remove screws and lockwashers securing spindle to deck.
9. Replace screws without lockwashers and tighten screws slightly.



## 4-55. REMOVE/REPLACE/ADJUST SPINDLE ASSEMBLY (CONT)

CAUTION

When extending carriage, move slowly to avoid damage to heads.



10. Extend carriage to position alignment tool as shown. Check alignment with feeler gauge to determine degree of adjustment necessary.
11. Using end of hammer handle, gently tap spindle until dimension between alignment tool and spindle meets the  $0.003 \pm 0.001$  specification (step 6).
12. Tighten one screw at a time and check dimension between alignment tool and spindle after tightening each screw.
13. Remove first screw tightened and replace washer. Replace screw and washer in spindle, tighten it, and recheck dimensional specification after tightening.
14. Repeat procedure in step 13 for second and third screws.
15. Remove screw securing alignment tool (step 3); remove alignment tool.
16. Replace head arm number 3 (para. 4-29, Replace, steps 1-4).
17. Adjust static ground spring (para. 4-38).
18. Check and adjust speed transducer (para 4-45, steps 2-10).

## 4-55. REMOVE/REPLACE/ADJUST SPINDLE ASSEMBLY (CONT)

19. Check and align head number 3 (para. 4-30).
  - If using FTU TB 303 do steps 3 thru 56 (Check) and steps 1 thru 27 (Align)
  - If using FTU TB 216 do steps 3 thru 61 (Check) and 63 thru 65 (Align)
20. Replace bracket (para. 4-29, Replace, steps 6-9)





## APPENDIX A

### REFERENCES

#### A-1. INTRODUCTION

This appendix lists all forms, field manuals and technical manuals referenced in, or required for use with, this technical manual.

#### A-2. FORMS

Equipment Inspection and Maintenance Worksheet . . . . .	DA Form 2404
Quality Deficiency Report . . . . .	Form SF 368
Discrepancy in Shipment Report . . . . .	Form SF 364
Recommended Changes to Equipment Technical Manuals . . . . .	DA Form 2028-2
Recommended Changes to Publications and Blank Forms . . . . .	DA Form 2028
Maintenance Request . . . . .	DA Form 2407

#### A-3. TECHNICAL MANUALS

Operator's Manual: Disk Memory Unit MU-705/MYQ-4 . . . . .	TM 11-7025-208-10"
Procedures for Destruction of Electronic Material to Prevent Enemy Use (Electronics Command) . . . . .	TM 750-244-2
The Army Maintenance Management System (TAMMS) . . . . .	TM 38-750
Administrative Storage of Equipment . . . . .	TM 740-90-1

#### A-4. MISCELLANEOUS PUBLICATIONS

Consolidated Index of Army Publications and Blank Forms . . . . .	DA PAM 310-1
---	--------------



# APPENDIX B

## MAINTENANCE ALLOCATION CHART

### Section 1. INTRODUCTION

#### B-1. GENERAL

This Maintenance Allocation Chart (MAC) provides a summary of maintenance operations for the disk drive. This document assigns categories of maintenance for specific maintenance functions on repairable items and identifies tools and equipment required to perform each function. Each maintenance function is assigned to the lowest level of maintenance prepared to perform that function for the disk drive. It should be understood that each maintenance function can also be performed at all higher levels of maintenance. The higher levels of maintenance will have tools and test equipment to perform the maintenance functions assigned to and normally performed by lower levels of maintenance.

The following paragraphs of Section I present maintenance function definitions, explanation of MAC column entries, and explanation of column entries of the tool and test equipment requirements section. Section 11 presents the MAC for the disk drive and Section III presents the tool and test equipment requirements.

#### B-2. MAINTENANCE FUNCTION DEFINITIONS.

Maintenance Functions are limited to and defined as follows:

a. Inspect. Determination of the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination.

b. Test. Verification of serviceability and detection of beginning failure by measuring the mechanical or electrical characteristics of an item and comparing those characteristics with prescribed standards.

c. Service. Performance of operations required periodically to keep an item in proper operating condition. Such operations would include cleaning, preservation, draining, painting, or replenishment of fuel/lubricants/hydraulic fluids or compressed air supplies.

d. Adjust. Maintenance within prescribed limits by bringing into proper or exact position, or by setting the operating characteristics to the specified parameters.

e. Align. Adjustment of specified variable elements of an item to the maximum or desired performance.

f. Calibrate. Determination and cause corrections to or adjustments to instruments or test measuring and diagnostic equipment used in precision measurement. Consists of comparing two instruments, one a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

g. Install. Emplacement, seating, or fixing into position an item, part, or module (component or assembly) in a manner to allow proper functioning of the equipment/system.

h. Replace. Substitution of a serviceable like-type part, subassembly, or module (component or assembly) for an unserviceable counterpart.

i. Repair. Application of maintenance services (inspect, test, service, adjust, align, calibrate, replace) or other maintenance actions (welding, grinding, riveting, straightening, facing, remachining, or resurfacing) to restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module/component/assembly, and item or system. This function does not include trial and error replacement of consumable spare type items such as fuses, lamps, or electronic tubes.

j. Overhaul. Periodic maintenance effort (service/action) necessary to restore an item to a completely serviceable/operational condition as prescribed by maintenance standards (e.g., DWR) in appropriate technical publications. Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like-new condition.

k. Rebuild. Restoration of unserviceable equipment to a like-new condition in accordance with original manufacturing standards. Rebuild is the highest degree of material maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hour, miles etc.) considered in classifying Army equipment/components.

B-3. EXPLANATION OF MAC COLUMN ENTRIES.

a. Group Number. This column lists group numbers, the purpose of which is to identify components, assemblies, subassemblies and modules with the next highest assembly.

b. Component/Assembly. This column contains the noun names of components, assemblies, subassemblies, and modules for which maintenance is authorized.

c. Maintenance Function. This column lists the functions to be performed on the item listed in the Component/Assembly column.

d. Maintenance Category. This column specifies, by the listing of a "worktime" figure in the appropriate subcolumn(s), the lowest level of maintenance authorized to perform the function listed in the Maintenance Function column. This figure represents the active time required to perform that maintenance function at the indicated category of maintenance. If the number or complexity of the tasks within the listed maintenance function varies at different maintenance categories, appropriate "worktime" figures will be shown for each category. The number of man-hours specified by the "worktime" figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time, troubleshooting time, and quality assurance/quality control time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the MAC.

Subcolumns of the Maintenance category Column are:

- C -- Operation/Crew
- O -- Organizational
- F -- Direct Support
- H -- General Support
- D -- Depot

e. Tools and Equipment. This column specifies by code those common tool sets (not individual tools) and special tools, test, and supporting equipment required to perform the designated function.

Explanation of Column Entries of Tool and Test Equipment Requirements Table.

a. Tool or Test Equipment Reference Code. The numbers in this column coincide with the numbers used in the tools and equipment column of the MAC. The numbers indicate the applicable tool or test equipment for the maintenance functions.

b. Maintenance Category. The codes in this column indicate the maintenance category allocated the tool or test equipment.

c. Nomenclature. This column lists the noun name and nomenclature of tools and test equipment required to perform the maintenance functions.

d. National/NATO Stock Number. This column presents the National/NATO Stock number of the specific tool or test equipment when these numbers are assigned.

e. Tool Number. This column lists the manufacturer's part number of the tool, followed by the Federal supply code for the manufacturer (5 digit) in parentheses, when these numbers are fully identified.

SECTION II MAINTENANCE ALLOCATION CHART  
FOR DISK MEMORY UNIT MU-705/MYQ-4

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) TOOLS AND EQUIP.	(6) REMARKS
			C	O	F	H	D		
02	Disk Memory Unit (MU-705/MYQ-4)	Service		1.5				1, 15, 16, 18, 21	F
		Test			0.2			1, 2, 4, 5, 6, 7, 10	
		Replace			0.5			1, 3, 4, 5, 6, 7, 10, 17	
		Repair			0.7			1, 3, 4, 5, 6, 7, 8, 9, 10, 19, 20, 22	
		Overhaul					80.0		A
0201	Base Assy. (A1XX)	Test			0.2			4, 5	
		Repair			0.3			1, 5, 10, 200	
020101	Power Supply PWB (AXKV)	Test			0.2			4, 5	
		Adjust			0.2			1, 5, 10	
		Replace			0.3			1	
		Repair					0.8		A
0202	Logic Chassis Assy. (A2XX)	Test			0.2			4, 5, 6, 7, 10	
		Repair			0.1			1, 6	
020201	Circuit Card Assy. Write Clock (CLSV)	Test			0.2			4, 5, 6, 7, 10	
		Replace Repair			0.1		0.3	1, 5	A
020202	Circuit Card Assy. Fine Servo Decoder (HFRV)	Test			0.2			4, 5, 6, 7	
		Replace			0.1			1, 6	
		Repair					0.3		A
020203	Circuit Card Assy. Fault Card (HKFV)	Test			0.2			4, 5, 6, 7	
		Replace			0.1				
		Repair					0.3		A
020204	Circuit Card Assy. Read PLO (BLZV)	Test			0.2			4, 5, 6, 7	
		Replace			0.1			1, 6	
		Repair					0.3		A
020205	Circuit Card Assy. Data Latch (KLRV)	Test			0.2			4, 5, 6, 7	
		Replace			0.1			1, 6	
		Repair					0.1		A
020206	Circuit Card Assy. D/A Functional Generator (JLQV)	Test			0.2			4, 5, 6, 7	
		Adjust			0.5			1, 4, 6, 10	
		Replace			0.7			1, 6	
		Repair					0.8		A

SECTION II MAINTENANCE ALLOCATION CHART  
FOR DISK MEMORY UNIT MU-705/MYQ-4

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) TOOLS AND EQUIP.	(6) REMARKS	
			C	O	F	H	D			
020207	Circuit Card Assy. Access Control #2 (ELUV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020208	Circuit Card Assy. Swi tchi ng Mode Con- trol (FLPV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020209	Circuit Card Assy. Interlocks and Speed Detector (6SGV)	Test Repl ace Repai r			0.1 0.2			0.3	4, 5, 6, 7 1, 6	A
020210	Circuit Card Assy. Transmitter (BTHV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020211	Circuit Card Assy. Recei ver (BRSV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020212	Circuit Card Assy. Bus-In-Mul ti pl exer (6SNV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020213	Circuit Card Assy. DIFF Generator and Controls (FLWV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020214	Circuit Card Assy. NRZ to Compensated MFM PWB (ELXV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020215	Circuit Card Assy. Access Control and Index/Spector Decode (ELTV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020216	Circuit Card Assy. Access Control #1 (PLW)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020217	Circuit Card Assy. Bus-In & RPS (6SLV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A
020218	Circuit Card Assy. Comp. Assy. (AXYV)	Test Repl ace Repai r			0.2 0.1			0.3	4, 5, 6, 7 1, 6	A

SECTION II MAINTENANCE ALLOCATION CHART  
FOR DISK MEMORY UNIT MU-705/MYQ-4

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY					(5) TOOLS AND EQUIP.	(6) REMARKS	
			C	O	F	H	D			
020219	Logic Chassis W/ Backplane	Test Replace Repair			1.0 1.0			3.0	1, 2, 10 1	A
0203	Deck Assy. (A3XX)	Test Adjust Repair			0.2 0.2 0.5				4, 5, 8, 10 8, 9, 10 1, 8, 9, 11	
020301	Circuit Card Assy. Writer (EZKN)	Test Replace Repair			0.2 0.5			0.3	4, 5 1	A
020302	Circuit Card Assy. Head Select & Read Amplifier (NZJN)	Test Replace Repair			0.2 0.1			0.3	4, 5 1	A
020303	Amplifier Power Bd. (5VTN)	Test Replace Repair			0.2 0.5			0.3	4, 5 1	A
020304	Circuit Card Assy. Pre-Amp, Track Servo (EZON)	Test Replace Repair			0.2 0.5			0.3	4, 5 1	A
020305	Coil Carriage	Test Replace Repair			0.3 3.0			2.0	4, 10 1, 5, 8, 9, 10, 11	A A
		Align Repair						2.0 2.0		A A
020306	Spindle, Wheel	Test Replace Repair Repair Align			1.0 2.0 3.0 2.0			2.0	1, 12 1, 13 1, 12	A
0204	Cable Assy.	Replace Repair			0.1			0.3	1	A
0205	Cable Assy.	Replace Repair			0.1			0.3	1	A
0206	Cable Assy.	Replace Repair			0.1			0.3	1	A



SECTION III TOOL AND TEST EQUIPMENT REQUIREMENTS  
FOR DISK MEMORY UNIT MU-705/MYQ-4

TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
1	O, F	Tool Kit Electronic Equipment TK17	5180-01-023-4982	
2	O, F	T & V Pack (Standard Part of DAS3 System)	TBD	HIS SHU 152J (33322)
3	F	Decimal Socket Set	5120-00-247-0748	
4	F	Oscilloscope, OS-261/C	6625-00-127-0079	
5	F	Multimeter, Digital AN/USM-451	6625-01-060-6804	
6	F	MSU Card Extraction Tool	7010-01-101-6680	
7	F	MSU Card Extender	7010-01-101-6679	
8	F	MSU Head Alignment Pack	7010-01-101-6681	
9	F	MSU Head Adjustment Tool	5120-01-059-6860	
10	F	MSU Field Test Unit, TB216A	7010-01-103-7623	
11	F	MSU Torque Screwdriver Kit	5180-01-007-8999	
12	F	Alignment Tool	TBD	MPI 75018400 (33322)
13	F	Hex Key Allen Set - Decimal	5120-00-529-1475	
14	F	Shim Stock, Plastic	TBD	PSS5A (07631)
15	F	Magnetic Pickup	5120-00-545-4268	
16	F	Mirror, Ball Joint	5120-00-448-2455	
17	F	Screwdriver, Stubby, Phillips		HIS 97017133-001 (33322)
18	F	Vacuum Cleaner	TBD	S1015030W (29335)
19	F	Phillips Screwdriver, No. 1x10"	5120-00-580-2361	
20	F	Phillips Screwdriver, Offset	5120-00-256-9014	

SECTION III TOOL AND TEST EQUIPMENT REQUIREMENTS  
FOR DISK MEMORY UNIT MU-705/MYQ-4

TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
21	F	Lubri cant	TBD	TBD
22	F	Shi m Stock, Pl asti c		PSS5A (07631)

SECTION IV MAINTENANCE ALLOCATION CHART  
FOR DISK MEMORY UNIT MU-705/MYQ-4

---

Reference Code	Remarks
A.	Repair by contractor.
B.	DS repair of 0107 Power Supply limited to replacement of fan aria/or fuses.
C.	DS repair of 0125 Power Distribution Unit limited to replacement of fuses.
D.	DS repair of 070501 XPS/4 Board limited to replacement of fuses.
E.	DS repair of 0706 Universal Wire Harness limited to replacement of connectors and limit switch.
F.	See Technical System Manual for Complete Group Coding.

---



# APPENDIX C

## EXPENDABLE SUPPLIES AND MATERIALS LIST

### Section 1. INTRODUCTION

#### C-1. SCOPE

This appendix lists expendable supplies and materials you are authorized for the support of DAS3.

#### C-2. GENERAL

This list identifies items that do not have to accompany DAS3 and that do not have to be turned in with it.

#### C-3. EXPLANATION OF LISTING

National stock numbers, descriptions, and quantities are provided to help you identify and request the additional items you require to support this equipment.

### Section II. EXPENDABLE SUPPLIES AND MATERIALS

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
		7530-00-285-5836	Paper, Writing UU-P-121	PG
		7510-00-281-5254	Pencil, General Writing SS-P-166	DZ
		7520-00-904-1265	Marker, Tube Type, Fine Tip	DZ
		8030-00-058-5398	Sealing Compound (Loctite) MIL-S-22473	EA
		8035-00-222-2423	Cloth, Lintfree	YD
		6810-00-753-4993	Alcohol, Isopropyl 81348 TTI-735	CN
		6515-00-303-8250	Dielectric Grease Applicator, Disposable 81348 GG-A-616	PG
		7510-00-551-9823	Tape, Transparent 3" Core	RO
		6850-00-105-3084	Trichlorotrifluoroethane Freon TF	CN



# APPENDIX D

## SCHEMATIC DIAGRAMS

### Index of Diagrams

Figure No.	Title
D-1	Site Power Circuit
D-2	Emergency Retract Circuit
F0-1	AC Power System
F0-2	Power Supply (2 sheets)
F0-3	Plus and Minus 5 V Power Supply (2 sheets)
F0-4	Track Servo Preamp Circuit
F0-5	Power Amplifier Circuit
F0-6	Cycle Up Diagram
F0-7	Cycle Up Seek Error Diagram
F0-8	Normal Seek Function Diagram
F0-9	Disk Drive Data Flow Diagram

#### D-1. GENERAL

Appendix D illustrates the power circuits required to operate the disk drive. Other special circuits and functional diagrams are also included. This information will be helpful if the troubleshooting procedures within this manual fail to help you isolate a fault. You can use common test procedures to check the circuits.

#### D-2. DIAGRAMS

Figures D-1 and F0-1 illustrate the input power requirements and the ac power system. Figures F0-2 and F0-3 illustrate the dc power requirements which supply the voltages necessary for operation of the logic boards. Figures F0-4 and F0-5 illustrate special functional circuits.

Figure F0-6 is used for alternate troubleshooting of cycle up faults. Figure F0-7 is used for alternate troubleshooting of initial seek errors. Figure F0-8 is used for alternate troubleshooting of such errors which occur during operation.

Figure F0-9 is used for alternate troubleshooting when there is a data transfer fault.




Figure D-1. Site Power Circuit






Figure D-2. Emergency Retract Circuit



## GLOSSARY

**ANALOG SIGNALS.** A continuous electrical signal that varies in frequency or amplitude in relation to a digital input.

**BACKPLANE (Backpanel).** An assembly used to join several circuit boards or mother boards into a working unit.

**CLOCK CIRCUITS.** Generate clock signals to control the clock related processing tasks.

**CENTRAL PROCESSOR UNIT.** Transmits data and control signals to other units.

**DIBIT.** A group of two bits. In four phase modulation each dibit is encoded as one of four unique carrier phase shifts.

**DISK.** A generic name for mass storage devices such as diskette, cartridge disk or storage module.

**END OF TRAVEL.** Heads move over a disk surface between two borders. The outermost border is called the end of travel.

**FEEDBACK SIGNAL.** A signal which returns a portion of the output to its input circuit.

**INPUT/OUTPUT SIGNALS.** Signals transmitted from the CPU which control input or output data.

**MOTHER BOARD.** An assembly used to join several logic boards into one working component.

**READ/WRITE HEAD.** Electromagnetic devices which perform read/write functions.

**SERVO HEAD.** Electromagnetic device which provides positioning data for read/write functions.



# INDEX

SUBJECT	A	PARAGRAPH
Abbreviations, List of . . . . .		1-9
Absolute Filter, Remove/Replace . . . . .		4-51
AC Transformer, Remove/Replace . . . . .		4-15
AC or DC Circuit Breaker, Remove/Replace . . . . .		4-23
Adjust		
Drive Belt . . . . .		4-34
Plus/Minus 5 Volts . . . . .		4-19
Static Ground Spring . . . . .		4-38
Velocity Gain . . . . .		4-47
Administrative Storage . . . . .		1-5
Alternative Troubleshooting Techniques . . . . .		4-6
Army Electronic Materiel, Destruction of . . . . .		1-4
 B		
Backplane, Remove/Replace . . . . .		4-27
Blower Motor, Remove/Replace . . . . .		4-13
Blower or Transformer Tuning Capacitor, Remove/Replace . . . . .		4-21
Brake Assembly, Remove/Replace . . . . .		4-40
 C		
Capabilities, Equipment . . . . .		1-11
Carriage Coil, Manually Position . . . . .		4-48
Check		
Control Panel, Remove/Replace . . . . .		4-49
Cover for Maintenance, Remove/Replace . . . . .		4-11
Checking Unpacked Equipment . . . . .		<b>3-5</b>
Common Tools and Equipment . . . . .	3-1,	4-1
Check/Align Read/Write Heads . . . . .		4-30
Check and Adjust Speed Transducer . . . . .		4-45
Clean Heads . . . . .		4-32
 D		
Data, Equipment . . . . .		1-15
Deck Interlock Switch, Remove/Replace . . . . .		4-17
Description, Functional . . . . .		2-2
Destruction of-Army Electronic Materiel . . . . .		1-4
Detection Fault . . . . .		2-12
Differences Between Disk Drive Models . . . . .		1-14
Drive Belt, Adjust . . . . .		4-34
Drive Belt, Remove/Replace . . . . .		4-33
Drive Motor Capacitor, Remove/Replace . . . . .		4-36

SUBJECT	E	PARAGRAPH
Electromechanical, Functions . . . . .		2-4
Elapsed Time Meter, Remove/Replace . . . . .		4-22
Equipment		
Common Tools and . . . . .		3-1, 4-1
Data . . . . .		1-15
Identification Plate . . . . .		1-13
Handling Precautions . . . . .		4-10
Purpose, Capabilities and Features . . . . .		1-11
F		
Fault Detection . . . . .		2-10
Features, Equipment . . . . .		1-11
Field Test Unit, Install . . . . .		4-53
Forms, Maintenance. . . . .		1-3
Functional Description . . . . .		2-2
Functions, Electromechanical . . . . .		2-4
Functions, Interface . . . . .		2-5
Functions, Machine Clock . . . . .		2-9
Functions, Power Systems . . . . .		2-3
Functions, Read/Write . . . . .		2-11
Functions, Seek . . . . .		2-7
G		
Glossary. . . . .		1-10
H		
Head Operation. . . . .		2-10
Heads Loads Switch, Remove/Replace/Adjust . . . . .		4-28
I		
Identification Plate, Equipment . . . . .		1-13
Index of Publications . . . . .		1-2
Information, Reference . . . . .		1-7
Interface, Functions . . . . .		1-5
Install Fieldtest Unit. . . . .		4-53
L		
Line Filter, Remove/Replace . . . . .		4-24
List of Abbreviations . . . . .		1-9
List, Nomenclature Cross Reference . . . . .		1-8
Location and Description of Major Components . . . . .		1-12
Logic Cage Boards, Remove/Replace . . . . .		4-26

SUBJECT	M	PARAGRAPH
Machine Clock Functions . . . . .		2-9
Maintenance		
Forms, Records and Reports. . . . .		1-3
Procedures . . . . .		4-9
Major Components, Location and Description of . . . . .		1-12
Manually Position Carriage Coil . . . . .		4-48
	N	
Nomenclature Cross Reference List . . . . .		1-8
	O	
Operation, Head . . . . .		2-10
	P	
Pack Cover Interlock Switch, Remove/Replace . . . . .		4-50
Pack Cover Solenoid, Remove/Replace/Adjust . . . . .		4-52
Plus/Minus 5 Volts, Adjust . . . . .		4-19
PMCS Procedures . . . . .		3-7
Power Amplifier Assembly, Remove/Replace . . . . .		4-43
Power Supply Assembly, Remove/Replace . . . . .		4-18
Power System Functions . . . . .		2-3
Precautions, Equipment Handling . . . . .		4-9
Procedures		
Alternative Troubleshooting . . . . .		4-6
Maintenance. . . . .		4-9
PMCS . . . . .		3-7
Troubleshooting . . . . .		4-7
	R	
Raise/Lower Deck for Maintenance . . . . .		4-12
Raise/Lower Logic Cage for Maintenance . . . . .		4-25
Read/Write Board Assembly, Remove/Replace . . . . .		4-41
Read/Write Functions . . . . .		2-11
Read/Write Heads, Check/Align . . . . .		4-30
Read/Write Heads, Remove/Replace . . . . .		4-29
Records, Maintenance . . . . .		1-3
Reference Information . . . . .		1-7
Remove/Replace		
Absolute Filter . . . . .		4-51
AC or DC Circuit Breaker . . . . .		4-23
AC Transformer . . . . .		4-15
Backplane. . . . .		4-27
Blower Motor . . . . .		4-13
Blower or Transformer Tuning Capacitor . . . . .		4-21
Brake Assembly . . . . .		4-40
Control Panel . . . . .		4-49
Cover for Maintenance . . . . .		4-11
Deck Interlock Switch . . . . .		4-17
Drive Belt . . . . .		4-33

SUBJECT	R (CONT)	PARAGRAPH
Drive Motor Capacitor . . . . .		4-36
Elapsed Time Meter . . . . .		4-22
Interlock Switch . . . . .		4-17
Line Filter . . . . .		4-24
Logic Cage Boards . . . . .		4-26
Pack Cover Interlock Switch . . . . .		4-50
Pack Cover Solenoid . . . . .		4-52
Power Amplifier Assembly . . . . .		4-43
Power Supply Assembly . . . . .		4-18
Read/Write Board Assembly . . . . .		4-41
Read/Write Heads . . . . .		4-29
Run Triac . . . . .		4-16
Servo Head . . . . .		4-31
Servo Starting Capacitors . . . . .		4-20
Solid State Switch (Start Triac) . . . . .		4-35
Speed Transducer . . . . .		4-44
Spindle Motor . . . . .		4-39
Spindle Lockshaft . . . . .		4-54
Static Ground Spring . . . . .		4-37
Terminal Board . . . . .		4-14
Track Servo Preamp . . . . .		4-42
Velocity Transducer . . . . .		4-46
Remove/Replace/Adjust Heads Loads Switch . . . . .		4-28
Remove/Replace/Adjust Pack Cover Solenoid . . . . .		4-52
Remove/Replace/Adjust Spindle Assembly . . . . .		4-55
Repair Parts, Spares and . . . . .	3-3,	4-3
Reporting Equipment Improvement Recommendations (EIR) . . . . .		1-6
Reports, Maintenance . . . . .		1-3
Run Triac, Remove/Replace. . . . .		4-16
S		
Seek, Functions . . . . .		2-6
Servo Head, Remove/Replace . . . . .		4-31
Servo Starting Capacitor, Remove/Replace . . . . .		4-20
Solenoid, Remove/Replace/Adjust pack Cover . . . . .		4-52
Solid State Switch (Start Triac), Remove/Replace . . . . .		4-35
Spares and Repair Parts. . . . .	3-3,	4-3
Special Tools, TMDE and Support Equipment . . . . .	3-2,	4-2
Speed Transducer, Check and Adjust . . . . .		4-45
Speed Transducer, Remove/Replace . . . . .		4-44
Spindle Assembly, Remove/Replace/Adjust . . . . .		4-55
Spindle Motor, Remove/Replace . . . . .		4-39
Spindle Lockshaft, Remove/Replace . . . . .		4-54
Static Ground Spring, Adjust . . . . .		4-38
Static Ground Spring, Remove/Replace . . . . .		4-37
Storage, Administrative . . . . .		1-5
Support Equipment . . . . .	3-2..	4-2



SUBJECT	T	PARAGRAPH
Terminal Board, Remove/Replace . . . . .		4-14
TMDE . . . . .		3-2, 4-2
Tools		
Common . . . . .		3-1, 4-1
Special . . . . .		3-2, 4-2
Track Orientation . . . . .		2-8
Track Servo Preamp, Remove/Replace . . . . .		4-42
Troubleshooting		
Phases . . . . .		4-5
Procedures . . . . .		4-7
Techniques, Alternate . . . . .		4-6

u

Unit Selection . . . . .		2-6
Unpacked Equipment, Checking . . . . .		3-5
Unpacking . . . . .		3-4

v

Velocity Gain, Adjust . . . . .		4-47
Velocity Transducer, Remove/Replace . . . . .		4-46



SOMETHING WRONG WITH THIS PUBLICATION?



THEN JOT DOWN!  
DOPE AI301'T IT ON THIS  
FORM. CAREF ULLY TEAR IT  
OUT, FOLD IT AND DROP IT

Stateside Army Depot  
ATTN: AMSTA-US  
Stateside, N.J. 07703

DATE S

10 July 1975

PUBLICATION NUMBER

TM 11-5840-340-12

PUBLICATION DATE

23 Jan 74

Radar Set AN/PRC-76

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PAR GRAI	FIGU NO	TABLE NO
2-25	2-28		
0	5-3		3-1
5-6	7-8		

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

Recommend that the installation antenna alignment procedure be changed throughout to specify a 2° antenna lag rather than 1°. IFF

REASON: Experience has shown that with only a 1° lag the antenna servo system is too sensitive to wind gusting in excess of 25 knots, and has a tendency to rapidly accelerate and decelerate as it hunts, causing strain to the drive train. Hunting is minimized by adjusting the lag to 2° without degradation of operation.

Item 5, Function column. Change "2 db" to "3db."

REASON: The adjustment procedure for the TRANS POWER FAULT indicator calls for a 3 db (500 watts) adjustment to light the TRANS POWER FAULT indicator.

Add new step f.1 to read, "Replace cover plate remove, step e.1, above."

REASON: To replace the cover plate.

Zone C 3. On J1-2, change "+24 VDC to "+5 VDC."

REASON: This is the output line of the 5 VDC power supply. +24 VDC is the input voltage.

ED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SSG I.

6

SIGN HERE

DA, FORM 2028-2 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE,

PS--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

FILL IN YOUR  
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID  
DEPARTMENT OF THE ARMY  
DOD 314



OFFICIAL BUSINESS  
PENALTY FOR PRIVATE USE \$300

**SAMPLE**

Commander  
US Army Communications-Electronics Command  
and Fort Monmouth  
ATTN: DRSEL-ME-MP  
Fort Monmouth, New Jersey 07703

TEAR ALONG PERFORATED LINE

# SOMETHING WRONG WITH THIS PUBLICATION?



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-7025-208-23

PUBLICATION DATE

8 Mar 84

PUBLICATION TITLE

DISK MEMORY UNIT  
MU-705/MYQ-4

BE EXACT PIN-POINT WHERE IT IS

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2  
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS  
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID  
DEPARTMENT OF THE ARMY  
DOD 314



TEAR ALONG PERFORATED LINE

Commander  
US Army Communications-Electronics Command  
and Fort Monmouth  
ATTN: DRSEL-ME-MP  
Fort Monmouth, New Jersey 07703

# SOMETHING WRONG WITH THIS PUBLICATION?



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-7025-208-23

PUBLICATION DATE

8 Mar 84

PUBLICATION TITLE

DISK MEMORY UNIT  
MU-705/MYQ-4

BE EXACT PIN-POINT WHERE IT IS

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2  
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

\_\_\_\_\_  
\_\_\_\_\_

OFFICIAL BUSINESS  
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID  
DEPARTMENT OF THE ARMY  
DOD 314



TEAR ALONG PERFORATED LINE

Commander  
US Army Communications-Electronics Command  
and Fort Monmouth  
ATTN: DRSEL-ME-MP  
Fort Monmouth, New Jersey 07703



# SOMETHING WRONG WITH THIS PUBLICATION?



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS )

DATE SENT

PUBLICATION NUMBER

TM 11-7025-208-23

PUBLICATION DATE

8 Mar 84

PUBLICATION TITLE

DISK MEMORY UNIT  
MU-705/MYQ-4

BE EXACT PIN-POINT WHERE IT IS

PAGE NO.	PARA GRAPH	FIGURE NO.	TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 2028-2  
JUL 79

PREVIOUS EDITIONS ARE OBSOLETE

P.S.-IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

FILL IN YOUR  
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

\_\_\_\_\_  
\_\_\_\_\_

OFFICIAL BUSINESS  
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID  
DEPARTMENT OF THE ARMY  
DOD 314



TEAR ALONG PERFORATED LINE

Commander  
US Army Communications-Electronics Command  
and Fort Monmouth  
ATTN: DRSEL-ME-MP  
Fort Monmouth, New Jersey 07703

By Order of the Secretary of the Army:

JOHN A. WICKHAM JR.  
*General, United States Army*  
*Chief of Staff*

Official:


ROBERT M. JOYCE  
*Major General, United States Army*  
*The Adjutant General*


Distribution:


To be distributed in accordance with special list.

☆ U.S. GOVERNMENT PRINTING OFFICE : 1986 O - 491-421 (40120)











FROM FIGURE FO-3  
(SHEET 2 OF 2)







Change 2

FO-3: Plus and Minus 5 V Power Supply (2 of 2)

