

HDL Coder™

Reference

R2013a

MATLAB®

How to Contact MathWorks



www.mathworks.com	Web
comp.soft-sys.matlab	Newsgroup
www.mathworks.com/contact_TS.html	Technical Support
@	
suggest@mathworks.com	Product enhancement suggestions
bugs@mathworks.com	Bug reports
doc@mathworks.com	Documentation error reports
service@mathworks.com	Order status, license renewals, passcodes
info@mathworks.com	Sales, pricing, and general information



508-647-7000 (Phone)



508-647-7001 (Fax)



The MathWorks, Inc.
3 Apple Hill Drive
Natick, MA 01760-2098

For contact information about worldwide offices, see the MathWorks Web site.

HDL Coder™ Reference

© COPYRIGHT 2013 by The MathWorks, Inc.

The software described in this document is furnished under a license agreement. The software may be used or copied only under the terms of the license agreement. No part of this manual may be photocopied or reproduced in any form without prior written consent from The MathWorks, Inc.

FEDERAL ACQUISITION: This provision applies to all acquisitions of the Program and Documentation by, for, or through the federal government of the United States. By accepting delivery of the Program or Documentation, the government hereby agrees that this software or documentation qualifies as commercial computer software or commercial computer software documentation as such terms are used or defined in FAR 12.212, DFARS Part 227.72, and DFARS 252.227-7014. Accordingly, the terms and conditions of this Agreement and only those rights specified in this Agreement, shall pertain to and govern the use, modification, reproduction, release, performance, display, and disclosure of the Program and Documentation by the federal government (or other entity acquiring for or through the federal government) and shall supersede any conflicting contractual terms or conditions. If this License fails to meet the government's needs or is inconsistent in any respect with federal procurement law, the government agrees to return the Program and Documentation, unused, to The MathWorks, Inc.

Trademarks

MATLAB and Simulink are registered trademarks of The MathWorks, Inc. See www.mathworks.com/trademarks for a list of additional trademarks. Other product or brand names may be trademarks or registered trademarks of their respective holders.

Patents

MathWorks products are protected by one or more U.S. patents. Please see www.mathworks.com/patents for more information.

Revision History

March 2013 Online only

New for Version 3.2 (R2013a)

Function Reference

1

Class Reference

2

Function Reference

codegen

Purpose	Generate HDL code from MATLAB code
Syntax	<pre>codegen -config hdlcfg matlab_design_name codegen -config hdlcfg -float2fixed fixptcfg matlab_design_name e</pre>
Description	<p>codegen -config hdlcfg matlab_design_name generates HDL code from MATLAB® code.</p> <p>codegen -config hdlcfg -float2fixed fixptcfg matlab_design_name converts floating-point MATLAB code to fixed-point code, then generates HDL code.</p>
Input Arguments	<p>hdlcfg - HDL code generation configuration <code>coder.Hd1Config</code></p> <p>HDL code generation configuration options, specified as a <code>coder.Hd1Config</code> object.</p> <p>Create a <code>coder.Hd1Config</code> object using the HDL coder.config function.</p> <p>matlab_design_name - MATLAB design function name <code>string</code></p> <p>Name of top-level MATLAB function for which you want to generate HDL code.</p> <p>fixptcfg - Floating-point to fixed-point conversion configuration <code>coder.FixptConfig</code></p> <p>Floating-point to fixed-point conversion configuration options, specified as a <code>coder.FixptConfig</code> object.</p> <p>Use <code>fixptcfg</code> when generating HDL code from floating-point MATLAB code. Create a <code>coder.FixptConfig</code> object using the HDL coder.config function.</p>

Examples

Generate Verilog® Code from MATLAB Code

Create a `coder.HdlConfig` object, `hdlcfg`.

```
hdlcfg = coder.config('hdl'); % Create an 'hdl' config with default se
```

Set the test bench name. In this example, the test bench function name is `mlhdlc_dti_tb`.

```
hdlcfg.TestBenchName = 'mlhdlc_dti_tb';
```

Set the target language to Verilog.

```
hdlcfg.TargetLanguage = 'Verilog';
```

Generate HDL code from your MATLAB design. In this example, the MATLAB design function name is `mlhdlc_dti`.

```
codegen -config hdlcfg mlhdlc_dti
```

Generate HDL Code from Floating-Point MATLAB Code

Create a `coder.FixptConfig` object, `fixptcfg`, with default settings.

```
fixptcfg = coder.config('fixpt');
```

Set the test bench name. In this example, the test bench function name is `mlhdlc_dti_tb`.

```
fixptcfg.TestBenchName = 'mlhdlc_dti_tb';
```

Create a `coder.HdlConfig` object, `hdlcfg`, with default settings.

```
hdlcfg = coder.config('hdl');
```

Convert your floating-point MATLAB design to fixed-point, and generate HDL code. In this example, the MATLAB design function name is `mlhdlc_dti`.

```
codegen -float2fixed fixptcfg -config hdlcfg mlhdlc_dti
```

See Also [coder.FixptConfig](#) | [coder.HdlConfig](#) | [coder.config](#)

Related Examples

- “Generate HDL Code from MATLAB Code Using the Command Line Interface”

Purpose

Create HDL Coder code generation configuration objects

Syntax

```
config_obj = coder.config('hdl')
config_obj = coder.config('fixpt')
```

Description

`config_obj = coder.config('hdl')` creates a `coder.HdLCfg` configuration object for use with the HDL codegen function when generating HDL code from MATLAB code.

`config_obj = coder.config('fixpt')` creates a `coder.FixptConfig` configuration object for use with the HDL codegen function when generating HDL code from floating-point MATLAB code. The `coder.FixptConfig` object configures the floating-point to fixed-point conversion.

Examples**Generate HDL Code from Floating-Point MATLAB Code**

Create a `coder.FixptConfig` object, `fixptcfg`, with default settings.

```
fixptcfg = coder.config('fixpt');
```

Set the test bench name. In this example, the test bench function name is `mlhdlc_dti_tb`.

```
fixptcfg.TestBenchName = 'mlhdlc_dti_tb';
```

Create a `coder.HdLCfg` object, `hdlcfg`, with default settings.

```
hdlcfg = coder.config('hdl');
```

Convert your floating-point MATLAB design to fixed-point, and generate HDL code. In this example, the MATLAB design function name is `mlhdlc_dti`.

```
codegen -float2fixed fixptcfg -config hdlcfg mlhdlc_dti
```

See Also

`coder.HdLCfg` | `coder.FixptConfig` | `codegen`

coder.config

Related Examples

- “Generate HDL Code from MATLAB Code Using the Command Line Interface”

coder.FixptConfig.addFunctionReplacement

Purpose Replace floating-point function name with fixed-point function name

Syntax `fxptcfg.addFunctionReplacement(floatFn,fixedFn)`

Description `fxptcfg.addFunctionReplacement(floatFn,fixedFn)` specifies a function replacement in a `coder.FixptConfig` object. During floating-point to fixed-point conversion in the HDL code generation workflow, the coder replaces the specified floating-point function name with the specified fixed-point function name.

Input Arguments
floatFn - Name of floating-point function

'' (default) | string

Name of floating-point function, specified as a string.

fixedFn - Name of fixed-point function

'' (default) | string

Name of fixed-point function, specified as a string.

Examples **Specify Function Replacement in Fixed-Point Conversion Configuration Object**

Create a fixed-point code configuration object, `fpxCfg`, with a test bench, `myTestbenchName`.

```
fpxCfg = coder.config('fixpt');
fpxCfg.TestBenchName = myTestbenchName;
fpxCfg.addFunctionReplacement('min', 'fi_min');
codegen -float2fixed fpxCfg designName
```

Specify that the floating-point function, `min`, should be replaced with the fixed-point function, `fi_min`.

```
fpxCfg.addFunctionReplacement('min', 'fi_min');
```

When you generate code, the coder replaces instances of `min` with `fi_min` during floating-point to fixed-point conversion.

coder.FixptConfig.addFunctionReplacement

Alternatives

You can specify function replacements in the HDL Workflow Advisor.
See “Function Replacements”.

See Also

`coder.FixptConfig` | `coder.config` | `codegen`

Class Reference

coder.FixptConfig

Purpose HDL codegen floating-point to fixed-point conversion configuration object

Description A `coder.FixptConfig` object contains the configuration parameters that the HDL codegen function requires to convert floating-point MATLAB code to fixed-point MATLAB code during HDL code generation. Use the `-ffloat2fixed` option to pass this object to the `codegen` function.

Construction `fixptcfg = coder.config('fixpt')` creates a `coder.FixptConfig` object for floating-point to fixed-point conversion during HDL code generation.

Properties **DefaultFractionLength**

Default fixed-point fraction length.

Values: 4 (default) | positive integer

DefaultWordLength

Default fixed-point word length.

Values: 14 (default) | positive integer

FixPtFileNameSuffix

Suffix for fixed-point file names.

Values: '_FixPt' | string

LaunchNumericTypesReport

View the numeric types report after the coder has proposed fixed-point types.

Values: true (default) | false

LogIOForComparisonPlotting

Enable simulation data logging to plot the data differences introduced by fixed-point conversion.

Values: true (default) | false

ProposeFractionLengthsForDefaultWordLength

Propose fixed-point types based on DefaultWordLength.

Values: true (default) | false

ProposeWordLengthsForDefaultFractionLength

Propose fixed-point types based on DefaultFractionLength.

Values: false (default) | true

SafetyMargin

Safety margin percentage by which to increase the simulation range when proposing fixed-point types.

Values: 4 (default) | positive integer

TestBenchName

Test bench function name, specified as a string. You must specify a test bench.

Values: '' (default) | string

Methods

`addFunctionReplacement`

Replace floating-point function name with fixed-point function name

Examples**Generate HDL Code from Floating-Point MATLAB Code**

Create a `coder.FixptConfig` object, `fixptcfg`, with default settings.

```
fixptcfg = coder.config('fixpt');
```

Set the test bench name. In this example, the test bench function name is `mlhdlc_dti_tb`.

```
fixptcfg.TestBenchName = 'mlhdlc_dti_tb';
```

Create a `coder.HdlConfig` object, `hdlcfg`, with default settings.

coder.FixptConfig

```
hdlcfg = coder.config('hdl');
```

Convert your floating-point MATLAB design to fixed-point, and generate HDL code. In this example, the MATLAB design function name is `mlhdlc_dti`.

```
codegen -float2fixed fixptcfg -config hdlcfg mlhdlc_dti
```

Alternatives

You can also generate HDL code from MATLAB code using the HDL Workflow Advisor. For more information, see “HDL Code Generation from a MATLAB Algorithm”.

See Also

`coder.HdlConfig` | `coder.config` | `codegen`

Related Examples

- “Generate HDL Code from MATLAB Code Using the Command Line Interface”

Purpose	HDL codegen configuration object
Description	A <code>coder.HdLConfig</code> object contains the configuration parameters that the HDL codegen function requires to generate HDL code. Use the <code>-config</code> option to pass this object to the <code>codegen</code> function.
Construction	<code>hdlcfg = coder.config('hdl')</code> creates a <code>coder.HdLConfig</code> object for HDL code generation.
Properties	Basic
	GenerateHDLTestBench
	Generate an HDL test bench, specified as a logical. Values: <code>false</code> (default) <code>true</code>
	HDLCodingStandard
	HDL coding standard to follow and check when generating code, specified as a string. Generates a compliance report showing errors, warnings, and messages. Values: <code>'None'</code> (default) <code>'Industry'</code>
	HDLLintTool
	HDL lint tool script to generate, specified as a string. You must set <code>HDLCodingStandard</code> to <code>'Industry'</code> to use this property. Values: <code>'None'</code> (default) <code>'SpyGlass'</code> <code>'LEDA'</code>
	SimulateGeneratedCode
	Simulate generated code, specified as a logical. Values: <code>false</code> (default) <code>true</code>
	PartitionFunctions
	Specify whether to generate instantiable HDL code modules from functions. Values: <code>false</code> (default) <code>true</code>

SimulationIterationLimit

Maximum number of simulation iterations during test bench generation, specified as an integer. This property affects only test bench generation, not simulation during fixed-point conversion.

Values: unlimited (default) | positive integer

SimulationTool

Simulation tool name, specified as a string.

Values: 'ModelSim' (default) | 'ISIM'

SynthesisTool

Synthesis tool name, specified as a string.

Values: 'Xilinx ISE' (default) | 'Altera Quartus II'

SynthesisToolChipFamily

Synthesis target chip family name, specified as a string.

Values: 'Virtex4' (default) | string

SynthesisToolDeviceName

Synthesis target device name, specified as a string.

Values: 'xc4vsx35' (default) | string

SynthesisToolPackageName

Synthesis target package name, specified as a string.

Values: 'ff668' (default) | string

SynthesisToolSpeedValue

Synthesis target speed, specified as a string.

Values: '-10' (default) | string

SynthesizeGeneratedCode

Synthesize generated code or not, specified as a logical.

Values: `false` (default) | `true`

TargetLanguage

Target language, specified as a string.

Values: '`VHDL`' (default) | '`Verilog`'

TestBenchName

Test bench function name, specified as a string. You must specify a test bench.

Values: '' (default) | string

Cosimulation**GenerateCosimTestBench**

Generate a cosimulation test bench or not, specified as a logical.

Values: `false` (default) | `true`

SimulateCosimTestBench

Simulate generated cosimulation test bench, specified as a logical. This option is ignored if `GenerateCosimTestBench` is `false`.

Values: `false` (default) | `true`

CosimClockEnableDelay

Time (in clock cycles) between deassertion of reset and assertion of clock enable.

Values: 0 (default)

CosimClockHighTime

The number of nanoseconds the clock is high.

Values: 5 (default)

CosimClockLowTime

The number of nanoseconds the clock is low.

Values: 5 (default)

CosimHoldTime

The hold time for input signals and forced reset signals, specified in nanoseconds.

Values: 2 (default)

CosimLogOutput

Log and plot outputs of the reference design function and HDL simulator.

Values: `false` (default) | `true`

CosimResetLength

Specify time (in clock cycles) between assertion and deassertion of reset.

Values: 2 (default)

CosimRunMode

HDL simulator run mode during simulation, specified as a string. When in Batch mode, you do not see the HDL simulator GUI, and the HDL simulator automatically shuts down after simulation.

Values: `Batch` (default) | `GUI`

CosimTool

HDL simulator for the generated cosim test bench, specified as a string.

Values: `ModelSim` (default) | `Incisive`

FPGA-in-the-loop

GenerateFILTestBench

Generate a FIL test bench or not, specified as a logical.

Values: `false` (default) | `true`

SimulateFILTestBench

Simulate generated cosimulation test bench, specified as a logical. This option is ignored if `GenerateCosimTestBench` is `false`.

Values: `false` (default) | `true`

FILBoardName

FPGA board name, specified as a string. You must override the default value and specify a valid board name.

Values: `'Choose a board'` (default) | string

FILBoardIPAddress

IP address of the FPGA board, specified as a string. You must enter a valid IP address.

Values: `192.168.0.2` (default) | string

FILBoardMACAddress

MAC address of the FPGA board, specified as a string. You must enter a valid MAC address.

Values: `00-0A-35-02-21-8A` (default) | string

FILAdditionalFiles

List of additional source files to include, specified as a string. Separate file names with a semi-colon (`";"`).

Values: `''` (default) | string

FILLogOutputs

Log and plot outputs of the reference design function and FPGA.

Values: `false` (default) | `true`

Examples**Generate Verilog Code from MATLAB Code**

Create a `coder.HdLConfig` object, `hdlcfg`.

```
hdlcfg = coder.config('hdl'); % Create an 'hdl' config with default settings
```

Set the test bench name. In this example, the test bench function name is `mlhdlc_dti_tb`.

```
hdlcfg.TestBenchName = 'mlhdlc_dti_tb';
```

Set the target language to Verilog.

```
hdlcfg.TargetLanguage = 'Verilog';
```

Generate HDL code from your MATLAB design. In this example, the MATLAB design function name is `mlhdlc_dti`.

```
codegen -config hdlcfg mlhdlc_dti
```

Generate Cosim and FIL Test Benches

Create a `coder.FixptConfig` object with default settings and provide test bench name.

```
fixptcfg = coder.config('fixpt');
fixptcfg.TestBenchName = 'mlhdlc_sfir_tb';
```

Create a `coder.HdLConfig` object with default settings and set enable rate.

```
hdlcfg = coder.config('hdl'); % Create an 'hdl' config with default settings
hdlcfg.EnableRate = 'DUTBaseRate';
```

Instruct MATLAB to generate a cosim test bench and a FIL test bench. Specify FPGA board name.

```
hdlcfg.GenerateCosimTestBench = true;
hdlcfg.FILBoardName = 'Xilinx Virtex-5 XUPV5-LX110T development board';
hdlcfg.GenerateFILTestBench = true;
```

Perform code generation, Cosim test bench generation, and FIL test bench generation.

```
codegen -float2fixed fixptcfg -config hdlcfg mlhdlc_sfir
```

Alternatives

You can also generate HDL code from MATLAB code using the HDL Workflow Advisor. For more information, see “HDL Code Generation from a MATLAB Algorithm”.

See Also

`coder.FixptConfig` | `coder.config` | `codegen`

Related Examples

- “Generate HDL Code from MATLAB Code Using the Command Line Interface”