


Simulink® Real-Time™

Reference

R2014a



MATLAB® & SIMULINK®



How to Contact MathWorks



www.mathworks.com Web
comp.soft-sys.matlab Newsgroup
www.mathworks.com/contact_TS.html Technical Support



suggest@mathworks.com Product enhancement suggestions
bugs@mathworks.com Bug reports
doc@mathworks.com Documentation error reports
service@mathworks.com Order status, license renewals, passcodes
info@mathworks.com Sales, pricing, and general information



508-647-7000 (Phone)



508-647-7001 (Fax)



The MathWorks, Inc.
3 Apple Hill Drive
Natick, MA 01760-2098

For contact information about worldwide offices, see the MathWorks Web site.

Simulink® Real-Time™ Reference

© COPYRIGHT 2002–2014 by The MathWorks, Inc.

The software described in this document is furnished under a license agreement. The software may be used or copied only under the terms of the license agreement. No part of this manual may be photocopied or reproduced in any form without prior written consent from The MathWorks, Inc.

FEDERAL ACQUISITION: This provision applies to all acquisitions of the Program and Documentation by, for, or through the federal government of the United States. By accepting delivery of the Program or Documentation, the government hereby agrees that this software or documentation qualifies as commercial computer software or commercial computer software documentation as such terms are used or defined in FAR 12.212, DFARS Part 227.72, and DFARS 252.227-7014. Accordingly, the terms and conditions of this Agreement and only those rights specified in this Agreement, shall pertain to and govern the use, modification, reproduction, release, performance, display, and disclosure of the Program and Documentation by the federal government (or other entity acquiring for or through the federal government) and shall supersede any conflicting contractual terms or conditions. If this License fails to meet the government's needs or is inconsistent in any respect with federal procurement law, the government agrees to return the Program and Documentation, unused, to The MathWorks, Inc.

Trademarks

MATLAB and Simulink are registered trademarks of The MathWorks, Inc. See www.mathworks.com/trademarks for a list of additional trademarks. Other product or brand names may be trademarks or registered trademarks of their respective holders.

Patents

MathWorks products are protected by one or more U.S. patents. Please see www.mathworks.com/patents for more information.

Revision History

March 2007	Online only	New for Version 3.2 (Release 2007a)
September 2007	Online only	Updated for Version 3.3 (Release 2007b)
March 2008	Online only	Updated for Version 3.4 (Release 2008a)
October 2008	Online only	Updated for Version 4.0 (Release 2008b)
March 2009	Online only	Updated for Version 4.1 (Release 2009a)
September 2009	Online only	Updated for Version 4.2 (Release 2009b)
March 2010	Online only	Updated for Version 4.3 (Release 2010a)
April 2011	Online only	Updated for Version 5.0 (Release 2011a)
September 2011	Online only	Updated for Version 5.1 (Release 2011b)
March 2012	Online only	Revised for Version 5.2 (Release 2012a)
September 2012	Online only	Revised for Version 5.3 (Release 2012b)
March 2013	Online only	Revised for Version 5.4 (Release 2013a)
September 2013	Online only	Revised for Version 5.5 (Release 2013b)
March 2014	Online only	Revised for Version 6.0 (Release 2014a)

Functions

1

Simulink Real-Time API Reference for C

2

C API Error Messages	2-2
C API Structures and Functions — Alphabetical List ..	2-6

Simulink Real-Time API Reference for COM

3

COM API Methods — Alphabetical List	3-2
---	-----

Configuration Parameters

4

Configuration Parameters	4-2
Simulink Real-Time Options Pane	4-3
Automatically download application after building	4-4
Download to default target PC	4-5
Specify target PC name	4-6
Name of Simulink Real-Time object created by build process	4-7
Use default communication timeout	4-8
Specify the communication timeout in seconds	4-9
Execution mode	4-10

Real-time interrupt source	4-11
I/O board generating the interrupt	4-12
PCI slot (-1: autosearch) or ISA base address	4-16
Log Task Execution Time	4-17
Signal logging data buffer size in doubles	4-18
Number of events (each uses 20 bytes)	4-21
Double buffer parameter changes	4-22
Load a parameter set from a file on the designated target file system	4-24
File name	4-25
Build COM objects from tagged signals/parameters	4-26
Generate CANape extensions	4-27
Include model hierarchy on the target application	4-28
Enable Stateflow animation	4-29

Using Simulink Real-Time Explorer Instruments

5

Instrumenting a Model	5-2
Create Instrument Panel	5-4
Configure Instrument for Set Point Parameter	5-5
Configure Instrument for Tank Level Signal	5-7
Run Instrumented Model	5-9
Instruments — Alphabetical List	5-11

Target Computer Command-Line Interface Reference

6

Target Computer Commands	6-2
Target Object Methods	6-2
Target Object Property Commands	6-3
Scope Object Methods	6-5
Scope Object Property Commands	6-6
Aliasing with Variable Commands	6-8

Support Package Reference

7

Support Package Functions	7-2
--	------------

Functions

Purpose List environment properties assigned to MATLAB variable (not recommended)


Syntax `getxpcenv`
`getxpcenv propertyname`

Description `getxpcenv` displays, in the Command Window, the property names and current property values for the Simulink® Real-Time™ environment.

Note Function `getxpcenv` will be removed in a future release. Use `SimulinkRealTime.getTargetSettings` instead.

`getxpcenv propertyname` displays the current value of property `propertyname`. The environment properties define communication between the host computer and target computer and the type of target boot kernel created during the setup process.

Tip To access a subset of these properties in Simulink Real-Time Explorer:

- 1 Expand a target computer node in the **Targets** pane.
- 2 Click the Target Properties icon  in the toolbar or double-click **Properties**.

-
- “Host-to-Target Communication” on page 1-3
 - “Target Settings” on page 1-9
 - “Boot Configuration” on page 1-12
 - “Host Configuration” on page 1-14

Host-to-Target Communication

Environment Property	Description
HostTargetComm	<p>Property values are 'RS232' and 'TcpIp'.</p> <p>Select RS-232 or TCP/IP from the Communication type list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you select RS-232, you also must set the property RS232HostPort. If you select TCP/IP, then you must set the other properties that start with TcpIp.</p> <hr/> <p>Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.</p> <hr/>
RS232Baudrate	<p>Property values are '115200', '57600', '38400', '19200', '9600', '4800', '2400', and '1200'.</p> <p>Select 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 from the Baud rate list in the Target Properties pane of Simulink Real-Time Explorer.</p>

Environment Property	Description
RS232HostPort	<p>Property values are 'COM1' and 'COM2'.</p> <p>Select COM1 or COM2 from the Host port list in the Target Properties pane of Simulink Real-Time Explorer. The software automatically determines the COM port on the target computer.</p> <p>Before you can select an RS-232 port, you need to set the HostTargetComm property to RS232.</p>
TcpIpGateway	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the IP address for your gateway in the Gateway box in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to 255.255.255.255, which means that a gateway is not used to connect to the target computer.</p> <p>If you communicate with your target computer from within a LAN that uses gateways, and your host and target computers are connected through a gateway, you must enter a value for this property. If your LAN does not use gateways, you do not need to change this property. Ask your system administrator.</p>

Environment Property	Description
TcpIpSubNetMask	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the subnet mask of your LAN in the Subnet mask box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, your subnet mask could be 255.255.255.0.</p>
TcpIpTargetAddress	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter a valid IP address for your target computer in the IP address box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, 192.168.0.10.</p>
TcpIpTargetBusType	<p>Property values are 'PCI', 'ISA', and 'USB'.</p> <p>Select PCI, ISA, or USB from the Bus type list in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to PCI, and determines the bus type of your target computer. You do not need to define a bus type for your host computer, which can be the</p>

Environment Property	Description
	<p>same or different from the bus type in your target computer.</p> <p>If TcpIpTargetBusType is set to PCI, then the properties TcpIpISAMemPort and TcpIpISAIRQ have no effect on TCP/IP communication.</p> <p>If you are using an ISA bus card, set TcpIpTargetBusType to ISA and enter values for TcpIpISAMemPort and TcpIpISAIRQ.</p>
TcpIpTargetDriver	<p>Property values are '3C90x', 'I8254x', 'I82559', 'NE2000', 'NS83815', 'R8139', 'R8168', 'Rhine', 'RTLANCE', 'SMC91C9X', 'USBAX772', 'USBAX172', and 'Auto'.</p> <p>Select THREECOM_3C90x, INTEL_I8254x, INTEL_I82559, NE2000, NS83815, R8139, R8168, Rhine, RTLANCE, SMC91C9X, USBAX772, USBAX172, or Auto from the Target driver list in the Target Properties pane of Simulink Real-Time Explorer.</p>

Environment Property	Description
TcpIpTargetISAIRQ	<p>Property value is 'n', where <i>n</i> is between 5 and 15 inclusive.</p> <p>Select an IRQ value from the IRQ list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on the ISA-bus Ethernet card.</p> <p>On your ISA bus card, assign an IRQ and I/O-port base address by moving the jumpers on the card.</p> <p>Set the IRQ to 5, 10, or 11. If one of these hardware settings leads to a conflict in your target computer, choose another IRQ and make the corresponding changes to your jumper settings.</p>

Environment Property	Description
TcpIpTargetISAMemPort	<p>Property value is '0xnnnn'.</p> <p>Enter an I/O port base address in the Address box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on your ISA bus Ethernet card.</p> <p>On your ISA bus card, assign an IRQ and I/O port base address by moving the jumpers on the card.</p> <p>Set the I/O port base address to around 0x300. If one of these hardware settings leads to a conflict in your target computer, choose another I/O port base address and make the corresponding changes to your jumper settings.</p>
TcpIpTargetPort	<p>Property value is 'xxxxx'.</p> <p>Enter a port address greater than 20000 in the Port box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>This property is set by default to 22222. The default value is higher than the reserved area</p>

Environment Property	Description
	(telnet, ftp, . . .) and is only of use on the target computer.

Target Settings

Environment Property	Description
EthernetIndex	<p>Property value is 'n', where <i>n</i> indicates the index number for the Ethernet card on a target computer. Note that the (<i>n</i>-1)th Ethernet card on the target computer has an index number '<i>n</i>'. The default index number is 0.</p> <p>If the target computer has multiple Ethernet cards, you must select one of the cards for host-target communication. This option returns the index number of the card selected on the target computer upon booting.</p>
LegacyMultiCoreConfig	<p>Property values are 'on' and 'off' (the default).</p> <p>Set this value to 'on' only if your target computer contains hardware not compliant with the Advanced Configuration and Power Interface (ACPI) standard. Otherwise, set this value to 'off'.</p>
MaxModelSize	<p>Supported property values are '1MB' (the default) and '4MB'. Value '16MB' is not supported.</p> <p>Select 1 MB or 4 MB from the Model size list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Setting Model size is enabled for Boot mode Stand Alone only.</p> <p>Choosing the maximum model size reserves the specified amount of memory on the target computer for the target application. Memory not used by the target</p>

Environment Property	Description
	<p>application is used by the kernel and by the heap for data logging.</p> <p>Selecting too high a value leaves less memory for data logging. Selecting too low a value does not reserve enough memory for the target application and creates an error. You can approximate the size of the target application by the size of the DLM file produced by the build process.</p>
MulticoreSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Multicore CPU check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your target computer has multicore processors, set this value to 'on' to take advantage of these processors for background tasks. Otherwise, set this value to 'off'.</p>
Name	Target computer name.
NonPentiumSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Target is a 386/486 check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if your target computer has a 386 or 486 compatible processor. Otherwise, set it to 'off'. If your target computer has a Pentium or higher compatible processor, selecting this check box slows the performance of your target computer.</p>

Environment Property	Description
SecondaryIDE	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Secondary IDE check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' only if you want to use the disks connected to a secondary IDE controller. If you do not have disks connected to the secondary IDE controller, leave this value set to 'off'.</p>
ShowHardware	<p>Property values are 'on' and 'off' (the default).</p> <p>If you create a target boot kernel when ShowHardware is 'on' and boot the target computer with it, the kernel displays the index, bus, slot, function, and target driver for each Ethernet card on the target monitor.</p> <p>The host computer cannot communicate with the target computer after the kernel boots with ShowHardware set.</p>
TargetRAMSizeMB	<p>Property values are 'Auto' (the default) and 'xxx', where xxx is a positive value specifying the amount of RAM, in megabytes, installed on the target computer.</p> <p>Under RAM size, click the Auto or Manual button in the Target Properties pane of Simulink Real-Time Explorer. If you click Manual, enter the amount of RAM, in megabytes, installed on the target computer in the Size(MB) box.</p> <p>TargetRAMSizeMB defines the total amount of installed RAM in the target computer. This RAM is used for the kernel, target application, data logging, and other functions that use the heap.</p> <p>If TargetRAMSizeMB is assigned 'Auto', the target application reads the target computer BIOS and determines the amount of memory up to a maximum of 2 GB. If the target application cannot read the BIOS,</p>

Environment Property	Description
	<p>you must select Manual mode and enter the amount of memory, in megabytes, up to a maximum of 2 GB.</p> <p>The Simulink Real-Time kernel can use only 2 GB of memory.</p>
TargetScope	<p>Property values are 'Disabled' and 'Enabled' (the default).</p> <p>Select or clear the Graphics mode check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you set TargetScope to Disabled, the target computer displays information as text.</p> <p>To use the full features of a target scope, install a keyboard on the target computer.</p>
USBSupport	<p>Property values are 'on' (the default) and 'off'.</p> <p>Select or clear the USB Support check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if you want to use a USB port on the target computer; for example, to connect a USB mouse. Otherwise, set it to 'off'.</p>

Boot Configuration

Environment Property	Description
BootFloppyLocation	Drive name for creation of target boot disk.
DOSLoaderLocation	Location of DOSLoader files to boot target computers from devices other than floppy disk or CD.

Environment Property	Description
TargetBoot	<p>Property values are 'BootFloppy', 'CDBoot', 'DOSLoader', 'NetworkBoot', and 'StandAlone'.</p> <p>Select Removable Disk, CD, DOS Loader, Network, or Stand Alone from the Boot mode list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your license file does not include the license for the Simulink Real-Time standalone mode product, your only options are Removable Disk, CD, DOS Loader, and Network. With the Simulink Real-Time standalone mode product licensed and installed, you have the additional choice of Stand Alone.</p> <hr/> <p>Tip In the Target Properties pane of Simulink Real-Time Explorer, click the Create boot disk button to create a bootable image in the specified boot mode.</p> <hr/>
TargetMACAddress	<p>Physical target computer MAC address from which to accept boot requests when booting within a dedicated network. Format the MAC address as six pairs of hexadecimal numbers, separated by colons:</p>

Environment Property	Description
	xx:xx:xx:xx:xx:xx To update the MAC address in Simulink Real-Time Explorer, first click the Reset button in the Target Properties pane. You can then click the Specify new MAC address button to enter a MAC address manually in the MAC address box. If you do not enter a MAC address manually, the software will obtain the MAC address automatically the next time you restart the target computer.

Host Configuration

Environment Property	Description
Version	Simulink Real-Time version number. Displayed only from getxpcenv when called without arguments.

Examples

Display the Simulink Real-Time environment in the format shown below.

```
getxpcenv
Simulink Real-Time Target Settings

Name                : TargetPC1

TargetRAMSizeMB    : Auto
MaxModelSize       : 1MB
```

```
SecondaryIDE           : off
NonPentiumSupport      : off
MulticoreSupport       : on
LegacyMultiCoreConfig  : off
USBSupport             : on
ShowHardware           : off
EthernetIndex          : 0

HostTargetComm         : TcpIp
TcpIpTargetAddress     : 10.10.10.15
TcpIpTargetPort        : 22222
TcpIpSubNetMask        : 255.255.255.0
TcpIpGateway           : 10.10.10.100
RS232HostPort          : COM1
RS232Baudrate          : 115200
TcpIpTargetDriver      : Auto
TcpIpTargetBusType     : PCI
TcpIpTargetISAMemPort  : 0x300
TcpIpTargetISAIRQ      : 5

TargetScope            : Enabled

TargetBoot             : NetworkBoot
TargetMACAddress       : 90:e2:ba:17:5d:15
```

Return specific environment property value.

```
env = getxpcenv('HostTargetComm')
env =

    'TcpIp'
```

See Also

setxpcenv | xpcbootdisk

getxpcinfo

Purpose Retrieve diagnostic information to help troubleshoot configuration issues (not recommended)

Syntax `getxpcinfo`
`getxpcinfo('-a')`

Arguments `'-a'` Appends diagnostic information to an existing `xpcinfo.txt` file. If one does not exist, this function creates the file in the current folder.

Description `getxpcinfo` returns diagnostic information for troubleshooting Simulink Real-Time configuration issues. This function generates and saves the information in the `xpcinfo.txt` file, in the current folder. If the file `xpcinfo.txt` already exists, this function overwrites it with the new information.

Note Function `getxpcinfo` will be removed in a future release. Use `SimulinkRealTime.getSupportInfo` instead.

`getxpcinfo('-a')` appends the diagnostic information to the `xpcinfo.txt` file, in the current folder. If the file `xpcinfo.txt` does not exist, this function creates it.

You can send the file `xpcinfo.txt` to MathWorks® Technical Support for evaluation and guidance. To create this file, you must have write permission for the current folder.

Warning

The file `xpcinfo.txt` might contain information sensitive to your organization. Review the contents of this file before sending to MathWorks.

Purpose Determine PCI boards installed in target computer (not recommended)

Syntax

```
getxpcpci
getxpcpci 'all'
getxpcpci 'verbose'
getxpcpci 'supported'

pci_devices = getxpcpci
pci_devices = getxpcpci('all')
pci_devices = getxpcpci('verbose')
pci_devices = getxpcpci(target_object, ___)

pci_devices_supported = getxpcpci('supported')
```

Description `getxpcpci` without an argument queries the default target computer for installed PCI devices (boards) that are supported by driver blocks in the Simulink Real-Time block library.

Note Function `getxpcpci` will be removed in a future release. Use `SimulinkRealTime.target.getPCIInfo` instead.

The call displays in the Command Window information about the PCI devices found, including:

- PCI bus number
- Slot number
- Assigned IRQ number
- Vendor (manufacturer) name
- Device (board) name
- Device type
- Vendor PCI ID
- Device PCI ID

- Device release version.

Before you can use this call, you must meet the following preconditions:

- The host-target communication link must be working. Before you can use `getxpcpci`, the function `xpctargetping` must return success.
- Either a target application is loaded or the loader is active. Before building the model, you can use `getxpcpci` to find resources to enter into a driver block dialog box. Such resources include PCI bus number, slot number, and assigned IRQ number.

`getxpcpci 'all'` displays information about all of the PCI devices found on the default target computer. This information includes graphics controllers, network cards, SCSI cards, and devices that are part of the motherboard chip set (for example, PCI-to-PCI bridges).

`getxpcpci 'verbose'` shows the information displayed by `getxpcpci 'all'` for the default target computer, plus information about the PCI addresses assigned to this board by the BIOS.

`getxpcpci 'supported'` displays a list of the PCI devices currently supported by the Simulink Real-Time block library. This call does not access the target computer, so host-target communication does not have to be active.

`pci_devices = getxpcpci` without an argument queries the default target computer for installed PCI devices (boards) that are supported by driver blocks in the Simulink Real-Time block library. The call returns a structure containing information about the PCI devices found.

`pci_devices = getxpcpci('all')` and `pci_devices = getxpcpci('verbose')` both return a structure containing information about all PCI devices found on the default target computer. This structure includes information about the PCI addresses assigned to this board by the BIOS.

`pci_devices = getxpcpci(target_object, ___)` applies the option arguments to the target computer represented by `target_object`.

`pci_devices_supported = getxpcpci('supported')` returns a structure containing a list of PCI devices currently supported by the Simulink Real-Time block library. This call does not access the target computer, so host-target communication does not have to be active.

Input Arguments

target_object - Object representing target computer

object created by `xpctarget.xpc`

Object representing the target computer being queried, as returned by `xpctarget.xpc`.

Example: `target_object = xpctarget.xpc('TargetPC1')`

Data Types

function_handle

Output Arguments

pci_devices - Information about the PCI devices in the target computer

vector

The vector returned by `getxpcpci` without an argument contains information only for those PCI devices supported by Simulink Real-Time blocks. The vectors returned by `getxpcpci` with the arguments `'all'` and `'verbose'` contain information about all PCI devices in the target computer and are identical.

The fields in this structure are:

Bus - PCI bus where device resides

scalar

Bus and Slot are used together to uniquely identify the location of a device or bus adapter in the target computer.

Slot - PCI slot where device resides

scalar

Slot and Bus are used together to uniquely identify the location of a device or bus adapter in the target computer.

VendorID - Identifier for manufacturer of the device

string

Hexadecimal numeric string containing the identifier assigned by the PCI standards organization to the manufacturer of this device or bus adapter.

DeviceID - Identifier for device among those manufactured by the vendor

string

Hexadecimal numeric string containing the identifier assigned by the manufacturer to this device or bus adapter.

SubVendorID - Identifier for manufacturer of subsystem

string

Hexadecimal numeric string containing the identifier assigned by the PCI standards organization to the manufacturer of the entire subsystem (board).

SubDeviceID - Identifier for subsystem among those manufactured by the subvendor

string

Hexadecimal numeric string containing the identifier assigned by the manufacturer to this subsystem (board).

BaseClass - Standard PCI class of the device

string

Hexadecimal numeric string containing the standard PCI base classification of this device or bus adapter. BaseClass and SubClass together identify the type and function of the device.

SubClass - Standard PCI subclass of the device

string

Hexadecimal numeric string containing the standard PCI subclass classification of this device or bus adapter. SubClass and BaseClass together identify the type and function of the device.

Interrupt - IRQ used by the device

scalar

Provides the board-level interrupt used by the device or bus adapter to trigger I/O with the target computer CPU.

BaseAddresses - Information for each Base Address Register (BAR) used by the device

vector

For each BAR used by this device or bus adapter, the vector contains a structure with the following fields:

AddressSpaceIndicator - Indicates whether the address is a memory or I/O address

0 | 1

- 0 — Address is memory address
- 1 — Address is I/O address

BaseAddress - Memory address used by the device

string

Hexadecimal string containing the base memory address used by the device.

MemoryType - Indicates the size of the address decode, 32-bit or 64-bit

0 | 1

Not used if AddressSpaceIndicator is 1 (I/O address).

- 0 — 32-bit address decode

- 1 — 64-bit address decode

Prefetchable - Indicates whether the memory is prefetchable

0 | 1

Not used if AddressSpaceIndicator is 1 (I/O address).

- 0 — Address not prefetchable
- 1 — Address prefetchable

VendorName - Name of vendor of device

string

Identifies the vendor of the specific device or bus adapter. Set to 'Unknown' for unknown devices or bus adapters.

Release - MATLAB® release version in which driver became available

string

If the device is supported by the Simulink Real-Time block library, contains the MATLAB and Simulink release version in which the driver was released. Otherwise, contains an empty vector.

Notes - Additional information about the device

string

Contains additional description of the device or bus adapter.

DeviceName - Name of device

string

Identifies the specific device or bus adapter. Set to 'Unknown' for unknown devices or bus adapters.

DeviceType - Identifies the functions of the device

string

Contains abbreviations such as 'DI' (digital input) that indicate the function or functions of the device or bus adapter.

ADChan - Number of analog inputs

string

Decimal numeric string containing the number of analog inputs to the device.

DACHan - Number of analog outputs

string

Decimal numeric string containing the number of analog outputs from the device.

DIOChan - Number of digital inputs and outputs

string

Decimal numeric string containing the number of digital inputs and outputs to and from the device.

pci_devices_supported - Information about the PCI devices supported by the product

vector

Vector of information about the devices and bus adapters represented by blocks in the Simulink Real-Time block library.

The fields are as follows:

VendorID - Identifier for manufacturer of the device

string

Hexadecimal numeric string containing the identifier assigned by the PCI standards organization to the manufacturer of this device or bus adapter.

DeviceID - Identifier for device among those manufactured by the vendor

string

Hexadecimal numeric string containing the identifier assigned by the manufacturer to this device or bus adapter.

SubVendorID - Identifier for manufacturer of subsystem

string

Hexadecimal numeric string containing the identifier assigned by the PCI standards organization to the manufacturer of the entire subsystem (board).

SubDeviceID - Identifier for subsystem among those manufactured by the subvendor

string

Hexadecimal numeric string containing the identifier assigned by the manufacturer to this subsystem (board).

DeviceName - Name of device

string

Identifies the specific device or bus adapter. Set to 'Unknown' for unknown devices or bus adapters.

VendorName - Name of vendor of device

string

Identifies the vendor of the specific device or bus adapter. Set to 'Unknown' for unknown devices or bus adapters.

DeviceType - Identifies the functions of the device

string

Contains abbreviations such as 'DI' (digital input) that indicate the function or functions of the device or bus adapter.

DACChan - Number of analog outputs

string

Decimal numeric string containing the number of analog outputs from the device.

ADChan - Number of analog inputs

string

Decimal numeric string containing the number of analog inputs to the device.

DIOChan - Number of digital inputs and outputs

string

Decimal numeric string containing the number of digital inputs and outputs to and from the device.

Release - MATLAB release version in which driver became available

string

If the device is supported by the Simulink Real-Time block library, contains the MATLAB and Simulink release version in which the driver was released. Otherwise, contains an empty vector.

Notes - Additional information about the device

string

Contains additional description of the device or bus adapter.

Examples

Display information for PCI devices that are supported by Simulink Real-Time block library on default computer

Start the default target computer with the Simulink Real-Time kernel. Verify the connection between the host and the target computer. At the MATLAB command prompt, type the command on the host computer.

```
xpctargetping
```

```
getxpcpci
```

```
List of installed PCI devices:
```

```
Measurement Computing    PCI-DI024
    Bus 1, Slot 11, IRQ 10
    DI DO
    VendorID 0x1307, DeviceID 0x0028,
```

```
SubVendorID 0x1307, SubDeviceID 0x0028  
A/D Chan: 0, D/A Chan: 0, DIO Chan: 24  
Released in: R14SP2 or Earlier
```

```
.  
. .  
. .
```

Display information for all PCI devices on default computer

Start the default target computer with the Simulink Real-Time kernel. Verify the connection between the host and the target computer. At the MATLAB command prompt, type the command on the host computer.

```
xpctargetping
```

```
getxpcpci 'all'
```

```
List of installed PCI devices:
```

```
Intel                               Unknown  
  Bus 0, Slot 0, IRQ 0  
  Host Bridge  
  VendorID 0x8086, DeviceID 0x1130,  
    SubVendorID 0x8086, SubDeviceID 0x4532  
. . .  
Measurement Computing             PCI-DI024  
  Bus 1, Slot 11, IRQ 10  
  DI DO  
  VendorID 0x1307, DeviceID 0x0028,  
    SubVendorID 0x1307, SubDeviceID 0x0028  
  A/D Chan: 0, D/A Chan: 0, DIO Chan: 24  
  Released in: R14SP2 or Earlier  
. . .
```

Display verbose information for all PCI devices on default computer

Start the default target computer with the Simulink Real-Time kernel. Verify the connection between the host and the target computer. At the MATLAB command prompt, type the command on the host computer.

```
xpctargetping
```

```
getxpcpci 'verbose'
```

```
List of installed PCI devices:
```

```
Intel                               Unknown
  Bus 0, Slot 0, IRQ 0
  Host Bridge
  VendorID 0x8086, DeviceID 0x1130,
    SubVendorID 0x8086, SubDeviceID 0x4532
  BaseClass 6, SubClass 0
  BAR BaseAddress AddressSpace  MemoryType PreFetchable
    0)      E8000000           Memory  32-bit decoder      no
  .
  .
  .
Measurement Computing             PCI-DI024
  Bus 1, Slot 11, IRQ 10
  DI D0
  VendorID 0x1307, DeviceID 0x0028,
    SubVendorID 0x1307, SubDeviceID 0x0028
  A/D Chan: 0, D/A Chan: 0, DIO Chan: 24
  Released in: R14SP2 or Earlier
  BaseClass FF, SubClass FF
  BAR BaseAddress AddressSpace
    1)      DC00                I/O
    2)      DFF4                I/O
  .
  .
  .
```

Display all PCI devices supported by Simulink Real-Time block library

At the MATLAB prompt, type the command on the host computer.

```
getxpcpci 'supported'
```

List of supported PCI devices:

Vendor	Device	Type . . .
ADDI-DATA	APCI-1710	Inc. Encoder
ADLINK	PCI-6208A	AO DI DO
.	.	.
.	.	.
.	.	.
Speedgoat	I0321 (PMC-FPGA)	AI (I0321-5)
Speedgoat	I0331 (PMC-FPGA)	DI DO (LVDS/LVCMOS)

Return information for PCI devices that are supported by Simulink Real-Time block library on default computer

Start the default target computer with the Simulink Real-Time kernel. Verify the connection between the host and the target computer. At the MATLAB command prompt, type the command on the host computer. Display the first structure in the vector.

```
xpctargetping
```

```
pci_devices=getxpcpci;  
pci_devices(1)
```

```
ans =
```

```
          Bus: 1  
          Slot: 11  
    VendorID: '1307'  
    DeviceID: '28'  
  SubVendorID: '1307'
```

```

SubDeviceID: '28'
BaseClass: 'FF'
SubClass: 'FF'
Interrupt: 10
BaseAddresses: [1x6 struct]
VendorName: 'Measurement Computing'
Release: 'R14SP2 or Earlier'
Notes: ''
DeviceName: 'PCI-DI024'
DeviceType: 'DI DO'
ADChan: '0'
DACHan: '0'
DIOChan: '24'

```

Return information for all PCI devices on default computer

Start the default target computer with the Simulink Real-Time kernel. Verify the connection between the host and the target computer. At the MATLAB command prompt, type the command on the host computer. Display the first structure in the vector.

```
xpctargetping
```

```
pci_devices=getxpcpci('all');
pci_devices(1)
```

```
ans =
```

```

Bus: 0
Slot: 0
VendorID: '8086'
DeviceID: '1130'
SubVendorID: '8086'
SubDeviceID: '4532'
BaseClass: '6'
SubClass: '0'
Interrupt: 0

```

```
BaseAddresses: [1x6 struct]
VendorName: 'Intel'
Release: ''
Notes: ''
DeviceName: 'Unknown'
DeviceType: 'Host Bridge'
ADChan: ''
DACHan: ''
DIOChan: ''
```

Return verbose information for all PCI devices via target_object

Start the default target computer with the Simulink Real-Time kernel. Get the `target_object` using `xpctarget.xpc`. Verify the connection between the host and the target computer. At the MATLAB prompt, type the command on the host computer. Display the first structure in the vector.

```
target_object=xpctarget.xpc('XPCLABTGT4');
target_object.targetping

pci_devices=getxpcpci(target_object,'verbose');
pci_devices(1)
```

```
ans =
```

```
Bus: 0
Slot: 0
VendorID: '8086'
DeviceID: '1130'
SubVendorID: '8086'
SubDeviceID: '4532'
BaseClass: '6'
SubClass: '0'
Interrupt: 0
BaseAddresses: [1x6 struct]
```

```

VendorName: 'Intel'
  Release: ''
  Notes: ''
DeviceName: 'Unknown'
DeviceType: 'Host Bridge'
  ADChan: ''
  DACHan: ''
  DIOChan: ''

```

Return all PCI devices supported by Simulink Real-Time block library

At the MATLAB prompt, type the command on the host computer.

```

pci_devices_supported=getxpcpci('supported');
pci_devices_supported(1)

```

ans =

```

VendorID: '10e8'
DeviceID: '818f'
SubVendorID: '-1'
SubDeviceID: '-1'
DeviceName: 'APCI-1710'
VendorName: 'ADDI-DATA'
DeviceType: 'Inc. Encoder'
  DACHan: '0'
  ADChan: '0'
  DIOChan: '0'
  Release: 'R14SP2 or Earlier'
  Notes: ''

```

Related Examples

- “Where to Find PCI Board Information”
- “Command-Line Ethernet Card Selection by Index”

Concepts

- “PCI Bus I/O Devices”

readxpcfile

Purpose Read real-time Scope file format data (not recommended)

Syntax
`matlab_data = readxpcfile(xpcfile_name)`
`matlab_data = readxpcfile(xpcfile_data)`

Description `matlab_data = readxpcfile(xpcfile_name)` takes as an argument the name of a host computer file containing a vector of byte data (uint8). The file is copied from the target computer using `xpctarget.ftp` Class methods.

Note Function `readxpcfile` will be removed in a future release. Use `SimulinkRealTime.utils.getFileScopeData` instead.

`matlab_data = readxpcfile(xpcfile_data)` takes as an argument a MATLAB variable containing a vector of byte data (uint8). The data is read from the target computer using `xpctarget.fs` Class methods.

Input Arguments

xpcfile_name - Name of file from which to read real-time Scope file format data

`'data.dat'`

File must contain a vector of uint8 data.

Data Types

char

xpcfile_data - Workspace variable containing real-time Scope file format data

vector

Data Types

uint8

Output Arguments

matlab_data - State and time data for plotting

structure

The state and time data is stored in a structure containing six fields. The key fields are numSignals, data, and signalNames.

version - Version code

0 (default) | double

Internal

sector - Sector of data file

0 (default) | double

Internal

headersize - Number of bytes of data file header

512 (default) | double

Internal

numSignals - Number of columns containing signal and time data

double

If N signals are connected to the real-time Scope block, numSignals = $N + 1$.

data - Columns containing signal and time data

double array

The data array contains numSignals columns. The first N columns represent signal state data. The last column contains the time at which the state data is captured.

The data array contains as many rows as there are data points.

signalNames - Names of columns containing signal and time data

cell vector

The `signalNames` vector contains `numSignals` elements. The first N elements are signal names. The last element is the string `Time`.

Examples

These examples access a file on a target computer using different methods and plot the results. The model includes one scalar signal connected to a real-time Scope block of type `File`. The model has been built, downloaded, and run, producing file `'data.dat'` on the target computer.

Using `xpcfile_name` argument to read file and plot results

Upload the file using `xpctarget.ftp` Class methods. Read the file on the host using `readxpcfile`. Plot the results.

Upload file `'data.dat'` from the target computer.

```
xpcftp=xpctarget.ftp;  
xpcftp.get('data.dat');
```

Read the file and process its data into MATLAB format.

```
matlab_data=readxpcfile('data.dat');
```

Plot the signal data (column 1) on the Y axis against time (column 2) on the X axis.

```
plot(matlab_data.data(:,2), matlab_data.data(:,1));  
xlabel(matlab_data.signalNames(2));  
ylabel(matlab_data.signalNames(1));
```

Using `xpcfile_data` argument to store data, convert to MATLAB format, and plot results

Read the file on the target computer using `xpctarget.fs` Class methods. Store the data in a workspace variable. Convert the data to MATLAB format using `readxpcfile`. Plot the results.

Read file `'data.dat'` from the target computer.

```
f=xpctarget.fs;
```

```
h=f.fopen('data.dat');  
xpcfile_data=f.fread(h);  
f fclose(h);
```

Process data from the workspace variable into MATLAB format.

```
matlab_data=readxpcfile(xpcfile_data);
```

Plot the signal data (column 1) on the Y axis against time (column 2) on the X axis.

```
plot(matlab_data.data(:,2), matlab_data.data(:,1));  
xlabel(matlab_data.signalNames(2));  
ylabel(matlab_data.signalNames(1));
```

See Also

[Scope](#) | [xpctarget.ftp Class](#) | [xpctarget.fs Class](#)

setxpcenv

Purpose Change Simulink Real-Time environment properties (not recommended)

Syntax

```
setxpcenv
setxpcenv('property_name','property_value')
setxpcenv('prop_name1','prop_value1','prop_name2',. . .)
```

Arguments

property_name	Not case sensitive. Property names can be shortened as long as they can be differentiated from the other property names.
property_value	Character string. Type setxpcenv without arguments to get a listing of allowed values. Property values are not case sensitive.

Description Function to enter new values for environment properties. If the new value is different from the current value, the property is marked as having a new value. setxpcenv works similarly to the set function of the MATLAB Handle Graphics® system.

Note Command setxpcenv will be removed in a future release. Use SimulinkRealTime.targetSettings.set instead.

setxpcenv called without arguments returns a list of allowed property values in the MATLAB window.


setxpcenv('property_name','property_value') sets property property_name to property_value.

setxpcenv('prop_name1','prop_value1','prop_name2',. . .) is called with one or more argument pairs. The first argument of a pair is the property name; the second is the new value for this property.

The environment properties define communication between the host computer and target computer and the type of target boot kernel created during the setup process. With the exception of the Version property,

you can set environment properties using the `setxpcenv` function or the Simulink Real-Time Explorer window, accessed via the `xpcexplr` function. An understanding of the environment properties will help you configure the Simulink Real-Time environment.

Tip To access a subset of these properties in Simulink Real-Time Explorer:

- 1 Expand a target computer node in the **Targets** pane.
 - 2 Click the Target Properties icon  in the toolbar or double-click **Properties**.
-

- “Host-to-Target Communication” on page 1-37
- “Target Settings” on page 1-43
- “Boot Configuration” on page 1-47

Host-to-Target Communication

Environment Property	Description
HostTargetComm	<p>Property values are 'RS232' and 'TcpIp'.</p> <p>Select RS-232 or TCP/IP from the Communication type list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you select RS-232, you also must set the property <code>RS232HostPort</code>. If you select TCP/IP, then you must set the other properties that start with <code>TcpIp</code>.</p>

Environment Property	Description
	<hr/> <p>Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.</p> <hr/>
RS232Baudrate	<p>Property values are '115200', '57600', '38400', '19200', '9600', '4800', '2400', and '1200'.</p> <p>Select 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 from the Baud rate list in the Target Properties pane of Simulink Real-Time Explorer.</p>
RS232HostPort	<p>Property values are 'COM1' and 'COM2'.</p> <p>Select COM1 or COM2 from the Host port list in the Target Properties pane of Simulink Real-Time Explorer. The software automatically determines the COM port on the target computer.</p> <p>Before you can select an RS-232 port, you need to set the HostTargetComm property to RS232.</p>

Environment Property	Description
TcpIpGateway	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the IP address for your gateway in the Gateway box in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to 255.255.255.255, which means that a gateway is not used to connect to the target computer.</p> <p>If you communicate with your target computer from within a LAN that uses gateways, and your host and target computers are connected through a gateway, you must enter a value for this property. If your LAN does not use gateways, you do not need to change this property. Ask your system administrator.</p>
TcpIpSubNetMask	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the subnet mask of your LAN in the Subnet mask box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, your subnet mask could be 255.255.255.0.</p>

Environment Property	Description
TcpIpTargetAddress	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter a valid IP address for your target computer in the IP address box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, 192.168.0.10.</p>
TcpIpTargetBusType	<p>Property values are 'PCI', 'ISA', and 'USB'.</p> <p>Select PCI, ISA, or USB from the Bus type list in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to PCI, and determines the bus type of your target computer. You do not need to define a bus type for your host computer, which can be the same or different from the bus type in your target computer.</p> <p>If TcpIpTargetBusType is set to PCI, then the properties TcpIpISAMemPort and TcpIpISAIRQ have no effect on TCP/IP communication.</p> <p>If you are using an ISA bus card, set TcpIpTargetBusType to ISA and enter values</p>

Environment Property	Description
	for TcpIpISAMemPort and TcpIpISAIRQ.
TcpIpTargetDriver	<p>Property values are '3C90x', 'I8254x', 'I82559', 'NE2000', 'NS83815', 'R8139', 'R8168', 'Rhine', 'RTLANCE', 'SMC91C9X', 'USBAX772', 'USBAX172', and 'Auto'.</p> <p>Select THREECOM_3C90x, INTEL_I8254x, INTEL_I82559, NE2000, NS83815, R8139, R8168, Rhine, RTLANCE, SMC91C9X, USBAX772, USBAX172, or Auto from the Target driver list in the Target Properties pane of Simulink Real-Time Explorer.</p>
TcpIpTargetISAIRQ	<p>Property value is 'n', where <i>n</i> is between 5 and 15 inclusive.</p> <p>Select an IRQ value from the IRQ list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on the ISA-bus Ethernet card.</p>

Environment Property	Description
	<p>On your ISA bus card, assign an IRQ and I/O-port base address by moving the jumpers on the card.</p> <p>Set the IRQ to 5, 10, or 11. If one of these hardware settings leads to a conflict in your target computer, choose another IRQ and make the corresponding changes to your jumper settings.</p>
TcpIpTargetISAMemPort	<p>Property value is '0xnxxx'.</p> <p>Enter an I/O port base address in the Address box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on your ISA bus Ethernet card.</p> <p>On your ISA bus card, assign an IRQ and I/O port base address by moving the jumpers on the card.</p> <p>Set the I/O port base address to around 0x300. If one of these hardware settings leads to a conflict in your target computer, choose another I/O port base address and make the</p>

Environment Property	Description
	corresponding changes to your jumper settings.
TcpIpTargetPort	<p>Property value is 'xxxxx'.</p> <p>Enter a port address greater than 20000 in the Port box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>This property is set by default to 22222. The default value is higher than the reserved area (telnet, ftp, . . .) and is only of use on the target computer.</p>

Target Settings

Environment Property	Description
EthernetIndex	<p>Property value is 'n', where n indicates the index number for the Ethernet card on a target computer. Note that the $(n-1)$th Ethernet card on the target computer has an index number 'n'. The default index number is 0.</p> <p>If the target computer has multiple Ethernet cards, you must select one of the cards for host-target communication. This option returns the index number of the card selected on the target computer upon booting.</p>
LegacyMultiCoreConfig	<p>Property values are 'on' and 'off' (the default).</p> <p>Set this value to 'on' only if your target computer contains hardware not compliant with the Advanced Configuration and Power Interface (ACPI) standard. Otherwise, set this value to 'off'.</p>

Environment Property	Description
MaxModelSize	<p>Supported property values are '1MB' (the default) and '4MB'. Value '16MB' is not supported.</p> <p>Select 1 MB or 4 MB from the Model size list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Setting Model size is enabled for Boot mode Stand Alone only.</p> <p>Choosing the maximum model size reserves the specified amount of memory on the target computer for the target application. Memory not used by the target application is used by the kernel and by the heap for data logging.</p> <p>Selecting too high a value leaves less memory for data logging. Selecting too low a value does not reserve enough memory for the target application and creates an error. You can approximate the size of the target application by the size of the DLM file produced by the build process.</p>
MulticoreSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Multicore CPU check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your target computer has multicore processors, set this value to 'on' to take advantage of these processors for background tasks. Otherwise, set this value to 'off'.</p>
Name	Target computer name.

Environment Property	Description
NonPentiumSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Target is a 386/486 check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if your target computer has a 386 or 486 compatible processor. Otherwise, set it to 'off'. If your target computer has a Pentium or higher compatible processor, selecting this check box slows the performance of your target computer.</p>
SecondaryIDE	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Secondary IDE check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' only if you want to use the disks connected to a secondary IDE controller. If you do not have disks connected to the secondary IDE controller, leave this value set to 'off'.</p>
ShowHardware	<p>Property values are 'on' and 'off' (the default).</p> <p>If you create a target boot kernel when ShowHardware is 'on' and boot the target computer with it, the kernel displays the index, bus, slot, function, and target driver for each Ethernet card on the target monitor.</p> <p>The host computer cannot communicate with the target computer after the kernel boots with ShowHardware set.</p>

Environment Property	Description
TargetRAMSizeMB	<p>Property values are 'Auto' (the default) and 'xxx', where xxx is a positive value specifying the amount of RAM, in megabytes, installed on the target computer.</p> <p>Under RAM size, click the Auto or Manual button in the Target Properties pane of Simulink Real-Time Explorer. If you click Manual, enter the amount of RAM, in megabytes, installed on the target computer in the Size(MB) box.</p> <p>TargetRAMSizeMB defines the total amount of installed RAM in the target computer. This RAM is used for the kernel, target application, data logging, and other functions that use the heap.</p> <p>If TargetRAMSizeMB is assigned 'Auto', the target application reads the target computer BIOS and determines the amount of memory up to a maximum of 2 GB. If the target application cannot read the BIOS, you must select Manual mode and enter the amount of memory, in megabytes, up to a maximum of 2 GB.</p> <p>The Simulink Real-Time kernel can use only 2 GB of memory.</p>
TargetScope	<p>Property values are 'Disabled' and 'Enabled' (the default).</p> <p>Select or clear the Graphics mode check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you set TargetScope to Disabled, the target computer displays information as text.</p>

Environment Property	Description
	To use the full features of a target scope, install a keyboard on the target computer.
USBSupport	<p>Property values are 'on' (the default) and 'off'.</p> <p>Select or clear the USB Support check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if you want to use a USB port on the target computer; for example, to connect a USB mouse. Otherwise, set it to 'off'.</p>

Boot Configuration

Environment Property	Description
BootFloppyLocation	Drive name for creation of target boot disk.
DOSLoaderLocation	Location of DOSLoader files to boot target computers from devices other than floppy disk or CD.
TargetBoot	<p>Property values are 'BootFloppy', 'CDBoot', 'DOSLoader', 'NetworkBoot', and 'StandAlone'.</p> <p>Select Removable Disk, CD, DOS Loader, Network, or Stand Alone from the Boot mode list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your license file does not include the license for the Simulink Real-Time standalone</p>

Environment Property	Description
	<p>mode product, your only options are Removable Disk, CD, DOS Loader, and Network. With the Simulink Real-Time standalone mode product licensed and installed, you have the additional choice of Stand Alone.</p> <hr/> <p>Tip In the Target Properties pane of Simulink Real-Time Explorer, click the Create boot disk button to create a bootable image in the specified boot mode.</p>
TargetMACAddress	<p>Physical target computer MAC address from which to accept boot requests when booting within a dedicated network. Format the MAC address as six pairs of hexadecimal numbers, separated by colons:</p> <p>xx:xx:xx:xx:xx:xx</p> <p>To update the MAC address in Simulink Real-Time Explorer, first click the Reset button in the Target Properties pane. You can then click the Specify new MAC address button to enter a MAC address manually in the MAC address box. If you do not enter a MAC address manually, the software will obtain the</p>

Environment Property	Description
	MAC address automatically the next time you restart the target computer.

Examples

List the current environment properties.

```
setxpcenv
```

Change the serial communication port of the host computer to COM2.

```
setxpcenv('RS232HostPort','COM2')
```

See Also

```
getxpcenv | xpcbootdisk
```

How To

- “Ethernet Communication Setup”
- “RS-232 Communication Setup”
- “Target Boot Methods”
- “Command-Line Setup”

xpcbench

Purpose Benchmark Simulink Real-Time models on target computer

Syntax

```
xpcbench
xpcbench benchmark
xpcbench benchmark -reboot
xpcbench benchmark -cleanup
xpcbench benchmark -verbose
xpcbench benchmark -reboot -cleanup -verbose
```

```
expected_results = xpcbench()
current_results = xpcbench(benchmark, ___)
```

Description xpcbench benchmarks the real-time execution performance of Simulink Real-Time applications on your target computer. It compares the result to stored benchmark results from other computers.

Note Function xpcbench will be removed in a future release. Use slrtbench instead.

Benchmark execution includes generating benchmark models, building and downloading Simulink Real-Time applications, searching for the minimal achievable sample time, and displaying results.

xpcbench without an argument displays representative results for benchmarks run on various target computers with various compiler versions. Display includes:

- Relative Performance — Bar graph containing the computers tested, ranked by relative performance.
- Minimal achievable sample times in μs — Table containing, for each target computer tested, the minimal achievable sample time for the benchmarks, in microseconds.
- Target Information — Technical information about the target computers benchmarked.

Depending upon the value of `benchmark`, `xpcbench benchmark` produces different outputs:

- `xpcbench this` displays benchmark results your target computer, compared with the representative benchmark results for other target computers:
 - Relative Performance — Bar graph containing the computers tested, ranked by relative performance.
 - Minimal achievable sample times in μs — Table containing, for each target computer tested, the minimal achievable sample time for the benchmarks, in microseconds.
 - Target Information — Technical information about the target computers benchmarked.

The entry for your target computer is highlighted.

- `xpcbench benchmark` prints the benchmark name, the number of blocks, the model build time in seconds, the execution time in seconds, and the minimal achievable sample time in microseconds in the Command Window.

`xpcbench benchmark -reboot` runs the benchmark, then restarts the target computer.

`xpcbench benchmark -cleanup` runs the benchmark, plots or prints benchmark results, and deletes the build files.

`xpcbench benchmark -verbose` prints build output, runs the benchmark, and plots or prints benchmark results.

`xpcbench benchmark -reboot -cleanup -verbose` prints build output, restarts the target computer, deletes build files, and plots or prints results.

You can add zero or more of these control arguments in arbitrary order.

`expected_results = xpcbench()` returns the benchmark results for the five predefined benchmarks in a structure array.

Depending upon the value of `benchmark`, `current_results = xpcbench(benchmark, ___)` returns different results:

- `xpcbench('this')` returns the benchmark results for the predefined benchmarks in a structure array.
- `xpcbench(benchmark)` returns the benchmark results for the specified model in a structure.

Input Arguments

benchmark - Benchmark name or model name

`this` | `usermdl` | `minimal` | `f14` | `f14*5` | `f14*10` | `f14*25` | `f14*100`

Benchmark, specified as a literal string or string variable containing one of:

<code>this</code>	All five predefined benchmark models (<code>minimal</code> , <code>f14</code> , <code>f14*5</code> , <code>f14*10</code> , <code>f14*25</code>)
<code>usermdl</code>	Your model, <code>usermdl</code> .
<code>minimal</code>	Minimal model consisting of three blocks (Constant, Gain, Termination).
<code>f14</code>	Standard Simulink example <code>f14</code> (62 blocks, 10 continuous states).
<code>f14*5</code>	Five <code>f14</code> systems modeled in subsystems (310 blocks, 50 continuous states).
<code>f14*10</code>	Ten <code>f14</code> systems (620 blocks, 100 continuous states).
<code>f14*25</code>	25 <code>f14</code> systems (1550 blocks, 250 continuous states).
<code>f14*100</code>	100 <code>f14</code> systems (6200 blocks, 1000 continuous states).

When using function form, enclose literal arguments (`this`, `-reboot`) in single quotes (`'this'`, `'-reboot'`).

Example:

Data Types

`char`

Output Arguments

expected_results - Results of predefined benchmarks previously run on representative target computers

`struct array`

Contains representative benchmark results in a structure array with element fields:

<i>Machine</i>	Target computer information string containing CPU type, CPU speed, compiler
<i>BenchResults</i>	Target computer benchmark performance for all five predefined benchmarks
<i>Desc</i>	Target computer descriptor string containing machine type, RAM size, cache size

current_results - Current results of specified benchmark

`struct`

Contains actual benchmark results in a structure with fields:

<i>Name</i>	Benchmark name
<i>nBlocks</i>	Number of blocks in benchmark
<i>BuildTime</i>	Elapsed time in seconds to build benchmark

<i>BenchTime</i>	Elapsed time in seconds to run benchmark
<i>Tsmin</i>	Minimal achievable sample time in seconds for benchmark

Tips

- Before you run `xpcbench`, you must be able to start the target computer, connect the host computer to the target computer, and run the confidence test, `slrttest`, with no failures.
- After running `xpcbench` on your model and system, set your model sample time to the minimal achievable sample time value reported. Smaller sample times overload the target computer.
- The stored benchmark results were collected with **Multicore CPU support** disabled. When evaluating your system, temporarily disable this target setting using `slrtexplr`.
- The stored benchmark models were compiled using a sampling of the supported compilers. When evaluating your system, find the closest match to the compiler that you are using.
- Benchmark `minimal` has neither continuous nor discrete states. It provides information about the target computer interrupt latencies.

Examples

`xpcbench`


Show representative benchmark results from various target computers.

Start the target computer and run confidence test.

```
slrttest
```

Display representative results on predefined benchmarks.

```
xpcbench
```



xpcbench this

Benchmark the target computer with the predefined benchmarks.

Start the target computer and run confidence test.

```
slrtest
```


Run the benchmark models and display results.

```
xpcbench this
```

```
### Starting Simulink Real-Time build procedure
    for model: xpcminimal
### Successful completion of build procedure for model: xpcminimal
### Looking for target: TargetPC1
### Download model onto target: TargetPC1

### Running benchmark for model: xpcminimal
.
.
.
### Running benchmark for model: f14tmp1
.
.
.
### Running benchmark for model: f14tmp5
.
.
.
### Running benchmark for model: f14tmp10
.
.
.
### Running benchmark for model: f14tmp25
.
.
.
```


Running benchmark for model: f14tmp100



xpcbench this -verbose -reboot -cleanup

Benchmark the target computer with the predefined benchmarks, and then delete build files.

Start the target computer and run confidence test.


```
slrttest
```

Run the benchmark models, delete build files, and display results.

```
xpcbench this -verbose -reboot -cleanup
```

```
### Starting Simulink Real-Time build procedure
    for model: xpcminimal
### Generating code into build folder: xpcminimal_xpc_rtw
### Invoking Target Language Compiler on xpcminimal.rtw
.
.
.
### Successful completion of build procedure for model:
    xpcminimal
### Looking for target: TargetPC1
### Download model onto target: TargetPC1
### Create SimulinkRealTime.target object tg
Target: TargetPC1
    Connected                = Yes
.
.
.
### Running benchmark for model: xpcminimal
### Reboot target: TargetPC1..... OK.
.
.
### Running benchmark for model: f14tmp1
### Reboot target: TargetPC1..... OK.
.
.
```

```
.  
### Running benchmark for model: f14tmp5  
### Reboot target: TargetPC1..... OK.  
.br/>.br/>.br/>### Running benchmark for model: f14tmp10  
### Reboot target: TargetPC1..... OK.  
.br/>.br/>.br/>### Running benchmark for model: f14tmp25  
### Reboot target: TargetPC1..... OK.  
.br/>.br/>.br/>### Running benchmark for model: f14tmp100  
### Reboot target: TargetPC1..... OK.
```



xpcbench xpcosc

Use model xpcosc to benchmark the target computer, then clean up build files

Start the target computer and run confidence test.

```
slrtest
```

Run benchmark on xpcosc, delete build files, and print results.

```
xpcbench xpcosc
```

```
### Starting Simulink Real-Time build procedure
for model: xpcosc
### Successful completion of build procedure for model: xpcosc
### Looking for target: TargetPC1
### Download model onto target: TargetPC1

### Running benchmark for model: xpcosc

Benchmark results for model:                xpcosc
Number of blocks in model:                  10
Elapsed time for model build (sec):         33.4
Elapsed time for model benchmark (sec):     236.7
Minimal achievable sample time (microsec): 12.4
```

xpcbench xpcosc --verbose -reboot -cleanup

Use model xpcosc to benchmark the target computer, then clean up build files

Start the target computer and run confidence test.

```
slrtest
```

Run benchmark on xpcosc, delete build files, and print results.

```
xpcbench xpcosc -verbose -reboot -cleanup
```

```
### Starting Simulink Real-Time build procedure
for model: xpcosc
### Generating code into build folder: xpcosc_slrt_rtw
### Invoking Target Language Compiler on xpcosc.rtw
.
.
.
### Successful completion of build procedure for model: xpcosc
### Looking for target: TargetPC1
### Download model onto target: TargetPC1
### Create SimulinkRealTime.target object tg
Target: TargetPC1
    Connected          = Yes
.
.
.

### Running benchmark for model: xpcosc
### Reboot target: TargetPC1..... OK

Benchmark results for model:                xpcosc
Number of blocks in model:                  10
Elapsed time for model build (sec):         29.4
Elapsed time for model benchmark (sec):     210.5
Minimal achievable sample time (microsec): 10.9
```

expected_results = xpcbench()

Return a structure array containing benchmark results showing what to expect of various target computers.

Start the target computer and run confidence test.

slrttest


Return an array with representative results for each processor type, in arbitrary order.

xpcbench

```
expected_results = xpcbench();
expected_results(1)

ans =

    Machine: 'Generic Intel(R) Core(TM) 2 Quad (VisualC 10.0)'
    BenchResults: [1.2359e-05 1.3184e-05 1.5623e-05 1.8978e-05
                  3.1175e-05 1.2723e-04]
    Desc: '% Intel(R) Core(TM)2 Quad CPU Q6600 @ 2.40GHz
% RAM: 2044MB
% CP...'
```

```
current_results =  
xpcbench('xpcosc','-verbose','-reboot','-cleanup')
```

Benchmark the target computer using the xpcosc model and all control options, and return a structure array with results.

Start the target computer and run confidence test.

```
slrttest
```

Build 'xpcosc', print build messages, run benchmark, delete build files, restart the target computer, and return results.

```
current_results = xpcbench('xpcosc','-verbose','-reboot',  
    '-cleanup')
```

```
### Starting Simulink Real-Time build procedure  
for model: xpcosc  
### Generating code into build folder: xpcosc_slrt_rtw  
### Generated code for 'xpcosc' is up to date because no  
    structural, parameter or code replacement library  
    changes were found.  
  
. . .  
### Successful completion of build procedure for model: xpcosc  
### Looking for target: TargetPC1  
### Download model onto target: TargetPC1  
### Create SimulinkRealTime.target object tg  
Target: TargetPC1  
    Connected = Yes  
  
. . .  
### Running benchmark for model: xpcosc  
### Reboot target: TargetPC1..... OK  
  
Benchmark results for model: xpcosc
```

```
Number of blocks in model:          10
Elapsed time for model build (sec):  14.5
Elapsed time for model benchmark (sec): 200.5
Minimal achievable sample time (microsec): 11.9
```

```
current_results =
    Name: 'xpcosc'
    nBlocks: 10
    BuildTime: 14.4840
    BenchTime: 200.4516
    TsmIn: 1.1875e-05
```

See Also

slrtttest

**External
Web Sites**

- http://www.mathworks.com/support/compilers/current_release/

xpcbootdisk

Purpose Create Simulink Real-Time boot disk or DOS Loader files and confirm current environment properties (not recommended)

Syntax xpcbootdisk

Description xpcbootdisk creates an Simulink Real-Time boot floppy, CD or DVD boot image, network boot image, or DOS Loader files for the current Simulink Real-Time environment. Use the setxpcenv function to set environment properties.

Note Command xpcbootdisk will be removed in a future release. Use SimulinkRealTime.createBootImage instead.

What xpcbootdisk does depends upon the value of the TargetBoot property.

- **BootFloppy** — To create a boot floppy disk, the software prompts you to insert an empty formatted disk into the drive. The software writes the kernel image onto the disk and displays a summary of the creation process.
- **CDBoot** — To create a CD or DVD boot disk, the software prompts you to insert an empty formatted CD or DVD into the drive. The software writes the kernel image onto the CD or DVD and displays a summary of the creation process.
- **NetworkBoot** — To create a network boot image, the software starts the network boot server process.
- **DOSLoader** — To create DOS Loader files, the software writes kernel image and DOS Loader files into a designated location on the host computer. You can then copy the files to the target computer hard drive, to a floppy disk, or to a flash drive.
- **StandAlone** — To create files for a standalone application, you must separately compile and download a combined kernel and target

application. `SimulinkRealTime.createBootImage` does not generate a standalone application.

If you update the environment, you need to update the target boot floppy, CD boot image, network boot image, or DOS Loader files for the new Simulink Real-Time environment with the function `xpcbootdisk`.

Examples

To create a boot floppy disk, in the MATLAB window, type:

```
xpcbootdisk
```

See Also

`setxpcenv` | `getxpcenv` | `xpcnetboot`

How To

- “Target Boot Methods”
- “Command-Line Target Boot Methods”

xpcbytes2file

Purpose Generate file suitable for use by real-time From File block (not recommended)

Syntax `xpcbytes2file(filename,var1,...,varn)`

Arguments

<code>filename</code>	Name of the data file from which the From File block distributes data.
<code>var1, . . . ,varn</code>	Column of data to be output to the model.

Description `xpcbytes2file(filename,var1,...,varn)` outputs one column of `var1, . . . ,varn` from file `filename` at every time step. All variables must have the same number of columns; the number of rows and data types can differ.

Note Command `xpcbytes2file` will be removed in a future release. Use `SimulinkRealTime.utils.bytes2file` instead.

If the data is organized such that a row refers to a single time step and not a column. pass to `xpcbytes2file` the transpose of the variable. To optimize file writes, organize the data in columns.

Examples

In the following example, to use the real-time From File block to output a variable `errorval` (single precision, scalar) and `velocity` (double, width 3) at every time step, you can generate the file with the command:

```
xpcbytes2file('myfile', errorval, velocity)
```

where `errorval` has class `'single'` and dimensions `[1 x N]` and `velocity` has class `'double'` and dimensions `[3 x N]`.

Set up the real-time From File block to output

28 bytes

```
(1 * sizeof('single') + 3 * sizeof('double'))
```

at every sample time.

Purpose Configure target computer and target application for execution (not recommended)

Syntax xpcexplr


Description Typing xpcexplr at the MATLAB command prompt opens Simulink Real-Time Explorer.

Note Command xpcexplr will be removed in a future release. Use slrtexplr instead.

Simulink Real-Time Explorer includes the following capabilities:

- Environment configuration — Use the Simulink Real-Time Explorer **Target Properties** pane to configure the Simulink Real-Time environment properties and create an Simulink Real-Time bootable image.

Use node **File system** under the **MATLAB Session** tree to browse the target computer file system.
- Control — Use the Simulink Real-Time Explorer **Targets** and **Applications** panes to load, unload, and run target applications. You can change stop time and sample times without regenerating code, and get task execution time information during or after the last run.
- Signal acquisition — Use the Simulink Real-Time Explorer **Scopes** pane and the **Model Hierarchy** node in the **Applications** pane to interactively monitor signals, add host, target, or file scopes, add or remove signals, and save and load signal groups.
- Parameter tuning — Use the Simulink Real-Time Explorer **Model Hierarchy** node in the **Applications** pane to change tunable parameters in your target application and save and load parameter groups.

- Window configuration — Use the tab and the  icon to make multiple workspaces visible at the same time.


Use **File > Save Layout** and **Load Layout** to save and restore the Simulink Real-Time Explorer window layout.

Examples

Default

Open Simulink Real-Time Explorer

```
xpcexplr
```



Related Examples

- “Ethernet Communication Setup”
- “RS-232 Communication Setup”
- “Target Computer Settings”
- “Target Boot Methods”
- “Execute Target Application Using Simulink Real-Time Explorer”
- “Monitor Signals Using Simulink Real-Time Explorer”
- “Create Target Scopes Using Simulink Real-Time Explorer”

- “Create Host Scopes Using Simulink Real-Time Explorer”
- “Create File Scopes Using Simulink Real-Time Explorer”
- “Tune Parameters Using Simulink Real-Time Explorer”

xpcgetCC

Purpose Compiler settings for Simulink Real-Time environment (not recommended)

Syntax

```
type = xpcgetCC  
type = xpcgetCC('Type')  
[type, location] = xpcgetCC  
location= xpcgetCC('Location')  
xpcgetCC('supported')  
xpcgetCC('installed')  
[compilers] = xpcgetCC('installed')
```

Description *type* = xpcgetCC and *type* = xpcgetCC('Type') return the compiler type in *type*.

Note Function xpcgetCC will be removed in a future release. Use slrtgetCC instead.

[*type*, *location*] = xpcgetCC returns the compiler type and its location in *type* and *location*.

location= xpcgetCC('Location') returns the compiler location in *location*.

xpcgetCC('supported') lists supported compiler versions for the Simulink Real-Time environment.

xpcgetCC('installed') lists the Simulink Real-Time supported compilers installed on the current host computer

[*compilers*] = xpcgetCC('installed') returns the Simulink Real-Time supported compilers installed on the current host computer in a structure.

The `mex -setup` command sets the default compiler for Simulink Real-Time builds, provided the MEX compiler is a supported Microsoft® compiler. The `slrtgetCC` function returns the result of the `slrtsetCC` command only, not the result of the `mex` command. If `xpcgetCC` returns

an empty string as *location*, Simulink Real-Time uses the MEX compiler.

Examples

Return the compiler type.

```
type = xpcgetCC
```

Return the compiler type and compiler location.

```
[type, location] = xpcgetCC
```

Return the Simulink Real-Time supported compilers installed on the current host computer in a structure and access the structure fields

```
[compilers] = xpcgetCC('installed')
```

```
compilers =
```

```
1x3 struct array with fields:
```

```
    Type  
    Name  
    Location
```

```
compilers.Type
```

```
ans =
```

```
VisualC
```

See Also

```
xpcsetCC
```

xpcnetboot

Purpose Create kernel to boot target computer over dedicated network (not recommended)

Syntax
`xpcnetboot`
`xpcnetboot targetPCName`

Arguments

<i>targetPCName</i>	Target computer name as identified in Simulink Real-Time Explorer.
---------------------	--

Description `xpcnetboot` creates an Simulink Real-Time kernel from which a target computer within the same network can start.

Note Command `xpcnetboot` will be removed in a future release. Use `SimulinkRealTime.createBootImage` instead.

`xpcnetboot` starts the following services as server processes:

- Bootstrap protocol (bootp) — `xpcbootpserver.exe`
- Trivial file transfer protocol (tftp) — `xpctftpserver.exe`

These processes respond to network boot requests from the target computer.

`xpcnetboot` without an argument creates a kernel for the default target computer (as identified in Simulink Real-Time Explorer).

`xpcnetboot targetPCName` creates an Simulink Real-Time kernel and waits for a request from the target computer named *targetPCName* (as identified in Simulink Real-Time Explorer).

Examples In the following example, `xpcnetboot` creates an Simulink Real-Time kernel and waits for a request from the target computer, `TargetPC1`.

```
xpcnetboot TargetPC1
```

Purpose	Compiler settings for Simulink Real-Time environment (not recommended)
Syntax	<code>xpcsetCC('setup')</code> <code>xpcsetCC('location')</code> <code>xpcsetCC('type')</code> <code>xpcsetCC(type,location)</code>
Description	<code>xpcsetCC('setup')</code> queries the host computer for installed C compilers that the Simulink Real-Time environment supports. You can then select the C compiler.

Note Command `xpcsetCC` will be removed in a future release. Use `slrtsetCC` instead.

`xpcsetCC('location')` sets the compiler location.

`xpcsetCC('type')` sets the compiler type. `'type'` must be `VISUALC`, representing the Microsoft Visual Studio® C compiler.

`xpcsetCC(type,location)` sets the compiler type and location.

The command `mex -setup` sets the default compiler for Simulink Real-Time builds, provided the MEX compiler is a supported Microsoft compiler. Use `xpcsetCC -setup` only if you need to specify different compilers for MEX and Simulink Real-Time.

To return to the default compiler from a setting by `xpcsetCC`, type `xpcsetCC('VisualC','')`, setting the compiler location to the empty string.

See Also `xpcgetCC`

How To • “Command-Line C Compiler Configuration”

xpctarget Package

Purpose Package for Simulink Real-Time MATLAB classes (not recommended)

Description Use xpctarget package objects to access the MATLAB command line capabilities.

Note Package xpctarget will be removed in a future release. Use package SimulinkRealTime methods instead.

Functions

Assign these object creation functions to a MATLAB variable to get access to the properties and methods of the class.

Function	Description
xpctarget.fs	Create file system object
xpctarget.ftp	Create file transfer protocol (FTP) object
xpctarget.targets	Create container object to manage target computer environment collection objects
xpctarget.xpc	Create target object representing target application

Purpose Stores target environment properties (not recommended)

Description Each `xpctarget.env` Class object contains the environment properties for a particular target computer. A collection of these objects is stored in an `xpctarget.targets` Class object. An individual object in a collection is accessed via the `xpctarget.targets.Item (env collection object)` method.

Note Class `xpctarget.env` will be removed in a future release. Use `classSimulinkRealTime.targetSettings` instead.

Methods


Method	Description
<code>xpctarget.env.get (env object)</code>	Return property values for an environment object
<code>xpctarget.env.set (env object)</code>	Change property values for an environment object

xpctarget.env Class

Properties

The environment properties define communication between the host computer and target computer and the type of target boot floppy created during the setup process. An understanding of the environment properties will help you configure the Simulink Real-Time environment.

Tip To access a subset of these properties in Simulink Real-Time Explorer:

- 1 Expand a target computer node in the **Targets** pane.
- 2 Click the Target Properties icon  in the toolbar or double-click **Properties**.

-
- Host-to-Target Communication on page 82
 - Target Settings on page 88
 - Boot Configuration on page 92

Host-to-Target Communication

Environment Property	Description
HostTargetComm	<p>Property values are 'RS232' and 'TcpIp'.</p> <p>Select RS-232 or TCP/IP from the Communication type list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you select RS-232, you also must set the property RS232HostPort. If you select TCP/IP, then you must set the other properties that start with TcpIp.</p>

Environment Property	Description
	<p>Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.</p>
RS232Baudrate	<p>Property values are '115200', '57600', '38400', '19200', '9600', '4800', '2400', and '1200'.</p> <p>Select 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 from the Baud rate list in the Target Properties pane of Simulink Real-Time Explorer.</p>
RS232HostPort	<p>Property values are 'COM1' and 'COM2'.</p> <p>Select COM1 or COM2 from the Host port list in the Target Properties pane of Simulink Real-Time Explorer. The software automatically determines the COM port on the target computer.</p> <p>Before you can select an RS-232 port, you need to set the HostTargetComm property to RS232.</p>

xpctarget.env Class

Environment Property	Description
TcpIpGateway	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the IP address for your gateway in the Gateway box in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to 255.255.255.255, which means that a gateway is not used to connect to the target computer.</p> <p>If you communicate with your target computer from within a LAN that uses gateways, and your host and target computers are connected through a gateway, you must enter a value for this property. If your LAN does not use gateways, you do not need to change this property. Ask your system administrator.</p>
TcpIpSubNetMask	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the subnet mask of your LAN in the Subnet mask box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, your subnet mask could be 255.255.255.0.</p>

Environment Property	Description
TcpIpTargetAddress	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter a valid IP address for your target computer in the IP address box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, 192.168.0.10.</p>
TcpIpTargetBusType	<p>Property values are 'PCI', 'ISA', and 'USB'.</p> <p>Select PCI, ISA, or USB from the Bus type list in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to PCI, and determines the bus type of your target computer. You do not need to define a bus type for your host computer, which can be the same or different from the bus type in your target computer.</p> <p>If TcpIpTargetBusType is set to PCI, then the properties TcpIpISAMemPort and TcpIpISAIRQ have no effect on TCP/IP communication.</p> <p>If you are using an ISA bus card, set TcpIpTargetBusType to ISA and enter values</p>

xpctarget.env Class

Environment Property	Description
	for TcpIpISAMemPort and TcpIpISAIRQ.
TcpIpTargetDriver	<p>Property values are '3C90x', 'I8254x', 'I82559', 'NE2000', 'NS83815', 'R8139', 'R8168', 'Rhine', 'RTLANCE', 'SMC91C9X', 'USBAX772', 'USBAX172', and 'Auto'.</p> <p>Select THREECOM_3C90x, INTEL_I8254x, INTEL_I82559, NE2000, NS83815, R8139, R8168, Rhine, RTLANCE, SMC91C9X, USBAX772, USBAX172, or Auto from the Target driver list in the Target Properties pane of Simulink Real-Time Explorer.</p>
TcpIpTargetISAIRQ	<p>Property value is 'n', where <i>n</i> is between 5 and 15 inclusive.</p> <p>Select an IRQ value from the IRQ list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on the ISA-bus Ethernet card.</p>

Environment Property	Description
	<p>On your ISA bus card, assign an IRQ and I/O-port base address by moving the jumpers on the card.</p> <p>Set the IRQ to 5, 10, or 11. If one of these hardware settings leads to a conflict in your target computer, choose another IRQ and make the corresponding changes to your jumper settings.</p>
TcpIpTargetISAMemPort	<p>Property value is '0xnxxx'.</p> <p>Enter an I/O port base address in the Address box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on your ISA bus Ethernet card.</p> <p>On your ISA bus card, assign an IRQ and I/O port base address by moving the jumpers on the card.</p> <p>Set the I/O port base address to around 0x300. If one of these hardware settings leads to a conflict in your target computer, choose another I/O port base address and make the</p>

xpctarget.env Class

Environment Property	Description
	corresponding changes to your jumper settings.
TcpIpTargetPort	<p>Property value is 'xxxxx'.</p> <p>Enter a port address greater than 20000 in the Port box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>This property is set by default to 22222. The default value is higher than the reserved area (telnet, ftp, . . .) and is only of use on the target computer.</p>

Target Settings

Environment Property	Description
EthernetIndex	<p>Property value is 'n', where n indicates the index number for the Ethernet card on a target computer. Note that the $(n-1)$th Ethernet card on the target computer has an index number 'n'. The default index number is 0.</p> <p>If the target computer has multiple Ethernet cards, you must select one of the cards for host-target communication. This option returns the index number of the card selected on the target computer upon booting.</p>
LegacyMultiCoreConfig	<p>Property values are 'on' and 'off' (the default).</p> <p>Set this value to 'on' only if your target computer contains hardware not compliant with the Advanced Configuration and Power Interface (ACPI) standard. Otherwise, set this value to 'off'.</p>

Environment Property	Description
MaxModelSize	<p>Supported property values are '1MB' (the default) and '4MB'. Value '16MB' is not supported.</p> <p>Select 1 MB or 4 MB from the Model size list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Setting Model size is enabled for Boot mode Stand Alone only.</p> <p>Choosing the maximum model size reserves the specified amount of memory on the target computer for the target application. Memory not used by the target application is used by the kernel and by the heap for data logging.</p> <p>Selecting too high a value leaves less memory for data logging. Selecting too low a value does not reserve enough memory for the target application and creates an error. You can approximate the size of the target application by the size of the DLM file produced by the build process.</p>
MulticoreSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Multicore CPU check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your target computer has multicore processors, set this value to 'on' to take advantage of these processors for background tasks. Otherwise, set this value to 'off'.</p>
Name	Target computer name.

xpctarget.env Class

Environment Property	Description
NonPentiumSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Target is a 386/486 check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if your target computer has a 386 or 486 compatible processor. Otherwise, set it to 'off'. If your target computer has a Pentium or higher compatible processor, selecting this check box slows the performance of your target computer.</p>
SecondaryIDE	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Secondary IDE check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' only if you want to use the disks connected to a secondary IDE controller. If you do not have disks connected to the secondary IDE controller, leave this value set to 'off'.</p>
ShowHardware	<p>Property values are 'on' and 'off' (the default).</p> <p>If you create a target boot kernel when ShowHardware is 'on' and boot the target computer with it, the kernel displays the index, bus, slot, function, and target driver for each Ethernet card on the target monitor.</p> <p>The host computer cannot communicate with the target computer after the kernel boots with ShowHardware set.</p>

Environment Property	Description
TargetRAMSizeMB	<p>Property values are 'Auto' (the default) and 'xxx', where xxx is a positive value specifying the amount of RAM, in megabytes, installed on the target computer.</p> <p>Under RAM size, click the Auto or Manual button in the Target Properties pane of Simulink Real-Time Explorer. If you click Manual, enter the amount of RAM, in megabytes, installed on the target computer in the Size(MB) box.</p> <p>TargetRAMSizeMB defines the total amount of installed RAM in the target computer. This RAM is used for the kernel, target application, data logging, and other functions that use the heap.</p> <p>If TargetRAMSizeMB is assigned 'Auto', the target application reads the target computer BIOS and determines the amount of memory up to a maximum of 2 GB. If the target application cannot read the BIOS, you must select Manual mode and enter the amount of memory, in megabytes, up to a maximum of 2 GB.</p> <p>The Simulink Real-Time kernel can use only 2 GB of memory.</p>
TargetScope	<p>Property values are 'Disabled' and 'Enabled' (the default).</p> <p>Select or clear the Graphics mode check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you set TargetScope to Disabled, the target computer displays information as text.</p>

xpctarget.env Class

Environment Property	Description
	To use the full features of a target scope, install a keyboard on the target computer.
USBSupport	<p>Property values are 'on' (the default) and 'off'.</p> <p>Select or clear the USB Support check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if you want to use a USB port on the target computer; for example, to connect a USB mouse. Otherwise, set it to 'off'.</p>

Boot Configuration

Environment Property	Description
BootFloppyLocation	Drive name for creation of target boot disk.
DOSLoaderLocation	Location of DOSLoader files to boot target computers from devices other than floppy disk or CD.
TargetBoot	<p>Property values are 'BootFloppy', 'CDBoot', 'DOSLoader', 'NetworkBoot', and 'StandAlone'.</p> <p>Select Removable Disk, CD, DOS Loader, Network, or Stand Alone from the Boot mode list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your license file does not include the license for the Simulink Real-Time standalone mode product, your only options</p>

Environment Property	Description
	<p>are Removable Disk, CD, DOS Loader, and Network. With the Simulink Real-Time standalone mode product licensed and installed, you have the additional choice of Stand Alone.</p> <hr/> <p>Tip In the Target Properties pane of Simulink Real-Time Explorer, click the Create boot disk button to create a bootable image in the specified boot mode.</p> <hr/>
TargetMACAddress	<p>Physical target computer MAC address from which to accept boot requests when booting within a dedicated network. Format the MAC address as six pairs of hexadecimal numbers, separated by colons:</p> <p>xx:xx:xx:xx:xx:xx</p> <p>To update the MAC address in Simulink Real-Time Explorer, first click the Reset button in the Target Properties pane. You can then click the Specify new MAC address button to enter a MAC address manually in the MAC address box. If you do not enter a MAC address manually, the software will obtain the MAC address automatically the</p>

xpctarget.env Class

Environment Property	Description
	next time you restart the target computer.

Purpose Return target environment property values (not recommended)

Syntax

```
property_value = env_object.property_name  
property_value = env_object.get('property_name')  
property_value = get(env_object, 'property_name')  
property_value = env_object.get  
property_value = get(env_object)
```

Arguments

env_object	Name of a target environment object.
property_name	Name of a target environment object property.

Description `property_value = env_object.property_name` gets the current value of property `property_name` from target environment object `env_object`.

Note Method `xpctarget.env.get (env object)` will be removed in a future release. Use `SimulinkRealTime.getTargetSettings` instead.

Alternative syntaxes are:

```
property_value = env_object.get('property_name')
```

```
property_value = get(env_object, 'property_name')
```

`property_value = env_object.get` gets the values of all properties of target environment object `env_object`. An alternative syntax is:

```
property_value = get(env_object)
```


Get an individual environment object with the `xpctarget.targets.Item (env collection object)` method. For example:

```
tgs=xpctarget.targets;  
env_object=tgs.Item('TargetPC1');  
property_value=env_object.HostTargetComm
```

xpctarget.env.get (env object)

The environment properties for a target environment object are listed in the following tables.

Tip To access a subset of these properties in Simulink Real-Time Explorer:

- 1 Expand a target computer node in the **Targets** pane.
- 2 Click the Target Properties icon  in the toolbar or double-click **Properties**.

-
- “Host-to-Target Communication” on page 1-96
 - “Target Settings” on page 1-102
 - “Boot Configuration” on page 1-106

Host-to-Target Communication

Environment Property	Description
HostTargetComm	<p>Property values are 'RS232' and 'TcpIp'.</p> <p>Select RS-232 or TCP/IP from the Communication type list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you select RS-232, you also must set the property RS232HostPort. If you select TCP/IP, then you must set the other properties that start with TcpIp.</p>

Environment Property	Description
	<hr/> <p>Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.</p> <hr/>
RS232Baudrate	<p>Property values are '115200', '57600', '38400', '19200', '9600', '4800', '2400', and '1200'.</p> <p>Select 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 from the Baud rate list in the Target Properties pane of Simulink Real-Time Explorer.</p>
RS232HostPort	<p>Property values are 'COM1' and 'COM2'.</p> <p>Select COM1 or COM2 from the Host port list in the Target Properties pane of Simulink Real-Time Explorer. The software automatically determines the COM port on the target computer.</p> <p>Before you can select an RS-232 port, you need to set the HostTargetComm property to RS232.</p>

xpctarget.env.get (env object)

Environment Property	Description
TcpIpGateway	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the IP address for your gateway in the Gateway box in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to 255.255.255.255, which means that a gateway is not used to connect to the target computer.</p> <p>If you communicate with your target computer from within a LAN that uses gateways, and your host and target computers are connected through a gateway, you must enter a value for this property. If your LAN does not use gateways, you do not need to change this property. Ask your system administrator.</p>
TcpIpSubNetMask	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the subnet mask of your LAN in the Subnet mask box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, your subnet mask could be 255.255.255.0.</p>

Environment Property	Description
TcpIpTargetAddress	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter a valid IP address for your target computer in the IP address box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, 192.168.0.10.</p>
TcpIpTargetBusType	<p>Property values are 'PCI', 'ISA', and 'USB'.</p> <p>Select PCI, ISA, or USB from the Bus type list in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to PCI, and determines the bus type of your target computer. You do not need to define a bus type for your host computer, which can be the same or different from the bus type in your target computer.</p> <p>If TcpIpTargetBusType is set to PCI, then the properties TcpIpISAMemPort and TcpIpISAIRQ have no effect on TCP/IP communication.</p> <p>If you are using an ISA bus card, set TcpIpTargetBusType to ISA and enter values</p>

xpctarget.env.get (env object)

Environment Property	Description
	for TcpIpISAMemPort and TcpIpISAIRQ.
TcpIpTargetDriver	<p>Property values are '3C90x', 'I8254x', 'I82559', 'NE2000', 'NS83815', 'R8139', 'R8168', 'Rhine', 'RTLANCE', 'SMC91C9X', 'USBAX772', 'USBAX172', and 'Auto'.</p> <p>Select THREECOM_3C90x, INTEL_I8254x, INTEL_I82559, NE2000, NS83815, R8139, R8168, Rhine, RTLANCE, SMC91C9X, USBAX772, USBAX172, or Auto from the Target driver list in the Target Properties pane of Simulink Real-Time Explorer.</p>
TcpIpTargetISAIRQ	<p>Property value is 'n', where <i>n</i> is between 5 and 15 inclusive.</p> <p>Select an IRQ value from the IRQ list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on the ISA-bus Ethernet card.</p>

Environment Property	Description
	<p>On your ISA bus card, assign an IRQ and I/O-port base address by moving the jumpers on the card.</p> <p>Set the IRQ to 5, 10, or 11. If one of these hardware settings leads to a conflict in your target computer, choose another IRQ and make the corresponding changes to your jumper settings.</p>
TcpIpTargetISAMemPort	<p>Property value is '0xnnnn'.</p> <p>Enter an I/O port base address in the Address box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on your ISA bus Ethernet card.</p> <p>On your ISA bus card, assign an IRQ and I/O port base address by moving the jumpers on the card.</p> <p>Set the I/O port base address to around 0x300. If one of these hardware settings leads to a conflict in your target computer, choose another I/O port base address and make the</p>

xpctarget.env.get (env object)

Environment Property	Description
	corresponding changes to your jumper settings.
TcpIpTargetPort	<p>Property value is 'xxxxx'.</p> <p>Enter a port address greater than 20000 in the Port box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>This property is set by default to 22222. The default value is higher than the reserved area (telnet, ftp, . . .) and is only of use on the target computer.</p>

Target Settings

Environment Property	Description
EthernetIndex	<p>Property value is 'n', where <i>n</i> indicates the index number for the Ethernet card on a target computer. Note that the (n-1)th Ethernet card on the target computer has an index number 'n'. The default index number is 0.</p> <p>If the target computer has multiple Ethernet cards, you must select one of the cards for host-target communication. This option returns the index number of the card selected on the target computer upon booting.</p>
LegacyMultiCoreConfig	<p>Property values are 'on' and 'off' (the default).</p> <p>Set this value to 'on' only if your target computer contains hardware not compliant with the Advanced Configuration and Power Interface (ACPI) standard. Otherwise, set this value to 'off'.</p>

Environment Property	Description
MaxModelSize	<p>Supported property values are '1MB' (the default) and '4MB'. Value '16MB' is not supported.</p> <p>Select 1 MB or 4 MB from the Model size list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Setting Model size is enabled for Boot mode Stand Alone only.</p> <p>Choosing the maximum model size reserves the specified amount of memory on the target computer for the target application. Memory not used by the target application is used by the kernel and by the heap for data logging.</p> <p>Selecting too high a value leaves less memory for data logging. Selecting too low a value does not reserve enough memory for the target application and creates an error. You can approximate the size of the target application by the size of the DLM file produced by the build process.</p>
MulticoreSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Multicore CPU check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your target computer has multicore processors, set this value to 'on' to take advantage of these processors for background tasks. Otherwise, set this value to 'off'.</p>
Name	Target computer name.

xpctarget.env.get (env object)

Environment Property	Description
NonPentiumSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Target is a 386/486 check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if your target computer has a 386 or 486 compatible processor. Otherwise, set it to 'off'. If your target computer has a Pentium or higher compatible processor, selecting this check box slows the performance of your target computer.</p>
SecondaryIDE	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Secondary IDE check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' only if you want to use the disks connected to a secondary IDE controller. If you do not have disks connected to the secondary IDE controller, leave this value set to 'off'.</p>
ShowHardware	<p>Property values are 'on' and 'off' (the default).</p> <p>If you create a target boot kernel when ShowHardware is 'on' and boot the target computer with it, the kernel displays the index, bus, slot, function, and target driver for each Ethernet card on the target monitor.</p> <p>The host computer cannot communicate with the target computer after the kernel boots with ShowHardware set.</p>

Environment Property	Description
TargetRAMSizeMB	<p>Property values are 'Auto' (the default) and 'xxx', where xxx is a positive value specifying the amount of RAM, in megabytes, installed on the target computer.</p> <p>Under RAM size, click the Auto or Manual button in the Target Properties pane of Simulink Real-Time Explorer. If you click Manual, enter the amount of RAM, in megabytes, installed on the target computer in the Size(MB) box.</p> <p>TargetRAMSizeMB defines the total amount of installed RAM in the target computer. This RAM is used for the kernel, target application, data logging, and other functions that use the heap.</p> <p>If TargetRAMSizeMB is assigned 'Auto', the target application reads the target computer BIOS and determines the amount of memory up to a maximum of 2 GB. If the target application cannot read the BIOS, you must select Manual mode and enter the amount of memory, in megabytes, up to a maximum of 2 GB.</p> <p>The Simulink Real-Time kernel can use only 2 GB of memory.</p>
TargetScope	<p>Property values are 'Disabled' and 'Enabled' (the default).</p> <p>Select or clear the Graphics mode check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you set TargetScope to Disabled, the target computer displays information as text.</p>

xpctarget.env.get (env object)

Environment Property	Description
	To use the full features of a target scope, install a keyboard on the target computer.
USBSupport	<p>Property values are 'on' (the default) and 'off'.</p> <p>Select or clear the USB Support check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if you want to use a USB port on the target computer; for example, to connect a USB mouse. Otherwise, set it to 'off'.</p>

Boot Configuration

Environment Property	Description
BootFloppyLocation	Drive name for creation of target boot disk.
DOSLoaderLocation	Location of DOSLoader files to boot target computers from devices other than floppy disk or CD.
TargetBoot	<p>Property values are 'BootFloppy', 'CDBoot', 'DOSLoader', 'NetworkBoot', and 'StandAlone'.</p> <p>Select Removable Disk, CD, DOS Loader, Network, or Stand Alone from the Boot mode list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your license file does not include the license for the Simulink Real-Time standalone</p>

Environment Property	Description
	<p>mode product, your only options are Removable Disk, CD, DOS Loader, and Network. With the Simulink Real-Time standalone mode product licensed and installed, you have the additional choice of Stand Alone.</p> <hr/> <p>Tip In the Target Properties pane of Simulink Real-Time Explorer, click the Create boot disk button to create a bootable image in the specified boot mode.</p> <hr/>
TargetMACAddress	<p>Physical target computer MAC address from which to accept boot requests when booting within a dedicated network. Format the MAC address as six pairs of hexadecimal numbers, separated by colons:</p> <p>xx:xx:xx:xx:xx:xx</p> <p>To update the MAC address in Simulink Real-Time Explorer, first click the Reset button in the Target Properties pane. You can then click the Specify new MAC address button to enter a MAC address manually in the MAC address box. If you do not enter a MAC address manually, the software will obtain the</p>

xpctarget.env.get (env object)

Environment Property	Description
	MAC address automatically the next time you restart the target computer.

See Also

`xpctarget.env.set (env object)`

Purpose Change target environment object property values (not recommended)

Syntax

```
env_object.property_name = property_value  
env_object.set('prop_name1','prop_value1','prop_name2',. . .)  
set(env_object,'prop_name1','prop_value1','prop_name2',. . .)
```

Arguments

env_object	Name of a target environment object.
property_name	Name of a target environment object property.
property_value	Value for a target environment object property. Always use quotation marks for character strings; quotation marks are optional for numbers.

Description env_object.property_name = property_value sets property property_name of target environment object env_object to property_value.

Note Method xpctarget.env.set (env object) will be removed in a future release. Use SimulinkRealTime.targetSettings.set instead.

Alternative syntaxes for one or more property-value pairs are:

```
env_object.set('prop_name1','prop_value1','prop_name2',. . .  
.)  
set(env_object,'prop_name1','prop_value1','prop_name2',. . .  
.)
```

Get an individual environment object with the xpctarget.targets.Item (env collection object) method. For example:


```
tgs=xpctarget.targets;  
env_object=tgs.Item('TargetPC1');
```

xpctarget.env.set (env object)

```
env_object.HostTargetComm='RS232'
```

Not all properties are user writable. The writable properties for a target environment object are listed in the following table.

Tip To access a subset of these properties in Simulink Real-Time Explorer:

- 1 Expand a target computer node in the **Targets** pane.
- 2 Click the Target Properties icon  in the toolbar or double-click **Properties**.

-
- “Host-to-Target Communication” on page 1-110
 - “Target Settings” on page 1-116
 - “Boot Configuration” on page 1-120

Host-to-Target Communication

Environment Property	Description
HostTargetComm	<p>Property values are 'RS232' and 'TcpIp'.</p> <p>Select RS-232 or TCP/IP from the Communication type list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you select RS-232, you also must set the property RS232HostPort. If you select TCP/IP, then you must set the other properties that start with TcpIp.</p>

Environment Property	Description
	<hr/> <p>Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.</p> <hr/>
RS232Baudrate	<p>Property values are '115200', '57600', '38400', '19200', '9600', '4800', '2400', and '1200'.</p> <p>Select 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 from the Baud rate list in the Target Properties pane of Simulink Real-Time Explorer.</p>
RS232HostPort	<p>Property values are 'COM1' and 'COM2'.</p> <p>Select COM1 or COM2 from the Host port list in the Target Properties pane of Simulink Real-Time Explorer. The software automatically determines the COM port on the target computer.</p> <p>Before you can select an RS-232 port, you need to set the HostTargetComm property to RS232.</p>

xpctarget.env.set (env object)

Environment Property	Description
TcpIpGateway	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the IP address for your gateway in the Gateway box in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to 255.255.255.255, which means that a gateway is not used to connect to the target computer.</p> <p>If you communicate with your target computer from within a LAN that uses gateways, and your host and target computers are connected through a gateway, you must enter a value for this property. If your LAN does not use gateways, you do not need to change this property. Ask your system administrator.</p>
TcpIpSubNetMask	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter the subnet mask of your LAN in the Subnet mask box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, your subnet mask could be 255.255.255.0.</p>

Environment Property	Description
TcpIpTargetAddress	<p>Property value is 'xxx.xxx.xxx.xxx'.</p> <p>Enter a valid IP address for your target computer in the IP address box in the Target Properties pane of Simulink Real-Time Explorer. Ask your system administrator for this value.</p> <p>For example, 192.168.0.10.</p>
TcpIpTargetBusType	<p>Property values are 'PCI', 'ISA', and 'USB'.</p> <p>Select PCI, ISA, or USB from the Bus type list in the Target Properties pane of Simulink Real-Time Explorer. This property is set by default to PCI, and determines the bus type of your target computer. You do not need to define a bus type for your host computer, which can be the same or different from the bus type in your target computer.</p> <p>If TcpIpTargetBusType is set to PCI, then the properties TcpIpISAMemPort and TcpIpISAIRQ have no effect on TCP/IP communication.</p> <p>If you are using an ISA bus card, set TcpIpTargetBusType to ISA and enter values</p>

xpctarget.env.set (env object)

Environment Property	Description
	for TcpIpISAMemPort and TcpIpISAIRQ.
TcpIpTargetDriver	<p>Property values are '3C90x', 'I8254x', 'I82559', 'NE2000', 'NS83815', 'R8139', 'R8168', 'Rhine', 'RTLANCE', 'SMC91C9X', 'USBAX772', 'USBAX172', and 'Auto'.</p> <p>Select THREECOM_3C90x, INTEL_I8254x, INTEL_I82559, NE2000, NS83815, R8139, R8168, Rhine, RTLANCE, SMC91C9X, USBAX772, USBAX172, or Auto from the Target driver list in the Target Properties pane of Simulink Real-Time Explorer.</p>
TcpIpTargetISAIRQ	<p>Property value is 'n', where <i>n</i> is between 5 and 15 inclusive.</p> <p>Select an IRQ value from the IRQ list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on the ISA-bus Ethernet card.</p>

Environment Property	Description
	<p>On your ISA bus card, assign an IRQ and I/O-port base address by moving the jumpers on the card.</p> <p>Set the IRQ to 5, 10, or 11. If one of these hardware settings leads to a conflict in your target computer, choose another IRQ and make the corresponding changes to your jumper settings.</p>
TcpIpTargetISAMemPort	<p>Property value is '0xnnnn'.</p> <p>Enter an I/O port base address in the Address box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you are using an ISA bus Ethernet card, you must enter values for the properties TcpIpISAMemPort and TcpIpISAIRQ. The values of these properties must correspond to the jumper settings or ROM settings on your ISA bus Ethernet card.</p> <p>On your ISA bus card, assign an IRQ and I/O port base address by moving the jumpers on the card.</p> <p>Set the I/O port base address to around 0x300. If one of these hardware settings leads to a conflict in your target computer, choose another I/O port base address and make the</p>

xpctarget.env.set (env object)

Environment Property	Description
	corresponding changes to your jumper settings.
TcpIpTargetPort	<p>Property value is 'xxxxx'.</p> <p>Enter a port address greater than 20000 in the Port box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>This property is set by default to 22222. The default value is higher than the reserved area (telnet, ftp, . . .) and is only of use on the target computer.</p>

Target Settings

Environment Property	Description
EthernetIndex	<p>Property value is 'n', where <i>n</i> indicates the index number for the Ethernet card on a target computer. Note that the (n-1)th Ethernet card on the target computer has an index number 'n'. The default index number is 0.</p> <p>If the target computer has multiple Ethernet cards, you must select one of the cards for host-target communication. This option returns the index number of the card selected on the target computer upon booting.</p>
LegacyMultiCoreConfig	<p>Property values are 'on' and 'off' (the default).</p> <p>Set this value to 'on' only if your target computer contains hardware not compliant with the Advanced Configuration and Power Interface (ACPI) standard. Otherwise, set this value to 'off'.</p>

Environment Property	Description
MaxModelSize	<p>Supported property values are '1MB' (the default) and '4MB'. Value '16MB' is not supported.</p> <p>Select 1 MB or 4 MB from the Model size list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Setting Model size is enabled for Boot mode Stand Alone only.</p> <p>Choosing the maximum model size reserves the specified amount of memory on the target computer for the target application. Memory not used by the target application is used by the kernel and by the heap for data logging.</p> <p>Selecting too high a value leaves less memory for data logging. Selecting too low a value does not reserve enough memory for the target application and creates an error. You can approximate the size of the target application by the size of the DLM file produced by the build process.</p>
MulticoreSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Multicore CPU check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your target computer has multicore processors, set this value to 'on' to take advantage of these processors for background tasks. Otherwise, set this value to 'off'.</p>
Name	Target computer name.

xpctarget.env.set (env object)

Environment Property	Description
NonPentiumSupport	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Target is a 386/486 check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if your target computer has a 386 or 486 compatible processor. Otherwise, set it to 'off'. If your target computer has a Pentium or higher compatible processor, selecting this check box slows the performance of your target computer.</p>
SecondaryIDE	<p>Property values are 'on' and 'off' (the default).</p> <p>Select or clear the Secondary IDE check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' only if you want to use the disks connected to a secondary IDE controller. If you do not have disks connected to the secondary IDE controller, leave this value set to 'off'.</p>
ShowHardware	<p>Property values are 'on' and 'off' (the default).</p> <p>If you create a target boot kernel when ShowHardware is 'on' and boot the target computer with it, the kernel displays the index, bus, slot, function, and target driver for each Ethernet card on the target monitor.</p> <p>The host computer cannot communicate with the target computer after the kernel boots with ShowHardware set.</p>

Environment Property	Description
TargetRAMSizeMB	<p>Property values are 'Auto' (the default) and 'xxx', where xxx is a positive value specifying the amount of RAM, in megabytes, installed on the target computer.</p> <p>Under RAM size, click the Auto or Manual button in the Target Properties pane of Simulink Real-Time Explorer. If you click Manual, enter the amount of RAM, in megabytes, installed on the target computer in the Size(MB) box.</p> <p>TargetRAMSizeMB defines the total amount of installed RAM in the target computer. This RAM is used for the kernel, target application, data logging, and other functions that use the heap.</p> <p>If TargetRAMSizeMB is assigned 'Auto', the target application reads the target computer BIOS and determines the amount of memory up to a maximum of 2 GB. If the target application cannot read the BIOS, you must select Manual mode and enter the amount of memory, in megabytes, up to a maximum of 2 GB.</p> <p>The Simulink Real-Time kernel can use only 2 GB of memory.</p>
TargetScope	<p>Property values are 'Disabled' and 'Enabled' (the default).</p> <p>Select or clear the Graphics mode check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If you set TargetScope to Disabled, the target computer displays information as text.</p>

xpctarget.env.set (env object)

Environment Property	Description
	To use the full features of a target scope, install a keyboard on the target computer.
USBSupport	<p>Property values are 'on' (the default) and 'off'.</p> <p>Select or clear the USB Support check box in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>Set this value to 'on' if you want to use a USB port on the target computer; for example, to connect a USB mouse. Otherwise, set it to 'off'.</p>

Boot Configuration

Environment Property	Description
BootFloppyLocation	Drive name for creation of target boot disk.
DOSLoaderLocation	Location of DOSLoader files to boot target computers from devices other than floppy disk or CD.
TargetBoot	<p>Property values are 'BootFloppy', 'CDBoot', 'DOSLoader', 'NetworkBoot', and 'StandAlone'.</p> <p>Select Removable Disk, CD, DOS Loader, Network, or Stand Alone from the Boot mode list in the Target Properties pane of Simulink Real-Time Explorer.</p> <p>If your license file does not include the license for the Simulink Real-Time standalone</p>

Environment Property	Description
	<p>mode product, your only options are Removable Disk, CD, DOS Loader, and Network. With the Simulink Real-Time standalone mode product licensed and installed, you have the additional choice of Stand Alone.</p> <hr/> <p>Tip In the Target Properties pane of Simulink Real-Time Explorer, click the Create boot disk button to create a bootable image in the specified boot mode.</p> <hr/>
TargetMACAddress	<p>Physical target computer MAC address from which to accept boot requests when booting within a dedicated network. Format the MAC address as six pairs of hexadecimal numbers, separated by colons:</p> <p>xx:xx:xx:xx:xx:xx</p> <p>To update the MAC address in Simulink Real-Time Explorer, first click the Reset button in the Target Properties pane. You can then click the Specify new MAC address button to enter a MAC address manually in the MAC address box. If you do not enter a MAC address manually, the software will obtain the</p>

xpctarget.env.set (env object)

Environment Property	Description
	MAC address automatically the next time you restart the target computer.

See Also

`xpctarget.env.get (env object)`

Purpose Manage the folders and files on the target computer (not recommended)

Description This class includes the folder methods from `xpctarget.fsbase` Class and implements file access methods used on the target computer.

Note Class `xpctarget.fs` will be removed in a future release. Use class `SimulinkRealTime.fileSystem` instead.

Constructor

Constructor	Description
<code>xpctarget.fs</code>	Create file system object

Methods

These methods are inherited from `xpctarget.fsbase` Class.

Method	Description
<code>xpctarget.fsbase.cd</code>	Change folder on target computer
<code>xpctarget.fsbase.dir</code>	List contents of current folder on target computer
<code>xpctarget.fsbase.mkdir</code>	Make folder on target computer
<code>xpctarget.fsbase.pwd</code>	Current folder path of target computer
<code>xpctarget.fsbase.rmdir</code>	Remove folder from target computer

These methods are specific to class `fs`.

Method	Description
<code>xpctarget.fs.diskinfo</code>	Information about target computer drive
<code>xpctarget.fs.fclose</code>	Close open target computer file(s)
<code>xpctarget.fs.fileinfo</code>	Target computer file information
<code>xpctarget.fs.filetable</code>	Information about open files in target computer file system

xpctarget.fs Class

Method	Description
<code>xpctarget.fs.fopen</code>	Open target computer file for reading
<code>xpctarget.fs.fread</code>	Read open target computer file
<code>xpctarget.fs.fwrite</code>	Write binary data to open target computer file
<code>xpctarget.fs.getfilesize</code>	Size of file on target computer
<code>xpctarget.fs.removefile</code>	Remove file from target computer

Purpose Create Simulink Real-Time file system object (not recommended)

Syntax

```
fileSYS_object = xpctarget.fs  
fileSYS_object = xpctarget.fs(target_object)  
fileSYS_object = xpctarget.fs  
fileSYS_object = xpctarget.fs()
```

Arguments

<code>fileSYS_object</code>	Variable name to reference the file system object.
<code>target_object</code>	Variable name to reference the target object.

Description Constructor of a file system object (`xpctarget.fs` Class). The file system object represents the file system on the target computer. You work with the file system by changing the file system object using methods.

Note Constructor `xpctarget.fs` will be removed in a future release. Use constructor `SimulinkRealTime.fileSystem` instead.

If you have one target computer, or if you designate a target computer as the default one in your system, use `fileSYS_object = xpctarget.fs` to create a file system object.

If you have a target computer object in the Simulink Real-Time Explorer, use `fileSYS_object = xpctarget.fs(target_object)` to construct a corresponding file system object from the MATLAB Command Window.

Examples In the following example, a file system object for the default target computer is created.

```
fs1 = xpctarget.fs
```

xpctarget.fs

If you have an `xpctarget.xpc` object, you can construct an `xpctarget.fs` object by passing the `xpctarget.xpc` object variable to the `xpctarget.fs` constructor as an argument.

```
tg1 = xpctarget.xpc('TargetPC1');  
fs2 = xpctarget.fs(tg1)
```

Purpose Information about target computer drive (not recommended)

Syntax `filesystem_obj.diskinfo(target_PC_drive)`
`diskinfo(filesystem_obj,target_PC_drive)`

Arguments

<code>filesystem_obj</code>	Name of the <code>xpctarget.fs</code> file system object.
<code>target_PC_drive</code>	Name of the target computer drive for which to return information.

Description `filesystem_obj.diskinfo(target_PC_drive)` returns disk information for the specified target computer drive. An alternative syntax is:
`diskinfo(filesystem_obj,target_PC_drive)`

This is a method of `xpctarget.fs` objects called from the host computer.

xpctarget.fs.diskinfo

Examples

Return disk information for the target computer C:\ drive for the file system object fsys.

```
diskinfo(fsys, 'C:\') or fsys.diskinfo('C:\')  
ans =
```

```
          Label: 'SYSTEM '  
      DriveLetter: 'C'  
        Reserved: ''  
      SerialNumber: 1.0294e+009  
FirstPhysicalSector: 63  
          FATType: 32  
          FATCount: 2  
      MaxDirEntries: 0  
      BytesPerSector: 512  
SectorsPerCluster: 4  
      TotalClusters: 2040293  
      BadClusters: 0  
      FreeClusters: 1007937  
          Files: 19968  
      FileChains: 22480  
      FreeChains: 1300  
LargestFreeChain: 64349
```


Purpose	Close open target computer files (not recommended)				
Syntax	<code>fclose(filesys_obj,file_ID)</code> <code>filesys_obj.fclose(file_ID)</code>				
Arguments	<table><tr><td><code>filesys_obj</code></td><td>Name of the <code>xpctarget.fs</code> file system object.</td></tr><tr><td><code>file_ID</code></td><td>File identifier of the file to close.</td></tr></table>	<code>filesys_obj</code>	Name of the <code>xpctarget.fs</code> file system object.	<code>file_ID</code>	File identifier of the file to close.
<code>filesys_obj</code>	Name of the <code>xpctarget.fs</code> file system object.				
<code>file_ID</code>	File identifier of the file to close.				
Description	Method of <code>xpctarget.fs</code> objects. From the host computer, closes one or more open files in the target computer file system (except standard input, output, and error). The <code>file_ID</code> argument is the file identifier associated with an open file (see <code>xpctarget.fs.fopen</code> and <code>xpctarget.fs.filetable</code>). You cannot have more than eight files open in the file system.				
Examples	Close the open file identified by the file identifier <code>h</code> in the file system object <code>fsys</code> . <code>fclose(fsys,h)</code> or <code>fsys.fclose(h)</code>				
See Also	<code>fclose</code> <code>xpctarget.fs.fopen</code> <code>xpctarget.fs.fread</code> <code>xpctarget.fs.filetable</code> <code>xpctarget.fs.fwrite</code>				

xpctarget.fs.fileinfo

Purpose Target computer file information (not recommended)

Syntax fileinfo(filesys_obj,file_ID)
filesys_obj.fileinfo(file_ID)

Arguments

filesys_obj	Name of the xpctarget.fs file system object.
file_ID	File identifier of the file for which to get file information.

Description Method of xpctarget.fs objects. From the host computer, gets the information for the file associated with file_ID.

Examples Return file information for the file associated with the file identifier h in the file system object fsys.

```
fileinfo(fsys,h) or fsys.fileinfo(h)
ans =
        FilePos: 0
        AllocatedSize: 12288
        ClusterChains: 1
        VolumeSerialNumber: 1.0450e+009
        FullName: 'C:\DATA.DAT'
```

Purpose Information about open files in target computer file system (not recommended)

Syntax filetable(filesys_obj)
filesys_obj.filetable

Arguments filesys_obj Name of the xpctarget.fs file system object.

Description Method of xpctarget.fs objects. From the host computer, displays a table of the open files in the target computer file system. You cannot have more than eight files open in the file system.

Examples Return a table of the open files in the target computer file system for the file system object fsys.

```
filetable(fsys) or fsys.filetable
```

```
ans =
```

Index	Handle	Flags	FilePos	Name
0	00060000	R__	8512	C:\DATA.DAT
1	00080001	R__	0	C:\DATA1.DAT
2	000A0002	R__	8512	C:\DATA2.DAT
3	000C0003	R__	8512	C:\DATA3.DAT
4	001E000S	R__	0	C:\DATA4.DAT

The table returns the open file handles in hexadecimal. To convert a handle to one that other xpctarget.fs methods, such as fclose, can use, use the hex2dec function.

```
h1 = hex2dec('001E0001')
```

```
h1 =
```

```
1966081
```

To close that file, use the xpctarget.fs fclose method.

```
fsys.fclose(h1);
```

xpctarget.fs.filetable

See Also

`xpctarget.fs.fopen` | `xpctarget.fs.fclose`

Purpose Open target computer file for reading (not recommended)

Syntax

```
file_ID = fopen(file_obj, 'file_name')
file_ID = file_obj.fopen('file_name')
file_ID = fopen(file_obj, 'file_name', permission)
file_ID = file_obj.fopen('file_name', permission)
```

Arguments

<code>file_obj</code>	Name of the <code>xpctarget.fs</code> object.
<code>'file_name'</code>	Name of the target computer to open.
<code>permission</code>	Values are <code>'r'</code> , <code>'w'</code> , <code>'a'</code> , <code>'r+'</code> , <code>'w+'</code> , or <code>'a+'</code> . This argument is optional with <code>'r'</code> as the default value.

Description Method of `xpctarget.fs` objects. From the host computer, opens the specified filename on the target computer for binary access.

The permission argument values are

- `'r'`
Open the file for reading (default). The method does nothing if the file does not already exist.
- `'w'`
Open the file for writing. The method creates the file if it does not already exist.
- `'a'`
Open the file for appending to the file. Initially, the file pointer is at the end of the file. The method creates the file if it does not already exist.
- `'r+'`
Open the file for reading and writing. Initially, the file pointer is at the beginning of the file. The method does nothing if the file does not already exist.

xpctarget.fs.fopen

- 'w+'

Open the file for reading and writing. The method empties the file first, if the file already exists and has content, and places the file pointer at the beginning of the file. The method creates the file if it does not already exist.

- 'a+'

Open the file for reading and appending to the file. Initially, the file pointer is at the beginning of the file. The method creates the file if it does not already exist.

You cannot have more than eight files open in the file system. This method returns the file identifier for the open file in `file_ID`. You use `file_ID` as the first argument to the other file I/O methods (such as `xpctarget.fs.fclose`, `xpctarget.fs.fread`, and `xpctarget.fs.fwrite`).

Examples

Open the file `data.dat` in the target computer file system object `fsys`. Assign the resulting file handle to a variable for reading.

```
h = fopen(fsys,'data.dat') or fsys.fopen('data.dat')
ans =
    2883584
d = fread(fsys,h);
```

See Also

`fopen` | `xpctarget.fs.fclose` | `xpctarget.fs.fread` | `xpctarget.fs.fwrite`

Purpose Read open target computer file (not recommended)

Syntax

```
A = file_obj.fread(file_ID)
A = fread(file_obj,file_ID)
A = file_obj.fread(file_ID,offset,numbytes)
A = fread(file_obj,file_ID,offset,numbytes)
```

Arguments

<code>file_obj</code>	Name of the <code>xpctarget.fs</code> object.
<code>file_ID</code>	File identifier of the file to read.
<code>offset</code>	Position from the beginning of the file from which <code>fread</code> can start to read.
<code>numbytes</code>	Maximum number of bytes <code>fread</code> can read.

Description

`A = file_obj.fread(file_ID)` reads binary data from the file on the target computer and writes it into matrix `A`. The `file_ID` argument is the file identifier associated with an open file (see `xpctarget.fs.fopen`). An alternative syntax is:

```
A = fread(file_obj,file_ID)
```

`A = file_obj.fread(file_ID,offset,numbytes)` reads a block of bytes from `file_ID` and writes the block into matrix `A`. An alternative syntax is:

```
A = fread(file_obj,file_ID,offset,numbytes)
```

The `offset` argument specifies the position from the beginning of the file from which this function can start to read. `numbytes` specifies the maximum number of bytes to read.

To get a count of the total number of bytes read into `A`, use the following:

```
count = length(A);
```

xpctarget.fs.fread

`length(A)` might be less than the number of bytes requested if that number of bytes are not currently available. It is zero if the operation reaches the end of the file.

This is a method of `xpctarget.fs` objects called from the host computer.

Examples

Open the file `data.dat` in the target computer file system object `fsys`. Assign the resulting file handle to a variable for reading.

```
h=fsys.fopen('data.dat')
d=fread(fsys,h);
```

This reads the file `data.dat` and stores the contents of the file to `d`. This content is in the Simulink Real-Time file format.

See Also

`fread` | `xpctarget.fs.fclose` | `xpctarget.fs.fopen` | `xpctarget.fs.fwrite`

Purpose Write binary data to open target computer file (not recommended)

Syntax
`fwrite(file_obj,file_ID,A)`
`file_obj.fwrite(file_ID,A)`

Arguments

<code>file_obj</code>	Name of the <code>xpctarget.fs</code> object.
<code>file_ID</code>	File identifier of the file to write.
<code>A</code>	Elements of matrix <code>A</code> to be written to the specified file.

Description Method of `xpctarget.fs` objects. From the host computer, writes the elements of matrix `A` to the file identified by `file_ID`. The data is written to the file in column order. The `file_ID` argument is the file identifier associated with an open file (see `xpctarget.fs.fopen`). `fwrite` requires that the file be open with write permission.

Examples Open the file `data.dat` in the target computer file system object `fsys`. Assign the resulting file handle to a variable for writing.

```
h = fopen(fsys,'data.dat','w')
```

or

```
fsys.fopen('data.dat','w')
```

```
ans =  
    2883584  
d = fwrite(fsys,h,magic(5));
```

This writes the elements of matrix `A` to the file handle `h`. This content is written in column order.

See Also `fwrite` | `xpctarget.fs.fclose` | `xpctarget.fs.fopen` | `xpctarget.fs.fread`

xpctarget.fs.getfilesize

Purpose Size of file on target computer (not recommended)

Syntax `getfilesize(file_obj,file_ID)`
`file_obj.getfilesize(file_ID)`

Arguments

<code>file_obj</code>	Name of the <code>xpctarget.fs</code> object.
<code>file_ID</code>	File identifier of the file to get the size of.

Description Method of `xpctarget.fs` objects. From the host computer, gets the size (in bytes) of the file identified by the `file_ID` file identifier on the target computer file system. Use the Simulink Real-Time file object method `xpctarget.fs.fopen` to open the file system object.

Examples Get the size of the file identifier `h` for the file system object `fsys`.

```
getfilesize(fsys,h) or fsys.getfilesize(h)
```

See Also `xpctarget.fs.fopen`

Purpose Remove file from target computer (not recommended)

Syntax
`removefile(file_obj,file_name)`
`file_obj.removefile(file_name)`

Arguments

<code>file_name</code>	Name of the file to remove from the target computer file system.
<code>file_obj</code>	Name of the <code>xpctarget.fs</code> object.

Description Method of `xpctarget.fs` objects. Removes a file from the target computer file system.

You cannot recover this file once it is removed.

Note Method `xpctarget.fs.removefile` will be removed in a future release. Use method `SimulinkRealTime.fileSystem.removefile` instead.

Examples Remove the file `data2.dat` from the target computer file system `fsys`.

```
removefile(fsys,'data2.dat')
```

or

```
fsys.removefile('data2.dat')
```

xpctarget.fs.selectdrive

Purpose Select target computer drive (not recommended)

Syntax `selectdrive(file_obj, 'drive')`
`file_obj.selectdrive('drive')`

Arguments

<code>drive</code>	Name of the drive to set.
<code>file_obj</code>	Name of the <code>xpctarget.fs</code> object.

Description Method of `xpctarget.fs` objects. `selectdrive` sets the current drive of the target computer to the specified string. Enter the drive string with an extra backslash (`\`). For example, `D:\\` for the `D:\` drive.

Note Method `xpctarget.fs.selectdrive` will be removed in a future release. Use method `SimulinkRealTime.fileSystem.selectdrive` or `SimulinkRealTime.fileSystem.cd` instead.

Examples Set the current target computer drive to `D:\`.

```
selectdrive(fsys, 'D:\\')
```

or

```
fsys.selectdrive('D:\\')
```

Purpose Base class of file system and file transfer protocol (FTP) classes (not recommended)

Description This class is the base class for `xpctarget.fs Class` and `xpctarget.ftp Class`. All methods are inherited by the derived classes. The constructor for this class is called implicitly when the constructors for the derived classes are called:

Note Class `xpctarget.fsbase` will be removed in a future release. Use class `SimulinkRealTime.fileSystem` instead.

Methods

These methods are inherited by the derived classes.

Method	Description
<code>xpctarget.fsbase.cd</code>	Change folder on target computer
<code>xpctarget.fsbase.dir</code>	List contents of current folder on target computer
<code>xpctarget.fsbase.mkdir</code>	Make folder on target computer
<code>xpctarget.fsbase.pwd</code>	Current folder path of target computer
<code>xpctarget.fsbase.rmdir</code>	Remove folder from target computer

xpctarget.fsbase.cd

Purpose Change folder on target computer (not recommended)

Syntax `cd(file_obj,target_PC_dir)`
`file_obj.cd(target_PC_dir)`

Arguments

<code>file_obj</code>	Name of the <code>xpctarget.ftp</code> or <code>xpctarget.fs</code> object.
<code>target_PC_dir</code>	Name of the target computer folder to change to.

Description Method of `xpctarget.fsbase`, `xpctarget.ftp`, and `xpctarget.fs` objects. From the host computer, changes folder on the target computer.

Note Method `xpctarget.fsbase.cd` will be removed in a future release. Use method `SimulinkRealTime.fileSystem.cd` or `SimulinkRealTime.fileSystem.selectdrive` instead.

Examples Change folder from the current to one named `logs` for the file system object `fsys`.

```
cd(fsys,logs) or fsys.cd(logs)
```

Change folder from the current to one named `logs` for the FTP object `f`.

```
cd(f,logs) or f.cd(logs)
```

See Also `cd` | `xpctarget.fsbase.mkdir` | `xpctarget.fsbase.pwd`

Purpose List contents of current folder on target computer (not recommended)

Syntax `dir(file_obj)`

Arguments

<code>file_obj</code>	Name of the <code>xpctarget.ftp</code> or <code>xpctarget.fs</code> object.
-----------------------	---

Description Method of `xpctarget.fsbase`, `xpctarget.ftp`, and `xpctarget.fs` objects. From the host computer, lists the contents of the current folder on the target computer.

Note Method `xpctarget.fsbase.dir` will be removed in a future release. Use method `SimulinkRealTime.fileSystem.dir` instead.

To get the results in an M-by-1 structure, use a syntax like `ans=dir(file_obj)`. This syntax returns a structure like the following:

```
ans =  
1x5 struct array with fields:  
name  
date  
time  
bytes  
isdir
```

where

- `name` — Name of an object in the folder, shown as a cell array. The name, stored in the first element of the cell array, can have up to eight characters. The three-character file extension is stored in the second element of the cell array.
- `date` — Date of the last save of that object
- `time` — Time of the last save of that object

xpctarget.fsbasedir

- bytes — Size in bytes of that object
- isdir — Logical value indicating that the object is (1) or is not (0) a folder

Examples

List the contents of the current folder for the file system object `fsys`. You can also list the contents of the current folder for the FTP object `f`.

```
dir(fsys) or dir(f)
4/12/1998    20:00          222390      IO  SYS
 11/2/2003   13:54           6      MSDOS  SYS
 11/5/1998   20:01          93880    COMMAND  COM
 11/2/2003   13:54   <DIR>         0      TEMP
 11/2/2003   14:00          33  AUTOEXEC  BAT
  11/2/2003  14:00          512  BOOTSECT  DOS
 18/2/2003   16:33          4512  SC1SIGNA  DAT
 18/2/2003   16:17   <DIR>         0      FOUND  000
 29/3/2003   19:19          8512      DATA  DAT
 28/3/2003   16:41          8512  DATADATA  DAT
 28/3/2003   16:29          4512  SC4INTEG  DAT
  1/4/2003    9:28        201326592  PAGEFILE  SYS
 11/2/2003   14:13   <DIR>         0      WINNT
  4/5/2001   13:05        214432  NTLDR      '
  4/5/2001   13:05        34468  NTDETECT  COM
 11/2/2003   14:15   <DIR>         0  DRIVERS
 22/1/2001   11:42          217    BOOT     INI '
 28/3/2003   16:41          8512      A      DAT
 29/3/2003   19:19          2512  SC3SIGNA  DAT
 11/2/2003   14:25   <DIR>         0  INETPUB
 11/2/2003   14:28           0    CONFIG  SYS
 29/3/2003   19:10          2512  SC3INTEG  DAT
  1/4/2003   18:05          2512  SC1GAIN  DAT
  11/2/2003  17:26   <DIR>         0  UTILIT~1
```

You must use the `dir(f)` syntax to list the contents of the folder.

See Also

`dir` | `xpctarget.fsbase.mkdir` | `xpctarget.fsbase.cd` |
`xpctarget.fsbase.pwd`

xpctarget.fsbase.mkdir

Purpose Make folder on target computer (not recommended)

Syntax mkdir(file_obj,dir_name)
file_obj.mkdir(dir_name)

Arguments

file_obj	Name of the xpctarget.ftp or xpctarget.fs object.
dir_name	Name of the folder to be created.

Description Method of xpctarget.fsbase, xpctarget.ftp, and xpctarget.fs objects. From the host computer, makes a new folder in the current folder on the target computer file system.

Note Method xpctarget.fsbase.mkdir will be removed in a future release. Use method SimulinkRealTime.fileSystem.mkdir instead.

Note that to delete a folder from the target computer, you need to reboot the computer into DOS or some other operating system and use a utility in that system to delete the folder.

Examples Create a new folder, logs, in the target computer file system object fsys.

```
mkdir(fsys,logs)
```

or

```
fsys.mkdir(logs)
```

Create a new folder, logs, in the target computer FTP object f.

```
mkdir(f,logs) or f.mkdir(logs)
```

See Also mkdir | xpctarget.fsbase.dir | xpctarget.fsbase.pwd

Purpose	Current folder path of target computer (not recommended)
Syntax	<code>pwd(file_obj)</code> <code>file_obj.pwd</code>
Arguments	<code>file_obj</code> Name of the <code>xpctarget.ftp</code> or <code>xpctarget.fs</code> object.
Description	Method of <code>xpctarget.fsbase</code> , <code>xpctarget.ftp</code> , and <code>xpctarget.fs</code> objects. Returns the pathname of the current target computer folder.
<hr/> Note Method <code>xpctarget.fsbase.cd</code> will be removed in a future release. Use method <code>SimulinkRealTime.fileSystem.pwd</code> instead. <hr/>	
Examples	Return the target computer current folder for the file system object <code>fsys</code> . <code>pwd(fsys)</code> or <code>fsys.pwd</code> Return the target computer current folder for the FTP object <code>f</code> . <code>pwd(f)</code> or <code>f.pwd</code>
See Also	<code>pwd</code> <code>xpctarget.fsbase.dir</code> <code>xpctarget.fsbase.mkdir</code>

xpctarget.fsbase.rmdir

Purpose Remove folder from target computer (not recommended)

Syntax `rmdir(file_obj,dir_name)`
`file_obj.rmdir(dir_name)`

Arguments

<code>dir_name</code>	Name of the folder to remove from the target computer file system.
<code>file_obj</code>	Name of the <code>xpctarget.fs</code> object.

Description Method of `xpctarget.fsbase`, `xpctarget.ftp`, and `xpctarget.fs` objects. Removes a folder from the target computer file system.
You cannot recover this folder once it is removed.

Note Method `xpctarget.fsbase.rmdir` will be removed in a future release. Use method `SimulinkRealTime.fileSystem.rmdir` instead.

Examples Remove the folder `data2dir.dat` from the target computer file system `fsys`.

```
rmdir(f,'data2dir.dat')
```

or

```
fsys.rmdir('data2dir.dat')
```

Purpose Manage the folders and files on the target computer via file transfer protocol (FTP) (not recommended)

Description The FTP object represents the file on the target computer. You work with the file folders using the inherited methods, and transport the file between the host and target computers using the `xpctarget.ftp` methods.

Note Class `xpctarget.ftp` will be removed in a future release. Use class `SimulinkRealTime.fileSystem` instead.

Constructor

Constructor	Description
<code>xpctarget.ftp</code>	Create file transfer protocol (FTP) object

Methods

These methods are inherited from `xpctarget.fsbase` Class.

Method	Description
<code>xpctarget.fsbase.cd</code>	Change folder on target computer
<code>xpctarget.fsbase.dir</code>	List contents of current folder on target computer
<code>xpctarget.fsbase.mkdir</code>	Make folder on target computer
<code>xpctarget.fsbase.pwd</code>	Current folder path of target computer
<code>xpctarget.fsbase.rmdir</code>	Remove folder from target computer

These methods are specific to class `ftp`.

xpctarget.ftp Class

Method	Description
xpctarget.ftp.get (ftp)	Retrieve copy of requested file from target computer
xpctarget.ftp.put	Copy file from host computer to target computer

Purpose Create file object (not recommended)

Syntax
`file_object = xpctarget.ftp`
`file_object = xpctarget.ftp(target_object)`

Arguments	<code>file_object</code>	Variable name to reference the file object.
	<code>target_object</code>	Variable name to reference the target object.

Description Constructor of a file object (`xpctarget.ftp` Class). The file object represents the file on the target computer. You work with the file by changing the file object using methods.

Note Constructor `xpctarget.ftp` will be removed in a future release. Use constructor `SimulinkRealTime.fileSystem` instead.

If you have one target computer, or if you designate a target computer as the default one in your system, use `file_object = xpctarget.ftp` to create a file object.

If you have a target computer object in the Simulink Real-Time Explorer, use `file_object = xpctarget.ftp(target_object)` to construct a corresponding file object from the MATLAB Command Window.

Examples In the following example, a file object for the default target computer is created.

```
ftp1=xpctarget.ftp
```

xpctarget.ftp

If you have an `xpctarget.xpc` object, you can construct a file object by passing the `xpctarget.xpc` object variable to the `xpctarget.ftp` constructor as an argument.

```
tg1=xpctarget.xpc('TargetPC1');  
ftp2=xpctarget.ftp(tg1)
```


Purpose Retrieve copy of requested file from target computer (not recommended)

Syntax
`get(file_obj,file_name)`
`file_obj.get(file_name)`

Arguments

<code>file_obj</code>	Name of the <code>xpctarget.ftp</code> object.
<code>file_name</code>	Name of a file on the target computer.

Description Method of `xpctarget.ftp` objects. Copies the specified filename from the target computer to the current folder of the host computer. `file_name` must be either a fully qualified filename on the target computer, or located in the current folder of the target computer.

Note Method `xpctarget.ftp.get (ftp)` will be removed in a future release. Use method `SimulinkRealTime.copyFileToHost` instead.

Examples Retrieve a copy of the file named `data.dat` from the current folder of the target computer file object `f`.

```
get(f,'data.dat') or f.get('data.dat')  
ans = data.dat
```

See Also `xpctarget.ftp.put`

xpctarget.ftp.put

Purpose Copy file from host computer to target computer (not recommended)

Syntax
`put(file_obj,file_name)`
`file_obj.put(file_name)`

Arguments

<code>file_obj</code>	Name of the <code>xpctarget.ftp</code> object.
<code>file_name</code>	Name of the file to copy to the target computer.

Description Method of `xpctarget.ftp` objects. Copies a file from the host computer to the target computer. `file_name` must be a file in the current folder of the host computer. The method writes `file_name` to the target computer disk.

Note Method `xpctarget.ftp.put` will be removed in a future release. Use method `SimulinkRealTime.copyFileToTarget` instead.

`put` might be slower than the `get` operation for the same file. This is expected behavior.

Examples Copy the file `data2.dat` from the current folder of the host computer to the current folder of the target computer FTP object `f`.

```
put(f, 'data2.dat')
```

or

```
fsys.put('data2.dat')
```

See Also `xpctarget.fsbase.dir` | `xpctarget.ftp.get` (ftp)

Purpose Container object to manage target computer environment collection objects (not recommended)

Description The targets class contains a collection of environment settings, stored in `xpctarget.env` Class objects.

Note Class `xpctarget.targets` will be removed in a future release. Use package `SimulinkRealTime` methods instead.

Constructor

Constructor	Description
<code>xpctarget.targets</code>	Create container object to manage target computer environment collection objects

Methods

Method	Description
<code>xpctarget.targets.Add (env collection object)</code>	Add a new Simulink Real-Time environment collection object.
<code>xpctarget.targets.getTargetNames (env collection object)</code>	Retrieve the Simulink Real-Time environment collection object names.
<code>xpctarget.targets.Item (env collection object)</code>	Retrieve Simulink Real-Time environment collection object.
<code>xpctarget.targets.makeDefault (env collection object)</code>	Set target computer environment collection object as default.
<code>xpctarget.targets.Remove (env collection object)</code>	Remove an Simulink Real-Time environment collection object.

xpctarget.targets Class

Properties

Property	Description	Writable
DefaultTarget	Returns an <code>xpctarget.env</code> object that references the default target computer object environment.	No
NumTargets	Returns the number of target computer environment objects in the container.	No

Purpose	Create container object to manage target computer environment collection objects (not recommended)
Syntax	<code>env_collection_object = xpctarget.targets</code>
Description	Constructor for target environment object collection (<code>xpctarget.targets</code> Class). The collection manages the environment object (<code>xpctarget.env</code> Class) for a multitarget Simulink Real-Time system.

Note Constructor `xpctarget.targets` will be removed in a future release.

This is in contrast to the `setxpcenv` and `getxpcenv` functions, which manage the environment properties for the default target computer. You work with the environment objects by changing the environment properties using methods.

Use the syntax

```
env_object = xpctarget.targets
```

Access properties of an `env_collection_object` object with `env_collection_object.propertyname`, `env_collection_object.propertyname.propertyname`, or with the `xpctarget.targets.get (env collection object)` and `xpctarget.targets.set (env collection object)` commands.

Access an individual environment object via `xpctarget.targets.Item (env collection object)`,

Examples	Create an environment container object. With this object, you can manage the environment collection objects for the targets in your system.
-----------------	---

```
tgs=xpctarget.targets
```

xpctarget.targets

See Also

xpctarget.targets.get (env collection object) |
xpctarget.targets.set (env collection object)

xpctarget.targets.Add (env collection object)

Purpose Add new Simulink Real-Time environment collection object (not recommended)

Syntax `env_collection_object.Add`

Description Method of `xpctarget.targets` objects. `Add` creates an Simulink Real-Time environment collection object on the host computer.

Note Method `xpctarget.targets.Add (env collection object)` will be removed in a future release. Use method `SimulinkRealTime.addTarget` instead.

Examples Add a new Simulink Real-Time environment collection object to the system. Assume that `tgs` represents the environment collection object. The first `get(tgs)` function returns the current number of target computers. The second function returns the number of target computers after you add one.

```
tgs=xpctarget.targets;  
get(tgs);  
tgs.Add;  
get(tgs);
```

See Also `xpctarget.targets` | `xpctarget.targets.set (env collection object)` | `xpctarget.targets.get (env collection object)`

xpctarget.targets.get (env collection object)

Purpose Return target object collection environment property values (not recommended)

Syntax `get(env_collection_object, 'env_collection_object_property')`

Arguments

<code>env_collection_object</code>	Name of a collection of target objects.
<code>'env_collection_object_property'</code>	Name of a target object environment property.

Description `get` gets the values of environment properties for a collection of target objects.

Note Method `xpctarget.targets.get (env collection object)` will be removed in a future release. Use method `SimulinkRealTime.getTargetSettings` instead.

The environment properties for a target environment object collection are listed in the following table. This table includes a description of the properties and which properties you can change directly by assigning a value.

Property	Description	Writable
DefaultTarget	Contains an instance of the default target environment object (<code>xpctarget.env</code>).	No
NumTargets	Contains the number of target objects in the Simulink Real-Time system. The actual number of target computers in the system can differ from this value.	No

xpctarget.targets.get (env collection object)

Examples

List the values of the target object collection environment property values. Assume that `tgs` represents the target object collection environment.

```
tgs=xpctarget.targets;  
get(tgs);
```

List the value for the target object environment collection property `NumTargets`. Note that the property name is a string, in quotation marks, and not case sensitive.

```
get(tgs, 'NumTargets') or tgs.get('NumTargets')
```

See Also

`get | xpctarget.targets.set (env collection object) | set`

xpctarget.targets.getTargetNames (env collection object)

Purpose Retrieve Simulink Real-Time environment object names (not recommended)

Syntax `env_collection_object.getTargetNames`

Description Method of `xpctarget.targets` objects. `getTargetNames` retrieves the names of the existing Simulink Real-Time environment collection objects from the `xpctarget.targets` class.

Note Method `xpctarget.targets.getTargetNames (env collection object)` will be removed in a future release. Use package `SimulinkRealTime` methods instead.

Examples Retrieve the names of the Simulink Real-Time environment collection objects in the system. Assume that `tgs` represents the target object collection environment.

```
tgs=xpctarget.targets;  
get(tgs);  
tgs.getTargetNames
```

See Also `xpctarget.targets` | `xpctarget.targets.set (env collection object)` | `xpctarget.targets.get (env collection object)`

xpctarget.targets.Item (env collection object)

Purpose Retrieve specific Simulink Real-Time environment (env) object (not recommended)

Syntax `env_collection_object.Item('env_object_name')`

Description Method of `xpctarget.targets` objects. `Item` retrieves a specific environment object (`xpctarget.env Class`) from the `xpctarget.targets` class. Use this method to work with a particular target computer environment object.

Note `xpctarget.targets.Item (env collection object)` will be removed in a future release. Use `SimulinkRealTime.getTargetSettings` instead.

Examples Retrieve a new Simulink Real-Time environment collection object from the system. Assume that `tgs` represents the target object collection environment.

```
tgs=xpctarget.targets;  
get(tgs);  
tgs.getTargetNames  
tgs.Item('TargetPC1')
```

See Also `xpctarget.targets` | `xpctarget.targets.set (env collection object)` | `xpctarget.targets.get (env collection object)`

xpctarget.targets.makeDefault (env collection object)

Purpose Set specific target computer environment object as default (not recommended)

Syntax `env_collection_object.makeDefault('env_object_name')`

Description Method of `xpctarget.targets` objects. `makeDefault` sets the specified target computer environment object as the default target computer from the `xpctarget.targets` class.

Note `xpctarget.targets.makeDefault (env collection object)` will be removed in a future release. Use `SimulinkRealTime.targetSettings.setAsDefaultTarget` instead.

Examples Set the specified target collection object as the default target computer collection. Assume that `tgs` represents the target object collection environment.

```
tgs=xpctarget.targets;  
get(tgs);  
tgs.getTargetNames  
tgs.makeDefault('TargetPC2')
```

See Also `xpctarget.targets` | `xpctarget.targets.set (env collection object)` | `xpctarget.targets.get (env collection object)`

xpctarget.targets.Remove (env collection object)

Purpose Remove specific Simulink Real-Time environment object (not recommended)

Syntax `env_collection_object.Remove('env_collection_object_name')`

Description Method of `xpctarget.targets` objects. Remove removes an existing Simulink Real-Time environment object from the environment collection. If you remove the target environment object of the default target computer, the next target environment object becomes the default target computer. You can remove all but the last target computer, which becomes the default target computer.

Note `xpctarget.targets.Remove (env collection object)` will be removed in a future release. Use `SimulinkRealTime.removeTarget` instead.

Examples Remove an Simulink Real-Time environment collection object from the system. Assume that `tgs` represents the target object collection environment.

```
tgs=xpctarget.targets;  
get(tgs);  
tgs.getTargetNames  
tgs.Remove('TargetPC2')
```

See Also `xpctarget.targets` | `xpctarget.targets.set (env collection object)` | `xpctarget.targets.get (env collection object)`

xpctarget.targets.set (env collection object)

Purpose Change target object environment collection object property values (not recommended)

Syntax

```
set(env_collection_object)
set(env_collection_object, 'property_name1',
'property_value1','property_name2', 'property_value2', . . .)
env_collection_object.set('property_name1',
'property_value1')
set(env_collection_object, property_name_vector,
property_value_vector)
env_collection_object.property_name = property_value
```

Arguments

<code>env_collection_object</code>	Name of a target environment collection object.
<code>'property_name'</code>	Name of a target object environment collection property. Always use quotation marks for character strings.
<code>property_value</code>	Value for a target object environment collection property. Always use quotation marks for character strings; quotation marks are optional for numbers.

Description `set` sets the values of environment properties for a collection of target object environments. Not all properties are user writable. Properties are entered as property-value pairs.

Note `xpctarget.targets.set (env collection object)` will be removed in a future release. Use `SimulinkRealTime.targetSettings.set` instead.

xpctarget.targets.set (env collection object)

The environment properties for a target object collection are listed in the following table. This table includes a description of the properties and which properties you can change directly by assigning a value.

Property	Description	Writable
DefaultTarget	Contains an instance of the default target environment object (xpctarget.env).	No
NumTargets	Contains the number of target objects in the Simulink Real-Time system. The actual number of target computers in the system can differ from this value.	No

See Also

`get` | `set` | `xpctarget.targets.get` (env collection object)

xpctarget.xpc Class

Purpose Target object representing target application (not recommended)

Description Provides access to methods and properties used to start and stop the target application, read and set parameters, monitor signals, and retrieve status information about the target computer.

Note Class `xpctarget.xpc` will be removed in a future release. Use class `SimulinkRealTime.target` instead.

Constructor

Constructor	Description
<code>xpctarget.xpc</code>	Create target object representing target application

Methods

Method	Description
<code>xpctarget.xpc.addscope</code>	Create scopes
<code>xpctarget.xpc.close</code>	Close serial port connecting host computer with target computer
<code>xpctarget.xpc.get</code> (target application object)	Return target application object property values
<code>xpctarget.xpc.getlog</code>	All or part of output logs from target object
<code>xpctarget.xpc.getparam</code>	Value of target object parameter index
<code>xpctarget.xpc.getparamlist</code>	Parameter index from parameter list
<code>xpctarget.xpc.getparamname</code>	Block path and parameter name from index list
<code>xpctarget.xpc.getscope</code>	Scope object pointing to scope defined in kernel
<code>xpctarget.xpc.getsignal</code>	Value of target object signal index
<code>xpctarget.xpc.getsignallist</code>	Signal index or signal property from signal list

Method	Description
xpctarget.xpc.getsignal	Retrieve list of signal indices
xpctarget.xpc.getsignal	Return signal label
xpctarget.xpc.getsignal	Signal name from index list
xpctarget.xpc.load	Download target application to target computer
xpctarget.xpc.loadparameters	Restore parameter values saved in specified file
xpctarget.xpc.reboot	Reboot target computer
xpctarget.xpc.remscope	Remove scope from target computer
xpctarget.xpc.saveparameters	Save current target application parameter values
xpctarget.xpc.set (target application object)	Change target application object property values
xpctarget.xpc.setparam	Change writable target object parameters
xpctarget.xpc.start (target application object)	Start execution of target application on target computer
xpctarget.xpc.stop (target application object)	Stop execution of target application on target computer
xpctarget.xpc.targetping	Test communication between host and target computers
xpctarget.xpc.unload	Remove current target application from target computer

Properties

Properties are read using `xpctarget.xpc.get` (target application object). Writable properties are written using `xpctarget.xpc.set` (target application object).

xpctarget.xpc Class

Property	Description	Writable
Application	Name of the Simulink model and target application built from that model.	No
AvgTET	<p>Average task execution time. This value is an average of the measured CPU times, in seconds, to run the model equations and post outputs during each sample interval. Task execution time is nearly constant, with minor deviations due to cache, memory access, interrupt latency, and multirate model execution.</p> <p>The TET includes:</p> <ul style="list-style-type: none">• Complete I/O latency.• Data logging (the parts that happen in a real-time task). This includes data captured in scopes.• Asynchronous interruptions.• Parameter updating latency (if the Double buffer parameter changes parameter is set in the Simulink Real-Time Options node of the model Configuration Parameters dialog box). <p>Note that the TET is not the only consideration in determining the minimum achievable sample time. Other considerations, not included in the TET, are:</p> <ul style="list-style-type: none">• Time required to measure TET• Interrupt latency required to schedule and run one step of the model	No

Property	Description	Writable
CommunicationTimeout	Communication timeout between host and target computer, in seconds.	Yes
Connected	Communication status between the host computer and the target computer. Values are 'Yes' and 'No'.	No
CPUoverload	CPU status for overload. If the target application requires more CPU time than the sample time of the model, this value is set from 'none' to 'detected' and the current run is stopped. Returning this status to 'none' requires either a faster processor or a larger sample time.	No
ExecTime	Execution time. Time, in seconds, since your target application started running. When the target application stops, the total execution time is displayed.	No
LogMode	Controls which data points are logged: <ul style="list-style-type: none">• Time-equidistant logging. Logs a data point at every time interval. Set value to 'Normal'.• Value-equidistant logging. Logs a data point only when an output signal from the <code>OutputLog</code> changes by a specified value (increment). Set the value to the difference in signal values.	Yes

xpctarget.xpc Class

Property	Description	Writable
MaxLogSamples	<p>Maximum number of samples for each logged signal within the circular buffers for TimeLog, StateLog, OutputLog, and TETLog. StateLog and OutputLog can have one or more signals.</p> <p>This value is calculated by dividing the Signal Logging Buffer Size by the number of logged signals. The Signal Logging Buffer Size box is in the Simulink Real-Time Options pane of the Configuration Parameters dialog box.</p>	No
MaxTET	<p>Maximum task execution time. Corresponds to the slowest time (longest time measured), in seconds, to update model equations and post outputs.</p>	No
MinTET	<p>Minimum task execution time. Corresponds to the fastest time (smallest time measured), in seconds, to update model equations and post outputs.</p>	No
Mode	<p>Type of Simulink Coder™ code generation. Values are 'Real-Time Singletasking', 'Real-Time Multitasking', and 'Accelerate'. The default value is 'Real-Time Singletasking'. Even if you select 'Real-Time Multitasking', the actual mode can be 'Real-Time Singletasking'. This happens if your model contains only one or two tasks and the sample rates are equal.</p>	No

Property	Description	Writable
NumLogWraps	The number of times the circular buffer wrapped. The buffer wraps each time the number of samples exceeds MaxLogSamples.	No
NumParameters	The number of parameters from your Simulink model that you can tune or change.	No
NumSignals	The number of signals from your Simulink model that are available to be viewed with a scope.	No
OutputLog	Storage in the MATLAB workspace for the output or Y-vector logged during execution of the target application.	No
Parameters	<p>List of tunable parameters. This list is visible only when ShowParameters is set to 'on':</p> <ul style="list-style-type: none"> • Property value. Value of the parameter in a Simulink block. • Type. Data type of the parameter. Always <code>double</code>. • Size. Size of the parameter. For example, scalar, 1-by-2 vector, or 2-by-3 matrix. • Parameter name. Name of a parameter in a Simulink block. • Block name. Name of a Simulink block. 	No

xpctarget.xpc Class

Property	Description	Writable
SampleTime	Time between samples. This value equals the step size, in seconds, for updating the model equations and posting the outputs. (See “Alternative Configuration and Control Methods” for limitations on target property changes to sample times.)	Yes
Scopes	List of index numbers, with one index for each scope.	No
SessionTime	Time since the kernel started running on your target computer. This is also the elapsed time since you booted the target computer. Values are in seconds.	No
ShowParameters	Flag set to view or hide the list of parameters from your Simulink blocks. This list is shown when you display the properties for a target object. Values are 'on' and 'off'.	Yes
ShowSignals	Flag set to view or hide the list of signals from your Simulink blocks. This list is shown when you display the properties for a target object. Values are 'on' and 'off'.	Yes
Signals	List of viewable signals. This list is visible only when ShowSignals is set to 'on'. <ul style="list-style-type: none">• Property name. S0, S1. . .• Property value. Value of the signal.• Block name. Name of the Simulink block the signal is from.	No

Property	Description	Writable
StateLog	Storage in the MATLAB workspace for the state or x-vector logged during execution of the target application.	No
Status	Execution status of your target application. Values are 'stopped' and 'running'.	No
StopTime	Time when the target application stops running. Values are in seconds. The original value is set in the Solver pane of the Configuration Parameters dialog box. When the ExecTime reaches StopTime, the application stops running.	Yes
TETLog	Storage in the MATLAB workspace for a vector containing task execution times during execution of the target application. To enable logging of the TET, you need to select the Log Task Execution Time check box in the Simulink Real-Time Options pane of the Configuration Parameters dialog box.	No
TimeLog	Storage in the MATLAB workspace for the time or T-vector logged during execution of the target application.	No
ViewMode	Display either all scopes or a single scope on the target computer. Value is 'all' or a single scope index. This property is active only if the environment property TargetScope is set to enabled.	Yes

xpctarget.xpc

Purpose Create target object representing target application (not recommended)

Syntax

```
target_object=xpctarget.xpc
target_object=xpctarget.xpc
target_object=xpctarget.xpc('target_name')
target_object=xpctarget.xpc('target_name')
```

Arguments

target_object	Variable name to reference the target object
target_name	Target name as specified in the Simulink Real-Time Explorer

Description Constructor of a target object (xpctarget.xpc Class). The target object represents the target application and target computer. You make changes to the target application by changing the target object using methods and properties.

Note Constructor xpctarget.xpc will be removed in a future release. Use constructor SimulinkRealTime.target or function slrt instead.

If you have one target computer, or if you designate a target computer as the default one in your system, use target_object=xpctarget.xpc.

If you have a target computer object in the Simulink Real-Time Explorer, use target_object=xpctarget.xpc('target_name') to construct a corresponding target object from the MATLAB Command Window.

Examples Before you build a target application, you can check the connection between your host and target computers by creating a target object, then using the xpctarget.xpc.targetping method to check the connection.

```
tg = xpctarget.xpc
    Simulink Real-Time Object
```



```
Connected          = Yes  
Application        = loader
```

```
tg.targetping
```

```
ans =
```

```
success
```

If you have an Simulink Real-Time Explorer target object, and you want to construct a corresponding target object in the MATLAB Command Window, use a command like the following:

```
target_object=xpctarget.xpc('TargetPC1')
```

See Also

```
xpctarget.xpc.get (target application object) |  
xpctarget.xpc.set (target application object) |  
xpctarget.xpc.targetping
```

xpctarget.xpc.addscope

Purpose Create scopes (not recommended)

Syntax Create a scope and scope object without assigning to a MATLAB variable.

Note Method `xpctarget.xpc.addscope` will be removed in a future release. Use method `SimulinkRealTime.target.addscope` instead.

```
addscope(target_object, scope_type, scope_number)
target_object.addscope(scope_type, scope_number)
```

Create a scope, scope object, and assign to a MATLAB variable

```
scope_object = addscope(target_object,
    scope_type, scope_number)
scope_object = target_object.addscope(scope_type,
    scope_number)
```

Target computer command line — When you are using this command on the target computer, you can only add a target scope.


```
addscope
addscope scope_number
```

Arguments

- `target_object` Name of a target object. The default target name is `tg`.
- `scope_type` Values are `'host'`, `'target'`, or `'file'`. This argument is optional with `host` as the default value.
- `scope_number` Vector of new scope indices. This argument is optional. The next available integer in the target object property `Scopes` as the default value.
- If you enter a scope index for an existing scope object, the result is an error.

Description

`addscope` creates a scope of the specified type and updates the target object property `Scopes`. This method returns a scope object vector. If the result is not assigned to a variable, the scope object properties are listed in the MATLAB window. The Simulink Real-Time product supports 10 target scopes, 8 file scopes, and as many host scopes as the target computer resources can support. If you try to add a scope with the same index as an existing scope, the result is an error.



Examples

Create a scope and scope object `sc1` using the method `addscope`. A target scope is created on the target computer with an index of 1, and a scope object is created on the host computer, assigned to the variable `sc1`. The target object property `Scopes` is changed from `No scopes` defined to 1.

```
sc1 = addscope(tg, 'target', 1)
```

or

```
sc1 = tg.addscope('target', 1)
```

Create a scope with the method `addscope` and then create a scope object, corresponding to this scope, using the method `getscope`. A target scope is created on the target computer with an index of 1, and a scope object is created on the host computer, but it is not assigned to a variable. The target object property `Scopes` is changed from `No scopes` defined to 1.

xpctarget.xpc.addscope

```
addscope(tg, 'target', 1) or tg.addscope('target', 1)
sc1 = getscope(tg, 1) or sc1 = tg.getscope(1)
```

Create two scopes using a vector of scope objects `scvector`. Two target scopes are created on the target computer with scope indices of 1 and 2, and two scope objects are created on the host computer that represent the scopes on the target computer. The target object property `Scopes` is changed from `No scopes defined` to `1,2`.

```
scvector = addscope(tg, 'target', [1, 2])
```

Create a scope and scope object `sc4` of type `file` using the method `addscope`. A file scope is created on the target computer with an index of 4. A scope object is created on the host computer and is assigned to the variable `sc4`. The target object property `Scopes` is changed from `No scopes defined` to `4`.

```
sc4 = addscope(tg, 'file', 4) or sc4 = tg.addscope('file', 4)
```

See Also

`xpctarget.xpc.remscope` | `xpctarget.xpc.getscope`

How To

- “Target Scope Usage”
- “Host Scope Usage”
- “File Scope Usage”
- “Application and Driver Scripts”

Purpose Close serial port connecting host computer with target computer (not recommended)

Syntax `close(target_object)`
`target_object.close`

Arguments `target_object` Name of a target object.

Description `close` closes the serial connection between the host computer and a target computer. If you want to use the serial port for another function without quitting the MATLAB window – for example, a modem – use this function to close the connection.

Note Method `xpctarget.xpc.close` will be removed in a future release. Use method `SimulinkRealTime.target.close` instead.

xpctarget.xpc.get (target application object)

Purpose Return target application object property values (not recommended)

Syntax `get(target_object, 'target_object_property')`

Arguments

<code>target_object</code>	Name of a target object.
<code>'target_object_property'</code>	Name of a target object property.

Description `get` gets the value of readable target object properties from a target object.

Note Method `xpctarget.xpc.get` (target application object) will be removed in a future release. Use method `SimulinkRealTime.target.get` instead.

The properties for a target object are listed in the following table. This table includes a description of the properties and which properties you can change directly by assigning a value.

Property	Description	Writable
Application	Name of the Simulink model and target application built from that model.	No
AvgTET	Average task execution time. This value is an average of the measured CPU times, in seconds, to run the model equations and post outputs during each sample interval. Task execution time is nearly constant, with minor deviations due to cache, memory access, interrupt latency, and multirate model execution. The TET includes: <ul style="list-style-type: none">• Complete I/O latency.	No

xpctarget.xpc.get (target application object)

Property	Description	Writable
	<ul style="list-style-type: none">• Data logging (the parts that happen in a real-time task). This includes data captured in scopes.• Asynchronous interruptions.• Parameter updating latency (if the Double buffer parameter changes parameter is set in the Simulink Real-Time Options node of the model Configuration Parameters dialog box). <p>Note that the TET is not the only consideration in determining the minimum achievable sample time. Other considerations, not included in the TET, are:</p> <ul style="list-style-type: none">• Time required to measure TET• Interrupt latency required to schedule and run one step of the model	
CommunicationTimeOut	Communication timeout between host and target computer, in seconds.	Yes
Connected	Communication status between the host computer and the target computer. Values are 'Yes' and 'No'.	No
CPUoverload	CPU status for overload. If the target application requires more CPU time than the sample time of the model, this value is set from 'none' to 'detected' and the current run is stopped. Returning this status to 'none' requires either a faster processor or a larger sample time.	No

xpctarget.xpc.get (target application object)

Property	Description	Writable
ExecTime	Execution time. Time, in seconds, since your target application started running. When the target application stops, the total execution time is displayed.	No
LogMode	Controls which data points are logged: <ul style="list-style-type: none">• Time-equidistant logging. Logs a data point at every time interval. Set value to 'Normal'.• Value-equidistant logging. Logs a data point only when an output signal from the OutputLog changes by a specified value (increment). Set the value to the difference in signal values.	Yes
MaxLogSamples	Maximum number of samples for each logged signal within the circular buffers for TimeLog, StateLog, OutputLog, and TETLog. StateLog and OutputLog can have one or more signals. This value is calculated by dividing the Signal Logging Buffer Size by the number of logged signals. The Signal Logging Buffer Size box is in the Simulink Real-Time Options pane of the Configuration Parameters dialog box.	No
MaxTET	Maximum task execution time. Corresponds to the slowest time (longest time measured), in seconds, to update model equations and post outputs.	No

xpctarget.xpc.get (target application object)

Property	Description	Writable
MinTET	Minimum task execution time. Corresponds to the fastest time (smallest time measured), in seconds, to update model equations and post outputs.	No
Mode	Type of Simulink Coder code generation. Values are 'Real-Time Singletasking', 'Real-Time Multitasking', and 'Accelerate'. The default value is 'Real-Time Singletasking'. Even if you select 'Real-Time Multitasking', the actual mode can be 'Real-Time Singletasking'. This happens if your model contains only one or two tasks and the sample rates are equal.	No
NumLogWraps	The number of times the circular buffer wrapped. The buffer wraps each time the number of samples exceeds MaxLogSamples.	No
NumParameters	The number of parameters from your Simulink model that you can tune or change.	No
NumSignals	The number of signals from your Simulink model that are available to be viewed with a scope.	No
OutputLog	Storage in the MATLAB workspace for the output or Y-vector logged during execution of the target application.	No

xpctarget.xpc.get (target application object)

Property	Description	Writable
Parameters	<p>List of tunable parameters. This list is visible only when ShowParameters is set to 'on':</p> <ul style="list-style-type: none">• Property value. Value of the parameter in a Simulink block.• Type. Data type of the parameter. Always double.• Size. Size of the parameter. For example, scalar, 1-by-2 vector, or 2-by-3 matrix.• Parameter name. Name of a parameter in a Simulink block.• Block name. Name of a Simulink block.	No
SampleTime	<p>Time between samples. This value equals the step size, in seconds, for updating the model equations and posting the outputs. (See “Alternative Configuration and Control Methods” for limitations on target property changes to sample times.)</p>	Yes
Scopes	<p>List of index numbers, with one index for each scope.</p>	No
SessionTime	<p>Time since the kernel started running on your target computer. This is also the elapsed time since you booted the target computer. Values are in seconds.</p>	No
ShowParameters	<p>Flag set to view or hide the list of parameters from your Simulink blocks. This list is shown when you display the properties for a target object. Values are 'on' and 'off'.</p>	Yes

xpctarget.xpc.get (target application object)

Property	Description	Writable
ShowSignals	Flag set to view or hide the list of signals from your Simulink blocks. This list is shown when you display the properties for a target object. Values are 'on' and 'off'.	Yes
Signals	List of viewable signals. This list is visible only when ShowSignals is set to 'on'. <ul style="list-style-type: none">• Property name. S0, S1. . .• Property value. Value of the signal.• Block name. Name of the Simulink block the signal is from.	No
StateLog	Storage in the MATLAB workspace for the state or x-vector logged during execution of the target application.	No
Status	Execution status of your target application. Values are 'stopped' and 'running'.	No
StopTime	Time when the target application stops running. Values are in seconds. The original value is set in the Solver pane of the Configuration Parameters dialog box. When the ExecTime reaches StopTime, the application stops running.	Yes

xpctarget.xpc.get (target application object)

Property	Description	Writable
TETLog	Storage in the MATLAB workspace for a vector containing task execution times during execution of the target application. To enable logging of the TET, you need to select the Log Task Execution Time check box in the Simulink Real-Time Options pane of the Configuration Parameters dialog box.	No
TimeLog	Storage in the MATLAB workspace for the time or T-vector logged during execution of the target application.	No
ViewMode	Display either all scopes or a single scope on the target computer. Value is 'all' or a single scope index. This property is active only if the environment property TargetScope is set to enabled.	Yes

Examples

List the value for the target object property StopTime. Notice that the property name is a string, in quotation marks, and not case sensitive.

```
get(tg,'stoptime') or tg.get('stoptime')  
ans = 0.2
```

See Also

```
get | set | xpctarget.xpc.set (target application object)  
| xpctarget.xpcsc.get (scope object) | xpctarget.xpc.set  
(target application object)
```

Purpose All or part of output logs from target object (not recommended)

Syntax `log = getlog(target_object, 'log_name', first_point, number_samples, decimation)`

Arguments

<code>log</code>	User-defined MATLAB variable.
<code>'log_name'</code>	Values are TimeLog, StateLog, OutputLog, or TETLog. This argument is required.
<code>first_point</code>	First data point. The logs begin with 1. This argument is optional. Default is 1.
<code>number_samples</code>	Number of samples after the start time. This argument is optional. Default is all points in log.
<code>decimation</code>	1 returns all sample points. n returns every nth sample point. This argument is optional. Default is 1.

Description Use this function instead of the function `get` when you want only part of the data.

Note Method `xpctarget.xpc.getlog` will be removed in a future release. Use method `SimulinkRealTime.target.getlog` instead.

Examples To get the first 1000 points in a log,

```
Out_log = getlog(tg, 'TETLog', 1, 1000)
```

To get every other point in the output log and plot values,

```
Output_log = getlog(tg, 'TETLog', 1, 10, 2)
Time_log = getlog(tg, 'TimeLog', 1, 10, 2)
plot(Time_log, Output_log)
```

xpctarget.xpc.getlog

How To

- xpctarget.xpc.get (target application object)
- “Set Configuration Parameters”

Purpose Value of target object parameter index (not recommended)

Syntax `getparam(target_object, parameter_index)`

Arguments

<code>target_object</code>	Name of a target object. The default name is <code>tg</code> .
<code>parameter_index</code>	Index number of the parameter.

Description `getparam` returns the value of the parameter associated with `parameter_index`.

Note Method `xpctarget.xpc.getparam` will be removed in a future release. Use method `SimulinkRealTime.target.getparam` instead.

Examples Get the value of parameter index 5.

```
getparam(tg, 5)
ans = 400
```

xpctarget.xpc.getparamid

Purpose	Parameter index from parameter list (not recommended)	
Syntax	<code>getparamid(target_object, 'block_name', 'parameter_name')</code>	
Arguments	<code>target_object</code>	Name of a target object. The default name is <code>tg</code> .
	<code>'block_name'</code>	Simulink block path without model name.
	<code>'parameter_name'</code>	Name of a parameter within a Simulink block.

Description `getparamid` returns the index of a parameter in the parameter list based on the path to the parameter name. The names must be entered in full and are case sensitive. Note, enter for `block_name` the mangled name that Simulink Coder uses for code generation.

Note Method `xpctarget.xpc.getparamid` will be removed in a future release. Use method `SimulinkRealTime.target.getparamid` instead.

Examples Get the parameter property for the parameter `Gain` in the Simulink block `Gain1`, incrementally increase the gain, and pause to observe the signal trace.

```
id = getparamid(tg, 'Subsystem/Gain1', 'Gain')
for i = 1 : 3
    set(tg, id, i*2000);
    pause(1);
end
```

Get the property index of a single block.

```
getparamid(tg, 'Gain1', 'Gain') ans = 5
```

See Also `xpctarget.xpc.getsignalid`

How To

- “Application and Driver Scripts”
- “Why Does the getparamid Function Return Nothing?”

xpctarget.xpc.getparamname

Purpose Block path and parameter name from index list (not recommended)

Syntax `getparamname(target_object, parameter_index)`

Arguments

<code>target_object</code>	Name of a target object. The default name is <code>tg</code> .
<code>parameter_index</code>	Index number of the parameter.

Description `getparamname` returns two argument strings, block path and parameter name, from the index list for the specified parameter index.

Note Method `xpctarget.xpc.getparamid` will be removed in a future release. Use method `SimulinkRealTime.target.getparamid` instead.

Examples Get the block path and parameter name of parameter index 5.

```
[blockPath,parName]=getparamname(tg,5)
blockPath =
Signal Generator
parName =
Amplitude
```

Purpose Scope object pointing to scope defined in kernel (not recommended)


Syntax
`scope_object_vector = getscope(target_object, scope_number)`
`scope_object = target_object.getscope(scope_number)`

Arguments

<code>target_object</code>	Name of a target object.
<code>scope_number_vector</code>	Vector of existing scope indices listed in the target object property <code>Scopes</code> . The vector can have only one element.
<code>scope_object</code>	MATLAB variable for a new scope object vector. The vector can have only one scope object.

Description `getscope` returns a scope object vector. If you try to get a nonexistent scope, the result is an error. You can retrieve the list of existing scopes using the method `get(target_object, 'scopes')` or `target_object.scopes`.

Note Method `xpctarget.xpc.getscope` will be removed in a future release. Use method `SimulinkRealTime.target.getscope` instead.



Examples

If your Simulink model has an Simulink Real-Time scope block, a target scope is created at the time the target application is downloaded to the target computer. To change the number of samples, you need to create a scope object and then change the scope object property `NumSamples`.

```
sc1 = getscope(tg,1) or sc1 = tg.getscope(1)
sc1.NumSample = 500
```

The following example gets the properties of all scopes on the target computer and creates a vector of scope objects on the host computer. If the target object has more than one scope, it create a vector of scope objects.

```
scvector = getscope(tg)
```

See Also

`getxpcenv` | `xpctarget.xpc.remscope`

How To

- “Application and Driver Scripts”

Purpose Value of target object signal index (not recommended)

Syntax `getsignal(target_object, signal_index)`

Arguments

<code>target_object</code>	Name of a target object. The default name is <code>tg</code> .
<code>signal_index</code>	Index number of the signal.

Description `getsignal` returns the value of the signal associated with `signal_index`.

Note Method `xpctarget.xpc.getsignal` will be removed in a future release. Use method `SimulinkRealTime.target.getsignal` instead.

Examples Get the value of signal index 2.

```
getsignal(tg, 2)
ans = -3.3869e+006
```

xpctarget.xpc.getsignalid

Purpose Signal index or signal property from signal list (not recommended)

Syntax `getsignalid(target_object, 'signal_name')`
`tg.getsignalid('signal_name')`

Arguments

<code>target_object</code>	Name of an existing target object.
<code>signal_name</code>	Enter the name of a signal from your Simulink model. For blocks with a single signal, the <code>signal_name</code> is equal to the <code>block_name</code> . For blocks with multiple signals, the Simulink Real-Time software appends S1, S2 . . . to the <code>block_name</code> .

Description `getsignalid` returns the index or name of a signal from the signal list, based on the path to the signal name. The block names must be entered in full and are case sensitive. Note, enter for `block_name` the mangled name that Simulink Coder uses for code generation.

Note Method `xpctarget.xpc.getsignalid` will be removed in a future release. Use method `SimulinkRealTime.target.getsignalid` instead.

Examples Get the signal index for the single signal from the Simulink block Gain1.

```
getsignalid(tg, 'Gain1') or tg.getsignalid('Gain1')
ans = 6
```

See Also `xpctarget.xpc.getparamid`

How To

- “Application and Driver Scripts”
- “Why Does the `getparamid` Function Return Nothing?”

Purpose

Return vector of signal indices (not recommended)

Syntax

```
getsignalidsfromlabel(target_object, signal_label)  
target_object.getsignalidsfromlabel(signal_label)
```

Arguments

<code>target_object</code>	Name of a target object. The default name is <code>tg</code> .
<code>signal_label</code>	Signal label (from Simulink model).

Description

`getsignalidsfromlabel` returns a vector of one or more signal indices that are associated with the labeled signal, `signal_label`. This function assumes that you have labeled the signal for which you request the index (see the **Signal name** parameter of the “Signal Properties Controls”). Note that the Simulink Real-Time software refers to Simulink signal names as signal labels.

Note Method `xpctarget.xpc.getsignalidsfromlabel` will be removed in a future release. Use method `SimulinkRealTime.target.getsignalidsfromlabel` instead.

Examples

Get the vector of signal indices for a signal labeled Gain.

```
>> tg.getsignalidsfromlabel('xpcoscGain')  
ans =  
0
```

See Also

`xpctarget.xpc.getsignallabel`

xpctarget.xpc.getsignallabel

Purpose Return signal label (not recommended)

Syntax `getsignallabel(target_object, signal_index)`
`target_object.getsignallabel(signal_index)`

Arguments

<code>target_object</code>	Name of a target object. The default name is <code>tg</code> .
<code>signal_index</code>	Index number of the signal.

Description `getsignallabel` returns the signal label for the specified signal index, `signal_index`. `signal_label`. This function assumes that you have labeled the signal for which you request the label (see the **Signal name** parameter of the “Signal Properties Controls”). Note that the Simulink Real-Time software refers to Simulink signal names as signal labels.

Note Method `xpctarget.xpc.getsignallabel` will be removed in a future release. Use method `SimulinkRealTime.target.getsignallabel` instead.

Examples

```
>> getsignallabel(tg, 0)
ans =
xpcoscGain
```

See Also `xpctarget.xpc.getsignalidsfromlabel`

Purpose Signal name from index list (not recommended)

Syntax `getsignalname(target_object, signal_index)`
`target_object.getsignalname(signal_index)`

Arguments

<code>target_object</code>	Name of a target object. The default name is <code>tg</code> .
<code>signal_index</code>	Index number of the signal.

Description `getsignalname` returns one argument string, signal name, from the index list for the specified signal index.

Note Method `xpctarget.xpc.getsignalname` will be removed in a future release. Use method `SimulinkRealTime.target.getsignalname` instead.

Examples Get the signal name of signal ID 2.

```
[sigName]=getsignalname(tg,2)
sigName =
Gain2
```

xpctarget.xpc.load

Purpose Download target application to target computer (not recommended)

Syntax
`target_object = target_object.load(target_application)`
`target_object = load(target_object,target_application)`

Description `target_object = target_object.load(target_application)` loads the application `target_application` onto the target computer represented by `target_object`.

Note Method `xpctarget.xpc.load` will be removed in a future release. Use method `SimulinkRealTime.target.load` instead.

The call returns `target_object`, updated with the new state of the target.

`target_object = load(target_object,target_application)` is an alternative syntax.

Input Arguments

target_object

Object of type `xpctarget.xpc` that represents the target computer. Before calling this function, make sure that you have started the target computer with the Simulink Real-Time kernel and have applied the required host-target communication settings.

Data Types

struct

target_application

Name of the target application, without file extension. `target_application` can also contain the absolute path to the target application, without file extension.

You must build the application in the current working folder on the host computer. By default, the Simulink Real-Time software calls `xpctarget.xpc.load` automatically after the Simulink

Coder build process completes. If a target application was previously loaded, before downloading the new target application, xpctarget.xpc.load unloads the old target application.

If you are running the target application in Standalone mode, a call to xpctarget.xpc.load has no effect. To load a new application, you must rebuild the standalone application files with the new application and transfer the updated files to the target computer using xpctarget.ftp. Then, restart the target computer with the new standalone application.

Data Types

char

Examples

Load xpcosc

Load the target application xpcosc into target computer TargetPC1, represented by target object tg. Start the application.

Get the target object.

```
tg=xpctarget.xpc('TargetPC1')
```

```
Simulink Real-Time Object
```

```
Connected          = Yes
Application         = loader
```

Load the target application.

```
tg.load('xpcosc')
```

```
Simulink Real-Time Object
```

```
Connected          = Yes
Application         = xpcosc
Mode               = Real-Time Single-Tasking
Status             = stopped
CPUOverload        = none
```

xpctarget.xpc.load

```
ExecTime           = 0.0000
SessionTime        = 918.5713
StopTime           = 0.200000
SampleTime         = 0.000250
AvgTET             = NaN
MinTET             = 9999999.000000
MaxTET             = 0.000000
ViewMode           = 0

TimeLog            = Vector(0)
StateLog           = Matrix (0 x 2)
OutputLog          = Matrix (0 x 2)
TETLog             = Vector(0)
MaxLogSamples      = 16666
NumLogWraps        = 0
LogMode            = Normal

Scopes             = No Scopes defined
NumSignals         = 7
ShowSignals        = off

NumParameters      = 7
ShowParameters     = off
```

Start the application.

```
tg.start;
```

See Also xpctarget.xpc.unload

Related Examples

- “Application and Driver Scripts”

Purpose Restore parameter values saved in specified file (not recommended)

Syntax `loadparamset(target_object, 'filename')`
`target_object.loadparamset('filename')`

Arguments

<code>target_object</code>	Name of an existing target object.
<code>filename</code>	Enter the name of the file that contains the saved parameters.

Description `loadparamset` restores the target application parameter values saved in the file `filename`. This file must be located on a local drive of the target computer. This method assumes that you have a parameter file from a previous run of the `xpctarget.xpc.saveparamset` method.

Note Method `xpctarget.xpc.loadparamset` will be removed in a future release. Use method `SimulinkRealTime.target.loadparamset` instead.

See Also `xpctarget.xpc.saveparamset`

xpctarget.xpc.reboot

Purpose Reboot target computer (not recommended)

Syntax MATLAB command line

```
reboot(target_object)
```

Target computer command line

```
reboot
```

Arguments target_object Name of an existing target object.

Description reboot reboots the target computer, and if a target boot disk is still present, the Simulink Real-Time kernel is reloaded.

Note Method `xpctarget.xpc.reboot` will be removed in a future release. Use method `SimulinkRealTime.target.reboot` instead.

On the target computer command line, you can use the corresponding command `reboot`.

You can also use this method to reboot the target computer back to Windows® after removing the target boot disk.

Note This method might not work on some target hardware.

See Also `xpctarget.xpc.load` | `xpctarget.xpc.unload`

Purpose Remove scope from target computer (not recommended)

Syntax MATLAB command line

```
remscope(target_object, scope_number_vector)
target_object.remscope(scope_number_vector)
remscope(target_object)
target_object.remscope
```

Target computer command line

```
remscope scope_number
remscope 'all'
```


Arguments

target_object	Name of a target object. The default name is tg.
scope_number_vector	Vector of existing scope indices listed in the target object property Scopes.
scope_number	Single scope index.

Description

If a scope index is not given, the method `remscope` deletes all scopes on the target computer. The method `remscope` has no return value. The scope object representing the scope on the host computer is not deleted.

Note Method `xpctarget.xpc.remscope` will be removed in a future release. Use method `SimulinkRealTime.target.remscope` instead.



Note that you can only permanently remove scopes that are added with the method `addscope`. This is a scope that is outside a model. If you remove a scope that has been added through a scope block (the scope block is inside the model), a subsequent run of that model creates the scope again.

Examples

Remove a single scope.

```
remscope(tg,1)
```

or

```
tg.remscope(1)
```

Remove two scopes.

```
remscope(tg,[1 2])
```

or

```
tg.remscope([1,2])
```

Remove all scopes.

```
remscope(tg)
```

or

tg.remscope

See Also

xpctarget.xpc.addscope | xpctarget.xpc.getscope

How To

- “Application and Driver Scripts”

xpctarget.xpc.saveparamset

Purpose Save current target application parameter values (not recommended)

Syntax
`saveparamset(target_object, 'filename')`
`target_object.saveparamset('filename')`

Arguments

<code>target_object</code>	Name of an existing target object.
<code>filename</code>	Enter the name of the file to contain the saved parameters.

Description `saveparamset` saves the target application parameter values in the file `filename`. This method saves the file on a local drive of the target computer (C:\ by default). You can later reload these parameters with the `xpctarget.xpc.loadparamset` function.

Note Method `xpctarget.xpc.saveparamset` will be removed in a future release. Use method `SimulinkRealTime.target.saveparamset` instead.

You might want to save target application parameter values if you change these parameter values while the application is running in Real-Time mode. Saving these values enables you to easily recreate target application parameter values from a number of application runs.

See Also `xpctarget.xpc.loadparamset`

xpctarget.xpc.set (target application object)

Purpose Change target application object property values (not recommended)

Syntax MATLAB command line

```
set(target_object)
set(target_object, 'property_name1', 'property_value1',
'property_name2', 'property_value2', . . .)
target_object.set('property_name1', 'property_value1')
set(target_object, property_name_vector,
property_value_vector)
target_object.property_name = property_value
```

Target computer command line - Commands are limited to the target object properties stoptime, sampletime, and parameters.

```
parameter_name = parameter_value
stoptime = floating_point_number
sampletime = floating_point_number
```

Arguments

target_object	Name of a target object.
'property_name'	Name of a target object property. Always use quotation marks.
property_value	Value for a target object property. Always use quotation marks for character strings; quotation marks are optional for numbers.

Description

set sets the properties of the target object. Not all properties are user writable.

Note Method xpctarget.xpc.set (target application object) will be removed in a future release. Use method SimulinkRealTime.target.set instead.

xpctarget.xpc.set (target application object)

Properties must be entered in pairs or, using the alternate syntax, as one-dimensional cell arrays of the same size. This means they must both be row vectors or both column vectors, and the corresponding values for properties in `property_name_vector` are stored in `property_value_vector`. The writable properties for a target object are listed in the following table. This table includes a description of the properties:

Property	Description	Writable
Application	Name of the Simulink model and target application built from that model.	No
AvgTET	<p>Average task execution time. This value is an average of the measured CPU times, in seconds, to run the model equations and post outputs during each sample interval. Task execution time is nearly constant, with minor deviations due to cache, memory access, interrupt latency, and multirate model execution.</p> <p>The TET includes:</p> <ul style="list-style-type: none">• Complete I/O latency.• Data logging (the parts that happen in a real-time task). This includes data captured in scopes.• Asynchronous interruptions.• Parameter updating latency (if the Double buffer parameter changes parameter is set in the Simulink Real-Time Options node of the model Configuration Parameters dialog box). <p>Note that the TET is not the only consideration in determining the minimum achievable sample time. Other</p>	No

xpctarget.xpc.set (target application object)

Property	Description	Writable
	considerations, not included in the TET, are: <ul style="list-style-type: none">• Time required to measure TET• Interrupt latency required to schedule and run one step of the model	
CommunicationTimeOut	Communication timeout between host and target computer, in seconds.	Yes
Connected	Communication status between the host computer and the target computer. Values are 'Yes' and 'No'.	No
CPUoverload	CPU status for overload. If the target application requires more CPU time than the sample time of the model, this value is set from 'none' to 'detected' and the current run is stopped. Returning this status to 'none' requires either a faster processor or a larger sample time.	No
ExecTime	Execution time. Time, in seconds, since your target application started running. When the target application stops, the total execution time is displayed.	No
LogMode	Controls which data points are logged: <ul style="list-style-type: none">• Time-equidistant logging. Logs a data point at every time interval. Set value to 'Normal'.• Value-equidistant logging. Logs a data point only when an output signal from the OutputLog changes by a specified value (increment). Set the value to the difference in signal values.	Yes

xpctarget.xpc.set (target application object)

Property	Description	Writable
MaxLogSamples	<p>Maximum number of samples for each logged signal within the circular buffers for TimeLog, StateLog, OutputLog, and TETLog. StateLog and OutputLog can have one or more signals.</p> <p>This value is calculated by dividing the Signal Logging Buffer Size by the number of logged signals. The Signal Logging Buffer Size box is in the Simulink Real-Time Options pane of the Configuration Parameters dialog box.</p>	No
MaxTET	<p>Maximum task execution time. Corresponds to the slowest time (longest time measured), in seconds, to update model equations and post outputs.</p>	No
MinTET	<p>Minimum task execution time. Corresponds to the fastest time (smallest time measured), in seconds, to update model equations and post outputs.</p>	No
Mode	<p>Type of Simulink Coder code generation. Values are 'Real-Time Singletasking', 'Real-Time Multitasking', and 'Accelerate'. The default value is 'Real-Time Singletasking'. Even if you select 'Real-Time Multitasking', the actual mode can be 'Real-Time Singletasking'. This happens if your model contains only one or two tasks and the sample rates are equal.</p>	No

xpctarget.xpc.set (target application object)

Property	Description	Writable
NumLogWraps	The number of times the circular buffer wrapped. The buffer wraps each time the number of samples exceeds MaxLogSamples.	No
NumParameters	The number of parameters from your Simulink model that you can tune or change.	No
NumSignals	The number of signals from your Simulink model that are available to be viewed with a scope.	No
OutputLog	Storage in the MATLAB workspace for the output or Y-vector logged during execution of the target application.	No
Parameters	List of tunable parameters. This list is visible only when ShowParameters is set to 'on': <ul style="list-style-type: none">• Property value. Value of the parameter in a Simulink block.• Type. Data type of the parameter. Always double.• Size. Size of the parameter. For example, scalar, 1-by-2 vector, or 2-by-3 matrix.• Parameter name. Name of a parameter in a Simulink block.• Block name. Name of a Simulink block.	No

xpctarget.xpc.set (target application object)

Property	Description	Writable
SampleTime	Time between samples. This value equals the step size, in seconds, for updating the model equations and posting the outputs. (See “Alternative Configuration and Control Methods” for limitations on target property changes to sample times.)	Yes
Scopes	List of index numbers, with one index for each scope.	No
SessionTime	Time since the kernel started running on your target computer. This is also the elapsed time since you booted the target computer. Values are in seconds.	No
ShowParameters	Flag set to view or hide the list of parameters from your Simulink blocks. This list is shown when you display the properties for a target object. Values are 'on' and 'off'.	Yes
ShowSignals	Flag set to view or hide the list of signals from your Simulink blocks. This list is shown when you display the properties for a target object. Values are 'on' and 'off'.	Yes
Signals	List of viewable signals. This list is visible only when ShowSignals is set to 'on'. <ul style="list-style-type: none">• Property name. S0, S1. . .• Property value. Value of the signal.• Block name. Name of the Simulink block the signal is from.	No

xpctarget.xpc.set (target application object)

Property	Description	Writable
StateLog	Storage in the MATLAB workspace for the state or x-vector logged during execution of the target application.	No
Status	Execution status of your target application. Values are 'stopped' and 'running'.	No
StopTime	Time when the target application stops running. Values are in seconds. The original value is set in the Solver pane of the Configuration Parameters dialog box. When the ExecTime reaches StopTime, the application stops running.	Yes
TETLog	Storage in the MATLAB workspace for a vector containing task execution times during execution of the target application. To enable logging of the TET, you need to select the Log Task Execution Time check box in the Simulink Real-Time Options pane of the Configuration Parameters dialog box.	No
TimeLog	Storage in the MATLAB workspace for the time or T-vector logged during execution of the target application.	No
ViewMode	Display either all scopes or a single scope on the target computer. Value is 'all' or a single scope index. This property is active only if the environment property TargetScope is set to enabled.	Yes

The function `set` typically does not return a value. However, if called with an explicit return argument, for example, `a = set(target_object, property_name, property_value)`, it returns the value of the properties after the indicated settings have been made.

xpctarget.xpc.set (target application object)

Examples

Get a list of writable properties for a scope object.

```
set(tg)
ans =
    StopTime: {}
    SampleTime: {}
    ViewMode: {}
    LogMode: {}
    ShowParameters: {}
    ShowSignals: {}
```

Change the property ShowSignals to on.

```
tg.set('showsignals', 'on') or set(tg, 'showsignals', 'on')
```

As an alternative to the method set, use the target object property ShowSignals. In the MATLAB window, type

```
tg.showsignals = 'on'
```

See Also

```
get | set | xpctarget.xpc.get (target application object) |
xpctarget.xpcsc.get (scope object) | xpctarget.xpcsc.set
(scope object)
```

How To

- “Application and Driver Scripts”

Purpose Change writable target object parameters (not recommended)

Syntax `setparam(target_object, parameter_index, parameter_value)`

Arguments

<code>target_object</code>	Name of an existing target object. The default name is <code>tg</code> .
<code>parameter_index</code>	Index number of the parameter.
<code>parameter_value</code>	Value for a target object parameter.

Description Method of a target object. Set the value of the target parameter. This method returns a structure that stores the parameter index, previous parameter values, and new parameter values in the following fields:

- `parIndexVec`
- `OldValues`
- `NewValues`

Note Method `xpctarget.xpc.setparam` will be removed in a future release. Use method `SimulinkRealTime.target.setparam` instead.

Examples Set the value of parameter index 5 to 100.

```
setparam(tg, 5, 100)
ans =
parIndexVec: 5
OldValues: 400
NewValues: 100
```

Simultaneously set values for multiple parameters. Use the cell array format to specify new parameter values.

```
setparam(tg, [1 5], {10,100})
```

xpctarget.xpc.setparam

```
ans =  
parIndexVec: [1 5]  
OldValues: {[2] [4]}  
NewValues: {[10] [100]}
```

xpctarget.xpc.start (target application object)

Purpose Start execution of target application on target computer (not recommended)

Syntax MATLAB command line

```
start(target_object)
target_object.start
+target_object
```

Target computer command line

```
start
```

Arguments target_object Name of a target object. The default name is tg.

Description Method of both target and scope objects. Starts execution of the target application represented by the target object. Before using this method, the target application must be created and loaded on the target computer. If a target application is running, this command has no effect.

Note Method `xpctarget.xpc.start (target application object)` will be removed in a future release. Use method `SimulinkRealTime.target.start` instead.

Examples Start the target application represented by the target object tg.

```
+tg
tg.start
start(tg)
```

See Also `xpctarget.xpc.stop (target application object)`
| `xpctarget.xpc.load` | `xpctarget.xpc.unload` |
`xpctarget.xpcsc.stop (scope object)`

xpctarget.xpc.stop (target application object)

Purpose Stop execution of target application on target computer (not recommended)

Syntax MATLAB command line

```
stop(target_object)
target_object.stop
-target_object
```

Target computer command line

```
stop
```

Arguments target_object Name of a target object.

Description Stops execution of the target application represented by the target object. If the target application is stopped, this command has no effect.

Note Method xpctarget.xpc.stop (target application object) will be removed in a future release. Use method SimulinkRealTime.target.stop instead.

Examples Stop the target application represented by the target object tg.

```
stop(tg) or tg.stop or -tg
```

See Also xpctarget.xpc.start (target application object) | xpctarget.xpcsc.stop (scope object) | xpctarget.xpcsc.start (scope object)

Purpose Test communication between host and target computers (not recommended)

Syntax targetping(target_object)
target_object.targetping

Arguments target_object Name of a target object.

Description Method of a target object. Use this method to ping a target computer from the host computer. This method returns `success` if the Simulink Real-Time kernel is loaded and running and communication is working between host and target, otherwise it returns `failed`.

This function works with both RS-232 and TCP/IP communication.

Note

- Method `xpctarget.xpc.targetping` will be removed in a future release. Use command `slrtpingtarget` or method `SimulinkRealTime.target.ping` instead.
 - RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.
-

Examples Ping the communication between the host and the target object `tg`.

`targetping(tg)` or `tg.targetping`

See Also `xpctarget.xpc`

xpctarget.xpc.unload

Purpose	Remove current target application from target computer (not recommended)
Syntax	<code>unload(target_object)</code> <code>target_object.unload</code>
Arguments	<code>target_object</code> Name of a target object that represents a target application.
Description	Method of a target object. The kernel goes into loader mode and is ready to download new target application from the host computer.

Note Method `xpctarget.xpc.unload` will be removed in a future release. Use method `SimulinkRealTime.target.unload` instead.

If you are running in StandAlone mode, this command has no effect. To unload and reload a new application, you must rebuild the standalone application with the new application, then reboot the target computer with the updated standalone application.

Examples Unload the target application represented by the target object `tg`.

`unload(tg)` or `tg.unload`

See Also `xpctarget.xpc.load` | `xpctarget.xpc.reboot`

Purpose

Control and access properties of file scopes (not recommended)

Description

The scope gets a data package from the kernel and stores the data in a file in the target computer file system. Depending on the setting of `WriteMode`, the file size is or is not continuously updated. You can then transfer the data to another computer for examination or plotting.

Note Class `xpctarget.xpcfcs` will be removed in a future release. Use class `SimulinkRealTime.fileScope` instead.

Methods

These methods are inherited from `xpctarget.xpcsc` Class.

Method	Description
<code>xpctarget.xpcsc.addsignals</code>	Add signals to scope represented by scope object
<code>xpctarget.xpcsc.get</code> (scope object)	Return property values for scope objects
<code>xpctarget.xpcsc.removesignals</code>	Remove signals from scope represented by scope object
<code>xpctarget.xpcsc.set</code> (scope object)	Change property values for scope objects
<code>xpctarget.xpcsc.start</code> (scope object)	Start execution of scope on target computer
<code>xpctarget.xpcsc.stop</code> (scope object)	Stop execution of scope on target computer
<code>xpctarget.xpcsc.trigger</code>	Software trigger start of data acquisition for scope(s)

Properties

These properties are inherited from `xpctarget.xpcsc` Class.

xpctarget.xpcfs Class

Property	Description	Writable
Application	Name of the Simulink model associated with this scope object.	No
Decimation	A number n, where every nth sample is acquired in a scope window.	Yes
NumPrePostSamples	Number of samples collected before or after a trigger event. The default value is 0. Entering a negative value collects samples before the trigger event. Entering a positive value collects samples after the trigger event. If you set <code>TriggerMode</code> to 'FreeRun', this property has no effect on data acquisition.	Yes
NumSamples	<p>Number of contiguous samples captured during the acquisition of a data package. If the scope stops before capturing this number of samples, the scope has the collected data up to the end of data collection, then has zeroes for the remaining uncollected data. Note that you should know what type of data you are collecting, it is possible that your data contains zeroes.</p> <p>For file scopes, this parameter works in conjunction with the AutoRestart check box. If the AutoRestart box is selected, the file scope collects data up to Number of Samples, then starts over again, overwriting the buffer. If the AutoRestart box is not selected, the file scope collects data only up to Number of Samples, then stops.</p>	Yes
ScopeId	A numeric index, unique for each scope.	No
Signals	List of signal indices from the target object to display on the scope.	Yes

Property	Description	Writable
Status	Indicate whether data is being acquired, the scope is waiting for a trigger, the scope has been stopped (interrupted), or acquisition is finished. Values are 'Acquiring', 'Ready for being Triggered', 'Interrupted', and 'Finished'.	No
TriggerLevel	If TriggerMode is 'Signal', indicates the value the signal has to cross to trigger the scope and start acquiring data. The trigger level can be crossed with either a rising or falling signal.	Yes
TriggerMode	Trigger mode for a scope. Valid values are 'FreeRun' (default), 'Software', 'Signal', and 'Scope'.	Yes
TriggerSample	<p>If TriggerMode is 'Scope', then TriggerSample specifies which sample of the triggering scope the current scope should trigger on. For example, if TriggerSample is 0 (default), the current scope triggers on sample 0 (first sample acquired) of the triggering scope. This means that the two scopes will be perfectly synchronized. If TriggerSample is 1, the first sample (sample 0) of the current scope will be at the same instant as sample number 1 (second sample in the acquisition cycle) of the triggering scope.</p> <p>As a special case, setting TriggerSample to -1 means that the current scope is triggered at the end of the acquisition cycle of the triggering scope. Thus, the first sample of the triggering scope is acquired one sample after the last sample of the triggering scope.</p>	Yes

xpctarget.xpcfs Class

Property	Description	Writable
TriggerScope	If TriggerMode is 'Scope', identifies the scope to use for a trigger. A scope can be set to trigger when another scope is triggered. You do this by setting the slave scope property TriggerScope to the scope index of the master scope.	Yes
TriggerSignal	If TriggerMode is 'Signal', identifies the block output signal to use for triggering the scope. You identify the signal with a signal index from the target object property Signal.	Yes
TriggerSlope	If TriggerMode is 'Signal', indicates whether the trigger is on a rising or falling signal. Values are 'Either' (default), 'Rising', and 'Falling'.	Yes
Type	Determines whether the scope is displayed on the host computer or on the target computer. Values are 'Host', 'Target', and 'File'. Property Type is set only once, when the scope is created on the target computer.	No

These properties are specific to class xpcfs.

Property	Description	Writeable
AutoRestart	Values are 'on' and 'off'. For file scopes, enable the file scope to collect data up to the number of samples (NumSamples), then start over again, appending the new data to the end of the signal data file. Clear the AutoRestart check box to have the file scope collect data up to Number of samples , then stop. If the named signal data file already exists when you start the	No

Property	Description	Writeable
	<p>target application, the software overwrites the old data with the new signal data.</p> <p>To use the DynamicFileName property, set AutoRestart to 'on' first.</p> <p>For host or target scopes, this parameter has no effect.</p>	
DynamicFileName	<p>Values are 'on' and 'off'. By default, the value is 'off'.</p> <p>Enable the ability to dynamically create multiple log files for file scopes.</p> <p>To use DynamicFileName, set AutoRestart to 'on' first. When you enable DynamicFileName, configure Filename to create incrementally numbered file names for the multiple log files. Failure to do so causes an error when you try to start the scope.</p> <p>You can enable the creation of up to 99999999 files (<%%>.dat). The length of a file name, including the specifier, cannot exceed eight characters.</p> <p>For host or target scopes, this parameter has no effect.</p>	Yes

xpctarget.xpcfs Class

Property	Description	Writeable
Filename	<p>Provide a name for the file to contain the signal data. By default, the target computer writes the signal data to a file named C:\data.dat for scope blocks. Note that for file scopes created through the MATLAB interface, no name is initially assigned to <code>FileName</code>. After you start the scope, the software assigns a name for the file to acquire the signal data. This name typically consists of the scope object name, <code>ScopeId</code>, and the beginning letters of the first signal added to the scope.</p> <p>If you set <code>DynamicFileName</code> and <code>AutoRestart</code> to 'on', configure <code>Filename</code> to dynamically increment. Use a base file name, an underscore (<code>_</code>), and a <code>< ></code> specifier. Within the specifier, enter one to eight <code>%</code> symbols. Each symbol <code>%</code> represents a decimal location in the file name. The specifier can appear anywhere in the file name. For example, the following value for <code>Filename</code>, <code>C:\work\file_<%%>.dat</code> creates file names with the following pattern:</p> <pre>file_001.dat file_002.dat file_003.dat</pre>	No

Property	Description	Writeable
	<p>The last file name of this series will be <code>file_999.dat</code>. If the function is still logging data when the last file name reaches its maximum size, the function starts from the beginning and overwrites the first file name in the series. If you do not retrieve the data from existing files before they are overwritten, the data is lost.</p> <p>For host or target scopes, this parameter has no effect.</p>	
MaxWriteFileSize	<p>Provide the maximum size of <code>Filename</code>, in bytes. This value must be a multiple of <code>WriteSize</code>. Default is <code>536870912</code>.</p> <p>When the size of a log file reaches <code>MaxWriteFileSize</code>, the software creates a subsequently numbered file name, and continues logging data to that file, up until the highest log file number you have specified. If the software cannot create additional log files, it overwrites the first log file.</p> <p>For host or target scopes, this parameter has no effect.</p>	Yes

xpctarget.xpcfs Class

Property	Description	Writeable
Mode	<p>Note The Mode property will be removed in a future release.</p> <ul style="list-style-type: none">• For target scopes, use <code>DisplayMode</code>.• For file scopes, use <code>WriteMode</code>.• For host scopes, this parameter has no effect.	Yes
WriteMode	<p>For file scopes, specify when a file allocation table (FAT) entry is updated. Values are 'Lazy' or 'Commit'. Both modes write the signal data to the file. With 'Commit' mode, each file write operation simultaneously updates the FAT entry for the file. This mode is slower, but the file system maintains the actual file size. With 'Lazy' mode, the FAT entry is updated only when the file is closed and not during each file write operation. This mode is faster, but if the system crashes before the file is closed, the file system might not know the actual file size (the file contents, however, will be intact).</p> <p>For host or target scopes, this parameter has no effect.</p>	Yes
WriteSize	Enter the block size, in bytes, of the data chunks. This parameter	Yes

Property	Description	Writeable
	<p>specifies that a memory buffer, of length number of samples (<code>NumSamples</code>), collect data in multiples of <code>WriteSize</code>. By default, this parameter is 512 bytes, which is the typical disk sector size. Using a block size that is the same as the disk sector size provides better performance.</p> <p>If you experience a system crash, you can expect to lose an amount of data the size of <code>WriteSize</code>.</p> <p>For host or target scopes, this parameter has no effect.</p>	

xpctarget.xpcsc.addsignal

Purpose Add signals to scope represented by scope object (not recommended)

Syntax MATLAB command line

```
addsignal(scope_object_vector, signal_index_vector)
scope_object_vector.addsignal(signal_index_vector)
```

Target command line

```
addsignal scope_index = signal_index, signal_index, . . .
```

Arguments

scope_object_vector	Name of a single scope object or the name of a vector of scope objects.
signal_index_vector	For one signal, use a single number. For two or more signals, enclose numbers in brackets and separate with commas.
scope_index	Single scope index.

Description

`addsignal` adds signals to a scope object. The signals must be specified by their indices, which you can retrieve using the target object method `getsignalid`. If the `scope_object_vector` has two or more scope objects, the same signals are assigned to each scope.

Note

- You must stop the scope before you can add a signal to it.
 - Method `xpctarget.xpcsc.addsignal` will be removed in a future release. Use methods `SimulinkRealTime.targetScope.addsignal`, `SimulinkRealTime.hostScope.addsignal`, and `SimulinkRealTime.fileScope.addsignal` instead.
-

Examples

Add signals 0 and 1 from the target object `tg` to the scope object `sc1`. The signals are added to the scope, and the scope object property `Signals` is updated to include the added signals.

```
sc1 = getscope(tg,1)
addsignal(sc1,[0,1]) or sc1.addsignal([0,1])
```

Display a list of properties and values for the scope object `sc1` with the property `Signals`, as shown below.

```
sc1.Signals
Signals          = 1 : Signal Generator
                  0 : Integrator1
```

Another way to add signals without using the method `addsignal` is to use the scope object method `set`.

```
set(sc1,'Signals', [0,1]) or sc1.set('signals',[0,1])
```

Or, to directly assign signal values to the scope object property `Signals`,

```
sc1.signals = [0,1]
```

See Also

`xpctarget.xpcsc.remsignal` | `xpctarget.xpcsc.set` (scope object) | `xpctarget.xpc.addscope` | `xpctarget.xpc.getsignalid`

How To

- “Target Scope Usage”
- “Host Scope Usage”
- “File Scope Usage”
- “Application and Driver Scripts”

xpctarget.xpcsc.get (scope object)

Purpose Return property values for scope objects (not recommended)

Syntax
`get(scope_object_vector)`
`get(scope_object_vector, 'scope_object_property')`
`get(scope_object_vector, scope_object_property_vector)`

Arguments

<code>target_object</code>	Name of a target object.
<code>scope_object_vector</code>	Name of a single scope or name of a vector of scope objects.
<code>scope_object_property</code>	Name of a scope object property.

Description `get` gets the value of readable scope object properties from a scope object or the same property from each scope object in a vector of scope objects. Scope object properties let you select signals to acquire, set triggering modes, and access signal information from the target application. You can view and change these properties using scope object methods.

Note Method `xpctarget.xpcsc.get (scope object)` will be removed in a future release. Use methods `SimulinkRealTime.targetScope.get`, `SimulinkRealTime.hostScope.get`, and `SimulinkRealTime.fileScope.get` instead.

The properties for a scope object are listed in the following table. This table includes descriptions of the properties and the properties you can change directly by assigning a value.

Property	Description	Writable
Application	Name of the Simulink model associated with this scope object.	No
Decimation	A number <i>n</i> , where every <i>n</i> th sample is acquired in a scope window.	Yes

xpctarget.xpcsc.get (scope object)

Property	Description	Writable
NumPrePostSamples	Number of samples collected before or after a trigger event. The default value is 0. Entering a negative value collects samples before the trigger event. Entering a positive value collects samples after the trigger event. If you set TriggerMode to 'FreeRun', this property has no effect on data acquisition.	Yes
NumSamples	<p>Number of contiguous samples captured during the acquisition of a data package. If the scope stops before capturing this number of samples, the scope has the collected data up to the end of data collection, then has zeroes for the remaining uncollected data. Note that you should know what type of data you are collecting, it is possible that your data contains zeroes.</p> <p>For file scopes, this parameter works in conjunction with the AutoRestart check box. If the AutoRestart box is selected, the file scope collects data up to Number of Samples, then starts over again, overwriting the buffer. If the AutoRestart box is not selected, the file scope collects data only up to Number of Samples, then stops.</p>	Yes
ScopeId	A numeric index, unique for each scope.	No
Signals	List of signal indices from the target object to display on the scope.	Yes
Status	Indicate whether data is being acquired, the scope is waiting for a trigger, the scope has been stopped (interrupted), or acquisition is finished. Values are 'Acquiring', 'Ready for being Triggered', 'Interrupted', and 'Finished'.	No

xpctarget.xpcsc.get (scope object)

Property	Description	Writable
TriggerLevel	If TriggerMode is 'Signal', indicates the value the signal has to cross to trigger the scope and start acquiring data. The trigger level can be crossed with either a rising or falling signal.	Yes
TriggerMode	Trigger mode for a scope. Valid values are 'FreeRun' (default), 'Software', 'Signal', and 'Scope'.	Yes
TriggerSample	<p>If TriggerMode is 'Scope', then TriggerSample specifies which sample of the triggering scope the current scope should trigger on. For example, if TriggerSample is 0 (default), the current scope triggers on sample 0 (first sample acquired) of the triggering scope. This means that the two scopes will be perfectly synchronized. If TriggerSample is 1, the first sample (sample 0) of the current scope will be at the same instant as sample number 1 (second sample in the acquisition cycle) of the triggering scope.</p> <p>As a special case, setting TriggerSample to -1 means that the current scope is triggered at the end of the acquisition cycle of the triggering scope. Thus, the first sample of the triggering scope is acquired one sample after the last sample of the triggering scope.</p>	Yes
TriggerScope	If TriggerMode is 'Scope', identifies the scope to use for a trigger. A scope can be set to trigger when another scope is triggered. You do this by setting the slave scope property TriggerScope to the scope index of the master scope.	Yes

xpctarget.xpcsc.get (scope object)

Property	Description	Writable
TriggerSignal	If TriggerMode is 'Signal', identifies the block output signal to use for triggering the scope. You identify the signal with a signal index from the target object property Signal.	Yes
TriggerSlope	If TriggerMode is 'Signal', indicates whether the trigger is on a rising or falling signal. Values are 'Either' (default), 'Rising', and 'Falling'.	Yes
Type	Determines whether the scope is displayed on the host computer or on the target computer. Values are 'Host', 'Target', and 'File'. Property Type is set only once, when the scope is created on the target computer.	No

Examples

List the readable properties, along with their current values. This is given in the form of a structure whose field names are the property names and whose field values are property values.

```
get(sc)
```

List the value for the scope object property Type. Notice that the property name is a string, in quotation marks, and is not case sensitive.

```
get(sc, 'type')  
ans = Target
```

See Also

```
get | set | xpctarget.xpcsc.set (scope object) |  
xpctarget.xpc.set (target application object)
```

xpctarget.xpcsc Class

Purpose Base class for the scope classes (not recommended)

Description This is the base class for the scope classes, `xpctarget.xpcfs Class`, `xpctarget.xpcschost Class`, and `xpctarget.xpcstg Class`. All methods and properties are inherited by the derived classes. When a mixture of derived classes are stored in a scope collection, only the base class methods and properties are available. The scope class constructors are `Private` and are not intended to be called from the MATLAB prompt.

Note Class `xpctarget.xpcsc` will be removed in a future release. Use classes `SimulinkRealTime.targetScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.fileScope` instead.

A scope acquires data from the target application and displays that data on the target computer, uploads the data to the host computer, or stores that data in a file in the target computer file system. The target, host, or file scopes run on the target computer.

Methods

These methods are inherited by the derived classes.

Method	Description
<code>xpctarget.xpcsc.addsignals</code>	Add signals to scope represented by scope object
<code>xpctarget.xpcsc.get</code> (scope object)	Return property values for scope objects
<code>xpctarget.xpcsc.removesignals</code>	Remove signals from scope represented by scope object
<code>xpctarget.xpcsc.set</code> (scope object)	Change property values for scope objects
<code>xpctarget.xpcsc.start</code> (scope object)	Start execution of scope on target computer

Method	Description
xpctarget.xpcsc.stop (scope object)	Stop execution of scope on target computer
xpctarget.xpcsc.trigge	Software trigger start of data acquisition for scope(s)

Properties

These properties are inherited by the derived classes.

Property	Description	Writable
Application	Name of the Simulink model associated with this scope object.	No
Decimation	A number n, where every nth sample is acquired in a scope window.	Yes
NumPrePostSamples	Number of samples collected before or after a trigger event. The default value is 0. Entering a negative value collects samples before the trigger event. Entering a positive value collects samples after the trigger event. If you set TriggerMode to 'FreeRun', this property has no effect on data acquisition.	Yes
NumSamples	<p>Number of contiguous samples captured during the acquisition of a data package. If the scope stops before capturing this number of samples, the scope has the collected data up to the end of data collection, then has zeroes for the remaining uncollected data. Note that you should know what type of data you are collecting, it is possible that your data contains zeroes.</p> <p>For file scopes, this parameter works in conjunction with the AutoRestart check box. If the AutoRestart box is selected, the file scope collects data up to Number of Samples, then starts over again, overwriting the buffer. If the</p>	Yes

xpctarget.xpcsc Class

Property	Description	Writable
	AutoRestart box is not selected, the file scope collects data only up to Number of Samples , then stops.	
ScopeId	A numeric index, unique for each scope.	No
Signals	List of signal indices from the target object to display on the scope.	Yes
Status	Indicate whether data is being acquired, the scope is waiting for a trigger, the scope has been stopped (interrupted), or acquisition is finished. Values are 'Acquiring', 'Ready for being Triggered', 'Interrupted', and 'Finished'.	No
TriggerLevel	If TriggerMode is 'Signal', indicates the value the signal has to cross to trigger the scope and start acquiring data. The trigger level can be crossed with either a rising or falling signal.	Yes
TriggerMode	Trigger mode for a scope. Valid values are 'FreeRun' (default), 'Software', 'Signal', and 'Scope'.	Yes
TriggerSample	If TriggerMode is 'Scope', then TriggerSample specifies which sample of the triggering scope the current scope should trigger on. For example, if TriggerSample is 0 (default), the current scope triggers on sample 0 (first sample acquired) of the triggering scope. This means that the two scopes will be perfectly synchronized. If TriggerSample is 1, the first sample (sample 0) of the current scope will be at the same instant as sample number 1 (second sample in the acquisition cycle) of the triggering scope. As a special case, setting TriggerSample to -1 means that the current scope is triggered at the end of the acquisition cycle of the triggering scope.	Yes

Property	Description	Writable
	Thus, the first sample of the triggering scope is acquired one sample after the last sample of the triggering scope.	
TriggerScope	If TriggerMode is 'Scope', identifies the scope to use for a trigger. A scope can be set to trigger when another scope is triggered. You do this by setting the slave scope property TriggerScope to the scope index of the master scope.	Yes
TriggerSignal	If TriggerMode is 'Signal', identifies the block output signal to use for triggering the scope. You identify the signal with a signal index from the target object property Signal.	Yes
TriggerSlope	If TriggerMode is 'Signal', indicates whether the trigger is on a rising or falling signal. Values are 'Either' (default), 'Rising', and 'Falling'.	Yes
Type	Determines whether the scope is displayed on the host computer or on the target computer. Values are 'Host', 'Target', and 'File'. Property Type is set only once, when the scope is created on the target computer.	No

xpctarget.xpcsc.remsignal

Purpose Remove signals from scope represented by scope object (not recommended)

Syntax **MATLAB command line**

```
remsignal(scope_object)
remsignal(scope_object, signal_index_vector)
scope_object.remsignal(signal_index_vector)
```

Target command line

```
remsignal scope_index = signal_index, signal_index, . . .
```

Arguments

scope_object	MATLAB object created with the target object method <code>addscope</code> or <code>getscope</code> .
signal_index_vector	Index numbers from the scope object property <code>Signals</code> . This argument is optional, and if it is left out all signals are removed.
signal_index	Single signal index.

Description `remsignal` removes signals from a scope object. The signals must be specified by their indices, which you can retrieve using the target object method `getsignalid`. If the `scope_index_vector` has two or more scope objects, the same signals are removed from each scope. The argument `signal_index` is optional; if it is left out, all signals are removed.

Note

- You must stop the scope before you can remove a signal from it.
 - Method `xpctarget.xpcsc.remsignal` will be removed in a future release. Use methods `SimulinkRealTime.targetScope.remsignal`, `SimulinkRealTime.hostScope.remsignal`, and `SimulinkRealTime.fileScope.remsignal` instead.
-

Examples

Remove signals 0 and 1 from the scope represented by the scope object `sc1`.

```
sc1.get('signals')
ans= 0 1
```

Remove signals from the scope on the target computer with the scope object property `Signals` updated.

```
remsignal(sc1,[0,1])
```

or

```
sc1.remsignal([0,1])
```

See Also

`xpctarget.xpcsc.remsignal` | `xpctarget.xpc.getsignalid`

xpctarget.xpcsc.set (scope object)

Purpose Change property values for scope objects (not recommended)

Syntax

```
set(scope_object_vector)
set(scope_object_vector, property_name1, property_value1,
property_name2, property_value2, . . .)
scope_object_vector.set('property_name1', property_value1,
. . .)
set(scope_object, 'property_name', property_value, . . .)
```

Arguments

<code>scope_object</code>	Name of a scope object or a vector of scope objects.
<code>'property_name'</code>	Name of a scope object property. Always use quotation marks.
<code>property_value</code>	Value for a scope object property. Always use quotation marks for character strings; quotation marks are optional for numbers.

Description Method for scope objects. Sets the properties of the scope object. Not all properties are user writable. Scope object properties let you select signals to acquire, set triggering modes, and access signal information from the target application. You can view and change these properties using scope object methods.

Note Method `xpctarget.xpcsc.set (scope object)` will be removed in a future release. Use methods `SimulinkRealTime.targetScope.set`, `SimulinkRealTime.hostScope.set`, and `SimulinkRealTime.fileScope.set` instead.

Properties must be entered in pairs or, using the alternate syntax, as one-dimensional cell arrays of the same size. This means they must both be row vectors or both column vectors, and the corresponding values for properties in `property_name_vector` are stored in `property_value_vector`.

xpctarget.xpcsc.set (scope object)

The function `set` typically does not return a value. However, if called with an explicit return argument, for example, `a = set(target_object, property_name, property_value)`, it returns the values of the properties after the indicated settings have been made.

The properties for a scope object are listed in the following table. This table includes descriptions of the properties and the properties you can change directly by assigning a value.

Property	Description	Writable
Application	Name of the Simulink model associated with this scope object.	No
Decimation	A number n , where every n th sample is acquired in a scope window.	Yes
NumPrePostSamples	Number of samples collected before or after a trigger event. The default value is 0. Entering a negative value collects samples before the trigger event. Entering a positive value collects samples after the trigger event. If you set <code>TriggerMode</code> to 'FreeRun', this property has no effect on data acquisition.	Yes
NumSamples	<p>Number of contiguous samples captured during the acquisition of a data package. If the scope stops before capturing this number of samples, the scope has the collected data up to the end of data collection, then has zeroes for the remaining uncollected data. Note that you should know what type of data you are collecting, it is possible that your data contains zeroes.</p> <p>For file scopes, this parameter works in conjunction with the AutoRestart check box. If the AutoRestart box is selected, the file scope collects data up to Number of Samples, then starts over again, overwriting the buffer. If the AutoRestart box is not selected, the file scope</p>	Yes

xpctarget.xpcsc.set (scope object)

Property	Description	Writable
	collects data only up to Number of Samples , then stops.	
ScopeId	A numeric index, unique for each scope.	No
Signals	List of signal indices from the target object to display on the scope.	Yes
Status	Indicate whether data is being acquired, the scope is waiting for a trigger, the scope has been stopped (interrupted), or acquisition is finished. Values are 'Acquiring', 'Ready for being Triggered', 'Interrupted', and 'Finished'.	No
TriggerLevel	If TriggerMode is 'Signal', indicates the value the signal has to cross to trigger the scope and start acquiring data. The trigger level can be crossed with either a rising or falling signal.	Yes
TriggerMode	Trigger mode for a scope. Valid values are 'FreeRun' (default), 'Software', 'Signal', and 'Scope'.	Yes
TriggerSample	<p>If TriggerMode is 'Scope', then TriggerSample specifies which sample of the triggering scope the current scope should trigger on. For example, if TriggerSample is 0 (default), the current scope triggers on sample 0 (first sample acquired) of the triggering scope. This means that the two scopes will be perfectly synchronized. If TriggerSample is 1, the first sample (sample 0) of the current scope will be at the same instant as sample number 1 (second sample in the acquisition cycle) of the triggering scope.</p> <p>As a special case, setting TriggerSample to -1 means that the current scope is triggered at the end of the acquisition cycle of the triggering scope. Thus, the first sample of the triggering scope is</p>	Yes

xpctarget.xpcsc.set (scope object)

Property	Description	Writable
	acquired one sample after the last sample of the triggering scope.	
TriggerScope	If TriggerMode is 'Scope', identifies the scope to use for a trigger. A scope can be set to trigger when another scope is triggered. You do this by setting the slave scope property TriggerScope to the scope index of the master scope.	Yes
TriggerSignal	If TriggerMode is 'Signal', identifies the block output signal to use for triggering the scope. You identify the signal with a signal index from the target object property Signal.	Yes
TriggerSlope	If TriggerMode is 'Signal', indicates whether the trigger is on a rising or falling signal. Values are 'Either' (default), 'Rising', and 'Falling'.	Yes
Type	Determines whether the scope is displayed on the host computer or on the target computer. Values are 'Host', 'Target', and 'File'. Property Type is set only once, when the scope is created on the target computer.	No

Examples

Get a list of writable properties for a scope object.

```
sc1 = getscope(tg,1)
set(sc1)
ans=
    NumSamples: {}
    Decimation: {}
    TriggerMode: {5x1 cell}
    TriggerSignal: {}
    TriggerLevel: {}
    TriggerSlope: {4x1 cell}
    TriggerScope: {}
    TriggerSample: {}
```

xpctarget.xpcsc.set (scope object)

```
    Signals: {}  
    NumPrePostSamples: {}  
    Mode: {5x1 cell}  
    YLimit: {}  
    Grid: {}
```

The property value for the scope object sc1 is changed to on:

```
sc1.set('grid', 'on') or set(sc1, 'grid', 'on')
```

See Also

```
get | set | xpctarget.xpcsc.get (scope object) |  
xpctarget.xpc.set (target application object) |  
xpctarget.xpc.get (target application object)
```

xpctarget.xpcsc.start (scope object)

Purpose Start execution of scope on target computer (not recommended)

Syntax MATLAB command line

```
start(scope_object_vector)
scope_object_vector.start
+scope_object_vector
start(getscope((target_object, signal_index_vector))
```

Target computer command line

```
startscope scope_index
startscope 'all'
```

Arguments

target_object	Name of a target object.
scope_object_vector	Name of a single scope object, name of vector of scope objects, list of scope object names in vector form [scope_object1, scope_object2], or the target object method getscope, which returns a scope_object vector.
signal_index_vector	Index for a single scope or list of scope indices in vector form.
scope_index	Single scope index.

Description

Method for a scope object. Starts a scope on the target computer represented by a scope object on the host computer. This method might not start data acquisition, which depends on the trigger settings. Before using this method, you must create a scope. To create a scope, use the target object method addscope or add Simulink Real-Time scope blocks to your Simulink model.

xpctarget.xpcsc.start (scope object)

Note Method `xpctarget.xpcsc.start (scope object)` will be removed in a future release. Use methods `SimulinkRealTime.targetScope.start`, `SimulinkRealTime.hostScope.start`, and `SimulinkRealTime.fileScope.start` instead.

Examples

Start one scope with the scope object `sc1`.

```
sc1 = getscope(tg,1) or sc1 = tg.getscope(1)
start(sc1) or sc1.start or +sc1
```

or type

```
start(getscope(tg,1))
```

Start two scopes.

```
somescopes = getscope(tg,[1,2]) or somescopes=
tg.getscope([1,2])
start(somescopes) or somescopes.start
```

or type

```
sc1 = getscope(tg,1) or sc1 =tg.getscope(1)
sc2 = getscope(tg,2) or sc2 = tg.getscope(2)
start([sc1,sc2])
```

or type

```
start(getscope(tg,[1,2]))
```

Start all scopes:

```
allscopes = getscope(tg) or allscopes = tg.getscope
start(allscopes) or allscopes.start or +allscopes
```

or type

xpctarget.xpcsc.start (scope object)

`start(getscope(tg))` or `start(tg.getscope)`

See Also

`xpctarget.xpc.getscope` | `xpctarget.xpc.stop` (target application object) | `xpctarget.xpcsc.stop` (scope object)

xpctarget.xpcsc.stop (scope object)

Purpose Stop execution of scope on target computer (not recommended)

Syntax MATLAB command line

```
stop(scope_object_vector)
scope_object.stop
-scope_object
stop(getscope(target_object, signal_index_vector))
```

Target computer command line

```
stopscope scope_index
stopscope 'all'
```

Arguments

target_object	Name of a target object.
scope_object_vector	Name of a single scope object, name of vector of scope objects, list of scope object names in a vector form [scope_object1, scope_object2], or the target object method getscope, which returns a scope_object vector.
signal_index_vector	Index for a single scope or list of scope indices in vector form.
scope_index	Single scope index.

Description Method for scope objects. Stops the scopes represented by the scope objects.

Note Method `xpctarget.xpcsc.stop (scope object)` will be removed in a future release. Use methods `SimulinkRealTime.targetScope.stop`, `SimulinkRealTime.hostScope.stop`, and `SimulinkRealTime.fileScope.stop` instead.

Examples

Stop one scope represented by the scope object `sc1`.

```
stop(sc1) or sc1.stop or -sc1
```

Stop all scopes with a scope object vector `allscopes` created with the command

```
allscopes = getscope(tg) or allscopes = tg.getscope.  
stop(allscopes) or allscopes.stop or -allscopes
```

or type

```
stop(getscope(tg)) or stop(tg.getscope)
```

See Also

```
xpctarget.xpc.getscope | xpctarget.xpc.stop (target  
application object) | xpctarget.xpc.start (target application  
object) | xpctarget.xpcsc.start (scope object)
```

xpctarget.xpcsc.trigger

Purpose Software-trigger start of data acquisition for scopes (not recommended)

Syntax `trigger(scope_object_vector)` or `scope_object_vector.trigger`

Arguments

<code>scope_object_vector</code>	Name of a single scope object, name of a vector of scope objects, list of scope object names in a vector form [<code>scope_object1</code> , <code>scope_object2</code>], or the target object method <code>getscope</code> , which returns a <code>scope_object</code> vector.
----------------------------------	--

Description Method for a scope object. If the scope object property `TriggerMode` has a value of 'software', this function triggers the scope represented by the scope object to acquire the number of data points in the scope object property `NumSamples`.

Note Method `xpctarget.xpcsc.trigger` will be removed in a future release. Use methods `SimulinkRealTime.targetScope.trigger`, `SimulinkRealTime.hostScope.trigger`, and `SimulinkRealTime.fileScope.trigger` instead.

Note that only scopes with type `host` store data in the properties `scope_object.Time` and `scope_object.Data`.

Examples Set a single scope to software trigger, trigger the acquisition of one set of samples, and plot data.

```
sc1 = tg.addscope('host',1) or sc1=addscope(tg,'host',1)
sc1.triggermode = 'software'
tg.start, or start(tg), or +tg
sc1.start or start(sc1) or +sc1
sc1.trigger or trigger(sc1)
plot(sc1.time, sc1.data)
```



```
sc1.stop or stop(sc1) or -sc1  
tg.stop or stop(tg) or -tg1
```

Set all scopes to software trigger and trigger to start.

```
allscopes = tg.getscopes  
allscopes.triggermode = 'software'  
allscopes.start or start(allscopes) or +allscopes  
allscopes.trigger or trigger(allscopes)
```

xpctarget.xpcschoost Class

Purpose Control and access properties of host scopes (not recommended)

Description The scope gets a data package from the kernel, waits for an upload command from the host computer, and uploads the data to the host. The host computer displays the data using a scope viewer or other MATLAB functions.

Note Class `xpctarget.xpcschoost` will be removed in a future release. Use class `SimulinkRealTime.hostScope` instead.

Methods

These methods are inherited from `xpctarget.xpcsc` Class.

Method	Description
<code>xpctarget.xpcsc.addsignals</code>	Add signals to scope represented by scope object
<code>xpctarget.xpcsc.get</code> (scope object)	Return property values for scope objects
<code>xpctarget.xpcsc.removesignals</code>	Remove signals from scope represented by scope object
<code>xpctarget.xpcsc.set</code> (scope object)	Change property values for scope objects
<code>xpctarget.xpcsc.start</code> (scope object)	Start execution of scope on target computer
<code>xpctarget.xpcsc.stop</code> (scope object)	Stop execution of scope on target computer
<code>xpctarget.xpcsc.trigger</code>	Software trigger start of data acquisition for scope(s)

Properties

These properties are inherited from `xpctarget.xpcsc` Class.

Property	Description	Writable
Application	Name of the Simulink model associated with this scope object.	No
Decimation	A number n, where every nth sample is acquired in a scope window.	Yes
NumPrePostSamples	Number of samples collected before or after a trigger event. The default value is 0. Entering a negative value collects samples before the trigger event. Entering a positive value collects samples after the trigger event. If you set TriggerMode to 'FreeRun', this property has no effect on data acquisition.	Yes
NumSamples	<p>Number of contiguous samples captured during the acquisition of a data package. If the scope stops before capturing this number of samples, the scope has the collected data up to the end of data collection, then has zeroes for the remaining uncollected data. Note that you should know what type of data you are collecting, it is possible that your data contains zeroes.</p> <p>For file scopes, this parameter works in conjunction with the AutoRestart check box. If the AutoRestart box is selected, the file scope collects data up to Number of Samples, then starts over again, overwriting the buffer. If the AutoRestart box is not selected, the file scope collects data only up to Number of Samples, then stops.</p>	Yes
ScopeId	A numeric index, unique for each scope.	No
Signals	List of signal indices from the target object to display on the scope.	Yes

xpctarget.xpcschoost Class

Property	Description	Writable
Status	Indicate whether data is being acquired, the scope is waiting for a trigger, the scope has been stopped (interrupted), or acquisition is finished. Values are 'Acquiring', 'Ready for being Triggered', 'Interrupted', and 'Finished'.	No
TriggerLevel	If TriggerMode is 'Signal', indicates the value the signal has to cross to trigger the scope and start acquiring data. The trigger level can be crossed with either a rising or falling signal.	Yes
TriggerMode	Trigger mode for a scope. Valid values are 'FreeRun' (default), 'Software', 'Signal', and 'Scope'.	Yes
TriggerSample	<p>If TriggerMode is 'Scope', then TriggerSample specifies which sample of the triggering scope the current scope should trigger on. For example, if TriggerSample is 0 (default), the current scope triggers on sample 0 (first sample acquired) of the triggering scope. This means that the two scopes will be perfectly synchronized. If TriggerSample is 1, the first sample (sample 0) of the current scope will be at the same instant as sample number 1 (second sample in the acquisition cycle) of the triggering scope.</p> <p>As a special case, setting TriggerSample to -1 means that the current scope is triggered at the end of the acquisition cycle of the triggering scope. Thus, the first sample of the triggering scope is acquired one sample after the last sample of the triggering scope.</p>	Yes

xpctarget.xpcschoost Class

Property	Description	Writable
TriggerScope	If TriggerMode is 'Scope', identifies the scope to use for a trigger. A scope can be set to trigger when another scope is triggered. You do this by setting the slave scope property TriggerScope to the scope index of the master scope.	Yes
TriggerSignal	If TriggerMode is 'Signal', identifies the block output signal to use for triggering the scope. You identify the signal with a signal index from the target object property Signal.	Yes
TriggerSlope	If TriggerMode is 'Signal', indicates whether the trigger is on a rising or falling signal. Values are 'Either' (default), 'Rising', and 'Falling'.	Yes
Type	Determines whether the scope is displayed on the host computer or on the target computer. Values are 'Host', 'Target', and 'File'. Property Type is set only once, when the scope is created on the target computer.	No

These properties are specific to class xpctarget.xpcschoost.

Property	Description	Writeable
Data	Contains the output data for a single data package from a scope. For target or file scopes, this parameter has no effect.	No
Time	Contains the time data for a single data package from a scope. For target or file scopes, this parameter has no effect.	No

xpctarget.xpcsctg Class

Purpose Control and access properties of target scopes (not recommended)

Description The kernel acquires a data package and the scope displays the data on the target computer screen. Depending on the setting of `DisplayMode`, the data may be displayed numerically or graphically by a redrawing, sliding, and rolling display.

Note Class `xpctarget.xpcsctg` will be removed in a future release. Use class `SimulinkRealTime.targetScope` instead.

Methods

These methods are inherited from `xpctarget.xpcsc` Class.

Method	Description
<code>xpctarget.xpcsc.addsignals</code>	Add signals to scope represented by scope object
<code>xpctarget.xpcsc.get</code> (scope object)	Return property values for scope objects
<code>xpctarget.xpcsc.removesignals</code>	Remove signals from scope represented by scope object
<code>xpctarget.xpcsc.set</code> (scope object)	Change property values for scope objects
<code>xpctarget.xpcsc.start</code> (scope object)	Start execution of scope on target computer
<code>xpctarget.xpcsc.stop</code> (scope object)	Stop execution of scope on target computer
<code>xpctarget.xpcsc.trigger</code>	Software trigger start of data acquisition for scope(s)

Properties

These properties are inherited from `xpctarget.xpcsc` Class.

Property	Description	Writable
Application	Name of the Simulink model associated with this scope object.	No
Decimation	A number n, where every nth sample is acquired in a scope window.	Yes
NumPrePostSamples	Number of samples collected before or after a trigger event. The default value is 0. Entering a negative value collects samples before the trigger event. Entering a positive value collects samples after the trigger event. If you set TriggerMode to 'FreeRun', this property has no effect on data acquisition.	Yes
NumSamples	<p>Number of contiguous samples captured during the acquisition of a data package. If the scope stops before capturing this number of samples, the scope has the collected data up to the end of data collection, then has zeroes for the remaining uncollected data. Note that you should know what type of data you are collecting, it is possible that your data contains zeroes.</p> <p>For file scopes, this parameter works in conjunction with the AutoRestart check box. If the AutoRestart box is selected, the file scope collects data up to Number of Samples, then starts over again, overwriting the buffer. If the AutoRestart box is not selected, the file scope collects data only up to Number of Samples, then stops.</p>	Yes
ScopeId	A numeric index, unique for each scope.	No
Signals	List of signal indices from the target object to display on the scope.	Yes

xpctarget.xpcsctg Class

Property	Description	Writable
Status	Indicate whether data is being acquired, the scope is waiting for a trigger, the scope has been stopped (interrupted), or acquisition is finished. Values are 'Acquiring', 'Ready for being Triggered', 'Interrupted', and 'Finished'.	No
TriggerLevel	If TriggerMode is 'Signal', indicates the value the signal has to cross to trigger the scope and start acquiring data. The trigger level can be crossed with either a rising or falling signal.	Yes
TriggerMode	Trigger mode for a scope. Valid values are 'FreeRun' (default), 'Software', 'Signal', and 'Scope'.	Yes
TriggerSample	<p>If TriggerMode is 'Scope', then TriggerSample specifies which sample of the triggering scope the current scope should trigger on. For example, if TriggerSample is 0 (default), the current scope triggers on sample 0 (first sample acquired) of the triggering scope. This means that the two scopes will be perfectly synchronized. If TriggerSample is 1, the first sample (sample 0) of the current scope will be at the same instant as sample number 1 (second sample in the acquisition cycle) of the triggering scope.</p> <p>As a special case, setting TriggerSample to -1 means that the current scope is triggered at the end of the acquisition cycle of the triggering scope. Thus, the first sample of the triggering scope is acquired one sample after the last sample of the triggering scope.</p>	Yes

xpctarget.xpcsctg Class

Property	Description	Writable
TriggerScope	If TriggerMode is 'Scope', identifies the scope to use for a trigger. A scope can be set to trigger when another scope is triggered. You do this by setting the slave scope property TriggerScope to the scope index of the master scope.	Yes
TriggerSignal	If TriggerMode is 'Signal', identifies the block output signal to use for triggering the scope. You identify the signal with a signal index from the target object property Signal.	Yes
TriggerSlope	If TriggerMode is 'Signal', indicates whether the trigger is on a rising or falling signal. Values are 'Either' (default), 'Rising', and 'Falling'.	Yes
Type	Determines whether the scope is displayed on the host computer or on the target computer. Values are 'Host', 'Target', and 'File'. Property Type is set only once, when the scope is created on the target computer.	No

These properties are specific to class xpcsctg.

Property	Description	Writable
DisplayMode	For target scopes, indicate how a scope displays the signals. Values are 'Numerical', 'Redraw' (default), 'Sliding', and 'Rolling'. For host or file scopes, this parameter has no effect.	Yes

xpctarget.xpcsctg Class

Property	Description	Writeable
	.	
Grid	Values are 'on' and 'off'. For host or file scopes, this parameter has no effect.	Yes
Mode	<hr/> Note The Mode property will be removed in a future release. <ul style="list-style-type: none">• For target scopes, use DisplayMode.• For file scopes, use WriteMode.• For host scopes, this parameter has no effect. <hr/>	Yes
YLimit	Minimum and maximum y-axis values. This property can be set to 'auto'. For host or file scopes, this parameter has no effect.	Yes

Purpose Tests communication between host and target computers (not recommended)

Syntax xpctargetping

xpctargetping target_computer_name
xpctargetping TcpIp TargetAddress TargetPort
xpctargetping RS232 HostPort Baudrate

Description Returns success if the Simulink Real-Time kernel is loaded and running, and communication is working between the host and target computers. Otherwise, returns failed.

Note Command xpctargetping will be removed in a future release. Use command slrtpingtarget or method SimulinkRealTime.target.ping instead.

xpctargetping without an argument returns success if the host computer and the default target computer can communicate using the settings for that computer. Otherwise, returns failed.

xpctargetping target_computer_name returns success if the host computer can communicate with target computer target_computer_name using the settings for that computer. Otherwise, returns failed.

Input Arguments

target_computer_name - Name of specific target computer

TargetPC1 | TargetPC2 | ...

Name property of a particular target computer environment object. The default name is TargetPC1.

When using function form, enclose the argument (target_computer_name,) in single quotes ('TargetPC1').

xpctargetping

Example: TargetPC1

Data Types

char

Examples

Check communication with default target computer

```
xpctargetping
```

Check communication with specified target computer

```
xpctargetping TargetPC1
```

Purpose Open Simulink Real-Time display window on host computer (not recommended)

Syntax

```
xpctargetspy
xpctargetspy(target_object)
xpctargetspy('target_object_name')
```

Arguments

<code>target_object</code>	Variable name to reference the target object.
<code>target_object_name</code>	Target object name as specified in the Simulink Real-Time Explorer.

Description This graphical user interface (GUI) allows you to upload displayed data from the target computer. By default, `xpctargetspy` opens a Real-Time Simulink Real-Time display window for the target object, `tg`. If you have multiple target computers in your system, you can call the `xpctargetspy` function for a particular target object, `target_object`.

Note Command `xpctargetspy` will be removed in a future release. Use command method `SimulinkRealTime.target.viewTargetScreen` instead.

If you have one target computer, or if you designate a target computer as the default one in your system, use the syntax

```
xpctargetspy
```

If you have specified a target computer object in the Simulink Real-Time Explorer, you can use the following syntax.

```
target_object=xpctarget.xpc('target_object_name')
```

Then, use the following syntax.

```
xpctargetspy(target_object)
```

The behavior of xpctargetspy depends on the value for the environment property TargetScope:

- If TargetScope is enabled, a single graphics screen is uploaded. The screen is not continually updated because of a higher data volume when a target graphics card is in VGA mode. You must explicitly request an update. To manually update the host screen with another target screen, move the pointer into the Real-Time Simulink Real-Time display window and right-click to select **Update Simulink Real-Time Target Screen**.
- If TargetScope is disabled, text output is transferred once every second to the host and displayed in the window.

Examples

To open the Real-Time Simulink Real-Time display window for the default target computer, tg, in the MATLAB window, type

```
xpctargetspy
```

To open the Real-Time Simulink Real-Time display window for target computer 'TargetPC1' in the MATLAB window, type

```
tg1=xpctarget.xpc('TargetPC1');  
xpctargetspy(tg1)
```

Purpose	Test Simulink Real-Time installation (not recommended)				
Syntax	<pre>xpctest xpctest('noreboot') xpctest('-noreboot') xpctest('target_name') xpctest('target_name','noreboot') xpctest('target_name','-noreboot')</pre>				
Arguments	<table><tr><td>'target_name'</td><td>Name of target computer to test.</td></tr><tr><td>'noreboot'</td><td>Only one possible option. Skips the reboot test. Use this option if the target hardware does not support software rebooting. Value is 'noreboot' or '-noreboot'.</td></tr></table>	'target_name'	Name of target computer to test.	'noreboot'	Only one possible option. Skips the reboot test. Use this option if the target hardware does not support software rebooting. Value is 'noreboot' or '-noreboot'.
'target_name'	Name of target computer to test.				
'noreboot'	Only one possible option. Skips the reboot test. Use this option if the target hardware does not support software rebooting. Value is 'noreboot' or '-noreboot'.				
Description	xpctest is a series of tests to check the basic functioning of Simulink Real-Time.				

Note Command `xpctest` will be removed in a future release. Use command `slrttest` instead.

`xpctest` tests the following functionality:

- Initiate communication between the host and target computers.
- Reboot the target computer to reset the target environment.
- Build a target application on the host computer.
- Download a target application to the target computer.
- Check communication between the host and target computers using commands.
- Execute a target application.

- Compare the results of a simulation and the target application run.

`xpctest('noreboot')` or `xpctest('-noreboot')` skips the reboot test on the default target computer. Use this option if target hardware does not support software rebooting.

`xpctest('target_name')` runs the tests on the target computer identified by 'target_name'.

`xpctest('target_name','noreboot')` or `xpctest('target_name','-noreboot')` runs the tests on the target computer identified by 'target_name', but skips the reboot test.

Examples

If the target hardware does not support software rebooting, or to skip the reboot test, in the MATLAB window, type

```
xpctest('-noreboot')
```

To run `xpctest` on a specified target computer, for example TargetPC1, type

```
xpctest('TargetPC1')
```

How To

- “Run Confidence Test on Configuration”
- “Test 1: Ping Using System Ping”

Purpose Disconnect target computer from current client application (not recommended)

Syntax `xpcwwenable`
`xpcwwenable('target_obj_name')`

Description `xpcwwenable` disconnects the target application from the MATLAB interface so you can connect to the Web browser.

Note Command `xpcwwenable` will be removed in a future release. Use method `SimulinkRealTime.target.close` instead.

You can also use this function to connect to the MATLAB interface after using a Web browser, or to switch to another Web browser.

`xpcwwenable('target_obj_name')` disconnects the target application on `target_obj_name` (for example 'TargetPC1') from the MATLAB interface.

Simulink Real-Time API Reference for C

- “C API Error Messages” on page 2-2
- “C API Structures and Functions — Alphabetical List” on page 2-6

C API Error Messages

The header file `matlabroot\toolbox\rtw\targets\xpc\api\xpcapiconst.h` defines these error messages.

Message	Description
ECOMPORTACCFAIL	COM port access failed
ECOMPORTISOPEN	COM port is already opened
ECOMPORTREAD	ReadFile failed while reading from COM port
ECOMPORTWRITE	WriteFile failed while writing to COM port
ECOMTIMEOUT	timeout while receiving: check serial link
EFILEOPEN	Error opening file
EFILEREAD	Error reading file
EFILERENAME	Error renaming file
EFILEWRITE	Error writing file
EINTERNAL	Internal Error
EINVADDR	Invalid IP Address
EINVARGUMENT	Invalid Argument
EINVALIDMODEL	Model name does not match saved value
EINVBAUDRATE	Invalid value for baudrate
EINVCOMMTYP	Invalid communication type
EINVCOMPORT	COM port can only be 0 or 1 (COM1 or COM2)
EINVDECIMATION	Decimation must be positive
EINVFILENAME	Invalid file name
EINVINSTANDALONE	Command not valid for StandAlone
EINVLGDATA	Invalid lgdata structure
EINVLGINCR	Invalid increment for value equidistant logging
EINVLGMODE	Invalid Logging mode
EINVLOGID	Invalid log identifier

Message	Description
EINVNUMPARAMS	Invalid number of parameters
EINVNUMSIGNALS	Invalid number of signals
EINVPARIDX	Invalid parameter index
EINVPORT	Invalid Port Number
EINVSCIDX	Invalid Scope Index
EINVSTYPE	Invalid Scope type
EINVSIGIDX	Invalid Signal index
EINVTRIGMODE	Invalid trigger mode
EINVTRIGSLOPE	Invalid Trigger Slope Value
EINVTRSCIDX	Invalid Trigger Scope index
EINVNUMSAMP	Number of samples must be nonnegative
EINVSTARTVAL	Invalid value for "start"
EINVTFIN	Invalid value for TFinal
EINVTS	Invalid value for Ts (must be between 8e-6 and 10)
EINVWSVER	Invalid Winsock version (1.1 needed)
EINVXPCVERSION	Target has an invalid version of Simulink Real-Time
ELOADAPPFIRST	Load the application first
ELOGGINGDISABLED	Logging is disabled
EMALFORMED	Malformed message
EMEMALLOC	Memory allocation error
ENODATALOGGED	No data has been logged
ENOERR	No error
ENOFREEPORT	No free Port in C API
ENOMORECHANNELS	No more channels in scope
ENOSPACE	Space not allocated
EOUTPUTLOGDISABLED	Output Logging is disabled

Message	Description
EPARNOTFOUND	Parameter not found
EPARSIZEMISMATCH	Parameter Size mismatch
EPINGCONNECT	Could not connect to Ping socket
EPINGPORTOPEN	Error opening Ping port
EPINGSOCKET	Ping socket error
EPORTCLOSED	Port is not open
ERUNSIMFIRST	Run simulation first
ESCFINVALIDFNAME	Invalid filename tag used for dynamic file name
ESCFISNOTAUTO	Autorestart must be enabled for dynamic file names
ESCFNUMISNOTMULT	MaxWriteFileSize must be a multiple of the writesize
ESCTYPENOTTGT	Scope Type is not "Target"
ESIGLABELNOTFOUND	Signal label not found
ESIGLABELNOTUNIQUE	Ambiguous signal label (signal labels are not unique)
ESIGNOTFOUND	Signal not found
ESOCKOPEN	Socket Open Error
ESTARTSIMFIRST	Start simulation first
ESTATELOGDISABLED	State Logging is disabled
ESTOPSCFIRST	Stop scope first
ESTOPSIMFIRST	Stop simulation first
ETCPCONNECT	TCP/IP Connect Error
ETCPREAD	TCP/IP Read Error
ETCPTIMEOUT	TCP/IP timeout while receiving data
ETCPWRITE	TCP/IP Write error
ETETLOGDISABLED	TET Logging is disabled

Message	Description
ETGTMEMALLOC	Target memory allocation failed
ETIMELOGDISABLED	Time Logging is disabled
ETOOMANYSAMPLES	Too Many Samples requested
ETOOMANYSCOPES	Too many scopes are present
ETOOMANYSIGNALS	Too many signals in Scope
EUNLOADAPPFIRST	Unload the application first
EUSEDYNSCOPE	Use DYNAMIC_SCOPE flag at compile time
EWRITEFILE	LoadDLM: WriteFile Error
EWSINIT	WINSOCK: Initialization Error
EWSNOTREADY	Winsock not ready

C API Structures and Functions – Alphabetical List

Purpose Type definition for file system folder information structure

Syntax

```
typedef struct {
    char      Name[8];
    char      Ext[3];
    char      Day;
    int  Month;
    int  Year;
    int  Hour;
    int  Min;
    int  isDir;
    unsigned long  Size;
} dirStruct;
```

Fields

<i>Name</i>	This value contains the name of the file or folder.
<i>Ext</i>	This value contains the file type of the element, if the element is a file (<i>isDir</i> is 0). If the element is a folder (<i>isDir</i> is 1), this field is empty.
<i>Day</i>	This value contains the day the file or folder was last modified.
<i>Month</i>	This value contains the month the file or folder was last modified.
<i>Year</i>	This value contains the year the file or folder was last modified.
<i>Hour</i>	This value contains the hour the file or folder was last modified.
<i>Min</i>	This value contains the minute the file or folder was last modified.

dirStruct

<i>isDir</i>	This value indicates if the element is a file (0) or folder (1). If it is a folder, Bytes has a value of 0.
<i>Size</i>	This value contains the size of the file in bytes. If the element is a folder, this value is 0.

Description The `dirStruct` structure contains information for a folder in the file system.

See Also API function `xPCFSDirItems`

Purpose

Type definition for file system disk information structure

Syntax

```
typedef struct {
    char        Label[12];
    char        DriveLetter;
    char        Reserved[3];
    unsigned int SerialNumber;
    unsigned int FirstPhysicalSector;
    unsigned int FATType;
    unsigned int FATCount;
    unsigned int MaxDirEntries;
    unsigned int BytesPerSector;
    unsigned int SectorsPerCluster;
    unsigned int TotalClusters;
    unsigned int BadClusters;
    unsigned int FreeClusters;
    unsigned int Files;
    unsigned int FileChains;
    unsigned int FreeChains;
    unsigned int LargestFreeChain;
} diskinfo;
```

Fields

<i>Label</i>	This value contains the zero-terminated string that contains the volume label. The string is empty if the volume has no label.
<i>DriveLetter</i>	This value contains the drive letter, in uppercase.
<i>Reserved</i>	Reserved.
<i>SerialNumber</i>	This value contains the volume serial number.
<i>FirstPhysicalSector</i>	This value contains the logical block addressing (LBA) address of the logical drive boot record. For 3.5-inch disks, this value is 0.

<i>FATType</i>	This value contains the type of file system found. It can contain 12 , 16 , or 32 for FAT-12, FAT-16, or FAT-32 volumes, respectively.
<i>FATCount</i>	This value contains the number of FAT partitions on the volume.
<i>MaxDirEntries</i>	This value contains the size of the root folder. For FAT-32 systems, this value is 0.
<i>BytesPerSector</i>	This value contains the sector size. This value is most likely to be 512.
<i>SectorsPerCluster</i>	This value contains, in sectors, the size of the smallest unit of storage that can be allocated to a file.
<i>TotalClusters</i>	This value contains the number of file storage clusters on the volume.
<i>BadClusters</i>	This value contains the number of clusters that have been marked as bad. These clusters are unavailable for file storage.
<i>FreeClusters</i>	This value contains the number of clusters that are currently available for storage.
<i>Files</i>	This value contains the number of files, including folders, on the volume. This number excludes the root folder and files that have an allocated file size of 0.
<i>FileChains</i>	This value contains the number of contiguous cluster chains. On a completely unfragmented volume, this value is identical to the value of <i>Files</i> .

<i>FreeChains</i>	This value contains the number of contiguous cluster chains of free clusters. On a completely unfragmented volume, this value is 1.
<i>LargestFreeChain</i>	This value contains the maximum allocated file size, in number of clusters, for a newly allocated contiguous file. On a completely unfragmented volume, this value is identical to <i>FreeClusters</i> .

Description The `diskinfo` structure contains information for file system disks.

See Also API function `xPCFSDiskInfo`

fileinfo

Purpose Type definition for file information structure

Syntax

```
typedef struct {  
    int         FilePos;  
    int         AllocatedSize;  
    int         ClusterChains;  
    int         VolumeSerialNumber;  
    char        FullName[255];  
}fileinfo;
```

Fields

<i>FilePos</i>	This value contains the current file pointer.
<i>AllocatedSize</i>	This value contains the currently allocated file size.
<i>ClusterChains</i>	This value indicates how many separate cluster chains are allocated for the file.
<i>VolumeSerialNumber</i>	This value holds the serial number of the volume the file resides on.
<i>FullName</i>	This value contains a copy of the complete path name of the file. This field is valid only while the file is open.

Description The fileinfo structure contains information for files in the file system.

See Also xPCFSFileInfo

Purpose	Type definition for logging options structure				
Syntax	<pre>typedef struct { int <i>mode</i>; double <i>incrementvalue</i>; } lgmode;</pre>				
Fields	<table><tr><td><i>mode</i></td><td>This value indicates the type of logging you want. Specify LGMOD_TIME for time-equidistant logging. Specify LGMOD_VALUE for value-equidistant logging.</td></tr><tr><td><i>incrementvalue</i></td><td>If you set <i>mode</i> to LGMOD_VALUE for value-equidistant data, this option specifies the increment (difference in amplitude) value between logged data points. A data point is logged only when an output signal or a state changes by <i>incrementvalue</i>. If you set <i>mode</i> to LGMOD_TIME, <i>incrementvalue</i> is ignored.</td></tr></table>	<i>mode</i>	This value indicates the type of logging you want. Specify LGMOD_TIME for time-equidistant logging. Specify LGMOD_VALUE for value-equidistant logging.	<i>incrementvalue</i>	If you set <i>mode</i> to LGMOD_VALUE for value-equidistant data, this option specifies the increment (difference in amplitude) value between logged data points. A data point is logged only when an output signal or a state changes by <i>incrementvalue</i> . If you set <i>mode</i> to LGMOD_TIME, <i>incrementvalue</i> is ignored.
<i>mode</i>	This value indicates the type of logging you want. Specify LGMOD_TIME for time-equidistant logging. Specify LGMOD_VALUE for value-equidistant logging.				
<i>incrementvalue</i>	If you set <i>mode</i> to LGMOD_VALUE for value-equidistant data, this option specifies the increment (difference in amplitude) value between logged data points. A data point is logged only when an output signal or a state changes by <i>incrementvalue</i> . If you set <i>mode</i> to LGMOD_TIME, <i>incrementvalue</i> is ignored.				
Description	The lgmode structure specifies data logging options. The <i>mode</i> variable accepts either the numeric values 0 or 1 or their equivalent constants LGMOD_TIME or LGMOD_VALUE from xpcapiconst.h.				
See Also	API functions xPCSetLogMode, xPCGetLogMode				

scopedata

Purpose Type definition for scope data structure

Syntax

```
typedef struct {
    int    number;
    int    type;
    int    state;
    int    signals[10];
    int    numsamples;
    int    decimation;
    int    triggermode;
    int    numprepostsamples;
    int    triggersignal
    int    triggerscope;
    int    triggerscopesample;
    double triggerlevel;
    int    triggerslope;
} scopedata;
```

Fields

<i>number</i>	The scope number.
<i>type</i>	Determines whether the scope is displayed on the host computer or on the target computer. Values are one of the following: 1 Host 2 Target
<i>state</i>	Indicates the scope state. Values are one of the following: 0 Waiting to start 1 Scope is waiting for a trigger 2 Data is being acquired 3 Acquisition is finished 4 Scope is stopped (interrupted)

	5	Scope is preacquiring data
<i>signals</i>		List of signal indices from the target object to display on the scope.
<i>numsamples</i>		Number of contiguous samples captured during the acquisition of a data package.
<i>decimation</i>		A number, N, meaning every Nth sample is acquired in a scope window.
<i>triggermode</i>		Trigger mode for a scope. Values are one of the following:
	0	FreeRun (default)
	1	Software
	2	Signal
	3	Scope
<i>numprepostsamples</i>		If this value is less than 0, this is the number of samples to be saved before a trigger event. If this value is greater than 0, this is the number of samples to skip after the trigger event before data acquisition begins.
<i>triggersignal</i>		If <i>triggermode</i> is 2 (Signal), identifies the block output signal to use for triggering the scope. Identify the signal with a signal index.
<i>triggerscope</i>		If <i>triggermode</i> is 3 (Scope), identifies the scope to use for a trigger. A scope can be set to trigger when another scope is triggered.
<i>triggerscopesample</i>		If <i>triggermode</i> is 3 (Scope), specifies the number of samples to be acquired by the triggering scope before triggering a second scope. This must be a nonnegative value.

<i>triggerlevel</i>	If <i>triggermode</i> is 2 (Signal), indicates the value the signal has to cross to trigger the scope to start acquiring data. The trigger level can be crossed with either a rising or falling signal.
<i>triggerslope</i>	If <i>triggermode</i> is 2 (Signal), indicates whether the trigger is on a rising or falling signal. Values are: 0 Either rising or falling (default) 1 Rising 2 Falling

Description

The `scopedata` structure holds the data about a scope used in the functions `xPCGetScope` and `xPCSetScope`. In the structure, the fields are as in the various `xPCGetSc*` functions (for example, *state* is as in `xPCScGetState`, *signals* is as in `xPCScGetSignals`, etc.). The signal vector is an array of the signal identifiers, terminated by -1.

See Also

API functions `xPCSetScope`, `xPCGetScope`, `xPCScGetType`, `xPCScGetState`, `xPCScGetSignals`, `xPCScGetNumSamples`, `xPCScGetDecimation`, `xPCScGetTriggerMode`, `xPCScGetNumPrePostSamples`, `xPCScGetTriggerSignal`, `xPCScGetTriggerScope`, `xPCScGetTriggerLevel`, `xPCScGetTriggerSlope`

Purpose Create new scope

Prototype `void xPCAddScope(int port, int scType, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scType</i>	Enter the type of scope.
<i>scNum</i>	Enter a number for a new scope. Values are 1, 2, 3. . .

Description The `xPCAddScope` function creates a new scope on the target computer. For *scType*, scopes can be of type `host` or `target`, depending on the value of *scType*:

- `SCTYPE_HOST` for type `host`
- `SCTYPE_TARGET` for type `target`
- `SCTYPE_FILE` for type `file`

Constants for *scType* are defined in the header file `xpcapiconst.h` as `SCTYPE_HOST`, `SCTYPE_TARGET`, and `SCTYPE_FILE`.

Calling the `xPCAddScope` function with *scNum* having the number of an existing scope produces an error. Use `xPCGetScopes` to find the numbers of existing scopes.

See Also API functions `xPCScAddSignal`, `xPCScRemSignal`, `xPCRemScope`, `xPCSetScope`, `xPCGetScope`, `xPCGetScopes`

Target object method `SimulinkRealTime.target.addscope`

xPCAverageTET

Purpose	Return average task execution time
Prototype	<code>double xPCAverageTET(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCAverageTET</code> function returns the average task execution time (TET) for the target application.
Description	The <code>xPCAverageTET</code> function returns the TET for the target application. You can use this function when the target application is running or when it is stopped.
See Also	API functions <code>xPCMaximumTET</code> , <code>xPCMinimumTET</code> Property <code>AvgTET</code> of <code>SimulinkRealTime.target</code>

Purpose Close RS-232 or TCP/IP communication connection

Prototype `void xPCCloseConnection(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Description The `xPCCloseConnection` function closes the RS-232 or TCP/IP communication channel opened by `xPCOpenSerialPort`, `xPCOpenTcpIpPort`, or `xPCOpenConnection`. Unlike `xPCClosePort`, it preserves the connection information such that a subsequent call to `xPCOpenConnection` succeeds without the need to resupply communication data such as the IP address or port number. To completely close the communication channel, call `xPCDeRegisterTarget`. Calling the `xPCCloseConnection` function followed by calling `xPCDeRegisterTarget` is equivalent to calling `xPCClosePort`.

Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.

See Also API functions `xPCOpenConnection`, `xPCOpenSerialPort`, `xPCOpenTcpIpPort`, `xPCReOpenPort`, `xPCRegisterTarget`, `xPCDeRegisterTarget`

xPCClosePort

Purpose Close RS-232 or TCP/IP communication connection

Prototype `void xPCClosePort(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Description The `xPCClosePort` function closes the RS-232 or TCP/IP communication channel opened by either `xPCOpenSerialPort` or by `xPCOpenTcpIpPort`. Calling this function is equivalent to calling `xPCCloseConnection` and `xPCDeRegisterTarget`.

Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.

See Also API functions `xPCOpenSerialPort`, `xPCOpenTcpIpPort`, `xPCReOpenPort`, `xPCOpenConnection`, `xPCCloseConnection`, `xPCRegisterTarget`, `xPCDeRegisterTarget`

Target object method `SimulinkRealTime.target.close`

Purpose Delete target communication properties from Simulink Real-Time API library

Prototype `void xPCDeRegisterTarget(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Description The `xPCDeRegisterTarget` function causes the Simulink Real-Time API library to completely “forget” about the target communication properties. You use this at the end of a session in which you use `xPCOpenConnection` and `xPCCloseConnection` to connect and disconnect from the target without entering the properties each time. It works similarly to `xPCClosePort`, but does not close the connection to the target computer. Before calling this function, you must first call the function `xPCCloseConnection` to close the connection to the target computer. The combination of calling the `xPCCloseConnection` and `xPCDeRegisterTarget` functions has the same result as calling `xPCClosePort`.

See Also API functions `xPCRegisterTarget`, `xPCOpenTcpIpPort`, `xPCOpenSerialPort`, `xPCClosePort`, `xPCReOpenPort`, `xPCOpenConnection`, `xPCCloseConnection`, `xPCTargetPing`

xPCErrorMsg

Purpose Return text description for error message

Prototype `char *xPCErrorMsg(int error_number, char *error_message);`

Arguments

error_number Enter the constant of an error.

error_message The xPCErrorMsg function copies the error message string into the buffer pointed to by *error_message*. *error_message* is then returned. You can later use *error_message* in a function such as printf.

If *error_message* is NULL, the xPCErrorMsg function returns a pointer to a statically allocated string.

Return The xPCErrorMsg function returns a string associated with the error *error_number*.

Description The xPCErrorMsg function returns *error_message*, which makes it convenient to use in a printf or similar statement. Use the xPCGetLastError function to get the constant for which you are getting the message.

See Also API functions xPCSetLastError, xPCGetLastError

Purpose Unload Simulink Real-Time DLL

Prototype `void xPCFreeAPI(void);`

Description The xPCFreeAPI function unloads the Simulink Real-Time dynamic link library. You must execute this function once at the end of the application to unload the Simulink Real-Time API DLL. This frees the memory allocated to the functions. This function is defined in the file `xpcinitfree.c`. Link this file with your application.

See Also API functions `xPCInitAPI`, `xPCNumLogWraps`, `xPCNumLogSamples`, `xPCMaxLogSamples`, `xPCGetStateLog`, `xPCGetTETLog`, `xPCSetLogMode`, `xPCGetLogMode`

xPCFSCD

Purpose Change current folder on target computer to specified path

Prototype `void xPCFSCD(int port, char *dir);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>dir</i>	Enter the path on the target computer to change to.

Description The `xPCFSCD` function changes the current folder on the target computer to the path specified in *dir*. Use the `xPCFSGetPWD` function to show the current folder of the target computer.

See Also API function `xPCFSGetPWD`
File object method `SimulinkRealTime.fileSystem.cd`

Purpose Close file on target computer

Prototype `void xPCFSCloseFile(int port, int fileHandle);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>fileHandle</i>	Enter the file handle of an open file on the target computer.

Description The `xPCFSCloseFile` function closes the file associated with *fileHandle* on the target computer. *fileHandle* is the handle of a file previously opened by the `xPCFSOpenFile` function.

See Also API functions `xPCFSOpenFile`, `xPCFSReadFile`, `xPCFSWriteFile`
File object method `SimulinkRealTime.fileSystem.fclose`

xPCFSDir

Purpose Get contents of specified folder on target computer

Prototype `void xPCFSDir(int port, const char *path, char *data, int numbytes);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>path</i>	Enter the path on the target computer.
<i>data</i>	The contents of the folder are stored in <i>data</i> , whose allocated size is specified in <i>numbytes</i> .
<i>numbytes</i>	Enter the size, in bytes, of the array <i>data</i> .

Description The `xPCFSDir` function copies the contents of the target computer folder specified by *path* into *data*. The `xPCFSDir` function returns the listing in the *data* array, which must be of size *numbytes*. Use the `xPCFSDirSize` function to obtain the size of the folder listing for the *numbytes* parameter.

See Also API function `xPCFSDirSize`
File object method `SimulinkRealTime.fileSystem.dir`

Purpose

Get contents of specified folder on target computer

Prototype

```
void xPCFSDirItems(int port, const char *path, dirStruct  
*dirs, int numDirItems);
```

Arguments

port Enter the value returned by either the function xPCOpenSerialPort or the function xPCOpenTcpIpPort.

path Enter the path on the target computer.

dirs Enter the structure to contain the contents of the folder.

numDirItems Enter the number of items in the folder.

Description

The xPCFSDirItems function copies the contents of the target computer folder specified by *path*. The xPCFSDirItems function copies the listing into the *dirs* structure, which must be of size *numDirItems*. Use the xPCFSDirStructSize function to obtain the size of the folder for the *numDirItems* parameter.

See Also

API functions xPCFSDirStructSize, dirStruct
File object method SimulinkRealTime.fileSystem.dir

xPCFSDirSize

Purpose Return size of specified folder listing on target computer

Prototype `int xPCFSDirSize(int port, const char *path);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>path</i>	Enter the folder path on the target computer.

Return The `xPCFSDirSize` function returns the size, in bytes, of the specified folder listing. If this function detects an error, it returns -1.

Description The `xPCFSDirSize` function returns the size, in bytes, of the buffer required to list the folder contents on the target computer. Use this size as the *numbytes* parameter in the `xPCFSDir` function.

See Also API function `xPCFSDirItems`
File object method `SimulinkRealTime.fileSystem.dir`

Purpose Get number of items in folder

Prototype `int xPCFSDirStructSize(int port, const char *path);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>path</i>	Enter the folder path on the target computer.

Return The `xPCFSDirStructSize` function returns the number of items in the folder on the target computer. If this function detects an error, it returns -1.

Description The `xPCFSDirStructSize` function returns the number of items in the folder on the target computer. Use this size as the *numDirItems* parameter in the `xPCFSDirItems` function.

See Also API function `xPCFSDir`
File object method `SimulinkRealTime.fileSystem.dir`

xPCFSDiskInfo

Purpose Information about target computer file system

Prototype `diskinfo xPCFSDiskInfo(int port, const char *driveletter);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>driveletter</i>	Enter the drive letter of the file system for which you want information.

Description The `xPCFSDiskInfo` function returns disk information for the file system of the specified target computer drive, *driveletter*. This function returns this information in the `diskinfo` structure.

See Also API structure `SimulinkRealTime.fileSystem.diskinfo`

Purpose	Return information for open file on target computer				
Prototype	<code>fileinfo xPCFSFileInfo(int <i>port</i>, int <i>fileHandle</i>);</code>				
Arguments	<table><tr><td><i>port</i></td><td>Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code>.</td></tr><tr><td><i>fileHandle</i></td><td>Enter the file handle of an open file on the target computer.</td></tr></table>	<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .	<i>fileHandle</i>	Enter the file handle of an open file on the target computer.
<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .				
<i>fileHandle</i>	Enter the file handle of an open file on the target computer.				
Description	The <code>xPCFSFileInfo</code> function returns information about the specified open file, <code>filehandle</code> , in a structure of type <code>fileinfo</code> .				
See Also	Structure <code>SimulinkRealTime.fileSystem.fileinfo</code>				

xPCFSError

Purpose Get text description for error number on target computer file system

Prototype `void xPCFSError(int port, unsigned int error_number, char *error_message);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>error_number</i>	Enter the constant of an error.
<i>error_message</i>	The string of the message associated with the error <i>error_number</i> is stored in <i>error_message</i> .

Description The `xPCFSError` function gets the *error_message* associated with *error_number*. This enables you to use the error message in a `printf` or similar statement.

Purpose Return size of file on target computer

Prototype `int xPCFSGetFileSize(int port, int fileHandle);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>fileHandle</i>	Enter the file handle of an open file on the target computer.

Return Return the size of the specified file in bytes. If this function detects an error, it returns -1.

Description The `xPCFSGetFileSize` function returns the size, in bytes, of the file associated with *fileHandle* on the target computer. *fileHandle* is the handle of a file previously opened by the `xPCFSOpenFile` function.

See Also API functions `xPCFSOpenFile`, `xPCFSReadFile`
File object methods `SimulinkRealTime.fileSystem.fopen` and `SimulinkRealTime.fileSystem.fread`

xPCFSGetPWD

Purpose Get current folder of target computer

Prototype `void xPCFSGetPWD(int port, char *pwd);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>pwd</i>	The path of the current folder is stored in <i>pwd</i> .

Description The `xPCFSGetPWD` function places the path of the current folder on the target computer in *pwd*, which must be allocated by the caller.

See Also File object method `SimulinkRealTime.fileSystem.pwd`

Purpose Create new folder on target computer

Prototype `void xPCFSMKDIR(int port, const char *dirname);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>dirname</i>	Enter the name of the folder to create on the target computer.

Description The `xPCFSMKDIR` function creates the folder *dirname* in the current folder of the target computer.

See Also API function `xPCFSGetPWD`
File object method `SimulinkRealTime.fileSystem.mkdir`

xPCFSOpenFile

Purpose Open file on target computer

Prototype `int xPCFSOpenFile(int port, const char *filename,
const char *permission);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>filename</i>	Enter the name of the file to open on the target computer.
<i>permission</i>	Enter the read/write permission with which to open the file. Values are r (read) or w (read/write).

Return The `xPCFSOpenFile` function returns the file handle for the opened file. If function detects an error, it returns -1.

Description The `xPCFSOpenFile` function opens the specified file, *filename*, on the target computer. If the file does not exist, the `xPCFSOpenFile` function creates *filename*, then opens it. You can open a file for read or read/write access.

See Also API functions `xPCFSCloseFile`, `xPCFSGetFileSize`, `xPCFSReadFile`, `xPCFSWriteFile`

File object methods `SimulinkRealTime.fileSystem fclose`,
`SimulinkRealTime.fileSystem filetable`,
`SimulinkRealTime.fileSystem fwrite`
`SimulinkRealTime.fileSystem fopen` and
`SimulinkRealTime.fileSystem fread`

Purpose Read open file on target computer

Prototype `void xPCFSReadFile(int port, int fileHandle, int start, int numbytes, unsigned char *data);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>fileHandle</i>	Enter the file handle of an open file on the target computer.
<i>start</i>	Enter an offset from the beginning of the file from which this function can start to read.
<i>numbytes</i>	Enter the number of bytes this function is to read from the file.
<i>data</i>	The contents of the file are stored in <i>data</i> .

Description The `xPCFSReadFile` function reads an open file on the target computer and places the results of the read operation in the array *data*. *fileHandle* is the file handle of a file previously opened by `xPCFSOpenFile`. You can specify that the read operation begin at the beginning of the file (default) or at a certain offset into the file (*start*). The *numbytes* parameter specifies how many bytes the `xPCFSReadFile` function is to read from the file.

See Also API functions `xPCFSCloseFile`, `xPCFSGetFileSize`, `xPCFSOpenFile`, `xPCFSWriteFile`

File object methods `SimulinkRealTime.fileSystem.fopen` and `SimulinkRealTime.fileSystem.fread`

xPCFSRemoveFile

Purpose Remove file from target computer

Prototype `void xPCFSRemoveFile(int port, const char *filename);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>filename</i>	Enter the name of a file on the target computer.

Description The `xPCFSRemoveFile` function removes the file named *filename* from the target computer file system. *filename* can be a relative or absolute path name on the target computer.

See Also File object method `SimulinkRealTime.fileSystem.removefile`

Purpose Remove folder from target computer

Prototype `void xPCFSRMDIR(int port, const char *dirname);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>dirname</i>	Enter the name of a folder on the target computer.

Description The `xPCFSRMDIR` function removes a folder named *dirname* from the target computer file system. *dirname* can be a relative or absolute path-name on the target computer.

See Also File object method `SimulinkRealTime.fileSystem.rmdir`

xPCFSScGetFilename

Purpose Get name of file for scope

Prototype `const char *xPCFSScGetFilename(int port, int scNum, char *filename);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>filename</i>	The name of the file for the specified scope is stored in <i>filename</i> .

Return Returns the value of *filename*, the name of the file for the scope.

Description The `xPCFSScGetFilename` function returns the name of the file to which scope *scNum* will save signal data. *filename* points to a caller-allocated character array to which the filename is copied.

See Also API function `xPCFSScSetFilename`
Property `Filename` of `SimulinkRealTime.fileSystem`

Purpose Get write mode of file for scope

Prototype `int xPCFSScGetWriteMode(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return Returns the number indicating the write mode. Values are

- | | |
|---|--|
| 0 | Lazy mode. The FAT entry is updated only when the file is closed and not during each file write operation. This mode is faster, but if the system crashes before the file is closed, the file system might not have the actual file size (the file contents, however, will be intact). |
| 1 | Commit mode. Each file write operation simultaneously updates the FAT entry for the file. This mode is slower, but the file system maintains the actual file size. |

Description The `xPCFSScGetWriteMode` function returns the write mode of the file for the scope.

See Also API function `xPCFSScSetWriteMode`
Property `WriteMode` of `SimulinkRealTime.fileSystem`

xPCFSScGetWriteSize

Purpose	Get block write size of data chunks				
Prototype	<code>unsigned int xPCFSScGetWriteSize(int <i>port</i>, int <i>scNum</i>);</code>				
Arguments	<table><tr><td><i>port</i></td><td>Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code>.</td></tr><tr><td><i>scNum</i></td><td>Enter the scope number.</td></tr></table>	<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .	<i>scNum</i>	Enter the scope number.
<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .				
<i>scNum</i>	Enter the scope number.				
Return	Returns the block size, in bytes, of the data chunks.				
Description	The <code>xPCFSScGetWriteSize</code> function gets the block size, in bytes, of the data chunks.				
See Also	API function <code>xPCFSScSetWriteSize</code> Property <code>WriteSize</code> of <code>SimulinkRealTime.fileSystem</code>				

Purpose Specify name for file to contain signal data

Prototype `void xPCFSScSetFilename(int port, int scNum,
const char *filename);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>filename</i>	Enter the name of a file to contain the signal data.

Description The `xPCFSScSetFilename` function sets the name of the file to which the scope will save the signal data. The Simulink Real-Time software creates this file in the target computer file system. Note that you can only call this function when the scope is stopped.

See Also API function `xPCFSScGetFilename`
Property `Filename` of `SimulinkRealTime.fileSystem`

xPCFSScSetWriteMode

Purpose Specify when file allocation table entry is updated

Prototype `void xPCFSScSetWriteMode(int port, int scNum, int writeMode);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>writeMode</i>	Enter an integer for the write mode: 0 Enables lazy write mode 1 Enables commit write mode

Description

The `xPCFSScSetWriteMode` function specifies when a file allocation table (FAT) entry is updated. Both modes write the signal data to the file, as follows:

- | | |
|---|--|
| 0 | Lazy mode. The FAT entry is updated only when the file is closed and not during each file write operation. This mode is faster, but if the system crashes before the file is closed, the file system might not have the actual file size (the file contents, however, will be intact). |
| 1 | Commit mode. Each file write operation simultaneously updates the FAT entry for the file. This mode is slower, but the file system maintains the actual file size. |

See Also

API function `xPCFSScGetWriteMode`

Property `WriteMode` of `SimulinkRealTime.fileSystem`

Purpose Specify that memory buffer collect data in multiples of write size

Prototype `void xPCFSScSetWriteSize(int port, int scNum, unsigned int writeSize);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>writeSize</i>	Enter the block size, in bytes, of the data chunks.

Description The `xPCFSScSetWriteSize` function specifies that a memory buffer collect data in multiples of *writeSize*. By default, this parameter is 512 bytes, which is the typical disk sector size. Using a block size that is the same as the disk sector size provides better performance. *writeSize* must be a multiple of 512.

See Also API function `xPCFSScGetWriteSize`
Property `WriteSize` of `SimulinkRealTime.fileSystem`

xPCFSWriteFile

Purpose Write to file on target computer

Prototype `void xPCFSWriteFile(int port, int fileHandle, int numbytes, const unsigned char *data);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>fileHandle</i>	Enter the file handle of an open file on the target computer.
<i>numbytes</i>	Enter the number of bytes this function is to write into the file.
<i>data</i>	The contents to write to <i>fileHandle</i> are stored in <i>data</i> .

Description The `xPCFSWriteFile` function writes the contents of the array *data* to the file specified by *fileHandle* on the target computer. The *fileHandle* parameter is the handle of a file previously opened by `xPCFSOpenFile`. *numbytes* is the number of bytes to write to the file.

See Also API functions `xPCFSCloseFile`, `xPCFSGetFileSize`, `xPCFSOpenFile`, `xPCFSReadFile`

Purpose	Get version number of Simulink Real-Time API
Prototype	<code>const char *xPCGetAPIVersion(void);</code>
Return	The <code>xPCGetApiVersion</code> function returns a string with the version number of the Simulink Real-Time kernel on the target computer.
Description	The <code>xPCGetApiVersion</code> function returns a string with the version number of the Simulink Real-Time kernel on the target computer. The string is a constant string within the API DLL. Do not modify this string.
See Also	API function <code>xPCGetTargetVersion</code>

xPCGetAppName

Purpose Return target application name

Prototype `char *xPCGetAppName(int port, char *model_name);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>model_name</i>	The <code>xPCGetAppName</code> function copies the target application name string into the buffer pointed to by <i>model_name</i> . <i>model_name</i> is then returned. You can later use <i>model_name</i> in a function such as <code>printf</code> . Note that the maximum size of the buffer is 256 bytes. To reserve enough space for the application name string, allocate a buffer of size 256 bytes.

Return The `xPCGetAppName` function returns a string with the name of the target application.

Description The `xPCGetAppName` function returns the name of the target application. You can use the return value, *model_name*, in a `printf` or similar statement. In case of error, the name string is unchanged.

Examples Allocate 256 bytes for the buffer `appname`.

```
char *appname=malloc(256);
xPCGetAppName(iport, appname);
appname=realloc(appname, strlen(appname)+1);
...
free(appname);
```

See Also API function `xPCIsAppRunning`
Target object property `Application`

Purpose Return display mode for target message window

Prototype `int xPCGetEcho(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Return The `xPCGetEcho` function returns the number indicating the display mode. Values are

1 Display is on. Messages are displayed in the message display window on the target.

0 Display is off.

Return The `xPCGetEcho` function the display mode of the target computer using communication channel *port*. If the function detects an error, it returns -1.

Description The `xPCGetEcho` function returns the display mode of the target computer using communication channel *port*. Messages include the status of downloading the target application, changes to parameters, and changes to scope signals.

See Also API function `xPCSetEcho`

xPCGetExecTime

Purpose	Return target application execution time
Prototype	<code>double xPCGetExecTime(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCGetExecTime</code> function returns the current execution time for a target application. If the function detects an error, it returns -1.
Description	The <code>xPCGetExecTime</code> function returns the current execution time for the running target application. If the target application is stopped, the value is the last running time when the target application was stopped. If the target application is running, the value is the current running time.
See Also	API functions <code>xPCSetStopTime</code> , <code>xPCGetStopTime</code> Property <code>ExecTime</code> of <code>SimulinkRealTime.target</code>

Purpose	Return constant of last error
Prototype	<code>int xPCGetLastError(void);</code>
Return	The xPCGetLastError function returns the error constant for the last reported error. If the function did not detect an error, it returns 0.
Description	The xPCGetLastError function returns the constant of the last reported error by another API function. This value is reset every time you call a new function. Therefore, you should check this constant value immediately after a call to an API function. For a list of error constants and messages, see “C API Error Messages” on page 2-2.
See Also	API functions xPCErrorMsg, xPCSetLastError

xPCGetLoadTimeOut

Purpose Return timeout value for communication between host computer and target computer

Prototype `int xPCGetLoadTimeOut(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Return The `xPCGetLoadTimeOut` function returns the number of seconds allowed for the communication between the host computer and target application. If the function detects an error, it returns -1.

Description The `xPCGetLoadTimeOut` function returns the number of seconds allowed for the communication between the host computer and the target application. When an Simulink Real-Time API function initiates communication between the host computer and target computer, it waits for a certain amount of time before checking to see if the communication is complete. In the case where communication with the target computer is not complete, the function returns a timeout error.

For example, when you load a new target application onto the target computer, the function `xPCLoadApp` waits for a certain amount of time before checking to see if the initialization of the target application is complete. In the case where initialization of the target application is not complete, the function `xPCLoadApp` returns a timeout error. By default, `xPCLoadApp` checks for the readiness of the target computer for up to 5 seconds. However, for larger models or models requiring longer initialization (for example, those with thermocouple boards), the default might not be long enough and a spurious timeout is generated. Other functions that communicate with the target computer will wait for *timeOut* seconds before declaring a timeout event. The function `xPCSetLoadTimeOut` sets the timeout to a different number.

Use the `xPCGetLoadTimeOut` function if you suspect that the current number of seconds (the timeout value) is too short. Then use the `xPCSetLoadTimeOut` function to set the timeout to a higher number.

See Also

API functions xPCLoadApp, xPCSetLoadTimeOut

xPCUnloadApp

“Increase the Time for Downloads”

xPCGetLogMode

Purpose	Return logging mode and increment value for target application
Prototype	<code>lgmode xPCGetLogMode(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCGetLogMode</code> function returns the logging mode in the <code>lgmode</code> structure. If the logging mode is 1 (<code>LGMOD_VALUE</code>), this function also returns an increment value in the <code>lgmode</code> structure. If an error occurs, this function returns -1.
Description	The <code>xPCGetLogMode</code> function gets the logging mode and increment value for the current target application. The increment (difference in amplitude) value is measured between logged data points. A data point is logged only when an output signal or a state changes by the increment value.
See Also	API function <code>xPCSetLogMode</code> API structure <code>lgmode</code>

Purpose	Return number of outputs
Prototype	<code>int xPCGetNumOutputs(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCGetNumOutputs</code> function returns the number of outputs in the current target application. If the function detects an error, it returns -1.
Description	The <code>xPCGetNumOutputs</code> function returns the number of outputs in the target application. The number of outputs equals the sum of the input signal widths of the output blocks at the root level of the Simulink model.
See Also	API functions <code>xPCGetOutputLog</code> , <code>xPCGetNumStates</code> , <code>xPCGetStateLog</code>

xPCGetNumParams

Purpose	Return number of tunable parameters
Prototype	<code>int xPCGetNumParams(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCGetNumParams</code> function returns the number of tunable parameters in the target application. If the function detects an error, it returns -1.
Description	The <code>xPCGetNumParams</code> function returns the number of tunable parameters in the target application. Use this function to see how many parameters you can get or modify.
See Also	API functions <code>xPCGetParamIdx</code> , <code>xPCSetParam</code> , <code>xPCGetParam</code> , <code>xPCGetParamName</code> , <code>xPCGetParamDims</code> Property <code>NumParameters</code> of <code>SimulinkRealTime.target</code>

Purpose	Return number of scopes added to target application
Prototype	<code>int xPCGetNumScopes(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCGetNumScopes</code> function returns the number of scopes that have been added to the target application. If the function detects an error, it returns -1.
Description	The <code>xPCGetNumScopes</code> function returns the number of scopes that have been added to the target application.

xPCGetNumScSignals

Purpose Returns number of signals added to specific scope

Prototype `int xPCGetNumScSignals(int port, int scopeId);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scopeId</i>	Enter the ID number of the scope for which you want to get the number of added signals.

Return The `xPCGetNumScSignals` function returns the number of signals that have been added to the scope, *scopeID*. If the function detects an error, it returns -1.

Description The `xPCGetNumScSignals` function returns the number of signals that have been added to the scope, *scopeID*.

Purpose	Return number of signals
Prototype	<code>int xPCGetNumSignals(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCGetNumSignals</code> function returns the number of signals in the target application. If the function detects an error, it returns -1.
Description	The <code>xPCGetNumSignals</code> function returns the total number of signals in the target application that can be monitored from the host. Use this function to see how many signals you can monitor.
See Also	API functions <code>xPCGetSignalIdx</code> , <code>xPCGetSignal</code> , <code>xPCGetSignals</code> , <code>xPCGetSignalName</code> , <code>xPCGetSignalWidth</code> Property <code>NumSignals</code> of <code>SimulinkRealTime.target</code>

xPCGetNumStates

Purpose	Return number of states
Prototype	<code>int xPCGetNumStates(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCGetNumStates</code> function returns the number of states in the target application. If the function detects an error, it returns -1.
Description	The <code>xPCGetNumStates</code> function returns the number of states in the target application.
See Also	API functions <code>xPCGetStateLog</code> , <code>xPCGetNumOutputs</code> , <code>xPCGetOutputLog</code> Property <code>StateLog</code> of <code>SimulinkRealTime.target</code>

Purpose Copy output log data to array

Prototype

```
void xPCGetOutputLog(int port, int first_sample,  
int num_samples,  
int decimation, int output_id, double *output_data);
```

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>first_sample</i>	Enter the index of the first sample to copy.
<i>num_samples</i>	Enter the number of samples to copy from the output log.
<i>decimation</i>	Select whether to copy every sample value or every Nth value.
<i>output_id</i>	Enter an output identification number.
<i>output_data</i>	The log is stored in <i>output_data</i> , whose allocation is the responsibility of the caller.

Description The `xPCGetOutputLog` function gets the output log and copies that log to an array. You get the data for each output signal in turn by specifying *output_id*. Output IDs range from 0 to (N-1), where N is the return value of `xPCGetNumOutputs`. Entering 1 for *decimation* copies all values. Entering N copies every Nth value.

For *first_sample*, the sample indices range from 0 to (N-1), where N is the return value of `xPCNumLogSamples`. Get the maximum number of samples by calling the function `xPCNumLogSamples`.

Note that the target application must be stopped before you get the number.

xPCGetOutputLog

See Also

API functions `xPCNumLogWraps`, `xPCNumLogSamples`, `xPCMaxLogSamples`, `xPCGetNumOutputs`, `xPCGetStateLog`, `xPCGetTETLog`, `xPCGetTimeLog`

Target object method `SimulinkRealTime.target.getlog`

Property `OutputLog` of `SimulinkRealTime.target`

Purpose Get parameter value and copy it to array

Prototype `void xPCGetParam(int port, int paramIndex, double *paramValue);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>paramIndex</i>	Enter the index for a parameter.
<i>paramValue</i>	The function returns a parameter value as an array of doubles.

Description The `xPCGetParam` function returns the parameter as an array in *paramValue*. *paramValue* must be large enough to hold the parameter. You can query the size by calling the function `xPCGetParamDims`. Get the parameter index by calling the function `xPCGetParamIdx`. The parameter matrix is returned as a vector, with the conversion being done in column-major format. It is also returned as a double, regardless of the data type of the actual parameter.

For *paramIndex*, values range from 0 to (N-1), where N is the return value of `xPCGetNumParams`.

See Also API functions `xPCSetParam`, `xPCGetParamDims`, `xPCGetParamIdx`, `xPCGetNumParams`

`SimulinkRealTime.target.getparamid`

Properties `ShowParameters` and `Parameters` of `SimulinkRealTime.target`

xPCGetParamDims

Purpose Get row and column dimensions of parameter

Prototype void xPCGetParamDims(int *port*, int *paramIndex*,
int **dimension*);

Arguments

<i>port</i>	Enter the value returned by either the function xPCOpenSerialPort or the function xPCOpenTcpIpPort.
<i>paramIndex</i>	Parameter index.
<i>dimension</i>	Dimensions (row, column) of a parameter.

Description The xPCGetParamDims function gets the dimensions (row, column) of a parameter with *paramIndex* and stores them in *dimension*, which must have at least two elements.

For *paramIndex*, values range from 0 to (N-1), where N is the return value of xPCGetNumParams.

See Also API functions xPCGetParamIdx, xPCGetParamName, xPCSetParam, xPCGetParam, xPCGetNumParams

SimulinkRealTime.target.getparamid

Properties ShowParameters and Parameters of SimulinkRealTime.target

Purpose Return parameter index

Prototype `int xPCGetParamIdx(int port, const char *blockName, const char *paramName);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>blockName</i>	Enter the full block path generated by Simulink Coder.
<i>paramName</i>	Enter the parameter name for a parameter associated with the block.

Return The `xPCGetParamIdx` function returns the parameter index for the parameter name. If the function detects an error, it returns -1.

Description The `xPCGetParamIdx` function returns the parameter index for the parameter name (*paramName*) associated with a Simulink block (*blockName*). Both *blockName* and *paramName* must be identical to those generated at target application building time. The block names should be referenced from the file `model_namept.m` in the generated code, where *model_name* is the name of the model. Note that a block can have one or more parameters.

See Also API functions `xPCGetParamDims`, `xPCGetParamName`, `xPCGetParamSimulinkRealTime.target.getparamid`
Properties `ShowParameters` and `Parameters` of `SimulinkRealTime.target`

xPCGetParamName

Purpose Get name of parameter

Prototype `void xPCGetParamName(int port, int paramIdx,
char *blockName, char
*paramName);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>paramIdx</i>	Enter a parameter index.
<i>blockName</i>	String with the full block path generated by Simulink Coder.
<i>paramName</i>	Name of a parameter for a specific block.

Description The `xPCGetParamName` function gets the parameter name and block name for a parameter with the index *paramIdx*. The block path and name are returned and stored in *blockName*, and the parameter name is returned and stored in *paramName*. You must allocate enough space for both *blockName* and *paramName*. If the *paramIdx* is invalid, `xPCGetLastError` returns nonzero, and the strings are unchanged. Get the parameter index from the function `xPCGetParamIdx`.

See Also API functions `xPCGetParam`, `xPCGetParamDims`, `xPCGetParamIdx`
Properties `ShowParameters` and `Parameters` of `SimulinkRealTime.target`

Purpose	Return target application sample time
Prototype	<code>double xPCGetSampleTime(int port);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCGetSampleTime</code> function returns the sample time, in seconds, of the target application. If the function detects an error, it returns -1.
Description	The <code>xPCGetSampleTime</code> function returns the sample time, in seconds, of the target application. You can get the error by using the function <code>xPCGetLastError</code> .
See Also	API function <code>xPCSetSampleTime</code> Property <code>SampleTime</code> of <code>SimulinkRealTime.target</code>

xPCGetScope

Purpose Get and copy scope data to structure

Prototype `scopedata xPCGetScope(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCGetScope` function returns a structure of type `scopedata`.

Description

Note The `xPCGetScope` function will be removed in a future release. Use the `xPCScGetScopePropertyName` functions to access property values instead. For example, to get the number of samples being acquired in one data acquisition cycle, use `xPCScGetNumSamples`.

The `xPCGetScope` function gets properties of a scope with *scNum* and copies the properties into a structure with type `scopedata`. You can use this function in conjunction with `xPCSetScope` to change several properties of a scope at one time. See `scopedata` for a list of properties. Use the `xPCGetScope` function to get the scope number.

See Also

API functions `xPCSetScope`, `scopedata`

Target object method `SimulinkRealTime.target.getscope`

Purpose Get and copy list of scope numbers

Prototype `void xPCGetScopeList(int port, int *data);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>data</i>	List of scope numbers in an integer array (allocated by the caller) as a list of unsorted integers.

Description The `xPCGetScopeList` function gets the list of scopes currently defined. *data* must be large enough to hold the list of scopes. You can query the size by calling the function `xPCGetNumScopes`.

Note Use the `xPCGetScopeList` function instead of the `xPCGetScopes` function. The `xPCGetScopes` will be removed in a future release.

xPCGetScopes

Purpose Get and copy list of scope numbers

Prototype `void xPCGetScopes(int port, int *data);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>data</i>	List of scope numbers in an integer array (allocated by the caller) as a list of unsorted integers and terminated by -1.

Description The `xPCGetScopes` function gets the list of scopes currently defined. You can use the constant `MAX_SCOPES` (defined in `xpcapiconst.h`) as the size of *data*. This is currently set to 30 scopes.

Note This function will be removed in a future release. Use the `xPCGetScopeList` function instead.

See Also API functions `xPCSetScope`, `xPCGetScope`, `xPCScGetSignals`
Property `Scopes` of `SimulinkRealTime.target`

Purpose	Return length of time Simulink Real-Time kernel has been running		
Prototype	<code>double xPCGetSessionTime(int <i>port</i>);</code>		
Arguments	<table><tr><td><i>port</i></td><td>Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code>.</td></tr></table>	<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .		
Return	The <code>xPCGetSessionTime</code> function returns the amount of time in seconds that the Simulink Real-Time kernel has been running on the target computer. If the function detects an error, it returns -1.		
Description	The <code>xPCGetSessionTime</code> function returns, as a double, the amount of time in seconds that the Simulink Real-Time kernel has been running. This value is also the time that has elapsed since you last booted the target computer.		

xPCGetSignal

Purpose Return value of signal

Prototype `double xPCGetSignal(int port, int sigNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>sigNum</i>	Enter a signal number.

Return The `xPCGetSignal` function returns the current value of signal *sigNum*. If the function detects an error, it returns -1.

Description The `xPCGetSignal` function returns the current value of a signal. For vector signals, use `xPCGetSignals` rather than call this function multiple times. Use the `xPCGetSignalIdx` function to get the signal number.

See Also API function `xPCGetSignals`
Property `Signals` of `SimulinkRealTime.target`

Purpose Return index for signal

Prototype `int xPCGetSignalIdx(int port, const char *sigName);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>sigName</i>	Enter a signal name.

Return The `xPCGetSignalIdx` function returns the index for the signal with name *sigName*. If the function detects an error, it returns -1.

Description The `xPCGetSignalIdx` function returns the index of a signal. The name must be identical to the name generated when the application was built. You should reference the name from the file `model_namebio.m` in the generated code, where *model_name* is the name of the model. The creator of the application should already know the signal name.

See Also API functions `xPCGetSignalName`, `xPCGetSignalWidth`, `xPCGetSignal`, `xPCGetSignals`

Target object method `SimulinkRealTime.target.getsignalid`

xPCGetSigIdxfromLabel

Purpose Return array of signal indices

Prototype `int xPCGetSigIdxfromLabel(int port, const char *sigLabel, int *sigIds);`

Arguments

<i>port</i>	Enter the value returned by either the function xPCOpenSerialPort or the function xPCOpenTcpIpPort.
<i>sigLabel</i>	String with the name of a signal label.
<i>sigIds</i>	Return array of signal indices.

Return If xPCGetSigIdxfromLabel finds a signal, it fills an array *sigIds* with signal indices and returns 0. If it finds no signal, it returns -1.

Description The xPCGetSigIdxfromLabel function returns in *sigIds* the array of signal indices for signal *sigName*. This function assumes that you have labeled the signal for which you request the indices (see the **Signal name** parameter of the “Signal Properties Controls”). Note that the Simulink Real-Time software refers to Simulink signal names as signal labels. The creator of the application should already know the signal name/label. Signal labels must be unique.

sigIds must be large enough to contain the array of indices. You can use the xPCGetSigLabelWidth function to get the required amount of memory to be allocated by the *sigIds* array.

See Also API functions xPCGetSignalLabel, xPCGetSigLabelWidth

Purpose

Copy label of signal to character array

Prototype

```
char * xPCGetSignalLabel(int port, int sigIdx,  
char *sigLabel);
```

Arguments

port Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

sigIdx Enter signal index.

sigLabel Return signal label associated with signal index, *sigIdx*.

Return

The `xPCGetSignalLabel` function returns the label of the signal.

Description

The `xPCGetSignalLabel` function copies and returns the signal label, including the block path, of a signal with *sigIdx*. The result is stored in *sigLabel*. If *sigIdx* is invalid, `xPCGetLastError` returns a nonzero value, and *sigLabel* is unchanged. The function returns *sigLabel*, which makes it convenient to use in a `printf` or similar statement. This function assumes that you already know the signal index. Signal labels must be unique.

This function assumes that you have labeled the signal for which you request the index (see the **Signal name** parameter of the “Signal Properties Controls”). Note that the Simulink Real-Time software refers to Simulink signal names as signal labels. The creator of the application should already know the signal name/label.

See Also

API functions `xPCGetSigIdxfromLabel`, `xPCGetSigLabelWidth`

xPCGetSigLabelWidth

Purpose Return number of elements in signal

Prototype `int xPCGetSigLabelWidth(int port, const char *sigName);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>sigName</i>	String with the name of a signal.

Return The `xPCGetSigLabelWidth` function returns the number of elements that the signal `sigName` contains. If the function detects an error, it returns -1.

Description The `xPCGetSigLabelWidth` function returns the number of elements that the signal `sigName` contains. This function assumes that you have labeled the signal for which you request the elements (see the **Signal name** parameter of the “Signal Properties Controls”). Note that the Simulink Real-Time software refers to Simulink signal names as signal labels. The creator of the application should already know the signal name/label. Signal labels must be unique.

See Also API functions `xPCGetSigIdxfromLabel`, `xPCGetSignalLabel`

Purpose Copy name of signal to character array

Prototype `char *xPCGetSignalName(int port, int sigIdx,
char *sigName);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>sigIdx</i>	Enter a signal index.
<i>sigName</i>	String with the name of a signal.

Return The `xPCGetSignalName` function returns the name of the signal.

Description The `xPCGetSignalName` function copies and returns the signal name, including the block path, of a signal with *sigIdx*. The result is stored in *sigName*. If *sigIdx* is invalid, `xPCGetLastError` returns a nonzero value, and *sigName* is unchanged. The function returns *sigName*, which makes it convenient to use in a `printf` or similar statement. This function assumes that you already know the signal index.

See Also API functions `xPCGetSignalIdx`, `xPCGetSignalWidth`, `xPCGetSignal`, `xPCGetSignals`

Properties `ShowSignals` and `Signals` of `SimulinkRealTime.target`

xPCGetSignals

Purpose Return vector of signal values

Prototype

```
int xPCGetSignals(int port, int numSignals,
const int *signals,
double *values);
```

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>numSignals</i>	Enter the number of signals to be acquired (that is, the number of values in <i>signals</i>).
<i>signals</i>	Enter the list of signal numbers to be acquired.
<i>values</i>	Returned values are stored in the double array <i>values</i> .

Return The `xPCGetSignals` function returns 0 if it completes execution without detecting an error. If the function detects an error, it returns -1.

Description The `xPCGetSignals` function is the vector version of the function `xPCGetSignal`. This function returns the values of a vector of signals (up to 1000) as fast as it can acquire them. The signal values may not be at the same time step (for that, define a scope of type `SCTYPE_HOST` and use `xPCScGetData`). `xPCGetSignal` does the same thing for a single signal, and could be used multiple times to achieve the same result. However, the `xPCGetSignals` function is faster, and the signal values are more likely to be spaced closely together. The signals are converted to doubles regardless of the actual data type of the signal.

For *signals*, the list you provide should be stored in an integer array. Get the signal numbers with the function `xPCGetSignalIdx`.

See Also API function `xPCGetSignal`, `xPCGetSignalIdx`

Example To reference signal vector data rather than scalar values, pass a vector of indices for the signal data. For example:


```
/* ***** */

/* Assume a signal of width 10, with the blockpath
 * mySubsys/mySignal and the signal index s1.
 */

int i;
int sigId[10];
double sigVal[10]; /* Signal values are stored here */

/* Get the ID of the first signal */
sigId[0] = xPCGetSignalIdx(port, "mySubsys/mySignal/s1");

if (sigId[0] == -1) {
/* Handle error */
}

for (i = 1; i < 10; i++) {
    sigId[i] = sigId[0] + i;
}

xPCGetSignals(port, 10, sigId, sigVal);
/* If no error, sigVal should have the signal values */

/* ***** */
```

To repeatedly get the signals, repeat the call to `xPCGetSignals`. If you do not change `sigID`, you only need to call `xPCGetSignalIdx` once.

xPCGetSignalWidth

Purpose Return width of signal

Prototype `int xPCGetSignalWidth(int port, int sigIdx);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>sigIdx</i>	Enter the index of a signal.

Return The `xPCGetSignalWidth` function returns the signal width for a signal with *sigIdx*. If the function detects an error, it returns -1.

Description The `xPCGetSignalWidth` function returns the number of signals for a specified signal index. Although signals are manipulated as scalars, the width of the signal might be useful to reassemble the components into a vector again. A signal's width is the number of signals in the vector.

See Also API functions `xPCGetSignalIdx`, `xPCGetSignalName`, `xPCGetSignal`, `xPCGetSignals`

Purpose Copy state log values to array

Prototype

```
void xPCGetStateLog(int port, int first_sample,  
int num_samples,  
int decimation, int state_id, double *state_data);
```

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>first_sample</i>	Enter the index of the first sample to copy.
<i>num_samples</i>	Enter the number of samples to copy from the output log.
<i>decimation</i>	Select whether to copy all the sample values or every Nth value.
<i>state_id</i>	Enter a state identification number.
<i>state_data</i>	The log is stored in <i>state_data</i> , whose allocation is the responsibility of the caller.

Description

The `xPCGetStateLog` function gets the state log. It then copies the log into *state_data*. You get the data for each state signal in turn by specifying the *state_id*. State IDs range from 1 to (N-1), where N is the return value of `xPCGetNumStates`. Entering 1 for *decimation* copies all values. Entering N copies every Nth value. For *first_sample*, the sample indices range from 0 to (N-1), where N is the return value of `xPCNumLogSamples`. Use the `xPCNumLogSamples` function to get the maximum number of samples.

Note that the target application must be stopped before you get the number.

xPCGetStateLog

See Also

API functions `xPCNumLogWraps`, `xPCNumLogSamples`, `xPCMaxLogSamples`, `xPCGetNumStates`, `xPCGetOutputLog`, `xPCGetTETLog`, `xPCGetTimeLog`

`SimulinkRealTime.target.getlog`

Property `StateLog` of `SimulinkRealTime.target`

Purpose Return stop time

Prototype `double xPCGetStopTime(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Return The `xPCGetStopTime` function returns the stop time as a double, in seconds, of the target application. If the function detects an error, it returns `-10.0`. If the stop time is infinity (run forever), this function returns `-1.0`.

Description The `xPCGetStopTime` function returns the stop time, in seconds, of the target application. This is the amount of time the target application runs before stopping. If the function detects an error, it returns `-10.0`. You will then need to use the function `xPCGetLastError` to find the error number.

See Also API function `xPCSetStopTime`
Property `StopTime` of `SimulinkRealTime.target`

xPCGetTargetVersion

Purpose Get Simulink Real-Time kernel version

Prototype `void xPCGetTargetVersion(int port, char *ver);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>ver</i>	The version is stored in <i>ver</i> .

Description The `xPCGetTargetVersion` function gets a string with the version number of the Simulink Real-Time kernel on the target computer. It then copies that version number into *ver*.

See Also `xPCGetAPIVersion`

Purpose Copy TET log to array

Prototype `void xPCGetTETLog(int port, int first_sample,
int num_samples, int decimation,
double *TET_data);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>first_sample</i>	Enter the index of the first sample to copy.
<i>num_samples</i>	Enter the number of samples to copy from the TET log.
<i>decimation</i>	Select whether to copy all the sample values or every Nth value.
<i>TET_data</i>	The log is stored in <i>TET_data</i> , whose allocation is the responsibility of the caller.

Description The `xPCGetTETLog` function gets the task execution time (TET) log. It then copies the log into *TET_data*. Entering 1 for *decimation* copies all values. Entering N copies every Nth value. For *first_sample*, the sample indices range from 0 to (N-1), where N is the return value of `xPCNumLogSamples`. Use the `xPCNumLogSamples` function to get the maximum number of samples.

Note that the target application must be stopped before you get the number.

See Also API functions `xPCNumLogWraps`, `xPCNumLogSamples`, `xPCMaxLogSamples`, `xPCGetNumOutputs`, `xPCGetStateLog`, `xPCGetTimeLog`

`SimulinkRealTime.target.getlog`

Property `TETLog` of `SimulinkRealTime.target`

xPCGetTimeLog

Purpose Copy time log to array

Prototype `void xPCGetTimeLog(int port, int first_sample,
int num_samples,
int decimation, double *time_data);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>first_sample</i>	Enter the index of the first sample to copy.
<i>num_samples</i>	Enter the number of samples to copy from the time log.
<i>decimation</i>	Select whether to copy all the sample values or every Nth value.
<i>time_data</i>	The log is stored in <i>time_data</i> , whose allocation is the responsibility of the caller.

Description The `xPCGetTimeLog` function gets the time log and copies the log into *time_data*. This is especially relevant in the case of value-equidistant logging, where the logged values might not be uniformly spaced in time. Entering 1 for *decimation* copies all values. Entering N copies every Nth value. For *first_sample*, the sample indices range from 0 to (N-1), where N is the return value of `xPCNumLogSamples`. Use the `xPCNumLogSamples` function to get the number of samples.

Note that the target application must be stopped before you get the number.

See Also API functions `xPCNumLogWraps`, `xPCNumLogSamples`, `xPCMaxLogSamples`, `xPCGetStateLog`, `xPCGetTETLog`, `xPCSetLogMode`, `xPCGetLogMode`
`SimulinkRealTime.target.getlog`
Property `TimeLog` of `SimulinkRealTime.target`

Purpose	Initialize Simulink Real-Time DLL
Prototype	<code>int xPCInitAPI(void);</code>
Return	The xPCInitAPI function returns 0 if it completes execution without detecting an error. If the function detects an error, it returns -1.
Description	The xPCInitAPI function initializes the Simulink Real-Time dynamic link library. You must execute this function once at the beginning of the application to load the Simulink Real-Time API DLL. This function is defined in the file <code>xpcinitfree.c</code> . Link this file with your application.
See Also	API functions <code>xPCFreeAPI</code> , <code>xPCNumLogWraps</code> , <code>xPCNumLogSamples</code> , <code>xPCMaxLogSamples</code> , <code>xPCGetStateLog</code> , <code>xPCGetTETLog</code> , <code>xPCSetLogMode</code> , <code>xPCGetLogMode</code>

xPCIsAppRunning

Purpose	Return target application running status
Prototype	<code>int xPCIsAppRunning(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	If the target application is stopped, the <code>xPCIsAppRunning</code> function returns 0. If the target application is running, this function returns 1. If the function detects an error, it returns -1.
Description	The <code>xPCIsAppRunning</code> function returns 1 or 0 depending on whether the target application is stopped or running. If the function detects is an error, use the function <code>xPCGetLastError</code> to check for the error string constant.
See Also	API function <code>xPCIsOverloaded</code> Property <code>Status of SimulinkRealTime.target</code>

Purpose	Return target computer overload status
Prototype	<code>int xPCIsOverloaded(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	If the target application has overloaded the CPU, the <code>xPCIsOverloaded</code> function returns 1. If it has not overloaded the CPU, the function returns 0. If this function detects error, it returns -1.
Description	The <code>xPCIsOverloaded</code> function checks if the target application has overloaded the target computer and returns 1 if it has and 0 if it has not. If the target application is not running, the function returns 0.
See Also	API function <code>xPCIsAppRunning</code> Property <code>CPUOverload</code> of <code>SimulinkRealTime.target</code>

xPCIsScFinished

Purpose Return data acquisition status for scope

Prototype `int xPCIsScFinished(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return If a scope finishes a data acquisition cycle, the `xPCIsScFinished` function returns 1. If the scope is in the process of acquiring data, this function returns 0. If the function detects an error, it returns -1.

Description The `xPCIsScFinished` function returns a Boolean value depending on whether scope *scNum* is finished (state of `SCST_FINISHED`) or not. You can also call this function for target scopes; however, because target scopes restart immediately, it is almost impossible to find these scopes in the finished state. Use the `xPCGetScope` function to get the scope number.

See Also API function `xPCScGetState`
Scope object property `Status`

Purpose Load target application onto target computer

Prototype `void xPCLoadApp(int port, const char *pathstr,
const char *filename);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>pathstr</i>	Enter the full path to the target application file, excluding the file name. For example, in C, use a string like "C:\\work".
<i>filename</i>	Enter the name of a compiled target application (*.dlm) without the file extension. For example, in C use a string like "xpcosc".

Description The `xPCLoadApp` function loads the compiled target application to the target computer. *pathstr* must not contain the trailing backslash. *pathstr* can be set to `NULL` or to the string 'nopath' if the application is in the current folder. The variable *filename* must not contain the target application extension.

Before returning, `xPCLoadApp` waits for a certain amount of time before checking whether the model initialization is complete. In the case where the model initialization is incomplete, `xPCLoadApp` returns a timeout error to indicate a connection problem (for example, `ETCPREAD`). By default, `xPCLoadApp` checks for target readiness five times, with each attempt taking approximately 1 second (less if the target is ready). However, for larger models or models requiring longer initialization (for example, those with thermocouple boards), the default might not be long enough and a spurious timeout can be generated. The functions `xPCGetLoadTimeOut` and `xPCSetLoadTimeOut` control the number of attempts made.

xPCLoadApp

See Also

API functions `xPCStartApp`, `xPCStopApp`, `xPCUnloadApp`,
`xPCSetLoadTimeOut`, `xPCGetLoadTimeOut`

Target object method `SimulinkRealTime.target.load`

Purpose Restore parameter values

Prototype `void xPCLoadParamSet(int port, const char *filename);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>filename</i>	Enter the name of the file that contains the saved parameters.

Description The `xPCLoadParamSet` function restores the target application parameter values saved in the file *filename*. This file must be located on a local drive of the target computer. The parameter file must have been saved from a previous call to `xPCSaveParamSet`.

See Also API function `xPCSaveParamSet`

xPCMaxLogSamples

Purpose	Return maximum number of samples that can be in log buffer
Prototype	<code>int xPCMaxLogSamples(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCMaxLogSamples</code> function returns the total number of samples. If the function detects an error, it returns -1.
Description	The <code>xPCMaxLogSamples</code> function returns the total number of samples that can be returned in the logging buffers.
See Also	API functions <code>xPCNumLogSamples</code> , <code>xPCNumLogWraps</code> , <code>xPCGetStateLog</code> , <code>xPCGetOutputLog</code> , <code>xPCGetTETLog</code> , <code>xPCGetTimeLog</code> Property <code>MaxLogSamples</code> of <code>SimulinkRealTime.target</code>

Purpose Copy maximum task execution time to array

Prototype `void xPCMaximumTET(int port, double *data);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>data</i>	Array of at least two doubles.

Description The `xPCMaximumTET` function gets the maximum task execution time (TET) that was achieved during the previous target application run. This function also returns the time at which the maximum TET was achieved. The `xPCMaximumTET` function then copies these values into the *data* array. The maximum TET value is copied into the first element, and the time at which it was achieved is copied into the second element.

See Also API functions `xPCMinimumTET`, `xPCAverageTET`
Property `MaxTET` of `SimulinkRealTime.target`

xPCMinimumTET

Purpose Copy minimum task execution time to array

Prototype `void xPCMinimumTET(int port, double *data);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>data</i>	Array of at least two doubles.

Description The `xPCMinimumTET` function gets the minimum task execution time (TET) that was achieved during the previous target application run. This function also returns the time at which the minimum TET was achieved. The `xPCMinimumTET` function then copies these values into the *data* array. The minimum TET value is copied into the first element, and the time at which it was achieved is copied into the second element.

See Also API functions `xPCMaximumTET`, `xPCAverageTET`
Property `MinTET` of `SimulinkRealTime.target`

Purpose	Return number of samples in log buffer
Prototype	<code>int xPCNumLogSamples(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCNumLogSamples</code> function returns the number of samples in the log buffer. If the function detects an error, it returns -1.
Description	<p>The <code>xPCNumLogSamples</code> function returns the number of samples in the log buffer. In contrast to <code>xPCMaxLogSamples</code>, which returns the maximum number of samples that can be logged (because of buffer size constraints), <code>xPCNumLogSamples</code> returns the number of samples actually logged.</p> <p>Note that the target application must be stopped before you get the number.</p>
See Also	API functions <code>xPCGetStateLog</code> , <code>xPCGetOutputLog</code> , <code>xPCGetTETLog</code> , <code>xPCGetTimeLog</code> , <code>xPCMaxLogSamples</code>

xPCNumLogWraps

Purpose	Return number of times log buffer wraps
Prototype	<code>int xPCNumLogWraps(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCNumLogWraps</code> function returns the number of times the log buffer wraps. If the function detects an error, it returns -1.
Description	The <code>xPCNumLogWraps</code> function returns the number of times the log buffer wraps.
See Also	API functions <code>xPCNumLogSamples</code> , <code>xPCMaxLogSamples</code> , <code>xPCGetStateLog</code> , <code>xPCGetOutputLog</code> , <code>xPCGetTETLog</code> , <code>xPCGetTimeLog</code> Property <code>NumLogWraps</code> of <code>SimulinkRealTime.target</code>

Purpose Open connection to target computer

Prototype `void xPCOpenConnection(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Description The `xPCOpenConnection` function opens a connection to the target computer whose data is indexed by *port*. Before calling this function, set up the target information by calling `xPCRegisterTarget`. A call to either `xPCOpenSerialPort` or `xPCOpenTcpIpPort` can also set up the target information. If the port is already open, calling this function has no effect.

See Also API functions `xPCOpenTcpIpPort`, `xPCClosePort`, `xPCReOpenPort`, `xPCTargetPing`, `xPCCloseConnection`, `xPCRegisterTarget`

xPCOpenSerialPort

Purpose Open RS-232 connection to Simulink Real-Time system

Prototype `int xPCOpenSerialPort(int comPort, int baudRate);`

Arguments

<i>comPort</i>	Index of the COM port to be used (0 is COM1, 1 is COM2, and so forth).
<i>baudRate</i>	<i>baudRate</i> must be one of the following values: 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200.

Return The `xPCOpenSerialPort` function returns the port value for the connection. If the function detects an error, it returns -1.

Description The `xPCOpenSerialPort` function initiates an RS-232 connection to an Simulink Real-Time system. It returns the port value for the connection. Be sure to pass this value to all the Simulink Real-Time API functions that require a port value.

If you enter a value of 0 for *baudRate*, this function sets the baud rate to the default value (115200).

Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.

See Also API functions `xPCOpenTcpIpPort`, `xPCClosePort`, `xPCReOpenPort`, `xPCTargetPing`, `xPCOpenConnection`, `xPCCloseConnection`, `xPCRegisterTarget`, `xPCDeRegisterTarget`

Purpose	Open TCP/IP connection to Simulink Real-Time system				
Prototype	<pre>int xPCOpenTcpIpPort(const char *ipAddress, const char *ipPort);</pre>				
Arguments	<table><tr><td><i>ipAddress</i></td><td>Enter the IP address of the target as a dotted decimal string. For example, "192.168.0.10".</td></tr><tr><td><i>ipPort</i></td><td>Enter the associated IP port as a string. For example, "22222".</td></tr></table>	<i>ipAddress</i>	Enter the IP address of the target as a dotted decimal string. For example, "192.168.0.10".	<i>ipPort</i>	Enter the associated IP port as a string. For example, "22222".
<i>ipAddress</i>	Enter the IP address of the target as a dotted decimal string. For example, "192.168.0.10".				
<i>ipPort</i>	Enter the associated IP port as a string. For example, "22222".				
Return	The xPCOpenTcpIpPort function returns a nonnegative integer that you can then use as the port value for an Simulink Real-Time API function that requires it. If this operation fails, this function returns -1.				
Description	The xPCOpenTcpIpPort function opens a connection to the TCP/IP location specified by the IP address. It returns a nonnegative integer if it succeeds. Use this integer as the <i>ipPort</i> variable in the Simulink Real-Time API functions that require a port value. The global error number is also set, which you can get using xPCGetLastError.				
See Also	API functions xPCOpenSerialPort, xPCClosePort, xPCReOpenPort, xPCTargetPing				

xPCReboot

Purpose Reboot target computer

Prototype `void xPCReboot(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Description The `xPCReboot` function reboots the target computer. This function returns nothing. This function does not close the connection to the target computer. You should either explicitly close the port or call `xPCReOpenPort` once the target computer has rebooted.

See Also API function `xPCReOpenPort`
Target object method `SimulinkRealTime.target.reboot`

Purpose	Reopen communication channel
Prototype	<code>int xPCReOpenPort(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCReOpenPort</code> function returns 0 if it reopens a connection without detecting an error. If the function detects an error, it returns -1.
Description	The <code>xPCReOpenPort</code> function reopens the communications channel pointed to by <i>port</i> . The difference between this function and <code>xPCOpenSerialPort</code> or <code>xPCOpenTcpIpPort</code> is that <code>xPCReOpenPort</code> uses the already existing settings, while the other functions need to set up the port.
See Also	API functions <code>xPCOpenTcpIpPort</code> , <code>xPCClosePort</code>

xPCRegisterTarget

Purpose Register target with Simulink Real-Time API library

Prototype `int xPCRegisterTarget(int commType, const char *ipAddress, const char *ipPort, int comPort, int baudRate);`

Arguments *commType* Specify the communication type (TCP/IP or RS-232) between the host and the target.

Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.

ipAddress Enter the IP address of the target as a dotted decimal string. For example, "192.168.0.10".

ipPort Enter the associated IP port as a string. For example, "22222".

comPort *comPort* and *baudRate* are as in xPCOpenSerialPort.

baudRate The *baudRate* must be one of the following values: 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200.

Return The xPCRegisterTarget function returns the port number. If the function detects an error, it returns -1.

Description The xPCRegisterTarget function works similarly to xPCOpenSerialPort and xPCOpenTcpIpPort, except that it does not try to open a connection to the target computer. In other words, xPCOpenSerialPort or xPCOpenTcpIpPort is equivalent to calling xPCRegisterTarget with the required parameters, followed by a call to xPCOpenConnection.

Use the constants COMMTYP_TCP/IP and COMMTYP_RS232 for *commType*. If *commType* is set to COMMTYP_RS232, the function ignores *ipAddress*

and *ipPort*. Analogously, the function ignores *comPort* and *baudRate* if *commType* is set to `COMMTYP_TCPIP`.

If you enter a value of 0 for *baudRate*, this function sets the baud rate to the default value (115200).

See Also

API functions `xPCDeRegisterTarget`, `xPCOpenTcpIpPort`, `xPCOpenSerialPort`, `xPCClosePort`, `xPCReOpenPort`, `xPCOpenConnection`, `xPCCloseConnection`, `xPCTargetPing`

xPCRemScope

Purpose Remove scope

Prototype `void xPCRemScope(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Description The `xPCRemScope` function removes the scope with number *scNum*. Attempting to remove a nonexistent scope causes an error. For a list of existing scopes, see `xPCGetScopes`. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCAddScope`, `xPCScRemSignal`, `xPCGetScopes`
Target object method `SimulinkRealTime.target.remscope`

Purpose Save parameter values of target application

Prototype `void xPCSaveParamSet(int port, const char *filename);`

Arguments

port Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

filename Enter the name of the file to contain the saved parameters.

Description The `xPCSaveParamSet` function saves the target application parameter values in the file *filename*. This function saves the file on a local drive of the current target computer. You can later reload these parameters with the `xPCLoadParamSet` function.

You might want to save target application parameter values if you change these parameter values while the application is running in Real-Time mode. Saving these values enable you to easily recreate target application parameter values from a number of application runs.

See Also API function `xPCLoadParamSet`

xPCScAddSignal

Purpose Add signal to scope

Prototype `void xPCScAddSignal(int port, int scNum, int sigNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>sigNum</i>	Enter a signal number.

Description The `xPCScAddSignal` function adds the signal with number *sigNum* to the scope *scNum*. The signal should not already exist in the scope. You can use `xPCScGetSignals` to get a list of the signals already present. Use the function `xPCGetScope` to get the scope number. Use the `xPCGetSignalIdx` function to get the signal number.

See Also API functions `xPCScRemSignal`, `xPCAddScope`, `xPCRemScope`, `xPCGetScopes`

Scope object methods `SimulinkRealTime.fileScope.addsignal`, `SimulinkRealTime.hostScope.addsignal`, and `SimulinkRealTime.targetScope.addsignal`

Purpose Scope autorestart status

Prototype `long xPCScGetAutoRestart(int port, int scNum)`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetAutoRestart` function returns the autorestart flag value of scope *scNum*. If the function detects an error, it returns -1.

Description The `xPCScGetAutoRestart` function gets the autorestart flag value for scope *scNum*. Autorestart flag can be disabled (0) or enabled (1).

See Also API functions `xPCScSetAutoRestart`

xPCScGetData

Purpose Copy scope data to array

Prototype

```
void xPCScGetData(int port, int scNum, int signal_id, int start, int numsamples, int decimation, double *data);
```

Arguments

<i>port</i>	Enter the value returned by either the function xPCOpenSerialPort or the function xPCOpenTcpIpPort.
<i>scNum</i>	Enter the scope number.
<i>signal_id</i>	Enter a signal number. Enter -1 to get time stamped data.
<i>start</i>	Enter the first sample from which data retrieval is to start.
<i>numsamples</i>	Enter the number of samples retrieved with a decimation of <i>decimation</i> , starting from the <i>start</i> value.
<i>decimation</i>	Enter a value such that every <i>decimation</i> sample is retrieved in a scope window.
<i>data</i>	The data is available in the array <i>data</i> , starting from sample <i>start</i> .

Description The xPCScGetData function gets the data used in a scope. Use this function for scopes of type SCTYPE_HOST. The scope must be either in state "Finished" or in state "Interrupted" for the data to be retrievable. (Use the xPCScGetState function to check the state of the scope.) The data must be retrieved one signal at a time. The calling function must allocate the space ahead of time to store the scope data. *data* must be an array of doubles, regardless of the data type of the signal to be retrieved. Use the function xPCScGetSignals to get the list of signals in the scope for *signal_id*. Use the function xPCGetScope to get the scope number for *scNum*.

To get time stamped data, specify -1 for `signal_id`. From the output, you can then get the number of nonzero elements.

See Also

API functions `xPCGetScope`, `xPCScGetState`, `xPCScGetSignals`

Property Data of `SimulinkRealTime.hostScope`

xPCScGetDecimation

Purpose Return decimation of scope

Prototype `int xPCScGetDecimation(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetDecimation` function returns the decimation of scope *scNum*. If the function detects an error, it returns -1.

Description The `xPCScGetDecimation` function gets the decimation of scope *scNum*. The decimation is a number, N, meaning every Nth sample is acquired in a scope window. Use the `xPCGetScope` function to get the scope number.

See Also API function `xPCScSetDecimation`
Property `Decimation` of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose Get number of pre- or post-triggering samples before triggering scope

Prototype `int xPCScGetNumPrePostSamples(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetNumPrePostSamples` function returns the number of samples for pre- or posttriggering for scope *scNum*. If an error occurs, this function returns the minimum integer value (-2147483647-1).

Description The `xPCScGetNumPrePostSamples` function gets the number of samples for pre- or posttriggering for scope *scNum*. A negative number implies pretriggering, whereas a positive number implies posttriggering samples. Use the `xPCGetScope` function to get the scope number.

See Also API function `xPCScSetNumPrePostSamples`
Property `NumPrePostSamples` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScGetNumSamples

Purpose Get number of samples in one data acquisition cycle

Prototype `int xPCScGetNumSamples(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetNumSamples` function returns the number of samples in the scope *scNum*. If the function detects an error, it returns -1.

Description The `xPCScGetNumSamples` function gets the number of samples in one data acquisition cycle for scope *scNum*. Use the `xPCGetScope` function to get the scope number.

See Also API function `xPCScSetNumSamples`
Property `NumSamples` of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose	Get number of signals in scope				
Prototype	<code>int xPCScGetNumSignals(int <i>port</i>, int <i>scNum</i>);</code>				
Arguments	<table><tr><td><i>port</i></td><td>Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code>.</td></tr><tr><td><i>scNum</i></td><td>Enter the scope number.</td></tr></table>	<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .	<i>scNum</i>	Enter the scope number.
<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .				
<i>scNum</i>	Enter the scope number.				
Return	The <code>xPCScGetNumSignals</code> function returns the number of signals in the scope <i>scNum</i> . If the function detects an error, it returns -1.				
Description	The <code>xPCScGetNumSignals</code> function gets the number of signals in the scope <i>scNum</i> . Use the <code>xPCGetScope</code> function to get the scope number.				
See Also	API function <code>xPCGetScope</code>				

xPCScGetSignalList

Purpose Copy list of signals to array

Prototype void xPCScGetSignalList(int *port*, int *scNum*, int **data*)

Arguments

<i>port</i>	Value returned by either the function xPCOpenSerialPort or the function xPCOpenTcpIpPort.
<i>scNum</i>	Enter the scope number.
<i>data</i>	Integer array allocated by the caller as a list containing the signal identifiers.

Description The xPCScGetSignals function gets the list of signals defined for scope *scNum*. The array *data* must be large enough to hold the list of signals. To query the size, use the xPCScGetNumSignals function. Use the xPCGetScope function to get the scope number.

Note Use the xPCScGetSignalList function instead of the xPCScGetSignals function. The xPCScGetSignals will be removed in a future release.

Purpose Copy list of signals to array

Prototype `void xPCScGetSignals(int port, int scNum, int *data);`

Arguments

<i>port</i>	Value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>data</i>	Integer array allocated by the caller as a list containing the signal identifiers, terminated by -1.

Description The `xPCScGetSignals` function gets the list of signals defined for scope *scNum*. You can use the constant `MAX_SIGNALS`, defined in `xpcapiconst.h`, as the size of *data*. Use the `xPCGetScope` function to get the scope number.

Note This function will be removed in a future release. Use the `xPCScGetSignalList` function instead.

See Also API functions `xPCScGetData`, `xPCGetScopes`
Scope object property `Signals`

xPCScGetStartTime

Purpose Get start time for last data acquisition cycle

Prototype `double xPCScGetStartTime(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetStartTime` function returns the start time for the last data acquisition cycle of a scope. If the function detects an error, it returns -1.

Description The `xPCScGetStartTime` function gets the time at which the last data acquisition cycle for scope *scNum* started. This is only valid for scopes of type `SCTYPE_HOST`. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCScGetNumSamples`, `xPCScGetDecimation`

Purpose Get state of scope

Prototype `int xPCScGetState(int port, int scNum);`

Arguments

port Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

scNum Enter the scope number.

Return The `xPCScGetState` function returns the state of scope *scNum*. If the function detects an error, it returns -1.

Description The `xPCScGetState` function gets the state of scope *scNum*, or -1 upon error. Use the `xPCGetScope` function to get the scope number.

Constants to find the scope state, defined in `xpcapiconst.h`, have the following meanings:

Constant	Value	Description
SCST_WAITTOSTART	0	Scope is ready and waiting to start.
SCST_PREACQUIRING	5	Scope acquires a predefined number of samples before triggering.
SCST_WAITFORTRIG	1	After a scope is finished with the preacquiring state, it waits for a trigger. If the scope does not preacquire data, it enters the wait for trigger state.
SCST_ACQUIRING	2	Scope is acquiring data. The scope enters this state when it leaves the wait for trigger state.

xPCScGetState

Constant	Value	Description
SCST_FINISHED	3	Scope is finished acquiring data when it has attained the predefined limit.
SCST_INTERRUPTED	4	The user has stopped (interrupted) the scope.

See Also

API functions `xPCScStart`, `xPCScStop`

Scope object property `Status`

Purpose Get trigger level for scope

Prototype `double xPCScGetTriggerLevel(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetTriggerLevel` function returns the scope trigger level. If the function detects an error, it returns -1.

Description The `xPCScGetTriggerLevel` function gets the trigger level for scope *scNum*. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCScSetTriggerLevel`, `xPCScSetTriggerSlope`, `xPCScGetTriggerSlope`, `xPCScSetTriggerSignal`, `xPCScGetTriggerSignal`, `xPCScSetTriggerScope`, `xPCScGetTriggerScope`, `xPCScSetTriggerMode`, `xPCScGetTriggerMode`

Property `TriggerLevel` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScGetTriggerMode

Purpose Get trigger mode for scope

Prototype `int xPCScGetTriggerMode(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetTriggerMode` function returns the scope trigger mode. If the function detects an error, it returns -1.

Description The `xPCScGetTriggerMode` function gets the trigger mode for scope *scNum*. Use the `xPCGetScope` function to get the scope number. Use the constants defined in `xpcapiconst.h` to interpret the trigger mode. These constants include the following:

Constant	Value	Description
TRIGMD_FREERUN	0	There is no trigger mode. The scope triggers when it is ready to trigger, regardless of the circumstances.
TRIGMD_SOFTWARE	1	Only user intervention can trigger the scope. No other triggering is possible.

Constant	Value	Description
TRIGMD_SIGNAL	2	The scope is triggered only after a signal has crossed a value.
TRIGMD_SCOPE	3	The scope is triggered by another scope at the trigger point of the triggering scope, modified by the value of <code>triggerscopesample</code> (see <code>scopedata</code>).

See Also

API functions `xPCScSetTriggerLevel`, `xPCScGetTriggerLevel`, `xPCScSetTriggerSlope`, `xPCScGetTriggerSlope`, `xPCScSetTriggerSignal`, `xPCScGetTriggerSignal`, `xPCScSetTriggerScope`, `xPCScGetTriggerScope`, `xPCScSetTriggerMode`

Methods `SimulinkRealTime.fileScope.trigger`, `SimulinkRealTime.hostScope.trigger`, and `SimulinkRealTime.targetScope.trigger`

Property `TriggerMode` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScGetTriggerScope

Purpose Get trigger scope

Prototype `int xPCScGetTriggerScope(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetTriggerScope` function returns a trigger scope. If the function detects an error, it returns -1.

Description The `xPCScGetTriggerScope` function gets the trigger scope for scope *scNum*. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCScSetTriggerLevel`, `xPCScGetTriggerLevel`, `xPCScSetTriggerSlope`, `xPCScGetTriggerSlope`, `xPCScSetTriggerSignal`, `xPCScGetTriggerSignal`, `xPCScSetTriggerMode`, `xPCScGetTriggerMode`

Property `TriggerScope` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose Get sample number for triggering scope

Prototype `int xPCScGetTriggerScopeSample(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetTriggerScopeSample` function returns a nonnegative integer for a real sample, and -1 for the special case where triggering is at the end of the data acquisition cycle for a triggering scope. If the function detects an error, it returns `INT_MIN` (-2147483647-1).

Description The `xPCScGetTriggerScopeSample` function gets the number of samples a triggering scope (*scNum*) acquires before starting data acquisition on a second scope. This value is a nonnegative integer for a real sample, and -1 for the special case where triggering is at the end of the data acquisition cycle for a triggering scope. Use the `xPCGetScope` function to get the scope number for the trigger scope.

See Also API functions `xPCScSetTriggerLevel`, `xPCScGetTriggerLevel`, `xPCScSetTriggerSlope`, `xPCScGetTriggerSlope`, `xPCScSetTriggerSignal`, `xPCScGetTriggerSignal`, `xPCScSetTriggerScope`, `xPCScGetTriggerScope`, `xPCScSetTriggerMode`, `xPCScGetTriggerMode`, `xPCScSetTriggerScopeSample`

Property `TriggerSample` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScGetTriggerSignal

Purpose Get trigger signal for scope

Prototype `int xPCScGetTriggerSignal(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetTriggerSignal` function returns the scope trigger signal. If the function detects an error, it returns -1.

Description The `xPCScGetTriggerSignal` function gets the trigger signal for scope *scNum*. Use the `xPCGetScope` function to get the scope number for the trigger scope.

See Also API functions `xPCScSetTriggerLevel`, `xPCScGetTriggerLevel`, `xPCScSetTriggerSlope`, `xPCScGetTriggerSlope`, `xPCScSetTriggerSignal`, `xPCScSetTriggerScope`, `xPCScGetTriggerScope`, `xPCScSetTriggerMode`, `xPCScGetTriggerMode`

Methods `SimulinkRealTime.fileScope.trigger`, `SimulinkRealTime.hostScope.trigger`, and `SimulinkRealTime.targetScope.trigger`

Property `TriggerSignal` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose Get trigger slope for scope

Prototype `int xPCScGetTriggerSlope(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetTriggerSlope` function returns the scope trigger slope. If the function detects an error, it returns -1.

Description The `xPCScGetTriggerSlope` function gets the trigger slope of scope *scNum*. Use the `xPCGetScope` function to get the scope number for the trigger scope. Use the constants defined in `xpcapiconst.h` to interpret the trigger slope. These constants have the following meanings:

Constant	Value	Description
TRIGSLOPE_EITHER	0	The trigger slope can be either rising or falling.
TRIGSLOPE_RISING	1	The trigger slope must be rising when the signal crosses the trigger value.
TRIGSLOPE_FALLING	2	The trigger slope must be falling when the signal crosses the trigger value.

xPCScGetTriggerSlope

See Also

API functions `xPCScSetTriggerLevel`, `xPCScGetTriggerLevel`,
`xPCScSetTriggerSlope`, `xPCScSetTriggerSignal`,
`xPCScGetTriggerSignal`, `xPCScSetTriggerScope`,
`xPCScGetTriggerScope`, `xPCScSetTriggerMode`, `xPCScGetTriggerMode`

Methods `SimulinkRealTime.fileScope.trigger`,
`SimulinkRealTime.hostScope.trigger`, and
`SimulinkRealTime.targetScope.trigger`

Property `TriggerSlope` of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose Get type of scope

Prototype `int xPCScGetType(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCScGetType` function returns the scope type. If the function detects an error, it returns -1.

Description The `xPCScGetType` function gets the type (`SCTYPE_HOST` for host, `SCTYPE_TARGET` for target, or `SCTYPE_FILE` for file) of scope *scNum*. Use the constants defined in `xpcapiconst.h` to interpret the return value. A scope of type `SCTYPE_HOST` is displayed on the host computer while a scope of type `SCTYPE_TARGET` is displayed on the target computer screen. A scope of type `SCTYPE_FILE` is stored on a storage medium. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCAddScope`, `xPCRemScope`
Property Type of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScRemSignal

Purpose Remove signal from scope

Prototype `void xPCScRemSignal(int port, int scNum, int sigNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>sigNum</i>	Enter a signal number.

Description The `xPCScRemSignal` function removes a signal from the scope with number *scNum*. The scope must already exist, and signal number *sigNum* must exist in the scope. Use `xPCGetScopes` to determine the existing scopes, and use `xPCScGetSignals` to determine the existing signals for a scope. Use this function only when the scope is stopped. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCScAddSignal`, `xPCAddScope`, `xPCRemScope`, `xPCGetScopes`, `xPCScGetSignals`, `xPCScGetState`

Scope object methods `SimulinkRealTime.fileScope.remsignal`, `SimulinkRealTime.hostScope.remsignal`, and `SimulinkRealTime.targetScope.remsignal`

Purpose Scope autorestart status

Prototype `void xPCScSetAutoRestart(int port, int scNum, int autorestart)`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>autorestart</i>	Enter value to enable (1) or disable (0) scope autorestart.

Description The `xPCScSetAutoRestart` function sets the autorestart flag for scope *scNum* to 0 or 1. 0 disables the flag, 1 enables it. Use this function only when the scope is stopped.

See Also API functions `xPCScGetAutoRestart`

xPCScSetDecimation

Purpose Set decimation of scope

Prototype `void xPCScSetDecimation(int port, int scNum,
int decimation);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>decimation</i>	Enter an integer for the decimation.

Description The `xPCScSetDecimation` function sets the *decimation* of scope *scNum*. The decimation is a number, N, meaning every Nth sample is acquired in a scope window. Use this function only when the scope is stopped. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCScGetDecimation`, `xPCScGetState`
Property `Decimation` of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose Set number of pre- or posttriggering samples before triggering scope

Prototype `void xPCScSetNumPrePostSamples(int port, int scNum, int prepost);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>prepost</i>	A negative number means pretriggering, while a positive number means posttriggering. This function can only be used when the scope is stopped.

Description The `xPCScSetNumPrePostSamples` function sets the number of samples for pre- or posttriggering for scope *scNum* to *prepost*. Use this function only when the scope is stopped. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCScGetNumPrePostSamples`, `xPCScGetState`
Property `NumPrePostSamples` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScSetNumSamples

Purpose Set number of samples in one data acquisition cycle

Prototype `void xPCScSetNumSamples(int port, int scNum, int samples);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>samples</i>	Enter the number of samples you want to acquire in one cycle.

Description The `xPCScSetNumSamples` function sets the number of samples for scope *scNum* to *samples*. Use this function only when the scope is stopped. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScope` function to get the scope number.

See Also API functions `xPCScGetNumSamples`, `xPCScGetState`
Property `NumSamples` of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose

Set trigger level for scope

Prototype

```
void xPCScSetTriggerLevel(int port, int scNum,  
double level);
```

Arguments

<i>port</i>	Enter the value returned by either the function xPCOpenSerialPort or the function xPCOpenTcpIpPort.
<i>scNum</i>	Enter the scope number.
<i>level</i>	Value for a signal to trigger data acquisition with a scope.

Description

The xPCScSetTriggerLevel function sets the trigger level to *level* for scope *scNum*. Use this function only when the scope is stopped. Use xPCScGetState to check the state of the scope. Use the xPCGetScope function to get the scope number for the trigger scope.

See Also

API functions xPCScGetTriggerLevel, xPCScSetTriggerSlope, xPCScGetTriggerSlope, xPCScSetTriggerSignal, xPCScGetTriggerSignal, xPCScSetTriggerScope, xPCScGetTriggerScope, xPCScSetTriggerMode, xPCScGetTriggerMode, xPCScGetState

Property TriggerLevel of SimulinkRealTime.fileScope, SimulinkRealTime.hostScope, and SimulinkRealTime.targetScope

xPCScSetTriggerMode

Purpose Set trigger mode of scope

Prototype `void xPCScSetTriggerMode(int port, int scNum, int mode);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>mode</i>	Trigger mode for a scope.

Description The `xPCScSetTriggerMode` function sets the trigger mode of scope *scNum* to *mode*. Use this function only when the scope is stopped. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScopes` function to get a list of scopes.

Use the constants defined in `xpcapiconst.h` to interpret the trigger mode:

Constant	Value	Description
TRIGMD_FREERUN	0	There is no trigger mode. The scope triggers when it is ready to trigger, regardless of the circumstances. This is the default.
TRIGMD_SOFTWARE	1	Only user intervention can trigger the scope. No other triggering is possible.
TRIGMD_SIGNAL	2	The scope is triggered only after a signal has crossed a value.
TRIGMD_SCOPE	3	The scope is triggered by another scope at the trigger point of the triggering scope, modified by the value of <code>triggerscopesample</code> (see <code>scopedata</code>).

See Also

API functions `xPCGetScopes`, `xPCScSetTriggerLevel`,
`xPCScGetTriggerLevel`, `xPCScSetTriggerSlope`,
`xPCScGetTriggerSlope`, `xPCScSetTriggerSignal`,
`xPCScGetTriggerSignal`, `xPCScSetTriggerScope`,
`xPCScGetTriggerScope`, `xPCScGetTriggerMode`, `xPCScGetState`

Methods `SimulinkRealTime.fileScope.trigger`,
`SimulinkRealTime.hostScope.trigger`, and
`SimulinkRealTime.targetScope.trigger`

Property `TriggerMode` of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScSetTriggerScope

Purpose Select scope to trigger another scope

Prototype `void xPCScSetTriggerScope(int port, int scNum, int trigScope);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>trigScope</i>	Enter the scope number of the scope used for a trigger.

Description The `xPCScSetTriggerScope` function sets the trigger scope of scope *scNum* to *trigScope*. This function can only be used when the scope is stopped. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScopes` function to get a list of scopes.

The scope type can be `SCTYPE_HOST`, `SCTYPE_TARGET`, or `SCTYPE_FILE`.

See Also API functions `xPCGetScopes`, `xPCScSetTriggerLevel`, `xPCScGetTriggerLevel`, `xPCScSetTriggerSlope`, `xPCScGetTriggerSlope`, `xPCScSetTriggerSignal`, `xPCScGetTriggerSignal`, `xPCScGetTriggerScope`, `xPCScSetTriggerMode`, `xPCScGetTriggerMode`, `xPCScGetState`

Property `TriggerScope` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose Set sample number for triggering scope

Prototype `void xPCScSetTriggerScopeSample(int port, int scNum, int trigScSamp);`

Arguments

<code>port</code>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<code>scNum</code>	Enter the scope number.
<code>trigScSamp</code>	Enter a nonnegative integer for the number of samples acquired by the triggering scope before starting data acquisition on a second scope.

Description The `xPCScSetTriggerScopeSample` function sets the number of samples (`trigScSamp`) a triggering scope acquires before it triggers a second scope (`scNum`). Use the `xPCGetScopes` function to get a list of scopes.

For meaningful results, set `trigScSamp` between `-1` and `(nSamp-1)`. `nSamp` is the number of samples in one data acquisition cycle for the triggering scope. If you specify too large a value, the scope is never triggered.

If you want to trigger a second scope at the end of a data acquisition cycle for the triggering scope, enter a value of `-1` for `trigScSamp`.

See Also API functions `xPCGetScopes`, `xPCScSetTriggerLevel`, `xPCScGetTriggerLevel`, `xPCScSetTriggerSlope`, `xPCScGetTriggerSlope`, `xPCScSetTriggerSignal`, `xPCScGetTriggerSignal`, `xPCScSetTriggerScope`, `xPCScGetTriggerScope`, `xPCScSetTriggerMode`, `xPCScGetTriggerMode`, `xPCScGetTriggerScopeSample`

Property `TriggerSample` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScSetTriggerSignal

Purpose Select signal to trigger scope

Prototype `void xPCScSetTriggerSignal(int port, int scNum, int trigSig);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>trigSig</i>	Enter a signal number.

Description The `xPCScSetTriggerSignal` function sets the trigger signal of scope *scNum* to *trigSig*. The trigger signal *trigSig* must be one of the signals in the scope. Use this function only when the scope is stopped. You can use `xPCScGetSignals` to get the list of signals in the scope. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCScGetState`, `xPCScSetTriggerLevel`, `xPCScGetTriggerLevel`, `xPCScSetTriggerSlope`, `xPCScGetTriggerSlope`, `xPCScGetTriggerSignal`, `xPCScSetTriggerScope`, `xPCScGetTriggerScope`, `xPCScSetTriggerMode`, `xPCScGetTriggerMode`

Property `TriggerSignal` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose Set slope of signal that triggers scope

Prototype `void xPCScSetTriggerSlope(int port, int scNum, int trigSlope);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>trigSlope</i>	Enter the slope mode for the signal that triggers the scope.

Description The `xPCScSetTriggerSlope` function sets the trigger slope of scope *scNum* to *trigSlope*. Use this function only when the scope is stopped. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScopes` function to get a list of scopes.

Use the constants defined in `xpcapiconst.h` to set the trigger slope:

Constant	Value	Description
<code>TRIGSLOPE_EITHER</code>	0	The trigger slope can be either rising or falling.
<code>TRIGSLOPE_RISING</code>	1	The trigger signal value must be rising when it crosses the trigger value.
<code>TRIGSLOPE_FALLING</code>	2	The trigger signal value must be falling when it crosses the trigger value.

xPCScSetTriggerSlope

See Also

API functions `xPCGetScopes`, `xPCScSetTriggerLevel`,
`xPCScGetTriggerLevel`, `xPCScGetTriggerSlope`,
`xPCScSetTriggerSignal`, `xPCScGetTriggerSignal`,
`xPCScSetTriggerScope`, `xPCScGetTriggerScope`,
`xPCScSetTriggerMode`, `xPCScGetTriggerMode`, `xPCScGetState`

Property `TriggerSlope` of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose Set software trigger of scope

Prototype `void xPCScSoftwareTrigger(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Description The `xPCScSoftwareTrigger` function triggers scope *scNum*. The scope must be in the state `Waiting for trigger` for this function to succeed. Use `xPCScGetState` to check the state of the scope. Use the `xPCGetScopes` function to get a list of scopes.

Regardless of the trigger mode setting, you can use `xPCScSoftwareTrigger` to force a trigger. In trigger mode `Software`, this function is the only way to trigger the scope.

See Also API functions `xPCGetScopes`, `xPCScGetState`, `xPCIsScFinished`

Methods `SimulinkRealTime.fileScope.trigger`,
`SimulinkRealTime.hostScope.trigger`, and
`SimulinkRealTime.targetScope.trigger`

Property `TriggerMode` of `SimulinkRealTime.fileScope`,
`SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

xPCScStart

Purpose Start data acquisition for scope

Prototype `void xPCScStart(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Description The `xPCScStart` function starts or restarts the data acquisition of scope *scNum*. If the scope does not have to preacquire samples, it enters the `Waiting for Trigger` state. The scope must be in state `Waiting to Start`, `Finished`, or `Interrupted` for this function to succeed. Call `xPCScGetState` to check the state of the scope or, for host scopes that are already started, call `xPCIsScFinished`. Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCScGetState`, `xPCScStop`, `xPCIsScFinished`

Scope object method `SimulinkRealTime.fileScope.start`, `SimulinkRealTime.hostScope.start`, `SimulinkRealTime.targetScope.start`

Purpose Stop data acquisition for scope

Prototype `void xPCScStop(int port, int scNum);`

Arguments

port Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

scNum Enter the scope number.

Description The `xPCScStop` function stops the scope *scNum*. This sets the scope to the "Interrupted" state. The scope must be running for this function to succeed. Use `xPCScGetState` to determine the state of the scope. Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCScStart`, `xPCScGetState`

Scope object methods `SimulinkRealTime.fileScope.stop`,
`SimulinkRealTime.hostScope.stop`,
`SimulinkRealTime.targetScope.stop`

xPCSetEcho

Purpose Turn message display on or off

Prototype `void xPCSetEcho(int port, int mode);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>mode</i>	Valid values are
0	Turns the display off
1	Turns the display on

Description On the target computer screen, the `xPCSetEcho` function sets the message display on the target computer on or off. You can change the mode only when the target application is stopped. When you turn the message display off, the message screen no longer updates. Existing messages remain on the screen as they were.

See Also API function `xPCGetEcho`

Purpose Set last error to specific string constant

Prototype `void xPCSetLastError(int error);`

Arguments *error* Specify the string constant for the error.

Description The xPCSetLastError function sets the global error constant returned by xPCGetLastError to *error*. This is useful only to set the string constant to ENOERR, indicating no error was found.

See Also API functions xPCGetLastError, xPCErrorMsg

xPCSetLoadTimeOut

Purpose Change initialization timeout value between host computer and target computer

Prototype `void xPCSetLoadTimeOut(int port, int timeOut);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>timeOut</i>	Enter the new communication timeout value.

Description The `xPCSetLoadTimeOut` function changes the timeout value for communication between the host computer and target computer. The *timeOut* value is the time an Simulink Real-Time API function waits for the communication between the host computer and target computer to complete before returning. It enables you to set the number of communication attempts to be made before signaling a timeout.

For example, the function `xPCLoadApp` waits to check whether the model initialization for a new application is complete before returning. When a new target application is loaded onto the target computer, the function `xPCLoadApp` waits for a certain time to check whether the model initialization is complete before returning. If the model initialization is incomplete within the allotted time, `xPCLoadApp` returns a timeout error.

By default, `xPCLoadApp` checks for target readiness for up to 5 seconds. However, for larger models or models requiring longer initialization (for example, models with thermocouple boards), the default might not be long enough and a spurious timeout can be generated. Other functions that communicate with the target computer will wait for *timeOut* seconds before declaring a timeout event.

See Also API functions `xPCGetLoadTimeOut`, `xPCLoadApp`, `xPCUnloadApp`

Purpose	Set logging mode and increment value of scope				
Prototype	<code>void xPCSetLogMode(int <i>port</i>, lgmode <i>logging_data</i>);</code>				
Arguments	<table><tr><td><i>port</i></td><td>Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code>.</td></tr><tr><td><i>logging_data</i></td><td>Logging mode and increment value.</td></tr></table>	<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .	<i>logging_data</i>	Logging mode and increment value.
<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .				
<i>logging_data</i>	Logging mode and increment value.				
Description	The <code>xPCSetLogMode</code> function sets the logging mode and increment to the values set in <i>logging_data</i> . See the structure <code>lgmode</code> for more details.				
See Also	API function <code>xPCGetLogMode</code> API structure <code>lgmode</code> Property <code>LogMode</code> of <code>SimulinkRealTime.target</code>				

xPCSetParam

Purpose Change value of parameter

Prototype `void xPCSetParam(int port, int paramIdx, const double *paramValue);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>paramIdx</i>	Parameter index.
<i>paramValue</i>	Vector of doubles, assumed to be the size required by the parameter type

Description The `xPCSetParam` function sets the parameter *paramIdx* to the value in *paramValue*. For matrices, *paramValue* should be a vector representation of the matrix in column-major format. Although *paramValue* is a vector of doubles, the function converts the values to the expected data types (using truncation) before setting them.

See Also API functions `xPCGetParamDims`, `xPCGetParamIdx`, `xPCGetParam`

Purpose Change target application sample time

Prototype `void xPCSetSampleTime(int port, double ts);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>ts</i>	Sample time for the target application.

Description The `xPCSetSampleTime` function sets the sample time, in seconds, of the target application to *ts*. Use this function only when the application is stopped.

See Also API function `xPCGetSampleTime`
Property `SampleTime` of `SimulinkRealTime.target`

xPCSetScope

Purpose Set properties of scope

Prototype `void xPCSetScope(int port, scopedata state);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>state</i>	Enter a structure of type <code>scopedata</code> .

Description

Note The `xPCSetScope` function will be removed in a future release. Use the `xPCScSetScopePropertyName` functions to access property values instead. For example, to set the number of samples to acquire in one data acquisition cycle, use `xPCScSetNumSamples`.

The `xPCSetScope` function sets the properties of a scope using a *state* structure of type `scopedata`. Set the properties you want to set for the scope. You can set several properties at the same time. For convenience, call the function `xPCGetScope` first to populate the structure with the current values. You can then change the desired values. Use this function only when the scope is stopped. Use `xPCScGetState` to determine the state of the scope.

See Also

API functions `xPCGetScope`, `xPCScGetState`, `scopedata`

Scope object methods `SimulinkRealTime.fileScope.set`, `SimulinkRealTime.hostScope.set`, and `SimulinkRealTime.targetScope.set`

Purpose Change target application stop time

Prototype `void xPCSetStopTime(int port, double tfinal);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>tfinal</i>	Enter the stop time, in seconds.

Description The `xPCSetStopTime` function sets the stop time of the target application to the value in *tfinal*. The target application will run for this number of seconds before stopping. Set *tfinal* to -1.0 to set the stop time to infinity.

See Also API function `xPCGetStopTime`
Property `StopTime` of `SimulinkRealTime.target`

xPCStartApp

Purpose	Start target application		
Prototype	<code>void xPCStartApp(int <i>port</i>);</code>		
Arguments	<table><tr><td><i>port</i></td><td>Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code>.</td></tr></table>	<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .		
Description	The <code>xPCStartApp</code> function starts the target application loaded on the target computer.		
See Also	API function <code>xPCStopApp</code> Target object method <code>SimulinkRealTime.target.start</code>		

Purpose Stop target application

Prototype `void xPCStopApp(int port);`

Arguments *port* Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

Description The `xPCStopApp` function stops the target application loaded on the target computer. The target application remains loaded and the parameter changes you made remain intact. If you want to stop and unload an application, use `xPCUnloadApp`.

See Also API functions `xPCStartApp`, `xPCUnloadApp`
Target object method `SimulinkRealTime.target.stop`

xPCTargetPing

Purpose	Ping target computer		
Prototype	<code>int xPCTargetPing(int <i>port</i>);</code>		
Arguments	<table><tr><td><i>port</i></td><td>Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code>.</td></tr></table>	<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .		
Return	The <code>xPCTargetPing</code> function does not return an error status. This function returns 1 if the target responds. If the target computer does not respond, the function returns 0.		
Description	<p>The <code>xPCTargetPing</code> function pings the target computer and returns 1 or 0 depending on whether the target responds or not. This function returns an error string constant only when there is an error in the input parameter (for example, the port number is invalid or <i>port</i> is not open). Other errors, such as the inability to connect to the target, are ignored.</p> <p>If you are using TCP/IP, note that <code>xPCTargetPing</code> will cause the target computer to close the TCP/IP connection. You can use <code>xPCOpenConnection</code> to reconnect. You can also use this <code>xPCTargetPing</code> feature to close the target computer connection in the event of an aborted TCP/IP connection (for example, if your host side program crashes).</p>		
See Also	API functions <code>xPCOpenConnection</code> , <code>xPCOpenSerialPort</code> , <code>xPCOpenTcpIpPort</code> , <code>xPCClosePort</code>		

Purpose Get status of grid line for particular scope

Prototype `int xPCTgScGetGrid(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return Returns the status of the grid for a scope of type `SCTYPE_TARGET`. If the function detects an error, it returns -1.

Description The `xPCTgScGetGrid` function gets the state of the grid lines for scope *scNum* (which must be of type `SCTYPE_TARGET`). A return value of 1 implies grid on, while 0 implies grid off. Note that when the scope mode is set to `SCMODE_NUMERICAL`, the grid is not drawn even when the grid mode is set to 1.

Tip

- Use `xPCTgScSetMode` and `xPCTgScGetMode` to set and retrieve the scope mode.
 - Use `xPCGetScopes` to get a list of scopes.
-

See Also API functions `xPCGetScopes`, `xPCTgScSetGrid`, `xPCTgScSetViewMode`, `xPCTgScGetViewMode`, `xPCTgScSetMode`, `xPCTgScGetMode`, `xPCTgScSetYLimits`, `xPCTgScGetYLimits`

xPCTgScGetMode

Purpose Get scope mode for displaying signals

Prototype `int xPCTgScGetMode(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Return The `xPCTgScGetMode` function returns the value corresponding to the scope mode. The possible values are

- `SCMODE_NUMERICAL = 0`
- `SCMODE_REDRAW = 1`
- `SCMODE_SLIDING = 2`
- `SCMODE_ROLLING = 3`

If this function detects an error, it returns -1.

Description The `xPCTgScGetMode` function gets the mode (`SCMODE_NUMERICAL`, `SCMODE_REDRAW`, `SCMODE_SLIDING`, `SCMODE_ROLLING`) of the scope *scNum*, which must be of type `SCTYPE_TARGET`. Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCTgScSetGrid`, `xPCTgScGetGrid`, `xPCTgScSetViewMode`, `xPCTgScGetViewMode`, `xPCTgScSetMode`, `xPCTgScSetYLimits`, `xPCTgScGetYLimits`

Property `DisplayMode` of `SimulinkRealTime.fileScope`, `SimulinkRealTime.hostScope`, and `SimulinkRealTime.targetScope`

Purpose	Get view mode for target computer display
Prototype	<code>int xPCTgScGetViewMode(int <i>port</i>);</code>
Arguments	<i>port</i> Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
Return	The <code>xPCTgScGetViewMode</code> function returns the view mode for the target computer screen. If the function detects an error, it returns -1.
Description	The <code>xPCTgScGetViewMode</code> function gets the view (zoom) mode for the target computer display. If the returned value is not zero, the number is that of the scope currently displayed on the screen. If the value is 0, then all defined scopes are displayed on the target computer screen, but no scopes are in focus (all scopes are unzoomed).
See Also	API functions <code>xPCGetScopes</code> , <code>xPCTgScSetGrid</code> , <code>xPCTgScGetGrid</code> , <code>xPCTgScSetViewMode</code> , <code>xPCTgScSetMode</code> , <code>xPCTgScGetMode</code> , <code>xPCTgScSetYLimits</code> , <code>xPCTgScGetYLimits</code> Property <code>ViewMode</code> of <code>SimulinkRealTime.target</code>

xPCTgScGetYLimits

Purpose Copy *y*-axis limits for scope to array

Prototype `void xPCTgScGetYLimits(int port, int scNum, double *limits);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>limits</i>	The first element of the array is the lower limit while the second element is the upper limit.

Description The `xPCTgScGetYLimits` function gets and copies the upper and lower limits for a scope of type `SCTYPE_TARGET` and with scope number *scNum*. The limits are stored in the array *limits*. If both elements are zero, the limits are autoscaled. Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCTgScSetGrid`, `xPCTgScGetGrid`, `xPCTgScSetViewMode`, `xPCTgScGetViewMode`, `xPCTgScSetMode`, `xPCTgScGetMode`, `xPCTgScSetYLimits`

Property `Ylimit` of `SimulinkRealTime.targetScope`

Purpose Set grid mode for scope

Prototype `void xPCTgScSetGrid(int port, int scNum, int grid);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>grid</i>	Enter a grid value.

Description The `xPCTgScSetGrid` function sets the grid of a scope of type `SCTYPE_TARGET` and scope number *scNum* to *grid*. If *grid* is 0, the grid is off. If *grid* is 1, the grid is on and grid lines are drawn on the scope window. When the drawing mode of scope *scNum* is set to `SCMODE_NUMERICAL`, the grid is not drawn even when the grid mode is set to 1. Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCTgScGetGrid`, `xPCTgScSetViewMode`, `xPCTgScGetViewMode`, `xPCTgScSetMode`, `xPCTgScGetMode`, `xPCTgScSetYLimits`, `xPCTgScGetYLimits`

Scope object property `Grid`

xPCTgScSetMode

Purpose Set display mode for scope

Prototype `void xPCTgScSetMode(int port, int scNum, int mode);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.
<i>mode</i>	Enter the value for the mode.

Description The `xPCTgScSetMode` function sets the mode of a scope of type `SCTYPE_TARGET` and scope number *scNum* to *mode*. You can use one of the following constants for *mode*:

- `SCMODE_NUMERICAL = 0`
- `SCMODE_REDRAW = 1`
- `SCMODE_SLIDING = 2`
- `SCMODE_ROLLING = 3`

Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCTgScSetGrid`, `xPCTgScGetGrid`, `xPCTgScSetViewMode`, `xPCTgScGetViewMode`, `xPCTgScGetMode`, `xPCTgScSetYLimits`, `xPCTgScGetYLimits`

Property `DisplayMode` of `SimulinkRealTime.targetScope`

Purpose Set view mode for scope

Prototype `void xPCTgScSetViewMode(int port, int scNum);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
<i>scNum</i>	Enter the scope number.

Description The `xPCTgScSetViewMode` function sets the target computer screen to display one scope with scope number *scNum*. If you set *scNum* to 0, the target computer screen displays all the defined scopes. Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCTgScSetGrid`, `xPCTgScGetGrid`, `xPCTgScGetViewMode`, `xPCTgScSetMode`, `xPCTgScGetMode`, `xPCTgScSetYLimits`, `xPCTgScGetYLimits`

Property `ViewMode` of `SimulinkRealTime.target`

xPCTgScSetYLimits

Purpose Set *y*-axis limits for scope

Prototype `void xPCTgScSetYLimits(int port, int scNum, const double *YLimits);`

Arguments

port Enter the value returned by either the function `xPCOpenSerialPort` or the function `xPCOpenTcpIpPort`.

scNum Enter the scope number.

YLimits Enter a two-element array.

Description The `xPCTgScSetYLimits` function sets the *y*-axis limits for a scope with scope number *scNum* and type `SCTYPE_TARGET` to the values in the double array *YLimits*. The first element is the lower limit, and the second element is the upper limit. Set both limits to `0.0` to specify autoscaling. Use the `xPCGetScopes` function to get a list of scopes.

See Also API functions `xPCGetScopes`, `xPCTgScSetGrid`, `xPCTgScGetGrid`, `xPCTgScSetViewMode`, `xPCTgScGetViewMode`, `xPCTgScSetMode`, `xPCTgScGetMode`, `xPCTgScGetYLimits`

Property `Ylimit` of `SimulinkRealTime.targetScope`

Purpose Unload target application

Prototype `void xPCUnloadApp(int port);`

Arguments

<i>port</i>	Enter the value returned by either the function <code>xPCOpenSerialPort</code> or the function <code>xPCOpenTcpIpPort</code> .
-------------	--

Description The `xPCUnloadApp` function stops the current target application, removes it from the target computer memory, and resets the target computer in preparation for receiving a new target application. The function `xPCLoadApp` calls this function before loading a new target application.

See Also API function `xPCLoadApp`
Target object methods `SimulinkRealTime.target.load`,
`SimulinkRealTime.target.unload`

xPCUnloadApp

Simulink Real-Time API Reference for COM

COM API Methods – Alphabetical List

Purpose	Type definition for file system folder information structure	
Syntax	<pre>typedef struct { BSTR <i>Name</i>; BSTR <i>Date</i>; BSTR <i>Time</i>; long <i>Bytes</i>; long <i>isdir</i>; } FSDir;</pre>	
Fields	<i>Name</i>	This value contains the name of the file or folder.
	<i>Date</i>	This value contains the date the file or folder was last modified.
	<i>Time</i>	This value contains the time the file or folder was last modified.
	<i>Bytes</i>	This value contains the size of the file in bytes. If the element is a folder, this value is 0.
	<i>isdir</i>	This value indicates if the element is a file (0) or folder (1). If it is a folder, <i>Bytes</i> has a value of 0.
Description	The FSDir structure contains information for a folder in the file system.	
See Also	API method <code>xPCFileSystem.DirList</code>	

FSDiskInfo

Purpose Type definition for file system disk information structure

Syntax

```
typedef struct {
    BSTR Label;
    BSTR DriveLetter;
    BSTR Reserved;
    long SerialNumber;
    long FirstPhysicalSector;
    long FATType;
    long FATCount;
    long MaxDirEntries;
    long BytesPerSector;
    long SectorsPerCluster;
    long TotalClusters;
    long BadClusters;
    long FreeClusters;
    long Files;
    long FileChains;
    long FreeChains;
    long LargestFreeChain;
} FSDiskInfo;
```

Fields

<i>Label</i>	This value contains the zero-terminated string that contains the volume label. The string is empty if the volume has no label.
<i>DriveLetter</i>	This value contains the drive letter, in uppercase.
<i>Reserved</i>	Reserved.
<i>SerialNumber</i>	This value contains the volume serial number.
<i>FirstPhysicalSector</i>	This value contains the logical block address (LBA) of the logical drive boot record. For 3.5-inch disks, this value is 0.

<i>FATType</i>	This value contains the type of file system found. It can contain 12 , 16 , or 32 for FAT-12, FAT-16, or FAT-32 volumes, respectively.
<i>FATCount</i>	This value contains the number of FAT partitions on the volume.
<i>MaxDirEntries</i>	This value contains the size of the root folder. For FAT-32 systems, this value is 0.
<i>BytesPerSector</i>	This value contains the sector size. This value is most likely to be 512.
<i>SectorsPerCluster</i>	This value contains, in sectors, the size of the smallest unit of storage that can be allocated to a file.
<i>TotalClusters</i>	This value contains the number of file storage clusters on the volume.
<i>BadClusters</i>	This value contains the number of clusters that have been marked as bad. These clusters are unavailable for file storage.
<i>FreeClusters</i>	This value contains the number of clusters that are currently available for storage.
<i>Files</i>	This value contains the number of files, including folders, on the volume. This number excludes the root folder and files that have an allocated file size of 0.
<i>FileChains</i>	This value contains the number of contiguous cluster chains. On a completely unfragmented volume, this value is identical to the value of <i>Files</i> .

FSDiskInfo

<i>FreeChains</i>	This value contains the number of contiguous cluster chains of free clusters. On a completely unfragmented volume, this value is 1.
<i>LargestFreeChain</i>	This value contains the maximum allocated file size, in number of clusters, for a newly allocated contiguous file. On a completely unfragmented volume, this value is identical to <i>FreeClusters</i> .

Description The FSDiskInfo structure contains information for file system disks.

See Also API method `xPCFileSystem.GetDiskInfo`

Purpose	Change current folder on target computer to specified path
Prototype	<code>long CD(BSTR <i>dir</i>);</code>
Member Of	XPCAPICOMLib.xPCFileSystem
Arguments	[in] <i>dir</i> Enter the path on the target computer to change to.
Return	If the method detects an error, it returns -1. Otherwise, the method returns 0.
Description	The xPCFileSystem.CD method changes the current folder on the target computer to the path specified in <i>dir</i> . Use the xPCFileSystem.PWD method to show the current folder of the target computer.
See Also	API method xPCFileSystem.PWD

xPCFileSystem.CloseFile

Purpose	Close file on target computer		
Prototype	<code>CloseFile(long <i>filehandle</i>);</code>		
Member Of	XPCAPICOMLib.xPCFileSystem		
Arguments	<table><tr><td><code>[in] <i>filehandle</i></code></td><td>Enter the file handle of an open file on the target computer.</td></tr></table>	<code>[in] <i>filehandle</i></code>	Enter the file handle of an open file on the target computer.
<code>[in] <i>filehandle</i></code>	Enter the file handle of an open file on the target computer.		
Return	If the method detects an error, it returns -1. Otherwise, the method returns 0.		
Description	The <code>xPCFileSystem.CloseFile</code> method closes the file associated with <i>fileHandle</i> on the target computer. <i>fileHandle</i> is the handle of a file previously opened by the <code>xPCFileSystem.OpenFile</code> method.		
See Also	API methods <code>xPCFileSystem.OpenFile</code> , <code>xPCFileSystem.ReadFile</code> , <code>xPCFileSystem.WriteFile</code>		

Purpose Return contents of target computer folder

Prototype DirList(BSTR *path*);

Member Of XPCAPICOMLib.xPCFileSystem

Arguments [in] *path* Enter the path of the folder.

Description The xPCFileSystem.DirList method returns the contents of the target computer folder specified by *path* as an array of the FSDir structure.

See Also API structure FSDir
API method xPCFileSystem.GetDiskInfo

xPCFileSystem.GetDiskInfo

Purpose	Return disk information
Prototype	GetDiskInfo(BSTR <i>driveLetter</i>);
Member Of	XPCAPICOMLib.xPCFileSystem
Arguments	[in] <i>driveLetter</i> Enter the driver letter that contains the file system.
Description	The xPCFileSystem.GetDiskInfo method accepts as input the drive specified by <i>driveLetter</i> and fills in the fields of the FSDiskInfo structure.
See Also	API structure FSDiskInfo API method xPCFileSystem.DirList

Purpose	Return size of file on target computer		
Prototype	<code>long GetFileSize(long <i>filehandle</i>);</code>		
Member Of	XPCAPICOMLib.xPCFileSystem		
Arguments	<table><tr><td><code>[in] <i>filehandle</i></code></td><td>Enter the file handle of an open file on the target computer.</td></tr></table>	<code>[in] <i>filehandle</i></code>	Enter the file handle of an open file on the target computer.
<code>[in] <i>filehandle</i></code>	Enter the file handle of an open file on the target computer.		
Return	This method returns the size of the specified file in bytes.		
Description	The <code>xPCFileSystem.GetFileSize</code> method returns the size, in bytes, of the file associated with <i>filehandle</i> on the target computer. <i>filehandle</i> is the handle of a file previously opened by the <code>xPCFileSystem.OpenFile</code> method.		
See Also	API methods <code>xPCFileSystem.OpenFile</code> , <code>xPCFileSystem.ReadFile</code>		

xPCFileSystem.Init

Purpose Initialize file system object to communicate with target computer

Prototype `long Init(IxPCProtocol* xPCProtocol);`

Member Of XPCAPICOMLib.xPCFileSystem

Arguments

[in] xPCProtocol	Specify the communication port of the target computer object for which the file system is to be initialized.
------------------	--

Return If the method detects an error, it returns -1. Otherwise, the xPCFileSystem.Init method returns 0.

Description The xPCFileSystem.Init method initializes the file system object to communicate with the target computer referenced by the xPCProtocol object.

Purpose	Create folder on target computer
Prototype	long MKDIR(BSTR <i>dirname</i>);
Member Of	XPCAPICOMLib.xPCFileSystem
Arguments	[in] <i>dirname</i> Enter the name of the folder to create on the target computer.
Return	If the method detects an error, it returns -1. Otherwise, the method returns 0.
Description	The xPCFileSystem.MKDIR method creates the folder <i>dirname</i> in the current folder of the target computer.
See Also	API method xPCFileSystem.PWD

xPCFileSystem.OpenFile

Purpose Open file on target computer

Prototype `long OpenFile(BSTR filename, BSTR permission);`

Member Of XPCAPICOMLib.xPCFileSystem

Arguments

[in] <i>filename</i>	Enter the name of the file to open on the target computer.
[in] <i>permission</i>	Enter the read/write permission with which to open the file. Values are r (read) or w (read/write).

Return The xPCFileSystem.OpenFile method returns the file handle for the opened file.

Description The xPCFileSystem.OpenFile method opens the specified file, *filename*, on the target computer. If the file does not exist, the xPCFileSystem.OpenFile method creates *filename*, then opens it. You can open a file for read or read/write access.

Note Opening the file for write access overwrites the existing contents of the file. It does not append the new data.

See Also API methods xPCFileSystem.CloseFile, xPCFileSystem.GetFileSize, xPCFileSystem.ReadFile, xPCFileSystem.WriteFile

Purpose	Get current folder of target computer
Prototype	BSTR PWD();
Member Of	XPCAPICOMLib.xPCFileSystem
Return	This method returns the path of the current folder on the target computer.
Description	The xPCFileSystem.PWD method places the path of the current folder on the target computer.
See Also	API method xPCFileSystem.CD

xPCFileSystem.ReadFile

Purpose	Read open file on target computer						
Prototype	VARIANT ReadFile(int <i>fileHandle</i> , int <i>start</i> , int <i>numbytes</i>);						
Member Of	XPCAPICOMLib.xPCFileSystem						
Arguments	<table><tr><td>[in] <i>fileHandle</i></td><td>Enter the file handle of an open file on the target computer.</td></tr><tr><td>[in] <i>start</i></td><td>Enter an offset from the beginning of the file from which this method can start to read.</td></tr><tr><td>[in] <i>numbytes</i></td><td>Enter the number of bytes this method is to read from the file.</td></tr></table>	[in] <i>fileHandle</i>	Enter the file handle of an open file on the target computer.	[in] <i>start</i>	Enter an offset from the beginning of the file from which this method can start to read.	[in] <i>numbytes</i>	Enter the number of bytes this method is to read from the file.
[in] <i>fileHandle</i>	Enter the file handle of an open file on the target computer.						
[in] <i>start</i>	Enter an offset from the beginning of the file from which this method can start to read.						
[in] <i>numbytes</i>	Enter the number of bytes this method is to read from the file.						
Return	This method returns the results of the read operation as a VARIANT of type Byte. If the method detects an error, it returns VT_ERROR, whose value is 10, instead.						
Description	The xPCFileSystem.ReadFile method reads an open file on the target computer and returns the results of the read operation as a VARIANT of type Byte. <i>fileHandle</i> is the file handle of a file previously opened by xPCFileSystem.OpenFile. You can specify that the read operation begin at the beginning of the file (default) or at a certain offset into the file (<i>start</i>). The <i>numbytes</i> parameter specifies how many bytes the xPCFileSystem.ReadFile method is to read from the file.						
See Also	API methods xPCFileSystem.CloseFile, xPCFileSystem.GetFileSize, xPCFileSystem.OpenFile, xPCFileSystem.WriteFile						

Purpose	Remove file from target computer
Prototype	long RemoveFile(BSTR <i>filename</i>);
Member Of	XPCAPICOMLib.xPCFileSystem
Arguments	[in] <i>filename</i> Enter the name of a file on the target computer.
Return	If the method detects an error, it returns -1. Otherwise, the method returns 0.
Description	The xPCFileSystem.RemoveFile method removes the file named <i>filename</i> from the target computer file system. <i>filename</i> can be a relative or absolute path name on the target computer.

xPCFileSystem.RMDIR

Purpose Remove folder from target computer

Prototype long RMDIR(BSTR *dirname*);

Member Of XPCAPICOMLib.xPCFileSystem

Arguments [in] *dirname* Enter the name of a folder on the target computer.

Return If the method detects an error, it returns -1. Otherwise, the method returns 0.

Description The xPCFileSystem.RMDIR method removes a folder named *dirname* from the target computer file system. *dirname* can be a relative or absolute path name on the target computer.

Purpose	Get name of file for scope
Prototype	BSTR ScGetFileName(long <i>scNum</i>);
Member Of	XPCAPICOMLib.xPCFileSystem
Arguments	[in] <i>scNum</i> Enter the scope number.
Return	Returns the name of the file for the scope.
Description	The xPCFileSystem.ScGetFileName method returns the name of the file to which scope <i>scNum</i> will save signal data.
See Also	API method xPCFileSystem.ScSetFileName

xPCFileSystem.ScGetWriteMode

Purpose Get write mode of file for scope

Prototype `long ScGetWriteMode(long scNum);`

Member Of XPCAPICOMLib.xPCFileSystem

Arguments [in] *scNum* Enter the scope number.

Return This method returns the number indicating the write mode. Values are

- 0 Lazy mode. The FAT entry is updated only when the file is closed and not during each file write operation. This mode is faster, but if the system crashes before the file is closed, the file system might not have the actual file size (the file contents, however, will be intact).
- 1 Commit mode. Each file write operation simultaneously updates the FAT entry for the file. This mode is slower, but the file system maintains the actual file size.

Description The `xPCFileSystem.ScGetWriteMode` method returns the write mode of the file for the scope.

See Also API method `xPCFileSystem.ScSetWriteMode`

Purpose	Get block write size of data chunks		
Prototype	<code>long ScGetWriteSize(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLib.xPCFileSystem		
Arguments	<table><tr><td><code>[in] <i>scNum</i></code></td><td>Enter the scope number.</td></tr></table>	<code>[in] <i>scNum</i></code>	Enter the scope number.
<code>[in] <i>scNum</i></code>	Enter the scope number.		
Return	This method returns the block size, in bytes, of the data chunks.		
Description	The <code>xPCFileSystem.ScGetWriteSize</code> method gets the block size, in bytes, of the data chunks.		
See Also	API method <code>xPCFileSystem.ScSetWriteSize</code>		

xPCFileSystem.ScSetFileName

Purpose Specify file name to contain signal data

Prototype `long ScSetFileName(long scNum, BSTR filename);`

Member Of XPCAPICOMLib.xPCFileSystem

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>filename</i>	Enter the name of a file to contain the signal data.

Return If the method detects an error, it returns -1. Otherwise, the method returns 0.

Description The `xPCFileSystem.ScSetFileName` method sets the name of the file to which the scope will save the signal data. The Simulink Real-Time software creates this file in the target computer file system. Note that you can only call this method when the scope is stopped.

See Also API method `xPCFileSystem.ScGetFileName`

Purpose Specify when file allocation table entry is updated

Prototype `long ScSetWriteMode(long scNum, long writeMode);`

Member Of XPCAPICOMLib.xPCFileSystem

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>writeMode</i>	Enter an integer for the write mode:
0	Enables lazy write mode
1	Enables commit write mode

Return If the method detects an error, it returns -1. Otherwise, the method returns 0.

Description The `xPCFileSystem.ScSetWriteMode` method specifies when a file allocation table (FAT) entry is updated. Both modes write the signal data to the file, as follows:

- 0 Lazy mode. The FAT entry is updated only when the file is closed and not during each file write operation. This mode is faster, but if the system crashes before the file is closed, the file system might not have the actual file size (the file contents, however, will be intact).
- 1 Commit mode. Each file write operation simultaneously updates the FAT entry for the file. This mode is slower, but the file system maintains the actual file size.

See Also API method `xPCFileSystem.ScSetWriteMode`
Scope object property `Mode`

xPCFileSystem.ScSetWriteSize

Purpose Specify that memory buffer collect data in multiples of write size

Prototype `long ScSetWriteSize(long scNum, long writeSize);`

Member Of XPCAPICOMLib.xPCFileSystem

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>writeSize</i>	Enter the block size, in bytes, of the data chunks.

Return If the method detects an error, it returns -1. Otherwise, the method returns 0.

Description The `xPCFileSystem.ScSetWriteSize` method specifies that a memory buffer collect data in multiples of *writeSize*. By default, this parameter is 512 bytes, which is the typical disk sector size. Using a block size that is the same as the disk sector size provides better performance. *writeSize* must be a multiple of 512.

See Also API method `xPCFileSystem.ScGetWriteSize`
Scope object property `WriteSize`

Purpose	Write to file on target computer						
Prototype	<code>long WriteFile(long <i>fileHandle</i>, long <i>numbytes</i>, VARIANT <i>buffer</i>);</code>						
Member Of	XPCAPICOMLib.xPCFileSystem						
Arguments	<table><tr><td>[in] <i>fileHandle</i></td><td>Enter the file handle of an open file on the target computer.</td></tr><tr><td>[in] <i>numbytes</i></td><td>Enter the number of bytes this method is to write into the file.</td></tr><tr><td>[in] <i>buffer</i></td><td>The contents to write to <i>fileHandle</i> are stored in <i>buffer</i>.</td></tr></table>	[in] <i>fileHandle</i>	Enter the file handle of an open file on the target computer.	[in] <i>numbytes</i>	Enter the number of bytes this method is to write into the file.	[in] <i>buffer</i>	The contents to write to <i>fileHandle</i> are stored in <i>buffer</i> .
[in] <i>fileHandle</i>	Enter the file handle of an open file on the target computer.						
[in] <i>numbytes</i>	Enter the number of bytes this method is to write into the file.						
[in] <i>buffer</i>	The contents to write to <i>fileHandle</i> are stored in <i>buffer</i> .						
Return	If the method detects an error, it returns -1. Otherwise, the method returns 0.						
Description	The xPCFileSystem.WriteFile method writes the contents of the VARIANT <i>buffer</i> , of type Byte, to the file specified by <i>fileHandle</i> on the target computer. The <i>fileHandle</i> parameter is the handle of a file previously opened by xPCFSOpenFile. <i>numbytes</i> is the number of bytes to write to the file.						
See Also	API methods xPCFileSystem.CloseFile, xPCFileSystem.GetFileSize, xPCFileSystem.OpenFile, xPCFileSystem.ReadFile						

xPCProtocol.Close

Purpose	Close RS-232 or TCP/IP communication connection
Prototype	long Close();
Member Of	XPCAPICOMLib.xPCProtocol
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.
Description	The xPCProtocol.Close method closes the communication channel opened by xPCProtocol.RS232Connect or xPCProtocol.TcpIpConnect.

Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.

Purpose	Return current timeout value for target application initialization
Prototype	<code>long GetLoadTimeOut();</code>
Member Of	<code>XPCAPICOMLib.xPCProtocol</code>
Return	If the method detects an error, it returns -1. Otherwise, it returns the number of seconds allowed for the initialization of the target application.
Description	<p>The <code>xPCProtocol.GetLoadTimeOut</code> method returns the number of seconds allowed for the initialization of the target application.</p> <p>When you load a new target application onto the target computer, the method <code>xPCTarget.LoadApp</code> waits for a certain amount of time before checking to see whether the initialization of the target application is complete. In the case where initialization of the target application is not complete, the method <code>xPCTarget.LoadApp</code> returns a timeout error. By default, <code>xPCTarget.LoadApp</code> checks five times to see whether the target application is ready, with each attempt taking about 1 second. However, for larger models or models requiring longer initialization (for example, those with thermocouple boards), the default might not be long enough and a spurious timeout is generated. The method <code>xPCProtocol.SetLoadTimeOut</code> sets the timeout to a different number.</p> <p>Use the <code>xPCProtocol.GetLoadTimeOut</code> method if you suspect that the current number of seconds (the timeout value) is too short. Then use the <code>xPCProtocol.SetLoadTimeOut</code> method to set the timeout to a higher number.</p>

xPCProtocol.GetxPCErrorMsg

Purpose	Return error string
Prototype	BSTR GetxPCErrorMsg();
Member Of	XPCAPICOMLib.xPCProtocol
Return	If the xPCProtocol.GetxPCErrorMsg method completes without detecting an error, it returns the string for the last reported error.
Description	The xPCProtocol.GetxPCErrorMsg method returns the string of the last error reported by another COM API method. This value is reset every time you call a new method. Therefore, you should check this constant value immediately after a call to an API COM method. You can use this method in conjunction with the xPCProtocol.isxPCError method, which detects that an error has occurred.
See Also	API function xPCProtocol.isxPCError

Purpose	Initialize Simulink Real-Time API DLL
Prototype	<code>long Init();</code>
Member Of	<code>XPCAPICOMLib.xPCProtocol</code>
Return	If the Simulink Real-Time DLL, <code>xpcapi.dll</code> loads without causing <code>xPCProtocol.Init</code> to detect an error, the method returns 0. If <code>xpcapi.dll</code> fails to load, this method returns -1.
Description	<p>The <code>xPCProtocol.Init</code> method initializes the Simulink Real-Time API by loading the Simulink Real-Time DLL, <code>xpcapi.dll</code>, into memory. To load <code>xpcapi.dll</code> into memory, the method requires that the <code>xpcapi.dll</code> file be in one of the following folders:</p> <ul style="list-style-type: none">• The folder in which the application is loaded• The current folder• The Windows system folder

xPCProtocol.isPCError

Purpose	Return error status
Prototype	<code>long isPCError();</code>
Member Of	XPCAPICOMLIB.xPCProtocol
Return	If an error occurred, the method returns 1. Otherwise, it returns 0.
Description	Use the <code>xPCProtocol.isPCError</code> method to check for errors that might occur after a call to the <code>xPCProtocol</code> class methods. If the method detects that an error occurred, call the <code>xPCProtocol.GetPCErrorMsg</code> to get the string for the error.
See Also	API function <code>xPCProtocol.GetPCErrorMsg</code>

Purpose	Contain communication channel index
Prototype	long Port();
Member Of	XPCAPICOMLIB.xPCProtocol
Return	If the method detects an error, it returns a nonpositive number. Otherwise, it returns a positive number (the communication channel index).
Description	The xPCProtocol.Port property contains the communication channel index if connection with the target computer succeeds. Note that you only need to use this property when working with a model-specific COM library that you generate from a Simulink model.

xPCProtocol.Reboot

Purpose	Reboot target computer
Prototype	long Reboot();
Member Of	XPCAPICOMLib.xPCProtocol
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.
Description	The xPCProtocol.Reboot method reboots the target computer. This function does not close the connection to the target computer. You should explicitly close the connection, then reestablish the connection once the target computer has rebooted. Use the methods xPCProtocol.RS232Connect or xPCProtocol.TcpIpConnect to reestablish the connection.

Purpose	Open RS-232 connection to target computer				
Prototype	<code>long RS232Connect(long <i>comport</i>, long <i>baudrate</i>);</code>				
Member Of	XPCAPICOMLib.xPCProtocol				
Arguments	<table><tr><td>[in] <i>comport</i></td><td>Index of the COM port to be used (0 is COM1, 1 is COM2, and so forth).</td></tr><tr><td>[in] <i>baudrate</i></td><td><i>baudrate</i> must be one of the following values: 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200.</td></tr></table>	[in] <i>comport</i>	Index of the COM port to be used (0 is COM1, 1 is COM2, and so forth).	[in] <i>baudrate</i>	<i>baudrate</i> must be one of the following values: 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200.
[in] <i>comport</i>	Index of the COM port to be used (0 is COM1, 1 is COM2, and so forth).				
[in] <i>baudrate</i>	<i>baudrate</i> must be one of the following values: 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200.				
Return	The <code>xPCProtocol.RS232Connect</code> method returns the port value for the connection. If the method detects an error, it returns 0. Otherwise, it returns -1.				
Description	<p>The <code>xPCProtocol.RS232Connect</code> method initiates an RS-232 connection to an Simulink Real-Time system. It returns the port value for the connection. Be sure to pass this value to every Simulink Real-Time API function that requires a port value.</p> <p>If you enter a value of 0 for <i>baudrate</i>, this function sets the baud rate to the default value (115200).</p>				

Note RS-232 Host-Target communication mode will be removed in a future release. Use TCP/IP instead.

xPCProtocol.SetLoadTimeOut

Purpose Change initialization timeout value

Prototype `long SetLoadTimeOut(long timeOut);`

Member Of XPCAPICOMLib.xPCProtocol

Arguments [in] *timeOut* Enter the new initialization timeout value.

Return If the method detects an error, it returns 0. Otherwise, it returns -1. To get the string description for the error, use `xPCProtocol.GetxPCErrorMsg`.

Description The `xPCProtocol.SetLoadTimeOut` method changes the timeout value for initialization. The *timeOut* value is the time the method `xPCTarget.LoadApp` waits to check whether the model initialization for a new application is complete before returning. It enables you to set the number of initialization attempts to be made before signaling a timeout. When a new target application is loaded onto the target computer, the method `xPCTarget.LoadApp` waits for a certain time to check whether the model initialization is complete before returning. If the model initialization is incomplete within the allotted time, `xPCTarget.LoadApp` returns a timeout error.

By default, `xPCTarget.LoadApp` checks for target readiness five times, with each attempt taking approximately 1 second (less if the target is ready). However, for larger models or models requiring longer initialization (for example, those with thermocouple boards), the default might not be long enough and a spurious timeout can be generated.

Purpose	Ping target computer
Prototype	long TargetPing;
Member Of	XPCAPICOMLIB.xPCProtocol
Return	The xPCProtocol.TargetPing method does not return an error status. This method returns 1 if it reaches the target computer and the computer responds. If the target computer does not respond, the method returns 0.
Description	<p>The xPCProtocol.TargetPing method pings the target computer and returns 1 or 0 depending on whether the target responds or not. Errors such as the inability to connect to the target are ignored.</p> <p>If you are using TCP/IP, note that xPCProtocol.TargetPing will cause the target computer to close the TCP/IP connection. You can use xPCProtocol.TcpIpConnect to reconnect. You can also use this xPCProtocol.TargetPing feature to close the target computer connection in the event of an aborted TCP/IP connection (for example, if your host side program crashes).</p>

xPCProtocol.TcpIpConnect

Purpose	Open TCP/IP connection to target computer	
Prototype	long TcpIpConnect(BSTR <i>TargetIpAddress</i> , BSTR <i>TargetPort</i>);	
Member Of	XPCAPICOMLIB.xPCProtocol	
Arguments	[in] <i>TargetIpAddress</i>	Enter the IP address of the target as a dotted decimal string. For example, "192.168.0.10".
	[in] <i>TargetPort</i>	Enter the associated IP port as a string. For example, "22222".
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.	
Description	The xPCProtocol.TcpIpConnect method opens a connection to the TCP/IP location specified by the IP address. Use this integer as the <i>TargetPort</i> variable in the Simulink Real-Time COM API functions that require a port value.	

Purpose	Unload Simulink Real-Time API DLL from memory
Prototype	<code>long Term();</code>
Member Of	<code>XPCAPICOMLib.xPCProtocol</code>
Return	The <code>xPCProtocol.Term</code> method always returns -1.
Description	The <code>xPCProtocol.Term</code> method unloads the Simulink Real-Time API DLL (<code>xpcapi.dll</code>) from memory. You must call this method when you want to terminate your COM API application.

xPCScopes.AddFileScope

Purpose	Create new file scope
Prototype	<code>long AddFileScope(long scNum);</code>
Member Of	XPCAPICOMLib.xPCScopes
Arguments	[in] <i>scNum</i> Enter a number for a new scope. Values are 1, 2, 3. . .
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.
Description	<p>The <code>xPCScopes.AddFileScope</code> method creates a new file scope on the target computer.</p> <p>Calling the <code>xPCScopes.AddFileScope</code> method with <i>scNum</i> having the number of an existing scope produces an error. Use <code>xPCScopes.GetScopes</code> to find the numbers of existing scopes.</p>

Purpose	Create new host scope		
Prototype	<code>long AddHostScope(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLib.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter a number for a new scope. Values are 1, 2, 3. . .</td></tr></table>	[in] <i>scNum</i>	Enter a number for a new scope. Values are 1, 2, 3. . .
[in] <i>scNum</i>	Enter a number for a new scope. Values are 1, 2, 3. . .		
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.		
Description	<p>The <code>xPCScopes.AddHostScope</code> method creates a new host scope on the target computer.</p> <p>Calling the <code>xPCScopes.AddHostScope</code> method with <i>scNum</i> having the number of an existing scope produces an error. Use <code>xPCScopes.GetScopes</code> to find the numbers of existing scopes.</p>		

xPCScopes.AddTargetScope

Purpose	Create new target scope		
Prototype	<code>long AddTargetScope(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLib.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter a number for a new scope. Values are 1, 2, 3. . .</td></tr></table>	[in] <i>scNum</i>	Enter a number for a new scope. Values are 1, 2, 3. . .
[in] <i>scNum</i>	Enter a number for a new scope. Values are 1, 2, 3. . .		
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.		
Description	<p>If the method detects an error, it returns 0. The <code>xPCScopes.AddTargetScope</code> method creates a new scope on the target computer.</p> <p>Calling the <code>xPCScopes.AddTargetScope</code> method with <i>scNum</i> having the number of an existing scope produces an error. Use <code>xPCScopes.GetScopes</code> to find the numbers of existing scopes.</p>		

Purpose	Get and copy list of scope numbers		
Prototype	VARIANT GetScopes(long <i>size</i>);		
Member Of	XPCAPICOMLib.xPCScopes		
Arguments	<table><tr><td>[in] <i>size</i></td><td>Specify the size of the VARIANT array returned. This argument must be greater than MAX_SCOPES-1. The elements in the array consist of a list of unsorted integers, terminated by -1.</td></tr></table>	[in] <i>size</i>	Specify the size of the VARIANT array returned. This argument must be greater than MAX_SCOPES-1. The elements in the array consist of a list of unsorted integers, terminated by -1.
[in] <i>size</i>	Specify the size of the VARIANT array returned. This argument must be greater than MAX_SCOPES-1. The elements in the array consist of a list of unsorted integers, terminated by -1.		
Return	The xPCScopes.GetScopes method returns a VARIANT array with elements containing a list of scope numbers from the target application.		
Description	The xPCScopes.GetScopes method gets a VARIANT array with elements containing a list of scope numbers currently defined for the target application. Specify the size of the VARIANT array returned. This size must be greater than the maximum number of scopes -1, up to a maximum of 30 scopes. The elements in the array consist of a list of unsorted integers, terminated by -1.		

xPCScopes.GetxPCError

Purpose	Get error string
Prototype	BSTR GetxPCError();
Member Of	XPCAPICOMLib.xPCScopes
Return	The xPCScopes.GetxPCError method returns the string for the last reported error. If the software has not reported an error, this method returns 0.
Description	The xPCScopes.GetxPCError method gets the string of the last reported error by another COM API method. This value is reset every time you call a new method. Therefore, you should check this constant value immediately after a call to an API COM method. You can use this method in conjunction with the xPCScopes.isxPCError method, which detects that an error has occurred.
See Also	API function xPCScopes.isxPCError

Purpose	Initialize scope object to communicate with target computer		
Prototype	<code>long Init(IxPCProtocol* xPCProtocol);</code>		
Member Of	<code>XPCAPICOMLib.xPCScopes</code>		
Arguments	<table><tr><td><code>[in] xPCProtocol</code></td><td>Specify the communication port of the target computer object for which the scope is to be initialized.</td></tr></table>	<code>[in] xPCProtocol</code>	Specify the communication port of the target computer object for which the scope is to be initialized.
<code>[in] xPCProtocol</code>	Specify the communication port of the target computer object for which the scope is to be initialized.		
Return	If the <code>xPCScopes.Init</code> method initializes the scope object without detecting an error, it returns 0. If the scope object fails to initialize, the method returns -1.		
Description	The <code>xPCScopes.Init</code> method initializes the scope object to communicate with the target computer referenced by the <code>xPCProtocol</code> object.		

xPCScopes.IsScopeFinished

Purpose	Get data acquisition status for scope
Prototype	<code>long IsScopeFinished(long <i>scNum</i>);</code>
Member Of	XPCAPICOMLIB.xPCScopes
Arguments	[in] <i>scNum</i> Enter the scope number.
Return	If the method detects an error, it returns -1. If a scope finishes a data acquisition cycle, this method returns 1. If the scope is in the process of acquiring data, this method returns 0.
Description	The <code>xPCScopes.IsScopeFinished</code> method gets a 1 or 0 depending on whether scope <i>scNum</i> is finished (state of <code>SCST_FINISHED</code>) or not. You can also call this function for target scopes; however, because target scopes restart immediately, it is almost impossible to find these scopes in the finished state.

Purpose	Get error status
Prototype	<code>long isxPCError();</code>
Member Of	XPCAPICOMLIB.xPCScopes
Return	If an error occurred, the method returns 1. Otherwise, it returns 0.
Description	Use the <code>xPCScopes.isxPCError</code> method to check for errors that might occur after a call to the <code>xPCScopes</code> class methods. If the software detects that an error occurred, call the <code>xPCScopes.GetxPCError</code> method to get the string for the error.
See Also	API function <code>xPCScopes.GetxPCError</code>

xPCScopes.RemScope

Purpose	Remove scope		
Prototype	<code>long RemScope(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.		
Description	The <code>xPCScopes.RemScope</code> method removes the scope with number <i>scNum</i> . Attempting to remove a nonexistent scope causes an error. For a list of existing scopes, use <code>xPCScopes.GetScopes</code> .		

Purpose Add signal to scope

Prototype `long ScopeAddSignal(long scNum, long sigNum);`

Member Of XPCAPICOMLib.xPCScopes

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>sigNum</i>	Enter a signal number.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCScopes.ScopeAddSignal` method adds the signal with number *sigNum* to the scope *scNum*. The signal should not already exist in the scope. You can use `xPCScopes.ScopeGetSignals` to get a list of the signals already present. Use the `xPCTarget.GetSignalIdx` method to get the signal number.

xPCScopes.ScopeGetAutoRestart

Purpose Scope autorestart value

Prototype `long ScopeGetAutoRestart(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The `xPCScopes.ScopeGetAutoRestart` method returns the scope autorestart flag value (1 if enabled, 0 if disabled). If the method detects an error, it returns -1.

Description The `xPCScopes.ScopeGetAutoRestart` method gets the autorestart flag value for scope *scNum*. Autorestart flag can be disabled (0) or enabled (1).

Purpose Copy scope data to array

Prototype VARIANT ScopeGetData(long *scNum*, long *signal_id*, long *start*, long *numsamples*, long *decimation*);

Member Of XPCAPICOMLIB.xPCScopes

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>signal_id</i>	Enter a signal number. Enter -1 to get time stamped data.
[in] <i>start</i>	Enter the first sample from which data retrieval is to start.
[in] <i>numsamples</i>	Enter the number of samples retrieved with a decimation of <i>decimation</i> , starting from the <i>start</i> value.
[in] <i>decimation</i>	Enter a value such that every <i>decimation</i> sample is retrieved in a scope window.

Return The xPCScopes.ScopeGetData method returns a VARIANT array with elements containing the data used in a scope.

Description The xPCScopes.ScopeGetData method gets the data used in a scope. Use this function for scopes of type SCTYPE_HOST. The scope must be either in state Finished or in state Interrupted for the data to be retrievable. (Use the xPCScopes.ScopeGetState method to check the state of the scope.) The data must be retrieved one signal at a time. The calling function determines and allocates the space ahead of time to store the scope data. Use the method xPCScopes.ScopeGetSignals to get the list of signals in the scope for *signal_id*.

xPCScopes.ScopeGetData

To get time stamped data, specify -1 for `signal_id`. From the output, you can then get the number of nonzero elements.

Purpose	Get decimation of scope		
Prototype	<code>long ScopeGetDecimation(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	The <code>xPCScopes.ScopeGetDecimation</code> method returns the decimation of scope <i>scNum</i> . If the method detects an error, it returns -1.		
Description	The <code>xPCScopes.ScopeGetDecimation</code> method gets the decimation of scope <i>scNum</i> . The decimation is a number, N, meaning every Nth sample is acquired in a scope window.		

xPCScopes.ScopeGetNumPrePostSamples

Purpose Get number of pre- or posttriggering samples before triggering scope

Prototype `long ScopeGetNumPrePostSamples(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The `xPCScopes.ScopeGetNumPrePostSamples` method returns the number of samples for pre- or posttriggering for scope *scNum*. If an error occurs, this method returns -1.

Description The `xPCScopes.ScopeGetNumPrePostSamples` method gets the number of samples for pre- or posttriggering for scope *scNum*. A negative number implies pretriggering, whereas a positive number implies posttriggering samples.

xPCScopes.ScopeGetNumSamples

Purpose	Get number of samples in one data acquisition cycle		
Prototype	<code>long ScopeGetNumSamples(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	The <code>xPCScopes.ScopeGetNumSamples</code> method returns the number of samples in the scope <i>scNum</i> . If the method detects an error, it returns -1.		
Description	The <code>xPCScopes.ScopeGetNumSamples</code> method gets the number of samples in one data acquisition cycle for scope <i>scNum</i> .		

xPCScopes.ScopeGetSignals

Purpose Get list of signals

Prototype `VARIANT ScopeGetSignals(long scNum, long size);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>size</i>	Enter an integer to allocate the number of elements to be returned in the VARIANT array. This size is required for the method to copy the list of signals into the VARIANT array. The maximum number of signals is 10.

Return The `xPCScopes.ScopeGetSignals` method returns a VARIANT array with elements consisting of the list of signals defined for a scope.

Description The `xPCScopes.ScopeGetSignals` method gets the list of signals defined for scope *scNum*. You can use the constant `MAX_SIGNALS`.

Purpose	Get last data acquisition cycle start time		
Prototype	<code>double ScopeGetStartTime(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	The <code>xPCScopes.ScopeGetStartTime</code> method returns the start time for the last data acquisition cycle of a scope. If the method detects an error, it returns -1.		
Description	The <code>xPCScopes.ScopeGetStartTime</code> method gets the time at which the last data acquisition cycle for scope <i>scNum</i> started. This is only valid for scopes of type <code>SCTYPE_HOST</code> .		

xPCScopes.ScopeGetState

Purpose Get state of scope

Prototype BSTR ScopeGetState(long *scNum*);

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The xPCScopes.ScopeGetState method returns the state of scope *scNum*. If the method detects an error, it returns -1.

Description The xPCScopes.ScopeGetState method gets the state of scope *scNum*, or -1 upon error.

Constants to find the scope state have the following meanings:

Constant	Value	Description
SCST_WAITTOSTART	0	Scope is ready and waiting to start.
SCST_PREACQUIRING	5	Scope acquires a predefined number of samples before triggering.
SCST_WAITFORTRIG	1	After a scope is finished with the preacquiring state, it waits for a trigger. If the scope does not preacquire data, it enters the wait for trigger state.
SCST_ACQUIRING	2	Scope is acquiring data. The scope enters this state when it leaves the wait for trigger state.

Constant	Value	Description
SCST_FINISHED	3	Scope is finished acquiring data when it has attained the predefined limit.
SCST_INTERRUPTED	4	The user has stopped (interrupted) the scope.

xPCScopes.ScopeGetTriggerLevel

Purpose	Get trigger level for scope		
Prototype	<code>double ScopeGetTriggerLevel(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	The <code>xPCScopes.ScopeGetTriggerLevel</code> method returns the scope trigger level. If the method detects an error, it returns -1.		
Description	The <code>xPCScopes.ScopeGetTriggerLevel</code> method gets the trigger level for scope <i>scNum</i> .		

xPCScopes.ScopeGetTriggerMode

Purpose Get trigger mode for scope

Prototype `long ScopeGetTriggerMode(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The `xPCScopes.ScopeGetTriggerMode` method returns the scope trigger mode. If the method detects an error, it returns -1.

Description The `xPCScopes.ScopeGetTriggerMode` method gets the trigger mode for scope *scNum*. Use the constants here to interpret the trigger mode:

Constant	Value	Description
TRIGMD_FREERUN	0	There is no trigger mode. The scope triggers when it is ready to trigger, regardless of the circumstances.
TRIGMD_SOFTWARE	1	Only user intervention can trigger the scope. No other triggering is possible.
TRIGMD_SIGNAL	2	The scope is triggered only after a signal has crossed a value.
TRIGMD_SCOPE	3	The scope is triggered by another scope at the trigger point of the triggering scope, modified by the value of <code>triggerscopesample</code> (see <code>scopedata</code>).

xPCScopes.ScopeGetTriggerMode

See Also

API function `xPCScopes.ScopeGetTriggerModeStr`

xPCScopes.ScopeGetTriggerModeStr

Purpose Get trigger mode as string

Prototype BSTR ScopeGetTriggerModeStr(long scNum);

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] scNum Enter the scope number.

Return The xPCScopes.ScopeGetTriggerModeStr method returns a string containing the trigger mode string.

Description The xPCScopes.ScopeGetTriggerModeStr method gets the trigger mode string for scope scNum. This method returns one of the following strings.

Constant	Description
FreeRun	There is no trigger mode. The scope triggers when it is ready to trigger, regardless of the circumstances.
Software	Only user intervention can trigger the scope. No other triggering is possible.
Signal	The scope is triggered only after a signal has crossed a value.
Scope	The scope is triggered by another scope at the trigger point of the triggering scope, modified by the value of triggerscopesample (see scopedata).

See Also API function xPCScopes.ScopeGetTriggerMode

xPCScopes.ScopeGetTriggerSample

Purpose Get sample number for triggering scope

Prototype `long ScopeGetTriggerSample(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The `xPCScopes.ScopeGetTriggerSample` method returns a nonnegative integer for a real sample, and -1 for the special case where triggering is at the end of the data acquisition cycle for a triggering scope. If the method detects an error, it returns -1.

Description The `xPCScopes.ScopeGetTriggerSample` method gets the number of samples a triggering scope (*scNum*) acquires before starting data acquisition on a second scope. This value is a nonnegative integer for a real sample, and -1 for the special case where triggering is at the end of the data acquisition cycle for a triggering scope.

xPCScopes.ScopeGetTriggerSignal

Purpose	Get trigger signal for scope		
Prototype	<code>long ScopeGetTriggerSignal(long <i>scNum</i>);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	The <code>xPCScopes.ScopeGetTriggerSignal</code> method returns the scope trigger signal. If the method detects an error, it returns -1.		
Description	The <code>xPCScopes.ScopeGetTriggerSignal</code> method gets the trigger signal for scope <i>scNum</i> .		

xPCScopes.ScopeGetTriggerSlope

Purpose Get trigger slope for scope

Prototype `long ScopeGetTriggerSlope(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The `xPCScopes.ScopeGetTriggerSlope` method returns the scope trigger slope. If the method detects an error, it returns -1.

Description The `xPCScopes.ScopeGetTriggerSlope` method gets the trigger slope of scope *scNum*. Use the constants here to interpret the trigger slope:

String	Value	Description
TRIGSLOPE_EITHER	0	The trigger slope can be either rising or falling.
TRIGSLOPE_RISING	1	The trigger slope must be rising when the signal crosses the trigger value.
TRIGSLOPE_FALLING	2	The trigger slope must be falling when the signal crosses the trigger value.

See Also API function `xPCScopes.ScopeGetTriggerSlopeStr`

xPCScopes.ScopeGetTriggerSlopeStr

Purpose Get trigger slope as string

Prototype `BSTR ScopeGetTriggerSlopeStr(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The `xPCScopes.ScopeGetTriggerSlopeStr` method returns a string containing the trigger slope string.

Description The `xPCScopes.ScopeGetTriggerSlopeStr` method gets the trigger slope string for scope *scNum*. This method returns one of the following strings:

String	Description
Either	The trigger slope can be either rising or falling.
Rising	The trigger slope must be rising when the signal crosses the trigger value.
Falling	The trigger slope must be falling when the signal crosses the trigger value.

See Also API function `xPCScopes.ScopeGetTriggerSlope`

xPCScopes.ScopeGetType

Purpose Get type of scope

Prototype BSTR ScopeGetType(long *scNum*);

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The xPCScopes.ScopeGetType method returns the scope type as a string. If the method detects an error, it returns -1.

Description The xPCScopes.ScopeGetType method gets the type of scope *scNum*. This method returns one of the following strings:

String	Description
HOST	Host scope
Target	Target scope

Purpose Remove signal from scope

Prototype `long ScopeRemSignal(long scNum, long sigNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>sigNum</i>	Enter a signal number.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCScopes.ScopeRemSignal` method removes a signal from the scope with number *scNum*. The scope must already exist, and signal number *sigNum* must exist in the scope. Use `xPCScopes.GetScopes` to determine the existing scopes, and use `xPCScopes.ScopeGetSignals` to determine the existing signals for a scope. Use this function only when the scope is stopped. Use `xPCScopes.ScopeGetState` to check the state of the scope.

xPCScopes.ScopeSetAutoRestart

Purpose	Scope autorestart value				
Prototype	<code>long ScopeSetAutoRestart(long <i>scNum</i>, long <i>onoff</i>);</code>				
Member Of	XPCAPICOMLIB.xPCScopes				
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr><tr><td>[in] <i>onoff</i></td><td>Enter value to enable (1) or disable (0) scope autorestart.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.	[in] <i>onoff</i>	Enter value to enable (1) or disable (0) scope autorestart.
[in] <i>scNum</i>	Enter the scope number.				
[in] <i>onoff</i>	Enter value to enable (1) or disable (0) scope autorestart.				
Return	The <code>xPCScopes.ScopeSetAutoRestart</code> method returns the scope autorestart flag value (1 if enabled, 0 if disabled). If the method detects an error, it returns -1.				
Description	The <code>xPCScopes.ScopeSetAutoRestart</code> method sets the autorestart flag value for scope <i>scNum</i> . Autorestart flag can be disabled (0) or enabled (1).				

Purpose	Set decimation of scope				
Prototype	<code>long ScopeSetDecimation(long <i>scNum</i>, long <i>decimation</i>);</code>				
Member Of	XPCAPICOMLIB.xPCScopes				
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr><tr><td>[in] <i>decimation</i></td><td>Enter an integer for the decimation.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.	[in] <i>decimation</i>	Enter an integer for the decimation.
[in] <i>scNum</i>	Enter the scope number.				
[in] <i>decimation</i>	Enter an integer for the decimation.				
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.				
Description	The <code>xPCScopes.ScopeSetDecimation</code> method sets the <i>decimation</i> of scope <i>scNum</i> . The decimation is a number, N, meaning every Nth sample is acquired in a scope window. Use this function only when the scope is stopped. Use <code>xPCScopes.ScopeGetState</code> to check the state of the scope.				

xPCScopes.ScopeSetNumPrePostSamples

Purpose Set number of pre- or posttriggering samples before triggering scope

Prototype `long ScopeSetNumPrePostSamples(long scNum, long prepost);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>prepost</i>	A negative number means pretriggering, while a positive number means posttriggering. This function can only be used when the scope is stopped.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCScopes.ScopeSetNumPrePostSamples` method sets the number of samples for pre- or posttriggering for scope *scNum* to *prepost*. Use this method only when the scope is stopped. Use `xPCScopes.ScopeGetState` to check the state of the scope. Use the `xPCScopes.GetScopes` method to get a list of scope numbers.

xPCScopes.ScopeSetNumSamples

Purpose	Set number of samples in one data acquisition cycle				
Prototype	<code>long ScopeSetNumSamples(long <i>scNum</i>, long <i>samples</i>);</code>				
Member Of	XPCAPICOMLIB.xPCScopes				
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr><tr><td>[in] <i>samples</i></td><td>Enter the number of samples you want to acquire in one cycle.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.	[in] <i>samples</i>	Enter the number of samples you want to acquire in one cycle.
[in] <i>scNum</i>	Enter the scope number.				
[in] <i>samples</i>	Enter the number of samples you want to acquire in one cycle.				
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.				
Description	The <code>xPCScopes.ScopeSetNumSamples</code> method sets the number of samples for scope <i>scNum</i> to <i>samples</i> . Use this function only when the scope is stopped. Use <code>xPCScopes.ScopeGetState</code> to check the state of the scope.				

xPCScopes.ScopeSetTriggerLevel

Purpose	Set trigger level for scope				
Prototype	<code>long ScopeSetTriggerLevel(long <i>scNum</i>, double <i>level</i>);</code>				
Member Of	XPCAPICOMLIB.xPCScopes				
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr><tr><td>[in] <i>level</i></td><td>Value for a signal to trigger data acquisition with a scope.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.	[in] <i>level</i>	Value for a signal to trigger data acquisition with a scope.
[in] <i>scNum</i>	Enter the scope number.				
[in] <i>level</i>	Value for a signal to trigger data acquisition with a scope.				
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.				
Description	The <code>xPCScopes.ScopeSetTriggerLevel</code> method sets the trigger level to <i>level</i> for scope <i>scNum</i> . Use this function only when the scope is stopped. Use <code>xPCScopes.ScopeGetStateto</code> check the state of the scope.				

xPCScopes.ScopeSetTriggerMode

Purpose Set trigger mode of scope

Prototype `long ScopeSetTriggerMode(long scNum, long triggermode);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>triggermode</i>	Trigger mode for a scope.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCScopes.ScopeSetTriggerMode` method sets the trigger mode of scope *scNum* to *triggermode*. Use this method only when the scope is stopped. Use `xPCScopes.ScopeGetState` to check the state of the scope. Use the `xPCScopes.GetScopes` method to get a list of scopes.

Use the constants defined here to interpret the trigger mode:

Constant	Value	Description
TRIGMD_FREERUN	0	There is no trigger mode. The scope triggers when it is ready to trigger, regardless of the circumstances. This is the default.
TRIGMD_SOFTWARE	1	Only user intervention can trigger the scope. No other triggering is possible.

xPCScopes.ScopeSetTriggerMode

Constant	Value	Description
TRIGMD_SIGNAL	2	The scope is triggered only after a signal has crossed a value.
TRIGMD_SCOPE	3	The scope is triggered by another scope at the trigger point of the triggering scope, modified by the value of <code>triggerscopesample</code> (see <code>scopedata</code>).

Purpose	Set sample number for triggering scope				
Prototype	<code>long ScopeSetTriggerSample(long scNum, long trigScSample);</code>				
Member Of	XPCAPICOMLIB.xPCScopes				
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr><tr><td>[in] <i>trigScSample</i></td><td>Enter a nonnegative integer for the number of samples acquired by the triggering scope before starting data acquisition on a second scope.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.	[in] <i>trigScSample</i>	Enter a nonnegative integer for the number of samples acquired by the triggering scope before starting data acquisition on a second scope.
[in] <i>scNum</i>	Enter the scope number.				
[in] <i>trigScSample</i>	Enter a nonnegative integer for the number of samples acquired by the triggering scope before starting data acquisition on a second scope.				
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.				
Description	<p>The <code>xPCScopes.ScopeSetTriggerSample</code> method sets the number of samples (<i>trigScSample</i>) a triggering scope acquires before it triggers a second scope (<i>scNum</i>). Use the <code>xPCScopes.GetScopes</code> method to get a list of scopes.</p> <p>For meaningful results, set <i>trigScSample</i> between -1 and (<i>nSamp</i>-1). <i>nSamp</i> is the number of samples in one data acquisition cycle for the triggering scope. If you specify too large a value, the scope is never triggered.</p> <p>If you want to trigger a second scope at the end of a data acquisition cycle for the triggering scope, use a value of -1 for <i>trigScSamp</i>.</p>				

xPCScopes.ScopeSetTriggerSignal

Purpose	Select signal to trigger scope				
Prototype	<code>long ScopeSetTriggerSignal(long <i>scNum</i>, long <i>triggerSignal</i>);</code>				
Member Of	XPCAPICOMLIB.xPCScopes				
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr><tr><td>[in] <i>triggerSignal</i></td><td>Enter a signal number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.	[in] <i>triggerSignal</i>	Enter a signal number.
[in] <i>scNum</i>	Enter the scope number.				
[in] <i>triggerSignal</i>	Enter a signal number.				
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.				
Description	The <code>xPCScopes.ScopeSetTriggerSignal</code> method sets the trigger signal of scope <i>scNum</i> to <i>trigSig</i> . The trigger signal <i>trigSig</i> must be one of the signals in the scope. Use this method only when the scope is stopped. You can use <code>xPCScopes.ScopeGetSignals</code> to get the list of signals in the scope. Use <code>xPCScopes.ScopeGetState</code> to check the state of the scope. Use the <code>xPCScopes.GetScopes</code> method to get a list of scopes.				

Purpose Set slope of signal that triggers scope

Prototype `long ScopeSetTriggerSlope(long scNum, long triggerSlope);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments

[in] <i>scNum</i>	Enter the scope number.
[in] <i>triggerSlope</i>	Enter the slope mode for the signal that triggers the scope.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCScopes.ScopeSetTriggerSlope` method sets the trigger slope of scope *scNum* to *triggerSlope*. Use this method only when the scope is stopped. Use `xPCScopes.ScopeGetState` to check the state of the scope. Use the `xPCScopes.GetScopes` method to get a list of scopes.

Use the constants defined here to set the trigger slope:

Constant	Value	Description
TRIGSLOPE_EITHER	0	The trigger slope can be either rising or falling.
TRIGSLOPE_RISING	1	The trigger signal value must be rising when it crosses the trigger value.
TRIGSLOPE_FALLING	2	The trigger signal value must be falling when it crosses the trigger value.

xPCScopes.ScopeSoftwareTrigger

Purpose Set software trigger of scope

Prototype `long ScopeSoftwareTrigger(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCScopes.ScopeSoftwareTrigger` method triggers scope *scNum*. The scope must be in the state `Waiting for trigger` for this method to succeed. Use `xPCScopes.ScopeGetState` to check the state of the scope. Use the `xPCScopes.GetScopes` method to get a list of scopes.

You can use the `xPCScopes.ScopeSoftwareTrigger` method to trigger the scope, regardless of the trigger mode.

Purpose	Start data acquisition for scope		
Prototype	<code>long ScopeStart(long scNum);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.		
Description	The <code>xPCScopes.ScopeStart</code> method starts or restarts the data acquisition of scope <i>scNum</i> . If the scope does not have to preacquire samples, it enters the <code>Waiting for Trigger</code> state. The scope must be in state <code>Waiting to Start</code> , <code>Finished</code> , or <code>Interrupted</code> for this function to succeed. Call <code>xPCScopes.ScopeGetState</code> to check the state of the scope or, for host scopes that are already started, call <code>xPCScopes.IsScopeFinished</code> . Use the <code>xPCScopes.GetScopes</code> method to get a list of scopes.		

xPCScopes.ScopeStop

Purpose Stop data acquisition for scope

Prototype `long ScopeStop(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCScopes.ScopeStop` method stops the scope *scNum*. This sets the scope to the `Interrupted` state. The scope must be running for this function to succeed. Use `xPCScopes.ScopeGetState` to determine the state of the scope. Use the `xPCScopes.GetScopes` method to get a list of scopes.

Purpose	Get status of grid line for particular scope		
Prototype	<code>long TargetScopeGetGrid(long scNum);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	The <code>xPCScopes.TargetScopeGetGrid</code> method returns the state of the grid lines for scope <i>scNum</i> . If the method detects an error, it returns -1.		
Description	The <code>xPCScopes.TargetScopeGetGrid</code> method gets the state of the grid lines for scope <i>scNum</i> (which must be of type <code>SCTYPE_TARGET</code>). A return value of 1 implies grid on, while 0 implies grid off. Note that when the scope mode is set to <code>SCMODE_NUMERICAL</code> , the grid is not drawn even when the grid mode is set to 1.		

Tip

- Use the `xPCScopes.GetScopes` method to get a list of scopes.
 - Use `xPCScopes.TargetScopeGetMode` and `xPCScopes.TargetScopeSetMode` to retrieve and set the scope mode.
-

xPCScopes.TargetScopeGetMode

Purpose Get scope mode for displaying signals

Prototype `long TargetScopeGetMode(long scNum);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments [in] *scNum* Enter the scope number.

Return The `xPCScopes.TargetScopeGetMode` method returns the value corresponding to the scope mode. The possible values are

- SCMODE_NUMERICAL = 0
- SCMODE_REDRAW = 1
- SCMODE_SLIDING = 2
- SCMODE_ROLLING = 3

If the method detects an error, it returns -1.

Description The `xPCScopes.TargetScopeGetMode` method gets the mode of the scope *scNum*, which must be of type `SCTYPE_TARGET`. Use the `xPCScopes.GetScopes` method to get a list of scopes.

See Also API function `xPCScopes.TargetScopeGetModeStr`

xPCScopes.TargetScopeGetModeStr

Purpose	Get scope mode string for displaying signals		
Prototype	<code>BSTR TargetScopeGetModeStr(long scNum);</code>		
Member Of	XPCAPICOMLIB.xPCScopes		
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.
[in] <i>scNum</i>	Enter the scope number.		
Return	<p>The <code>xPCScopes.TargetScopeGetModeStr</code> method returns the string corresponding to the scope mode. The possible strings are</p> <ul style="list-style-type: none">• Numerical• Redraw• Sliding• Rolling		
Description	The <code>xPCScopes.TargetScopeGetModeStr</code> method gets the mode string of the scope <i>scNum</i> , which must be of type <code>SCTYPE_TARGET</code> . Use the <code>xPCScopes.GetScopes</code> method to get a list of scopes.		
See Also	API function <code>xPCScopes.TargetScopeGetMode</code>		

xPCScopes.TargetScopeGetViewMode

Purpose	Get view mode for target computer display
Prototype	<code>long TargetScopeGetViewMode();</code>
Member Of	XPCAPICOMLIB.xPCScopes
Return	The <code>xPCScopes.TargetScopeGetViewMode</code> method returns the view mode for the target computer screen. If the method detects an error, it returns -1.
Description	The <code>xPCScopes.TargetScopeGetViewMode</code> method gets the view (zoom) mode for the target computer display. If the returned value is not zero, the number is of the scope currently displayed on the screen. If the value is 0, then all defined scopes are displayed on the target computer screen, but no scopes are in focus (all scopes are unzoomed).

xPCScopes.TargetScopeGetYLimits

Purpose	Get <i>y</i> -axis limits for scope
Prototype	VARIANT TargetScopeGetYLimits(long <i>scNum</i>);
Member Of	XPCAPICOMLIB.xPCScopes
Arguments	[in] <i>scNum</i> Enter the scope number.
Return	The xPCScopes.TargetScopeGetYLimits method returns the upper and lower limits for target scopes.
Description	The xPCScopes.TargetScopeGetYLimits method gets and copies the upper and lower limits for a scope of type SCTYPE_TARGET and with scope number <i>scNum</i> . If both elements are zero, the limits are autoscaled. Use the xPCScopes.GetScopes method to get a list of scopes.

xPCScopes.TargetScopeSetGrid

Purpose	Set grid mode for scope				
Prototype	<code>long TargetScopeSetGrid(long <i>scNum</i>, long <i>gridonoff</i>);</code>				
Member Of	XPCAPICOMLIB.xPCScopes				
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr><tr><td>[in] <i>gridonoff</i></td><td>Enter a grid value (0 or 1).</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.	[in] <i>gridonoff</i>	Enter a grid value (0 or 1).
[in] <i>scNum</i>	Enter the scope number.				
[in] <i>gridonoff</i>	Enter a grid value (0 or 1).				
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.				
Description	The <code>xPCScopes.TargetScopeSetGrid</code> method sets the grid of a scope of type <code>SCTYPE_TARGET</code> and scope number <i>scNum</i> to <i>gridonoff</i> . If <i>gridonoff</i> is 0, the grid is off. If <i>gridonoff</i> is 1, the grid is on and grid lines are drawn on the scope window. When the drawing mode of scope <i>scNum</i> is set to <code>SCMODE_NUMERICAL</code> , the grid is not drawn even when the grid mode is set to 1. Use the <code>xPCScopes.GetScopes</code> method to get a list of scopes.				

Purpose Set display mode for scope

Prototype `long TargetScopeSetMode(long scNum, long mode);`

Member Of XPCAPICOMLIB.xPCScopes

Arguments

[in] <i>scNum</i>	Enter the scope number.
in] <i>mode</i>	Enter the value for the mode.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCScopes.TargetScopeSetMode` method sets the mode of a scope of type `SCTYPE_TARGET` and scope number *scNum* to *mode*. You can use one of the following constants for *mode*:

- `SCMODE_NUMERICAL = 0`
- `SCMODE_REDRAW = 1`
- `SCMODE_SLIDING = 2`
- `SCMODE_ROLLING = 3`

Use the `xPCScopes.GetScopes` method to get a list of scopes.

xPCScopes.TargetScopeSetViewMode

Purpose	Set view mode for scope
Prototype	<code>long TargetScopeSetViewMode(long <i>scNum</i>);</code>
Member Of	XPCAPICOMLIB.xPCScopes
Arguments	[in] <i>scNum</i> Enter the scope number.
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.
Description	The <code>xPCScopes.TargetScopeSetViewMode</code> method sets the target computer screen to display one scope with scope number <i>scNum</i> . If you set <i>scNum</i> to 0, the target computer screen displays all the defined scopes. Use the <code>xPCScopes.GetScopes</code> method to get a list of scopes.

xPCScopes.TargetScopeSetYLimits

Purpose	Set <i>y</i> -axis limits for scope				
Prototype	<code>long TargetScopeSetYLimits(long <i>scNum</i>, SAFEARRAY(double)* <i>YLimitarray</i>);</code>				
Member Of	XPCAPICOMLIB.xPCScopes				
Arguments	<table><tr><td>[in] <i>scNum</i></td><td>Enter the scope number.</td></tr><tr><td>[in, out] <i>YLimitarray</i></td><td>Enter a two-element array.</td></tr></table>	[in] <i>scNum</i>	Enter the scope number.	[in, out] <i>YLimitarray</i>	Enter a two-element array.
[in] <i>scNum</i>	Enter the scope number.				
[in, out] <i>YLimitarray</i>	Enter a two-element array.				
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.				
Description	The <code>xPCScopes.TargetScopeSetYLimits</code> method sets the <i>y</i> -axis limits for a scope with scope number <i>scNum</i> and type <code>SCTYPE_TARGET</code> to the values in the double array <i>YLimitArray</i> . The first element is the lower limit, and the second element is the upper limit. Set both limits to 0.0 to specify autoscaling. Use the <code>xPCScopes.GetScopes</code> method to get a list of scopes.				

xPCTarget.AverageTET

Purpose	Get average task execution time
Prototype	<code>double AverageTET();</code>
Member Of	XPCAPICOMLib.xPCTarget
Return	The <code>xPCTarget.AverageTET</code> method returns the average task execution time (TET) for the target application. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.AverageTET</code> method gets the TET for the target application. You can use this function when the target application is running or when it is stopped.

Purpose	Get target application name
Prototype	BSTR GetAppName();
Member Of	XPCAPICOMLib.xPCTarget
Return	The xPCTarget.GetAppName method returns a string with the name of the target application.
Description	The xPCTarget.GetAppName method gets the name of the target application. You can use the return value, <i>model_name</i> , in a printf or similar statement. In case of error, the string is unchanged. Be sure to allocate enough space to accommodate the longest target name you have.

xPCTarget.GetExecTime

Purpose	Get execution time for target application
Prototype	<code>double GetExecTime();</code>
Member Of	XPCAPICOMLib.xPCTarget
Return	The xPCTarget.GetExecTime method returns the current execution time for a target application. If the method detects an error, it returns -1.
Description	The xPCTarget.GetExecTime method gets the current execution time for the running target application. If the target application is stopped, the value is the last running time when the target application was stopped. If the target application is running, the value is the current running time.

Purpose	Get number of outputs
Prototype	<code>long GetNumOutputs();</code>
Member Of	<code>XPCAPICOMLib.xPCTarget</code>
Return	The <code>xPCTarget.GetNumOutputs</code> method returns the number of outputs in the current target application. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.GetNumOutputs</code> method gets the number of outputs in the target application. The number of outputs equals the sum of the input signal widths of the output blocks at the root level of the Simulink model.

xPCTarget.GetNumParams

Purpose	Get number of tunable parameters
Prototype	<code>long GetNumParams();</code>
Member Of	<code>XPCAPICOMLib.xPCTarget</code>
Return	The <code>xPCTarget.GetNumParams</code> method returns the number of tunable parameters in the target application. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.GetNumParams</code> method gets the number of tunable parameters in the target application. Use this method to see how many parameters you can get or modify.

Purpose	Get number of signals
Prototype	<code>long GetNumSignals();</code>
Member Of	XPCAPICOMLib.xPCTarget
Return	The <code>xPCTarget.GetNumSignals</code> method returns the number of signals in the target application. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.GetNumSignals</code> method gets the total number of signals in the target application that can be monitored from the host. Use this method to see how many signals you can monitor.

xPCTarget.GetNumStates

Purpose	Get number of states
Prototype	<code>long GetNumStates();</code>
Member Of	<code>XPCAPICOMLib.xPCTarget</code>
Return	The <code>xPCTarget.GetNumStates</code> method returns the number of states in the target application. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.GetNumStates</code> method gets the number of states in the target application.

Purpose Copy output log data to array

Prototype VARIANT GetOutputLog(long *start*, long *numsamples*, long *decimation*, long *output_id*);

Member Of XPCAPICOMLib.xPCTarget

Arguments

[in] <i>start</i>	Enter the index of the first sample to copy.
[in] <i>numsamples</i>	Enter the number of samples to copy from the output log.
[in] <i>decimation</i>	Select whether to copy all the sample values or every Nth value.
[in] <i>output_id</i>	Enter an output identification number.

Return The xPCTarget.GetOutputLog method returns output log data. You get the data for each output signal. If the method detects an error, it returns VT_ERROR, a scalar.

Description The xPCTarget.GetOutputLog method gets the output log and copies that log to an array. Output IDs range from 0 to (N-1), where N is the return value of xPCTarget.GetNumOutputs. Entering 1 for *decimation* copies all values. Entering N copies every Nth value.

For *start*, the sample indices range from 0 to (N-1), where N is the return value of xPCTarget.NumLogSamples. Get the maximum number of samples by calling the method xPCTarget.NumLogSamples.

Note that the target application must be stopped before you get the output log data.

xPCTarget.GetParam

Purpose Get parameter values

Prototype VARIANT GetParam(long *paramIdx*);

Member Of XPCAPICOMLib.xPCTarget

Arguments [in] *paramIdx* Enter the index for a parameter.

Return The xPCTarget.GetParam method returns the parameter values of a parameter.

Description The xPCTarget.GetParam method gets the parameter values of a parameter identified by *paramIdx*. This method returns an array of type VARIANT containing the parameter values, with the conversion of the values being done in column-major format. Each element in the array is a double, regardless of the data type of the actual parameter. You can query the dimensions of the array by calling the method xPCTarget.GetParamDims. See the Microsoft Visual Basic® .NET 2003 solution located in *matlabroot\toolbox\rtw\targets\xpc\api\VBNET\SigsAndParamsDemo* for an example of how to use this method.

See Also API method xPCTarget.GetParamDims, xPCTarget.SetParam

Purpose	Get row and column dimensions of parameter
Prototype	VARIANT GetParamDims(long <i>paramIdx</i>);
Member Of	XPCAPICOMLib.xPCTarget
Arguments	[in] <i>paramIdx</i> Parameter index.
Return	The xPCTarget.GetParamDims method returns a VARIANT array of two elements.
Description	The xPCTarget.GetParamDims method gets a VARIANT array of two elements. The first element contains the number of rows of the parameter, the second element contains the number of columns for your parameter.

xPCTarget.GetParamIdx

Purpose Get parameter index

Prototype `long GetParamIdx(BSTR blockName, BSTR paramName);`

Member Of XPCAPICOMLib.xPCTarget

Arguments

[in] <i>blockName</i>	Enter the full block path generated by the Simulink Coder software.
[in] <i>paramName</i>	Enter the parameter name for a parameter associated with the block.

Return The `xPCTarget.GetParamIdx` method returns the parameter index for the parameter name. If the method detects an error, it returns -1.

Description The `xPCTarget.GetParamIdx` method gets the parameter index for the parameter name (*paramName*) associated with a Simulink block (*blockName*). Both *blockName* and *paramName* must be identical to those generated at target application building time. The block names should be referenced from the file *model_namept.m* in the generated code, where *model_name* is the name of the model. Note that a block can have one or more parameters.

Purpose	Get parameter name
Prototype	VARIANT GetParamName(long <i>paramIdx</i>);
Member Of	XPCAPICOMLib.xPCTarget
Arguments	[in] <i>paramIdx</i> Enter a parameter index.
Return	The xPCTarget.GetParamName method returns a VARIANT array that contains two elements, the block path and parameter name, as strings.
Description	The xPCTarget.GetParamName method gets the parameter name and block name for a parameter with the index <i>paramIdx</i> . If <i>paramIdx</i> is invalid, xPCGetLastError returns nonzero, and the strings are unchanged. Get the parameter index with the method xPCTarget.GetParamIdx.

xPCTarget.GetSampleTime

Purpose	Get sample time
Prototype	<code>double GetSampleTime();</code>
Member Of	<code>XPCAPICOMLib.xPCTarget</code>
Return	The <code>xPCTarget.GetSampleTime</code> method returns the sample time, in seconds, of the target application. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.GetSampleTime</code> method gets the sample time, in seconds, of the target application. You can get the error by using the method <code>xPCGetLastError</code> .

Purpose Get signal value

Prototype `double GetSignal(long sigNum);`

Member Of XPCAPICOMLib.xPCTarget

Arguments [in] *sigNum* Enter a signal number.

Return The xPCTarget.GetSignal method returns the current value of signal *sigNum*. If the method detects an error, it returns -1.

Description The xPCTarget.GetSignal method gets the current value of a signal. Use the xPCTarget.GetSignalIdx method to get the signal number.

xPCTarget.GetSignalidsfromLabel

Purpose Get signal IDs from signal label

Prototype VARIANT GetSignalidsfromLabel(BSTR *sigLabel*);

Member Of XPCAPICOMLib.xPCTarget

Arguments [in] *sigLabel* Enter a signal label.

Return The xPCTarget.GetSignalidsfromLabel method returns a VARIANT array of the signal elements contained in the signal *sigLabel*. If no labels exist, the method returns an empty string.

Description The xPCTarget.GetSignalidsfromLabel method returns a VARIANT array of the signal elements contained in the signal *sigLabel*. Signal labels must be unique.

This method assumes that you have labeled the signal for which you request the indices (see the **Signal name** parameter of the “Signal Properties Controls”). Note that the Simulink Real-Time software refers to Simulink signal names as signal labels. The creator of the application should already know the signal name/label.

See Also API method xPCTarget.GetSignalLabel

Purpose	Get signal label
Prototype	BSTR GetSignalLabel(long <i>sigIdx</i>);
Member Of	XPCAPICOMLib.xPCTarget
Arguments	[in] <i>sigIdx</i> Enter a signal index.
Return	The xPCTarget.GetSignalLabel method returns the label of the signal. If no labels exist, the method returns an empty string.
Description	<p>The xPCTarget.GetSignalLabel method copies and gets the signal label of a signal with <i>sigIdx</i>. The method returns the signal label. This method assumes that you already know the signal index. Signal labels must be unique.</p> <p>This method assumes that you have labeled the signal for which you request the indices (see the Signal name parameter of the “Signal Properties Controls”). Note that the Simulink Real-Time software refers to Simulink signal names as signal labels. The creator of the application should already know the signal name/label.</p>
See Also	API method xPCTarget.GetSignalidsfromLabel

xPCTarget.GetSignalIdx

Purpose Get signal index

Prototype long GetSignalIdx(BSTR *sigName*);

Member Of XPCAPICOMLib.xPCTarget

Arguments [in] *sigName* Enter a signal name.

Return The xPCTarget.GetSignalIdx method returns the index for the signal with name *sigName*. If the method detects an error, it returns -1.

Description The xPCTarget.GetSignalIdx method gets the index of a signal. The name must be identical to the name generated when the application was built. You should reference the name from the file *model_namebio.m* in the generated code, where *model_name* is the name of the model. The creator of the application should already know the signal name.

Purpose	Copy signal name to character array
Prototype	BSTR GetSignalName(long <i>sigIdx</i>);
Member Of	XPCAPICOMLib.xPCTarget
Arguments	[in] <i>sigIdx</i> Enter a signal index.
Return	The xPCTarget.GetSignalName method returns the name of the signal.
Description	The xPCTarget.GetSignalName method copies and gets the signal name, including the block path, of a signal with <i>sigIdx</i> . The method returns a signal name, which makes it convenient to use in a <code>printf</code> or similar statement. This method assumes that you already know the signal index.

xPCTarget.GetSignals

Purpose	Get vector of signal values				
Prototype	VARIANT GetSignals(long <i>NumOfSignals</i> , SAFEARRAY(int)* <i>SignalsIdxArray</i>);				
Member Of	XPCAPICOMLib.xPCTarget				
Arguments	<table><tr><td>[in] <i>NumOfSignals</i></td><td>Enter the number of signals to acquire (the number of IDs in <i>SignalsIdxArray</i>).</td></tr><tr><td>[out] <i>SignalsIdxArray</i></td><td>Enter the IDs of the signals to acquire.</td></tr></table>	[in] <i>NumOfSignals</i>	Enter the number of signals to acquire (the number of IDs in <i>SignalsIdxArray</i>).	[out] <i>SignalsIdxArray</i>	Enter the IDs of the signals to acquire.
[in] <i>NumOfSignals</i>	Enter the number of signals to acquire (the number of IDs in <i>SignalsIdxArray</i>).				
[out] <i>SignalsIdxArray</i>	Enter the IDs of the signals to acquire.				
Return	The xPCTarget.GetSignals method returns a double-valued variant array containing the current value of a vector of signals. If the method detects an error, it returns VT_ERROR, a scalar.				
Description	This function returns the values of a vector of up to 1000 signals as fast as it can acquire them. The values are converted to doubles regardless of the actual data type of the signal.				

Tip

- Pass an integer array of signal numbers into *SignalsIdxArray*. Get the signal numbers with the function xPCTarget.GetSignalIdx.
 - The signal values may not be at the same time step. To get signal values at the same time step, define a scope of type SCTYPE_HOST and use xPCScopes.ScopeGetData.
-

The function xPCTarget.GetSignal does the same thing for a single signal, and could be used multiple times to achieve the same result.

However, xPCGetSignals is faster and the signal values are more likely to be spaced closely together.

See Also

API functions xPCTarget.GetSignal, xPCTarget.GetSignalIdx

xPCTarget.GetSignalWidth

Purpose Get width of signal

Prototype `long GetSignalWidth(long sigIdx);`

Member Of XPCAPICOMLib.xPCTarget

Arguments [in] *sigIdx* Enter the index of a signal.

Return The `xPCTarget.GetSignalWidth` method returns the signal width for a signal with *sigIdx*. If the method detects an error, it returns -1.

Description The `xPCTarget.GetSignalWidth` method gets the number of signals for a specified signal index. Although signals are manipulated as scalars, the width of the signal might be useful to reassemble the components into a vector. A signal's width is the number of signals in the vector.

Purpose	Get state log										
Prototype	VARIANT GetStateLog(long <i>start</i> , long <i>numsamples</i> , long <i>decimation</i> , long <i>state_id</i>);										
Member Of	XPCAPICOMLib.xPCTarget										
Arguments	<table><tr><td>[in] <i>start</i></td><td>Enter the index of the first sample to copy.</td></tr><tr><td>[in] <i>numsamples</i></td><td>Enter the number of samples to copy from the output log.</td></tr><tr><td>[in] <i>decimation</i></td><td>Select whether to copy all the sample values or every Nth value.</td></tr><tr><td>[in] <i>state_id</i></td><td>Enter a state identification number.</td></tr><tr><td>[out, retval] <i>Outarray</i></td><td>The log is stored in <i>Outarray</i>, whose allocation is the responsibility of the caller.</td></tr></table>	[in] <i>start</i>	Enter the index of the first sample to copy.	[in] <i>numsamples</i>	Enter the number of samples to copy from the output log.	[in] <i>decimation</i>	Select whether to copy all the sample values or every Nth value.	[in] <i>state_id</i>	Enter a state identification number.	[out, retval] <i>Outarray</i>	The log is stored in <i>Outarray</i> , whose allocation is the responsibility of the caller.
[in] <i>start</i>	Enter the index of the first sample to copy.										
[in] <i>numsamples</i>	Enter the number of samples to copy from the output log.										
[in] <i>decimation</i>	Select whether to copy all the sample values or every Nth value.										
[in] <i>state_id</i>	Enter a state identification number.										
[out, retval] <i>Outarray</i>	The log is stored in <i>Outarray</i> , whose allocation is the responsibility of the caller.										
Return	The xPCTarget.GetStateLog method returns the state log. If the method detects an error, it returns VT_ERROR, a scalar.										
Description	<p>The xPCTarget.GetStateLog method gets the state log. You get the data for each state signal in turn by specifying the <i>state_id</i>. State IDs range from 1 to (N-1), where N is the return value of xPCTarget.GetNumStates. Entering 1 for <i>decimation</i> copies all values. Entering N copies every Nth value. For <i>start</i>, the sample indices range from 0 to (N-1), where N is the return value of xPCTarget.NumLogSamples. Use the xPCTarget.NumLogSamples method to get the maximum number of samples.</p> <p>Note that the target application must be stopped before you get the number.</p>										

xPCTarget.GetStopTime

Purpose	Get stop time
Prototype	<code>double GetStopTime();</code>
Member Of	XPCAPICOMLib.xPCTarget
Return	The <code>xPCTarget.GetStopTime</code> method returns the stop time as a double, in seconds, of the target application. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.GetStopTime</code> method gets the stop time, in seconds, of the target application. This is the amount of time the target application runs before stopping.

Purpose Get TET log

Prototype VARIANT GetTETLog(long *start*, long *numsamples*, long *decimation*);

Member Of XPCAPICOMLib.xPCTarget

Arguments

[in] <i>start</i>	Enter the index of the first sample to copy.
[in] <i>numsamples</i>	Enter the number of samples to copy from the TET log.
[in] <i>decimation</i>	Select whether to copy all the sample values or every Nth value.
[out, retval] <i>Outarray</i>	The log is stored in <i>Outarray</i> , whose allocation is the responsibility of the caller.

Return The xPCTarget.GetTETLog method returns the TET log. If the method detects an error, it returns VT_ERROR, a scalar.

Description The xPCTarget.GetTETLog method gets the task execution time (TET) log. Entering 1 for *decimation* copies all values. Entering N copies every Nth value. For *start*, the sample indices range from 0 to (N-1), where N is the return value of xPCTarget.NumLogSamples. Use the xPCTarget.NumLogSamples method to get the maximum number of samples.

Note that the target application must be stopped before you get the number.

xPCTarget.GetTimeLog

Purpose Get time log

Prototype VARIANT GetTimeLog(long *start*, long *numsamples*, long *decimation*);

Member Of XPCAPICOMLib.xPCTarget

Arguments

[in] <i>start</i>	Enter the index of the first sample to copy.
[in] <i>numsamples</i>	Enter the number of samples to copy from the time log.
[in] <i>decimation</i>	Select whether to copy all the sample values or every Nth value.

Return The xPCTarget.GetTimeLog method returns the time log. If the method detects an error, it returns VT_ERROR, a scalar.

Description The xPCTarget.GetTimeLog method gets the time log. This is especially relevant in the case of value-equidistant logging, where the logged values might not be uniformly spaced in time. Entering 1 for *decimation* copies all values. Entering N copies every Nth value. For *start*, the sample indices range from 0 to (N-1), where N is the return value of xPCTarget.NumLogSamples. Use the xPCTarget.NumLogSamples method to get the number of samples.

Note that the target application must be stopped before you get the number.

Purpose	Get error string
Prototype	BSTR GetxPCError();
Member Of	XPCAPICOMLib.xPCTarget
Return	The xPCTarget.GetxPCError method returns the string for the last reported error. If the software has not reported an error, this method returns 0.
Description	The xPCTarget.GetxPCError method gets the string of the error last reported by another COM API method. This value is reset every time you call a new method. Therefore, you should check this constant value immediately after a call to an API COM method. You can use this method in conjunction with the xPCTarget.isxPCError method, which detects that an error has occurred.
See Also	API method xPCTarget.isxPCError

xPCTarget.Init

Purpose	Initialize target object to communicate with target computer
Prototype	<code>long Init(IxPCProtocol* xPCProtocol);</code>
Member Of	XPCAPICOMLib.xPCTarget
Return	<p>If the method detects an error, it returns -1. Otherwise, it returns 0.</p> <p>If the xPCTarget.Init method initializes the target object without detecting an error, it returns 0. If the target object fails to initialize, this method returns -1.</p>
Description	The xPCTarget.Init method initializes the target object to communicate with the target computer referenced by the xPCProtocol object.

Purpose	Return running status for target application
Prototype	<code>long IsAppRunning();</code>
Member Of	<code>XPCAPICOMLib.xPCTarget</code>
Return	If the target application is stopped, the <code>xPCTarget.IsAppRunning</code> method returns 0. If the target application is running, this method returns 1. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.IsAppRunning</code> method returns 1 or 0 depending on whether the target application is stopped or running.

xPCTarget.IsOverloaded

Purpose	Return overload status for target computer
Prototype	<code>long IsOverloaded();</code>
Member Of	<code>XPCAPICOMLib.xPCTarget</code>
Return	If the target application has overloaded the CPU, the <code>xPCTarget.IsOverloaded</code> method returns 1. If it has not overloaded the CPU, the method returns 0. If the method detects an error, it returns -1.
Description	The <code>xPCTarget.IsOverloaded</code> method checks if the target application has overloaded the target computer and returns 1 if it has and 0 if it has not. If the target application is not running, the method returns 0.

Purpose	Return error status
Prototype	<code>long isxPCError();</code>
Member Of	XPCAPICOMLIB.xPCTarget
Return	If an error occurred, the method returns 1. Otherwise, it returns 0.
Description	Use the <code>xPCTarget.isxPCError</code> method to check for errors that might occur after a call to the <code>xPCTarget</code> class methods. If the method detects that an error occurred, call the <code>xPCTarget.GetxPCError</code> method to get the string for the error.
See Also	API method <code>xPCTarget.GetxPCError</code>

xPCTarget.LoadApp

Purpose Load target application onto target computer

Prototype long LoadApp(BSTR *pathstr*, BSTR *filename*);

Member Of XPCAPICOMLIB.xPCTarget

Arguments

[in] <i>pathstr</i>	Enter the full path to the target application file, excluding the file name. For example, in C, use a string like "C:\\work", in Microsoft Visual Basic, use a string like 'C:\\work'.
[in] <i>filename</i>	Enter the name of a compiled target application (*.dlm) without the file extension. For example, in C use a string like "xpcosc", in Microsoft Visual Basic, use a string like 'xpcosc'.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The xPCTarget.LoadApp method loads the compiled target application to the target computer. *pathstr* must not contain the trailing backslash. *pathstr* can be set to NULL or to the string 'nopath' if the application is in the current folder. The variable *filename* must not contain the target application extension.

Before returning, xPCTarget.LoadApp waits for a certain amount of time before checking whether the model initialization is complete. In the case where the model initialization is incomplete, xPCTarget.LoadApp returns a timeout error to indicate a connection problem (for example, ETCPREAD). By default, xPCTarget.LoadApp checks for target readiness five times, with each attempt taking approximately 1 second (less if the target is ready). However, for larger models or models requiring longer initialization (for example, those with thermocouple boards), the default might not be long enough and a spurious timeout can

be generated. The methods `xPCProtocol.GetLoadTimeOut` and `xPCProtocol.SetLoadTimeOut` control the number of attempts made.

xPCTarget.MaximumTET

Purpose	Copy maximum task execution time to array
Prototype	VARIANT MaximumTET();
Member Of	XPCAPICOMLIB.xPCTarget
Return	The xPCTarget.MaximumTET method returns a VARIANT object containing the maximum task execution time (TET) and the time at which the maximum TET was achieved. The maximum TET value is copied into the first element, and the time at which it was achieved is copied into the second element.
Description	The xPCTarget.MaximumTET method returns the maximum TET that was achieved during the previous target application run.

Purpose	Return maximum number of samples that can be in log buffer
Prototype	<code>long MaxLogSamples();</code>
Member Of	XPCAPICOMLIB.xPCTarget
Return	The <code>xPCTarget.MaxLogSamples</code> method returns the total number of samples. If the method detects an error, it returns -1.
Description	<p>The <code>xPCTarget.MaxLogSamples</code> method returns the total number of samples that can be returned in the logging buffers.</p> <p>Note that the target application must be stopped before you get the number.</p>

xPCTarget.MinimumTET

Purpose	Copy minimum task execution time to array
Prototype	VARIANT MinimumTET();
Member Of	XPCAPICOMLIB.xPCTarget
Return	The xPCTarget.MinimumTET method returns a VARIANT object containing the minimum task execution time (TET) and the time at which the minimum TET was achieved. The minimum TET value is copied into the first element, and the time at which it was achieved is copied into the second element.
Description	The xPCTarget.MinimumTET method returns the minimum task execution time (TET) that was achieved during the previous target application run.

Purpose	Return number of samples in log buffer
Prototype	<code>long NumLogSamples();</code>
Member Of	XPCAPICOMLIB.xPCTarget
Return	The <code>xPCTarget.NumLogSamples</code> method returns the number of samples in the log buffer. If the method detects an error, it returns -1.
Description	<p>The <code>xPCTarget.NumLogSamples</code> method returns the number of samples in the log buffer. In contrast to <code>xPCTarget.MaxLogSamples</code>, which returns the maximum number of samples that can be logged (because of buffer size constraints), <code>xPCTarget.NumLogSamples</code> returns the number of samples actually logged.</p> <p>Note that the target application must be stopped before you get the number.</p>

xPCTarget.NumLogWraps

Purpose	Return number of times log buffer wraps
Prototype	<code>long NumLogWraps();</code>
Member Of	XPCAPICOMLIB.xPCTarget
Return	The xPCTarget.NumLogWraps method returns the number of times the log buffer wraps. If the method detects an error, it returns -1.
Description	<p>The xPCTarget.NumLogWraps method returns the number of times the log buffer wraps.</p> <p>Note that the target application must be stopped before you get the number.</p>

Purpose Change parameter value

Prototype `long SetParam(long paramIdx, SAFEARRAY(double)* newparamVal);`

Member Of XPCAPICOMLIB.xPCTarget

Arguments

[in] <i>paramIdx</i>	Parameter index.
[in, out] <i>newparamVal</i>	Vector of doubles, assumed to be the size required by the parameter type.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCTarget.SetParam` method sets the parameter *paramIdx* to the value in *newparamVal*. For matrices, *newparamVal* should be a vector representation of the matrix in column-major format. Although *newparamVal* is a vector of doubles, the method converts the values to the expected data types (using truncation) before setting them.

See Also API methods `xPCTarget.GetParam`, `xPCTarget.GetParamDims`, `xPCTarget.GetParamIdx`

xPCTarget.SetSampleTime

Purpose Change sample time for target application

Prototype `long SetSampleTime(double ts);`

Member Of XPCAPICOMLIB.xPCTarget

Arguments [in] *ts* Sample time for the target application.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCTarget.SetSampleTime` method sets the sample time, in seconds, of the target application to *ts*. Use this method only when the application is stopped.

Purpose Change stop time of target application

Prototype `long SetStopTime(double tfinal);`

Member Of XPCAPICOMLIB.xPCTarget

Arguments [in] *tfinal* Enter the stop time, in seconds.

Return If the method detects an error, it returns 0. Otherwise, it returns -1.

Description The `xPCTarget.SetStopTime` method sets the stop time of the target application to the value in *tfinal*. The target application will run for this number of seconds before stopping. Set *tfinal* to -1.0 to set the stop time to infinity.

xPCTarget.StartApp

Purpose	Start target application
Prototype	long StartApp()
Member Of	XPCAPICOMLIB.xPCTarget
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.
Description	The xPCTarget.StartApp method starts the target application loaded on the target machine.

Purpose	Stop target application
Prototype	<code>long StopApp();</code>
Member Of	XPCAPICOMLIB.xPCTarget
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.
Description	The <code>xPCTarget.StopApp</code> method stops the target application loaded on the target computer. The target application remains loaded, and the parameter changes you made remain intact. If you want to stop and unload an application, use <code>xPCTarget.UnLoadApp</code> .

xPCTarget.UnloadApp

Purpose	Unload target application
Prototype	<code>long UnloadApp();</code>
Member Of	XPCAPICOMLIB.xPCTarget
Return	If the method detects an error, it returns 0. Otherwise, it returns -1.
Description	The xPCTarget.UnloadApp method stops the current target application, removes it from the target computer memory, and resets the target computer in preparation for receiving a new target application. The method xPCTarget.LoadApp calls this method before loading a new target application.

Configuration Parameters

This topic deals with configuration parameters in Simulink Real-Time Explorer and in the MATLAB API.

Configuration Parameters

In this section...

- “Simulink Real-Time Options Pane” on page 4-3
- “Automatically download application after building” on page 4-4
- “Download to default target PC” on page 4-5
- “Specify target PC name” on page 4-6
- “Name of Simulink Real-Time object created by build process” on page 4-7
- “Use default communication timeout” on page 4-8
- “Specify the communication timeout in seconds” on page 4-9
- “Execution mode” on page 4-10
- “Real-time interrupt source” on page 4-11
- “I/O board generating the interrupt” on page 4-12
- “PCI slot (-1: autosearch) or ISA base address” on page 4-16
- “Log Task Execution Time” on page 4-17
- “Signal logging data buffer size in doubles” on page 4-18
- “Number of events (each uses 20 bytes)” on page 4-21
- “Double buffer parameter changes” on page 4-22
- “Load a parameter set from a file on the designated target file system” on page 4-24
- “File name” on page 4-25
- “Build COM objects from tagged signals/parameters” on page 4-26
- “Generate CANape extensions” on page 4-27
- “Include model hierarchy on the target application” on page 4-28
- “Enable Stateflow animation” on page 4-29

Simulink Real-Time Options Pane

Set up general information about building target applications, including target, execution, data logging, and other options.

Configuration

To enable the **Simulink Real-Time Options** pane, you must:

- 1 In the **Code Generation** pane of the Configuration Parameters dialog box, set the **System target file** parameter to `slrt.tlc` or `slrtert.tlc`.

Note If you open a model that was originally saved with **System target file** set to `xpctarget.tlc`, the software will automatically update the setting to `slrt.tlc`, and likewise with `xpctargetert.tlc` and `slrtert.tlc`. To retain the updated setting, you must save the updated model.

- 2 Select C for the **Language** parameter on the code generation pane.

Tips

- The default values work for the generation of most target applications. If you want to customize the build of your target application, set the option parameters to suit your specifications.
- To access configuration parameters from the MATLAB command line, use:
 - `gcs` — To access the current model.
 - `set_param` — To set the parameter value.
 - `get_param` — To get the current value of the parameter.

See Also

“Simulink Real-Time Options Configuration Parameters”

Automatically download application after building

Enable Simulink Coder to build and download the target application to the target computer.

Settings

Default: on



On

Builds and downloads the target application to the target computer.



Off

Builds the target application, but does not download it to the target computer.

Command-Line Information

Parameter: xPCisDownloadable

Type: string

Value: 'on' | 'off'

Default: 'on'

See Also

“Build and Download Target Application”

Download to default target PC

Direct Simulink Coder to download the target application to the default target computer.

Settings

Default: on



On

Downloads the target application to the default target computer. Assumes that you configured a default target computer through Simulink Real-Time Explorer.



Off

Enables the **Specify target PC name** field so that you can enter the target computer to which to download the target application.

Dependency

This parameter enables **Specify target PC name**.

Command-Line Information

Parameter: xPCisDefaultEnv

Type: string

Value: 'on' | 'off'

Default: 'on'

See Also

- “Ethernet Communication Setup”
- “RS-232 Communication Setup”

Specify target PC name

Specify a target computer name for your target application.

Settings

''

Tip

The target computer name appears in Simulink Real-Time Explorer as the target computer node, for example TargetPC1.

Dependencies

This parameter is enabled by **Download to default target PC**.

Command-Line Information

Parameter: xPCTargetPCEnvName

Type: string

Value: Any valid target computer

Default: ''

See Also

“Simulink Real-Time Explorer Basic Operations”

Name of Simulink Real-Time object created by build process

Enter the name of the target object created by the build process.

Settings

Default: tg

Tip

Use this name when you work with the target object through the command-line interface.

Command-Line Information

Parameter: RL320objectName

Type: string

Value: 'tg' | valid target object name

Default: 'tg'

See Also

“Target Driver Objects”

Use default communication timeout

Direct Simulink Real-Time software to wait 5 (default) seconds for the target application to be downloaded to the target computer.

Settings

Default: on



On

Waits the default amount of seconds (5) for the target application to be downloaded to the target computer.



Off

Enables the **Specify the communication timeout in seconds** field so that you can enter the maximum length of time in seconds you want to wait for a target application to be downloaded to the target computer.

Dependencies

This parameter enables **Specify the communication timeout in seconds**.

Command-Line Information

Parameter: xPCisModelTimeout

Type: string

Value: 'on' | 'off'

Default: 'on'

See Also

“Increase the Time for Downloads”

Specify the communication timeout in seconds

Specify a timeout, in seconds, to wait for the target application to download to the target computer.

Settings

Default: 5

Tip

Enter the maximum length of time in seconds you want to allow the Simulink Real-Time software to wait for the target application to download to the target computer. If the target application is not downloaded within this time frame, the software generates an error.

Dependencies

This parameter is enabled by **Use default communication timeout**.

Command-Line Information

Parameter: xPCModelTimeoutSecs

Type: string

Value: Any valid number of seconds

Default: '5'

See Also

“Increase the Time for Downloads”

Execution mode

Specify target application execution mode.

Settings

Default: Real-Time

Real-Time

Executes application as a real-time application.

Freerun

Executes application as fast as possible.

Multirate models cannot be executed in Freerun execution mode. On the **Solver** pane in the Configuration Parameters dialog box, set **Tasking mode for periodic sample times** to SingleTasking.

Command-Line Information

Parameter: RL32ModeModifier

Type: string

Value: 'Real-Time' | 'Freerun'

Default: 'Real-Time'

See Also

“Set Configuration Parameters”

Real-time interrupt source

Select a real-time interrupt source from the I/O board.

Settings

Default: Timer

Timer

Specifies that the board interrupt source is a timer.

Auto (PCI only)

Enables the Simulink Real-Time software to automatically determine the IRQ that the BIOS assigned to the board and use it.

3 to 15

Specifies that the board interrupt source is an IRQ number on the board.

Tips

- The Auto (PCI only) option is available only for PCI boards. If you have an ISA board (PC 104 or onboard parallel port), you must set the IRQ manually.
- The Simulink Real-Time software treats PCI parallel port plug-in boards like ISA boards. For PCI parallel port plug-in boards, you must set the IRQ manually.
- Multiple boards can share the same interrupt number.

Command-Line Information

Parameter: RL32IRQSourceModifier

Type: string

Value: 'Timer' | Auto (PCI only) | '3' | '4' | '5' | '6' | '7' | '8' | '9' | '10' | '11' | '12' | '13' | '14' | '15'

Default: 'Timer'

See Also

“Set Configuration Parameters”

I/O board generating the interrupt

Specify the board interrupt source.

Settings

Default: None/Other

ATI-RP-R5

Specifies that the interrupt source is an ATI-RP-R5 board.

AudioPMC+

Specifies that the interrupt source is the Bittware AudioPMC+ audio board.

Bitflow NEON

Specifies that the interrupt source is the BitFlow™ NEON video board.

Busmirror EB5100

Specifies that the interrupt source is the Busmirror EB5100 FlexRay™ board.

CB_CIO-CTR05

Specifies that the interrupt source is the Measurement Computing™ CIO-CTR05 board.

CB_PCI-CTR05

Specifies that the interrupt source is the Measurement Computing PCI-CTR05 board.

Diamond_MM-32

Specifies that the interrupt source is the Diamond Systems MM-32 board.

FastComm 422/2-PCI

Specifies that the interrupt source is the Fastcom® 422/2-PCI board.

FastComm 422/2-PCI-335

Specifies that the interrupt source is the Fastcom 422/2-PCI-335 board.

FastComm 422/4-PCI-335

Specifies that the interrupt source is the Fastcom 422/4-PCI-335 board.

GE_Fanuc(VMIC)_PCI-5565

Specifies that the interrupt source is the GE® Fanuc VMIC PCI-5565 board.

General Standards 24DSI12

Specifies that the interrupt source is the General Standards 24DSI12 board.

Parallel_Port

Specifies that the interrupt source is the parallel port of the target computer.

Quatech DSCP-200/300

Specifies that the interrupt source is the Quatech® DSCP-200/300 board.

Quatech ESC-100

Specifies that the interrupt source is the Quatech ESC-100 board.

Quatech QSC-100

Specifies that the interrupt source is the Quatech QSC-100 board.

Quatech QSC-200/300

Specifies that the interrupt source is the Quatech QSC-200/300 board.

RTD_DM6804

Specifies that the interrupt source is the Real-Time Devices DM6804 board.

SBS_25x0_ID_0x100

Specifies that the interrupt source is an SBS Technologies shared memory board associated with ID 0x100.

SBS_25x0_ID_0x101

Specifies that the interrupt source is an SBS Technologies shared memory board associated with ID 0x101.

SBS_25x0_ID_0x102

Specifies that the interrupt source is an SBS Technologies shared memory board associated with ID 0x102.

SBS_25x0_ID_0x103

Specifies that the interrupt source is an SBS Technologies shared memory board associated with ID 0x103.

Scramnet_SC150+

Specifies that the interrupt source is the Systran® Scramnet+ SC150 board.

Softing_CAN-AC2-104

Specifies that the interrupt source is the Softing® CAN-AC2-104 board.

Softing_CAN-AC2-PCI

Specifies that the interrupt source is the Softing CAN-AC2-PCI board.

Speedgoat_IO301

Specifies that the interrupt source is the Speedgoat IO301 FPGA board.

Speedgoat_IO302

Specifies that the interrupt source is the Speedgoat IO302 FPGA board.

Speedgoat_IO303

Specifies that the interrupt source is the Speedgoat IO303 FPGA board.

Speedgoat_IO311

Specifies that the interrupt source is the Speedgoat IO311 FPGA board.

Speedgoat_IO312

Specifies that the interrupt source is the Speedgoat IO312 FPGA board.

Speedgoat_IO313

Specifies that the interrupt source is the Speedgoat IO313 FPGA board.

Speedgoat_IO314

Specifies that the interrupt source is the Speedgoat IO314 FPGA board.

Speedgoat_IO321

Specifies that the interrupt source is the Speedgoat IO321 FPGA board.

Speedgoat_IO331

Specifies that the interrupt source is the Speedgoat IO331 FPGA board.

UEI_MF x

Specifies that the interrupt source is a United Electronic Industries UEI-MF series board.

None/Other

Specifies that the I/O board has no interrupt source.

Command-Line Information

Parameter: xPCIRQSourceBoard

Type: string

Value: 'ATI-RP-R5' |
'AudioPMC+' |
'Bitflow NEON' |
'Busmirror EB5100' |

'CB_CIO-CTR05' |
'CB_PCI-CTR05' |
'Diamond_MM-32' |
'FastComm 422/2-PCI' |
'FastComm 422/2-PCI-335' |
'FastComm 422/4-PCI-335' |
'GE_Fanuc(VMIC)_PCI-5565' |
'General Standards 24DSI12' |
'Parallel_Port' |
'Quatech DSCP-200/300' |
'Quatech ESC-100' |
'Quatech QSC-100' |
'Quatech QSC-200/300' |
'RTD_DM6804' |
'SBS_25x0_ID_0x100' |
'SBS_25x0_ID_0x101' |
'SBS_25x0_ID_0x102' |
'SBS_25x0_ID_0x103' |
'Scramnet_SC150+' |
'Softing_CAN-AC2-104' |
'Softing_CAN-AC2-PCI' |
'Speedgoat_I0301' |
'Speedgoat_I0302' |
'Speedgoat_I0303' |
'Speedgoat_I0311' |
'Speedgoat_I0312' |
'Speedgoat_I0313' |
'Speedgoat_I0314' |
'Speedgoat_I0321' |
'Speedgoat_I0331' |
'UEI_MFx' |
'None/Other'

Default: 'None/Other'

See Also

“Set Configuration Parameters”

PCI slot (-1: autosearch) or ISA base address

Enter the slot number or base address for the I/O board generating the interrupt.

Settings

Default: -1

The PCI slot can be either -1 (let the Simulink Real-Time software determine the slot number) or of the form [bus, slot].

The base address is a hexadecimal number of the form 0x300.

Tip

To determine the bus and PCI slot number of the boards in the target computer, in the Command Window, type:

```
tg = slrt;  
tg.getPCIInfo
```

Command-Line Information

Parameter: xPCIOIRQSlot

Type: string

Value: '-1' | hexadecimal value

Default: '-1'

See Also

“Simulink Real-Time Options Configuration Parameters”

“PCI Bus I/O Devices”

Log Task Execution Time

Log task execution times to the target object property `tg.TETlog`.

Settings

Default: on



On

Logs task execution times to the target object property `tg.TETlog`.



Off

Does not log task execution times to the target object property `tg.TETlog`.

Command-Line Information

Parameter: RL32LogTETModifier

Type: string

Value: 'on' | 'off'

Default: 'on'

See Also

“Simulink Real-Time Options Configuration Parameters”

“Signal Logging Basics”

Signal logging data buffer size in doubles

Enter the maximum number of sample points to save before wrapping.

Settings

Default: 100000

The maximum value for this option cannot exceed the available target computer memory, which the Simulink Real-Time software also uses to hold other items.

Tips

- Target applications use this buffer to store the time, states, outputs, and task execution time (TET) logs as defined in the Simulink model.
- The maximum value for this option derives from available target computer memory, which the Simulink Real-Time software also uses to hold other items. For example, in addition to signal logging data, the software also uses the target computer memory for the Simulink Real-Time kernel, target application, and scopes.

For example, assume that your model has six data items (time, two states, two outputs, and task execution time). If you enter a buffer size of 100000, the target object property `tg.MaxLogSamples` is calculated as $\text{floor}(100000 / 6) = 16666$. After the buffer saves 16666 sample points, it wraps and further samples overwrite the older ones.

- If you enter a logging buffer size larger than the available RAM on the target computer, after downloading and initializing the target application, the target computer displays a message, `ERROR: allocation of logging memory failed`. To avoid this error, either install more RAM or reduce the buffer size for logging, and then reboot the target computer. To calculate the maximum buffer size you might have for your target application logs, divide the amount of available RAM on your target computer by `sizeof(double)`, or 8. Enter that value for the **Signal logging data buffer size in doubles** value.

Command-Line Information

Parameter: `RL32LogBufSizeModifier`

Type: string

Value: '100000' | any valid memory size

Default: '100000'

See Also

“Simulink Real-Time Options Configuration Parameters”

Number of events (each uses 20 bytes)

Enter the maximum of events to log for the profiling tool.

Settings

Default: 5000

The maximum number of events to be logged for the profiling tool.

Tips

- An event is the start or end of an interrupt or iteration of the model. For example, one sample can have four events: the beginning and end of an interrupt, and the beginning and end of an iteration.
- Each event contains information such as the CPU ID, model thread ID (TID), event ID, and time stamp readings. Each event occupies 20 bytes.

Command-Line Information

Parameter: xPCRL32EventNumber

Type: string

Value: any valid number of events

Default: '5000'

See Also

“Execution Profiling for Target Applications”

Double buffer parameter changes

Use a double buffer for parameter tuning. This enables parameter tuning so that the process of changing parameters in the target application uses a double buffer.

Settings

Default: off



On

Changes parameter tuning to use a double buffer.



Off

Suppresses double buffering of parameter changes in the target application.

Tips

- When a parameter change request is received, the new value is compared to the old one. If the new value is identical to the old one, it is discarded, and if different, it is queued.
- At the start of execution of the next sample of the real-time task, the queued parameters are updated. This means that parameter tuning affects the task execution time (TET), and the very act of parameter tuning can cause a CPU overload error.
- Double buffering leads to a more robust parameter tuning interface, but it increases task execution time and the higher probability of overloads. Under typical conditions, keep double buffering off (default).

Command-Line Information

Parameter: xpcDblBuff

Type: string

Value: 'on' | 'off'

Default: 'off'

See Also

“Simulink Real-Time Options Configuration Parameters”

Load a parameter set from a file on the designated target file system

Automatically load a parameter set from a file on the designated target computer file system.

Settings

Default: off



On

Enable the automatic loading of a parameter set from the file specified by **File name** on the designated target computer file system.



Off

Suppress the automatic loading of a parameter set from a file on the designated target computer file system.

Dependencies

This parameter enables **File name**.

Command-Line Information

Parameter: xPCLoadParamSetFile

Type: string

Value: 'on' | 'off'

Default: 'off'

See Also

“Simulink Real-Time Options Configuration Parameters”

“Save and Reload Parameters Using MATLAB Language”

File name

Specify the target computer file name from which to load the parameter set.

Settings

''

Tip

If the named file does not exist, the software loads the parameter set built with the model.

Dependencies

This parameter is enabled by **Load a parameter set from a file on the designated target file system**.

Command-Line Information

Parameter: xPCOnTgtParamSetFileName

Type: string

Value: Any valid file name

Default: ''

See Also

“Simulink Real-Time Options Configuration Parameters”

Build COM objects from tagged signals/parameters

Enable build process to create a model-specific COM library file.

Settings

Default: off



On

Creates a model-specific COM library file, <model_name>COMiface.dll.



Off

Does not create a model-specific COM library file.

Tip

Use the model-specific COM library file to create custom GUIs with Visual Basic or other tools that can use COM objects.

Command-Line Information

Parameter: xpcObjCom

Type: string

Value: 'on' | 'off'

Default: 'off'

Generate CANape extensions

Enable target applications to generate data, such as that for A2L, for Vector CANape®.

Settings

Default: off



On

Enables target applications to generate data, such as that for A2L, for Vector CANape.



Off

Does not enable target applications to generate data, such as that for A2L, for Vector CANape.

Command-Line Information

Parameter: xPCGenerateASAP2

Type: string

Value: 'on' | 'off'

Default: 'off'

See Also

“Configuring the Vector CANape Device”

Include model hierarchy on the target application

Includes the Simulink model hierarchy as part of the target application.

Settings

Default: off



On

Includes the model hierarchy as part of the target application.



Off

Excludes the model hierarchy from the target application.

Tips

Including the model hierarchy in the target application:

- Lets you connect to the target computer from Simulink Real-Time Explorer without being in the target application build folder.
- Can increase the size of the target application, depending on the size of the model.

Command-Line Information

Parameter: xPCGenerateXML

Type: string

Value: 'on' | 'off'

Default: 'off'

See Also

“Monitor Signals Using Simulink Real-Time Explorer”

Enable Stateflow animation

Enables visualization of Stateflow® chart animation.

Settings

Default: off



On

Enables visualization of Stateflow chart animation.



Off

Disables visualization of Stateflow chart animation.

Command-Line Information

Parameter: xPCEnableSFAnimation

Type: string

Value: 'on' | 'off'

Default: 'off'

See Also


“Animate Stateflow Charts Using Simulink External Mode”

Using Simulink Real-Time Explorer Instruments

- “Instrumenting a Model” on page 5-2
- “Create Instrument Panel” on page 5-4
- “Configure Instrument for Set Point Parameter” on page 5-5
- “Configure Instrument for Tank Level Signal” on page 5-7
- “Run Instrumented Model” on page 5-9
- “Instruments — Alphabetical List” on page 5-11



Instrumenting a Model

In this example, based upon the xpctank model, you create an instrument panel that controls the tank level set point and displays the change in tank level in response to changes in set point.



Tank Level Control System

You must have already completed the following setup:

- 1 Built and downloaded the target application to the target computer using Simulink ( on the toolbar).
- 2 Run Simulink Real-Time Explorer (command `slrtexplr`).
- 3 Connected to the target computer in the **Targets** pane ( on the toolbar).


To instrument the xpctank model, perform these steps:

- 1 “Create Instrument Panel” on page 5-4
- 2 “Configure Instrument for Set Point Parameter” on page 5-5

3 “Configure Instrument for Tank Level Signal” on page 5-7

The next task is “Run Instrumented Model” on page 5-9.



Create Instrument Panel

- 1** In the **Panels** pane, right-click on the **Instrument Panels** node, and then click **Add New**.
- 2** Type a name and folder in the **Name** and **Location** text boxes. Give the panel a name like `xpctank_instr.slrtip`.
- 3** Click the Save icon  to save your instrument panel.


The next task is “Configure Instrument for Set Point Parameter” on page 5-5.

Configure Instrument for Set Point Parameter


You must have previously created the `xpctank_instr.slrtip` instrument panel.

- 1 From the **Palette** pane, drag a Slider instrument into the `xpctank_instr.slrtip` instrument panel.
- 2 Open the Parameter workspace for model `xpctank` ( on the toolbar).
- 3 In the Parameter workspace, select the Parameter icon  next to parameter `SetPoint` and drag it to the Slider instrument.


A small copy of the Parameter icon appears next to the Slider instrument.

- 4 Select the Slider instrument, and then click the Tasks icon  in the top right corner.
- 5 In the **Slider Tasks** dialog box, set property **Min** to 0 and property **Span** to 10.
- 6 From the **Palette** pane, drag a Label layout item to under the Slider instrument.
- 7 Click the Label element.
- 8 In the **Properties** pane, scroll down to the **Appearance** node. Set the **Text** property to `Set Point`.
- 9 Scroll down to the **TextAlign** property. Click the down arrow and select the center of the nine blocks presented.

The **TextAlign** property becomes `MiddleCenter`.

- 10 Click the Save icon  to save your instrument panel.

At the end of this task, the Simulink Real-Time Explorer window looks like this figure.





You can set the exact value of parameter `SetPoint` using, for example, a `NumericEntry` instrument.


The next task is “Configure Instrument for Tank Level Signal” on page 5-7.

Configure Instrument for Tank Level Signal


You must have previously created the `xpctank_instr.slrtip` instrument panel.

- 1 From the **Palette** pane, drag a `GaugeFluidLevel` instrument into the `xpctank_instr.slrtip` instrument panel.
- 2 Open the Signal workspace for model `xpctank` ( on the toolbar).
- 3 In the Signals workspace, select the Signal icon  next to signal `TankLevel` and drag it to the `Slider` instrument.


A small copy of the Signal icon appears next to the `Slider` instrument.

- 4 Select the `GaugeFluidLevel` instrument, and then click the **Tasks** icon  in the top right corner.
- 5 In the **GaugeFluidLevel Tasks** dialog box, set property **Min** to 0 and property **Span** to 10.
- 6 From the **Palette** pane, drag a `Label` layout item to under the `GaugeFluidLevel` instrument.
- 7 Click the `Label` element.
- 8 In the **Properties** pane, scroll down to the **Appearance** node. Set the **Text** property to `Tank Level`.
- 9 Scroll down to the **TextAlign** property. Click the down arrow and select the center of the nine blocks presented.

The **TextAlign** property becomes `MiddleCenter`.

- 10 Click the **Save** icon  to save your instrument panel.

At the end of this task, the Simulink Real-Time Explorer window looks like this figure.






You can view the exact value of signal TankLevel1 using, for example, a NumericDisplay instrument.


The next task is “Run Instrumented Model” on page 5-9.


Run Instrumented Model


This example shows how to run an instrumented model. Before carrying out this procedure, you must have performed the steps in “Instrumenting a Model” on page 5-2.

- 1** Set property **Stop time** to `inf` in the **Applications** pane ( on the toolbar).
- 2** To start the instrument, in the `xpctank_instr.slrtip` instrument panel, click the Run Instrument icon .
- 3** To start execution, in the **Applications** pane, click the target application, and then click the Start icon  on the toolbar.
- 4** Using the Slider instrument, set the tank level to the required value, such as 5.

The tank level rises to and oscillates around the set point, as shown in this figure.



5 To stop execution, in the **Applications** pane, click the target application, and then click the Stop icon  on the toolbar.

6 To stop the instruments, in the `xpctank_instr.slrtp` instrument panel, click the Stop Instrument icon .


Instruments – Alphabetical List

GaugeAngular
GaugeFluidLevel
GaugeLinear
GroupBox
HexadecimalDisplay
Knob
Label
LED
NumericDisplay
NumericEntry
NumericUpDownEntry
Panel
PictureBox
Slider
SwitchLED

GaugeAngular

Purpose

Graphic instrument to display signal values





Description

Use the GaugeAngular instrument to display real-valued data suitable for an angular gauge, such as pressure, speed, and current.

Key Parameters

The key parameters are under the **Instrument** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

Scale Graphic Display

The root node of this parameter is **Instrument**.

Parameter	Usage
AutoSize	If True, size the graphic to accommodate the parts of the display

The root node of these parameters is
→**Instrument**→**ScaleDisplay**→**GeneratorAuto**.

Parameter	Usage
DesiredIncrement	Display of major tick values. number of labels = $\text{span} / (\text{desired increment} + 1)$. Does nothing if the required labels do not fit in the space available in the graphic.
FixedMinMaxMajor	If True , the top and bottom ticks are constrained to be major ticks with min/max values defined by Min and Span
MidIncluded	If True , insert a tick halfway between major ticks. If MinorCount is even, space the minor ticks equally around the center tick. If MinorCount is odd, replace the center tick with the middle tick. If
MinorCount	Number of minor ticks between major ticks
MinTextSpacing	Minimum space between scale ticks

Scale Text Display

The root node of these parameters is
→**Instrument**→**ScaleDisplay**→**TextFormatting**.

Parameter	Usage
Precision	Number of digits to the right of the decimal point
PrecisionStyle	One of FixedDecimalPoints , SignificantDigits , None

GaugeAngular

Style	One of Number, Thousands, Prefix, Exponent, Price32nds, DateTime, DateTimeUTC
UnitsText	Display unit next to tick labels

General Scale Range

The root node of these parameters is →**Instrument**→**ScaleRange**.

Parameter	Usage
Min	Minimum possible value
Reverse	If True, flip the display to increase in the opposite direction
ScaleType	One of Linear, Log10, and SplitLinearLog10
Span	Number of values between the min and max values


Angular Scale Range

The root node of these parameters is →**Instrument**→**ScaleRange**.

Parameter	Usage
AngleMin	Specify starting point of scale, from bottom of circle
AngleSpan	Specify number of degrees taken up by scale

Purpose

Graphic instrument to display values of fluid sensor signals





Description

Use the GaugeFluidLevel instrument to display real-valued data suitable for a fluid gauge, such as volume and pressure.

Key Parameters

The key parameters are under the **Instrument** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

Scale Graphic Display

The root node of this parameter is **Instrument**.

Parameter	Usage
AutoSize	If True, size the graphic to accommodate the parts of the display

The root node of these parameters is
→**Instrument**→**ScaleDisplay**→**GeneratorAuto**.

GaugeFluidLevel

Parameter	Usage
DesiredIncrement	Display of major tick values. number of labels = $\text{span} / (\text{desired increment} + 1)$. Does nothing if the required labels do not fit in the space available in the graphic.
FixedMinMaxMajor	If True , the top and bottom ticks are constrained to be major ticks with min/max values defined by Min and Span
MidIncluded	If True , insert a tick halfway between major ticks. If MinorCount is even, space the minor ticks equally around the center tick. If MinorCount is odd, replace the center tick with the middle tick. If
MinorCount	Number of minor ticks between major ticks
MinTextSpacing	Minimum space between scale ticks

Scale Text Display

The root node of these parameters is
→**Instrument**→**ScaleDisplay**→**TextFormatting**.

Parameter	Usage
Precision	Number of digits to the right of the decimal point
PrecisionStyle	One of FixedDecimalPoints , SignificantDigits , None

Style	One of Number, Thousands, Prefix, Exponent, Price32nds, DateTime, DateTimeUTC
UnitsText	Display unit next to tick labels

General Scale Range


The root node of these parameters is →**Instrument**→**ScaleRange**.

Parameter	Usage
Min	Minimum possible value
Reverse	If True, flip the display to increase in the opposite direction
ScaleType	One of Linear, Log10, and SplitLinearLog10
Span	Number of values between the min and max values

GaugeLinear

Purpose

Graphic instrument to display signal values





Description

Use the GaugeLinear instrument to display real-valued data suitable for a linear gauge, such as temperature, volume, and pressure.

Key Parameters

The key parameters are under the **Instrument** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

Scale Graphic Display

The root node of this parameter is **Instrument**.

Parameter	Usage
AutoSize	If True, size the graphic to accommodate the parts of the display

The root node of these parameters is
→**Instrument**→**ScaleDisplay**→**GeneratorAuto**.

Parameter	Usage
DesiredIncrement	Display of major tick values. number of labels = $\text{span} / (\text{desired increment} + 1)$. Does nothing if the required labels do not fit in the space available in the graphic.
FixedMinMaxMajor	If True , the top and bottom ticks are constrained to be major ticks with min/max values defined by Min and Span
MidIncluded	If True , insert a tick halfway between major ticks. If MinorCount is even, space the minor ticks equally around the center tick. If MinorCount is odd, replace the center tick with the middle tick. If
MinorCount	Number of minor ticks between major ticks
MinTextSpacing	Minimum space between scale ticks

Scale Text Display

The root node of these parameters is
 →**Instrument**→**ScaleDisplay**→**TextFormatting**.

Parameter	Usage
Precision	Number of digits to the right of the decimal point
PrecisionStyle	One of FixedDecimalPoints , SignificantDigits , None

GaugeLinear

Style	One of Number, Thousands, Prefix, Exponent, Price32nds, DateTime, DateTimeUTC
UnitsText	Display unit next to tick labels


General Scale Range

The root node of these parameters is →**Instrument**→**ScaleRange**.

Parameter	Usage
Min	Minimum possible value
Reverse	If True, flip the display to increase in the opposite direction
ScaleType	One of Linear, Log10, and SplitLinearLog10
Span	Number of values between the min and max values

Purpose

Nonscrollable graphic container for instruments



Description

The **GroupBox** graphic provides a container for other instruments. It can be stretched and shrunk at design time, but cannot be scrolled.

Key Parameters

The key parameters are under the **Layout** node in the property list.

Parameter	Usage
AutoSize	If True, the box expands at design time to make visible the instruments within it
AutoSizeMode	Possible values are <code>GrowAndShrink</code> and <code>GrowOnly</code> . The default is <code>GrowOnly</code> .

HexadecimalDisplay

Purpose Text box instrument to display signal values



Description



The **HexadecimalDisplay** instrument displays numerical data in hexadecimal format. It is used for digital data, such as status codes and register contents.


Key Parameters

The key parameters are under the **Instrument** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

Parameter	Usage
AutoSize	If True, the box expands at design time to make visible the specified digits. The default is True.
DigitCount	Number of hex digits to be displayed
DigitLeading	Possible values are None and Zeros.

Purpose Graphic instrument to set parameter values





Description

Use the **Knob** instrument to set real-valued data such as amplitude and frequency under conditions where an exact value is not required.

Key Parameters

The key parameters are under the **Instrument** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

Offswitch Graphic Display

The root node of this parameter is →**Instrument**→**OffSwitch**.

Parameter	Usage
Enabled	If True, the switch is visible
On	If True, the switch is on

Scale Graphic Display

The root node of this parameter is **Instrument**.

Parameter	Usage
AutoSize	If True, size the graphic to accommodate the parts of the display

The root node of these parameters is
→**Instrument**→**ScaleDisplay**→**GeneratorAuto**.

Parameter	Usage
DesiredIncrement	Display of major tick values. number of labels = $\text{span}/(\text{desired increment} + 1)$. Does nothing if the required labels do not fit in the space available in the graphic.
FixedMinMaxMajor	If True , the top and bottom ticks are constrained to be major ticks with min/max values defined by Min and Span
MidIncluded	If True , insert a tick halfway between major ticks. If MinorCount is even, space the minor ticks equally around the center tick. If MinorCount is odd, replace the center tick with the middle tick. If
MinorCount	Number of minor ticks between major ticks
MinTextSpacing	Minimum space between scale ticks

Scale Text Display

The root node of these parameters is
→**Instrument**→**ScaleDisplay**→**TextFormatting**.

Parameter	Usage
Precision	Number of digits to the right of the decimal point

PrecisionStyle	One of FixedDecimalPoints, SignificantDigits, None
Style	One of Number, Thousands, Prefix, Exponent, Price32nds, DateTime, DateTimeUTC
UnitsText	Display unit next to tick labels

General Scale Range

The root node of these parameters is →**Instrument**→**ScaleRange**.

Parameter	Usage
Min	Minimum possible value
Reverse	If True, flip the display to increase in the opposite direction
ScaleType	One of Linear, Log10, and SplitLinearLog10
Span	Number of values between the min and max values

Angular Scale Range

The root node of these parameters is →**Instrument**→**ScaleRange**.

Parameter	Usage
AngleMin	Specify starting point of scale, from bottom of circle
AngleSpan	Specify number of degrees taken up by scale

Label

Purpose Graphic container for text

Description

Label


Use the **Label** graphic to add text to the instrument layout.

Key Parameters

The key parameters are under the **Appearance** and **Layout** nodes in the property list.

Appearance Parameters

The root node of these parameters is **Appearance**.

Parameter	Usage
Text	Contains the text displayed by the label
TextAlign	Specifies left-right, top-bottom alignment using a 3x3 matrix. This display represents setting TopLeft. 

Layout Parameters

The root node of this parameter is **Layout**.

Parameter	Usage
AutoSize	If True, size the graphic to accommodate the text

Purpose Graphic instrument to display signal values



Description



Use the **LED** instrument to display binary (1 or 0) data.

Key Parameters

The key parameters are under the **Instrument** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

General Parameters

The root node of these parameters is **Instrument**.

Parameter	Usage
AutoSize	If True, size the graphic to accommodate the specified graphic parameters.
BlinkerEnable	If True, LED graphic blinks continuously.

Indicator Parameters

The root node of these parameters is →**Instrument**→**Indicator**.

Parameter	Usage
ColorActive	Indicator color if signal value is 1.
ColorInactive	Indicator color if signal value is 0.

NumericDisplay

Purpose Text box instrument to display signal values



Description



Use the **NumericDisplay** instrument to display real-valued data in selected formats.

Key Parameters

The key parameters are under the **Instrument** and **Iocomp** nodes in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

General Parameters

The root node of this parameter is **Instrument**.

Parameter	Usage
AutoSize	If True, the box expands at design time to make visible the specified digits. The default is True.

Value Display

The root node of these parameters is →**Iocomp**→**TextFormatting**.


Parameter	Usage
Precision	Number of digits to the right of the decimal point
PrecisionStyle	One of FixedDecimalPoints, SignificantDigits, None

Style	One of Number, Thousands, Prefix, Exponent, Price32nds, DateTime, DateTimeUTC
UnitsText	Display unit next to tick labels

NumericEntry

Purpose Text box instrument to set parameter values



Description



Use the **NumericEntry** instrument to enter real-valued data in selected formats under conditions where an exact value is required.

Key Parameters

The key parameters are under the **Instrument** node in the property list.


To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

Text Display

The root node of these parameters is →**Instrument**→**TextFormatting**.

Parameter	Usage
Precision	Number of digits to the right of the decimal point
PrecisionStyle	One of FixedDecimalPoints, SignificantDigits, None
Style	One of Number, Thousands, Prefix, Exponent, Price32nds, DateTime, DateTimeUTC
UnitsText	Display unit next to tick labels



Purpose Text box instrument to set parameter values



Use the **NumericUpDownEntry** instrument to enter real-valued data and increment it by a specified amount under conditions where a step change is required.

Key Parameters

The key parameters are under the **Layout** and **Data** nodes in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

General Parameters

The root node of this parameter is **Layout**.

Parameter	Usage
AutoSize	If True, the box expands at design time to make visible the specified digits. The default is False.

Scale Range

The root node of these parameters is **Data**.

Parameter	Usage
DecimalPlaces	Number of decimal places to display
Increment	Value to add or subtract in response to an up-arrow or down-arrow

NumericUpDownEntry

Maximum	Maximum data value
Minimum	Minimum data value

Purpose Scrollable graphic container for instruments



Description

The **Panel** graphic provides a container for other instruments. You can stretch and shrink it at design time and scroll it at run time.

Key Parameters

The key parameters are under the **Layout** node in the property list.

Parameter	Usage
AutoScroll	If True, the box scrolls at run time to make fully visible partially-visible instruments within it.
AutoSize	If True, the box expands at design time to make visible the instruments within it.
AutoSizeMode	Possible values are <code>GrowAndShrink</code> and <code>GrowOnly</code> . The default is <code>GrowOnly</code>

PictureBox

Purpose Graphic container for pictures





Description

The **PictureBox** graphic provides a container for graphics, for example a photograph or line drawing.


Key Parameters

The key parameter is under the **Behavior** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

Parameter	Usage
SizeMode	Possible values are Normal, StretchImage, AutoSize, CenterImage, and Zoom. The default is Normal

Purpose Graphic instrument to set parameter values





Description

Use the **Slider** instrument to set real-valued data such as temperature and pressure under conditions where the exact value is not required.

Key Parameters

The key parameters are under the **Instrument** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

Scale Graphic Display

The root node of this parameter is **Instrument**.

Parameter	Usage
AutoSize	If True, size the graphic to accommodate the parts of the display

The root node of these parameters is
 →**Instrument**→**ScaleDisplay**→**GeneratorAuto**.

Slider

Parameter	Usage
DesiredIncrement	Display of major tick values. number of labels = $\text{span} / (\text{desired increment} + 1)$. Does nothing if the required labels do not fit in the space available in the graphic.
FixedMinMaxMajor	If True , the top and bottom ticks are constrained to be major ticks with min/max values defined by Min and Span
MidIncluded	If True , insert a tick halfway between major ticks. If MinorCount is even, space the minor ticks equally around the center tick. If MinorCount is odd, replace the center tick with the middle tick. If
MinorCount	Number of minor ticks between major ticks
MinTextSpacing	Minimum space between scale ticks

Scale Text Display

The root node of these parameters is
→**Instrument**→**ScaleDisplay**→**TextFormatting**.

Parameter	Usage
Precision	Number of digits to the right of the decimal point
PrecisionStyle	One of FixedDecimalPoints , SignificantDigits , None

Style	One of Number, Thousands, Prefix, Exponent, Price32nds, DateTime, DateTimeUTC
UnitsText	Display unit next to tick labels

General Scale Range

The root node of these parameters is →**Instrument**→**ScaleRange**.

Parameter	Usage
Min	Minimum possible value
Reverse	If True, flip the display to increase in the opposite direction
ScaleType	One of Linear, Log10, and SplitLinearLog10
Span	Number of values between the min and max values

SwitchLED

Purpose Graphic instrument to set parameter values



Description



Use the **SwitchLED** instrument to set a binary (1 or 0) status.

Key Parameters

The key parameters are under the **Instrument** node in the property list.

To access a parameter dialog box for the instrument as a whole, select the instrument and click the Tasks icon  in the top right corner. To access a dialog box for a parameter group, click the group, and then click the continuation dots  to the right of the group.

General Parameters

The root node of these parameters is **Instrument**.

Parameter	Usage
AutoSize	If True, size the graphic to accommodate the specified graphic parameters.
Text	Receives visible text on switch.

Indicator Parameters

The root node of these parameters is →**Instrument**→**Indicator**.

Parameter	Usage
ColorActive	Indicator color if signal value is 1.
ColorInactive	Indicator color if signal value is 0.

Target Computer Command-Line Interface Reference

Target Computer Commands

You have a limited set of commands that you can use to work the target application after it has been loaded to the target computer, and to interface with the scopes for that application.

The target computer command-line interface enables you to work with target and scope objects in a limited capacity. Methods let you interact directly with the scope or target. Property commands let you work with target and scope properties. Variable commands let you alias target computer command-line interface commands to names of your choice.

Refer to “Control Application at Target Computer Command Line” for a description of how to use these methods and commands.

In this section...
“Target Object Methods” on page 6-2
“Target Object Property Commands” on page 6-3
“Scope Object Methods” on page 6-5
“Scope Object Property Commands” on page 6-6
“Aliasing with Variable Commands” on page 6-8

Target Object Methods

When you are using the target computer command-line interface, target object methods are limited to starting and stopping the target application.

The following table lists the syntax for the target commands that you can use on the target computer. The equivalent MATLAB syntax is shown in the right column, and the target object name `tg` is used as an example for the MATLAB methods. These methods assume that you have already loaded the target application onto the target computer.

Target Computer Command	Description and Syntax	MATLAB Equivalent
start	Start the target application currently loaded on the target computer. Syntax: start	tg.start or +tg
stop	Stop the target application currently running on the target computer. Syntax: stop	tg.stop or -tg
reboot	Reboot the target computer. Syntax: reboot	tg.reboot

Target Object Property Commands

When you are using the target computer command-line interface, target object properties are limited to parameters, signals, stop time, and sample time. Note the difference between a parameter index (0, 1, . . .) and a parameter name (P0, P1, . . .).

The following table lists the syntax for the target commands that you can use to manipulate target object properties. The MATLAB equivalent syntax is shown in the right column, and the target object name `tg` is used as an example for the MATLAB methods.

Target Computer Command	Description and Syntax	MATLAB Equivalent
getpar	Display the value of a block parameter using the parameter index. Syntax: getpar parameter_index	get(tg, 'parameter_name')
setpar	Change the value of a block parameter using the parameter index. Syntax: setpar parameter_index = floating_point_number	set(tg, 'parameter_name', number)
stoptime	Enter a new stop time. Use inf to run the target application until you manually stop it or reset the target computer. Syntax: stoptime = floating_point_number	tg.stoptime = number
sampletime	Enter a new sample time. Syntax: sampletime = floating_point_number	tg.sampletime = number set(tg, 'SampleTime', number)

Target Computer Command	Description and Syntax	MATLAB Equivalent
P#	Display the value of a block parameter. For example, P2. Syntax: parameter_name. parameter_name is P0, P1, . . .	tg.getparam(parameter_index)
S#	Display the value of a signal. For example, S2. Syntax: signal_name signal_name is S0, S1,	tg.getsignal(signal_index)

Scope Object Methods

When using the target computer command-line interface, you use scope object methods to start a scope and add signal traces. Notice that the methods `addscope` and `remscope` are target object methods on the host computer, and notice the difference between a signal index (0, 1, . . .) and a signal name (S0, S1, . . .).

The following table lists the syntax for the target commands that you can use on the target computer. The MATLAB equivalent syntax is shown in the right column. The target object name `tg` and the scope object name `sc` are used as an example for the MATLAB methods.

Target Computer Command	Description and Syntax	MATLAB Equivalent
<code>addscope</code>	<code>addscope scope_index</code> <code>addscope</code>	<code>tg.addscope(scope_index)</code> <code>tg.addscope</code>
<code>remscope</code>	<code>remscope scope_index</code> <code>remscope all</code>	<code>tg.remscope(scope_index)</code> <code>tg.remscope</code>

Target Computer Command	Description and Syntax	MATLAB Equivalent
startscope	startscope scope_index	sc.start or +sc
stopscope	stopscope scope_index	sc.stop or -sc
addsignal	addsignal scope_index = signal_index1, signal_index2, . . .	sc.addsignal(signal_index_vector)
remsignal	remsignal scope_index = signal_index1, signal_index2, . . .	sc.remsignal(signal_index_vector)
viewmode	Zoom in to one scope or zoom out to all scopes. Syntax: viewmode scope_index viewmode 'all'	tg.viewMode = scope_index tg.viewMode = 'all'
ylim	ylim scope_index ylim scope_index = auto ylim scope_index = num1, num2	sc.YLimit sc.YLimit='auto' sc.YLimit([num1 num2])
grid	grid scope_index on grid scope_index off	sc.Grid = on sc.Grid = off

Scope Object Property Commands

When you use the target computer command-line interface, scope object properties are limited to those shown in the following table. Notice the difference between a scope index (0, 1, . . .) and the MATLAB variable name for the scope object on the host computer. The scope index is indicated in the top left corner of a scope window (SC0, SC1, . . .).

If a scope is running, you need to stop the scope before you can change a scope property.

The following table lists the syntax for the target commands that you can use on the target computer. The equivalent MATLAB syntax is shown in the right column, and the scope object name `sc` is used as an example for the MATLAB methods

Target Computer Command	MATLAB Equivalent
<code>numsamples scope_index = number</code>	<code>sc.NumSamples = number</code>
<code>decimation scope_index= number</code>	<code>sc.Decimation = number</code>
<code>scopemode scope_index = 0 or numerical, 1 or redraw, 2 or sliding, 3 or rolling</code>	<code>sc.Mode = 'numerical', 'redraw', 'sliding', 'rolling'</code>
<code>triggermode scope_index = 0, freerun, 1, software, 2, signal, 3, scope</code>	<code>sc.TriggerMode = 'freerun', 'software', 'signal', 'scope'</code>
<code>numprepostsamples scope_index = number</code>	<code>sc.NumPrePostSamples = number</code>
<code>triggersignal scope_index = signal_index</code>	<code>sc.TriggerSignal = signal_index</code>
<code>triggersample scope_index = number</code>	<code>sc.TriggerSample = number</code>
<code>triggerlevel scope_index = number</code>	<code>sc.TriggerLevel = number</code>
<code>triggerslope scope_index = 0, either, 1, rising, 2, falling</code>	<code>sc.TriggerSlope = 'Either', 'Rising', 'Falling'</code>
<code>triggerscope scope_index2 = scope_index1</code>	<code>sc.TriggerScope = scope_index1</code>
<code>triggerscopesample scope_index= integer</code>	<code>sc.TriggerScopeSample = integer</code>
Press the function key for the scope, and then press S .	<code>sc.trigger</code>

Aliasing with Variable Commands

The following table lists the syntax for the aliasing variable commands that you can use on the target computer. The MATLAB equivalent syntax is shown in the right column. For a usage example, see “Alias Commands at Target Computer Command Line”.

Target Computer Command	Description and Syntax	MATLAB Equivalent
setvar	Set a variable to a value. Later you can use that variable to do a macro expansion. Syntax: <code>setvar variable_name = target_pc_command</code> For example, you can type <code>setvar aa=startscope 2, setvar bb=stopscope 2</code> .	None
getvar	Display the value of a variable. Syntax: <code>getvar variable_name</code>	None
delvar	Delete a variable. Syntax: <code>delvar variable_name</code>	None
delallvar	Delete all variables. Syntax: <code>delallvar</code>	None
showvar	Display a list of variables. Syntax: <code>showvar</code>	None

Support Package Reference

Support Package Functions

Purpose Find and install support for third-party hardware or software

Syntax supportPackageInstaller


Description The supportPackageInstaller function opens *Support Package Installer*.

Support Package Installer can install *support packages*, which add support for specific third-party hardware or software to specific MathWorks products.

To see a list of available support packages, run Support Package Installer and advance to the second screen.

You can also start Support Package Installer in one of the following ways:

- On the MATLAB toolstrip, click **Add-Ons > Get Hardware Support Packages**.



- Double-click a support package installation file (*.mlpkginstall).

supportPackageInstaller

See Also

[targetUpdater](#) | [matlabshared.supportpkg.checkForUpdate](#) | [matlabshared.supportpkg.getInstalled](#)

Purpose Open Support Package Installer and install support for third-party hardware or software

Syntax targetinstaller

Description


Note This function has been superseded by supportPackageInstaller. Use supportPackageInstaller instead of targetinstaller.

The targetinstaller function opens *Support Package Installer*. Support Package Installer can install *support packages*, which add support for specific third-party hardware or software to specific MathWorks products. To see a list of available support packages, run Support Package Installer and advance to the second screen.

You can also start Support Package Installer in one of the following ways:

- On the MATLAB toolstrip, click **Add-Ons > Get Hardware Support Packages**.

targetinstaller



- Double-click a support package installation file (*.mlpkginstall).

See Also

`supportPackageInstaller` | `targetUpdater` |
`matlabshared.supportpkg.checkForUpdate` |
`matlabshared.supportpkg.getInstalled`

Purpose Open Support Package Installer and update firmware on third-party hardware

Syntax

Description The `targetupdater` function skips over the support package installation screens and opens Support Package Installer at the “Update firmware” screen. You can use this function to update the firmware on hardware without repeating the support package installation process.

Tip Use this function when you have multiple pieces of hardware.

The `targetupdater` function is only available for support packages that have already been installed and that require special firmware or setup steps.

If the **Hardware** parameter does not present an option for your hardware, use the `supportPackageInstaller` function to open Support Package Installer. Support Package Installer will guide you through the process of installing a support package for your hardware and, if required, updating the firmware.

See Also

`supportPackageInstaller` |
`matlabshared.supportpkg.checkForUpdate` |
`matlabshared.supportpkg.getInstalled`