

**Simulink® Real-Time™**

I/O Reference



**MATLAB® & SIMULINK®**

R2023a



## How to Contact MathWorks



Latest news: [www.mathworks.com](http://www.mathworks.com)  
Sales and services: [www.mathworks.com/sales\\_and\\_services](http://www.mathworks.com/sales_and_services)  
User community: [www.mathworks.com/matlabcentral](http://www.mathworks.com/matlabcentral)  
Technical support: [www.mathworks.com/support/contact\\_us](http://www.mathworks.com/support/contact_us)



Phone: 508-647-7000



The MathWorks, Inc.  
1 Apple Hill Drive  
Natick, MA 01760-2098

*Simulink® Real-Time™ I/O Reference*

© COPYRIGHT 2000–2023 by The MathWorks, Inc.

The software described in this document is furnished under a license agreement. The software may be used or copied only under the terms of the license agreement. No part of this manual may be photocopied or reproduced in any form without prior written consent from The MathWorks, Inc.

FEDERAL ACQUISITION: This provision applies to all acquisitions of the Program and Documentation by, for, or through the federal government of the United States. By accepting delivery of the Program or Documentation, the government hereby agrees that this software or documentation qualifies as commercial computer software or commercial computer software documentation as such terms are used or defined in FAR 12.212, DFARS Part 227.72, and DFARS 252.227-7014. Accordingly, the terms and conditions of this Agreement and only those rights specified in this Agreement, shall pertain to and govern the use, modification, reproduction, release, performance, display, and disclosure of the Program and Documentation by the federal government (or other entity acquiring for or through the federal government) and shall supersede any conflicting contractual terms or conditions. If this License fails to meet the government's needs or is inconsistent in any respect with federal procurement law, the government agrees to return the Program and Documentation, unused, to The MathWorks, Inc.

### Trademarks

MATLAB and Simulink are registered trademarks of The MathWorks, Inc. See [www.mathworks.com/trademarks](http://www.mathworks.com/trademarks) for a list of additional trademarks. Other product or brand names may be trademarks or registered trademarks of their respective holders.

### Patents

MathWorks products are protected by one or more U.S. patents. Please see [www.mathworks.com/patents](http://www.mathworks.com/patents) for more information.

## Revision History

November 2000	Online only	Revised for Version 1.1 (Release 12)
June 2001	Online only	Revised for Version 1.2 (Release 12.1)
September 2001	Online only	Revised for Version 1.3 (Release 12.1+)
July 2002	Online only	Revised for Version 2 (Release 13)
September 2002	Online only	Revised for Version 2.0.1 (Release 13)
September 2003	Online only	Revised for Version 2.0.1 (Release 13SPI)
June 2004	Online only	Revised for Version 2.5 (Release 14)
August 2004	Online only	Revised for Version 2.6 (Release 14+)
October 2004	Online only	Revised for Version 2.6.1 (Release 14SP1)
November 2004	Online only	Revised for Version 2.7 (Release 14SP1+)
March 2005	Online only	Revised for Version 2.7.2 (Release 14SP2)
September 2005	Online only	Revised for Version 2.8 (Release 14SP3)
March 2006	Online only	Revised for Version 2.9 (Release 2006a)
May 2006	Online only	Revised for Version 3.0 (Release 2006a+)
September 2006	Online only	Revised for Version 3.1 (Release 2006b)
March 2007	Online only	Revised for Version 3.2 (Release 2007a)
September 2007	Online only	Revised for Version 3.3 (Release 2007b)
March 2008	Online only	Revised for Version 3.4 (Release 2008a)
October 2008	Online only	Revised for Version 4.0 (Release 2008b)
March 2009	Online only	Revised for Version 4.1 (Release 2009a)
September 2009	Online only	Revised for Version 4.2 (Release 2009b)
March 2010	Online only	Revised for Version 4.3 (Release 2010a)
September 2010	Online only	Revised for Version 4.4 (Release 2010b)
April 2011	Online only	Revised for Version 5.0 (Release 2011a)
September 2011	Online only	Revised for Version 5.1 (Release 2011b)
March 2012	Online only	Revised for Version 5.2 (Release 2012a)
September 2012	Online only	Revised for Version 5.3 (Release 2012b)
March 2013	Online only	Revised for Version 5.4 (Release 2013a)
September 2013	Online only	Revised for Version 5.5 (Release 2013b)
March 2014	Online only	Revised for Version 6.0 (Release 2014a)
October 2014	Online only	Revised for Version 6.1 (Release 2014b)
March 2015	Online only	Revised for Version 6.2 (Release 2015a)
September 2015	Online only	Revised for Version 6.3 (Release 2015b)
March 2016	Online only	Revised for Version 6.4 (Release 2016a)
September 2016	Online only	Revised for Version 6.5 (Release 2016b)
March 2017	Online only	Revised for Version 6.6 (Release 2017a)
September 2017	Online only	Revised for Version 6.7 (Release 2017b)
March 2018	Online only	Revised for Version 6.8 (Release 2018a)
September 2018	Online only	Revised for Version 6.9 (Release 2018b)
March 2019	Online only	Revised for Version 6.10 (Release 2019a)
September 2019	Online only	Revised for Version 6.11 (Release 2019b)
March 2020	Online only	Revised for Version 6.12 (Release 2020a)
September 2020	Online only	Revised for Version 7.0 (Release 2020b)
March 2021	Online only	Revised for Version 7.1 (Release 2021a)
September 2021	Online only	Revised for Version 7.2 (Release 2021b)
March 2022	Online only	Revised for Version 8.0 (Release 2022a)
September 2022	Online only	Revised for Version 8.1 (Release 2022b)
March 2023	Online only	Revised for Version 8.2 (Release 2023a)



<b>1</b>	<b>Simulink Real-Time I/O Library</b>	
	<b>I/O Driver Blocks</b> .....	<b>1-2</b>
	Speedgoat I/O Modules .....	<b>1-2</b>
	Speedgoat I/O Blockset .....	<b>1-2</b>
	Simulink Real-Time Block Library .....	<b>1-2</b>
	<b>Add I/O Blocks to Simulink Model</b> .....	<b>1-4</b>
	<b>Configure Block Parameters</b> .....	<b>1-6</b>

## Async Block Library

<b>2</b>	<b>Periodic and Nonperiodic Events</b>	
	<b>About RTOS Tasks and Priorities</b> .....	<b>2-2</b>

**3**

**DDS**

**DDS Blocks**

**4**

**CAN Message Blocks Library**

**CAN Utility Blocks**

**5**

**EtherCAT Blocks Library**

**Model-Based EtherCAT Communications Support**

**6**

<b>Modeling EtherCAT Networks</b> .....	<b>6-2</b>
Blocks and Tasks .....	<b>6-2</b>
Order of Network Events .....	<b>6-3</b>
<b>Install EtherCAT Network Tools TwinCAT or EC-Engineer</b> .....	<b>6-5</b>
<b>Hardware Setup Requirements for TwinCAT 3</b> .....	<b>6-6</b>
<b>Configure EtherCAT Network by Using TwinCAT 3</b> .....	<b>6-7</b>
Scan EtherCAT Network .....	<b>6-7</b>
Configure EtherCAT Main Device Node Data .....	<b>6-7</b>
Export and Save EtherCAT Configuration by Using TwinCAT 3 .....	<b>6-9</b>
<b>Install EtherCAT Network for Execution</b> .....	<b>6-11</b>
<b>Configure EtherCAT Main Device Node Model</b> .....	<b>6-12</b>
Configure EtherCAT Init Block .....	<b>6-12</b>
Configure EtherCAT PDO Receive Blocks .....	<b>6-13</b>
Configure EtherCAT PDO Transmit Blocks .....	<b>6-14</b>

Update Async SDO Block Variables by Using Complete Access Mode .....	<b>6-15</b>
Configure EtherCAT Model Configuration Parameters .....	<b>6-23</b>
<b>EtherCAT Distributed Clock Algorithm .....</b>	<b>6-25</b>
Main Device Shift Mode .....	<b>6-25</b>
Bus Shift Mode .....	<b>6-26</b>
Limitations .....	<b>6-27</b>
<b>Fixed-Step Size Derivation .....</b>	<b>6-28</b>
<b>EtherCAT Protocol Mapping .....</b>	<b>6-29</b>
<b>EtherCAT Configurator Component Mapping .....</b>	<b>6-30</b>
<b>EtherCAT Data Types .....</b>	<b>6-31</b>
<b>EtherCAT Init Block DC Error Values .....</b>	<b>6-32</b>
<b>EtherCAT Error Codes .....</b>	<b>6-33</b>

## EtherCAT Blocks

# 7

## IP Internet Protocol Blocks Library

### Real-Time TCP Communication Support

# 8

TCP Transport Protocol .....	<b>8-2</b>
------------------------------	------------

### TCP Blocks

# 9

### Real-Time UDP Communication Support

# 10

UDP Transport Protocol .....	<b>10-2</b>
------------------------------	-------------

<b>UDP Data Exchange by Using Shared Ethernet Board</b> .....	<b>10-4</b>
UDP Data Transfer .....	<b>10-4</b>
Set Up slrt_ex_udpsendreceiveA .....	<b>10-5</b>
Set Up slrt_ex_udpsendreceiveB .....	<b>10-6</b>
<b>UDP Communication Setup</b> .....	<b>10-9</b>
<b>UDP and Variable-Size Signals</b> .....	<b>10-10</b>

## **Real-Time UDP Blocks**

# **11**

## **Model-Based Ethernet Communications Support**

# **12**

<b>Apply 802.1Q VLAN Tag by Using Ethernet Send and Receive Blocks</b> .....	<b>12-2</b>
---------------------------------------------------------------------------------	-------------

## **Ethernet Blocks**

# **13**

## **SAE J1939 Blocks Library**

## **SAE J1939**

# **14**

<b>SAE J1939 Blocks</b> .....	<b>14-2</b>
-------------------------------	-------------



**15**

**Logitech**

**Logitech Blocks**

**16**

**LIN**

**LIN Blocks**

**17**

**Logging Blocks Library**

**Logging Blocks**

**18**

**Profiling Blocks Library**

**Profiling Blocks**

**19**

**PTP Precision Time Protocol Blocks Library**

**PTP Blocks**

**20** |

**Precision Time Protocol**

**21** |

<b>Precision Time Protocol</b> .....	<b>21-2</b>
<b>PTP Prerequisites</b> .....	<b>21-4</b>

**Precision Time Protocol Blocks**

**22** |

**RS232 Serial Blocks Library**

**Serial Communications Support**

**23** |

<b>RS-232 Serial Communication</b> .....	<b>23-2</b>
Serial Connections for RS-232 .....	<b>23-2</b>
Serial Connection for USB to RS-232 .....	<b>23-2</b>
<b>RS-232 Legacy Drivers</b> .....	<b>23-4</b>
Add RS-232 Blocks .....	<b>23-4</b>
Building and Running the Real-Time Application .....	<b>23-5</b>
Simulink Real-Time RS-232 Reference .....	<b>23-5</b>

24

**Target Management**

**Target Management Blocks**

25

**Utilities**

**Utility Blocks**

26

**XCP Universal Measurement and Calibration Protocol**

**XCP Communications**

27

<b>XCP Client Mode</b> .....	27-2
<b>XCP Page Switching for Tunable Parameters</b> .....	27-3
Use XCP and ECU Pages for Parameters .....	27-4

**Stimulation Support**

28

<b>Control and Update Stimulation of Inports to Real-Time Application</b> .....	28-2
Stimulate Root Inport by Using MATLAB Language .....	28-2

**29**

**Speedgoat Blocks Library**

**Speedgoat Support**

**30**

<b>Speedgoat Target Computers and Speedgoat Support</b> .....	<b>30-2</b>
Speedgoat I/O Hardware .....	<b>30-2</b>
Speedgoat Communication Protocols .....	<b>30-3</b>

# Simulink Real-Time I/O Library

---

- “I/O Driver Blocks” on page 1-2
- “Add I/O Blocks to Simulink Model” on page 1-4
- “Configure Block Parameters” on page 1-6

## I/O Driver Blocks

In this section...
“Speedgoat I/O Modules” on page 1-2
“Speedgoat I/O Blockset” on page 1-2
“Simulink Real-Time Block Library” on page 1-2

The Simulink Real-Time environment is a solution for prototyping and testing real-time systems by using a desktop computer. To apply this solution, you add I/O blocks to your model. The blocks of the Simulink Real-Time library provide a particular function of an I/O module. By using I/O blocks in your model, you can generate executable code tuned specifically to your I/O requirements.

You add I/O driver blocks to your Simulink model to connect your model to I/O modules (I/O boards). These I/O modules then connect to the sensors and actuators in a physical system.

### Speedgoat I/O Modules

Speedgoat® real-time target machines are available with various I/O modules. See “Speedgoat I/O Hardware” on page 30-2.

### Speedgoat I/O Blockset

You can use the blocks in the Speedgoat I/O Blockset and the blocks in the Simulink Real-Time library in your Simulink Real-Time model. For a description of the Speedgoat blocks, see “Speedgoat I/O Hardware” on page 30-2.

### Simulink Real-Time Block Library

A driver block does not represent an entire board, but an I/O section supported by a board. The Simulink Real-Time library can have more than one block for each physical board. I/O driver blocks are written as C-code S-functions (noninlined S-functions). The source code for the C-code S-functions is included with the Simulink Real-Time software.

If your model contains I/O blocks, take I/O latency values into account for the model sample time.

To find latency values for Speedgoat boards, contact Speedgoat technical support.

You can open the I/O device driver library by using the Simulink library browser or by using the MATLAB® command `slrealtimelib`. The library `slrealtimelib` contains sublibraries grouped by the type of I/O function they provide.

When you double-click one of the I/O block groups, the sublibrary opens, displaying a list grouped by manufacturer. Double-clicking one of the manufacturer groups displays the I/O device driver blocks for the specified I/O functionality.

When you double-click one of the blocks, a Block Parameters dialog box opens, where you enter system-specific parameters. Parameters typically include block sample time and other block-specific parameters.

## See Also

### More About

- “Add I/O Blocks to Simulink Model” on page 1-4
- “Configure Block Parameters” on page 1-6

## Add I/O Blocks to Simulink Model

You can transform a Simulink model into a Simulink Real-Time model that accesses I/O drivers by using the Simulink Real-Time block library or the Simulink Real-Time: Speedgoat I/O Blockset. In the Simulink Real-Time block library, the highest hierarchical level in the library lists I/O function groups. The second level lists board manufacturer groups. The manufacturer groups contain the driver blocks for specific boards.

This example uses the Simulink model `slrt_ex_osc` to show how to replace Simulink blocks with Simulink Real-Time I/O blocks. For example, at the MATLAB Command Window, type:

```
open_system(fullfile(matlabroot, 'toolbox', 'slrealtime', ...
'examples', 'slrt_ex_osc'))
```

- 1 To browse the Simulink Real-Time block library, open the **Library: slrealtimelib** window. In the MATLAB Command Window, type:

```
slrealtimelib
```


- 2 To browse the Simulink Real-Time: Speedgoat I/O Blockset, open the **Library: speedgoatlib** window. In the MATLAB Command Window, type:

```
speedgoatlib
```

- 3 To open the model, in the MATLAB Command Window, type:

```
open_system(fullfile(matlabroot, 'toolbox', 'slrealtime', ...
'examples', 'slrt_ex_osc'))
```

The Simulink block diagram opens for the model `slrt_ex_osc`.



Model slrt\_ex\_osc  
Simulink Real-Time example model

Copyright 1999-2020 The MathWorks, Inc.

- 4 Open the Simulink Library Browser. Select **Simulink Real-Time: Speedgoat I/O Blockset > IO131**. Drag each of these blocks to the Simulink block diagram: Speedgoat IO131 Analog input block, Speedgoat IO131 Analog output block, and Speedgoat IO131 Setup.


The Simulink Editor adds the new I/O blocks to your model.

- 5 Remove the Signal Generator block and add the Speedgoat IO131 Analog input block in its place. Remove the Scope block and add the Speedgoat IO131 Analog output block in its place. The block parameters select the number of outputs for the block.



- 6 Save the model with a new name, such as `ex_slrt_iob_osc`. To open the completed model, in the MATLAB Command Window, type:

```
open_system(fullfile(matlabroot, 'toolbox', 'slrealtime', ...
    'examples', 'slrt_ex_iob_osc'))
```



You cannot run this model unless the required I/O board is installed in your target computer. You can substitute driver blocks for another I/O board that is installed in the target computer.

After you add I/O blocks to the model, set up the I/O operation by selecting block parameter values. For more information, see “Configure Block Parameters” on page 1-6.

## See Also

### More About

- “I/O Driver Blocks” on page 1-2
- “Configure Block Parameters” on page 1-6


## Configure Block Parameters

The block parameters define values for blocks in your model. For example, block parameters include channel numbers for multichannel boards, input and output voltage ranges, and sample time. For information about configuring block parameters for Speedgoat I/O modules, see the Speedgoat documentation at [www.speedgoat.com/help](http://www.speedgoat.com/help).

This procedure uses the Simulink model `slrt_ex_osc`. To open this model, in the MATLAB Command Window, type:

```
open_system(fullfile(matlabroot, 'toolbox', 'slrealtime', ...  
'examples', 'slrt_ex_osc'))
```

- 1 In the Simulink Editor, double-click the File Log block.
- 2 Fill in the File Log dialog box. For example, enter a decimation value to reduce file logging data collection.



When you change block parameter values through the block parameters dialog box, the changes take effect when you build the real-time application. You can also change parameter values in a real-time application without rebuilding the application. For more information, see “Tunable Block Parameters and Tunable Global Parameters”.

### See Also

#### More About

- “I/O Driver Blocks” on page 1-2
- “Add I/O Blocks to Simulink Model” on page 1-4

# Async Block Library



# Periodic and Nonperiodic Events

---

## About RTOS Tasks and Priorities

Real-time application execution tasks come from a number of model features, including:

- Each sample rate group in the model
- Function-call subsystem block connected to interrupt from an I/O module block
- Function-call subsystem block connected to a Thread Trigger block

The RTOS task scheduler automates scheduling of tasks for all sample rates in the model. You can configure your model to influence task priority of some rate-related tasks. For more information, see “Concurrent Execution on Simulink Real-Time”.

### See Also

Thread Trigger

### Related Examples

- “Concurrent Execution on Simulink Real-Time”

### More About


- “Execution Modes”

# Asynchronous Event: Blocks

---

## Thread Trigger

Call downstream function-call subsystem when selected input edge transition occurs




**Libraries:**  
Simulink Real-Time / Async

### Description

When the selected input edge transition occurs, the Thread Trigger block calls the downstream Function-Call Subsystem block or Triggered Subsystem block and sets the interrupt priority of the task. The block checks for the edge transition at the block sample rate.

If the input transition occurs while the task is running, a CPU overload occurs on the target computer.

You can use a Thread Trigger block with a Function-Call Subsystem block that resides inside a referenced model as shown in the figure. This approach is compatible with Simulink Coder™. Because the Thread Trigger block output signal is asynchronous and Simulink Coder does not permit an asynchronous output block inside a referenced model, place the Thread Trigger block at the top level of the model. This approach does not permit explicit partitioning. Remember to match the Asynchronous Task Specification priority (P : 245) to the priority selected in the Thread Trigger block. For more information, see About RTOS Tasks and Priorities.



Place the Thread Trigger block in the top level of the model.  
This approach is compatible with Simulink Coder.

### Ports

#### Input

**T** — Trigger input tested for selected transition  
boolean

Detects the edge type that is selected by using the **Trigger Edge** parameter as 1 for detected and 0 for not detected..

Example: 0



## Output

**F** — Function call output for task  
function call

Outputs the call to the downstream function and provides the thread scheduling priority for the task

## Parameters

**Trigger Edge** — Selects trigger edge type  
Rising Edge (default) | Falling Edge | Both Edges

Selects the trigger edge type that is detected by the block input.

**Programmatic Use**  
**Block Parameter:** edge

**ISR Task Priority** — Selects the ISR task priority for function  
245 (high priority) (default) | 235 (medium priority) | 225 (low priority)

Selects the interrupt service routine (ISR) task priority for the function call. You can select task priority values from 254 (highest priority) to 193 (lowest priority).

The Thread Trigger block provides means to call a Function-Call Subsystem block or Triggered Subsystem block that is a separate model thread. This thread can run with higher or lower priority than other execution threads. Each rate group in the model executes as a different execution thread. For more information, see “About RTOS Tasks and Priorities” on page 2-2.

**Programmatic Use**  
**Block Parameter:** taskpri

## Version History

Introduced in R2020b

### R2022b: Removed Thread Trigger Block Sample Time Parameter

The Sample Time parameter for the Thread Trigger block is removed. The block inherits sample time from the input signal to the block.

## Extended Capabilities

**C/C++ Code Generation**  
Generate C and C++ code using Simulink® Coder™.

## See Also

**Topics**  
“About RTOS Tasks and Priorities” on page 2-2



**DDS**



# DDS Blocks

---

DDS Blockset provides apps and blocks for modeling and simulating software applications that publish or subscribe to Data Distribution Service (DDS) middleware. The Simulink Real-Time DDS blocks support sending and receiving DDS messages.

## DDS Receive

Receive a DDS message



**Libraries:**  
Simulink Real-Time / DDS

### Description

The DDS Receive block receives a DDS message for a selected topic in the Simulink Real-Time model. The block allows you to attach a Simulink data dictionary containing the DDS data definitions with the model.

The DDS Receive and DDS Send blocks let Simulink Real-Time applications communicate with Data Distribution Service (DDS) middleware applications through a shared Simulink data dictionary. These blocks are compatible with the DDS Blockset, which includes a DDS dictionary that lets you manage, create, and edit your DDS definitions in Simulink. You can import DDS specifications as XML files to create a skeleton Simulink model as a starting point for developing algorithms for DDS applications. For more information, see “How does DDS Blockset Work?” (DDS Blockset).

The DDS Receive block receives a DDS message for a selected topic in the real-time application. You attach a Simulink data dictionary containing the DDS data definitions to the block. You can create a new data dictionary or associate an existing data dictionary to the block and select a topic, data writer path, and Quality of Service (QoS) from the data dictionary.

The DDS Receive block and DDS Send block have some limitations:

- You can use these blocks in the top level of a model. These blocks cannot be used in the referenced models.
- You can use these blocks in a real-time application. These blocks cannot be used for simulation in normal mode, accelerator mode, or rapid accelerator mode.
- You cannot use these blocks in protected models.

### Ports

#### Output

**DDS Msg** — DDS message  
simulink message of Bus type

Returns the DDS message sent.

### Parameters

**Data Dictionary** — Associate a data dictionary  
string | char

Associate a simulink data dictionary containing dds data definitions or create a new data dictionary for the model.

**Programmatic Use****Block Parameter:** datadict**Topic** — Select a topic name

string scalar | char vector

Select a topic from the drop-down menu for the data.

**Programmatic Use****Block Parameter:** topic**Reader XML Path** — Data writer XML path

string (default)

select the data writer XML path.

**Programmatic Use****Block Parameter:** xmlPath**Reader QoS** — Quality of service

string (default)

Select the quality of service from the drop-down menu.

**Programmatic Use****Block Parameter:** qos**Sample time** — Sample time

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use****Block Parameter:** sampletime

## Version History

**Introduced in R2022b**

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also


DDS Send

**Topics**

“How does DDS Blockset Work?” (DDS Blockset)

## DDS Send

Send a DDS message



**Libraries:**  
Simulink Real-Time / DDS

### Description

The DDS Receive and DDS Send blocks let Simulink Real-Time applications communicate with Data Distribution Service (DDS) middleware applications through a shared Simulink data dictionary. These blocks are compatible with the DDS Blockset, which includes a DDS dictionary that lets you manage, create, and edit your DDS definitions in Simulink. You can import DDS specifications as XML files to create a skeleton Simulink model as a starting point for developing algorithms for DDS applications. For more information, see “How does DDS Blockset Work?” (DDS Blockset).

The DDS Send block sends a DDS message for a selected topic in the real-time application. You can attach a Simulink data dictionary containing the DDS data definitions to the block. You can create a new data dictionary or associate an existing data dictionary to the block and select a topic, data writer path, and Quality of Service (QoS) from the data dictionary.

The DDS Receive block and DDS Send block have some limitations:

- You can use these blocks in the top level of a model. These blocks cannot be used in the referenced models.
- You can use these blocks in a real-time application. These blocks cannot be used for simulation in normal mode, accelerator mode, or rapid accelerator mode.
- You cannot use these blocks in protected models.

### Ports

#### Input

**DDS Msg** — DDS message  
simulink message of Bus type

Input the DDS message to be sent to a target.

Example: message

### Parameters

**Data Dictionary** — Associate a data dictionary  
string | char

Associate a simulink data dictionary containing dds data definitions or create a new data dictionary for the model.



**Programmatic Use****Block Parameter:** datadict**Topic** — Select a topic name

string scalar | char vector

Select a topic from the drop-down menu for the data.

**Programmatic Use****Block Parameter:** topic**Writer XML Path** — Data writer XML path

string (default)

select the data writer XML path.

**Programmatic Use****Block Parameter:** xmlPath**Writer QoS** — Quality of service

string (default)

Select the quality of service from the drop-down menu.

**Programmatic Use****Block Parameter:** qos**Sample time** — Sample time

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use****Block Parameter:** sampletime

## Version History

Introduced in R2022b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

DDS Receive

**Topics**

“How does DDS Blockset Work?” (DDS Blockset)



# **CAN Message Blocks Library**



# CAN Utility Blocks

---

## CAN Pack

Pack individual signals into CAN message



### Libraries:

Vehicle Network Toolbox / CAN Communication  
 Embedded Coder / Embedded Targets / Host Communication  
 Embedded Coder Support Package for Texas Instruments C2000 Processors / Target Communication  
 Simulink Real-Time / CAN / CAN MSG blocks

## Description

The CAN Pack block loads signal data into a CAN message at specified intervals during the simulation.

To use this block, you must have a license for Simulink software.

The CAN Pack block supports:

- Simulink Accelerator™ rapid accelerator mode. You can speed up the execution of Simulink models.
- Model referencing. Your model can include other Simulink models as modular components.

For more information, see “Design Your Model for Effective Acceleration”.

---

### Tip

- This block can be used to encode the signals of J1939 parameter groups up to 8 bytes. However, to work with J1939 messages, it is preferable to use the blocks in the J1939 Communication block library instead of this block. See “J1939”.
- 

## Ports

### Input

**Data** — CAN message signal input

single | double | int8 | int16 | int32 | int64 | uint32 | uint64 | boolean

The CAN Pack block has one input port by default. The number of block inputs is dynamic and depends on the number of signals you specify for the block. For example, if your message has four signals, the block can have four input ports.

The block supports the following input signal data types: single, double, int8, int16, int32, int64, uint8, uint16, uint32, uint64, and boolean. The block does not support fixed-point data types.

Code generation to deploy models to targets. If your signal information consists of signed or unsigned integers greater than 32 bits long, code generation is not supported.

## Output

**CAN Msg** — CAN message output  
 CAN\_MESSAGE | CAN\_MESSAGE\_BUS

This block has one output port, CAN Msg. The CAN Pack block takes the specified input signals and packs them into a CAN message. The output data type is determined by the **Output as bus** parameter setting.

## Parameters

**Data input as** — Select your data signal  
 raw data (default) | manually specified signals | CANdb specified signals

- **raw data**: Input data as a uint8 vector array. If you select this option, you only specify the message fields. All other signal parameter fields are unavailable. This option opens only one input port on your block.

The conversion formula is:

$$\text{raw\_value} = (\text{physical\_value} - \text{Offset}) / \text{Factor}$$

where `physical_value` is the original value of the signal and `raw_value` is the packed signal value.

- **manually specified signals**: Allows you to specify data signal definitions. If you select this option, use the **Signals** table to create your signals. The number of block inputs depends on the number of signals you specify.
- **CANdb specified signals**: Allows you to specify a CAN database file that contains message and signal definitions. If you select this option, select a CANdb file. The number of block inputs depends on the number of signals specified in the CANdb file for the selected message.

### Programmatic Use

**Block Parameter:** DataFormat

**Type:** string | character vector

**Values:** 'raw data' | 'manually specified signals' | 'CANdb specified signals'

**Default:** 'raw data'

**CANdb file** — CAN database file  
 character vector

This option is available if you specify that your data is input through a CANdb file in the **Data is input as** list. Click **Browse** to find the CANdb file on your system. The message list specified in the CANdb file populates the **Message** section of the dialog box. The CANdb file also populates the **Signals** table for the selected message.

File names that contain non-alphanumeric characters such as equal signs, ampersands, and so on are not valid CAN database file names. You can use periods in your database name. Before you use the CAN database files, rename them with non-alphanumeric characters.

### Programmatic Use

**Block Parameter:** CANdbFile

**Type:** string | character vector

**Message list** — CAN message list  
array of character vectors

This option is available if you specify that your data is input through a CANdb file in the **Data is input as** field and you select a CANdb file in the **CANdb file** field. Select the message to display signal details in the **Signals** table.

**Programmatic Use**

**Block Parameter:** MsgList

**Type:** string | character vector

**Name** — CAN message name

CAN Msg (default) | character vector

Specify a name for your CAN message. The default is CAN Msg. This option is available if you choose to input raw data or manually specify signals. This option is not available if you choose to use signals from a CANdb file.

**Programmatic Use**

**Block Parameter:** MsgName

**Type:** string | character vector

**Identifier type** — CAN identifier type

Standard (11-bit identifier) (default) | Extended (29-bit identifier)

Specify whether your CAN message identifier is a Standard or an Extended type. The default is Standard. A standard identifier is an 11-bit identifier and an extended identifier is a 29-bit identifier. This option is available if you choose to input raw data or manually specify signals. For CANdb specified signals, the **Identifier type** inherits the type from the database.

**Programmatic Use**

**Block Parameter:** MsgIDType

**Type:** string | character vector

**Values:** 'Standard (11-bit identifier)' | 'Extended (29-bit identifier)'

**Default:** 'Standard (11-bit identifier)'

**CAN Identifier** — CAN message ID

0 (default) | 0 to 536870911

Specify your CAN message ID. This number must be a positive integer from 0 through 2047 for a standard identifier and from 0 through 536870911 for an extended identifier. You can also specify hexadecimal values by using the hex2dec function. This option is available if you choose to input raw data or manually specify signals.

**Programmatic Use**

**Block Parameter:** MsgIdentifier

**Type:** string | character vector

**Values:** '0' to '536870911'

**Length (bytes)** — CAN message length

8 (default) | 0 to 8

Specify the length of your CAN message from 0 to 8 bytes. If you are using CANdb specified signals for your data input, the CANdb file defines the length of your message. If not, this field defaults to 8. This option is available if you choose to input raw data or manually specify signals.



**Programmatic Use****Block Parameter:** MsgLength**Type:** string | character vector**Values:** '0' to '8'**Default:** '8'**Remote frame** — CAN message as remote frame

off (default) | on

Specify the CAN message as a remote frame.

**Programmatic Use****Block Parameter:** Remote**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Output as bus** — CAN message as bus

off (default) | on

Select this option for the block to output CAN messages as a Simulink bus signal. For more information on Simulink bus objects, see “Composite Interfaces”.

**Programmatic Use****Block Parameter:** BusOutput**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Add signal** — Add CAN signal

Add a new signal to the signal table.

**Programmatic Use**

None

**Delete signal** — Remove CAN signal

Remove the selected signal from the signal table.

**Programmatic Use**

None

**Signals** — Signals table

table

This table appears if you choose to specify signals manually or define signals by using a CANdb file.

If you are using a CANdb file, the data in the file populates this table and you cannot edit the fields. To edit signal information, switch to manually specified signals.

If you have selected to specify signals manually, create your signals in this table. Each signal that you create has these values:

**Name**

Specify a descriptive name for your signal. The Simulink block in your model displays this name. The default is Signal [row number].

**Start bit**

Specify the start bit of the data. The start bit is the least significant bit counted from the start of the message data. The start bit must be an integer from 0 through 63.

**Length (bits)**


Specify the number of bits the signal occupies in the message. The length must be an integer from 1 through 64.

**Byte order**

Select either of these options:

- LE: Where the byte order is in little-endian format (Intel®). In this format you count bits from the least significant bit, to the most significant bit. For example, if you pack one byte of data in little-endian format, with the start bit at 20, the data bit table resembles this figure.

		Bit Number							
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Data Byte Number	Byte 0	7	6	5	4	3	2	1	0
	Byte 1	15	14	13	12	11	10	9	8
	Byte 2	23	22	21	20	19	18	17	16
	Byte 3	31	30	29	28	27	26	25	24
	Byte 4	39	38	37	36	35	34	33	32
	Byte 5	47	46	45	44	43	42	41	40
	Byte 6	55	54	53	52	51	50	49	48
	Byte 7	63	62	61	60	59	58	57	56



**Address**

- BE: Where byte order is in big-endian format (Motorola®). In this format you count bits from the least-significant bit to the most-significant bit. For example, if you pack one byte of data in big-endian format, with the start bit at 20, the data bit table resembles this figure.

		Bit Number							
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Data Byte Number	Byte 0	7	6	5	4	3	2	1	0
	Byte 1	15	14	13	12	11	10	9	8
	Byte 2	23	22	21	20	19	18	17	16
	Byte 3	31	30	29	28	27	26	25	24
	Byte 4	39	38	37	36	35	34	33	32
	Byte 5	47	46	45	44	43	42	41	40
	Byte 6	55	54	53	52	51	50	49	48
	Byte 7	63	62	61	60	59	58	57	56

MSB

LSB

Data is written up to the most significant bit and ends at 11.

Data begins at the least significant bit and starts at 20.

**Big-Endian Byte Order Counted from the Least Significant Bit to the Lowest Address**

**Data type**

Specify how the signal interprets the data in the allocated bits. Choose from:

- signed (default)
- unsigned
- single
- double

**Multiplex type**

Specify how the block packs the signals into the CAN message at each time step:

- **Standard**: The signal is packed at each time step.
- **Multiplexor**: The **Multiplexor** signal, or the mode signal is packed. You can specify only one **Multiplexor** signal per message.
- **Multiplexed**: The signal is packed if the value of the **Multiplexor** signal (mode signal) at run time matches the configured **Multiplex value** of this signal.

For example, a message has these signals with the following types and values.

Signal Name	Multiplex Type	Multiplex Value
Signal-A	Standard	Not applicable
Signal-B	Multiplexed	1
Signal-C	Multiplexed	0
Signal-D	Multiplexor	Not applicable

In this example:

- The block packs Signal-A (Standard signal) and Signal-D (Multiplexor signal) in every time step.
- If the value of Signal-D is 1 at a particular time step, then the block packs Signal-B along with Signal-A and Signal-D in that time step.
- If the value of Signal-D is 0 at a particular time step, then the block packs Signal-C along with Signal-A and Signal-D in that time step.
- If the value of Signal-D is not 1 or 0, the block does not pack either of the Multiplexed signals in that time step.

**Multiplex value**

This option is available only if you have selected the **Multiplex type** to be **Multiplexed**. The value you provide must match the **Multiplexor** signal value at run time for the block to pack the **Multiplexed** signal. The **Multiplex value** must be a positive integer or zero.

**Factor**

Specify the **Factor** value to apply to convert the physical value (signal value) to the raw value packed in the message. For more information, see the **Data input as** parameter conversion formula.

**Offset**

Specify the **Offset** value to apply to convert the physical value (signal value) to the raw value packed in the message. For more information, see the **Data input as** parameter conversion formula.

**Min, Max**

Define a range of signal values. The default settings are -Inf (negative infinity) and Inf, respectively. For **CANdb specified signals**, these settings are read from the CAN database. For **manually specified signals**, you can specify the minimum and maximum physical value of the signal. By default, these settings do not clip signal values that exceed the settings.

**Programmatic Use**

**Block Parameter:** SignalInfo

**Type:** string | character vector

## Version History

Introduced in R2009a

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

CAN Unpack | CAN FD Pack

**Topics**

“Design Your Model for Effective Acceleration”

## CAN Unpack

Unpack individual signals from CAN messages



### Libraries:

Vehicle Network Toolbox / CAN Communication  
 Embedded Coder / Embedded Targets / Host Communication  
 Embedded Coder Support Package for Texas Instruments C2000 Processors / Target Communication  
 Simulink Real-Time / CAN / CAN MSG blocks

## Description

The CAN Unpack block unpacks a CAN message into signal data using the specified output parameters at every time step. Data is output as individual signals.

To use this block, you also need a license for Simulink software.

The CAN Unpack block supports:

- The use of Simulink Accelerator Rapid Accelerator mode. Using this feature, you can speed up the execution of Simulink models.
- The use of model referencing. Using this feature, your model can include other Simulink models as modular components.

For more information on these features, see “Design Your Model for Effective Acceleration”.

---

### Tip

- To process every message coming through a channel, it is recommended that you use the CAN Unpack block in a function trigger subsystem. See “Using Triggered Subsystems”.
  - This block can be used to decode the signals of J1939 parameter groups up to 8 bytes. However, to work with J1939 messages, it is preferable to use the blocks in the J1939 Communication block library instead of this block. See “J1939”.
- 

## Ports

### Input

**CAN Msg** — CAN message input  
 CAN\_MESSAGE | CAN\_MESSAGE\_BUS

This block has one input port, **CAN Msg**. The block takes the specified input CAN messages and unpacks their signal data to separate outputs.

The block supports the following signal data types: single, double, int8, int16, int32, int64, uint8, uint16, uint32, uint64, and boolean. The block does not support fixed-point data types.



Code generation to deploy models to targets. Code generation is not supported if your signal information consists of signed or unsigned integers greater than 32 bits long.

## Output

### Data — CAN signal output

single | double | int8 | int16 | int32 | int64 | uint32 | uint64 | boolean

The block has one output port by default. The number of output ports is dynamic and depends on the number of signals that you specify for the block to output. For example, if your message has four signals, the block can have four output ports.

For signals specified manually or by a CANdb, the default output data type for CAN signals is double. To specify other types, use a Signal Specification block. This allows the block to support the following output signal data types: single, double, int8, int16, int32, int64, uint8, uint16, uint32, uint64, and boolean. The block does not support fixed-point types.

Additional output ports can be added by selecting the options in the parameters **Output ports** pane. For more information, see the parameters `Output identifier`, `Output timestamp`, `Output error`, `Output remote`, `Output length`, and `Output status`.

## Parameters

### Data to output as — Select your data signal

raw data (default) | manually specify signals | CANdb specified signals

- `raw data`: Output data as a uint8 vector array. If you select this option, you specify only the message fields. The other signal parameter fields are unavailable. This option opens only one output port on your block.

The conversion formula is:

$$\text{physical\_value} = \text{raw\_value} * \text{Factor} + \text{Offset}$$

where `raw_value` is the unpacked signal value and `physical_value` is the scaled signal value.

- `manually specified signals`: You can specify data signals. If you select this option, use the Signals table to create your signals message manually. The number of output ports on your block depends on the number of signals that you specify. For example, if you specify four signals, your block has four output ports.
- `CANdb specified signals`: You can specify a CAN database file that contains data signals. If you select this option, select a CANdb file. The number of output ports on your block depends on the number of signals specified in the CANdb file. For example, if the selected message in the CANdb file has four signals, your block has four output ports.

### Programmatic Use

**Block Parameter:** DataFormat

**Type:** string | character vector

**Values:** 'raw data' | 'manually specified signals' | 'CANdb specified signals'

**Default:** 'raw data'

### CANdb file — CAN database file

character vector

This option is available if you specify that your data is input via a CANdb file in the **Data to be output as** list. Click **Browse** to find the CANdb file on your system. The messages and signal

definitions specified in the CANdb file populate the **Message** section of the dialog box. The signals specified in the CANdb file populate **Signals** table. File names that contain non-alphanumeric characters such as equal signs, ampersands, and so forth are not valid CAN database file names. You can use periods in your database name. Rename CAN database files with non-alphanumeric characters before you use them.

**Programmatic Use****Block Parameter:** CANdbFile**Type:** string | character vector**Message list** — CAN message list

array of character vectors

This option is available if you specify in the **Data to be output as** list that your data is to be output as a CANdb file and you select a CANdb file in the **CANdb file** field. You can select the message that you want to view. The **Signals** table then displays the details of the selected message.

**Programmatic Use****Block Parameter:** MsgList**Type:** string | character vector**Name** — CAN message name

CAN Msg (default) | character vector

Specify a name for your CAN message. The default is CAN Msg. This option is available if you choose to output raw data or manually specify signals.

**Programmatic Use****Block Parameter:** MsgName**Type:** string | character vector**Identifier type** — CAN identifier type

Standard (11-bit identifier) (default) | Extended (29-bit identifier)

Specify whether your CAN message identifier is a Standard or an Extended type. The default is Standard. A standard identifier is an 11-bit identifier and an extended identifier is a 29-bit identifier. This option is available if you choose to output raw data or manually specify signals. For CANdb-specified signals, the **Identifier type** inherits the type from the database.

**Programmatic Use****Block Parameter:** MsgIDType**Type:** string | character vector**Values:** 'Standard (11-bit identifier)' | 'Extended (29-bit identifier)'**Default:** 'Standard (11-bit identifier)'**CAN Identifier** — CAN message identifier

0 (default) | 0 to 536870911

Specify your CAN message ID. This number must be an integer from 0 through 2047 for a standard identifier and from 0 through 536870911 for an extended identifier. If you specify -1, the block unpacks the messages that match the length specified for the message. You can also specify hexadecimal values by using the hex2dec function. This option is available if you choose to output raw data or manually specify signals.

**Programmatic Use****Block Parameter:** MsgIdentifier

**Type:** string | character vector

**Values:** '0' to '536870911'

**Length (bytes)** — CAN message length

8 (default) | 0 to 8

Specify the length of your CAN message from 0 to 8 bytes. If you are using `CANdb` specified signals for your output data, the `CANdb` file defines the length of your message. Otherwise, this field defaults to 8. This option is available if you choose to output raw data or manually specify signals.

**Programmatic Use**

**Block Parameter:** `MsgLength`

**Type:** string | character vector

**Values:** '0' to '8'

**Default:** '8'

**Add signal** — Add CAN signal

Add a signal to the signal table.

**Programmatic Use**

None

**Delete signal** — Remove CAN signal

Remove the selected signal from the signal table.

**Programmatic Use**

None

**Signals** — Signals table

table

If you choose to specify signals manually or define signals by using a `CANdb` file, this table appears.

If you are using a `CANdb` file, the data in the file populates this table and you cannot edit the fields. To edit signal information, switch to specified signals.

If you have selected to specify signals manually, create your signals manually in this table. Each signal that you create has these values:

**Name**

Specify a descriptive name for your signal. The Simulink block in your model displays this name. The default is `Signal [row number]`.

**Start bit**

Specify the start bit of the data. The start bit is the least significant bit counted from the start of the message. The start bit must be an integer from 0 through 63.

**Length (bits)**

Specify the number of bits the signal occupies in the message. The length must be an integer from 1 through 64.

**Byte order**

Select either of these options:

- LE: Where the byte order is in little-endian format (Intel). In this format you count bits from the least-significant bit to the most-significant bit. For example, if you pack one byte of data in little-endian format, with the start bit at 20, the data bit table resembles this figure.

		Bit Number							
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Data Byte Number	Byte 0	7	6	5	4	3	2	1	0
	Byte 1	15	14	13	12	11	10	9	8
	Byte 2	23	22	21	20	19	18	17	16
	Byte 3	31	30	29	28	27	26	25	24
	Byte 4	39	38	37	36	35	34	33	32
	Byte 5	47	46	45	44	43	42	41	40
	Byte 6	55	54	53	52	51	50	49	48
	Byte 7	63	62	61	60	59	58	57	56

Data begins at the least significant bit and starts at 20.

Data is written up to the most significant bit and ends at 27.

LSB

MSB

**Address**

- BE: Where the byte order is in big-endian format (Motorola). In this format you count bits from the least-significant bit to the most-significant bit. For example, if you pack one byte of data in big-endian format, with the start bit at 20, the data bit table resembles this figure.

		Bit Number							
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Data Byte Number	Byte 0	7	6	5	4	3	2	1	0
	Byte 1	15	14	13	12	11	10	9	8
	Byte 2	23	22	21	20	19	18	17	16
	Byte 3	31	30	29	28	27	26	25	24
	Byte 4	39	38	37	36	35	34	33	32
	Byte 5	47	46	45	44	43	42	41	40
	Byte 6	55	54	53	52	51	50	49	48
	Byte 7	63	62	61	60	59	58	57	56

**Data type**

Specify how the signal interprets the data in the allocated bits. Choose from:

- signed (default)
- unsigned
- single
- double

**Multiplex type**

Specify how the block unpacks the signals from the CAN message at each time step:

- **Standard**: The signal is unpacked at each time step.
- **Multiplexor**: The **Multiplexor** signal or the mode signal is unpacked. You can specify only one **Multiplexor** signal per message.
- **Multiplexed**: The signal is unpacked if the value of the **Multiplexor** signal (mode signal) at run time matches the configured **Multiplex value** of this signal.

For example, a message has four signals with these values.

Signal Name	Multiplex Type	Multiplex Value
Signal-A	Standard	Not applicable
Signal-B	Multiplexed	1
Signal-C	Multiplexed	0
Signal-D	Multiplexor	Not applicable

In this example:

- The block unpacks Signal-A (Standard signal) and Signal-D (Multiplexor signal) in every time step.
- If the value of Signal-D is 1 at a particular time step, then the block unpacks Signal-B along with Signal-A and Signal-D in that time step.
- If the value of Signal-D is 0 at a particular time step, then the block unpacks Signal-C along with Signal-A and Signal-D in that time step.
- If the value of Signal-D is not 1 or 0, the block does not unpack either of the Multiplexed signals in that time step.

**Multiplex value**

This option is available only if you have selected the **Multiplex type** to be **Multiplexed**. The value you provide must match the **Multiplexor** signal value at run time for the block to unpack the **Multiplexed** signal. The **Multiplex value** must be a positive integer or zero.

**Factor**

Specify the **Factor** value applied to convert the unpacked raw value to the physical value (signal value). For more information, see the **Data input as** parameter conversion formula.

**Offset**

Specify the **Offset** value applied to convert the physical value (signal value) to the unpacked raw value. For more information, see the **Data input as** parameter conversion formula.



**Min, Max**

Define a range of raw signal values. The default settings are `-Inf` (negative infinity) and `Inf`, respectively. For **CANdb specified signals**, these settings are read from the CAN database. For **manually specified signals**, you can specify the minimum and maximum physical value of the signal. By default, these settings do not clip signal values that exceed them.

**Programmatic Use**

**Block Parameter:** SignalInfo

**Type:** string | character vector

**Output identifier** — Add CAN ID output port

off (default)

Select this option to output a CAN message identifier. The data type of this port is `uint32`.

**Programmatic Use**

**Block Parameter:** IDPort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

**Output timestamp** — Add Timestamp output port

off (default) | on

Select this option to output the message timestamp. This value indicates when the message was received, measured as the number of seconds elapsed since the model simulation began. This option adds a new output port to the block. The data type of this port is `double`.

**Programmatic Use**

**Block Parameter:** TimestampPort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

**Output error** — Add Error output port

off (default) | on

Select this option to output the message error status. This option adds a new output port to the block. An output value of 1 on this port indicates that the incoming message is an error frame. If the output value is 0, there is no error. The data type of this port is `uint8`.

**Programmatic Use**

**Block Parameter:** ErrorPort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

**Output remote** — Add Remote output port

off (default) | on

Select this option to output the message remote frame status. This option adds a new output port to the block. The data type of this port is `uint8`.

**Programmatic Use**

**Block Parameter:** RemotePort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

**Output length** — Add Length output port

off (default) | on

Select this option to output the length of the message in bytes. This option adds a new output port to the block. The data type of this port is `uint8`.

**Programmatic Use**

**Block Parameter:** LengthPort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

**Output status** — Add Status output port

off (default) | on

Select this option to output the message received status. The status is 1 if the block receives a new message and 0 if it does not. This option adds a new output port to the block. The data type of this port is `uint8`.

**Programmatic Use**

**Block Parameter:** StatusPort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

## Version History

Introduced in R2009a

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also

CAN Pack | CAN FD Unpack

## Topics

“Design Your Model for Effective Acceleration”

# CAN FD Pack

Pack individual signals into message for CAN FD bus



## Libraries:

Vehicle Network Toolbox / CAN FD Communication  
 Embedded Coder Support Package for Texas Instruments C2000 Processors / Target Communication  
 Simulink Real-Time / CAN / CAN-FD MSG blocks

## Description

The CAN FD Pack block loads signal data into a message at specified intervals during the simulation.

To use this block, you also need a license for Simulink software.

The CAN FD Pack block supports:

- The use of Simulink Accelerator mode. Using this feature, you can speed up the execution of Simulink models. For more information, see “Design Your Model for Effective Acceleration”.

---

## Tip

- To work with J1939 messages, use the blocks in the J1939 Communication block library instead of this block. See “J1939”.
- 

## Ports

### Input

**Data** — CAN FD message signal input

single | double | int8 | int16 | int32 | int64 | uint32 | uint64 | boolean

The CAN FD Pack block has one input port by default. The number of block inputs is dynamic and depends on the number of signals that you specify for the block. For example, if your message has four signals, the block can have four input ports.

Code generation to deploy models to targets. Code generation is not supported if your signal information consists of signed or unsigned integers greater than 32 bits long.

### Output

**Msg** — CAN FD message output

CAN\_FD\_MESSAGE\_BUS

This block has one output port, Msg. The CAN FD Pack block takes the specified input signals and packs them into a CAN FD message, output as a Simulink CAN\_FD\_MESSAGE\_BUS signal. For more information on Simulink bus objects, see “Composite Interfaces”.

## Parameters

**Data input as** — Select your data signal

raw data (default) | manually specified signals | CANdb specified signals

- **raw data**: Input data as a uint8 vector array. If you select this option, you only specify the message fields. All other signal parameter fields are unavailable. This option opens only one input port on your block.

The conversion formula is:

$$\text{raw\_value} = (\text{physical\_value} - \text{Offset}) / \text{Factor}$$

where `physical_value` is the original value of the signal and `raw_value` is the packed signal value.

- **manually specified signals**: Allows you to specify data signal definitions. If you select this option, use the **Signals** table to create your signals. The number of block inputs depends on the number of signals you specify.
- **CANdb specified signals**: Allows you to specify a CAN database file that contains message and signal definitions. If you select this option, select a CANdb file. The number of block inputs depends on the number of signals specified in the CANdb file for the selected message.

### Programmatic Use

**Block Parameter:** DataFormat

**Type:** string | character vector

**Values:** 'raw data' | 'manually specified signals' | 'CANdb specified signals'

**Default:** 'raw data'

**CANdb file** — CAN database file

character vector

This option is available if you specify that your data is input through a CANdb file in the **Data is input as** list. Click **Browse** to find the CANdb file on your system. The message list specified in the CANdb file populates the **Message** section of the dialog box. The CANdb file also populates the **Signals** table for the selected message. File names that contain non-alphanumeric characters such as equal signs, ampersands, and so on are not valid CAN database file names. You can use periods in your database name. Before you use the CAN database files, rename them with non-alphanumeric characters.

### Programmatic Use

**Block Parameter:** CANdbFile

**Type:** string | character vector

**Message list** — CAN message list

array of character vectors

This option is available if you specify that your data is input through a CANdb file in the **Data is input as** field and you select a CANdb file in the **CANdb file** field. Select the message to display signal details in the **Signals** table.

### Programmatic Use

**Block Parameter:** MsgList

**Type:** string | character vector

**Name** — CAN FD message name  
CAN Msg (default) | character vector

Specify a name for your CAN FD message. The default is CAN Msg. This option is available if you choose to input raw data or manually specify signals. This option is not available if you choose to use signals from a CANdb file.

**Programmatic Use**  
**Block Parameter:** MsgName  
**Type:** string | character vector

**Protocol mode** — CAN FD message protocol  
CAN FD (default) | CAN

Specify the message protocol mode.

**Programmatic Use**  
**Block Parameter:** ProtocolMode  
**Type:** string | character vector  
**Values:** 'CAN FD' | 'CAN'  
**Default:** 'CAN FD'

**Identifier type** — CAN identifier type  
Standard (11-bit identifier) (default) | Extended (29-bit identifier)

Specify whether your CAN message identifier is a Standard or an Extended type. The default is Standard. A standard identifier is an 11-bit identifier and an extended identifier is a 29-bit identifier. This option is available if you choose to input raw data or manually specify signals. For CANdb specified signals, the **Identifier type** inherits the type from the database.

**Programmatic Use**  
**Block Parameter:** MsgIDType  
**Type:** string | character vector  
**Values:** 'Standard (11-bit identifier)' | 'Extended (29-bit identifier)'  
**Default:** 'Standard (11-bit identifier)'

**Identifier** — Message identifier  
0 (default) | 0 .. 536870911

Specify your message ID. This number must be a positive integer from 0 through 2047 for a standard identifier and from 0 through 536870911 for an extended identifier. You can also specify hexadecimal values by using the hex2dec function. This option is available if you choose to input raw data or manually specify signals.

**Programmatic Use**  
**Block Parameter:** MsgIdentifier  
**Type:** string | character vector  
**Values:** '0' to '536870911'

**Length (bytes)** — CAN FD message length  
8 (default) | 0 to 64

Specify the length of your message. For CAN messages the value can be 0 to 8 bytes; for CAN FD the value can be 0 to 8, 12, 16, 20, 24, 32, 48, or 64 bytes. If you are using CANdb specified signals for your data input, the CANdb file defines the length of your message. This option is available if you choose to input raw data or manually specify signals.

**Programmatic Use****Block Parameter:** MsgLength**Type:** string | character vector**Values:** '0' to '8', '12', '16', '20', '24', '32', '48', '64'**Default:** '8'**Remote frame** — CAN message as remote frame

off (default) | on

(Disabled for CAN FD protocol mode.) Specify the CAN message as a remote frame.

**Programmatic Use****Block Parameter:** Remote**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Bit Rate Switch (BRS)** — Enable bit rate switch

off (default) | on

(Disabled for CAN protocol mode.) Enable bit rate switch.

**Programmatic Use****Block Parameter:** BRSSwitch**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Add signal** — Add CAN FD signal

Add a signal to the signal table.

**Programmatic Use**

None

**Delete signal** — Remove CAN FD signal

Remove the selected signal from the signal table.

**Programmatic Use**

None

**Signals** — Signals table

table

This table appears if you choose to specify signals manually or define signals by using a CANdb file.

If you are using a CANdb file, the data in the file populates this table and you cannot edit the fields. To edit signal information, switch to manually specified signals.

If you have selected to specify signals manually, create your signals in this table. Each signal that you create has these values:

**Name**

Specify a descriptive name for your signal. The Simulink block in your model displays this name. The default is Signal [row number].

**Start bit**

Specify the start bit of the data. The start bit is the least significant bit counted from the start of the message data. For CAN the start bit must be an integer from 0 through 63, for CAN FD 0 through 511, within the number of bits in the message. (Note that message length is specified in bytes.)


**Length (bits)**

Specify the number of bits the signal occupies in the message. The length must be an integer from 1 through 64. The sum of all the signal lengths in a message is limited to the number of bits in the message length; that is, all signals must cumulatively fit within the length of the message. (Note that message length is specified in bytes and signal length in bits.)

**Byte order**

Select either of these options:

- LE: Where the byte order is in little-endian format (Intel). In this format you count bits from the least significant bit, to the most significant bit. For example, if you pack one byte of data in little-endian format, with the start bit at 20, the data bit table resembles this figure.




**Little-Endian Byte Order Counted from the Least-Significant Bit to the Highest**



**Address**

- BE: Where byte order is in big-endian format (Motorola). In this format you count bits from the least-significant bit to the most-significant bit. For example, if you pack one byte of data in big-endian format, with the start bit at 20, the data bit table resembles this figure.



**Big-Endian Byte Order Counted from the Least Significant Bit to the Lowest Address**

**Data type**

Specify how the signal interprets the data in the allocated bits. Choose from:

- signed (default)
- unsigned
- single
- double

Note: If you have a double signal that does not align exactly to the message byte boundaries, to generate code with Embedded Coder® you must check **Support long long** under **Device Details** in the **Hardware Implementation** pane of the Configuration Parameters dialog.

**Multiplex type**

Specify how the block packs the signals into the message at each time step:

- **Standard**: The signal is packed at each time step.
- **Multiplexor**: The Multiplexor signal, or the mode signal is packed. You can specify only one Multiplexor signal per message.
- **Multiplexed**: The signal is packed if the value of the Multiplexor signal (mode signal) at run time matches the configured **Multiplex value** of this signal.

For example, a message has four signals with these types and values.

Signal Name	Multiplex Type	Multiplex Value
Signal-A	Standard	Not applicable
Signal-B	Multiplexed	1
Signal-C	Multiplexed	0
Signal-D	Multiplexor	Not applicable

In this example:

- The block packs Signal-A (Standard signal) and Signal-D (Multiplexor signal) in every time step.
- If the value of Signal-D is 1 at a particular time step, then the block packs Signal-B along with Signal-A and Signal-D in that time step.
- If the value of Signal-D is 0 at a particular time step, then the block packs Signal-C along with Signal-A and Signal-D in that time step.
- If the value of Signal-D is not 1 or 0, the block does not pack either of the Multiplexed signals in that time step.

**Multiplex value**

This option is available only if you have selected the **Multiplex type** to be **Multiplexed**. The value you provide here must match the Multiplexor signal value at run time for the block to pack the Multiplexed signal. The **Multiplex value** must be a positive integer or zero.

**Factor**

Specify the **Factor** value to apply to convert the physical value (signal value) to the raw value packed in the message. See the **Data input as** parameter conversion formula to understand how physical values are converted to raw values packed into a message.

**Offset**

Specify the **Offset** value to apply to convert the physical value (signal value) to the raw value packed in the message. See the **Data input as** parameter conversion formula to understand how physical values are converted to raw values packed into a message.

**Min, Max**

Define a range of signal values. The default settings are -Inf (negative infinity) and Inf, respectively. For **CANdb specified signals**, these settings are read from the CAN database. For **manually specified signals**, you can specify the minimum and maximum physical value of the signal. By default, these settings do not clip signal values that exceed them.

**Programmatic Use**

**Block Parameter:** SignalInfo

**Type:** string | character vector

## Version History

Introduced in R2018a

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

**Blocks**

CAN FD Unpack | CAN Pack

**Topics**

“Design Your Model for Effective Acceleration”

“Composite Interfaces”

# CAN FD Unpack

Unpack individual signals from CAN FD messages



## Libraries:

Vehicle Network Toolbox / CAN FD Communication  
 Embedded Coder Support Package for Texas Instruments C2000 Processors / Target Communication  
 Simulink Real-Time / CAN / CAN-FD MSG blocks

## Description

The CAN FD Unpack block unpacks a CAN FD message into signal data by using the specified output parameters at every time step. Data is output as individual signals.

To use this block, you also need a license for Simulink software.

The CAN FD Unpack block supports:

- Simulink Accelerator mode. You can speed up the execution of Simulink models. For more information, see “Design Your Model for Effective Acceleration”.

---

## Tip

- To process every message coming through a channel, it is recommended that you use the CAN FD Unpack block in a function trigger subsystem. See “Using Triggered Subsystems”.
  - To work with J1939 messages, use the blocks in the J1939 Communication block library instead of this block. See “J1939”.
- 

## Ports

### Input

**Msg** — CAN FD message input  
 CAN\_FD\_MESSAGE\_BUS

This block has one input port, Msg. The CAN FD Unpack block takes the specified input CAN messages and unpacks their signal data to separate outputs.

The block supports the following input signal data types: single, double, int8, int16, int32, int64, uint8, uint16, uint32, uint64, and boolean. The block does not support fixed-point data types.

Code generation to deploy models to targets. Code generation is not supported if your signal information consists of signed or unsigned integers greater than 32 bits long.

### Output

**Data** — CAN message output  
 single | double | int8 | int16 | int32 | int64 | uint32 | uint64 | boolean

The CAN FD Unpack block has one output port by default. The number of data output ports is dynamic and depends on the number of signals you specify for the block to output. For example, if your block has four signals, it has four output ports, labeled by signal name.

For manually or CANdb specified signals, the default output signal data type is double. To specify other types, use a Signal Specification block. This allows the block to support the following output signal data types: single, double, int8, int16, int32, int64, uint8, uint16, uint32, uint64, and boolean. The block does not support fixed-point types.

Additional output ports can be added by the options in the parameters **Output ports** pane.

## Parameters

**Data to output as** — Select your data signal

`raw data (default) | manually specify signals | CANdb specified signals`

- **raw data:** Output data as a uint8 vector array. If you select this option, you specify only the message fields. The other signal parameter fields are unavailable. This option opens only one output port on your block.

The conversion formula is:

$$\text{physical\_value} = \text{raw\_value} * \text{Factor} + \text{Offset}$$

where `raw_value` is the unpacked signal value and `physical_value` is the scaled signal value.

- **manually specified signals:** You can specify data signals. If you select this option, use the Signals table to create your signals message manually. The number of output ports on your block depends on the number of signals that you specify. For example, if you specify four signals, your block has four output ports.
- **CANdb specified signals:** You can specify a CAN database file that contains data signals. If you select this option, select a CANdb file. The number of output ports on your block depends on the number of signals specified in the CANdb file. For example, if the selected message in the CANdb file has four signals, your block has four output ports.

### Programmatic Use

**Block Parameter:** DataFormat

**Type:** string | character vector

**Values:** 'raw data' | 'manually specified signals' | 'CANdb specified signals'

**Default:** 'raw data'

**CANdb file** — CAN database file

character vector

This option is available if you specify that your data is input via a CANdb file in the **Data to be output as** list. Click **Browse** to find the CANdb file on your system. The messages and signal definitions specified in the CANdb file populate the **Message** section of the dialog box. The signals specified in the CANdb file populate the **Signals** table. File names that contain non-alphanumeric characters such as equal signs, ampersands, and so forth, are not valid CAN database file names. You can use periods in your database name. Rename CAN database files with non-alphanumeric characters before you use them.

### Programmatic Use

**Block Parameter:** CANdbFile

**Type:** string | character vector

**Message list** — Message list  
array of character vectors

This option is available if you specify in the **Data to be output as** list that your data is to be output as a CANdb file and you select a CANdb file in the **CANdb file** field. You can select the message that you want to view. The **Signals** table then displays the details of the selected message.

**Programmatic Use**

**Block Parameter:** MsgList

**Type:** string | character vector

**Name** — Message name

CAN Msg (default) | character vector

Specify a name for your message. The default is `Msg`. This option is available if you choose to output raw data or manually specify signals.

**Programmatic Use**

**Block Parameter:** MsgName

**Type:** string | character vector

**Identifier type** — Identifier type

Standard (11-bit identifier) (default) | Extended (29-bit identifier)

Specify whether your message identifier is a `Standard` or an `Extended` type. The default is `Standard`. A standard identifier is an 11-bit identifier and an extended identifier is a 29-bit identifier. This option is available if you choose to output raw data or manually specify signals. For CANdb-specified signals, the **Identifier type** inherits the type from the database.

**Programmatic Use**

**Block Parameter:** MsgIDType

**Type:** string | character vector

**Values:** 'Standard (11-bit identifier)' | 'Extended (29-bit identifier)'

**Default:** 'Standard (11-bit identifier)'

**Identifier** — Message identifier

0 (default) | 0 .. 536870911

Specify your message ID. This number must be an integer from 0 through 2047 for a standard identifier and from 0 through 536870911 for an extended identifier. If you specify `-1`, the block unpacks the messages that match the length specified for the message. You can also specify hexadecimal values using the `hex2dec` function. This option is available if you choose to output raw data or manually specify signals.

**Programmatic Use**

**Block Parameter:** MsgIdentifier

**Type:** string | character vector

**Values:** '0' to '536870911'

**Length (bytes)** — CAN message length

8 (default) | 0 .. 8

Specify the length of your message. For CAN messages the value can be 0-8 bytes; for CAN FD the value can be 0-8, 12, 16, 20, 24, 32, 48, or 64 bytes. If you are using CANdb specified signals

for your output data, the CANdb file defines the length of your message. This option is available if you choose to output raw data or manually specify signals.

**Programmatic Use****Block Parameter:** MsgLength**Type:** string | character vector**Values:** '0' to '8', '12', '16', '20', '24', '32', '48', '64'**Default:** '8'**Add signal** — Add CAN signal

Add a signal to the signal table.

**Programmatic Use**

None

**Delete signal** — Remove CAN signal

Remove the selected signal from the signal table.

**Programmatic Use**

None

**Signals** — Signals table

table

If you choose to specify signals manually or define signals by using a CANdb file, this table appears.

If you are using a CANdb file, the data in the file populates this table and you cannot edit the fields. To edit signal information, switch to specified signals.

If you have selected to specify signals manually, create your signals manually in this table. Each signal that you create has these values:

**Name**

Specify a descriptive name for your signal. The Simulink block in your model displays this name. The default is Signal [row number].

**Start bit**

Specify the start bit of the data. The start bit is the least significant bit counted from the start of the message data. For CAN the start bit must be an integer from 0 through 63, for CAN FD 0 through 511, within the number of bits in the message. (Note that message length is specified in bytes.)

**Length (bits)**

Specify the number of bits the signal occupies in the message. The length must be an integer from 1 through 64. The sum of all the signal lengths in a message is limited to the number of bits in the message length; that is, all signals must cumulatively fit within the length of the message. (Note that message length is specified in bytes and signal length in bits.)


**Byte order**

Select either of the following options:

- LE: Where the byte order is in little-endian format (Intel). In this format you count bits from the least-significant bit to the most-significant bit and proceeding to the next higher byte as




you cross a byte boundary. For example, if you pack one byte of data in little-endian format, with the start bit at 20, the data bit table resembles this figure.



**Little-Endian Byte Order Counted from the Least Significant Bit to the Highest**

**Address**

- BE: Where the byte order is in big-endian format (Motorola). In this format you count bits from the least-significant bit to the most-significant bit and proceeding to the next lower byte as you cross a byte boundary. For example, if you pack one byte of data in big-endian format, with the start bit at 20, the data bit table resembles this figure.



**Big-Endian Byte Order Counted from the Least Significant Bit to the Lowest Address**

**Data type**

Specify how the signal interprets the data in the allocated bits. Choose from:

- signed (default)
- unsigned
- single
- double

Note: If you have a **double** signal that does not align exactly to the message byte boundaries, to generate code with Embedded Coder you must check **Support long long** under **Device Details** in the **Hardware Implementation** pane of the Configuration Parameters dialog.

**Multiplex type**

Specify how the block unpacks the signals from the message at each time step:

- **Standard**: The signal is unpacked at each time step.
- **Multiplexor**: The **Multiplexor** signal, or the mode signal is unpacked. You can specify only one **Multiplexor** signal per message.
- **Multiplexed**: The signal is unpacked if the value of the **Multiplexor** signal (mode signal) at run time matches the configured **Multiplex value** of this signal.

For example, a message has four signals with these values.

Signal Name	Multiplex Type	Multiplex Value
Signal-A	Standard	Not applicable
Signal-B	Multiplexed	1
Signal-C	Multiplexed	0
Signal-D	Multiplexor	Not applicable

In this example:

- The block unpacks Signal-A (Standard signal) and Signal-D (Multiplexor signal) in every time step.
- If the value of Signal-D is 1 at a particular time step, then the block unpacks Signal-B along with Signal-A and Signal-D in that time step.
- If the value of Signal-D is 0 at a particular time step, then the block unpacks Signal-C along with Signal-A and Signal-D in that time step.
- If the value of Signal-D is not 1 or 0, the block does not unpack either of the Multiplexed signals in that time step.

**Multiplex value**

This option is available only if you have selected the **Multiplex type** to be **Multiplexed**. The value you provide here must match the **Multiplexor** signal value at run time for the block to unpack the **Multiplexed** signal. The **Multiplex value** must be a positive integer or zero.

**Factor**

Specify the **Factor** value applied to convert the unpacked raw value to the physical value (signal value). For more information, see the **Data input as** parameter conversion formula.

**Offset**

Specify the **Offset** value applied to convert the physical value (signal value) to the unpacked raw value. For more information, see the **Data input as** parameter conversion formula.

**Min, Max**

Define a range of raw signal values. The default settings are `-Inf` (negative infinity) and `Inf`, respectively. For **CANdb specified signals**, these settings are read from the CAN database. For **manually specified signals**, you can specify the minimum and maximum physical value of the signal. By default, these settings do not clip signal values that exceed them.

**Programmatic Use**

**Block Parameter:** SignalInfo

**Type:** string | character vector

**Output identifier** — Add CAN ID output port

off (default) | on

Select this option to output a CAN message identifier. The data type of this port is `uint32`.

**Programmatic Use**

**Block Parameter:** IDPort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

**Output timestamp** — Add Timestamp output port

off (default) | on

Select this option to output the message timestamp. This value indicates when the message was received, measured as the number of seconds elapsed since the model simulation began. This option adds a new output port to the block. The data type of this port is `double`.

**Programmatic Use**

**Block Parameter:** TimestampPort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

**Output error** — Add Error output port

off (default) | on

Select this option to output the message error status. This option adds a new output port to the block. An output value of 1 on this port indicates that the incoming message is an error frame. If the output value is 0, there is no error. The data type of this port is `uint8`.

**Programmatic Use**

**Block Parameter:** ErrorPort

**Type:** string | character vector

**Values:** 'off' | 'on'

**Default:** 'off'

**Output remote** — Add Remote output port

off (default) | on

Select this option to output the message remote frame status. This option adds a new output port to the block. The data type of this port is `uint8`.

**Programmatic Use****Block Parameter:** RemotePort**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Output length** — Add Length output port

off (default) | on

Select this option to output the length of the message in bytes. This option adds a new output port to the block. The data type of this port is `uint8`.

**Programmatic Use****Block Parameter:** LengthPort**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Output status** — Add Status output port

off (default) | on

Select this option to output the message received status. The status is 1 if the block receives new message and 0 if it does not. This option adds a new output port to the block. The data type of this port is `uint8`.

**Programmatic Use****Block Parameter:** StatusPort**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Output Bit Rate Switch (BRS)** — Add BRS output port

off (default) | on

(Disabled for CAN protocol.) Select this option to output the message bit rate switch. This option adds a new output port to the block, which indicates if the CAN FD message bit rate switch is set. The data type of this port is `boolean`, indicating whether the bit rate for the data phase of the message is faster (`true`) or the same (`false`) as the bit rate of the arbitration phase.

For more information on BRS, see CAN FD - Some Protocol Details.

**Programmatic Use****Block Parameter:** BRSPort**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Output Error Status Indicator (ESI)** — Add ESI output port

off (default) | on

(Disabled for CAN protocol.) Select this option to output the message error status. This option adds a new output port to the block. The data type of this port is `boolean`, indicating if the CAN FD message error state indicator flag is set.

For more information on ESI, see CAN FD - Some Protocol Details.

**Programmatic Use****Block Parameter:** ESIPort**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'**Output Data Length Code (DLC)** — Add DLC output port

off (default) | on

(Disabled for CAN protocol.) Select this option to output the message data length. This option adds a new output port to the block. The data type of this port is `double`.

**Programmatic Use****Block Parameter:** DLCPort**Type:** string | character vector**Values:** 'off' | 'on'**Default:** 'off'

## Version History

Introduced in R2018a

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

**Blocks**

CAN FD Pack

**Topics**

“Design Your Model for Effective Acceleration”

“Composite Interfaces”



# EtherCAT Blocks Library



# Model-Based EtherCAT Communications Support

---

- “Modeling EtherCAT Networks” on page 6-2
- “Install EtherCAT Network Tools TwinCAT or EC-Engineer” on page 6-5
- “Hardware Setup Requirements for TwinCAT 3” on page 6-6
- “Configure EtherCAT Network by Using TwinCAT 3” on page 6-7
- “Install EtherCAT Network for Execution” on page 6-11
- “Configure EtherCAT Main Device Node Model” on page 6-12
- “EtherCAT Distributed Clock Algorithm” on page 6-25
- “Fixed-Step Size Derivation” on page 6-28
- “EtherCAT Protocol Mapping” on page 6-29
- “EtherCAT Configurator Component Mapping” on page 6-30
- “EtherCAT Data Types” on page 6-31
- “EtherCAT Init Block DC Error Values” on page 6-32
- “EtherCAT Error Codes” on page 6-33

## Modeling EtherCAT Networks

Ethernet for Control Automation (EtherCAT) is an open Ethernet network protocol for real-time distributed control, for example in automotive and industrial systems. The EtherCAT protocol provides:

- Deterministic and fast cycle times
- Inexpensive I/O module cost

EtherCAT networks consist of one main device node and several subordinate device nodes. The Simulink Real-Time EtherCAT sublibrary supports only the main device node of an EtherCAT network. You cannot emulate subordinate device nodes by using the blocks in the EtherCAT sublibrary. You can use these blocks to prototype multiple EtherCAT networks by using multiple Ethernet cards.

You model an EtherCAT network by using one of the third-party EtherCAT configurators: TwinCAT® 3 from Beckhoff® or EC-Engineer from Acontis.

To map the network model into a Simulink Real-Time model, become familiar with these mappings:

- “EtherCAT Protocol Mapping” on page 6-29
- “EtherCAT Configurator Component Mapping” on page 6-30

### Blocks and Tasks

At a minimum, each EtherCAT model must contain an EtherCAT Init block. The EtherCAT Init block contains a reference to an EtherCAT Network Information (ENI) file. The ENI file describes the network, including the device variables of the network.

If you generate the configuration file by using TwinCAT 3, use the software to create at least one cyclic input/output task. Link this task to at least one input channel and one output channel on each subordinate device. If you generate the file by using Acontis EC-Engineer, the software creates one default task linked to all subordinate device input/output channels. The task rate equals the sample time of the EtherCAT blocks.

When you know the input/output cycle ticks, in the Model Configuration Parameters dialog box, set the **Fixed-step size** to a value that is consistent with these constraints:

- The cycle tick of all EtherCAT subordinate devices.
- The sample times of all other blocks in the Simulink model.

For more information, see “Fixed-Step Size Derivation” on page 6-28.

When you know the device variables that you are using in your model, add an EtherCAT PDO Receive or EtherCAT PDO Transmit block for every EtherCAT device variable. When you add these blocks to the model, the block obtains the list of device variables from the configuration file in the EtherCAT Init block. When you specify a device variable in the block dialog box, the software updates the block information with device variable information from the configuration file.

To transmit CANopen over EtherCAT (CoE) information through your network, add SDO/CoE blocks to your model. To transmit by using the SERCOS (SERial Real time COmmunication Specification) over EtherCAT (SoE) interface through your network, add SSC/SoE blocks to your model.

The SDO/CoE blocks and SSC/SoE blocks come in two types, synchronous and asynchronous. From the EtherCAT perspective, there is little difference in the behavior of these types. The difference

occurs during the execution of the real-time application. The synchronous blocks halt execution while the blocks wait for a response. The asynchronous blocks continue executing and poll the I/O module for a response.

To avoid a CPU overload, set the sample time for the synchronous blocks to a value at least three times of that for the PDO blocks.

To track the state of the network or force the network into a particular state, add an EtherCAT Get State or EtherCAT Set State block.

## Order of Network Events

The EtherCAT Init block schedules network events in *Phase 1* and *Phase 2*.

### *Phase 1*

- 1** Read data from EtherCAT variables from the last received frame into EtherCAT PDO Receive blocks.
- 2** Use either of these blocks in any order:
  - EtherCAT PDO Receive — Processes data read from the last frame received from a subordinate device.
  - EtherCAT PDO Transmit — Buffers data to send in the next frame to a subordinate device.
- 3** Use each of these blocks in any order. Synchronous upload and download take at least three ticks of the fastest PDO cycle tick to complete processing.
  - EtherCAT Sync SDO Upload — Queues an SDO frame with new value, waits for response.
  - EtherCAT Sync SDO Download — Queues an SDO frame with request for data, waits for response.
  - EtherCAT Async SDO Upload — Queues an SDO frame with new value, checks for response, continues execution.
  - EtherCAT Async SDO Download — Queues an SDO frame with request for data, checks for response, continues execution.
  - EtherCAT Sync SSC/SoE Upload — Queues an SSC/SoE frame with new value, waits for response.
  - EtherCAT Sync SSC/SoE Download — Queues an SSC/SoE frame with request for data, waits for response.
  - EtherCAT Async SSC/SoE Upload — Queues an SSC/SoE frame with new value, checks for response, continues execution.
  - EtherCAT Async SSC/SoE Download — Queues an SSC/SoE frame with request for data, checks for response, continues execution.
  - EtherCAT Get State — Reads current state of EtherCAT network.
  - EtherCAT Set State — Queues request to change current state of EtherCAT network.

### *Phase 2*

- 1** Send the PDO frames followed by the next available queued SDO frames.

### See Also

EtherCAT Init | EtherCAT PDO Receive | EtherCAT PDO Transmit | EtherCAT Sync SDO Upload | EtherCAT Sync SDO Download | EtherCAT Async SDO Upload | EtherCAT Async SDO Download | EtherCAT Sync SSC/SoE Upload | EtherCAT Sync SSC/SoE Download | EtherCAT Async SSC/SoE Upload | EtherCAT Async SSC/SoE Download | EtherCAT Get State | EtherCAT Set State

### More About

- “Fixed-Step Size Derivation” on page 6-28
- “EtherCAT Protocol Mapping” on page 6-29
- “EtherCAT Configurator Component Mapping” on page 6-30
- “EtherCAT Data Types” on page 6-31
- “EtherCAT Init Block DC Error Values” on page 6-32

## Install EtherCAT Network Tools TwinCAT or EC-Engineer

To configure and diagnose your EtherCAT network, install third-party EtherCAT software. Example vendors and products are:

- acontis technologies GmbH, EC-Engineer
- Beckhoff Automation GmbH, TwinCAT 3

For TwinCAT 3 requirements, see “Hardware Setup Requirements for TwinCAT 3” on page 6-6. To install the TwinCAT 3 network and configuration software:

- 1** Install a dedicated, EtherCAT compatible Ethernet card on the development computer.
- 2** Download or buy the Beckhoff TwinCAT 3 configurator ([www.beckhoff.com](http://www.beckhoff.com)).
- 3** Install Microsoft® Visual Studio® on your development computer.

TwinCAT 3 uses the Microsoft Visual Studio IDE desktop as its user interface. For the required version, see the TwinCAT 3 documentation.

- 4** Install the TwinCAT 3 software on your development computer.

The next task is “Configure EtherCAT Network by Using TwinCAT 3” on page 6-7.

### See Also

#### External Websites

- [www.beckhoff.com](http://www.beckhoff.com)
- [www.acontis.com/en/](http://www.acontis.com/en/)

## Hardware Setup Requirements for TwinCAT 3

For the development and target computers, the EtherCAT I/O module has these requirements:

- Each Ethernet card must be compatible with EtherCAT communication.
- On the development computer, as a best practice, install two Ethernet cards in addition to your local area network card. Dedicate one card to linking the development and target computers. Dedicate the other card to EtherCAT network configuration.

Assign each Ethernet card a static IP address and a nonroutable subnet and netmask. You assign an IP address on the development computer extra Ethernet port that connects to the target EtherCAT subordinate device network by using a switch. For information on setting up the dedicated Ethernet card, see your network administrator.

Configure the development computer Ethernet card that you are using for EtherCAT to enable only the Internet Protocol Version 4 (TCP/IPv4) driver. For information on creating an EtherCAT configuration file, see the TwinCAT 3 documentation.

- On the target computer, consult with Speedgoat support for configuration of the two Ethernet cards in the Speedgoat target machine. A typical configuration dedicates one card to linking the development and target computers and dedicates the other card to model-based EtherCAT communication. See “Install EtherCAT Network for Execution” on page 6-11.

With only one card on the development computer, before configuring the EtherCAT network, unplug the Ethernet link cable and plug in the EtherCAT network cable. Before building and downloading the model, unplug the EtherCAT network cable, plug in the Ethernet link cable, disable the EtherCAT filter, and restart your development computer.



## Configure EtherCAT Network by Using TwinCAT 3

Before you start this procedure, familiarize yourself with TwinCAT 3 and its documentation.

Before configuring the network, perform the steps in “Install EtherCAT Network Tools TwinCAT or EC-Engineer” on page 6-5.

### Scan EtherCAT Network

This example uses an EtherCAT network that consists of Beckhoff EK1100, EL3062, and EL4002 modules connected in that order.

To scan an EtherCAT network by using TwinCAT 3:

- 1 Connect your EtherCAT network to the development computer Ethernet port dedicated to EtherCAT. Turn on the network.
- 2 Start Microsoft Visual Studio and create a TwinCAT 3 project.
- 3 In the TwinCAT menu, start the device scanner.

The scanner reports that new I/O devices have been found.

- 4 In the list of Ethernet devices that the scanner detects on the development computer, select the Ethernet device into which you plugged your EtherCAT network.

If you do not see an Ethernet device identified as an EtherCAT device, check your EtherCAT network configuration and power supply.

- 5 Scan for EtherCAT boxes on your network.

The scanner reports the EtherCAT devices on your network.

- 6 Disable free run mode.
- 7 In your TwinCAT project, make sure that the scanner downloaded the required information about your EtherCAT devices. If not a Beckhoff device, you could need the EtherCAT SubDevice Information (ESI) file from the device vendor.

### Configure EtherCAT Main Device Node Data

Before configuring the main device node of an EtherCAT network, scan the network by using TwinCAT.

#### Create EtherCAT Task

To create and configure an EtherCAT task:

- 1 In TwinCAT 3, add an item to your system task list.

In the Solution Explorer display tree, open the SYSTEM subtree and use a right-click on the Tasks entry and choose **Add New Item**. In the new dialog, select **TwinCAT Task With Image**. This allows you to add variables to the task PDO.

Provide a name for the task, for example Task 1. Configure Task 1 as a task with an image.

- 2 In the task list, select Task 1 and set its cycle ticks value to a value in milliseconds, such as 1 for 1 millisecond.

- 3 Record the cycle tick in milliseconds.

In the Model Configuration Parameters dialog box, use the cycle tick to calculate a value for the **Fixed-step size (fundamental sample time)** box. To enable Simulink to calculate the sample time, select Auto.

### Configure EtherCAT Task Inputs

To configure the task inputs:

- 1 In TwinCAT 3, under Term 1, access the nodes Term 2 and AI Standard Channel 1.
- 2 Drag the Value node of AI Standard Channel 1 to the Task 1 inputs.
- 3 Configure the Term 1 inputs as variables.
- 4 Link the AI Standard Channel 1 variable to Term 2.

Adding a variable to the task you created requires that you:

- 1 Add an empty variable to the task with the same type as the PDO variable you want to add.
- 2 Link it to the PDO variable that you want to add to the task from that task entry using the **Linked to...** button.

Adding any one variable from a specific subordinate device adds all PDO variables from that subordinate device to the task. For instance, with the EL3102 Analog Input module:

- 1 Left-click on your task Inputs entry and select **Add New Item**. The **Insert Variable** dialog opens.
- 2 Select the data type. For the EL3102 the AD values is an INT in the list. That is a 2 byte signed integer.
- 3 Change the name if needed, but this is not necessary.
- 4 Click on OK
- 5 A new dialog opens, click on **Linked to....**
- 6 In the new dialog, find the EL3102. Only variables with the data type selected above are visible. Both INT and UINT appear. Select any one of the EL3102 variables. You may need to change with check boxes are active under the **Show Variables** or **Show Variable Types** lists.
- 7 All of the EL3102 transmit (Input to main device stack) variables are now included in the task just by selecting one of them.
- 8 Repeat for one receive (Output to subordinate device) variable for that subordinate device.

### Configure EtherCAT Task Outputs

To configure the task outputs:

- 1 In TwinCAT 3, under Term 1, access the nodes Term 3 and A0 Outputs Channel 1.
- 2 Drag the Analog output node of A0 Outputs Channel 1 to the Task 1 outputs.
- 3 Configure the Term 1 analog outputs as variables.
- 4 Link the Analog output variable to Term 3.

### Configure EtherCAT Distributed Clocks

To configure the Term 3 distributed clock:

- 1 In TwinCAT 3, under Term 3, access the DC tab.
- 2 Change the DC operation mode to DC Synchron.

There are two main steps to configure distributed clocks:

- 1 Select the synchronization mode, either main device shift or bus shift. TwinCAT refers to these with TwinCAT centric names, not generic main device stack names.
- 2 In the Solution Explorer, select **I/O > Devices > Device 1 (EtherCAT)**
- 3 In the dialog in the right side, select the **EtherCAT** tab. Select the **Advanced Settings** button. On the left of the new dialog, select **Distributed Clocks**.
- 4 By default TwinCAT3 has **Automatic DC Mode Selection** chosen. Deselect that and choose **DC in use**. Choose the mode you want.
- 5 **Independent DC Time (Main Device Mode)** causes the target machine clock to be adjusted to synchronize with the first DC enabled EtherCAT subordinate device. This mode is also known as Main Device Shift DC mode.
- 6 **DC Time controlled by TwinCAT Time (Subordinate Device Mode)** uses the target computer execution time as the reference clock and to adjust the first DC enabled subordinate device to match the target computer. This is also known as Bus Shift mode.

For each DC enabled subordinate device, you need to ensure that it is configured correctly to participate in DC synchronization. For each subordinate device:

- 1 Select the subordinate device in Solution Explorer.
- 2 In the dialog, select the **DC** tab if it is available.
- 3 In the Operation Mode drop down menu, there could be several different names given. For instance DC Latch or DC Synchron are common and mean that the device synchronizes and uses DC timing. SM synchron is a common listing to mean that IO is not DC synchronized, but occurs on packet arrival (SM), not on DC time.
- 4 Click the **Advanced Settings** button.
- 5 Make sure the **Enable** checkbox is selected. There are additional settings that can be modified, but these are generally advanced options.

## Export and Save EtherCAT Configuration by Using TwinCAT 3

The EtherCAT Network Information (ENI) file represents the main device node of an EtherCAT network. To create the ENI file, scan and configure the network by using TwinCAT 3.

To export the ENI file from TwinCAT 3:

- 1 Under the **Device 1 (EtherCAT)** node, in the **EtherCAT** tab, execute the command to export the configuration file.
- 2 In the file save dialog box, enter an XML file name, such as BeckhoffAI0config.xml.

---

**Caution** The ENI file is formatted as an XML file with the .xml file extension. Building the real-time application produces an XML file with the same name as your model. To avoid a conflict, use an ENI file name that is different from the name of your model.

---

- 3 When you close Microsoft Visual Studio TwinCAT the project file is saved.

To review or modify your configuration, open the project SLN file by using Microsoft Visual Studio. If you modify the configuration, save both the XML and SLN files.

The next task is “Install EtherCAT Network for Execution” on page 6-11.

## Install EtherCAT Network for Execution

For TwinCAT 3 requirements, see “Hardware Setup Requirements for TwinCAT 3” on page 6-6. To install the EtherCAT Network for execution by using the target computer as main device node:

- 1 Run the Ethernet configuration tool. In the MATLAB Command Window, type:

```
speedgoat.configureEthernet
```


This tool lets you select either an IP address or reserve for EtherCAT each of the Ethernet ports that is not the host-target link port. In the EtherCAT Init block, you need an Ethernet port number. There, the number 1 refers to the first port that is reserved for EtherCAT using the Ethernet configuration tool. For more information, see the Speedgoat documentation.

- 2 Connect your EtherCAT network to the target computer Ethernet port dedicated to EtherCAT. Turn on the network.

The next task is “Configure EtherCAT Main Device Node Model” on page 6-12.

## Configure EtherCAT Main Device Node Model

Before configuring the model, complete the procedure in “Configure EtherCAT Network by Using TwinCAT 3” on page 6-7.



To configure model `slrt_ex_ethercat_beckhoff_aio` for execution by using the target computer as main device node, complete the procedure in “Configure EtherCAT Init Block” on page 6-12.

### Configure EtherCAT Init Block

Before you use the EtherCAT Init block, configure the EtherCAT network with TwinCAT 3.

Before you start this procedure, familiarize yourself with TwinCAT 3 and its documentation.

As part of the configuration process, create and save an EtherCAT Network Information (ENI) file. See “Configure EtherCAT Network by Using TwinCAT 3” on page 6-7.

To include EtherCAT distributed clocks when PTP is enabled for the model, use EtherCAT bus shift mode.

To configure the EtherCAT Init block of model `slrt_ex_ethercat_beckhoff_aio`:

- 1 Open model `slrt_ex_ethercat_beckhoff_aio`. In the MATLAB Command Window, type:

```
open_system(fullfile(matlabroot, 'toolbox', 'slrealtime', ...
'examples', 'slrt_ex_ethercat_beckhoff_aio'))
```

- 2 Double-click the EtherCAT Init block.
- 3 In the **Config file (ENI)** text box, browse to the EtherCAT Network Information (ENI) file that you created when you configured the network (here, 'BeckhoffAIOconfig.xml'). You can enter the file name with or without single quotes.
- 4 Use the default value 0 for parameter **Network Device index**.

If the model includes more than one EtherCAT network, enter a unique **Network Device Index** for each network. Enter the same value for all blocks in each network.

- 5 Enter the **Ethernet Port Number** for the EtherCAT port that you are connecting to your EtherCAT network. See “Install EtherCAT Network for Execution” on page 6-11.
- 6 Take the default value Large model for parameter **DC Tuning**.

- 7 To update the data in the EtherCAT Init block and propagate it to the other EtherCAT blocks, click **Refresh Data**.
- 8 Click **OK**.


## Configure EtherCAT PDO Receive Blocks

Before beginning this procedure, you must have selected a valid ENI file in the EtherCAT Init block.

Before you start this procedure, familiarize yourself with TwinCAT 3 and its documentation.

To configure the EtherCAT PDO Receive blocks of model `slrt_ex_ethercat_beckhoff_aio`:

- 1 Double-click the EtherCAT PDO Receive block labeled EtherCAT PDO Receive.
- 2 Set parameter **Network Device Index** to the value set in the EtherCAT Init block.
- 3 From the **Signal Name** list, select the variable, here Term 2 (EL3062).AI Standard Channel 1.Value.
- 4 Observe the value in seconds of parameter **Sample Time**.



- 5 Click **OK**.

Execute steps 1-5 for the EtherCAT PDO Receive block labeled EtherCAT PDO Receive 1.

## Configure EtherCAT PDO Transmit Blocks


Before beginning this procedure, you must have selected a valid ENI file in the EtherCAT Init block.

Before you start this procedure, familiarize yourself with TwinCAT 3 and its documentation.

To configure the EtherCAT PDO Transmit blocks of model `slrt_ex_ethercat_beckhoff_aio`:

- 1 Open model `slrt_ex_ethercat_beckhoff_aio`.
- 2 Double-click the EtherCAT PDO Transmit block labeled EtherCAT PDO Transmit.
- 3 Set parameter **Network Device Index** to the value set in the EtherCAT Init block.
- 4 Select a **Signal Name** variable, here Term 3 (EL4002).A0 Outputs Channel 1.Analog output.
- 5 Observe the value in seconds of parameter **Sample Time**.





6 Click **OK**.

Execute steps 2-6 for the EtherCAT PDO Transmit block labeled EtherCAT PDO Transmit 1.

## Update Async SDO Block Variables by Using Complete Access Mode

The EtherCAT Async SDO Upload block and EtherCAT Async SDO Download block have a parameter that selects between single register access and complete access. This complete access mode provides a convenient method to apply the information that you get from the ESI file, using the information to programmatically populate the number of bytes in the data to read. This example shows approaches to get that information by inspecting the ESI file.

- The EtherCAT Async SDO Upload (read) block outputs a vector of byte data to be parsed with an unpack block.
- The EtherCAT Async SDO Download (write) block receives a vector of byte data produced by a pack block.

This example uses the Beckhoff EL3102 AI (Analog Input) device and shows how to obtain the information from the ESI file to produce the correct configuration for the unpack and pack blocks that are needed. The example uses index 0x8000, which has a set of different variables with varying sizes. This one describes configuration options for an AI channel on the board.

This device has a set of subindexed variables on index 0x8000 (channel 1) and 0x8010 (channel 2) where each of these has subindex values up to 0x18 (24 decimal) for AI configuration settings. Not all subindex values in the range [0,0x18] are available. This information is available in the Beckhoff documentation on their website. The documentation describes what each parameter does on the device, but the documentation does not have exact bit location information. Views from the Beckhoff web site for the EL3102 shows the information.

The screenshot shows a web browser window titled "Beckhoff Information System - English - SeaMonkey". The address bar shows the URL "https://infosys.beckhoff.com/english.php?content". The page header features the Beckhoff logo and the text "New Automation Technology". A navigation bar includes links for "Home", "Contact", "www.beckhoff.com", and "email this page". A sidebar on the left contains a tree view with categories like "Foreword", "Product description", "Basics communication", "Mounting and wiring", "Commissioning", "TwinCAT Quick Start", "TwinCAT Development", "General Notes - EtherCAT", "Process data and operation", "Object description and parameters", "Restore object", "Configuration data", "Objects for regular operation", "Profile-specific objects", "Standard objects", "Basics about signal isolation", "Notices on analog specifications", "Appendix", and "EL31xx-00xx | Analog Input Terminals". The main content area is titled "EL30xx | Analog Input Terminals (12 bit)" and contains a section for "Configuration data" with the sub-heading "Index 80n0 AI settings (for 0 ≤ n ≤ 7)". Below this is a table with the following data:

Index (hex)	Name	Meaning	Data type	Flags	Default
80n0:0	AI Settings	Maximum subindex	UINT8	RO	0x18 (24 <sub>dec</sub> )
80n0:01	Enable user scale	User scale is active.	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:02	Presentation	0: Signed presentation 1: Unsigned presentation 2: Absolute value with MSB as sign Signed amount representation	BIT3	RW	0x00 (0 <sub>dec</sub> )

Beckhoff Information System - English - SeaMonkey

File Edit View Go Bookmarks Tools Window Help

Back Forward Reload Stop <https://infosys.beckhoff.com/english.php?content> Search Print

Home Bookmarks My Clusters Gecko: Menu Dev Pool WorkDay JIRA Source Code Search

Beckhoff Information System - English

# BECKHOFF New Automation Technology

## Beckhoff In

[Select language] Home Contact www.beckhoff.com email this page

- Foreword
- Product description
- Basics communication
- Mounting and wiring
- Commissioning
  - TwinCAT Quick Start
  - TwinCAT Development E
  - General Notes - EtherCA
  - Process data and opera
  - Object description and p
    - Restore object
    - Configuration dat
    - Objects for regular c
    - Profile-specific obje
    - Standard objects
  - Basics about signal isol
  - Notices on analog speci
- Appendix
  - EL31xx-00xx | Analog InputTerm
  - EL3182 | 2 Channel Analog Input
  - EL32xx-0xx0 | Analog Input Terr
  - EL3255 | 5 Channel Potentiomete
  - EL331x-00x0 | Analog Thermocou
  - EL3351 | 1 Channel Analog Res

### EL30xx | Analog Input Terminals (12 bit)

Address	Name	Description	Data Type	Access	Value
80n0:05	Siemens bits	The S5 bits are displayed in the three low-order bits	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:06	Enable filter	Enable filter, which makes PLC-cycle-synchronous data exchange unnecessary	BOOLEAN	RW	0x01 (1 <sub>dec</sub> )
80n0:07	Enable limit 1	Limit 1 enabled	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:08	Enable limit 2	Limit 2 enabled	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:0A	Enable user calibration	Enabling of the user calibration	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )

Transferring data from infosys.beckhoff.com...

The screenshot shows a web browser window displaying the Beckhoff Information System website. The page title is "EL30xx | Analog Input Terminals (12 bit)". A navigation menu on the left includes "Foreword", "Product description", "Basics communication", "Mounting and wiring", "Commissioning", "TwinCAT Quick Start", "TwinCAT Development E", "General Notes - EtherCAT", "Process data and opera", "Object description and p", "Restore object", "Configuration dat", "Objects for regular o", "Profile-specific obje", "Standard objects", "Basics about signal isol", "Notices on analog speci", "Appendix", "EL31xx-00xx | Analog InputTerm", "EL3182 | 2 Channel Analog Input", "EL32xx-0xx0 | Analog Input Terr", "EL3255 | 5 Channel Potentiomete", "EL331x-00x0 | Analog Thermocou", and "EL3351 | 1 Channel Analog Res".

Address	Parameter Name	Description	Bit Length	Access	Default Value
80n0:0B	Enable vendor calibration	Enabling of the vendor calibration	BOOLEAN	RW	0x01 (1 <sub>dec</sub> )
80n0:0E*	Swap limit bits	Swap limit bits	BOOLEAN	RW	0x00 (0 <sub>dec</sub> )
80n0:11	User scale offset	User scaling offset	INT16	RW	0x0000 (0 <sub>dec</sub> )
80n0:12	User scale gain	User scaling gain. The gain is represented in fixed-point format, with the factor 2 <sup>-16</sup> . The value 1 corresponds to 65535 <sub>dec</sub> (0x00010000 <sub>hex</sub> ) and is limited to +/-	INT32	RW	0x00010000 (65536 <sub>dec</sub> )

There are 17 subindexes in the range. When counting the number of bytes, a BOOLEAN is 1 bit and BIT3 is 3 bits with 16 and 32 bit ints as the usual sizes. This listing on the Beckhoff web site does not give the exact bit layout. Bit packing into bytes is not always obvious. In this example, there are 11 bits mentioned, one 3 bit plus 8 boolean, which requires 2 bytes. The information on this data sheet does not specify which bits are in each of the 2 bytes or specify the bit offsets.

Using either TwinCAT or ECEngineer to look at the CoE dictionary does not provide the exact bit layout.

The ESI file contains a full bit level description of 0x8000 and its subindexes, showing exactly where the single bit boolean variables are located in the data. The file also provides the full bit size of the set. The ESI files for devices that TwinCAT recognizes are kept in a directory in the TwinCAT install directory. With ECEngineer, the full set of ESI files it recognizes when shipped is not included, but is processed into the tool by an install process. Each device manufacturer is required to define ESI file

content for their devices. If necessary, ESI files can be obtained directly from the device manufacturer.

The ESI file defines this as a data type, DT8000 for 0x8000 in the EL3102 device. The bit size is 160 bits, which is 20 bytes. This 20 byte value needs to be entered into either the EtherCAT Async SDO Upload block or EtherCAT Async SDO Download block as the array size.

While there is a place in TwinCAT to check a box that says to enable complete access, that appears to only be necessary for TwinCAT to use complete access. Using the Acontis code to get complete access works even if the checkbox is not selected in TwinCAT before exporting the ENI file. No special configuration is needed to use complete access CoE when generating an ENI file. This checkbox can be ignored when creating an ENI file for Simulink Real-Time.

The next image is the EL31xx.xml ESI file. This one EtherCAT SubDevice Information file contains descriptions of over 100 different devices from Beckhoff in the EL31xx group of A/D converters. In a default install of TwinCAT 3.1, the file is found at C:\TwinCAT\3.1\Config\Io\EtherCAT\EL31xx.xml.

If you use a tool such as XML Notepad, you can look through the ESI file with a tree view where you can open sections you're interested in. Using XML Notepad, you find the devices that this ESI file refers to at **EtherCATInfo + Descriptions + Devices**. Next, you need to open the device nodes and look at the name in each. After finding the subordinate device with name EL3102, navigate to the **Device > Profile > Dictionary > DataTypes** entries where you find the types that are used with this device.

To find the datatype that describes the layout for the subindexes under 0x8000, you need to open the datatypes and look for DT8000 (DataType 8000). This datatype is a bit level description of all subindexes under 0x8000 as an example. The EL3102 has 39 different datatypes to search through. The non-structure like datatypes are given first and then the structure like datatypes are at the end numerically sorted by the number in DT<num>. For the EL3102, DT8000 is 6 before the end of the list. Not all manufacturers will name their data types the same way that Beckhoff does here for their devices.

The image shows that DT8000 has a bit size of 160 bits which is  $160/8 = 20$  bytes long. The subitems each describe one subindex bit length and starting bit. The one slight exception is that subindex 0 always contains the largest subindex that this item contains. If read as a single CoE read request, that value is read as a byte. If read as part of complete access, that first element is a uint8 followed by a padding byte that is zero, that's the same as the first entry being a 16 bit integer.

When you read through the subitems for DT8000, you see that not all subindex numbers are used. When determining how to unpack the block of bytes that are returned with a complete access read, there may be unused bytes to force alignment of 16 bit integers to 16 bit boundaries. A 32 bit int appears to be able to be at any 16 bit boundary.

Data is packed using little endian byte ordering. The example above for the max subindex unpacks the second byte as the high order 8 bits of the 16 bit integer, with the first byte being the low order 8 bits.

When unpacking bits for Boolean and short fixed point bitfields, bit 0 of a byte is the low order bit. In the ESI file, the starting bit offset can be found by computing the remainder mod 8 of the bit offset.

The screenshot displays the XML Notepad application window. The title bar reads "XML Notepad - C:\TwinCAT\3.1\Config\lo\EtherCAT\Beckhoff EL31xx.xml". The menu bar includes File, Edit, View, Insert, Window, and Help. The address bar shows the file path: C:\TwinCAT\3.1\Config\lo\EtherCAT\Beckhoff EL31xx.xml.

The interface is split into two main panes. On the left is the "Tree View", which shows a hierarchical structure of the XML document. The root is "xml", followed by "EtherCATInfo". Under "EtherCATInfo", there are several elements: "xmlns:xsi", "xsi:noNamespaceSchemaLocation", "Version", "Vendor", "Descriptions", "Groups", and "Devices". The "Devices" folder is expanded, showing a list of "Device" folders. One "Device" folder is further expanded to show "Physics", "Type", "HideType", "Name", "LcId", "#cdata-section", "Name", and "URL".

On the right is the "XSL Output" pane, which displays the XML code being processed. The visible code includes:
 

```

version="1.0"
http://www.w3.org/200...
EtherCATInfo.xsd
1.2

```

 Below this, there is a large block of "KK" and a "#cdata-section" containing the text "1033 EL3102 2Ch. Ana...".

At the bottom of the window is the "Error List" pane, which contains the following table:

Description	File	Line	Column
Error loading schema 'EtherCATInfo.xsd' Could not find file 'C:\T...	Beckhoff%20E...	2	69
Type 'HexDecValue' is not declared, or is not a simple type.	C:\TwinCAT\3.1...	0	0

The screenshot displays the XML Notepad application window titled "XML Notepad - C:\TwinCAT\3.1\Config\lo\EtherCAT\Beckhoff EL31xx.xml". The interface is split into two main panes: "Tree View" on the left and "XSL Output" on the right. The "Tree View" shows a hierarchical structure of XML elements, including folders for "Device", "Physics", "Type", "HideType", "Name", "LcId", "Profile", "ChannelInfo", "Dictionary", and "DataTypes". The "XSL Output" pane shows the rendered XML content, which includes the text "KK", "1033", and "EL3102 2Ch. Ana...".

At the bottom of the application, there is an "Error List" pane. It contains the following table:

Description	File	Line	Column
Error loading schema 'EtherCATInfo.xsd' Could not find file 'C:\T...	Beckhoff%20E...	2	69
Type 'HexDecValue' is not declared, or is not a simple type.	C:\TwinCAT\3.1...	0	0

The screenshot shows the XML Notepad application with the following content:

**Tree View:**

- DataType
  - DataType
  - DataType
    - Name: DT8000
    - BitSize: 160
    - SubItem
      - SubIdx: 0
      - Name: SubIndex 000
      - Type: USINT
      - BitSize: 8
      - BitOffs: 0
      - Flags
    - SubItem
      - SubIdx: 1
      - Name: Enable user scale
      - Type: BOOL
      - BitSize: 1
      - BitOffs: 16
      - Flags
    - SubItem
      - SubIdx: 2
      - Name: Presentation
      - Type: DT0800EN03
      - BitSize: 3
      - BitOffs: 17
      - Flags
    - SubItem
      - SubIdx: 5
      - Name: Siemens bits
      - BitSize: 2000
      - BitOffs: 0
      - Flags

**XSL Output:**

```

DT8000
160
0
SubIndex 000
USINT
8
0
1
Enable user scale
BOOL
1
16
2
Presentation
DT0800EN03
3
17
5
Siemens bits
2000
  
```

**Error List:**

Description	File	Line	Column
Warning: Error loading schema 'EtherCATInfo.xsd' Could not find file 'C:\T...	Beckhoff%20E...	2	69
Error: Type 'HexDecValue' is not declared, or is not a simple type.	C:\TwinCAT3.1...	0	0

The next image shows that subitem 21, Filter settings, has a data type of its own, DT0801EN16 which is defined as an enum in another datatype entry. Those values define the different filter bandwidths that the A/D can be set to use although the actual cutoff frequencies are given in the data sheet, not here in the ESI file. Those values are also listed in the Beckhoff man page for the EL3102.

Block parameters:

- Index — Edit box for main index, hex value as 0x8000, or converted to decimal as 32768.



- Access Mode — Complete Access
- Subindex — Edit box for first subindex to read or write. Only 0 or 1 are allowed for complete access. If 1 is chosen, then the value of index 0 is not returned.
- Data Type — uint8 or uint16
- Dimension — Edit box for the number of bytes to read or write. Get the bit size from the ESI file and divide by 8.
- Network Device Index — EtherCAT network ID
- Device Name — Pull down list of terminal device names

Most of the EtherCAT documentation shows indexes in hex. For this complete set for index 0x8000, the list of variable types in the pack or unpack block is:

```
{ 'uint16', 'uint8', 'uint8', 'int16', 'int32', 'int16', 'int16', 'uint16', 'int16', 'int16' }
```

To unpack the bits from both of the uint8 entries an additional bit unpack or bit pack block is needed for each one.

The unpack block also needs a cell array listing the vector dimension of each. In this case, this vector works:

```
{[1], [1], [1], [1], [1], [1], [1], [1], [1], [1]}
```


## Configure EtherCAT Model Configuration Parameters

Before beginning this procedure, you must have selected a valid ENI file in the EtherCAT Init block. For more information, see “Fixed-Step Size Derivation” on page 6-28.

To configure the configuration parameters for model `slrt_ex_ethercat_beckhoff_aio`:

- 1 Open model `slrt_ex_ethercat_beckhoff_aio`.
- 2 Calculate the greatest common divisor (GCD) of the **Sample Time** values for the EtherCAT tasks and for all source blocks in the model. In this case, the GCD is `0.010`.
- 3 In the Simulink Editor, on the **Real-Time** tab, from the **Prepare** section, click **Hardware Settings**. Select **Configuration Parameters > Solver**.
- 4 Set the **Type** parameter to Fixed-step and **Fixed-step size (fundamental sample time)** to one of the following:
  - An integral divisor of the GCD value, in seconds.
  - auto, if all other source blocks in the model have defined sample times.

In this case, set the parameter to `0.010`.



5 Click **OK**.

The next tasks are building, downloading, and executing the EtherCAT main device node model.

## EtherCAT Distributed Clock Algorithm

### In this section...

“Main Device Shift Mode” on page 6-25

“Bus Shift Mode” on page 6-26

“Limitations” on page 6-27


An EtherCAT network consists of a main device node (the target computer) connected to an arbitrary number of subordinate device nodes (devices). Each node contains a clock that controls its internal operation. When you enable distributed clocks in the ENI file by using the configurator program, EtherCAT designates one clock in the network as the reference clock. The EtherCAT distributed clock (DC) algorithm then synchronizes the operation of multiple network nodes to the reference clock.

The DC algorithm operates in two phases. In phase 1, the algorithm aligns the clocks of DC-enabled network nodes other than the main device node with the clock of the first DC-enabled subordinate device node. In phase 2, the algorithm aligns the remaining unaligned clock with the reference clock.


### Main Device Shift Mode

In main device shift mode, the reference clock is the clock of the first DC-enabled subordinate device in the network.

In phase 1, the algorithm shifts the sample time of the network nodes to align with the clock of the first subordinate device node. In that process, the EtherCAT Init block output value `NetworkToSubDeviceClkDiff` decreases to near zero.




In phase 2, the algorithm shifts the sample time of the main device stack running on the target computer to align with the first subordinate device node clock. In that process, the EtherCAT Init block output value `MdeviceToNetworkClkDiff` decreases to near zero. If there are no DC enabled devices, both values are zero.




### Bus Shift Mode

In bus shift mode, the reference clock is the clock of the main device stack running on the target computer.

In phase 1, the algorithm shifts the sample time of the DC-enabled network nodes to align with the clock of the first DC-enabled subordinate device node. In that process, the value `NetworkToSubDeviceClkDiff` decreases to near zero.



In phase 2, the algorithm shifts the sample time of the first DC-enabled subordinate device node to align with the clock of the main device stack. In that process, the value `MdeviceToNetworkClkDiff` decreases to near zero. The algorithm shifts the sample time of the other network nodes to stay aligned with the first subordinate device node clock. In that process, the value of `NetworkToSubDeviceClkDiff` can first increase, then decrease to near zero.



## Limitations

To include EtherCAT distributed clocks when PTP is enabled for the model, use EtherCAT bus shift mode.

## See Also

EtherCAT Init

## More About

- “EtherCAT Init Block DC Error Values” on page 6-32

## Fixed-Step Size Derivation

To configure the sample time for an EtherCAT model, set the **Fixed-step size (fundamental sample time)** for the entire model in the model Configuration Parameters **Solver** pane. You can also specify the sample times for key blocks. Sample times for blocks are integer multiples or divisors of the fundamental sample time.

During execution, the fixed-step size determines the cycle tick of the EtherCAT tasks and the sample times of the other source blocks in the model. Subject to the fixed step size value, the block type determines the sample time groups: a comparatively long sample time for the synchronous SDO blocks and another, shorter sample time for the rest of the blocks. As a best practice, set the sample time for the synchronous SDO blocks to a value at least three times of that for the PDO blocks.

Using an EtherCAT network configurator, specify the EtherCAT task cycle tick based on the requirements of the EtherCAT network. Specify the fixed-step size so that the GCD of the task cycle tick and the block sample times is an integer multiple of the fixed-step size.

For example, assume that the fastest EtherCAT task rate is 50 Hz for a corresponding cycle tick of 20 ms. The model block sample times, scaled to ms, are [20, 30, 40 50]. The FSS is:

$$\text{FSS} = \min(\text{gcd}(20, [20, 30, 40, 50]))$$

FSS =

10

The software sends all PDO data updates at the fastest EtherCAT task cycle tick (20 ms), even if you created multiple EtherCAT tasks running at different cycle ticks. The PDO Read and Write blocks run at the cycle tick for the tasks containing the given EtherCAT variable.

If you know that the other source blocks have defined sample times, you can set **Fixed-step size** to **auto**. If one or more block sample times are incompatible with the fixed sample time, there is an error during system update. If you do not encounter an error, in the Simulink Editor, on the **Debug** tab, from **Information Overlays**, click **Sample Time Colors** to see the block sample times.

## EtherCAT Protocol Mapping

EtherCAT supports several overlay protocols. Simulink Real-Time supports some of the protocols directly, provides others with minimal support, and does not support some other protocols.

Overlay Protocol	Protocol Description	Support Type	Action
CANopen over EtherCAT (CoE)	Implements CANopen functionality by using EtherCAT	Direct	Model CoE by using SDO upload and download blocks
Ethernet over EtherCAT (EoE)	Provides EtherCAT wrapper around Ethernet packets. EtherCAT acts as network switch	Minimal	Send wrapped EoE messages between separate subordinate devices
File Access over EtherCAT (FoE)	Updates the EtherCAT board ROM	Not supported	Update the EtherCAT subordinate device ROM with TwinCAT 3.
Functional Safety over EtherCAT (FSoE)	Sends asynchronous safety messages over the network	Not supported	Not applicable
Servcos over EtherCAT (SoE)	Wraps vendor-specific servo commands in a common protocol	Direct	SoE by using SSC up and down

CoE and SoE are two addressing schemes for configuration parameters in subordinate devices. SoE is used for some motor drives. For more information, see the device documentation.

## EtherCAT Configurator Component Mapping

This table summarizes the mapping between third-party EtherCAT configurator components and Simulink Real-Time blocks and block attributes. For more information, see the TwinCAT 3 or Acontis EC-Engineer documentation.

EtherCAT Configurator Component		Simulink Real-Time Component
TwinCAT	Acontis EC-Engineer	
Cycle ticks (task step)	Cycle time	Sample time
Scalars and vectors	Dimension	Dimension
BitSize	Byte size of type	Type Size
Data Type, BitSize	Data type	Signal Type
EtherCAT device variable names linked to variables in the task PDO	All PDO variable names included in default task as defined in the ENI file	EtherCAT PDO signal names for the Receive and Transmit PDO blocks

### See Also

EtherCAT PDO Receive | EtherCAT PDO Transmit

### More About

- “EtherCAT Data Types” on page 6-31



## EtherCAT Data Types

The Simulink Real-Time EtherCAT blocks directly support the following EtherCAT data types. The software maps other EtherCAT data types to a byte array. The byte array requires explicit data type conversion by using Byte Pack, Byte Unpack, or S-function blocks.

<b>EtherCAT Data Type</b>	<b>Data Type Size (bits)</b>	<b>Converted Simulink Data Type</b>
bit	1	uint8
bit8	8	uint8
bitarr	8 (bit array)	uint8
bitarr16	16 (bit array)	uint16
bitarr32	32 (bit array)	uint32
BOOL	1	Boolean
int8	8	int8
int16	16	int16
int32	32	int32
int64	64	int64
uint8	8	uint8
uint16	16	uint16
uint32	32	uint32

## EtherCAT Init Block DC Error Values

The Simulink Real-Time EtherCAT Init block returns the following EtherCAT distributed clock (DC) error values related to the main device shift controller and the bus shift controller.

Error Value	Description
1 (0x1)	Initialization function not called or not successful
2 (0x2)	Controller error — synchronization out of limit Main device shift: error 2, Maximum controller error exceeded Bus shift: error 2, Maximum controller error exceeded
3 (0x3)	Not enough memory
4 (0x4)	Hardware layer — (BSP) invalid
5 (0x5)	Hardware layer — error modifying the timer
6 (0x6)	Hardware layer — timer is not running
7 (0x7)	Hardware layer — function is called on wrong CPU
8 (0x8)	Invalid DC synchronization period length
9 (0x9)	Error DCM Controller SetVal is too small
10 (0xA)	Error DCM Controller — Drift between local timer and ref clock too high
11 (0xB)	ERROR: Error DCM Controller - Bus cycle time (dwBusCycleTimeUsec) doesn't match real cycle
27 (0x1B)	DC controller not ready Main device shift: error 27, DC controller not ready Bus shift: error 27, DC controller not ready
28 (0x1C)	DC controller busy

## EtherCAT Error Codes

The **Error** output for the EtherCAT blocks returns an EtherCAT error code. These blocks include:

- EtherCAT Sync SSC/SoE Upload
- EtherCAT Sync SSC/SoE Download
- EtherCAT Async SSC/SoE Upload
- EtherCAT Async SSC/SoE Download
- EtherCAT Sync SDO Upload
- EtherCAT Sync SDO Download
- EtherCAT Async SDO Upload
- EtherCAT Async SDO Download
- EtherCAT Set State

These EtherCAT error codes are prepended onto the small number error codes. These prepended codes must not appear without the small number added. These prepended codes appear in the upper 16 bits of the unsigned 32-bit error code. You can mask the codes to display the small number error code. In the table, the Decimal column shows the base 10 value after the upper 16 bits are masked.

Prepended Codes	Hexadecimal	Error Text
EC_E_NOERROR	0x00000000	No Error
EC_E_ERROR	0x98110000	Unspecific Error
EMRAS_E_ERROR	0x98110180	Unspecific RAS Error  The RAS (Remote Access Server) is not yet implemented
DCM_E_ERROR	0x981201C0	Unspecific DCM Error  This class of error comes from the main device shift DC driver
EC_TEXTBASE	0x0200	Unknown Text (Base)
EC_ALSTATEBASE	0x0300	AL Status No Error

These codes are the small-number EtherCAT error codes.

Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x01	1	ERROR: Feature not supported
EC_E_ERROR+0x02	2	ERROR: Invalid index
EC_E_ERROR+0x03	3	ERROR: Invalid offset
EC_E_ERROR+0x04	4	ERROR: Cancel
EC_E_ERROR+0x05	5	ERROR: Invalid size
EC_E_ERROR+0x06	6	ERROR: Invalid data
EC_E_ERROR+0x07	7	ERROR: Not ready
EC_E_ERROR+0x08	8	ERROR: Busy

Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x09	9	ERROR: Cannot queue acyclic EtherCAT command (MdeviceConfig.dwMaxQueuedEthFrames)
EC_E_ERROR+0x0A	10	ERROR: No memory left
EC_E_ERROR+0x0B	11	ERROR: Invalid parameter
EC_E_ERROR+0x0C	12	ERROR: Not found
EC_E_ERROR+0x0D	13	ERROR: Duplicate
EC_E_ERROR+0x0E	14	ERROR: Invalid state
EC_E_ERROR+0x0F	15	ERROR: Cannot add subordinate device to timer list
EC_E_ERROR+0x10	16	ERROR: Time-out
EC_E_ERROR+0x11	17	ERROR: Open failed
EC_E_ERROR+0x12	18	ERROR: Send failed
EC_E_ERROR+0x13	19	ERROR: Insert mailbox error
EC_E_ERROR+0x14	20	ERROR: Invalid mailbox command
EC_E_ERROR+0x15	21	ERROR: Unknown mailbox protocol command
EC_E_ERROR+0x16	22	ERROR: Access denied
EC_E_ERROR+0x17	23	ERROR: Identification failed
EC_E_ERROR+0x1A	26	ERROR: Invalid product key
EC_E_ERROR+0x1B	27	ERROR: Wrong format of main device XML file
EC_E_ERROR+0x1C	28	ERROR: Feature disabled
EC_E_ERROR+0x1D	29	ERROR: Shadow memory requested in wrong mode
EC_E_ERROR+0x1E	30	Bus configuration mismatch
EC_E_ERROR+0x1F	31	ERROR: Error in reading config file
EC_E_ERROR+0x20	32	ERROR: Configuration doesn't support SAFEOP and OP requested state
EC_E_ERROR+0x21	33	ERROR: Cyclic commands are missing
EC_E_ERROR+0x22	34	ERROR: AL_STATUS register read missing in XML file for at least one state
EC_E_ERROR+0x23	35	ERROR: Fatal internal McSm
EC_E_ERROR+0x24	36	ERROR: Subordinate device error
EC_E_ERROR+0x25	37	ERROR: Frame lost, IDX mismatch
EC_E_ERROR+0x26	38	ERROR: At least one EtherCAT command is missing in the received frame
EC_E_ERROR+0x28	40	ERROR: IOCTL EC_IOCTL_DC_LATCH_REQ_LTIMVALS not possible in DC Latching auto read mode
EC_E_ERROR+0x29	41	ERROR: Auto increment address - increment mismatch (subordinate device missing)
EC_E_ERROR+0x2A	42	ERROR: Subordinate device in invalid state, e.g. not in OP (API not callable in this state)

Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x2B	43	ERROR: Station address lost or subordinate device missing - FPRD to AL_STATUS failed
EC_E_ERROR+0x2C	44	ERROR: Too many cyclic commands in XML configuration file. (Check EC_T_MDEVICE_CONFIG.dwMaxQueuedEthFrames
EC_E_ERROR+0x2D	45	ERROR: Ethernet link cable disconnected
EC_E_ERROR+0x2E	46	ERROR: Main device core not accessible
EC_E_ERROR+0x2F	47	ERROR CoE: Mailbox send: working counter
EC_E_ERROR+0x31	49	ERROR: No mailbox support
EC_E_ERROR+0x32	50	ERROR CoE: Protocol not supported
EC_E_ERROR+0x33	51	ERROR EoE: Protocol not supported
EC_E_ERROR+0x34	52	ERROR FoE: Protocol not supported
EC_E_ERROR+0x35	53	ERROR SoE: Protocol not supported
EC_E_ERROR+0x36	54	ERROR VoE: Protocol not supported
CoE SDO command errors can be returned by the 4 SDO/CoE blocks		
EC_E_ERROR+0x40	64	ERROR SDO: Toggle bit not alternated
EC_E_ERROR+0x41	65	ERROR SDO: SDO protocol time-out
EC_E_ERROR+0x42	66	ERROR SDO: Client/server command specifier not valid or unknown
EC_E_ERROR+0x43	67	ERROR SDO: Invalid block size (block mode only
EC_E_ERROR+0x44	68	ERROR SDO: Invalid sequence number (block mode only
EC_E_ERROR+0x45	69	ERROR SDO: CRC error (block mode only
EC_E_ERROR+0x46	70	ERROR SDO: Out of memory
EC_E_ERROR+0x47	71	ERROR SDO: Unsupported access to an object
EC_E_ERROR+0x48	72	ERROR SDO: Attempt to read a write only object
EC_E_ERROR+0x49	73	ERROR SDO: Attempt to write a read only object
EC_E_ERROR+0x4A	74	ERROR SDO: Object does not exist in the object dictionary
EC_E_ERROR+0x4B	75	ERROR SDO: Object cannot be mapped to the PDO
EC_E_ERROR+0x4C	76	ERROR SDO: Number and length of objects to be mapped exceed PDO length
EC_E_ERROR+0x4D	77	ERROR SDO: General parameter incompatibility
EC_E_ERROR+0x4E	78	ERROR SDO: General internal incompatibility in the device.
EC_E_ERROR+0x4F	79	ERROR SDO: Access failed due to an hardware error

Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x50	80	ERROR SDO: Data type does not match, length of service parameter does not match
EC_E_ERROR+0x51	81	ERROR SDO: Data type does not match, service parameter too long
EC_E_ERROR+0x52	82	ERROR SDO: Data type does not match, service parameter too short
EC_E_ERROR+0x53	83	ERROR SDO: Sub-index does not exist
EC_E_ERROR+0x54	84	ERROR SDO: Write access - Parameter value out of range
EC_E_ERROR+0x55	85	ERROR SDO: Write access - Parameter value out of high limit
EC_E_ERROR+0x56	86	ERROR SDO: Write access - Parameter value out of low limit
EC_E_ERROR+0x57	87	ERROR SDO: Maximum value is less than minimum value
EC_E_ERROR+0x58	88	ERROR SDO: General error
EC_E_ERROR+0x59	89	ERROR SDO: Unable to transfer or store data to the application
EC_E_ERROR+0x5A	90	ERROR SDO: Unable to transfer or store data to the application because of local control
EC_E_ERROR+0x5B	91	ERROR SDO: Unable to transfer or store data to the application because of the present device state
EC_E_ERROR+0x5C	92	ERROR SDO: Dynamic generation of object dictionary failed or missing object dictionary
EC_E_ERROR+0x5D	93	ERROR SDO: Unknown code
FoE commands (not reachable with SLRT implementation)		
EC_E_ERROR+0x60	96	ERROR FoE: Vendor specific FoE error
EC_E_ERROR+0x61	97	ERROR FoE: Not found
EC_E_ERROR+0x62	98	ERROR FoE: Access denied
EC_E_ERROR+0x63	99	ERROR FoE: Disk full
EC_E_ERROR+0x64	100	ERROR FoE: Illegal
EC_E_ERROR+0x65	101	ERROR FoE: Wrong packet number
EC_E_ERROR+0x66	102	ERROR FoE: Already exists
EC_E_ERROR+0x67	103	ERROR FoE: User missing
EC_E_ERROR+0x68	104	ERROR FoE: Bootstrap only
EC_E_ERROR+0x69	105	ERROR FoE: Not bootstrap
EC_E_ERROR+0x6A	106	ERROR FoE: No rights

Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x6B	107	ERROR FoE: Program error
End of FoE specific errors		
General errors again		
EC_E_ERROR+0x70	112	ERROR: Main device configuration not found
EC_E_ERROR+0x71	113	ERROR: Command error while EEPROM upload
EC_E_ERROR+0x72	114	ERROR: Command error while EEPROM download
EC_E_ERROR+0x73	115	ERROR: Cyclic command wrong size (too long)
EC_E_ERROR+0x74	116	ERROR: Invalid input offset in cyc cmd, please check InputOffs
EC_E_ERROR+0x75	117	ERROR: Invalid output offset in cyc cmd, please check OutputOffs
EC_E_ERROR+0x76	118	ERROR: Port Close failed
EC_E_ERROR+0x77	119	ERROR: Port Open failed
SoE command errors, can be returned by the 4 SSC/SoE blocks		
EC_E_ERROR+0x78	120	ERROR SoE: Invalid access to element 0
EC_E_ERROR+0x79	121	ERROR SoE: Does not exist
EC_E_ERROR+0x7a	122	ERROR SoE: Invalid access to element 1
EC_E_ERROR+0x7b	123	ERROR SoE: Name does not exist
EC_E_ERROR+0x7c	124	ERROR SoE: Name undersize in transmission
EC_E_ERROR+0x7d	125	ERROR SoE: Name oversize in transmission
EC_E_ERROR+0x7e	126	ERROR SoE: Name unchangeable
EC_E_ERROR+0x7f	127	ERROR SoE: Name currently write-protected
EC_E_ERROR+0x80	128	ERROR SoE: Attribute undersize in transmission
EC_E_ERROR+0x81	129	ERROR SoE: Attribute oversize in transmission
EC_E_ERROR+0x82	130	ERROR SoE: Attribute unchangeable
EC_E_ERROR+0x83	131	ERROR SoE: Attribute currently write-protected
EC_E_ERROR+0x84	132	ERROR SoE: Unit does not exist
EC_E_ERROR+0x85	133	ERROR SoE: Unit undersize in transmission
EC_E_ERROR+0x86	134	ERROR SoE: Unit oversize in transmission

Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x87	135	ERROR SoE: Unit unchangeable
EC_E_ERROR+0x88	136	ERROR SoE: Unit currently write-protected
EC_E_ERROR+0x89	137	ERROR SoE: Minimum input value does not exist
EC_E_ERROR+0x8a	138	ERROR SoE: Minimum input value undersize in transmission
EC_E_ERROR+0x8b	139	ERROR SoE: Minimum input value oversize in transmission
EC_E_ERROR+0x8c	140	ERROR SoE: Minimum input value unchangeable
EC_E_ERROR+0x8d	141	ERROR SoE: Minimum input value currently write-protected
EC_E_ERROR+0x8e	142	ERROR SoE: Maximum input value does not exist
EC_E_ERROR+0x8f	143	ERROR SoE: Maximum input value undersize in transmission
EC_E_ERROR+0x90	144	ERROR SoE: Maximum input value oversize in transmission
EC_E_ERROR+0x91	145	ERROR SoE: Maximum input value unchangeable
EC_E_ERROR+0x92	146	ERROR SoE: Maximum input value currently write-protected
EC_E_ERROR+0x93	147	ERROR SoE: Data item does not exist
EC_E_ERROR+0x94	148	ERROR SoE: Data item undersize in transmission
EC_E_ERROR+0x95	149	ERROR SoE: Data item oversize in transmission
EC_E_ERROR+0x96	150	ERROR SoE: Data item unchangeable
EC_E_ERROR+0x97	151	ERROR SoE: Data item currently write-protected
EC_E_ERROR+0x98	152	ERROR SoE: Data item less than minimum input value limit
EC_E_ERROR+0x99	153	ERROR SoE: Data item exceeds maximum input value limit
EC_E_ERROR+0x9a	154	ERROR SoE: Data item is incorrect
EC_E_ERROR+0x9b	155	ERROR SoE: Data item is protected by password
EC_E_ERROR+0x9c	156	ERROR SoE: Data item temporary unchangeable (in AT or MDT)
EC_E_ERROR+0x9d	157	ERROR SoE: Invalid indirect
EC_E_ERROR+0x9e	158	ERROR SoE: Data item temporary unchangeable (parameter or opmode...)
EC_E_ERROR+0x9f	159	ERROR SoE: Command already active
EC_E_ERROR+0x100	256	ERROR SoE: Command not interruptible
EC_E_ERROR+0x101	257	ERROR SoE: Command not available (in this phase)
EC_E_ERROR+0x102	258	ERROR SoE: Command not available (invalid parameter...)



Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x103	259	ERROR SoE: Response drive number not identical with the requested drive number
EC_E_ERROR+0x104	260	ERROR SoE: Response IDN not identical with the requested IDN
EC_E_ERROR+0x105	261	ERROR SoE: At least one fragment lost
EC_E_ERROR+0x106	262	ERROR SoE: RX buffer is full (ecat call with too small data-buffer)
EC_E_ERROR+0x107	263	ERROR SoE: No data state.
EC_E_ERROR+0x108	264	ERROR SoE: No default value.
EC_E_ERROR+0x109	265	ERROR SoE: Default value transmission too long.
EC_E_ERROR+0x10a	266	ERROR SoE: Default value cannot be changed, read only.
EC_E_ERROR+0x10b	267	ERROR SoE: Invalid drive number.
EC_E_ERROR+0x10c	268	ERROR SoE: General error
EC_E_ERROR+0x10d	269	ERROR SoE: No element addressed.
End of SoE specific error codes		
EC_E_ERROR+0x10e	270	Command not executed. Subordinate device is not present on Bus
EC_E_ERROR+0x10f	271	ERROR FoE: Protocol not supported in boot strap
EC_E_ERROR+0x110	272	ERROR: command error while EEPROM reload
EC_E_ERROR+0x111	273	ERROR: command error while Reset Subordinate device Controller
EC_E_ERROR+0x11E	286	Bus configuration not detected, Topology changed
EC_E_ERROR+0x11F	287	ERROR EoE: Mailbox receive: working counter
EC_E_ERROR+0x120	288	ERROR FoE: Mailbox receive: working counter
EC_E_ERROR+0x121	289	ERROR SoE: mailbox receive: working counter
EC_E_ERROR+0x122	290	ERROR AoE: Mailbox receive: working counter
EC_E_ERROR+0x123	291	ERROR VoE: Mailbox receive: working counter
EC_E_ERROR+0x124	292	ERROR: EEPROM assignment failed
EC_E_ERROR+0x125	293	ERROR: Error mailbox received
EC_E_ERROR+0x126	294	ERROR: Redundancy line break
EC_E_ERROR+0x127	295	ERROR: Invalid EtherCAT cmd in cyclic frame with redundancy
EC_E_ERROR+0x128	296	ERROR: <PreviousPort>-tag is missing!
EC_E_ERROR+0x129	297	ERROR: DC is enabled and DC cyclic commands are missing (e.g. access to 0x900)!

Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x130	304	ERROR: DL Status Interrupt because of changed Topology
EC_E_ERROR+0x131	305	ERROR: The Pass Through Server is not running!
EC_E_ERROR+0x132	306	ERROR: The ADS adapter (Pass Through Server) is running
EC_E_ERROR+0x133	307	ERROR: Could not start the Pass Through Server
EC_E_ERROR+0x134	308	ERROR: The Pass Through Server could not bind the IP address with a socket
EC_E_ERROR+0x135	309	The Pass Through Server is running but not enabled
EC_E_ERROR+0x136	310	ERROR: This LinkLayer mode is not supported by the Pass Through Server
EC_E_ERROR+0x137	311	ERROR VoE: No VoE mailbox received
EC_E_ERROR+0x138	312	ERROR: SYNC out unit of reference clock is disabled
EC_E_ERROR+0x139	313	ERROR: Reference clock not found
EC_E_ERROR+0x13B	315	ERROR: Mailbox command working counter error
<p>AoE is not supported by any SLRT blocks. These should never be returned.</p>		
EC_E_ERROR+0x13C	316	ERROR AoE: Protocol not supported
EC_E_ERROR+0x13D	317	ERROR AoE: Invalid AoE response received
EC_E_ERROR+0x13E	318	ERROR AoE: Common AoE device error
EC_E_ERROR+0x13F	319	ERROR AoE: Service is not supported by server
EC_E_ERROR+0x140	320	ERROR AoE: Invalid index group
EC_E_ERROR+0x141	321	ERROR AoE: Invalid index offset
EC_E_ERROR+0x142	322	ERROR AoE: Reading/writing not permitted
EC_E_ERROR+0x143	323	ERROR AoE: Parameter size not correct
EC_E_ERROR+0x144	324	ERROR AoE: Invalid parameter value(s)
EC_E_ERROR+0x145	325	ERROR AoE: Device is not in a ready state
EC_E_ERROR+0x146	326	ERROR AoE: Device is busy
EC_E_ERROR+0x147	327	ERROR AoE: Invalid context
EC_E_ERROR+0x148	328	ERROR AoE: Out of memory
EC_E_ERROR+0x149	329	ERROR AoE: Invalid parameter value(s)
EC_E_ERROR+0x14A	330	ERROR AoE: Not found
EC_E_ERROR+0x14B	331	ERROR AoE: Syntax error in command or file
EC_E_ERROR+0x14C	332	ERROR AoE: Objects do not match
EC_E_ERROR+0x14D	333	ERROR AoE: Object already exists
EC_E_ERROR+0x14E	334	ERROR AoE: Symbol not found

Hexadecimal	Decimal	Error Text
EC_E_ERROR+0x14F	335	ERROR AoE: Symbol version invalid
EC_E_ERROR+0x150	336	ERROR AoE: Server is in invalid state
EC_E_ERROR+0x151	337	ERROR AoE: AdsTransMode not supported
EC_E_ERROR+0x152	338	ERROR AoE: Notification handle is invalid
EC_E_ERROR+0x153	339	ERROR AoE: Notification client not registered
EC_E_ERROR+0x154	340	ERROR AoE: No more notification handles
EC_E_ERROR+0x155	341	ERROR AoE: Size for watch too big
EC_E_ERROR+0x156	342	ERROR AoE: Device not initialized
EC_E_ERROR+0x157	343	ERROR AoE: Device has a timeout
EC_E_ERROR+0x158	344	ERROR AoE: Query interface failed
EC_E_ERROR+0x159	345	ERROR AoE: Wrong interface required
EC_E_ERROR+0x15A	346	ERROR AoE: Class ID is invalid
EC_E_ERROR+0x15B	347	ERROR AoE: Object ID is invalid
EC_E_ERROR+0x15C	348	ERROR AoE: Request is pending
EC_E_ERROR+0x15D	349	ERROR AoE: Request is aborted
EC_E_ERROR+0x15E	350	ERROR AoE: Signal warning
EC_E_ERROR+0x15F	351	ERROR AoE: Invalid array index
EC_E_ERROR+0x160	352	ERROR AoE: Symbol not active -> release handle and try again
EC_E_ERROR+0x161	353	ERROR AoE: Access denied
EC_E_ERROR+0x162	354	ERROR AoE: Internal error
EC_E_ERROR+0x163	355	ERROR AoE: Target port not found
EC_E_ERROR+0x164	356	ERROR AoE: Target machine not found
EC_E_ERROR+0x165	357	ERROR AoE: Unknown command ID
EC_E_ERROR+0x166	358	ERROR AoE: Port not connected
EC_E_ERROR+0x167	359	ERROR AoE: Invalid AMS length
EC_E_ERROR+0x168	360	ERROR AoE: invalid AMS Net ID
EC_E_ERROR+0x169	361	ERROR AoE: Port disabled
EC_E_ERROR+0x16A	362	ERROR AoE: Port already connected
EC_E_ERROR+0x16B	363	ERROR AoE: Invalid AMS port!
EC_E_ERROR+0x16C	364	ERROR AoE: No memory!
EC_E_ERROR+0x16D	365	ERROR AoE: Vendor specific AoE device error
EC_E_ERROR+0x16E	366	ERROR: Invalid AoE NetID!
End of AoE specific errors		

Hexadecimal	Decimal	Error Text
Generic errors that indicate configuration problems, should never happen.		
EC_E_ERROR+0x16F	367	ERROR: Maximum number of bus subordinate device has been exceeded
EC_E_ERROR+0x170	368	ERROR Mailbox: Syntax of 6 octet Mailbox header is wrong!
EC_E_ERROR+0x171	369	ERROR Mailbox: The Mailbox protocol is not supported
EC_E_ERROR+0x172	370	ERROR Mailbox: Field contains wrong value
EC_E_ERROR+0x173	371	ERROR Mailbox: The service in the Mailbox protocol is not supported
EC_E_ERROR+0x174	372	ERROR Mailbox: The mailbox protocol header of the mailbox protocol is wrong
EC_E_ERROR+0x175	373	ERROR Mailbox: Length of received mailbox data is too short
EC_E_ERROR+0x176	374	ERROR Mailbox: Mailbox protocol can not be processed because of limited resources
EC_E_ERROR+0x177	375	ERROR Mailbox: The length of data is inconsistent
EC_E_ERROR+0x178	376	ERROR: Subordinate devices with DC configured are present on bus before the reference clock
EC_E_ERROR+0x179	377	ERROR: Data type conversion failed
EC_E_ERROR+0x17A	378	ERROR FoE: File is bigger than max file size
EC_E_ERROR+0x17B	379	ERROR: Line crossed
EC_E_ERROR+0x17C	380	ERROR: Line crossed at subordinate device \"%s\", EtherCAT auto-increment address=%d, station address=%d. Error at port %d."
EC_E_ERROR+0x17D	381	ERROR: Socket disconnected

### See Also

EtherCAT Sync SSC/SoE Upload | EtherCAT Sync SSC/SoE Download | EtherCAT Async SSC/SoE Upload | EtherCAT Async SSC/SoE Download | EtherCAT Sync SDO Upload | EtherCAT Sync SDO Download | EtherCAT Async SDO Upload | EtherCAT Async SDO Download | EtherCAT Set State

# EtherCAT Blocks

---

## EtherCAT Init

Initialize EtherCAT main device node with data in the EtherCAT Network Information (ENI) file



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Init block initializes the EtherCAT main device stack. The block specifies the Ethernet interface cards in the network.

Before you use this block, create and save an EtherCAT Network Information (ENI) file. You export the ENI file from the Beckhoff TwinCAT or the acontis EC-Engineer. See “Configure EtherCAT Network by Using TwinCAT 3” on page 6-7.

To find the ENI file, click **Browse**. To read the ENI file and store the data in the EtherCAT Init block, click **Refresh Data**.

The Simulink Real-Time software supports multiple EtherCAT networks. To use multiple networks:

- Use a different Ethernet card interface for each EtherCAT network.
- In the model, use one EtherCAT Init block for each network.

To include EtherCAT distributed clocks when PTP is enabled for the model, use EtherCAT bus shift mode.

### Ports

#### Output

**Status** — Status information about the EtherCAT network  
vector

The `Status` vector contains these values: `ErrVal`, `MdeviceState`, `DCErrVal`, `MdeviceToNetworkClkDiff`, `DCInitState`, and `NetworkToSubDeviceClkDiff`.

- `ErrVal` — Error status:
  - No error: 0
  - Error: Value less than 0.

Because `ErrVal` shows the latest error status, the propagation of errors can hide the original error. To find the original error, add an EtherCAT Get Notifications block and use the `slrealtime.EtherCAT.filterNotifications` command to print the status codes that the EtherCAT stack transmits.

- `MdeviceState` — Operating state of the EtherCAT network.

State	Value	Description
INIT	1	Initialization — The system finds terminal devices and initializes the communication controller.
PREOP	2	Preoperational — The system uses the communication controller to exchange system-specific initialization data. In this state, the network cannot transmit or receive signal data.
SAFEOP	4	Safe operational — The network is running and ready for full operation. The supervisor sends input data to the terminal device. The terminal device output remains in a safe state.
OP	8	Operational — The network is in full operation. The supervisor sends input data to the terminal device. The terminal device responds with output data.

- **DCErrVal** — DC error status for the main device shift controller:
  - No DC Error for main device shift controller: 0
  - DC error for main device shift controller: Value from “EtherCAT Init Block DC Error Values” on page 6-32.

When you select main device shift controller mode, the value 0 indicates successful clock distribution. The **DCErrVal** does not apply when the distributed clock is disabled.

- **MdeviceToNetworkClkDiff** — Time difference, in nanoseconds, between the main device stack clock and the clock on the first subordinate device that has enabled DC.
- **DCInitState** — Operating state of the distributed clock:
  - DC not enabled, not initialized, or single EtherCAT DC subordinate device: 0
  - DC has been started and the EtherCAT DC subordinate devices are in sync with each other: 1
- **NetworkToSubDeviceClkDiff** — Time difference, in nanoseconds, between the clock on the first EtherCAT subordinate device and the least closely locked clock on the remaining subordinate devices.

This value applies only to subordinate devices that have enabled DC. If only one device on the network has enabled DC, this value is 0.

Data Types: int32

## Parameters

**Config file (ENI)** — ENI file from the EtherCAT configurator  
character vector

Specify the ENI file that you exported from the EtherCAT configurator.

You can specify the absolute path name or a relative path name from the current folder. If you specify only the file name, the software searches for the file in the current folder and on the MATLAB path. If more than one file with that name exists on the path, MATLAB displays a message box that indicates a clearer file specification is needed.

Clicking **Browse** inserts a full, editable path name.

**Programmatic Use****Block Parameter:** `config_file`**Network Device Index** — EtherCAT network identifier`0-15`

A unique integer in the range 0–15 that identifies the Ethernet card for an EtherCAT network.

For each EtherCAT network, the software generates a unique device index. The software inserts that device index as **Device index** into the EtherCAT Init block that represents the network. For more information about Speedgoat Target Machine settings, see “Install EtherCAT Network for Execution” on page 6-11.

**Programmatic Use****Block Parameter:** `device_id`**Ethernet Port Number** — Port number in target computer`int`

The first port reserved for EtherCAT by the `speedgoat.configureEthernet` function is port 1 here. For more information, see the description of the `speedgoat.configureEthernet` function in Speedgoat documentation. For more information about Speedgoat Target Machine settings, see “Install EtherCAT Network for Execution” on page 6-11.

**Programmatic Use****Block Parameter:** `portnum`**DC Tuning** — Distributed clock initialization parameter`Large model (default) | Medium model | Small model`

Enter the distributed clock initialization parameter from one of these values:

- `Large model (default)` — Sends 16,000 timing initialization packets and allows 1 second of settling time. Provides best initial synchronization between multiple subordinate devices that have DC enabled.
- `Medium model` — Sends 8,000 timing initialization packets and allows 0.3 seconds of settling time. The model reaches operational state about a second earlier than it does with the `Large model` setting.
- `Small model` — Sends 2,000 timing initialization packets and allows 0.2 seconds of settling time. The model reaches operational state earlier than it does with the other settings.

Monitor device synchronization at the moment that the model enters the operational state. If the ENI file enables DC, make sure that the devices are synchronized closely enough for your application.

**Programmatic Use****Block Parameter:** `dctuning`**Enable EtherCAT Log for Debugging** — Access to debugging and logging block parameters`Off (default) | Warning | Info | Verbose | All`

The selections choose:

- `Off` — Skip all except fatal errors in log.
- `Warning` — Include warnings and fatal errors in log.



- **Info** — Include information displays, warnings, and fatal errors in log.
- **Verbose** — Include sequencing information from EtherCAT stack, information displays, warnings, and fatal errors in log.
- **All** — include low level debugging information and all other categories in log.

The **Verbose** and **All** logging levels can produce so much data that it can cause overloads at fast task rates.

The target log file name is `E_Mdevice%d`, where `%d` is the device id value.

#### **Programmatic Use**

**Block Parameter:** `enaDebug`

## **Version History**

**Introduced in R2020b**

## **Extended Capabilities**

#### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

#### **See Also**

EtherCAT Get Notifications | `slrealtime.EtherCAT.filterNotifications` | “EtherCAT Init Block DC Error Values” on page 6-32

#### **Topics**

“Configure EtherCAT Network by Using TwinCAT 3” on page 6-7

“Configure EtherCAT Main Device Node Model” on page 6-12

#### **External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)

# EtherCAT Get Notifications

Collect notifications from the EtherCAT bus



**Libraries:**  
Simulink Real-Time / EtherCAT

## Description

The EtherCAT Get Notifications block collects notifications from the EtherCAT stack and presents them to the output as a 21-element vector of `int32`. At each time step, the block outputs what it has accumulated and clears itself for the next time step.

The vector contains the number of notifications in element 1, followed by up to 20 notification codes. The maximum number of notifications is 20. If the bus presents more than 20 notifications to the output, the block discards the newest notifications and presents the first 20 that were received.

## Ports

### Output

**Values** — Self-descriptive 21-element vector containing EtherCAT notification codes  
[Length 20 \* Notification]

- Length (0 - 20) — the number of notifications in the vector.
- Notification — a composite of a notification type and a specific value. The types are:
  - EC\_NOTIFY\_GENERIC [0x00000000 (0)] — Represents state changes, such as: 0x00000001 (1) — EtherCAT operational state change.
  - EC\_NOTIFY\_ERROR [0x00010000 (65536)] — Represents error states, such as 0x00010001 (65537):cyclic command: working counter error. Some describe changes in error state.
  - EC\_NOTIFY\_SCANBUS [0x00030000 (3\*65536)] — Represents ScanBus error states, such as 0x00030002 (196610):ScanBus mismatch.
  - EC\_NOTIFY\_HOTCONNECT [0x00040000 (4\*65536)] — Represents hot connect states, such as 0x00040005 (262149):Subordinate device disappears.

To print the valid notification values and descriptions, call `slrealtime.etherCAT.filterNotifications` without an argument.

Data Types: `int32`

## Parameters

**Network Device Index** — EtherCAT network identifier  
0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use****Block Parameter:** `device_id`**Sample time** — Sample time of block`-1 (default) | numeric`

Enter the base sample time or a multiple of the base sample time. Use the EtherCAT task sample time.

**Programmatic Use****Block Parameter:** `sample_time`**Tips**

To collect notifications:

- 1 Add the EtherCAT Get Notifications block to your model.
- 2 Connect the EtherCAT Get Notifications block to a File Log block.
- 3 Use exported data log data from signal data displayed in the Simulation Data Inspector. See example Get Time and Data Log from EtherCAT Get Notifications Block for the `slrealtime.EtherCAT.filterNotifications` function.

**Version History****Introduced in R2020b****Extended Capabilities****C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**`slrealtime.EtherCAT.filterNotifications` | EtherCAT Init**External Websites**[www.ethercat.org](http://www.ethercat.org)[www.beckhoff.com](http://www.beckhoff.com)[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT Get Scanbus Error Data

Detects when an EtherCAT device in the model is not responding



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Get Scanbus Error Data block detects when a device in the model is not responding, provides error output to stop the model, and generates log output that indicates which device is not responding. The log message provides detailed information about where the EtherCAT network does not match the ENI file. The log message indicates either that there is a missing device at a network position or that a different device is found in a network position than is specified in the ENI for that position. Only the first mismatch found is reported. The block `Error` output can be used to trigger the Stop Simulation block.

### Ports

#### Input

**Values** — Input from EtherCAT Get Notifications block  
[Length 20 \* Notification]

The block scans input from the EtherCAT Get Notifications block.

#### Output

**Error** — Indicates scanbus error  
false (default) | true

One boolean output that is true for one cycle following a notification for a scanbus error.

## Version History

Introduced in R2022b

### Extended Capabilities

#### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

### See Also

EtherCAT Get Notifications | `slrealtime.EtherCAT.filterNotifications`

#### External Websites

[www.ethercat.org](http://www.ethercat.org)  
[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT PDO Receive

Receive data from subordinate device represented by process data object



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT PDO Receive block receives data from the EtherCAT subordinate device.

The block parameter dialog box has two sections, parameters and signal information. When you specify an EtherCAT network and device variable name:

- The EtherCAT PDO Receive block mask is updated with the selected signal name.
- The signal information in the block parameter dialog box is updated to reflect the device variable.

---

**Note** If an error occurs while the software parses the configuration file specified in the EtherCAT Init block, this block displays an error message.

---

### Ports

#### Output

**D** — Data received from subordinate device  
[double]

Vector of data received from the EtherCAT subordinate device.

### Parameters

**Network Device Index** — EtherCAT network identifier  
0 (default) | 0-15

To associate a block with an EtherCAT network, copy the **Device index** value from the EtherCAT Init block representing that network into the **Device index** for the block.

#### Programmatic Use

**Block Parameter:** device\_id

**Signal name** — EtherCAT device variable name  
character vector

From the list, select the EtherCAT device variable name.

The block parameter dialog box updates the read-only signal information to reflect the device variable that you selected.

For a mapping of EtherCAT configurator components to Simulink Real-Time blocks and block attributes, see “EtherCAT Configurator Component Mapping” on page 6-30.

For a mapping of Simulink data types to EtherCAT data types, see “EtherCAT Data Types” on page 6-31.

**Programmatic Use**

**Block Parameter:** sig\_name

**Signal Offset** — Location in the process of signal data  
integer

This parameter is read-only.

After the execution of the EtherCAT Init block, location in the process image from which the data is available.

**Programmatic Use**

**Block Parameter:** sig\_offset

**Signal Type** — Data type for EtherCAT data  
character vector

This parameter is read-only.

Simulink data type for the EtherCAT data.

**Programmatic Use**

**Block Parameter:** sig\_type

**Type Size (bits)** — Size of EtherCAT data type  
integer

This parameter is read-only.

Size in bits of the EtherCAT data type.

**Programmatic Use**

**Block Parameter:** type\_size

**Signal Dimension** — Dimension of the signal  
integer

This parameter is read-only.

The EtherCAT blocks support vectors and scalars (vectors of dimension 1).

**Programmatic Use**

**Block Parameter:** sig\_dim

**Sample Time** — Rate at which this block is executed  
numeric

This parameter is read-only.

This rate is the execution rate of the EtherCAT task, as specified in the ENI file.

**Programmatic Use**

**Block Parameter:** `sample_time`

## **Version History**

**Introduced in R2020b**

## **Extended Capabilities**

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## **See Also**

EtherCAT Init | EtherCAT PDO Transmit

## **Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

## **External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)



# EtherCAT PDO Transmit

Send data to subordinate device represented by process data object



**Libraries:**  
Simulink Real-Time / EtherCAT

## Description

The EtherCAT PDO Transmit block transmits computed data to a particular variable in the EtherCAT subordinate device.

The block parameter dialog box has two sections, parameters and signal information. When you specify an EtherCAT network and device variable name:

- The EtherCAT PDO Receive block mask is updated with the selected signal name.
- The signal information in the block parameter dialog box is updated to reflect the device variable.

---

**Note** If an error occurs while the software parses the configuration file specified in the EtherCAT Init block, this block displays an error message.

---

## Ports

### Input

**D** — Data to transmit to subordinate device  
[double]

Vector of data to transmit to the EtherCAT subordinate device.

## Parameters

**Network Device Index** — EtherCAT network identifier  
0 (default) | 0 - 15

To associate a block with an EtherCAT network, copy the **Device index** value from the EtherCAT Init block representing that network into the **Device index** for the block.

### Programmatic Use

**Block Parameter:** device\_id

**Signal name** — EtherCAT device variable name  
character vector

From the list, select the EtherCAT device variable name.

The block parameter dialog box updates the read-only signal information to reflect the device variable that you selected.

For a mapping of EtherCAT configurator components to Simulink Real-Time blocks and block attributes, see “EtherCAT Configurator Component Mapping” on page 6-30.

For a mapping of Simulink data types to EtherCAT data types, see “EtherCAT Data Types” on page 6-31.

**Programmatic Use****Block Parameter:** sig\_name**Signal Offset** — Location in the process of signal data  
integer

This parameter is read-only.

After the execution of the EtherCAT Init block, location in the process image from which the data is available.

**Programmatic Use****Block Parameter:** sig\_offset**Signal Type** — Data type for EtherCAT data  
character vector

This parameter is read-only.

Simulink data type for the EtherCAT data.

**Programmatic Use****Block Parameter:** sig\_type**Type Size (bits)** — Size of EtherCAT data type  
integer

This parameter is read-only.

Size in bits of the EtherCAT data type.

**Programmatic Use****Block Parameter:** type\_size**Signal Dimension** — Dimension of the signal  
integer

This parameter is read-only.

The EtherCAT blocks support vectors and scalars (vectors of dimension 1).

**Programmatic Use****Block Parameter:** sig\_dim**Sample Time** — Rate at which this block is executed  
numeric

This parameter is read-only.

This rate is the execution rate of the EtherCAT task, as specified in the ENI file.

**Programmatic Use****Block Parameter:** `sample_time`**Version History****Introduced in R2020b****Extended Capabilities****C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

EtherCAT Init | EtherCAT PDO Receive

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**[www.ethercat.org](http://www.ethercat.org)[www.beckhoff.com](http://www.beckhoff.com)[www.acontis.com/en/](http://www.acontis.com/en/)

# EtherCAT Get State

Get state of EtherCAT network



**Libraries:**  
Simulink Real-Time / EtherCAT

## Description

The EtherCAT Get State block returns the state of the EtherCAT network.

## Ports

### Output

**State** — State received from the EtherCAT network

1 | 2 | 4 | 8

State	Value	Description
INIT	1	Initialization — The system finds terminal devices and initializes the communication controller.
PREOP	2	Preoperational — The system uses the communication controller to exchange system-specific initialization data. In this state, the network cannot transmit or receive signal data.
SAFEOP	4	Safe operational — The network is running and ready for full operation. The supervisor sends input data to the terminal device. The terminal device output remains in a safe state.
OP	8	Operational — The network is in full operation. The supervisor sends input data to the terminal device. The terminal device responds with output data.

## Parameters

**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

### Programmatic Use

**Block Parameter:** device\_id

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use****Block Parameter:** `sample_time`**Version History****Introduced in R2020b****Extended Capabilities****C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

EtherCAT Init | EtherCAT Set State

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**[www.ethercat.org](http://www.ethercat.org)[www.beckhoff.com](http://www.beckhoff.com)[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT Set State

Set state of EtherCAT network



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Set State block sets the state of the EtherCAT network to the value passed in through the **New State** port.

### Ports

#### Input

**New State** — State transmitted to the EtherCAT network

1 | 2 | 4 | 8

State	Value	Description
INIT	1	Initialization — The system finds terminal devices and initializes the communication controller.
PREOP	2	Preoperational — The system uses the communication controller to exchange system-specific initialization data. In this state, the network cannot transmit or receive signal data.
SAFEOP	4	Safe operational — The network is running and ready for full operation. The supervisor sends input data to the terminal device. The terminal device output remains in a safe state.
OP	8	Operational — The network is in full operation. The supervisor sends input data to the terminal device. The terminal device responds with output data.

#### Output

**Prev State** — Previous state of the network

1 | 2 | 4 | 8

This port returns the value of the previous setting of the **New State** port.

**Error** — Report an EtherCAT state error

0 | integer

If no error occurs, this port returns 0. Otherwise, it returns a nonzero value.

### Parameters

**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use**

**Block Parameter:** device\_id

**Timeout** — Time to wait for the network to change state

integer

Enter the number of seconds to wait for the EtherCAT network state to transition.

Set the timeout to 0 to return immediately. If you specify a nonzero **Timeout** value, in the Configuration Parameters **Solver** pane, set the **Fixed-step size** parameter to a value larger than the **Timeout** value.

**Programmatic Use**

**Block Parameter:** timeout

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use**

**Block Parameter:** sample\_time

## Version History

Introduced in R2020b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

EtherCAT Init | EtherCAT Get State

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT Get Device State

Get state of EtherCAT network



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Get Device State block returns the state of a device on the EtherCAT network.

### Ports

#### Output

**State** — State received from the selected device

1 | 2 | 4 | 8

State	Value	Description
INIT	1	Initialization — The system finds terminal devices and initializes the communication controller.
PREOP	2	Preoperational — The system uses the communication controller to exchange system-specific initialization data. In this state, the network cannot transmit or receive signal data.
SAFEOP	4	Safe operational — The network is running and ready for full operation. The supervisor sends input data to the terminal device. The terminal device output remains in a safe state.
OP	8	Operational — The network is in full operation. The supervisor sends input data to the terminal device. The terminal device responds with output data.

### Parameters

**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

#### Programmatic Use

**Block Parameter:** `device_id`

**SubDevice Name** — Name of EtherCAT subordinate device

character vector

Select an EtherCAT subordinate device from the list of available subordinate devices provided by the ENI configuration file. The configuration file is selected by the EtherCAT Init block.



**Programmatic Use****Block Parameter:** device\_name**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use****Block Parameter:** sample\_time

## Version History

Introduced in R2021b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

EtherCAT Init | EtherCAT Set State | EtherCAT Get State | EtherCAT Set Device State

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**[www.ethercat.org](http://www.ethercat.org)[www.beckhoff.com](http://www.beckhoff.com)[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT Set Device State

Set state of EtherCAT network



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Set Device State block sets the state of a device on the EtherCAT network to the value passed through the **New State** port.

### Ports

#### Input

**New State** — State transmitted to the EtherCAT network

1 | 2 | 4 | 8

State	Value	Description
INIT	1	Initialization — The system finds terminal devices and initializes the communication controller.
PREOP	2	Preoperational — The system uses the communication controller to exchange system-specific initialization data. In this state, the network cannot transmit or receive signal data.
SAFEOP	4	Safe operational — The network is running and ready for full operation. The supervisor sends input data to the terminal device. The terminal device output remains in a safe state.
OP	8	Operational — The network is in full operation. The supervisor sends input data to the terminal device. The terminal device responds with output data.

**Enable** — Enables block to send state request

0 | 1

The port takes a Boolean value. When true (1), the block sends a new state request. When false (0), the block does nothing.

#### Output

**Prev State** — Previous state of the selected device

1 | 2 | 4 | 8

This port returns the value of the previous state of the device. That value might not be the same as the previous state of this block.

**Error** — Report an EtherCAT state error

0 | integer

If no error occurs, this port returns 0. Otherwise, it returns a nonzero value. For more information, see “EtherCAT Error Codes” on page 6-33.

## Parameters

**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use**

**Block Parameter:** device\_id

**SubDevice Name** — Name of EtherCAT subordinate device

character vector

Select an EtherCAT subordinate device from the list of available subordinate devices provided by the ENI configuration file. The configuration file is selected by the EtherCAT Init block.

**Programmatic Use**

**Block Parameter:** device\_name

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use**

**Block Parameter:** sample\_time

## Version History

**Introduced in R2021b**

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

EtherCAT Init | EtherCAT Set State | EtherCAT Get State | EtherCAT Get Device State

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT Sync SDO Upload

Read data synchronously from subordinate device represented by service data object



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Sync SDO Upload block selects a CANopen register by **Index** value in the specified EtherCAT subordinate device and sends a read request. The block then waits until it receives a response or until the timeout period is over.

The response to an operation takes several ticks of the main task sample time. Assign the synchronous blocks a sample time slower than the main task sample time.

### Ports

#### Output

**Data** — Data received from subordinate device  
numeric

Returns data received from the EtherCAT subordinate device.

**Error** — Report an EtherCAT network error  
0 | integer

If no error occurs, this port transmits 0. Otherwise, it transmits a nonzero value. For a list of error codes, see “EtherCAT Error Codes” on page 6-33.

### Parameters

**Index** — Index of CANopen register  
integer

Specify the hexadecimal (for example, 0x7) or decimal index of the CANopen register.

If you specify an invalid index, the block returns a nonzero value through the Error output.

**Programmatic Use**  
**Block Parameter:** index

**Subindex** — Subindex of CANopen register  
integer

Specify the hexadecimal (for example, 0x7) or decimal subindex of the CANopen register.

If you specify an invalid subindex, the block returns a nonzero value through the Error output.

**Programmatic Use****Block Parameter:** subIndex**Data Type** — Data type of CANopen register

double (default) | single | int8 | uint8 | int16 | uint16 | int32 | uint32 | boolean

From the list, select the data type of the CANopen register.

If you select a data type that does not match the type of the entry, the block returns a nonzero value through the Error output.

**Programmatic Use****Block Parameter:** sig\_type**Dimension** — Dimension of CANopen register

1 (default)

Specify the row and column dimension of the CANopen register.

Enter the vector length as found in the CoE description for the subordinate device in its manual.

**Programmatic Use****Block Parameter:** sig\_dim**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.**Programmatic Use****Block Parameter:** device\_id**SubDevice Name** — Name of device that contains CANopen register

character vector

From the list, select the name of the device that contains the CANopen register.

The block populates this drop-down list with the contents of the configuration file.

**Programmatic Use****Block Parameter:** subdevice\_name**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use****Block Parameter:** sample\_time**Timeout** — Time to wait for response from subordinate device

numeric

The maximum number of milliseconds to wait for a response before returning a timeout error.

**Programmatic Use**

**Block Parameter:** timeout

## **Version History**

**Introduced in R2020b**

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## **See Also**

EtherCAT Init | EtherCAT Sync SDO Download

## **Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

## **External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)

# EtherCAT Sync SDO Download

Transmit data synchronously to subordinate device represented by service data object



**Libraries:**  
Simulink Real-Time / EtherCAT

## Description

The EtherCAT Sync SDO Download block selects a CANopen register by **Index** value in the specified EtherCAT subordinate device and sends a write request. The block then waits until it receives a response or until the timeout period is over.

The response to an operation takes several ticks of the main task sample time. Assign the synchronous blocks a sample time slower than the main task sample time.

## Ports

### Input

**Data** — Data to write to subordinate device  
numeric

Input data for writing to the EtherCAT subordinate device.

### Output

**Error** — Report an EtherCAT network error  
0 | integer

If no error occurs, this port transmits 0. Otherwise, it transmits a nonzero value. For a list of error codes, see “EtherCAT Error Codes” on page 6-33.

## Parameters

**Index** — Index of CANopen register  
integer

Specify the hexadecimal (for example, 0x7) or decimal index of the CANopen register.

If you specify an invalid index, the block returns a nonzero value through the Error output.

### Programmatic Use

**Block Parameter:** index

**Subindex** — Subindex of CANopen register  
integer

Specify the hexadecimal (for example, 0x7) or decimal subindex of the CANopen register.

If you specify an invalid subindex, the block returns a nonzero value through the Error output.

**Programmatic Use****Block Parameter:** subIndex**Data Type** — Data type of CANopen register

double (default) | single | int8 | uint8 | int16 | uint16 | int32 | uint32 | boolean

From the list, select the data type of the CANopen register.

If you select a data type that does not match the type of the entry, the block returns a nonzero value through the Error output.

**Programmatic Use****Block Parameter:** sig\_type**Dimension** — Dimension of CANopen register

1 (default)

Specify the row and column dimension of the CANopen register.

Enter the vector length as found in the CoE description for the subordinate device in its manual.

**Programmatic Use****Block Parameter:** sig\_dim**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.**Programmatic Use****Block Parameter:** device\_id**SubDevice Name** — Name of device that contains CANopen register

character vector

From the list, select the name of the device that contains the CANopen register.

The block populates this drop-down list with the contents of the configuration file.

**Programmatic Use****Block Parameter:** subdevice\_name**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use****Block Parameter:** sample\_time**Timeout** — Time to wait for response from subordinate device

numeric

The maximum number of milliseconds to wait for a response before returning a timeout error.



**Programmatic Use**

**Block Parameter:** timeout

## **Version History**

**Introduced in R2020b**

## **Extended Capabilities**

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## **See Also**

EtherCAT Init | EtherCAT Sync SDO Upload

## **Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

## **External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT Async SDO Upload

Read data asynchronously from subordinate device represented by service data object



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Async SDO Upload block selects a CANopen register by **Index** value in the specified EtherCAT subordinate device and sends a read request. It then immediately returns whatever value was returned from the device on an earlier call to the block.

### Ports

#### Input

**Enable** — Enables block to upload data  
int32

A value of 0 disables uploads. A constant value of 1 will send a new request each time the status returns to the idle state.

#### Output

**Data** — Data received from subordinate device  
numeric

Returns data received from the EtherCAT subordinate device.

**Status** — Status of data transfer  
0 | 1 | 2 | 3

Status of asynchronous data transfer:

- 0 — Mailbox transfer object idle, transfer not running
- 1 — Mailbox transfer object running, transfer not complete
- 2 — Transfer successfully executed
- 3 — Error occurred during transfer request

**Error** — Report an EtherCAT network error  
0 | integer

If no error occurs, this port transmits 0. Otherwise, it transmits a nonzero value. For a list of error codes, see “EtherCAT Error Codes” on page 6-33.

## Parameters

**Index** — Index of CANopen register  
integer

Specify the hexadecimal (for example, 0x7) or decimal index of the CANopen register.

If you specify an invalid index, the block returns a 3 through the Status output and a nonzero value through the Error output.

### Programmatic Use

**Block Parameter:** index

**Access Mode** — Select access mode for CoE variables  
Single Subindex (default) | Complete Access

When the **Access Mode** is Complete Access, the SubIndex parameter is hidden, and the correct subindex is assumed in each case. The complete access protocol for CoE access to variables provides:

- Access to all subindexes attached to a single index in the CoE dictionary for a single terminal device.
- Read or write all subindexes in the time it would take to read or write a single one of them.
- Simultaneously update all subindexes when a tuning parameter set is being written
- Capture a simultaneous read of all subindexes
- Allow use of EtherCAT devices that require complete access for configuration

### Programmatic Use

**Block Parameter:** complete

**Subindex** — Subindex of CANopen register  
integer

Specify the hexadecimal (for example, 0x7) or decimal subindex of the CANopen register.

If you specify an invalid subindex, the block returns a nonzero value through the Error output.

### Programmatic Use

**Block Parameter:** subIndex

**Data Type** — Data type of CANopen register  
double (default) | single | int8 | uint8 | int16 | uint16 | int32 | uint32 | boolean

From the list, select the data type of the CANopen register.

If you select a data type that does not match the type of the entry, the block returns a nonzero value through the Error output.

### Programmatic Use

**Block Parameter:** sig\_type

**Dimension** — Dimension of CANopen register  
1 (default)

Specify the row and column dimension of the CANopen register.

Enter the vector length as found in the CoE description for the subordinate device in its manual.

**Programmatic Use**

**Block Parameter:** sig\_dim

**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use**

**Block Parameter:** device\_id

**SubDevice Name** — Name of device that contains CANopen register

character vector

From the list, select the name of the device that contains the CANopen register.

The block populates this drop-down list with the contents of the configuration file.

**Programmatic Use**

**Block Parameter:** subdevice\_name

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use**

**Block Parameter:** sample\_time

## Version History

Introduced in R2020b

**R2022a: Complete Access Mode**

You can select the access mode for the EtherCAT Async SDO Upload block and EtherCAT Async SDO Download block.

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

EtherCAT Init | EtherCAT Async SDO Download

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

“Update Async SDO Block Variables by Using Complete Access Mode” on page 6-15

**External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT Async SDO Download

Transmit data asynchronously to subordinate device represented by service data object



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Async SDO Download block selects a CANopen register by **Index** value in the specified EtherCAT subordinate device and sends a write request. The block then immediately continues processing its input data.

### Ports

#### Input

**Data** — Data to write to subordinate device  
numeric

Input data for writing to the EtherCAT subordinate device.

**Enable** — Enables block to download data  
int32

A value of 0 disables downloads. A value greater than or equal to 1 enables the block to download data.

#### Output

**Status** — Status of data transfer  
0 | 1 | 2 | 3

Status of asynchronous data transfer:

- 0 — Mailbox transfer object idle, transfer not running
- 1 — Mailbox transfer object running, transfer not complete
- 2 — Transfer successfully executed
- 3 — Error occurred during transfer request

**Error** — Report an EtherCAT network error  
0 | integer

If no error occurs, this port transmits 0. Otherwise, it transmits a nonzero value. For a list of error codes, see “EtherCAT Error Codes” on page 6-33.

### Parameters

**Index** — Index of CANopen register  
integer

Specify the hexadecimal (for example, 0x7) or decimal index of the CANopen register.

If you specify an invalid index, the block returns a 3 through the Status output and a nonzero value through the Error output.

**Programmatic Use**

**Block Parameter:** index

**Access Mode** — Select access mode for CoE variables

Single Subindex (default) | Complete Access

When the **Access Mode** is Complete Access, the protocol for CoE access to variables provides:

- Access to all subindexes attached to a single index in the CoE dictionary for a single terminal device.
- Read or write all subindexes in the time it would take to read or write a single one of them.
- Simultaneously update all subindexes when a tuning parameter set is being written
- Capture a simultaneous read of all subindexes
- Allow use of EtherCAT devices that require complete access for configuration

**Programmatic Use**

**Block Parameter:** complete

**Subindex** — Subindex of CANopen register

integer

Specify the hexadecimal (for example, 0x7) or decimal subindex of the CANopen register.

If you specify an invalid subindex, the block returns a nonzero value through the Error output.

**Programmatic Use**

**Block Parameter:** subIndex

**Data Type** — Data type of CANopen register

double (default) | single | int8 | uint8 | int16 | uint16 | int32 | uint32 | boolean

From the list, select the data type of the CANopen register.

If you select a data type that does not match the type of the entry, the block returns a nonzero value through the Error output.

**Programmatic Use**

**Block Parameter:** sig\_type

**Dimension** — Dimension of CANopen register

1 (default)

Specify the row and column dimension of the CANopen register.

Enter the vector length as found in the CoE description for the subordinate device in its manual.

**Programmatic Use**

**Block Parameter:** sig\_dim

**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use**

**Block Parameter:** `device_id`

**SubDevice Name** — Name of device that contains CANopen register  
character vector

From the list, select the name of the device that contains the CANopen register.

The block populates this drop-down list with the contents of the configuration file.

**Programmatic Use**

**Block Parameter:** `subdevice_name`

**Sample time** — Sample time of block  
-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use**

**Block Parameter:** `sample_time`

## Version History

Introduced in R2020b

### R2022a: Complete Access Mode

You can select the access mode for the EtherCAT Async SDO Upload block and EtherCAT Async SDO Download block.

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

EtherCAT Init | EtherCAT Async SDO Upload

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

“Update Async SDO Block Variables by Using Complete Access Mode” on page 6-15

**External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)

[www.acontis.com/en/](http://www.acontis.com/en/)



# EtherCAT Sync SSC/SoE Upload

Read data synchronously from subordinate device represented by service data object



## Libraries:

Simulink Real-Time / EtherCAT

## Description

The EtherCAT Sync SSC/SoE Upload block provides synchronous SERCOS interface (Serial Real time COmmunication Specification) over EtherCAT (SoE) upload. The block selects an **IDN** in the specified subordinate device and sends an upload (read) request. The block then waits until it receives a response to the request or until the timeout period expires.

The response to an operation takes several ticks of the main task sample time. Assign the synchronous blocks a sample time slower than the main task sample time.

## Ports

### Output

**Data** — Data received from subordinate device  
numeric

Returns data received from the EtherCAT subordinate device. The data signal has the type specified in Data Type and a vector dimension given by Dimension.

**Error** — Report an EtherCAT network error  
0 | integer

If no error occurs, this port transmits 0. Otherwise, it transmits a nonzero value. For list of error codes, see “EtherCAT Error Codes” on page 6-33.

## Parameters

**IDN** — Identification Number  
character vector

Identify parameters.

The documentation for your EtherCAT device specifies the **IDN** values. You can select the **IDN** as a character vector that represents a 16-bit integer (according to IEC 61800 -7 -204), such as S-0-0150 or P-0-0150 with:

- First field (bit 15): S for Standard data, P for product-specific data
- Second field (bit 14 - 12): 0 . . 7 for parameter set
- Third field (bit 11 - 0): 0 . . 4095 for data-block number

**Programmatic Use****Block Parameter:** idn**Drive Number** — Index number of the drive

integer

Specify the decimal index of the drive.

SoE blocks apply to only motor controllers. A single subordinate device can support one or more drive or motor channels. The drive number is the zero-based index of the drive or motor channel on this subordinate device at which this block is aimed. In SoE terminology, the drive is the logic that sends control signals to the motor. Typically, this logic is a small processor inside the subordinate device.

**Programmatic Use****Block Parameter:** drive**Data Type** — Data type of the IDN

double (default) | single | int8 | uint8 | int16 | uint16 | int32 | uint32 | boolean

To identify the data type for the IDN, refer to the subordinate device documentation for the description of the IDN and the data type it uses. From the list, select the data type of the **IDN**.

If you select a data type that does not match the type of the entry, the block returns a nonzero value through the Error output.

**Programmatic Use****Block Parameter:** sig\_type**Dimension** — Dimension of data for this IDN

1 (default)

Specify the row dimension of data for this IDN.

To identify the dimension of data (vector size) for the IDN, refer to the subordinate device documentation for the description of the IDN and the number of data type values (the dimension) it uses. Enter the vector length as found in the SoE description for the subordinate device in its manual.

**Programmatic Use****Block Parameter:** sig\_dim**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use****Block Parameter:** device\_id**SubDevice Name** — Name of device that contains the IDN

character vector

From the list, select the name of the device that contains the **IDN**.

The block populates this drop-down list with the contents of the configuration file.

**Programmatic Use****Block Parameter:** subdevice\_name**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited. The EtherCAT Sync SSC/SoE Download block and the EtherCAT Sync SSC/SoE Upload block require at least three steps of the main EtherCAT processing task. Select a sample time that is three times that of the main task sample time or the model can overload and stop.

**Programmatic Use****Block Parameter:** sample\_time**Timeout** — Time to wait for response from subordinate device

numeric

Enter the maximum number of milliseconds to wait for a response from the EtherCAT subordinate device.

**Programmatic Use****Block Parameter:** timeout

## Version History

**Introduced in R2020b**

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

EtherCAT Init | EtherCAT Sync SSC/SoE Download

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**[www.ethercat.org](http://www.ethercat.org)[www.beckhoff.com](http://www.beckhoff.com)[www.acontis.com/en/](http://www.acontis.com/en/)

## EtherCAT Sync SSC/SoE Download

Transmit data synchronously to subordinate device represented by service data object



**Libraries:**  
Simulink Real-Time / EtherCAT

### Description

The EtherCAT Sync SSC/SoE Download block provides synchronous SERCOS interface (Serial Real time COmmunication Specification) over EtherCAT (SoE) download. The block selects an **IDN** in the specified subordinate device and sends a download (write) request. The block then waits until it receives a response to the request or until the timeout period expires.

The response to an operation takes several ticks of the main task sample time. Assign the synchronous blocks a sample time slower than the main task sample time.

### Ports

#### Input

**Data** — Data to write to subordinate device  
numeric

Input data for writing to the EtherCAT subordinate device. The data signal has the type specified in **Data Type** and vector dimension given by **Dimension**.

#### Output

**Error** — Report an EtherCAT network error  
0 | integer

If no error occurs, this port transmits 0. Otherwise, it transmits a nonzero value. For list of error codes, see “EtherCAT Error Codes” on page 6-33.

### Parameters

**IDN** — Identification Number  
character vector

Identify parameters.

The documentation for your EtherCAT device specifies the **IDN** values. You can select the **IDN** as a character vector that represents a 16-bit integer (according to IEC 61800 -7 -204), such as S-0-0150 or P-0-0150 with:

- First field (bit 15): S for Standard data, P for product-specific data
- Second field (bit 14 - 12): 0 . . 7 for parameter set
- Third field (bit 11 - 0): 0 . . 4095 for data-block number

**Programmatic Use****Block Parameter:** idn**Drive Number** — Index number of the drive

integer

Specify the decimal index of the drive.

SoE blocks apply to only motor controllers. A single subordinate device can support one or more drive or motor channels. The drive number is the zero-based index of the drive or motor channel on this subordinate device at which this block is aimed. In SoE terminology, the drive is the logic that sends control signals to the motor. Typically, this logic is a small processor inside the subordinate device.

**Programmatic Use****Block Parameter:** drive**Data Type** — Data type of the IDN

double (default) | single | int8 | uint8 | int16 | uint16 | int32 | uint32 | boolean

To identify the data type for the IDN, refer to the subordinate device documentation for the description of the IDN and the data type it uses. From the list, select the data type of the **IDN**.

If you select a data type that does not match the type of the entry, the block returns a nonzero value through the Error output.

**Programmatic Use****Block Parameter:** sig\_type**Dimension** — Dimension of data for this IDN

1 (default)

Specify the row dimension of data for this IDN.

To identify the dimension of data (vector size) for the IDN, refer to the subordinate device documentation for the description of the IDN and the number of data type values (the dimension) it uses. Enter the vector length as found in the SoE description for the subordinate device in its manual.

**Programmatic Use****Block Parameter:** sig\_dim**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use****Block Parameter:** device\_id**SubDevice Name** — Name of device that contains the IDN

character vector

From the list, select the name of the device that contains the **IDN**.

The block populates this drop-down list with the contents of the configuration file.

**Programmatic Use****Block Parameter:** subdevice\_name**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited. The EtherCAT Sync SSC/SoE Download block and the EtherCAT Sync SSC/SoE Upload block require at least three steps of the main EtherCAT processing task. Select a sample time that is three times that of the main task sample time or the model can overload and stop.

**Programmatic Use****Block Parameter:** sample\_time**Timeout** — Time to wait for response from subordinate device

numeric

Enter the maximum number of milliseconds to wait for a response from the EtherCAT subordinate device.

**Programmatic Use****Block Parameter:** timeout

## Version History

**Introduced in R2020b**

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

EtherCAT Init | EtherCAT Sync SSC/SoE Upload

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**[www.ethercat.org](http://www.ethercat.org)[www.beckhoff.com](http://www.beckhoff.com)[www.acontis.com/en/](http://www.acontis.com/en/)

# EtherCAT Async SSC/SoE Upload

Read data asynchronously from subordinate device represented by service data object



## Libraries:

Simulink Real-Time / EtherCAT

## Description

The EtherCAT Async SSC/SoE Upload block provides asynchronous SERCOS interface (Serial Real time COmmunication Specification) over EtherCAT (SoE) upload. The block selects an **IDN** in the specified subordinate device and sends an upload (read) request. After sending the request, the block immediately returns whatever value was returned from the device on an earlier call to the block.

## Ports

### Input

**Enable** — Enables block to upload data

int32

A value 0 disables uploads. A value greater than or equal to 1 enables the block to upload data.

### Output

**Data** — Data received from subordinate device

numeric

Returns data received from the EtherCAT subordinate device. The data signal has the type specified in Data Type and a vector dimension given by Dimension.

**Status** — Status of data transfer

0 | 1 | 2 | 3

Status of asynchronous data transfer:

- 0 — Mailbox transfer object idle, transfer not running
- 1 — Mailbox transfer object running, transfer not complete
- 2 — Transfer successfully executed
- 3 — Error occurred during transfer request

**Error** — Report an EtherCAT network error

0 | integer

If no error occurs, this port transmits 0. Otherwise, it transmits a nonzero value. For list of error codes, see “EtherCAT Error Codes” on page 6-33.

## Parameters

**IDN** — Identification Number  
character vector

Identify parameters.

The documentation for your EtherCAT device specifies the **IDN** values. You can select the **IDN** as a character vector that represents a 16-bit integer (according to IEC 61800 -7 -204), such as S-0-0150 or P-0-0150 with:

- First field (bit 15): S for Standard data, P for product-specific data
- Second field (bit 14 - 12): 0..7 for parameter set
- Third field (bit 11 - 0): 0..4095 for data-block number

**Programmatic Use**  
**Block Parameter:** idn

**Drive Number** — Index number of the drive  
integer

Specify the decimal index of the drive.

SoE blocks apply to only motor controllers. A single subordinate device can support one or more drive or motor channels. The drive number is the zero-based index of the drive or motor channel on this subordinate device at which this block is aimed. In SoE terminology, the drive is the logic that sends control signals to the motor. Typically, this logic is a small processor inside the subordinate device.

**Programmatic Use**  
**Block Parameter:** drive

**Data Type** — Data type of the IDN  
double (default) | single | int8 | uint8 | int16 | uint16 | int32 | uint32 | boolean

To identify the data type for the IDN, refer to the subordinate device documentation for the description of the IDN and the data type it uses. From the list, select the data type of the **IDN**.

If you select a data type that does not match the type of the entry, the block returns a nonzero value through the Error output.

**Programmatic Use**  
**Block Parameter:** sig\_type

**Dimension** — Dimension of data for this IDN  
1 (default)

Specify the row dimension of data for this IDN.

To identify the dimension of data (vector size) for the IDN, refer to the subordinate device documentation for the description of the IDN and the number of data type values (the dimension) it uses. Enter the vector length as found in the SoE description for the subordinate device in its manual.

**Programmatic Use**  
**Block Parameter:** sig\_dim



**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use**

**Block Parameter:** device\_id

**SubDevice Name** — Name of device that contains the IDN

character vector

From the list, select the name of the device that contains the **IDN**.

The block populates this drop-down list with the contents of the configuration file.

**Programmatic Use**

**Block Parameter:** subdevice\_name

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use**

**Block Parameter:** sample\_time

**Timeout** — Time to wait for response from subordinate device

numeric

Enter the maximum number of milliseconds to wait for a response from the EtherCAT subordinate device.

**Programmatic Use**

**Block Parameter:** timeout

## Version History

Introduced in R2020b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

EtherCAT Init | EtherCAT Async SSC/SoE Download

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)  
[www.acontis.com/en/](http://www.acontis.com/en/)

# EtherCAT Async SSC/SoE Download

Transmit data asynchronously to subordinate device represented by service data object



## Libraries:

Simulink Real-Time / EtherCAT

## Description

The EtherCAT Async SSC/SoE Download block provides asynchronous SERCOS interface (Serial Real time COmmunication Specification) over EtherCAT (SoE) download. The block selects an **IDN** in the specified subordinate device and sends a download (write) request. After sending the request, the block immediately continues processing its input data.

## Ports

### Input

**Data** — Data to write to subordinate device  
numeric

Input data for writing to the EtherCAT subordinate device. The data signal has the type specified in **Data Type** and vector dimension given by **Dimension**.

**Enable** — Enables block to download data  
int32

The Enable input is level sensitive and the block remains enabled while the input is non-zero. To send a value just once, you can enable the block with a single sample time pulse. There is a lag of approximately three cycles after the pulse for the data to send.

A value 0 disables downloads. A value greater than or equal to 1 enables the block to download data.

### Output

**Status** — Status of data transfer  
0 | 1 | 2 | 3

Status of asynchronous data transfer:

- 0 — Mailbox transfer object idle, transfer not running
- 1 — Mailbox transfer object running, transfer not complete
- 2 — Transfer successfully executed
- 3 — Error occurred during transfer request

**Error** — Report an EtherCAT network error  
0 | integer

If no error occurs, this port transmits 0. Otherwise, it transmits a nonzero value. For list of error codes, see “EtherCAT Error Codes” on page 6-33.

## Parameters

**IDN** — Identification Number  
character vector

Identify parameters.

The documentation for your EtherCAT device specifies the **IDN** values. You can select the **IDN** as a character vector that represents a 16-bit integer (according to IEC 61800 -7 -204), such as S-0-0150 or P-0-0150 with:

- First field (bit 15): S for Standard data, P for product-specific data
- Second field (bit 14 - 12): 0..7 for parameter set
- Third field (bit 11 - 0): 0..4095 for data-block number

**Programmatic Use**  
**Block Parameter:** idn

**Drive Number** — Index number of the drive  
integer

Specify the decimal index of the drive.

SoE blocks apply to only motor controllers. A single subordinate device can support one or more drive or motor channels. The drive number is the zero-based index of the drive or motor channel on this subordinate device at which this block is aimed. In SoE terminology, the drive is the logic that sends control signals to the motor. Typically, this logic is a small processor inside the subordinate device.

**Programmatic Use**  
**Block Parameter:** drive

**Data Type** — Data type of the IDN  
double (default) | single | int8 | uint8 | int16 | uint16 | int32 | uint32 | boolean

To identify the data type for the IDN, refer to the subordinate device documentation for the description of the IDN and the data type it uses. From the list, select the data type of the **IDN**.

If you select a data type that does not match the type of the entry, the block returns a nonzero value through the Error output.

**Programmatic Use**  
**Block Parameter:** sig\_type

**Dimension** — Dimension of data for this IDN  
1 (default)

Specify the row dimension of data for this IDN.

To identify the dimension of data (vector size) for the IDN, refer to the subordinate device documentation for the description of the IDN and the number of data type values (the dimension) it uses. Enter the vector length as found in the SoE description for the subordinate device in its manual.

**Programmatic Use**  
**Block Parameter:** sig\_dim

**Network Device Index** — EtherCAT network identifier

0 (default) | 0-11

To associate a block with an EtherCAT network, enter the **Network Device Index** value from the EtherCAT Init block representing that network into the **Network Device Index** for the block.

**Programmatic Use**

**Block Parameter:** device\_id

**SubDevice Name** — Name of device that contains the IDN

character vector

From the list, select the name of the device that contains the **IDN**.

The block populates this drop-down list with the contents of the configuration file.

**Programmatic Use**

**Block Parameter:** subdevice\_name

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use**

**Block Parameter:** sample\_time

**Timeout** — Time to wait for response from subordinate device

numeric

Enter the maximum number of milliseconds to wait for a response from the EtherCAT subordinate device.

**Programmatic Use**

**Block Parameter:** timeout

## Version History

Introduced in R2020b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

EtherCAT Init | EtherCAT Async SSC/SoE Upload

**Topics**

“EtherCAT Configurator Component Mapping” on page 6-30

“EtherCAT Data Types” on page 6-31

**External Websites**

[www.ethercat.org](http://www.ethercat.org)

[www.beckhoff.com](http://www.beckhoff.com)  
[www.acontis.com/en/](http://www.acontis.com/en/)

# **IP Internet Protocol Blocks Library**





# **Real-Time TCP Communication Support**

---

## TCP Transport Protocol

The Simulink Real-Time software supports communication from the target computer to other systems or devices by using Transmission Control Protocol (TCP). TCP provides ordered and error-checked packet transport.

TCP is a transport protocol layered on top of the Internet Protocol (IP). It is commonly known as TCP/IP.

- Stream — TCP is a *stream-oriented* protocol.

TCP is a stream of data that flows from one end of the network to the other. Another stream of data flows in the other direction. The TCP stack at the transmitting end is responsible for breaking the stream of data into packets and sending those packets. The stack at the receiving end is responsible for reassembling the packets into a data stream by using information in the packet headers.

- Connection — TCP is a *connection-based* protocol.

In TCP, the two ends of the communication link must be connected throughout the communication.

- Error Detection — TCP detects errors.

TCP packets contain a unique sequence number. The starting sequence number is communicated from the transmitter to the receiver at the beginning of communication. The receiver acknowledges each packet. That acknowledgment contains the sequence number so that the sender knows which packet was acknowledged. Lost packets can be retransmitted. The sender knows that they did not reach their destination because the sender did not receive an acknowledgment. The receiver can reassemble in order packets that arrive out of sequence. Timeouts can be established because the sender knows from the first few packets how long it takes to transmit a packet and receive its acknowledgment.

TCP communication requires a continuous connection and two-way streaming data is exchanged.

When describing TCP, the words *reliable* and *unreliable* have a specific meaning.

- *Reliable* means that if a packet is not acknowledged, it is retransmitted. It does not mean that the protocol always succeeds.
- *Unreliable* means that if too many packets are not acknowledged, the protocol can time out. It does not mean that the protocol packets usually fail to arrive.

You can construct a packet from Simulink data types such as `double`, `int8`, `int32`, `uint8`, or a combination of these data types. The Simulink Real-Time block library provides blocks for combining various signals into one packet (packing), and then transmitting it. It also provides blocks for splitting a packet (unpacking) into its component signals that you can then use in a Simulink model.

This information applies to both communication with a shared Ethernet board and communication with a dedicated Ethernet board. Consider adding a dedicated Ethernet board for enhanced performance over communication that uses a shared Ethernet board. Shared TCP communication shares bandwidth with the link between the development and target computers.

### See Also

TCP Receive | TCP Send | TCP Client | TCP Server

## External Websites

- [www.ietf.org/rfc/rfc793.txt](http://www.ietf.org/rfc/rfc793.txt)




# TCP Blocks

---

## TCP Client

Configure TCP client



**Libraries:**  
Simulink Real-Time / IP

### Description

The TCP Client block configures a TCP client.

The parameters **Client IP address** and **Client port** are optional. The **Client IP address** applies when the block executes in a real-time application on a target computer or in a model simulation on a development computer. If your model is running in Simulink on the development computer, you can use this block to transmit data to a remote device. In this case, the Windows<sup>®</sup> operating system determines the network connection.

### Ports

#### Input

**Enable** — Connect block to remote Ethernet device  
integer

If **Enable** is greater than zero, the block connects to the Ethernet device. Otherwise, the block does not connect to the Ethernet device.

#### Output

**Status** — Device returns a status of not connected or connected  
0 | 1

The status value is one of:

- 0 — Not connected
- 1 — Connected

As a best practice, connect the **Status** output of a TCP configure block to the **Enable** input of the associated TCP Send and TCP Receive blocks.

### Parameters

**Use host-target connection** — Use Ethernet connection between development and target computers  
'off' (default) | 'on'

**Dependency**

When you select this parameter, it deactivates the **Client IP address** parameter and excludes the ports 1 through 1023 and 5500 through 5560 from use by TCP.

**Programmatic Use**

**Block Parameter:** useHostTargetConn

**Remote server IP address** — IP address of the server device

x.x.x.x

Enter the IP address of the server to which you want to connect the client.

**Programmatic Use**

**Block Parameter:** remoteAddress

**Remote server port** — Port number of the server device

1–65535

Enter the port number of the server to which you want to connect the client.

Ports 1 through 1023 and 5500 through 5560 are reserved for Simulink Real-Time communications.

**Programmatic Use**

**Block Parameter:** remotePort

**Advanced Parameters**

**Client IP address** — IP address of the client device that is being configured

no value (default) | x.x.x.x

If you are using a dedicated Ethernet card, this value must match the **Local IP Address** parameter in the IP Config block for the network interface. The default value for the Client IP address field is no value. This empty field means that the operating system chooses the Client IP address for TCP transmission.

**Programmatic Use**

**Block Parameter:** clientAddress

**Client local port** — IP port of the client device that is being configured

no value (default) | 0–65535

The combination of **Client IP address** and **Client local port** must be unique.

Ports 1 through 1023 and 5500 through 5560 are reserved for Simulink Real-Time communications. Values '-1', '0', or 'empty' mean that the block transmits data by using any available port.

**Programmatic Use**

**Block Parameter:** clientPort

**Version History**

Introduced in R2020b

**R2021b: Changed Parameters Client IP Address and Client Port**

The parameters for the TCP Client block have changed. The parameters **Client IP address** and **Client port** are optional.

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

### **See Also**

TCP Server


### **External Websites**

[www.ietf.org/rfc/rfc793.txt](http://www.ietf.org/rfc/rfc793.txt)



# TCP Receive

Receive data over TCP network from a remote device



**Libraries:**  
Simulink Real-Time / IP

## Description

The TCP Receive block receives data sent from a remote client device to a server application on a target computer.

## Ports

### Input

**Enable** — Allow data reception  
integer

When `Enable > 0`, the block attempts to receive data sent to the remote device.

As a best practice, connect the `Status` output of a TCP configure block to the `Enable` input of the associated TCP Send and TCP Receive blocks.

### Output

**Data** — Data that is received from the remote client  
vector

The parameter **Receive width** determines the maximum size of the data vector.

Data Types: `uint8`

**Length** — Actual size of data vector  
double

To test whether the number of data items exceeds the width of the data output port, use this value.

## Parameters

**Receive using** — List of IP address and port pairs  
`x.x.x.x:y`

This parameter is read-only.

The block receives the list of IP address and port pairs from the TCP configuration blocks in the model.

Ports 1 through 1023 and 5500 through 5560 are reserved for Simulink Real-Time communications.

**Programmatic Use**

**Block Parameter:** socketAddPort

**Receive width** — Maximum expected length of data vector  
1–65504

Maximum number of uint8 values that the block expects to receive from the client device.

**Programmatic Use**

**Block Parameter:** rcvWidth

**Sample time** — Sample time of block  
-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that the sample time is inherited.

**Programmatic Use**

**Block Parameter:** sampleTime

## Version History

Introduced in R2020b

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also

TCP Client | TCP Server

### External Websites

[www.ietf.org/rfc/rfc793.txt](http://www.ietf.org/rfc/rfc793.txt)

# TCP Send

Send data over TCP network to a remote device



**Libraries:**  
Simulink Real-Time / IP

## Description

The TCP Send block sends data from a server application on a target computer to a remote client device.

## Ports

### Input

**Enable** — Allow data transmission  
integer

When `Enable > 0`, the block attempts to transmit data to the remote device.

As a best practice, connect the `Status` output of a TCP configure block to the `Enable` input of the associated TCP Send and TCP Receive blocks.

**Data** — Data to transmit over the TCP network  
vector

Vector of `Length` to transmit to the client device.

Data Types: `uint8`

**Length** — Length of data vector  
double

Number of `uint8` values to transmit to the client device.

### Output

**Status** — Number of bytes sent  
double

Returns the number of `uint8` values transmitted to the client device.

## Parameters

**Send using** — List of IP address and port pairs  
`x.x.x.x:y`

This parameter is read-only.

The block receives the list of IP address and port pairs from the TCP configuration blocks in the model.

Ports 1 through 1023 and 5500 through 5560 are reserved for Simulink Real-Time communications.

**Programmatic Use****Block Parameter:** `socketAddPort`**Sample time** — Sample time of block`-1` (default) | numeric

Enter the base sample time or a multiple of the base sample time. `-1` means that the sample time is inherited.

**Programmatic Use****Block Parameter:** `sampleTime`

## Version History

**Introduced in R2020b**

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**


TCP Client | TCP Server

**External Websites**

[www.ietf.org/rfc/rfc793.txt](http://www.ietf.org/rfc/rfc793.txt)

# TCP Server

Configure TCP server



**Libraries:**  
Simulink Real-Time / IP

## Description

The TCP Server block configures a TCP server.

## Ports

### Input

**Enable** — Connect block to remote Ethernet device  
integer

If **Enable** is greater than zero, the block connects to the Ethernet device. Otherwise, the block does not connect to the Ethernet device.

### Output

**Status** — Device returns a status of not connected or connected  
0 | 1

The status value is one of:

- 0 — Not connected
- 1 — Connected

As a best practice, connect the **Status** output of a TCP configure block to the **Enable** input of the associated TCP Send and TCP Receive blocks.

## Parameters

**Use host-target connection** — Use Ethernet connection between development and target computers  
'off' (default) | 'on'

### Dependency

When you select this parameter, it deactivates the **Server IP address** parameter and excludes the ports 1 through 1023 and 5500 through 5560 from use by TCP.

### Programmatic Use

**Block Parameter:** useHostTargetConn

**Server IP address** — IP address of the server device that is being configured  
x.x.x.x

If you are using a dedicated Ethernet card, this value must match the IP address configured for the Ethernet card on the target computer.

**Programmatic Use**

**Block Parameter:** serverAddress

**Server port** — IP port of the server device that is being configured  
1–65535

The combination of **Server IP address** and **Server port** must be unique.

Ports 1 through 1023 and 5500 through 5560 are reserved for Simulink Real-Time communications.

**Programmatic Use**

**Block Parameter:** serverPort

## Version History

Introduced in R2020b

### See Also

TCP Client

### External Websites

[www.ietf.org/rfc/rfc793.txt](http://www.ietf.org/rfc/rfc793.txt)

# Real-Time UDP Communication Support

---

- “UDP Transport Protocol” on page 10-2
- “UDP Data Exchange by Using Shared Ethernet Board” on page 10-4
- “UDP Communication Setup” on page 10-9
- “UDP and Variable-Size Signals” on page 10-10

## UDP Transport Protocol

The Simulink Real-Time software supports communication from the target computer to other systems or devices by using User Datagram Protocol (UDP) packets. UDP is a transport protocol that provides a direct method to send and receive packets over an IP network. UDP uses this direct method at the expense of reliability by limiting error checking and recovery.

UDP is a transport protocol layered on top of the Internet Protocol (IP). It is commonly known as UDP/IP.

- **Packet** — UDP is a *packet-oriented* protocol. You divide the data into packets and the protocol sends them to the receiver.
- **Connectionless** — UDP is a *connectionless* protocol. The protocol sends a packet to the receiver without checking to see if the receiver is ready to receive a packet. If the receiver is not ready, the packet is lost.
- **No Error Detection**— UDP does not support error detection. The protocol sends packets and does not track them. If packets arrive out of sequence, or are lost in transmission, the receiving end or the sending end does not know.

UDP communication requires that the sender identifies the receiver. If the receiver is not found or the communication is lost in transit, the packet is discarded.

When describing UDP, the words *reliable* and *unreliable* have a specific meaning.

- *Reliable* means that the protocol is not guaranteed to succeed. It does not mean that the protocol always succeeds.
- *Unreliable* means that protocol packets can fail to arrive without the system detecting that the packets did not arrive. It does not mean that the protocol packets usually fail to arrive.

UDP continues to receive packets while the receiver is active and processes data as quickly as it arrives.

UDP is a commonly used transport layer because of its lightweight nature. When used from Simulink Real-Time, UDP gives the real-time application a good chance of succeeding in real-time execution. Also, the datagram nature of UDP is optimal for sending samples of data from the real-time application generated by the Simulink Coder software. If the real-time application cannot process the data as quickly as it arrives, only the most recent packet is used. The earlier packets are ignored.

You can construct a packet from Simulink data types such as `double`, `int8`, `int32`, `uint8`, or a combination of these data types. The Simulink Real-Time block library provides blocks for combining various signals into one packet (packing), and then transmitting it. It also provides blocks for splitting a packet (unpacking) into its component signals that you can then use in a Simulink model.

The preceding information applies to communication with a shared Ethernet board and communication with a dedicated Ethernet board. Consider adding a dedicated Ethernet board for enhanced performance over communication by using a shared Ethernet board. Shared UDP communication shares bandwidth with the link between the development and target computers.

### See Also

UDP Send | UDP Receive



**Related Examples**

- “Target to Host Transmission by Using UDP”

**More About**

- “UDP Communication Setup” on page 10-9
- “UDP and Variable-Size Signals” on page 10-10

## UDP Data Exchange by Using Shared Ethernet Board

### In this section...

“UDP Data Transfer” on page 10-4

“Set Up `slrt_ex_udpsendreceiveA`” on page 10-5

“Set Up `slrt_ex_udpsendreceiveB`” on page 10-6

This example shows how to set up two-way data exchange by using an Ethernet board that is shared with the connection between the development and target computers. Using this configuration, you can communicate between two Simulink Real-Time systems, between the Simulink Real-Time and Simulink products, or between two Simulink models. When one or both of the systems are running as a non-real-time Simulink model, be sure to set the sample time.

This example does not require configuring a dedicated Ethernet card because the example uses the connection between the development and target computers.

The example models are named `slrt_ex_udpsendreceiveA` and `slrt_ex_udpsendreceiveB`. Replace the port and IP address examples with ports and addresses as required by your network. This example uses a target computer located at IP address `192.168.7.5` and uses a development computer located at IP address `192.168.7.2`.

### UDP Data Transfer

The models transfer two different data sets between them, one data set from `slrt_ex_udpsendreceiveA` to `slrt_ex_udpsendreceiveB` and another data set in the opposite direction.

For this example, the inputs are generated by using Simulink Constant blocks that use the MATLAB random number function (`rand`). The Simulink Coder software uses this function during code generation to generate random numbers. To generate the vector of `uint8` (3x3), use the MATLAB function:

```
uint8(255 * rand(3,3))
```

because 255 is the maximum value for an unsigned 8-bit integer. The other values are generated similarly.

#### `slrt_ex_udpsendreceiveA` to `slrt_ex_udpsendreceiveB`

The UDP data to send is 75 bytes wide. The data to transfer is in these formats:

- [3 3] of `uint8` (9 bytes)
- [1 1] of `uint16` (2 bytes)
- [2 4] of `double` (64 bytes)

When packed, the data is aligned on 1-byte boundaries.

#### `slrt_ex_udpsendreceiveB` to `slrt_ex_udpsendreceiveA`

The UDP data to be sent is 79 bytes wide. The data to transfer is in these formats:


- [4 1] of single (16 bytes)
- [2 2] of double (32 bytes)
- [2 2] of uint32 (16 bytes)
- [5 3] of int8 (15 bytes)

When packed, the data is aligned on 2-byte boundaries. A zero-valued pad byte is added during packing.

## Set Up slrt\_ex\_udpsendreceiveA

The final `slrt_ex_udpsendreceiveA` is shown in the figure.

The tables list the parameters for the send and receive sides of the model.



### slrt\_ex\_udpsendreceiveA Send Side

Block	Parameter	Value
Byte Packing	<b>Output port (packed) data type</b>	'uint8'
	<b>Input port (unpacked) data types (cell array)</b>	{'uint8', 'uint16', 'double'}
	<b>Byte alignment</b>	1
UDP Send	<b>Local IP address</b>	Use host-target connection

Block	Parameter	Value
	<b>Local port</b>	-1 (autoselect)
	<b>To IP address</b>	192.168.7.5
	<b>To port</b>	25000
	<b>Sample time (-1 for inherited)</b>	0.01

- The Length input port receives the output of a Width block that calculates the width of the signal connected to the Data port.
- The Byte Packing block settings match the Byte Unpacking block of `slrt_ex_udpsendreceiveB`.

### slrt\_ex\_udpsendreceiveA Receive Side


Block	Parameter	Value
UDP Receive	<b>Local IP address</b>	Use host-target connection
	<b>Local port</b>	25000
	<b>Receive width</b>	80
	<b>Receive from any source</b>	off
	<b>From IP address</b>	192.168.7.2
	<b>Sample time (-1 for inherited)</b>	0.01
Byte Unpacking	<b>Output port (unpacked) data types (cell array)</b>	{'single', 'double', 'uint32', 'int8'}
	<b>Output port (unpacked) dimensions (cell array)</b>	{4, [2 2], [2 2], [5 3]}
	<b>Byte alignment</b>	2

- The second output port of the UDP Receive block is sent into a terminator. You can use this output to determine when a packet has arrived. The same is true for the outputs of the Byte Unpack block.
- The **Receive width** of the UDP Receive block matches the output port width of the Byte Packing block in `slrt_ex_udpsendreceiveB`.
- The Byte Unpacking block settings match the settings of the Byte Packing block of `slrt_ex_udpsendreceiveB`.
- The number of unpacked bytes is 79. The byte alignment is 2. The Byte Unpacking block assumes that the input vector includes a pad 0 to align the vector on an even-numbered boundary.

### Set Up slrt\_ex\_udpsendreceiveB

The final `slrt_ex_udpsendreceiveB` model is shown in the figure.

The tables list the parameters for the receive side and the send side of the model.



### slrt\_ex\_udpsendreceiveB Receive Side

Block	Parameter	Value
UDP Receive	Local IP address	Use host-target connection
	Local port	25000
	Receive width	75
	Receive from any source	off
	From IP address	192.168.7.5
	Sample time (-1 for inherited)	0.01
Byte Unpacking	Output port (unpacked) data types (cell array)	{'uint8', 'uint16', 'double'}
	Output port (unpacked) dimensions (cell array)	{[3 3], 1, [2 4]}
	Byte alignment	1

- The second output port of the UDP Receive block is sent into a terminator. You can use this output to determine when a packet has arrived. The same is true for the outputs of the Byte Unpack block.
- The **Receive width** of the UDP Receive block matches the output port width of the Byte Packing block in `slrt_ex_udpsendreceiveA`.
- The Byte Unpacking block settings match the Byte Packing block in `slrt_ex_udpsendreceiveA`.

**slrt\_ex\_udpsendreceiveB Send Side**

Block	Parameter	Value
Byte Packing	<b>Output port (packed) data type</b>	'uint8'
	<b>Input port (unpacked) data types (cell array)</b>	{'single', 'double', 'uint32', 'int8'}
	<b>Byte alignment</b>	2
UDP Send	<b>Local IP address</b>	Use host-target connection
	<b>Local port</b>	-1 (autoselect)
	<b>To IP address</b>	192.168.7.2
	<b>To port</b>	25000
	<b>Sample time (-1 for inherited)</b>	0.01

- The Length input port receives the output of a Width block that calculates the width of the signal connected to the Data port.
- The Byte Packing block settings match the settings of the Byte Unpacking block of `slrt_ex_udpsendreceiveA`.
- The number of unpacked bytes is 79. The byte alignment is 2. The Byte Packing block pads the output vector with 0 to align on an even-numbered boundary.

**See Also**

UDP Send | UDP Receive

**Related Examples**

- “Target to Host Transmission by Using UDP”

**More About**

- “UDP Transport Protocol” on page 10-2
- “UDP Communication Setup” on page 10-9
- “UDP and Variable-Size Signals” on page 10-10

## UDP Communication Setup

The infrastructure provided in the Simulink Real-Time Library for UDP communication consists of two blocks: a UDP Send block and a UDP Receive block. These blocks are in the Simulink Real-Time Library, available from the Simulink Library under **Simulink Real-Time**. You can also access them from the MATLAB command line by typing:

```
slrealtimelib
```

The blocks are located under the IP heading in the library. The UDP Send block takes as input a vector of type `uint8`. The UDP Receive block outputs a vector of `uint8`. To convert arbitrary Simulink data types into this vector of `uint8`, use a Byte Packing block. To convert a vector of `uint8`s back into arbitrary Simulink data types, use a Byte Unpacking block.

If you are using a dedicated Ethernet port for UDP communication, use the Speedgoat Ethernet Configuration utility to configure the dedicated Ethernet board. For more information, see “Troubleshoot Model Upgrade for R2020b”.

To communicate with *big-endian* architecture systems, use the Byte Reversal/Change Endianness block. Your model does not need this block for communicating between 80x86-based computer systems running either the Simulink Real-Time RTOS or the Microsoft Windows operating system.

The blocks work from within the Simulink environment and from a real-time application running under the Simulink Real-Time system. Be careful about transmitting data between a Simulink simulation and a real-time application or using two Simulink models. A Simulink model is not a real-time model and can run several times faster or slower than a real-time application. Set the sample time of the UDP Send and UDP Receive blocks and the sample time of the Simulink model so that the blocks can communicate.

- You cannot configure two UDP Receive blocks with the same local port. For example, two UDP Receive blocks cannot have the same local port and different IP addresses.
- You cannot configure two UDP Send blocks with the same local port. For example, two UDP Send blocks cannot have the same local port and different IP addresses.

### See Also

UDP Send | UDP Receive

### Related Examples

- “Target to Host Transmission by Using UDP”

### More About

- “UDP Transport Protocol” on page 10-2

## UDP and Variable-Size Signals

The Simulink Real-Time UDP sublibrary does not directly support variable-size signals. The UDP Send block input port accepts only fixed-size signals.


To send variable-size signals through UDP, determine the maximum number of elements of a fixed-size input signal that you expect to connect to the block. Use the second input, `Length`, to specify the number of elements of this input signal to send through UDP.

This example configures the MATLAB Function block to accept a variable-size signal and maps that signal to a fixed-size output signal. It outputs the number of relevant elements. You can output the fixed-size output signal and number of elements to the inputs of the UDP Send block.

- 1 To accept a variable-size input signal, create a MATLAB Function block. MATLAB Function block inputs inherit their size, which can be variable-size.
- 2 In the MATLAB Function block, enter code like the following code. In this code, the maximum size of the variable-size input signal is 9.

```
function [y,y_length] = fcn(u)
%#codegen
y = uint8(zeros(9,1));
y_length = length(u);
for a = 1:y_length
    y(a) = u(a);
end
```

- 3 Specify the maximum size of the output `y`.
  - a Open the **Symbols** pane. In the **Modeling** tab, in the **Design** section, click **Symbols Pane**.
  - b Right-click the variable `y` and click **Inspect** to open the Property Inspector.
  - c Enter the maximum size of the input signal into the corresponding **Size** property for `y`. For this example, the size value is 9.
- 4 Provide a variable-size signal source to the MATLAB Function block.





**See Also**

UDP Send | MATLAB Function




# Real-Time UDP Blocks

---

## UDP Multicast Receive

Receive data over UDP network from a remote device



**Libraries:**  
Simulink Real-Time / IP

### Description

The UDP Multicast Receive block receives multicast data over a UDP network from a remote device. It can receive data by using the connection between the development and target computers or by using a dedicated Ethernet card. If you use a dedicated Ethernet card, use the Speedgoat configuration utility to configure the dedicated Ethernet board.

The UDP Multicast Receive block operates in a real-time application running on a target computer. The block does not operate in a model simulation on a development computer.

A maximum of 20 multicast groups can be joined. This number is determined as a product of the group address and group interface fields on the block mask.

### Examples

#### Setup for One Multicast Group Address

This example sets the block parameters for bind address to 0.0.0.0, a single group, and a single interface from which to receive multicast messages.

```
% for myModel, set UDP mcast rcv parameters for on group
set_param('myModel/UDP Multicast Receive',...
    'bindAddress','0.0.0.0',...
    'localPort','25000',...
    'rcvWidth','80',...
    'multicastAddress',{'225.11.11.11'},...
    'multicastInterface',{'192.168.7.5'})
```

#### Setup to Join Three Multicast Group Addresses and Two Interfaces

This example sets the block parameters for bind address to 0.0.0.0, three groups, and two interfaces from which to receive multicast messages. The block joins groups 225.11.11.11, 225.11.11.12, and 225.11.11.13 on the group interfaces 192.168.7.5 and 192.168.7.10. The block receives multicast messages for all those groups coming from any of those interfaces.

```
% for myModel, set UDP mcast rcv parameters for on group
set_param('myModel/UDP Multicast Receive',...
    'bindAddress','0.0.0.0',...
    'localPort','1',...
    'rcvWidth','16',...
    'multicastAddress',{'225.11.11.11','225.11.11.12','225.11.11.13'},...
    'multicastInterface',{'192.168.7.5','192.168.7.10'})
```

```
'multicastAddress', '{'225.11.11.11', '225.11.11.12', '225.11.11.13'}', ...
'multicastInterface', {'192.168.7.5', '192.168.7.10'}')
```

### Setup for Three Multicast Group Addresses and Two Interfaces

This example sets the block parameters for bind address to 0.0.0.0, three groups, and two interfaces from which to receive multicast messages. These settings specify multiple groups to subscribe to and the interface for receiving the multicast messages in the same order. There is a one to one mapping of group address and group interface.

```
% for myModel, set UDP mcast rcv parameters for on group
set_param('myModel/UDP Multicast Receive', ...
    'bindAddress', '0.0.0.0', ...
    'localPort', '25000', ...
    'rcvWidth', '80', ...
    'multicastAddress', '{'225.11.11.11', '225.11.11.12', '225.11.11.13'}', ...
    'multicastInterface', {'192.168.7.5', '192.168.7.5', '192.168.7.10'})
```

### Setup for Two Multicast Group Addresses and Three Interfaces

This example sets the block parameters for bind address to 0.0.0.0, three groups, and two interfaces from which to receive multicast messages. These settings specify multiple groups to subscribe to and the interface for receiving the multicast messages across all groups. The multicast groups receive messages from all the interfaces specified.

```
% for myModel, set UDP mcast rcv parameters for on group
set_param('myModel/UDP Multicast Receive', ...
    'bindAddress', '0.0.0.0', ...
    'localPort', '25000', ...
    'rcvWidth', '80', ...
    'multicastAddress', '{'225.11.11.11', '225.11.11.12'}', ...
    'multicastInterface', {'192.168.7.5', '192.168.7.10', '192.168.7.15'})
```

## Ports

### Output

**Data** — Data received

vector

Vector of uint8 containing data received over the UDP network. If no new packet is received, the data values are held. To determine whether a new packet has been received, use the **Length** output port.

Data Types: uint8

**Length** — Number of bytes received

double

Number of bytes in the new packet received, otherwise 0. If more bytes are received than can be output through the receive port with width defined by **Receive width**, the excess bytes are discarded.

## Parameters

### General Parameters

**Bind address** — Bind IP address for receiving multicast data  
0.0.0.0 (default)

The **Bind address** can be either 0.0.0.0 or a multicast address. When **Bind address** is set to 0.0.0.0, the block binds to INADDR\_ANY, which enables the socket to receive datagrams on all interfaces. This specification enables the **Group address** field on the block mask. When **Bind address** is set to a multicast IP address, the **Group address** field is hidden on the block mask.

If the **Bind address** is set to 0.0.0.0, the block also can receive unicast messages if the block is configured on a group interface over which unicast messages are sent. This unicast message receive occurs because address 0.0.0.0 allows listening to any messages on all interfaces of the target computer. To avoid this unicast message receive operation, use a multicast address as a bind address. Using that setup, the block only receives multicast messages and does not receive unicast messages.

#### Programmatic Use

**Block Parameter:** bindAddress

**Local port** — Destination UDP port to receive data  
1–65535

Specifies UDP port to receive data.

Ports 1 through 1023 and 5500 through 5560 are reserved for Simulink Real-Time communications.

#### Programmatic Use

**Block Parameter:** localPort

**Receive width** — Width of Data output vector  
16 (default) | 1–65504

Determines the width of the Data output vector. If this value is less than the number of bytes in the received packet, the excess bytes are discarded.

#### Programmatic Use

**Block Parameter:** rcvWidth

**Group address** — Multicast group to join  
{ } (default) | { 'x.x.x.x' } | dotted decimal character vector

This field is hidden when the bind address is a multicast address. Enter a valid IP address as a dotted decimal character vector, for example, { '224.0.0.0' }. One or more group addresses can be specified.

The UDP Multicast Receive block issues an error at model update if the group IP address is not a valid multicast address in the range 224.0.0.0 through 239.255.255.255.

Example: { '224.100.1.1' }

Example: { '224.100.1.1', '224.100.1.2' }

#### Programmatic Use

**Block Parameter:** multicastAddress

**Group interface** — Local IP interface from which to receive data  
 {} (default) | {'x.x.x.x'} | dotted decimal character vector

The **Group interface** IP address specifies the interfaces over which incoming multicast messages should be received. When the bind address is `0.0.0.0`, the multicast groups specified in the field **Group address** receive messages over the specified group interface or interfaces. When the bind address is a multicast address, that address receives messages over the specified group interface or interfaces. Enter a valid interface IP address as a dotted decimal character vector, for example, `'192.168.7.5'`. You can also use a MATLAB expression that returns a valid IP address as a character vector. One or more group interfaces can be specified.

Example: `'192.168.7.5'`

Example: `'192.168.7.5', '192.168.7.10'`

**Programmatic Use**

**Block Parameter:** `multicastInterface`

**Sample time (-1 for inherited)** — Sample time of block  
 -1 (default) | numeric

Enter the base sample time or a multiple of the base sample time.

**Programmatic Use**

**Block Parameter:** `sampleTime`

## Version History

Introduced in R2021a

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also


UDP Receive | UDP Send

## Topics

“UDP Transport Protocol” on page 10-2

## UDP Receive

Receive data over UDP network from a remote device



**Libraries:**  
Simulink Real-Time / IP

### Description

The UDP Receive block receives data over a UDP network from a remote device. It can receive data by using the connection between the development and target computers or by using a dedicated Ethernet card. If you use a dedicated Ethernet card, use the Speedgoat configuration utility to configure the dedicated Ethernet board.

The parameter **Local IP address** applies when the block executes in a real-time application on a target computer or in a model simulation on a development computer. If your model is running in Simulink on the development computer, you can use this block to receive data to a remote device. In this case, the Windows operating system determines the network connection.

### Ports

#### Output

**Data** — Data received  
vector

Vector of `uint8` containing data received over the UDP network. If no new packet is received, the data values are held. To determine whether a new packet has been received, use the **Length** output port. If you enable the **Enable Simulink messages** parameter, the data type is `UDP_Packet`. This data type consists of:

- **IP\_Address**: DataType: `uint8`, Complexity: real, Dimensions: [4 1]
- **IP\_Port**: DataType: `uint16`, Complexity: real, Dimensions: 1
- **Length**: DataType: `uint16`, Complexity: real, Dimensions: 1
- **Data**: DataType: `uint8`, Complexity: real, Dimensions: [75 1]

Data Types: `uint8` | `UDP_Packet`

**Length** — Number of bytes received  
double

This port is available when you disable the **Enable Simulink messages** parameter. The Length is the number of bytes in the new packet received, otherwise 0. If more bytes are received than can be output through the receive port with width defined by **Data width**, the excess bytes are discarded.



## Parameters

### General Parameters

**Use host-target connection** — Use Ethernet connection between development and target computers

'off' (default) | 'on'

#### Dependency

When you select this parameter, it deactivates the **Local IP address** parameter and excludes the ports 1 through 1023 and 5500 through 5560 from use by UDP.

#### Programmatic Use

**Block Parameter:** useHostTargetConn

**Local IP address** — Destination IP address for receiving data

Use `host-target connection` (default)

When **Local IP address** is set to `Use host-target connection`, the block uses the connection between the development and target computers. Use `0.0.0.0` to bind to `INADDR_ANY`, which enables the socket to receive broadcast datagrams.

#### Programmatic Use

**Block Parameter:** ipAddress

**Local port** — Destination UDP port to receive data

1–65535

Specifies UDP port to receive data.

Ports 1 through 1023 and 5500 through 5560 are reserved for Simulink Real-Time communications.

#### Programmatic Use

**Block Parameter:** localPort

**Receive width** — Width of Data output vector

1–65504

Determines the width of the `Data` output vector. If this value is less than the number of bytes in the received packet, the excess bytes are discarded.

#### Programmatic Use

**Block Parameter:** rcvWidth

**Receive from any source** — Causes receiver to accept data from any IP address

on (default) | off

When **Receive from any source** is on, the block receives data from any accessible IP address. When it is off, the block receives data from only the address that you specify in **From IP address**.

To make the **From IP address** parameter visible, clear the **Receive from any source** check box.

#### Programmatic Use

**Block Parameter:** rcvFmAny

**From IP address** — Source from which to receive data

x.x.x.x

Enter a valid IP address as a dotted decimal character vector, for example, 192.168.7.2. You can also use a MATLAB expression that returns a valid IP address as a character vector.

The address 255.255.255.255 is an invalid IP address.

To make this parameter visible, clear the **Receive from any source** check box.

**Programmatic Use**

**Block Parameter:** fmAddress

**Sample time (-1 for inherited)** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time.

**Programmatic Use**

**Block Parameter:** sampleTime

**Enable Simulink messages** — Data as messages

off (default) | on

The Enable Simulink messages directs the block to treat data as messages. When enabled, the Length port is removed.

**Programmatic Use**

**Block Parameter:** MessageOut

## Version History

Introduced in R2020b

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also


UDP Multicast Receive | UDP Send

## Topics

“UDP Transport Protocol” on page 10-2

# UDP Send

Send data over UDP network to a remote device



**Libraries:**  
Simulink Real-Time / IP

## Description

The UDP Send block sends data over a UDP network to a remote device. The block can send data by using the connection between the development and target computers or by using a dedicated Ethernet card. If you use a dedicated Ethernet card, use the Speedgoat configuration utility to configure the dedicated Ethernet board. One of the settings provided by this utility is the **Default Gateway** setting. When using the UDP Send block to broadcast to 255.255.255.255, the IP interface for broadcast is based on this **Default Gateway** setting.

To broadcast to all devices on the local subnetwork, set **To IP address** to 255 . 255 . 255 . 255. Otherwise, set **To IP address** to a valid IP address.

For unicasting, broadcasting and multicasting, the parameters **Local IP address** and **Local port** are optional. The **Local IP address** applies when the block executes in a real-time application on a target computer or in a model simulation on a development computer. If your model is running in Simulink on the development computer, you can use this block to transmit data to a remote device. In this case, the Windows operating system determines the network connection.

## Ports

### Input

**Data** — Data to transmit  
vector

Vector of `uint8` containing data to transmit over the UDP network. To determine how many bytes of data to transmit, use the **Length** input port. If you enable the **Enable Simulink messages** parameter, the data type is `UDP_Packet`. Use the `slrealtime.createUDPPacketBusObj` function to create the `Simulink.Bus` type `Ethernet_Packet`. This data type consists of:

- **IP\_Address**: DataType: `uint8`, Complexity: real, Dimensions: [4 1]
- **IP\_Port**: DataType: `uint16`, Complexity: real, Dimensions: 1
- **Length**: DataType: `uint16`, Complexity: real, Dimensions: 1
- **Data**: DataType: `uint8`, Complexity: real, Dimensions: [75 1]

Data Types: `uint8` | `UDP_Packet`

**Length** — Number of bytes of data to transmit  
double

This port is available when you disable the **Enable Simulink messages** parameter. The Length determines the number of bytes of data to transmit. Specify the width of the **Data** vector as the maximum number of bytes that you expect to transmit.

## Parameters

**Use host-target connection** — Use Ethernet connection between development and target computers

'off' (default) | 'on'

### Dependency

When you select this parameter, it deactivates the **Local IP address** parameter and excludes the ports 1 through 1023 and 5500 through 5560 from use by UDP.

### Programmatic Use

**Block Parameter:** useHostTargetConn

**To IP address** — IP address of target device

10.10.10.10 (default) | x.x.x.x

Specifies IP address of target device. To broadcast to all devices on the local subnetwork, send to 255.255.255.255.

### Programmatic Use

**Block Parameter:** toAddress

**To port** — UDP port of target device

34 (default) | 1–65535

Specify the UDP port of target device. With **To IP address**, this parameter defines the destination of the data transmission.

### Programmatic Use

**Block Parameter:** toPort

**Sample time (-1 for inherited)** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time.

### Programmatic Use

**Block Parameter:** sampleTime

**Enable Simulink messages** — Data as messages

off (default) | on

The Enable Simulink messages directs the block to treat data as messages. When enabled, the Length port is removed.

### Programmatic Use

**Block Parameter:** MessageIn

## Advanced Parameters

**Local IP address** — Source IP address for sending data

no value (default) | x.x.x.x

When **Local IP address** is set to **Use host-target connection**, the block uses the connection between the development and target computers. When **To IP address** is specified as a multicast address, the local IP address is used to determine the outbound interface over which multicast datagrams are sent. The default value for the Local IP address field is no value. This empty field means that the operating system chooses the Local IP address for UDP transmission.

**Programmatic Use****Block Parameter:** ipAddress**Local port** — Source UDP port to transmit data

no value (default) | 0–65535 | -1

Specifies local UDP port to transmit data.

Ports 1 through 1023 and 5500 through 5560 are reserved for Simulink Real-Time communications.

The value 0, -1, or no value mean that the block transmits data by using any available port.

**Programmatic Use****Block Parameter:** localPort

## Version History

**Introduced in R2020b****R2021b: Changed Parameters Local IP Address and Local Port**

The parameters for the UDP Send block have changed. For unicasting, broadcasting, and multicasting, the parameters **Local IP address** and **Local port** are optional.

**R2021a: Added Multicast Support**

The UDP Multicast Receive block was added, and the UDP Send block has multicast support. These blocks provide multicast message support for the UDP communications protocol.

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

UDP Multicast Receive | UDP Receive | `slrealtime.createUDPPacketBusObj`**Topics**

"UDP Transport Protocol" on page 10-2



# Model-Based Ethernet Communications Support

---

## Apply 802.1Q VLAN Tag by Using Ethernet Send and Receive Blocks

This example shows how to use Ethernet blocks to send and receive Ethernet packets on a target computer.

On the development computer, a UDP Send block sends a sample packet. On the target computer, this packet is received by an Ethernet Receive block, individual bytes in the payload are manipulated, and the resulting payload is sent out of the target computer by an Ethernet Send block.


The Ethernet blocks work only on the target computer.

These blocks can work in the default signal input/output mode and a message input/output mode. Both modes are shown in this example.

### Set Up Ethernet Send-Receive Model

Open the target model `slrt_ex_ethernetSendReceive`.

```
mdl1 = 'slrt_ex_ethernetSendReceive';
open_system(fullfile(matlabroot, 'toolbox', 'slrealtime', 'examples', mdl1));
```



Copyright 2021-2022 The MathWorks, Inc.

The target model requires a valid `Interface Name` parameter value in the two Receive blocks and the two Send blocks. You can obtain this information on the target computer by using the QNX Neutrino RTOS `ifconfig` command.

This example uses interface name `wm0` for the target IP address `'192.168.7.5'`.

Enter the interface name `wm0` into the four blocks in the model:

```
targetIface = 'wm0';
set_param('slrt_ex_ethernetSendReceive/Ethernet Receive', 'InterfaceName', targetIface)
```



```
set_param('slrt_ex_ethernetSendReceive/Ethernet Receive1', 'InterfaceName', targetIface)
set_param('slrt_ex_ethernetSendReceive/Ethernet Send', 'InterfaceName', targetIface)
set_param('slrt_ex_ethernetSendReceive/Ethernet Send1', 'InterfaceName', targetIface)
```

### Operations in the Ethernet Send-Receive Real-Time Application

Every packet sent from the development computer to the target computer is received by each Ethernet Receive block on the target.

The two Receive and corresponding Send blocks demonstrate the operation in signal mode and message mode, where Simulink messages represent the packets.

In signal mode, 'slrt\_ex\_ethernetSendReceive/Subsystem ' uses Simulink blocks to add a 802.1Q VLAN tag 32 and send it back to the host at a port incremented by 1. If the original sender port was 8001, the loopback destination port is 8002.

In the messages mode, slrt\_ex\_ethernetSendReceive/MATLAB System Object receives the packets. For each packet it then creates three new packets with the VLAN tags 24, 25, and 26.

### Manipulating the Ethernet Header

For details about Ethernet header structure, refer to the standards document for IEEE 802.1Q.

For details about the IPv4 header, refer to RFC 791 for Internet Protocol <https://datatracker.ietf.org/doc/html/rfc791>

These changes to the header occur in the Subsystem and the System object:

- 1 Switch source and destination MAC address: Swap bytes 1-6 with bytes 7-12.
- 2 Switch source and destination IP Address: Swap bytes 27-30 with bytes 31-34.
- 3 Switch source and destination port numbers: Swap bytes 35-36 with bytes 37-38.
- 4 Increment the new destination port number by 1: Add 1 to the value of byte 38.
- 5 Disable checksum verification: Set bytes 41-42 to 0. Without this change, the packets that are sent back to the development computer would be discarded, since checksum value would be incorrect. For details on checksum verification including recalculating new checksums, refer to RFC: 791 for Internet Protocol.
- 6 Add 802.1Q VLAN tag: IEEE 802.1Q adds a 4-byte VLAN tag between the Source/Destination MAC address and Length/Type fields of an Ethernet frame to identify the VLAN to which the frame belongs.

For the VLAN tags:

- 1 Make space for the VLAN tag by shifting bytes 13 onward to the right by 4 to the byte location starting at 17.
- 2 Insert the VLAN tag at byte locations 13-16. For example, to add tag 24, insert 0x81 0x00 0x00 0x18. Here the first 2 bytes correspond to a Tag protocol identifier (TPID), which is a 16-bit field set to a value of 0x8100 to identify the frame as an IEEE 802.1Q-tagged frame. The other 2 bytes set the Tag control information (TCI) to 0x0018, which includes the VLAN Identifier that corresponds to 24.


### Open and Set Up Packet Source Model on Development Computer

Open model slrt\_ex\_udpsend. Set the IP address.

```

developmentIP = '192.168.7.2';
mdl2 = 'slrt_ex_udpsend';
open_system(fullfile(matlabroot,'toolbox','slrealtime','examples',mdl2));
set_param('slrt_ex_udpsend/UDP Receive1', 'ipAddress', developmentIP)

```



Copyright 2021 The MathWorks, Inc.



This model uses UDP blocks to send one packet out when the execution time is 2 seconds.

Set the To IP address parameter on `slrt_ex_udpsend/SendPacketSubsystem/UDP Send` to the IP address of the target computer.

```

targetIP = '192.168.7.5';
set_param('slrt_ex_udpsend/SendPacketSubsystem/UDP Send', 'toAddress', targetIP)

```

### Run Ethernet Send-Receive Real-Time Application on Target Computer

Run the target model on the target using the **Run on Target** button. Or, in the MATLAB Command Window, type:

```

evalc('slbuild(mdl1)');
tg = slrealtime;
load(tg,mdl1)
start(tg)

```

### Simulate the UDP Send Model on the Development Computer

Simulate the model.


```
set_param('slrt_ex_udpsend', 'SimulationCommand', 'start')
```

### Open Simulink Data Inspector

Open the Simulation Data Inspector and observe the new packets created on the target computer. In the MATLAB Command Window, type:

```
Simulink.sdi.view;
```

The Simulation Data Inspector shows that four packets are received by the UDP Receive block through four instances of the data length changing to five (the UDP packet size).



Every simulation sends out just one packet at time = 2 seconds.

The Ethernet send-receive real-time application responds with four packets, which contain the same payload but with VLAN tags 24, 25, 26, and 32.

Windows does not expose the VLAN tags to applications. Due to this using a packet capture program such as Wireshark does not show VLAN tags.

The development computer model shows four UDP packets were received. These are UDP blocks, and Ethernet header information is not output.

For Windows systems that have connections that block the VLAN tag (such as VM Ethernet connections or a network interface between the development and target computers), these connections may prevent the packets from appearing on the output display.

One way to see the tags is by using QNX Neutrino RTOS `tcpdump` command on the target computer while logged in as user `root` by using password `root`. Use the command:

```
tcpdump -i <targetIface> -v -e vlan
```

For `targetIface`, use the interface name `wm0` from the **Set Up Ethernet Send-Receive Model** section.

### Close Models

```
bdclose('all');
```

# Ethernet Blocks

---

## Ethernet Receive

Receive Ethernet packets from Simulink Real-Time target computer



**Libraries:**  
Simulink Real-Time / IP / Ethernet

### Description

The Ethernet Receive block enables you to receive Ethernet packets on a Simulink Real-Time target computer. The block receives the packet from the Ethernet interface (device) that you select on the target computer.

### Ports

#### Output

**Data** — Outport for Ethernet packet  
Simulink message

Connect the Ethernet packet signal from this port to the model. If you enable the **Enable Simulink messages** parameter, the data type is `Ethernet_Packet`. This data type consists of:

- **Data:** DataType: uint8, Complexity: real, Dimensions: [64 1]
- **Length:** DataType: uint8, Complexity: real, Dimensions: 1

Data Types: uint8 | Ethernet\_Packet

**Length** — Number of bytes received  
double

This port is available when you disable the **Enable Simulink messages** parameter. The Length is the number of bytes in the new packet received, otherwise it is 0.

Data Types: double

### Parameters

**Interface Name** — Target computer Ethernet interface name  
wm0 | wm1 | character vector

The **Interface Name** is the name of the target computer Ethernet interface. Use the Speedgoat Ethernet Configuration Tool to identify the Ethernet index (interface) on the target computer.

#### Programmatic Use

**Block Parameter:** InterfaceName

**Data Width** — Data port width in bytes  
64 (default) | integer

The **Data Width** is the width of the Data port in bytes. Ethernet packets that are shorter than this width are padded with zeros.

**Programmatic Use**

**Block Parameter:** DataWidth

**Enable Simulink messages** — Data as messages

off (default) | on

The Enable Simulink messages directs the block to treat data as messages. When enabled, the Length port is removed.

**Programmatic Use**

**Block Parameter:** MessageOut

**Maximum messages in a time step** — Limit packets per time step

1 (default) | integer

The **Maximum messages in a time step** selects the maximum number of packets that the block outputs for each time step.

**Programmatic Use**

**Block Parameter:** MaxMessagesPerStep

**Capture filter** — Filter on received packets

character vector

The Capture filter selects which packets to receive. If no filter is provided, all packets are received. For information about capture filter syntax, see the **Expressions** section in the tcpdump page in the QNX Neutrino documentation. This example filter captures packets that are addressed to destination port 9001.

```
dst port 9001
```

**Programmatic Use**

**Block Parameter:** FilterString

**Sample Time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use**

**Block Parameter:** SampleTime

## Version History

Introduced in R2022a

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

**See Also**

Ethernet Send



# Ethernet Send

Send Ethernet packets from Simulink Real-Time target computer



**Libraries:**  
Simulink Real-Time / IP / Ethernet

## Description

The Ethernet Send block enables you to send an Ethernet packet that you construct by using Simulink blocks or a MATLAB Function block and connects this signal to the Data input. This input is fully customizable. The block sends the packet to the Ethernet interface (device) that you select on the target computer.

## Ports

### Input

**Data** — Inport for Ethernet packet  
signal input for constructed Ethernet packet

Connect the constructed Ethernet packet signal from the model to this inport. If you enable the **Enable Simulink messages** parameter, the data type is `Ethernet_Packet`. Use the `slrealtime.createEthernetPacketBusObj` function to create the `Simulink.Bus` type `Ethernet_Packet`. This data type consists of:

- **Data:** DataType: uint8, Complexity: real, Dimensions: [64 1]
- **Length:** DataType: uint8, Complexity: real, Dimensions: 1

Data Types: uint8 | Ethernet\_Packet

**Length** — Number of bytes of data to transmit  
double

This port is available when you disable the **Enable Simulink messages** parameter. The **Length** determines the number of bytes of data to transmit. Specify the width of the **Data** vector as the maximum number of bytes that you expect to transmit.

Data Types: double

## Parameters

**Interface Name** — Target computer interface name  
wm0 | wm1 | character vector

The **Interface Name** is the name of the target computer Ethernet interface. Use the Speedgoat Ethernet Configuration Tool to identify the Ethernet index (interface) on the target computer.

**Programmatic Use****Block Parameter:** InterfaceName**Overwrite source MAC address** — Replace source MAC Address with MAC address from Data port  
off (default) | on

If enabled, the source MAC address in the sent packets is overwritten by the MAC address from the Data port. If disabled (default), the source MAC address in the sent packets is the actual MAC address of the target computer.

**Programmatic Use****Block Parameter:** OverwriteSrcMACAddress**Enable Simulink messages** — Data as messages

off (default) | on

The Enable Simulink messages directs the block to treat data as messages. When enabled, the Length port is removed.

**Programmatic Use****Block Parameter:** MessageIn**Sample Time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use****Block Parameter:** SampleTime

## Version History

Introduced in R2022a

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

Ethernet Receive | `slrealtime.createEthernetPacketBusObj`

# **SAE J1939 Blocks Library**



# SAE J1939

---

## **SAE J1939 Blocks**

The Simulink Real-Time J1939 blocks enable you to send and receive messages over a FIFO-mode CAN network by using the SAE J1939 message protocol. See “CAN”.

Before you start, provide a J1939 database in `.dbc` format.

### **See Also**

### **More About**


- “CAN”

# SAE J1939 Blocks

---

# J1939 Network Configuration

Define J1939 network configuration name and database file



## Libraries:

Simulink Real-Time / J1939 Communication  
Vehicle Network Toolbox / J1939 Communication

## Description

The J1939 Network Configuration block is where you define a configuration name and specify the associated user-supplied J1939 database. You can include more than one block per model, each corresponding to a unique configuration on the CAN bus.

To use this block, you must have a license for both Vehicle Network Toolbox™ and Simulink software.

The J1939 communication blocks support the use of Simulink accelerator and rapid accelerator modes. You can speed up the execution of Simulink models by using these modes. For more information on these modes, see the Simulink documentation.

The J1939 communication blocks also support code generation that have limited deployment capabilities. Code generation requires a C++ compiler that is compatible with the code generation target. For the current list of supported compilers, see Supported and Compatible Compilers.

## Parameters

**Configuration name** — Define a name for this J1939 network configuration  
ConfigX (default) | character vector

The default value is ConfigX, where the number X increases from 1 based on the number of existing blocks.

**Database File** — Specify the J1939 database file name relative to the current folder  
not set (default) | character vector

An example file name, enter J1939.dbc if the file is in the current folder; otherwise enter the full path with the file name, such as C:\work\J1939.dbc.

The database file defines the J1939 parameter groups and nodes. This file must be in the DBC file format defined by Vector Informatik GmbH.

## Version History

Introduced in R2015b


## See Also

J1939 CAN Transport Layer | J1939 Receive | J1939 Transmit | J1939 Node Configuration



# J1939 Node Configuration

Configure J1939 node with address and network management attributes



## Libraries:

Simulink Real-Time / J1939 Communication  
Vehicle Network Toolbox / J1939 Communication

## Description

The J1939 Node Configuration block is where you define a node and associate it with a specific network configuration. Its Message information is read from the database for that configuration, unless you are creating and configuring a custom node.

To use this block, you must have a license for both Vehicle Network Toolbox and Simulink software.

The J1939 communication blocks support the use of Simulink accelerator and rapid accelerator modes. You can speed up the execution of Simulink models by using these modes. For more information on these modes, see “Design Your Model for Effective Acceleration”.

The J1939 communication blocks also support code generation that have limited deployment capabilities. Code generation requires a C++ compiler that is compatible with the code generation target. For the current list of supported compilers, see Supported and Compatible Compilers.

## Ports

### Output

**Address** — Returns the effective address of the node  
int8

This optional output port exists when you select the **Output current node address** check box in the dialog box.

**AC Status** — Indicates the success (1) or failure (0) of the node’s address claim  
0 | 1

This optional output port exists when you select the **Output address claim status** check box in the dialog box.

## Parameters

**Config name** — ID of the J1939 network configuration to associate with this node  
ConfigX (default) | character vector

To access the corresponding J1939 database, use this ID.

**Node name** — name of this J1939 node  
NodeX (default) | character vector

The available list shows `none` if no J1939 network configuration is found or no node is defined in the associated database. If you are creating a custom node, the node name must be unique within its J1939 network configuration.

**Message** — Nine network attributes as defined by the database file consistent with the J1939 protocol vector array

Unless you are defining a custom node, these parameters are read-only:

- **Allow arbitrary address** — Allow/disallow the node to switch to an arbitrary address if the station address is not available. If this option is off and the node loses its address claim, the node goes silent.
  - Node Address** — Station address, decimal, 8-bit.
- **Industry Group** — Decimal, 3-bit.
- **Vehicle System** — Decimal, 7-bit.
- **Vehicle System Instance** — Identifies one particular occurrence of a given vehicle system in a given network. If only one instance of a certain vehicle system exists in a network, then this field must be set to 0 to define it as the first instance. Decimal, 4-bit.
- **Function ID** — Decimal, 8-bit.
- **Function Instance** — Identifies the particular occurrence of a given function in a vehicle system and given network. If only one instance of a certain function exists in a network, then this field must be set to 0 to define it as the first instance. Decimal, 5-bit.
- **ECU Instance** — This 3-bit field is used when multiple electronic control units (ECU) are involved in performing a single function. If only one ECU is used for a particular controller application (CA), then this field must be set to 0 to define it as the first instance.
- **Manufacturer Code** — Decimal, 11-bit.
- **Identity Number** — Decimal, 21-bit.

**Sample time** — Simulation refresh rate  
0.01 (default) | double

Specify the sampling time of the block during simulation. This value defines the frequency at which the J1939 Node Configuration updates its optional output ports. If the block is inside a triggered subsystem or inherits a sample time, specify a value of `-1`. You can also specify a MATLAB variable for sample time. The default value is `0.01` simulation seconds. For information about simulation sample timing, see “What Is Sample Time?”.

**Output current node address** — Enable or disable the Address port display  
off (default) | on

Enable or disable the **Address** output port to show the effective address. The effective address is different from the predefined station address. If **Allow arbitrary address** is selected, a name conflict occurs, and the current node has lower priority. The output signal is a double value from 0 to 253. This port is disabled by default.

**Output address claim status** — Enable or disable the address claim AC Status display  
off (default) | on

Enable or disable the address claim **AC Status** output port to show the success of an address claim. The output value is binary, 1 for success or 0 for failure. This port is disabled by default.

## **Version History**


**Introduced in R2015b**

### **See Also**

J1939 CAN Transport Layer | J1939 Receive | J1939 Transmit | J1939 Network Configuration

## J1939 CAN Transport Layer

Generate and consume J1939 messages that are transported by CAN hardware



**Libraries:**  
Simulink Real-Time / J1939

### Description

The J1939 CAN Transport Layer block handles CAN messages that your model transmits or receives by using Simulink Real-Time CAN library blocks.

Connect the input side of the block to a block that receives CAN messages. Connect the output side of the block to a block that transmits the J1939 messages over CAN. Set up the transmitting block so that a CAN message is sent only when an J1939 message is available. Otherwise, the block sends 0 byte data when J1939 messages are not available, causing undefined behavior.

### Ports

#### Input

**CAN Msg** — CAN MESSAGE structures being consumed  
vector

Vector of CAN MESSAGE structures being consumed.

**N** — Number of messages  
integer

Number of messages in the vector.

#### Output

**CAN Msg** — CAN MESSAGE structures being generated  
vector

Vector of CAN MESSAGE structures being generated.

**N** — Number of messages  
integer

Number of messages in the vector.

## Version History

**Introduced in R2020b**

## **Extended Capabilities**

### **C/C++ Code Generation**


Generate C and C++ code using Simulink® Coder™.

### **See Also**

[J1939 Receive](#) | [J1939 Transmit](#) | [J1939 Node Configuration](#) | [J1939 Network Configuration](#)

## J1939 Receive

Receive J1939 parameter group messages



### Libraries:

Simulink Real-Time / J1939 Communication  
Vehicle Network Toolbox / J1939 Communication

## Description

The J1939 Receive block receives a J1939 message from the configured CAN device. The J1939 database file defines the nodes and parameter groups. You specify the J1939 database by using the J1939 Network Configuration block.

To use this block, you must have a license for both Vehicle Network Toolbox and Simulink software.

The J1939 communication blocks support the use of Simulink accelerator and rapid accelerator modes. You can speed up the execution of Simulink models by using these modes. For more information on these modes, see “Design Your Model for Effective Acceleration”.

The J1939 communication blocks also support code generation that have limited deployment capabilities. Code generation requires a C++ compiler that is compatible with the code generation target. For the current list of supported compilers, see Supported and Compatible Compilers.

## Ports

### Output

**Data** — Data output  
double

Depending on the J1939 parameter group defined in the J1939 database file, the block can have multiple data output signal ports. The block output data type is double.

**Msg Status** — Message received status  
0 | 1

When you select the **Output New Message Received status** check box in the parameters dialog, this port outputs 1 when a new message is received from the CAN bus. Otherwise, this port outputs 0.

## Parameters

**Config name** — Name of the J1939 network configuration to associate  
ConfigX (default) | character vector

The name of the J1939 network configuration to associate. This value is used to access the corresponding J1939 database. Only the nodes defined in the model and associated with the specified

J1939 network configuration appear in the Node name list. The option shows none if no J1939 network configuration is found.

**Node name** — Name of the J1939 node

NodeX (default) | character vector

The name of the J1939 node. The drop-down list includes all the nodes in the model, both custom nodes and nodes from the database.

**Parameter Group** — Parameter group number (PGN) and name from database

character vector

The parameter group number (PGN) and name from the database. The contents of this list vary depending on the parameter groups that the J1939 database file specifies. The default is the first parameter group for the selected node.

If you change any parameter group settings within your J1939 database file, open the J1939 Receive block dialog box and select the same **Parameter Group** and click **OK** or **Apply**.

**Signals** — Signals defined in the parameter group

array of character vectors

Signals that are defined in the parameter group. The **Min** and **Max** settings are read from the database, but by default the block does not clip signal values that exceed this range.

**Source Address Filter** — Filter messages based on source address

Allow all (default) | Allow only

Filter messages based on source address are:

- Allow only — Specify a single source address.
- Allow all — Accepts messages from any source address. This option is the default.

**Destination Address Filter** — Filter out message based on destination address

global and node specific (default) | global only | node specific only

Filter out a message based on the destination address:

- global only — Receive only broadcast messages.
- node specific only — Receive only messages addressed to this node.
- global and node specific — Receive all broadcast and node-addressed messages. This option is the default.

**Sample time** — Simulation refresh rate

0.01 (default) | double

The simulation refresh rate. Specify the sampling time of the block during simulation. This value defines the frequency at which the J1939 Receive block updates its output ports. If the block is inside a triggered subsystem or inherits a sample time, specify a value of -1. You can also specify a MATLAB variable for sample time. The default value is 0.01 simulation seconds. For information about simulation sample timing, see “What Is Sample Time?”.

**Output New Message Received status** — Create a Msg Status output

0 (default) | 1

Select this check box to create a **Msg Status** output port. Its output signal indicates a new incoming message, showing 1 for a new message received, or 0 when there is no new message.

## **Version History**

**Introduced in R2015b**


### **See Also**

J1939 CAN Transport Layer | J1939 Transmit | J1939 Network Configuration | J1939 Node Configuration



# J1939 Transmit

Transmit J1939 message



## Libraries:

Simulink Real-Time / J1939 Communication  
Vehicle Network Toolbox / J1939 Communication

## Description

The J1939 Transmit block transmits a J1939 message. The J1939 database file defines the nodes and parameter groups. You specify the J1939 database by using the J1939 Network Configuration block.

To use this block, you must have a license for both Vehicle Network Toolbox and Simulink software.

The J1939 communication blocks support the use of Simulink accelerator and rapid accelerator modes. You can speed up the execution of Simulink models by using these modes. For more information on these modes, see “Design Your Model for Effective Acceleration”.

The J1939 communication blocks also support code generation that have limited deployment capabilities. Code generation requires a C++ compiler that is compatible with the code generation target. For the current list of supported compilers, see Supported and Compatible Compilers.

## Ports

### Input

**Data** — Input data  
signal

Depending on the J1939 parameter group and signals defined in the J1939 database file, the block can have multiple data input ports.

**Trigger** — Enables the transmission of message  
0 | 1

Enables the transmission of the message for that sample. A value of 1 specifies to send, a value of 0 specifies not to send.

## Parameters

**Config name** — Name of the J1939 network configuration to associate  
ConfigX (default) | character vector

The name of the J1939 network configuration to associate with. This is used to access the corresponding J1939 database. Only the nodes defined in the model and associated with the specified J1939 network configuration appear in the Node name list. The option shows none if no J1939 network configuration is found.

**Node name** — Name of the J1939 node  
NodeX (default) | character vector

The name of the J1939 node. The drop-down list includes all the nodes in the model, both custom nodes and nodes from the database.

**Parameter Group** — Group number (PGN) and name  
int8

The parameter group number (PGN) and name from the database. The contents of this list vary depending on the parameter groups that the J1939 database file specifies. The default is the first parameter group for the selected node.

If you change any parameter group settings within your J1939 database file, you must then open the J1939 Transmit block dialog box and select the same **Parameter Group**, then click **OK** or **Apply** to update the parameter group information in the block.

**Signals** — Signals defined in parameter group  
array of character vectors

Signals defined in the parameter group. The **Min** and **Max** settings are read from the database, but by default the block does not clip signal values that exceed this range.

**PG Priority** — Priority of the parameter group  
int8

Priority of the parameter group, read from the database. This priority setting resolves clashes of multiple parameter groups transmitting on the same bus at the same time. If a conflict occurs, the priority group with lower priority (higher value) will refrain from transmitting. The value can range from 0 (highest priority) to 7 (lowest).

**Destination Address** — Name of the destination node  
int8

The name of the destination node. The default is the first node defined in the database, otherwise Custom.

For a custom destination address, you can specify 0-253 for the address of the destination node. For broadcasting to all nodes, use the Custom **Destination Address** setting with an address of 255.

**Sample time** — Simulation transmit rate  
-1 (default) | double

The simulation transmit rate, specified as the sampling time of the block during simulation. This value defines the frequency at which the J1939 Transmit block transmits messages. The default value of -1 is used when the block is inside a triggered subsystem or inherits a sample time. You can also specify a MATLAB variable for sample time. For information about simulation sample timing, see “What Is Sample Time?”.

## Version History

### Introduced in R2015b

**See Also**

J1939 CAN Transport Layer | J1939 Receive | J1939 Network Configuration | J1939 Node Configuration



# Logitech



# Logitech Blocks

---

The Simulink Real-Time Logitech blocks support Logitech G29 Steering Wheel functions.

# Logitech G29 Steering Wheel

Receive Logitech G29 Steering Wheel read data



## Libraries:

Simulink Real-Time / Logitech G29

## Description

The Logitech G29 Steering Wheel block reads data from a Logitech G29 Steering Wheel (PS3 only). The block does not support a Stick Shift module.

## Ports

### Output

**Buttons** — Status of steering wheel buttons

0 (= unpressed) | 1 (= pressed)

The **Buttons** output is a vector of Boolean values that indicate the status of buttons on the steering wheel. The order of the button values in the vector is:

- 1 Square
- 2 X
- 3 Circle
- 4 Triangle
- 5 LPaddle
- 6 RPaddle
- 7 L2
- 8 R2
- 9 L3
- 10 R3
- 11 Share
- 12 Option
- 13 PS

Data Types: Boolean

**Steering** — Value of steering wheel position

0 (= left most) | 65535 (= right most)

The **Steering** output value indicates the position of the steering wheel.

Data Types: uint16



**Pedals** — Status of throttle, brake, and clutch pedals

0 (= not engaged) | 255 (= fully engaged)

The `Pedals` output is a vector of values that indicate the status of the throttle, brake, and clutch pedals. The order of the pedal values in the vector is:

- 1 Throttle
- 2 Brake
- 3 Clutch

Data Types: `uint8`

**Direction** — Status of direction pad buttons on steering wheel

0 (= UP) | 2 (= RIGHT) | 4 (= DOWN) | 6 (= LEFT) | 8 (= UNPRESSED)

The `Direction` output value indicates a button press on the direction pad. When you press the direction pad in between the pad buttons, intermediate values occur.

Data Types: `uint8`

**Status** — Status of communications with steering wheel

0 (default) | negative value

The `Status` output value indicates successful communications with the steering wheel (0) or unsuccessful communications (negative value).

Data Types: `int32`

## Parameters

**sampleTime** — Sample time for steering wheel data

-1 (inherited) (default)

Select the sample time for steering wheel data. The recommended `sampleTime` is 10ms.

### Programmatic Use

**Block Parameter:** `sampleTime`

## Version History

Introduced in R2018b

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also

### External Websites

Logitech G29 Driving Force Racing Wheel



**LIN**



# LIN Blocks

---

The Simulink Real-Time LIN blocks support packing signals into frames and unpacking signals from frames by using information in an LIN description file (LDF).

## LIN Pack

Pack signals into data frame by using configuration in LIN description file



**Libraries:**  
Simulink Real-Time / LIN

### Description

The LIN Pack block packs signals into the data frame by using the configuration in the LIN description file (LDF). A local interconnect network (LIN) bus can use the packed data. The LIN Pack block supports LDF version 2.2 and previous.

### Ports

#### Input

**in** — input data to pack  
data

Receives data to pack for the LIN. The number of input ports is allocated based on the selected frame. The port name is assigned to each port.

#### Output

**lin\_data** — output LIN data  
LIN data

Sends packed LIN data.

### Parameters

**LDF File Name** — File path of LDF  
empty (default) | character vector | string scalar

Provides the file path of the LDF. If you do not set this parameter, you cannot use the block.

#### Programmatic Use

**Block Parameter:** LDFFileName

**Select Frame** — LIN frame  
None (default) | character vector | string scalar

Selects the LIN frame from selections available in LDF. If you do not select an LDF, the block uses None.

#### Programmatic Use

**Block Parameter:** selectedFrameName

**Frame ID** — LIN frame ID

1 (default) | uint8

Selects the LIN frame ID from selections available in LDF. If you do not select an LDF, the block uses 1.

**Programmatic Use****Block Parameter:** frameId

## Version History

**Introduced in R2021b**

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also


LIN Unpack

**External Websites**

Local Interconnect Network (LIN)

## LIN Unpack

Unpack signals from data frame by using configuration in LIN description file



**Libraries:**  
Simulink Real-Time / LIN

### Description

The LIN Unpack block unpacks the data frame by using the configuration in the LIN description file (LDF) and outputs signal data. You can use the unpacked local interconnect network (LIN) bus data as signal data in the model. The LIN Unpack block supports LDF version 2.2 and previous.

### Ports

#### Input

**message\_updated** — indicates message update  
0 (logical false) | 1 (logical true)

When the `message_updated` value is 1 (logical true), there is a message coming in from the LIN bus. This block outputs the unpacked signals. When the `message_updated` value is 0 (logical false), there is no message updated on the LIN bus, and this block outputs the default value for each signal defined in the LDF file.

**Lin\_data\_8\_bytes** — input LIN data to unpack  
LIN data

Receives LIN data to unpack.

#### Output

**out** — output data  
data

Sends unpacked data. The number of the output ports is allocated based on the number of signals in the selected frame. When a frame is selected, the port name is assigned to each port.

### Parameters

**LDF File Name** — File path of LDF  
empty (default) | character vector | string scalar

Provides the file path of the LDF. If you do not set this parameter, you cannot use the block.

#### Programmatic Use

**Block Parameter:** LDFFileName



**Select Frame** — LIN frame

None (default) | character vector | string scalar

Selects the LIN frame from selections available in LDF. If you do not select an LDF, the block uses None.

**Programmatic Use****Block Parameter:** selectedFrameName**Frame ID** — LIN frame ID

1 (default) | uint8

Selects LIN frame ID from selections available in LDF. If you do not select an LDF, the block uses 1.

**Programmatic Use****Block Parameter:** frameId

## Version History

Introduced in R2021b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

LIN Pack

**External Websites**

Local Interconnect Network (LIN)



# Logging Blocks Library



# Logging Blocks

---

The Simulink Real-Time file logging blocks support logging run data for viewing in the Simulation Data Inspector.

## File Log

Write signal data file log on target computer



**Libraries:**  
Simulink Real-Time / Logging

### Description

When you enable logging service, the File Log block logs the signal at its input port to the target computer file system.

For more information about the file logging workflow, see “Signal Logging and Streaming Basics”.

### Ports

#### Input

**S** — Signal data for file log  
scalar | vector | matrix | array | bus | nonvirtual bus

Provides the signal data input for the file log.

### Parameters

**Decimation** — Applies decimation to file log data  
1 (default) | integer

The decimation parameter value selects decimation for the samples captured in the file log.

By using the File Log decimation functions, you can tune the decimation parameter programmatically for the File Log in the model. These functions are:

- `getAllFileLogBlocks`
- `getFileLogDecimation`
- `setFileLogDecimation`

#### Programmatic Use

decimation

**Input Processing** — Selects processing mode for file log data  
Elements as channels (sample based) (default) | Columns as channels (frame based)

The input processing parameter value selects whether the logged signal data is processed and sent to the Simulation Data Inspector in sample or frame processing mode. For more information about sample-based data and frame-based data in the Simulation Data Inspector, see “View Data in the Simulation Data Inspector”.

**Programmatic Use**

inputProcessing

**Version History**

Introduced in R2020b

**R2022a: Decimation, Log Retention, and Frame-Based Input**

Functions let you get and set decimation values for File Log blocks in a model. Also, functions let you control when File Log recording starts and stops.

**Extended Capabilities****C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

Enable File Log | list | import | discard | getAllFileLogBlocks | getFileLogDecimation | setFileLogDecimation | startRecording | stopRecording

**Topics**

“Signal Logging and Streaming Basics”

## Enable File Log

Enable or disable file logging of signals on target computer



**Libraries:**  
Simulink Real-Time / Logging

### Description

When the input port value is true, the Enable File Log block enables the file logging service on the target computer so that File Log blocks in the model start recording data. When the input port value is false, the block disables file logging on the target computer, and the File Log blocks do not record data.

If a model includes a Enable File Log block, the `startRecording` function and `stopRecording` function only control signal streaming, not File Log logging. In this case, the `start(tg) AutoImportFileLog` option does not import data into the Simulation Data Inspector when you use the `stopRecording` function or click the **Stop Recording** button.

For more information about the file logging workflow, see “Signal Logging and Streaming Basics”.

### Ports

#### Input

**E** — Enable or disable file logging  
boolean

Provides enable or disable control over File Log block operation. When the enable input is triggered by a boolean signal in the model, there are logs created on the target computer. Retention of these logs depends on the `FileLogMaxRuns` setting.

## Version History

Introduced in R2020b

### Extended Capabilities

#### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

### See Also

File Log | list | import | discard | startRecording | stopRecording



**Topics**

“Signal Logging and Streaming Basics”



# Profiling Blocks Library




# Profiling Blocks

---

The Simulink Real-Time profiling blocks support real-time application execution profiling functions.

## Enable Profiler

Start and stop execution profiler on target computer



**Libraries:**  
Simulink Real-Time / Profiling

### Description

A rising edge on the Enable Profiler block **Start** input starts the execution profiler. A rising edge on the **Stop** input stops the execution profiler. A rising edge on both ports has no effect.

### Ports

#### Input

**Start** — Starts the profiler

0 | 1

When the **Start** input changes from 0 to 1, the block starts the profiler.

After the resources required to collect the data become available in the background, the profiler starts collecting data. Profiler preparation can span several time steps.

Data Types: Boolean

**Stop** — Stops the profiler

0 | 1

When the **Stop** input changes from 0 to 1, the block stops the profiler.

If the profiler is still running when the application stops, the profiler stops by itself. You do not have to trigger the **Stop** input.

The amount of data collected is limited to 1GB. The profiler stops by itself when it reaches this limit.

Data Types: Boolean

### Version History

Introduced in R2020b

### Extended Capabilities

#### C/C++ Code Generation


Generate C and C++ code using Simulink® Coder™.

**See Also**

`startProfiler` | `stopProfiler` | `getProfilerData` | `resetProfiler` | `ProfilerData`

## Log Event

Log an execution profiling event



**Libraries:**  
Simulink Real-Time / Profiling

### Description

When triggered, the Log Event block inserts a user-defined event into the execution profiling event stream. The user-defined event includes a channel ID, a code number, and a value number. The channel ID value ranges from 0 to 1023.

### Ports

#### Input

**T** — Trigger for log event  
1..9

When the T (trigger input) changes from 0 to 1 (Rising) or from 1 to 9 (Falling), the block inserts a user-defined simple event defined by the parameters **Channel**, **Code**, and **Value** into the execution profiling event stream.

Example: 1

### Parameters

**Channel** — Event channel ID  
0 (default) | int

Select the event change ID, for example 500.

#### Programmatic Use

channel

**Code** — Event code number  
0 (default) | uint32

Select the event code number, for example 200.

#### Programmatic Use

code

**Value** — Event value number  
0 (default) | uint32

Select the event value number, for example 200.



**Programmatic Use**

value

**Trigger type** — Selects trigger signal edge

Rising (default) | Falling | Either

Select the type of signal change that triggers the block. When the T (trigger input) changes from 0 to 1 (Rising) or from 1 to 0 (Falling), the block inserts a user-defined simple event defined by the parameters **Channel**, **Code**, and **Value** into the execution profiling event stream.

**Programmatic Use**

trigger

## Version History

Introduced in R2020b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

Enable Profiler



# **PTP Precision Time Protocol Blocks Library**



# PTP Blocks

---

The Simulink Real-Time PTP blocks support PTP protocol-related functions.



# Precision Time Protocol

---

- “Precision Time Protocol” on page 21-2
- “PTP Prerequisites” on page 21-4


## Precision Time Protocol

Measurement and control systems increasingly use distributed system technologies. To distribute measurement or control tasks over interconnected computing devices, such systems maintain a system-wide sense of time. Simulink Real-Time uses the Precision Time Protocol (PTP) to synchronize the system clock of each target computer to a reference time.

PTP (IEEE® 1588) is a protocol that synchronizes PTP clocks throughout a computer network. The current version of PTP (IEEE 1588-2008) describes a hierarchical master-slave architecture for clock distribution.

By design, this protocol is more accurate for local systems than the Network Time Protocol (NTP) and more robust than the Global Positioning System (GPS). On a local area network, the protocol achieves PTP clock accuracy in the submicrosecond range, making it suitable for distributed measurement. When you use this protocol to synchronize Simulink Real-Time applications across multiple target computers, it can synchronize execution to under 10  $\mu$ s.

Suppose that you are designing a control system for a wind power plant. To determine the plant parameters, you attach sensors that acquire the data shown in the diagram.



To record the data and timestamps, connect the sensors to a set of data acquisition target computers. Interconnect the data acquisition computers through an Ethernet network and a switch that supports the PTP protocol (a PTP transparent clock or boundary clock). To access the data and timestamps, connect the target computers to a development computer through another Ethernet network and switch. On the development computer, run MATLAB to do the data analysis, including:

- Sorting by time the data recorded on the different computers to analyze the event sequence over time.
- Filtering sensor data that has invalid (unsynchronized) timestamps.
- Integrating values of measured data collected at the same time from sensors connected to different computers.



Finally, you build and download the real-time applications to each target computer, run the applications, and collect and analyze the results at each valid timestamp. You use the results to design a control system for the wind power generator.

Simulink Real-Time supports the PTP protocol by using the RTOS PTP daemon. The `ptpd` daemon implements the Precision Time Protocol (PTP) Version 2 as defined by the IEEE 1588-2008 standard. For more information about the daemon, see the QNX Neutrino documentation.

To synchronize the target computer PTP clocks:

- 1 Connect the target computers by using their Intel i210 Ethernet cards.
- 2 On the master target computer, start the PTP daemon by using the `start(target_object.ptpd)` command or the `target_object.ptpd.AutoStart` property.
- 3 On the slave target computer, start the PTP daemon by using the `start(target_object.ptpd)` command or the `target_object.ptpd.AutoStart` property.

The PTP slave synchronizes its clock to the PTP master clock. The hardware timestamp from the Intel i210 Ethernet cards provides IEEE 1588-2008 standard compliant clock synchronization.

To get information about clock synchronization, add an IEEE 1588 Read Parameter block to the model. This block outputs a Precision Time Protocol parameter value that you select. The parameters are:

- **System time**
- **Calendar time**
- **Offset from Master**
- **Master to Slave Delay**
- **Slave to Master Delay**
- **One Way Delay**

## See Also

Subsystem | IEEE 1588 Read Parameter

## Related Examples

- “Synchronize PTP Clocks on Two Target Computers”

## More About

- “PTP Prerequisites” on page 21-4

## External Websites

- [standards.ieee.org](http://standards.ieee.org)

## PTP Prerequisites

The Simulink Real-Time implementation of PTP enforces specific requirements:

- PTP functionality is available only with a Speedgoat target computer. If you have not installed the Speedgoat I/O Blockset, attempting to build a real-time application with PTP causes a build error.
- The support for PTP IEEE-1588 is part of the on-board or installed I/O module connectivity of real-time target machines. After installing the Speedgoat I/O Blockset, you can confirm PTP support by using the function:

```
speedgoat.showPtpInterfaces('TargetObject', tg)
```

```
>> speedgoat.showPtpInterfaces('TargetObject', tg)
```

Label	Index	PTPSupport	Configuration
{'Host Link'}	{'wm0'}	{'No'}	{'IP: 192.168.7.5 Subnet: 255.255.255.0'}
{'ETH1' }	{'wm1'}	{'No'}	{'Not configured' }

To use PTP, the ethernet interface needs to be configured with an IP stack.  
Use the Ethernet configuration tool: `speedgoat.configureEthernet`

### See Also

Subsystem | IEEE 1588 Read Parameter

### Related Examples

- “Synchronize PTP Clocks on Two Target Computers”

### More About

- “Precision Time Protocol” on page 21-2

### External Websites


- [standards.ieee.org](http://standards.ieee.org)

# Precision Time Protocol Blocks

---

## IEEE 1588 Read Parameter

Output Precision Time Protocol status parameter values such as target computer system time, calendar time, and delays



**Libraries:**  
Simulink Real-Time / PTP

### Description

The IEEE 1588 Read Parameter block reads the parameter that you select and send its value to the block output. The block label changes based on the parameter that you select.

You can use the IEEE 1588 Read Parameter block to read the target computer system time even without a PTPd process running.

### Ports

#### Output Arguments

**Output** — Output selected by Parameter to read parameter  
`double | [uint32]`

The current parameter to read.

### Parameters

**Parameter to read** — Parameter to display at output

`System time (nanosecond) (default) | Calendar time (time_t) | Offset from Client | Client to Server Delay | One Way Delay`

Specify the parameter to read. Select one of:

- `System time (nanosecond)` — Current SLRT system time number of nanoseconds, counting from the current epoch. The output is a uint64.
- `Calendar time (time_t)` — Current SLRT calendar time in `time_t` int32 vector.
- `Offset from Client` — Time offset in seconds. The output is a double.
- `Client to Server Delay` — Time delay in seconds. The output is a double.
- `One Way Delay` — Time delay in seconds. The output is a double.

The `Calendar time (time_t)` vector contains these components:

- seconds after the minute - [0, 61] (until C99)[0, 60] (since C99)
- minutes after the hour - [0, 59]
- hours since midnight - [0, 23]
- day of the month - [1, 31]

- months since January - [0, 11]
- years since 1900
- days since Sunday - [0, 6]
- days since January 1 - [0, 365]
- Daylight Saving Time flag. The value is positive if DST is in effect, zero if not and negative if no information is available

**Programmatic Use****Block Parameter:** param**Sample time (-1 for inherited)** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time.

**Programmatic Use****Block Parameter:** sample\_time

## Version History

Introduced in R2020b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

Subsystem

**Topics**

“PTP Prerequisites” on page 21-4

**External Websites**

standards.ieee.org



# **RS232 Serial Blocks Library**





# Serial Communications Support

---

- “RS-232 Serial Communication” on page 23-2
- “RS-232 Legacy Drivers” on page 23-4

## RS-232 Serial Communication


The Simulink Real-Time software supports RS-232 serial communication by using the serial ports on the target computer mainboard as the RS-232 I/O devices. You can initiate RS-232 communication with these serial ports and the accompanying Simulink Real-Time drivers.

The Simulink Real-Time block library supplies legacy drivers to support RS-232 communication (see “RS-232 Legacy Drivers” on page 23-4). The composite drivers support RS-232 communication in asynchronous binary mode. They provide a simple ASCII encode/decode for the send and receive RS-232 blocks.

These drivers are described as legacy because the library supports legacy RS-232 communications by using the RTOS resource manager. To use the Legacy Serial Read block and Legacy Serial Write block, set up the serial ports by using the Legacy Serial Setup block.

### Serial Connections for RS-232

The Simulink Real-Time software supports serial communication by using the COM1 and COM2 ports on the target computer.




Your real-time applications can use these RS-232 ports as I/O devices. With the typical DTE/DCE configuration of the RS-232 device, the target computer is connected to the device with a null modem cable.

### Serial Connection for USB to RS-232

The Simulink Real-Time software supports serial communication from USB ports on the target computer to serial devices by using a USB-to-serial adapter cable. The USB-to-serial adapter should be at least USB 2.0 (preferably USB 3.0) compliant. Note that cables from some vendors may not work, despite claiming USB 2.0 compliance. The features to seek when purchasing a USB-to-serial adapter are:

- Uses the Future Technology Devices International (FTDI) chip or uses the Prolific chip set.
- USB serial class compliant without requiring an operating system specific driver.

To check which USB ports on the target computer are enabled and identify the USB support that the ports provide, enter the `usb -vvv` command at the command line by using the target computer keyboard or by using an SSH session. For more information, see “Target Computer Command Line”.



## See Also

[ASCII Encode](#) | [ASCII Decode](#) | [FIFO Read](#) | [FIFO Write](#) | [FIFO Read HDRS](#) | [FIFO Read Binary](#) | [Modem Control](#) | [Modem Status](#) | [ASCII Decode V2](#) | [Legacy Serial Read](#) | [Legacy Serial Setup](#) | [Legacy Serial Write](#) | [Legacy Serial Port](#) | [Legacy Serial Port F](#)

## More About

- “RS-232 Legacy Drivers” on page 23-4

## RS-232 Legacy Drivers

There are components that make up the RS-232 legacy drivers. You can create a model by using these drivers. These drivers perform RS-232 asynchronous communications.

The Simulink Real-Time software provides legacy drivers that support the target computer (main board) serial ports.

These drivers encapsulate the functionality of the device by using the Legacy Serial Port block and the Legacy Serial Port F blocks. For most RS-232 requirements, you can use these RS-232 drivers. For modem requirements, use the Modem Control block and Modem Status block.

### Add RS-232 Blocks

When you want to use the serial ports on the target computer for serial I/O, add RS-232 Legacy Serial Port or Legacy Serial Port F subsystem blocks to your Simulink model .

Before you start, decide what legacy serial ports you want to use. The example has you configure the Legacy Serial Port block. To configure this block, first select serial ports.

The following procedure shows how to use the serial ports on the target computer for I/O with the legacy drivers. It shows a model that uses legacy serial port 1 and legacy serial port 2.

- 1 Open the Simulink Real-Time block library. You can access the library from the Simulink Library Browser. In the Simulink Editor, on the **Real-Time** tab, from the **Prepare** section, click **Library Browser**. In the left pane, double-click **Simulink Real-Time**, and then click **RS232**. To open the library from the MATLAB Command Window, type:

```
slrealtimelib
```

- 2 In the Simulink Real-Time driver block library, double-click the **RS232** group block.
- 3 In the window with blocks for RS-232 legacy drivers, drag an ASCII Encode block to your Simulink model. This block encodes input for the Legacy Serial Port block XMT port.
- 4 Configure this block.
- 5 Drag an ASCII Decode block to your Simulink model. This block decodes output from the Legacy Serial Port block RCV port.
- 6 Configure this block.
- 7 Double-click the **Mainboard** group block.
- 8 Drag two Legacy Serial Port blocks to your Simulink model.
- 9 Double-click the first Legacy Serial Port block.
- 10 Configure this block for Legacy Serial Port 1
- 11 Double-click the second Legacy Serial Port block.
- 12 Configure this block for Legacy Serial Port 2
- 13 Add a Pulse Generator block and a target Scope block.
- 14 Configure the Pulse Generator block so that its **Pulse type** is **Sample based**.


The dialog box changes to display a **Sample time** parameter. Enter a **Sample time** that is slower than the one you set for **Receive Setup**.

- 15 From the Simulink Library Browser, select **Sinks**. Depending on your configuration, drag one or more Terminator blocks to your model.

From the Simulink Library Browser, select **Sources**. Depending on your configuration, drag the Ground block to your model.

A pre-constructed example model is available. The `slrt_ex_serialbaseboardasciitest` model uses two legacy serial ports. To open this model, in the MATLAB Command Window, type:

```
open_system(fullfile(matlabroot, 'toolbox', 'slrealtime', ...
'examples', 'slrt_ex_serialbaseboardasciitest'))
```



Your next task is to build and run the real-time application.

## Building and Running the Real-Time Application

The Simulink Real-Time and Simulink Coder software create C code from your Simulink model. You can then use a C compiler to create executable code that runs on the target computer. You must know how to configure your model to create a real-time application. See “Build and Download Real-Time Application by Using Run on Target”.

After you add the RS-232 blocks for the main board to your Simulink model and configure your model, you can build your real-time application.

In the Simulink Editor, on the **Real-Time** tab, click **Run on Target**.

## Simulink Real-Time RS-232 Reference

- “RS-232 FIFO Read Blocks” on page 23-6
- “RS-232 Signal Data Types” on page 23-7
- “RS-232 Zero Length Messages” on page 23-7

- “RS-232 Control When You Send a Message” on page 23-8

The Simulink Real-Time software supports RS-232 communication by using driver blocks in your Simulink model.

### RS-232 FIFO Read Blocks

There are three kinds of FIFO Read blocks: FIFO Read, FIFO Read HDRS, and FIFO Read Binary. To develop your model, use the following guidelines:

- Simple data streams — Use the FIFO Read block to read simple data streams. An example of a simple data stream is one that has numbers separated by spaces and ends with a new-line character. The FIFO Read block is a simple block that can easily extract these numbers.
- Complicated data streams — Use the FIFO Read HDRS and FIFO Read Binary blocks for more complicated data streams. A more complicated data stream can be one that contains headers, messages of varying lengths, or messages without specific terminators. A message header consists of one or more character identifiers at the beginning of a message that specify what data follows. ASCII messages normally have a variable length and a terminator. Typically, the messages of a particular device use the same predefined terminator. Binary messages are normally of fixed length without a specific terminator.

You can also use the FIFO Read HDRS and FIFO Read Binary blocks to work with devices that can send different messages at different times.

The input to these FIFO read blocks must be of type `serialfifo_ptr`, which is output from F type Send Receive subsystems.

These examples show instances when you can use the FIFO Read block.

- For an instrument that sends a character vector like this one:

```
<number> <number> ... <CR><LF>
```

use the simple FIFO Read block to read the message. Configure the FIFO Read block **Delimiter** parameter for a line feed (value of 10). Connect the output to an ASCII Decode block with a format that separates the numbers and feeds them to the output ports.

- For an instrument that can send one of several different messages, each beginning with a different fixed character vector, use the FIFO Read HDRS block. For example, a digital multimeter connected through an RS-232 port sends a voltage and amp reading with messages in this format:

```
volts <number> <CR><LF>
amps <number> <CR><LF>
```

Configure the FIFO Read HDRS block **Header** parameter for the `volts` and `amps` headers in a cell array: `{'volts', 'amps'}`. Configure the **Terminating string** parameter for carriage return (13) and line feed (10): `[13 10]`.


Connect the output to multiple ASCII Decode blocks, one for each header and message. For examples of how to use this block in a model, see the `slrt_ex_serialasciitest` and `slrt_ex_serialasciisplit` models in `matlab/toolbox/slrealtime/examples`.

- For an instrument that sends a binary message, you could know the length of each full message, including the header. Configure the FIFO Read Binary block **Header** parameter for the headers of the message in a cell array and the **Message Lengths** parameter for the message lengths. For further examples of how to use this block in a model, see the `slrt_ex_serialbinarytest` and `slrt_ex_serialbinarysplit` models in `matlabroot/toolbox/slrealtime/examples`.

## RS-232 Signal Data Types


Signals between blocks in composite drivers can be one of several basic data types: 8-bit, 16-bit, and 32-bit. These types are structures.

The 8-bit data types are NULL-terminated character vectors that are represented as Simulink vectors. The width is the maximum number of characters that can be stored. In the figure, M is the actual set of stored characters and N is the maximum number of characters that can be stored. This figure illustrates 8-bit int NULL-terminated and 8-bit uint NULL-terminated data types.



The character vector has 11 characters terminated with a NULL byte (0). The data type cannot contain a NULL byte as part of the real data.

The 16-bit and 32-bit data types use the first element of the vector as a count of the valid data. In the figure of a 16-bit data type, C is the count of the valid data and N is the width of the vector. This figure illustrates count + 16-bit int and count + 16-bit uint data types. This arrangement also applies to count + 32-bit int and count + 32-bit uint data types.



The serial blocks interpret each entry in the vector as a single character. The low-level Send block writes the low-order byte of each entry to the UART. The 16-bit and 32-bit data types allow the embedding of 8-bit data values, including 0. The 8-bit data type is most useful with the ASCII Encode and Decode blocks. The 16-bit and 32-bit data types are most useful for binary data streams.

## RS-232 Zero Length Messages

Usually, you configure a FIFO read block of your model serial I/O to execute faster than the model receives data. Doing so prevents the receive FIFO buffer from overflowing. You must also configure your model to deal with the possibility that a FIFO Read block does not have a message on its output.

Receive FIFOs can have too few characters for a FIFO read operation. A model that receives serial I/O can have a FIFO Read block that executes in this situation. Depending on how you configure the behavior, this condition causes a FIFO Read block to perform one of these operations:

- Return the last message it received.
- Return a zero-length message.

The Simulink Real-Time library of composite serial drivers has three FIFO Read blocks: FIFO Read HDRS, FIFO Read Binary, and FIFO Read. For the FIFO Read HDRS or FIFO Read Binary blocks, you configure this behavior by using the **Output behavior** parameter. The FIFO Read block returns either a new message or a zero-length message.

To execute model code only if a new message arrives, check the first element of the returned vector, depending on the character vector data type:

- In the 8-bit data type, the returned character vector is NULL-terminated. If the first element is 0, the character vector has zero length and the FIFO read did not detect a new message.
- In the 16-bit and 32-bit data types, the first element is the number of characters in the character vector. This value is 0 if the FIFO read did not detect a new message.

If the message has nonzero length, enable a subsystem to process the new character vector. Otherwise, do not process it.

### RS-232 Control When You Send a Message

You can use the structure of both serial data types to control when you send a message. For more information, see “RS-232 Signal Data Types” on page 23-7. In both cases, a 0 in the first position indicates an empty character vector.

- 8-bit data types — A value of 0 in the first position is the NULL terminator for the character vector.
- 16-bit and 32-bit data types — The first position is the number of characters that follow.

If you connect an empty character vector to the XMT port on one of the send/receive subsystems, no characters are pushed onto the transmit FIFO. You can get this empty character vector by using one of these methods:

- To send a specific character vector occasionally, use the Product, Matrix Multiply block to multiply the entire character vector by either 0 or 1. In this case, the 0 or 1 value becomes a transmit enable. To optimize this operation, use a Demux block to extract the first element. Multiply just that element by 0 or 1, then use the Mux block to combine it again.
- Use a Manual Switch, Multipoint Switch, or Switch block. Configure the blocks for two ports to choose between different messages, with one of the choices being a vector of 0 values. The Switch block chooses only between vectors of the same width. Because the character vector length does not use the whole vector, you can pad your data to the same width with 0 values.

### See Also

ASCII Encode | ASCII Decode | FIFO Read | FIFO Write | FIFO Read HDRS | FIFO Read Binary | Modem Control | Modem Status | ASCII Decode V2 | Legacy Serial Read | Legacy Serial Setup | Legacy Serial Write | Legacy Serial Port | Legacy Serial Port F



## **More About**

- “RS-232 Serial Communication” on page 23-2




# **Serial Communications Support: Blocks**

---

## ASCII Encode

Convert Simulink values into `uint8` character vector



**Libraries:**  
Simulink Real-Time / RS232

### Description

The ASCII Encode block generates a `uint8` output vector that contains a NULL-terminated character vector based on a `printf` like format string. The data comes from the input ports.

### Ports

#### Input

**1** — Numbered ports that receive values to encode  
numeric

Values that the block encodes as a null-terminated character vector.

Data Types: `double` | `int8` | `uint8` | `int16` | `uint16` | `int32` | `uint32`

#### Output

**D** — Null-terminated character vector  
character vector

Generated `uint8` output vector that contains a NULL-terminated character vector.

### Parameters

**Format string** — Format specifiers for converting values to ASCII  
`%d\` (default) | `%c` | `%i` | `%o` | `%u` | `%x` | `%e` | `%f` | `%g`

Enter a `printf` like format string. For each format specifier such as `%d`, the block replaces the format specifier by the converted value in the corresponding input variable. The format specifiers follow the normal description for `printf`.

#### Programmatic Use

**Block Parameter:** `format`

**Number of variables** — Number of block inputs  
1 (default) | integer

The value on each port is inserted into the output character vector with the format specified in **Format string**.

**Programmatic Use****Block Parameter:** nvars**Max output string length** — Maximum length of converted character vector, in bytes

128 (default) | integer

The block allocates enough memory to support this length for the output port. When specifying this length, include the NULL termination on the character vector.

If the converted character vector exceeds this length, the block returns an error and does not write that character vector to the output port.

**Programmatic Use****Block Parameter:** maxLength**Variable types** — Simulink data types allowed for input ports

```
{'double'} (default) | {'int8'} | {'uint8'} | {'int16'} | {'uint16'} | {'int32'} |
{'uint32'}
```

A cell vector with the same number of elements as specified in **Number of variables** can specify a different data type for each input port. A single element is replicated. For example:

```
nvars=3
```

```
{ } — The three inputs are doubles.
```

```
{'uint8'} — The three inputs are uint8.
```

```
{'uint16', 'double', 'uint8'} — The first input is a uint16, the second input is a double,
and the third input is a uint8.
```

**Programmatic Use****Block Parameter:** vartypes

## Version History

**Introduced in R2020b**

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

ASCII Decode


**Topics**

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

## ASCII Decode

Parse ASCII character vector into Simulink values



**Libraries:**  
Simulink Real-Time / RS232

### Description

The ASCII Decode block parses an input character vector according to a format specifier similar to `scanf` and makes converted values available to the real-time application.

### Ports

#### Input

**D** — Input vector to parse  
character vector

The input vector can be either 8-bit or 16-bit and signed or unsigned. If the data format is 16-bit, the block ignores the upper 8 bits of each entry.

Data Types: `int8` | `uint8` | `int16` | `uint16`

#### Output

**1** — Numbered ports that send Simulink values  
numeric

Output ports corresponding to items in **Format string**.

#### Dependency

**Number of variables** determines the number of output ports.

Data Types: `double` | `int8` | `uint8` | `int16` | `uint16` | `int32` | `uint32`

### Parameters

**Format string** — Format specifier for parsing input vector  
`%d\r` (default) | `%c` | `%i` | `%o` | `%u` | `%x` | `%e` | `%f` | `%g`

Enter a `scanf` like format string. Each format specifier such as `%d` must match a corresponding part of the input vector. Literal strings in the format must match the first character plus the number of characters. The format specifiers follow the normal description for `scanf`.

An example format string is:

```
'alpha %d bravo %f\n'
```

**Programmatic Use****Block Parameter:** format**Number of variables** — Number of output ports for this block

1 (default) | integer

Enter the number of output ports for this block. For example:

If **Format string** has the value of `%xmore text%x` and the input vector for the block has `cdmabcde fgh90`, you must specify the value of the **Number of variables** parameter as 2.

The first variable is assigned the value `0xcd`. Next, the character vector `mabcde fgh` is considered a match to `more text` because:

- The first character for both character vectors is m.
- Both character vectors have the same number of characters.

The second variable is then assigned the value `0x90`. The character vector `mabcde fgh` does not have to match exactly the value of **Format string**. This behavior is different from the behavior for `scanf`, which requires an exact match.

**Programmatic Use****Block Parameter:** nvars**Variable types** — Simulink data types allowed for output ports

```
{'double'} (default) | {'int8'} | {'uint8'} | {'int16'} | {'uint16'} | {'int32'} |
{'uint32'}
```

A cell vector with the same number of elements as specified in **Number of variables** can specify a different data type for each output port. A single element is replicated. For example:

```
nvars=3
```

```
{ } — The three outputs are doubles.
```

```
{'uint8'} — The three outputs are uint8.
```

```
{'uint16', 'double', 'uint8'} — The first output is a uint16, the second output is a double,
and the third output is a uint8.
```

**Programmatic Use****Block Parameter:** varids

## Version History

**Introduced in R2020b**

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

ASCII Encode

**Topics**

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4



# ASCII Decode V2

Parse ASCII character vector into Simulink values



**Libraries:**  
Simulink Real-Time / RS232

## Description

The ASCII Decode block parses an input vector produced by one of the following:

- Serial port Receive block
- Serial port FIFO Read block
- ASCII Encode block

This block makes the converted values available to a real-time application. It assumes that the input vector was prepared using an output format specifier similar to `printf` and uses an input format specifier similar to `scanf`.

This block generates inline code for the target computer. You cannot use it for Simulink simulation.

## Ports

### Input

**Data** — Input vector to parse  
character vector

The input vector can be either 8-bit or 16-bit and signed or unsigned. If the data format is 16-bit, the block ignores the upper 8 bits of each entry.

Data Types: `int8` | `uint8` | `int16` | `uint16`

### Output

**cnt** — Number of format specifiers satisfied by input  
integer

cnt receives the number of format specifiers satisfied by the input character vector.

**Value** — Inlined ports that send Simulink values  
numeric

Output ports corresponding to items in **Format**.

This block generates inline code for the target computer. You cannot use it for Simulink simulation.

Data Types: `single` | `double` | `int8` | `uint8` | `uint16` | `int16` | `int32` | `uint32`

## Parameters

**Format** — Format specifier for parsing input vector  
'%f\n' (default) | %c | %d | %i | %o | %u | %x | %e | %g

Enter a `scanf` like format string. Each format specifier such as `%d` must match a corresponding part of the input vector. Literal strings in the format must match the characters in the input vector. The format specifiers follow the normal description for `scanf`. The specifiers must be enclosed in single quotes. Failure to include these quotes causes simulation failures.

An example format string is:

```
'alpha %d bravo %f\n'
```

In this example, the data from the FIFO read is 'alpha 5'. In this case, `cnt` is 1 and the second output is unchanged from the last time both were found in a character vector. If the model expects 2 values, and `cnt` is less than 2, the model detects an error in the data.

### Programmatic Use

**Block Parameter:** format

## Version History

Introduced in R2020b

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also

### Topics

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

# FIFO Read

Read simple data streams



**Libraries:**  
Simulink Real-Time / RS232

## Description

The FIFO Read block is the read side of a FIFO read/write pair. You use this block to parse simple data streams. The block functions in two modes that you set by using the **Read to delimiter** check box.

- If you select the **Read to delimiter** check box, the block reads only elements if the specified delimiter has been written to the FIFO Write block. If the delimiter is found, the block returns elements up to and including the delimiter in the output vector. If the delimiter is not found, the block returns a zero-length vector, as determined by the data type. (If you have a zero-length vector, you can have your model perform a particular operation or ignore the case.)
- If you clear the **Read to delimiter** check box, the block returns elements between **Minimum read size** and the smaller of the number of elements currently in the FIFO and **Maximum read size**.

When performing ASCII reads, select the **Read to delimiter** check box. When performing binary reads, clear this check box.

Here are some examples of how you can set up the FIFO Read block:

- **Transmit side of the interrupt service routine** — If the interrupt reason is not an empty hardware FIFO on the UART, the maximum input port receives a value of 0. If the hardware FIFO is empty, it receives the size of the hardware FIFO. The minimum input port receives the constant value of 1.
- **Receive side of the interrupt service routine** — The typical case with ASCII data has the minimum and maximum input ports disabled. The **Read to delimiter parameter** check box is selected and the **Delimiter** parameter has the value of carriage return or line feed. The value of the **Maximum read size** parameter is large (along the order of the FIFO size) and the value of **Minimum read size** parameter is 1. In this form, the driver acts like a nonblocking read line.

An alternate receive-side configuration for fixed-length binary blocks of data has the value of the **Maximum read size** and **Minimum read size** parameters set to the fixed length of the block. The **Read to delimiter** parameter is not selected.

For complex data streams, consider using the FIFO Read HDRS and FIFO Read Binary blocks. For guidelines on when to use these blocks, see “RS-232 FIFO Read Blocks” on page 23-6.

## Ports

### Input

**F** — FIFO from which to read data  
`serialfifo_ptr`

Connects to the software FIFO containing data read from the serial port.

**MAX** — Maximum number of bytes to read from FIFO  
`integer`

The maximum number of bytes to return from the block.

### Dependency

To make this port visible, set parameter **Max and Min read size ports**.

**MIN** — Minimum number of bytes to read from FIFO  
`integer`

The minimum number of bytes to return from the block.

### Dependency

To make this port visible, set parameter **Max and Min read size ports**.

### Output

**D** — Parsed data read from FIFO  
`vector`

Vector containing the parsed data read from the FIFO.

### Dependency

To determine the data type of this vector, set the parameter **Output vector type**.

Data Types: `int8 | uint8 | int16 | uint16 | int32 | uint32`

**ENA** — Pass value of MAX through  
`integer`

Passes the value of port MAX through to the block that reads the ENA port.

### Dependency

To make this port visible, set parameters **Max and Min read size ports** and **Enable passthrough**.

## Parameters

**Maximum read size** — Maximum number of characters returned by block  
`1024 (default) | integer`

Specify the maximum number of characters for this block to return. The resulting vector size is one more than this maximum number of characters. This block indicates the number of characters being returned by using the extra element as:

- A null terminator for the 8-bit data types
- The character count for the 16-bit and 32-bit data types

Enter a large enough number. If this number is too small, the block cannot return anything. For example, if you enter the value 10, but on execution the FIFO contains 11 characters plus the null terminator, the block does not return any characters. If the FIFO contains 5, the block returns 5 characters plus the null terminator.

If you select the parameter **Max and Min read size ports**, the block interprets the value input on port MAX as the maximum number of characters to return. The actual maximum number of characters to return is the smaller of the value on port MAX and the maximum read size in the block parameters. Use this value in binary mode when you have not selected the **Read to delimiter** check box.

**Programmatic Use**

**Block Parameter:** maxsize

**Minimum read size** — Minimum number of characters returned by block

1 (default) | integer

Enter the smallest read size in bytes. The FIFO must contain at least this number of elements before elements are returned.

If you select the parameter **Max and Min read size ports**, the value of port MIN supersedes this value.

**Programmatic Use**

**Block Parameter:** minsize

**Read to delimiter** — Return delimited element sets

on (default) | off

Select this check box to enable the return of element sets that terminate with the **Delimiter** value. Use this parameter when working with character-based elements.

**Programmatic Use**

**Block Parameter:** usedelimiter

**Delimiter** — Terminator value for delimited element sets

13 (default) | uint

Enter the decimal value for an 8-bit input terminator. This parameter specifies the value on which a FIFO read operation terminates. This value works with the **Read to delimiter** parameter. By default, this block looks for a carriage return. It returns characters only when one is found. For reference, the decimal value of a carriage return is 13 and a line feed is 10.

**Programmatic Use**

**Block Parameter:** delimiter

**Output vector type** — Specify output data type

8 bit uint null terminated (default) | count+32 bit int | count+32 bit uint | count+16 bit int | count+16 bit uint | 8 bit int null terminated

The 8-bit data types produce a NULL-terminated character vector in the output vector. For 16-bit and 32-bit data types, the first element contains the number of elements to expect in the rest of the output vector.

**Programmatic Use****Block Parameter:** outputtype**Max and Min read size ports** — Enable maximum and minimum input ports

off (default) | on

When you select this check box:

- The value from input port MAX is the maximum number of characters to be removed from the FIFO. If this number exceeds the value of **Maximum read size**, the block disregards the value from the maximum input port. It takes the value of **Maximum read size** as the maximum number of characters to be removed from the FIFO.
- The value from the input port MIN is the minimum number of characters that the FIFO must contain before elements can be returned. This value supersedes the value set with the **Minimum read size** parameter.

This setting makes the input ports MAX and MIN visible.

**Programmatic Use****Block Parameter:** enable**Enable passthrough** — Enable passthrough of MAX value

off (default) | on

Select this check box to pass the value of input port MAX through to output port ENA.

**Dependency**

Causes output port ENA to become visible.

**Programmatic Use****Block Parameter:** enableout**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use**

sampletime

## Version History

Introduced in R2020b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

FIFO Write

**Topics**

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

## FIFO Write

Write simple data streams



**Libraries:**  
Simulink Real-Time / RS232

### Description

The FIFO Write block is the write side of a FIFO read/write pair. Use this block to generate simple data streams.

### Ports

#### Input

**D** — Data to write to FIFO  
vector

Vector containing the data to write to the FIFO.

#### Dependency

To determine the data type of this vector, set the parameter **Input vector type**.

Data Types: `int8` | `uint8` | `int16` | `uint16` | `int32` | `uint32`

#### Output

**F** — FIFO vector  
`serialfoptr`

Connects to the FIFO that writes data to the serial port.

**DP** — True if new data is present in the FIFO  
`true` | `false`

If data is present in the FIFO, returns `true`.

#### Dependency

To make this port visible, set parameters **Max and Min read size ports** and **Enable passthrough**.

### Parameters

**Size** — Size of FIFO, in bytes  
`1024` (default) | integer

Enter the number of elements that can be held in the FIFO at one time. If a write operation to the FIFO causes the number of elements to exceed **Size**, an error occurs.



**Programmatic Use****Block Parameter:** size**Input vector type** — Specify input data type

8 bit uint null terminated (default) | count+32 bit int | count+32 bit uint | count+16 bit int | count+16 bit uint | 8 bit int null terminated

For the 16-bit and 32-bit data types, include as first element the number of elements to expect in the rest of the input vector. The count controls how many bytes that the block copies into the FIFO. The block does not copy the count itself into the FIFO.

For the 8-bit data types, provide a NULL-terminated character vector in the output vector. The block copies data into the FIFO up to, but not including, the NULL terminator.

For more information, see “RS-232 Legacy Drivers” on page 23-4.

**Programmatic Use****Block Parameter:** inputtype**Data present output** — Enables output DP

off (default) | on

Select this check box to create the Boolean output DP. If data is present in the FIFO, DP becomes true. The transmit side of the send/receive subsystem uses this output. This output is given to the Enable TX block, which enables the transmitter buffer empty interrupt.

This setting makes the output port DP visible.

**Programmatic Use****Block Parameter:** present**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use**

sampletime

**ID** — Identifier for overflow messages

character vector

Enter a user-defined identifier for FIFO overflow messages.

**Programmatic Use****Block Parameter:** id

## Version History

**Introduced in R2020b**

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

### **See Also**

FIFO Read

### **Topics**

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

# FIFO Read HDRS

Read multiple ASCII data streams according to header information



## Libraries:

Simulink Real-Time / RS232

## Description

The FIFO Read HDRS block identifies and separates ASCII data streams that have embedded identifiers.

The data following a particular header can have varying lengths, but has a common termination marker such as <CR><LF>. Although you can attain this same functionality with the FIFO Read block, it requires a complicated state machine with this behavior:

- If the same header arrives in the FIFO more than once after the block was last executed, the block returns the latest instance of the header. The block catches up with data that arrives faster than the block executes.
- If a header arrives in the FIFO that does not match an item in the headers list, the block discards the message.
- If bytes arrive in the FIFO that do not match a header, the block interprets the message as having an unspecified header. The block skips these bytes.

The `matlab/toolbox/slrealtime/examples` folder contains examples that show how to use the FIFO Read HDRS block: `slrt_ex_serialbaseboardasciitest` and `slrt_ex_serialbaseboardasciisplit`.

## Ports

### Input

**F** — FIFO from which to read data  
`serialfifoptr`

Connects to the software FIFO containing data read from the serial port.

**E** — Enable read from FIFO  
`true | false`

If `true`, read from FIFO.

### Dependency

To make this port visible, set parameter **Enable input**.

## Output

**1** — Numbered output streams, one per header  
vector

Vectors containing the parsed data read from the FIFO. Each output corresponds to one of the headers.

### Dependency

To determine the data type of this vector, set the parameter **Output vector type**.

Data Types: `int8 | uint8 | int16 | uint16 | int32 | uint32`

## Parameters

**Header** — Search targets in ASCII data stream  
cell array of character vector

Enter the headers that you want the block to look for in a block of data from the FIFO. Enter each header in single quotes as an element in a cell array.

### Programmatic Use

**Block Parameter:** `hdr`

**Terminating string** — Characters that end data stream  
`[13 10]` (default) | `[integer]`

Enter the terminating character vector for the data. Enter the characters defining the end of character vector, typically one or two characters.

### Programmatic Use

**Block Parameter:** `nterm`

**Output behavior** — Behavior when no new data

`Zero output if no new data` (default) | `Hold last output if no new data`

From the list, select the behavior of the block if the FIFO has not received new data:

- `Hold last output if no new data` — Block keeps the output from the last FIFO message.
- `Zero output if no new data` — Block overwrites the first element of the output with 0.

### Programmatic Use

**Block Parameter:** `hold`

**Enable input** — Enable read from FIFO

`off` (default) | `on`

To create an input port that enables or disables the read operation, select this check box. The input port takes a Boolean signal.

### Dependency

Causes input port E to become visible.

**Programmatic Use****Block Parameter:** enable**Maximum read size** — Maximum number of characters returned by block

1024 (default) | integer

Specify the maximum number of characters for this block to return. The resulting vector size is one more than this maximum number of characters. This block indicates the number of characters being returned by using the extra element as:

- A NULL terminator for the 8-bit data types
- The character count for the 16-bit and 32-bit data types

Enter a large enough number. If this number is too small, the block cannot return anything. For example, if you enter the value 10, but on execution the FIFO contains 11 characters plus the null terminator, the block does not return any characters. If it contains 5, the block returns 5 characters plus the NULL terminator.

**Programmatic Use****Block Parameter:** maxsize**Output vector type** — Specify output data type

8 bit uint null terminated (default) | count+32 bit int | count+32 bit uint | count+16 bit int | count+16 bit uint | 8 bit int null terminated

The 8-bit data types produce a NULL-terminated character vector in the output vector. For 16-bit and 32-bit data types, the first element contains the number of elements to expect in the rest of the output vector.

**Programmatic Use****Block Parameter:** outputtype**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use**

sampletime

## Version History

Introduced in R2020b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

**See Also**

FIFO Read | FIFO Write | FIFO Read Binary

**Topics**

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

# FIFO Read Binary

Read multiple binary data streams according to header information



**Libraries:**  
Simulink Real-Time / RS232

## Description

The FIFO Read Binary block reads multiple binary headers from a FIFO.

This block identifies and separates data by finding unique byte sequences (headers) that mark the data. Each header indicates the start of a fixed-length binary message. If the same header arrived in the FIFO more than once since the block was last executed, the block discards the older data. It then returns the latest instance of the header. The block catches up with data that arrives faster than the block executes.

The `matlab/toolbox/slrealtime/examples` folder contains examples that show how to use the FIFO Read HDRS block: `slrt_ex_serialbaseboardbinarytest` and `slrt_ex_serialbaseboardbinarysplit`.

## Ports

### Input

**F** — FIFO from which to read data  
`serialfifoptr`

Connects to the software FIFO containing data read from the serial port.

**E** — Enable read from FIFO  
`true | false`

If `true`, read from FIFO.

### Dependency

To make this port visible, set parameter **Enable input**.

### Output

**1** — Numbered output streams, one per header  
`vector`

Vectors containing the parsed data read from the FIFO. Each output corresponds to one of the headers.

### Dependency

To determine the data type of this vector, set the parameter **Output vector type**.

Data Types: `int8` | `uint8` | `int16` | `uint16` | `int32` | `uint32`

## Parameters

**Header** — Search targets in binary data stream  
cell array of binary data

Enter the headers that you want the block to look for in a block of data from the FIFO. Enter each header as an element in a cell array either as a quoted character vector or a concatenation with `char(val)` for non-printable byte patterns.

### Programmatic Use

**Block Parameter:** `hdr`

**Message Lengths** — Message lengths, in bytes  
`1024` (default) | integer

Enter the message length, in bytes. Include the header in the length.

### Programmatic Use

**Block Parameter:** `lengths`

**Output behavior** — Behavior when no new data

`Zero output if no new data` (default) | `Hold last output if no new data`

From the list, select the behavior of the block if the FIFO has not received new data:

- `Hold last output if no new data` — Block keeps the output from the last FIFO message.
- `Zero output if no new data` — Block overwrites the first element of the output with 0.

### Programmatic Use

**Block Parameter:** `hold`

**Enable input** — Enable read from FIFO

`off` (default) | `on`

To create an input port that enables or disables the read operation, select this check box. The input port takes a Boolean signal.

### Dependency

Causes input port E to become visible.

### Programmatic Use

**Block Parameter:** `enable`

**Maximum read size** — Maximum number of characters returned by block

`1024` (default) | integer

Specify the maximum number of characters for this block to return. The resulting vector size is one more than this maximum number of characters. This block indicates the number of characters being returned by using the extra element as:

- A NULL terminator for the 8-bit data types
- The character count for the 16-bit and 32-bit data types



Enter a large enough number. If this number is too small, the block cannot return anything. For example, if you enter the value 10, but on execution the FIFO contains 11 characters plus the null terminator, the block does not return any characters. If it contains 5, the block returns 5 characters plus the NULL terminator.

**Programmatic Use**

**Block Parameter:** maxsize

**Output vector type** — Specify output data type

8 bit uint null terminated (default) | count+32 bit int | count+32 bit uint | count+16 bit int | count+16 bit uint | 8 bit int null terminated

The 8-bit data types produce a NULL-terminated character vector in the output vector. For 16-bit and 32-bit data types, the first element contains the number of elements to expect in the rest of the output vector.

**Programmatic Use**

**Block Parameter:** outputtype

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use**

sampletime

## Version History

Introduced in R2020b

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also


### Topics

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

## Modem Control

Control state of RTS and DTR output lines on serial port



### Libraries:

Simulink Real-Time / RS232 / Mainboard

## Description

The Modem Control block controls the state of either or both of the Request To Send (RTS) and Data Terminal Ready (DTR) output lines on the serial port. To choose which output lines to control, select the **RTS** and **DTR** parameters.

## Ports

### Input

**RTS** — Level-sensitive signal for setting ready-to-send line

`double`

The behavior of the block is:

- $RTS > 0.5$  — The block asserts the RTS control bit to `true`. The output goes to a positive voltage.
- $RTS \leq 0.5$  — The block asserts the RTS control bit to `false`. The output goes to a negative voltage.

### Dependency

If the **RTS** parameter is `off`, this input has no effect.

**DTR** — Level-sensitive signal for setting data-terminal-ready line

`double`

The behavior of the block is:

- $DTR > 0.5$  — The block asserts the DTR control bit to `true`. The output goes to a positive voltage.
- $DTR \leq 0.5$  — The block asserts the DTR control bit to `false`. The output goes to a negative voltage.

### Dependency

If the **DTR** parameter is `off`, this input has no effect.

## Parameters

**RTS** — Enable control of RTS line for serial device

`on (default) | off`

Select this check box to control the RTS line for this board.

**Programmatic Use**

rts

**DTR** — Enable control of DTR line for serial device  
on (default) | off

Select this check box to control the DTR line for this board.

**Programmatic Use**

dtr

**Serial port** — Select serial port

Legacy Serial Port 1 (default) | .. | Legacy Serial Port 8 | USB Serial Port 1 | .. | USB Serial Port 8

Selects the RS232 serial port for communications. If using USB-to-serial adapters, the target computer detects these adapters as `serusb1`, `serusb2`, and so on in the order that the adapters are connected to the serial devices. The order of port assignment is retained through the power cycle of the target computer or serial device if there is no change in the connections to the ports.

**Programmatic Use**

port

## Version History

Introduced in R2020b

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

[Legacy Serial Read](#) | [Legacy Serial Setup](#) | [Legacy Serial Write](#) | [Modem Status](#)


**Topics**

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

## Modem Status

Return state of modem control lines



### Libraries:

Simulink Real-Time / RS232 / Mainboard

## Description

The Modem Status block reads the state of the input modem control lines.

This block has outputs of type `Boolean`. If the input voltage is positive, the output is true. If the input voltage is negative, the output is false.

## Ports

### Output

**CTS** — Status of clear to send line

`true` | `false`

If `true`, the modem is ready to receive data.

### Dependency

To make this output visible, select the **CTS** parameter.

**DSR** — Status of data set ready line

`true` | `false`

If `true`, the modem is ready to send and receive data.

### Dependency

To make this output visible, select the **DSR** parameter.

**DCD** — Status of data carrier detect line

`true` | `false`

If `true`, the modem is receiving a carrier from a remote device.

### Dependency

To make this output visible, select the **DCD** parameter.

## Parameters

**CTS** — Enables clear to send status output

`on` (default) | `off`

Select this check box to monitor the CTS line of the modem.

Selecting this parameter makes the CTS port visible.

**Programmatic Use**

cts

**DSR** — Enables data set ready status output

on (default) | off

Select this check box to monitor the DSR line of the modem.

Selecting this parameter makes the DSR port visible.

**Programmatic Use**

dsr

**DCD** — Enables data carrier detect status output

on (default) | off

Select this check box to monitor the DCD line of the modem.

Selecting this parameter makes the DCD port visible.

**Programmatic Use**

dcd

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use**

sampletime

**Serial port** — Select serial port

Legacy Serial Port 1 (default) | .. | Legacy Serial Port 8 | USB Serial Port 1 | .. | USB Serial Port 8

Selects the RS232 serial port for communications. If using USB-to-serial adapters, the target computer detects these adapters as `serusb1`, `serusb2`, and so on in the order that the adapters are connected to the serial devices. The order of port assignment is retained through the power cycle of the target computer or serial device if there is no change in the connections to the ports.

**Programmatic Use**

port

## Version History

Introduced in R2020b

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

### **See Also**

Legacy Serial Read | Legacy Serial Setup | Legacy Serial Write | Modem Control


### **Topics**

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

# Legacy Serial Read

Read input data for baseboard serial communications



**Libraries:**  
Simulink Real-Time / RS232 / Mainboard

## Description

The Legacy Serial Read block reads input data for baseboard serial communications.

## Ports

### Output

**Output** — Data from serial port read  
serial data

The Output port provides the data from the serial port read.

## Parameters

**Serial port** — Select serial port

Legacy Serial Port 1 (default) | .. | Legacy Serial Port 8 | USB Serial Port 1 | .. | USB Serial Port 8

Select the RS232 serial port for communications. If using USB-to-serial adapters, the target computer detects these adapters as `serusb1`, `serusb2`, and so on in the order that the adapters are connected to the serial devices. The order of port assignment is retained through the power cycle of the target computer or serial device if there is no change in the connections to the ports.

### Programmatic Use

port

**Max Read Count** — Select maximum word read count

51 (default) | int

Use this value to select the maximum word read count.

### Programmatic Use

count

**Output Datatype** — Select output data type

8 bit uint null terminated (default) | 8 bit int null terminated | count+16 bit uint | count+16 bit int | count+32 bit uint | count+32 bit int

Use this value to select the output data type.

**Programmatic Use**

dtype

**SampleTime** — Select sample time in seconds

.01 (default) | double

Use this value to select the sample time in seconds.

**Programmatic Use**

sampletime

## Version History

**Introduced in R2020b**

### **R2021b: USB to Serial for RS232 Blocks**

The RS232 mainboard blocks support connecting USB serial adapter ports. The `Serial port` parameter of the Legacy Serial Read block, Legacy Serial Write block, Legacy Serial Setup block, Legacy Serial Port block, and Legacy Serial Port F block means that you can select a USB Serial Port or a Legacy Serial Port.

## Extended Capabilities

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

Legacy Serial Setup | Legacy Serial Write | Modem Control | Modem Status

### **Topics**


“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4



# Legacy Serial Setup

Set up baseboard serial communications



**Libraries:**  
Simulink Real-Time / RS232 / Mainboard

## Description

The Legacy Serial Setup block sets up baseboard serial communications.

## Parameters

**Serial port** — Select serial port

Legacy Serial Port 1 (default) | .. | Legacy Serial Port 8 | USB Serial Port 1 | .. | USB Serial Port 8

Select the RS232 serial port for communications. If using USB-to-serial adapters, the target computer detects these adapters as `serusb1`, `serusb2`, and so on in the order that the adapters are connected to the serial devices. The order of port assignment is retained through the power cycle of the target computer or serial device if there is no change in the connections to the ports.

**Programmatic Use**

port

**Baud rate** — Select serial port baud rate

115200 (default) | 57600 | 38400 | 19200 | 9600 | 4800 | 2400 | 1200 | 600 | 300 | 110

Use this value to select the serial port baud rate.

**Programmatic Use**

baud

**Number of data bits** — Select serial port data bits

8 (default) | 7 | 6 | 5

Use this value to select the number of serial port data bits.

**Programmatic Use**

width

**Number of stop bits** — Select serial port stop bits

1 (default) | 2

Use this value to select the number of serial port stop bits.

**Programmatic Use**

nstop

**Parity** — Select serial port parity  
None (default) | Even | Odd | Mark | Space

Use this value to select serial port parity.

**Programmatic Use**

parity

**Enable auto RTX/CTS** — Select serial port RTX/CTS mode  
off (default) | on

Use this value to select the serial port RTX/CTS mode.

**Programmatic Use**

ctsmode

## Version History

### Introduced in R2020b

#### R2021b: USB to Serial for RS232 Blocks

The RS232 mainboard blocks support connecting USB serial adapter ports. The `Serial port` parameter of the Legacy Serial Read block, Legacy Serial Write block, Legacy Serial Setup block, Legacy Serial Port block, and Legacy Serial Port F block means that you can select a USB Serial Port or a Legacy Serial Port.

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also

Legacy Serial Read | Legacy Serial Write | Modem Control | Modem Status


### Topics

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

# Legacy Serial Write

Write output data for baseboard serial communications



## Libraries:

Simulink Real-Time / RS232 / Mainboard

## Description

The Legacy Serial Write block writes output data for baseboard serial communications.

## Ports

### Input

**Input** — Data for serial port write  
serial data

The Input port contains the data to write for the serial port.

## Parameters

**Serial port** — Select serial port

Legacy Serial Port 1 (default) | .. | Legacy Serial Port 8 | USB Serial Port 1 | .. | USB Serial Port 8

Select the RS232 serial port for communications. If using USB-to-serial adapters, the target computer detects these adapters as `serusb1`, `serusb2`, and so on in the order that the adapters are connected to the serial devices. The order of port assignment is retained through the power cycle of the target computer or serial device if there is no change in the connections to the ports.

### Programmatic Use

port

**Output Datatype** — Select output data type

8 bit uint null terminated (default) | 8 bit int null terminated | count+16 bit uint | count+16 bit int | count+32 bit uint | count+32 bit int

Use this value to select the output data type.

### Programmatic Use

dtype

**SampleTime** — Select sample time in seconds

.01 (default) | double

Use this value to select the sample time in seconds.

**Programmatic Use**

sampletime

## Version History

Introduced in R2020b

**R2021b: USB to Serial for RS232 Blocks**

The RS232 mainboard blocks support connecting USB serial adapter ports. The `Serial port` parameter of the Legacy Serial Read block, Legacy Serial Write block, Legacy Serial Setup block, Legacy Serial Port block, and Legacy Serial Port F block means that you can select a `USB Serial Port` or a `Legacy Serial Port`.

## Extended Capabilities

**C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## See Also

Legacy Serial Read | Legacy Serial Setup | Modem Control | Modem Status

**Topics**

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4

# Legacy Serial Port

Send and receive data over mainboard baseboard serial port



## Libraries:

Simulink Real-Time / RS232 / Mainboard

## Description

The Send/Receive block sets up the serial interface to send and receive basic character streams. This block has basic First In, First Out (FIFO) Read blocks inside the subsystem. It generates output as an array of packed integers (settable at 8 bits, 16 bits, or 32 bits). Characters appear in the lower byte and received status information appears in the upper byte.

## Ports

### Input

**XMT** — Vector of data to transmit  
vector

Vector of the data used to transmit over the port.

Data Types: int8 | int16 | int32 | uint8 | uint16 | uint32

### Output

**RCV** — Vector of data received over serial port  
vector

Vector containing data that has been received from serial port.

Data Types: int8 | int16 | int32 | uint8 | uint16 | uint32

## Parameters

**Serial port** — Port that is being accessed

Legacy Serial Port 1 (default) | .. | Legacy Serial Port 8 | USB Serial Port 1 | .. | USB Serial Port 8

This parameter specifies the port for which you want to view or modify parameters. If using USB-to-serial adapters, the target computer detects these adapters as `serusb1`, `serusb2`, and so on in the order that the adapters are connected to the serial devices. The order of port assignment is retained through the power cycle of the target computer or serial device if there is no change in the connections to the ports.

### Programmatic Use

**Block Parameter:** port

**Baud rate** — Baud for transferring data

115200 (default) | 57600 | 38400 | 19200 | 9600 | 4800 | 2400 | 1200 | 600 | 300 | 110

Select a baud for transmitting and receiving data through the modem.

**Programmatic Use**

**Block Parameter:** baud

**Data bits** — Number of bits per character

8 (default) | 7 | 6 | 5

Select the number of bits that encode a character.

**Programmatic Use**

**Block Parameter:** width

**Stop bits** — Number of stop bits for port

1 (default) | 2

Select the number of stop bits for the character stream.

**Programmatic Use**

**Block Parameter:** nstop

**Parity** — Parity for checking data transfer

None (default) | Even | Odd | Mark | Space

Select a parity for checking data integrity.

**Programmatic Use**

**Block Parameter:** parity

**Enable auto RTS/CTS** — Enable RTS/CTS handshake

off (default) | on

To enable the Request To Send/Clear To Send (RTS/CTS) handshake of the Universal Asynchronous Receiver-Transmitter (UART) for flow control, select this check box. Serial controllers use the RTS/CTS handshake to prevent data loss due to hardware FIFO overflow on the device that you are sending to.

Usually, the interrupt service routine executes quickly enough to empty the FIFO. If your model gets FIFO overruns, select this check box.

**Programmatic Use**

**Block Parameter:** ctsmode

**Max Output count** — Maximum number of elements for block to return

1024 (default) | integer

Enter the maximum number of elements that you want returned by a single call to this block. The block uses this parameter to set the output vector width.

If you select the **Read to delimiter** check box and if the block does not find the delimiter before it reads **Receive maximum read** characters, the output vector is empty.

**Programmatic Use**

**Block Parameter:** maxread

**Min Output count** — Minimum number of elements for block to return

1 (default) | integer

Enter the minimum number of characters to read. If the FIFO does not contain at least this number of characters, the output vector is empty.

**Programmatic Use**

**Block Parameter:** `minread`

**Read to delimiter** — Return characters including message delimiter

`on (default) | off`

For the block to return all characters in the FIFO, up to and including the specified delimiter, select this check box.

If the buffer has errors, such as framing errors, the modem returns characters regardless of the presence of the delimiter. These returned characters help diagnose errors such as mismatched baud rates.

If the block does not find the delimiter before it reads **Receive maximum read** characters, the output vector is empty.

**Programmatic Use**

**Block Parameter:** `usedelimiter`

**Delimiter** — Numeric value of message delimiter

`13 (default) | integer`

Enter the numeric value of the character that is the message delimiter. Any value from 0 to 255 is valid. The common case looks for 10 (line feed) or 13 (carriage return).

**Programmatic Use**

**Block Parameter:** `delimiter`

**Receive data type** — Data type of receiver

`8 bit int null terminated (default) | 8 bit uint null terminated | count+16 bit int | count+16 bit uint | count+32 bit int | count+32 bit uint`

This parameter specifies the data type of the receiver. The 8-bit data types produce a NULL-terminated character vector in the output vector.

For 16-bit and 32-bit data types, the first element contains the number of valid elements in the rest of the output vector.

For 8-bit data types, only the character data is in the output vector, and a NULL terminator is appended. The 16-bit or 32-bit wide data types cause the error status from the UART to be placed in the second byte of each data element. (The error status contains the parity, overrun, framing, and break bits.) The character data is in the bottom 8 bits of each element. The first element of the vector contains the number of data elements that follow.

**Programmatic Use**

**Block Parameter:** `odtype`

**Receive FIFO size** — FIFO size in bytes

`1024 (default)`

This parameter specifies the receive FIFO size in bytes.

Example: `1024`

**Programmatic Use****Block Parameter:** `fifosize`Data Types: `int32`**Transmit data type** — Data type of transmitter`count+32 bit int (default) | count+32 bit uint | count+16 bit int | count+16 bit uint  
| 8 bit int null terminated | 8 bit uint null terminated`

This parameter specifies the data type of the transmitter. The 8-bit data types require a NULL-terminated character vector in the input vector.

The 16-bit and 32-bit data types reserve the first full element to contain the number of elements to expect in the rest of the input vector. Only the low-order byte of each data element is sent. Setting this data type enables a wider data type to hold the bytes.

If the data stream requires a NULL byte, select one of the 16-bit or 32-bit data types. Because the 8-bit data types are NULL-terminated character vectors, the NULL byte terminates the character vector.

**Programmatic Use****Block Parameter:** `idtype`**Sample Time** — Sample time`-1 (default) | numeric`

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited.

**Programmatic Use****Block Parameter:** `sampletime`

## Version History

**Introduced in R2008a****R2021b: USB to Serial for RS232 Blocks**

The RS232 mainboard blocks support connecting USB serial adapter ports. The `Serial port` parameter of the Legacy Serial Read block, Legacy Serial Write block, Legacy Serial Setup block, Legacy Serial Port block, and Legacy Serial Port F block means that you can select a USB Serial Port or a Legacy Serial Port.

## See Also

Legacy Serial Port F

**Topics**


"RS-232 Serial Communication" on page 23-2

"RS-232 Legacy Drivers" on page 23-4



# Legacy Serial Port F

Send and receive data over mainboard baseboard serial port with FIFO



## Libraries:

Simulink Real-Time / RS232 / Mainboard

## Description

The Send/Receive FIFO block sets up the serial interface to send and receive character and binary streams. It transmits input data as does the Send/Receive block, but it propagates received data through First In, First Out (FIFO) outputs.

A model that contains a Send/Receive FIFO block and the FIFO Read block provides the same capability as the Send/Receive block. A model that contains a Send/Receive FIFO block and a FIFO Read HDRS or FIFO Read Binary block provides greater capability than the Send/Receive block.

## Ports

### Input

**XMT** — Vector of data to transmit  
vector

Vector of the data used to transmit over the port.

Data Types: `int8` | `int16` | `int32` | `uint8` | `uint16` | `uint32`

### Output

**FIFO** — FIFO of data received over serial port  
`serialfifoptr`

First In, First Out (FIFO) containing data that has been received from the serial port.

## Parameters

**Serial port** — Port that is being accessed

`Legacy Serial Port 1 (default)` | .. | `Legacy Serial Port 8` | `USB Serial Port 1` | .. | `USB Serial Port 8`

This parameter specifies the port for which you want to view or modify parameters. If using USB-to-serial adapters, the target computer detects these adapters as `serusb1`, `serusb2`, and so on in the order that the adapters are connected to the serial devices. The order of port assignment is retained through the power cycle of the target computer or serial device if there is no change in the connections to the ports.

### Programmatic Use

**Block Parameter:** port

**Baud rate** — Baud for transferring data

115200 (default) | 57600 | 38400 | 19200 | 9600 | 4800 | 2400 | 1200 | 600 | 300 | 110

Select a baud for transmitting and receiving data through the modem.

**Programmatic Use**

**Block Parameter:** baud

**Data bits** — Number of bits per character

8 (default) | 7 | 6 | 5

Select the number of bits that encode a character.

**Programmatic Use**

**Block Parameter:** width

**Stop bits** — Number of stop bits for port

1 (default) | 2

Select the number of stop bits for the character stream.

**Programmatic Use**

**Block Parameter:** nstop

**Parity** — Parity for checking data transfer

None (default) | Even | Odd | Mark | Space

Select a parity for checking data integrity.

**Programmatic Use**

**Block Parameter:** parity

**Enable auto RTS/CTS** — Enable RTS/CTS handshake

off (default) | on

To enable the Request To Send/Clear To Send (RTS/CTS) handshake of the Universal Asynchronous Receiver-Transmitter (UART) for flow control, select this check box. Serial controllers use the RTS/CTS handshake to prevent data loss due to hardware FIFO overflow on the device that you are sending to.

Usually, the interrupt service routine executes quickly enough to empty the FIFO. If your model gets FIFO overruns, select this check box.

**Programmatic Use**

**Block Parameter:** ctsmode

**Port to modify** — Port that is being accessed

1 (default) | 2

This parameter specifies the port for which you want to view or modify parameters. On the Simulink block, the upper port is port 1 and the lower port is port 2.

**Programmatic Use**

**Block Parameter:** port

**Receive FIFO size** — FIFO size in bytes

1024 (default)

This parameter specifies the receive FIFO size in bytes.

Example: 1024

**Programmatic Use**

**Block Parameter:** fifosize

Data Types: int32

**Transmit data type** — Data type of transmitter

count+32 bit int (default) | count+32 bit uint | count+16 bit int | count+16 bit uint  
| 8 bit int null terminated | 8 bit uint null terminated

This parameter specifies the data type of the transmitter. The 8-bit data types require a NULL-terminated character vector in the input vector.

The 16-bit and 32-bit data types reserve the first full element to contain the number of elements to expect in the rest of the input vector. Only the low-order byte of each data element is sent. Setting this data type enables a wider data type to hold the bytes.

If the data stream requires a NULL byte, select one of the 16-bit or 32-bit data types. Because the 8-bit data types are NULL-terminated character vectors, the NULL byte terminates the character vector.

**Programmatic Use**

**Block Parameter:** idtype

**Sample Time** — Sample time

- 1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. - 1 means that the sample time is inherited.

**Programmatic Use**

**Block Parameter:** sampletime

## Version History

**Introduced in R2008a**

### **R2021b: USB to Serial for RS232 Blocks**

The RS232 mainboard blocks support connecting USB serial adapter ports. The `Serial port` parameter of the Legacy Serial Read block, Legacy Serial Write block, Legacy Serial Setup block, Legacy Serial Port block, and Legacy Serial Port F block means that you can select a USB Serial Port or a Legacy Serial Port.

## See Also

FIFO Read | FIFO Read HDRS | FIFO Read Binary | Legacy Serial Port

## Topics

“RS-232 Serial Communication” on page 23-2

“RS-232 Legacy Drivers” on page 23-4



# Target Management




# Target Management Blocks

---

The Simulink Real-Time target management blocks support target computer management functions.

## SLRT Overload Options

Select CPU overload options




### Libraries:

Simulink Real-Time / Target Management

### Description

The SLRT Overload Options block configures CPU overload options for the model rate identified through the TID port. This block outputs the current CPU overload count for the identified rate. If the **Enable TET Output** parameter is on, the block outputs TET data that you can mark for data logging in the Simulation Data Inspector.



### Ports

#### Input

**TID** — Task ID  
int

Connect any signal from the model to the TID (Task ID) port and the block applies the overload options to the model task in which the signal executes.

Example: 1

#### Output

**Count** — Overload count  
int

The CPU overload count for the selected model rate.

### Parameters

**Startup Duration** — Select startup steps for ignoring CPU overloads  
1 (default) | int

The number of startup execution steps for which overloads are ignored.

#### Programmatic Use

startupDur



**Source** — Selects CPU overload input during startup  
Tunable Parameter (default) | Input Port

The source of CPU overloads for the model rate during startup can be a tunable parameter or a block input port.

**Programmatic Use**

startupDurSrc

**Max Overloads** — Select maximum CPU overloads  
0 (default) | int

The number of accepted overloads before execution is halted. There is a separate overload counter for each sub-rate. Each counter is compared to **Max Overloads** separately, not compared to the sum of the counters.

**Programmatic Use**

maxOverload

**Source** — Selects CPU overload input after startup  
Tunable Parameter (default) | Input Port

The source of CPU overloads for the model rate after startup can come from a tunable parameter or from the block input port.

**Programmatic Use**

maxOverloadSrc

**Enable TET Output** — Enable output TET data  
off (default) | on

When enabled, the CPU overload data is output for display in the TET monitor and the Simulation Data Inspector.

**Programmatic Use**

TETFlag

## Version History

Introduced in R2020b

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also

Thread Trigger


## Topics

“CPU Overload”

“Troubleshoot Overloaded CPU from Executing Real-Time Application”

# Persistent Variable Read

Read persistent variable value from target computer



**Libraries:**  
Simulink Real-Time / Target Management

## Description

The Persistent Variable Read block reads the selected persistent variable from the target computer when you load the real-time application. If the block cannot find the selected variable, the block outputs the selected default value. The variable value persists when the target computer is shut down.

Use the `getPersistentVariables` function and `setPersistentVariables` function to access the persistent variable values on the target computer.

## Ports

### Output

**Data** — Persistent variable output data  
variable data

The data type and dimensions of the Persistent Variable Read block output port are set by the `Default value` parameter. If these properties do not match those of the variable stored on the target computer, an error occurs during real-time application load.

The block can take a complex number. The complexity of the Persistent Variable Read block output port is set by the `Default value` parameter. If this property does not match the complexity of the variable stored on the target computer, an error occurs during real-time application load.

Data Types: `single` | `double` | `int8` | `int16` | `int32` | `int64` | `uint8` | `uint16` | `uint32` | `uint64` | `Boolean`

## Parameters

**Variable name** — Name of persistent variable  
`Variable1` (default) | character vector | string

The **Variable name** parameter provides the name of the persistent variable. Use this name to access the variable in the structure of variable values retrieved from the target computer by using the `getPersistentVariables` function.

### Programmatic Use

**Block Parameter:** `varName`

**Default value** — Starting value of persistent variable when variable does not exist on target computer  
`0` (default) | supports same data types as Data port

The **Default value** parameter provides a starting value for the persistent variable when the variable does not exist on the target computer. This parameter sets the data type and dimensions of the Persistent Variable Read block output port.

**Programmatic Use**

**Block Parameter:** defaultValue

## Version History

Introduced in R2022a

## Extended Capabilities

**C/C++ Code Generation**


Generate C and C++ code using Simulink® Coder™.

**See Also**

Persistent Variable Write | [getPersistentVariables](#) | [setPersistentVariables](#)

# Persistent Variable Write

Write persistent variable value to target computer



## Libraries:

Simulink Real-Time / Target Management

## Description

The Persistent Variable Write block writes a value to the selected persistent variable when the real-time application starts and stops. The variable value persists when the target computer is shut down.

Use the `getPersistentVariables` function and `setPersistentVariables` function to access the persistent variable values on the target computer.

## Ports

### Input

**Data** — Persistent variable input data  
variable data

The data type of the Persistent Variable Write block input port is inherited from its input signal. The signal can be any dimension.

The block can take a complex number. The complexity of the Persistent Variable Write block input port is inherited from its input signal.

Data Types: `single` | `double` | `int8` | `int16` | `int32` | `int64` | `uint8` | `uint16` | `uint32` | `uint64` | `Boolean`

## Parameters

**Variable name** — Name of persistent variable  
`Variable1` (default) | character vector | string

The **Variable name** parameter provides the name of the persistent variable. Use this name to access the variable in the structure of variable values retrieved from the target computer by using the `getPersistentVariables` function.

### Programmatic Use

**Block Parameter:** `varName`

## Version History

Introduced in R2022a

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

### **See Also**

Persistent Variable Read | `getPersistentVariables` | `setPersistentVariables`

# Utilities





# Utility Blocks

---

The Simulink Real-Time utility blocks support utility functions. Some of these blocks exist in the Utilities library, available at the top level of the Simulink Real-Time Block Library. Other blocks are available as sublibraries of the I/O function that they support.

## Bit Packing

Construct data frames



**Libraries:**  
Simulink Real-Time / Utilities

### Description

The Bit Packing block constructs data frames. Its output port is typically connected to an input port of a Send block or Digital Output block. The block has one output port. This port can be a vector of arbitrary size. It represents the data frame entity constructed by the signals entering the block at its input ports. The number of input ports depends on the setting in the block dialog box.

### Parameters

**Bit Patterns** — Packed data bit pattern  
{[0:31]} (default)

Specify bit patterns. The data type entered in the control must be a MATLAB cell array vector. The number of elements in the cell array define the number of input ports shown by this block instance. The cell array elements must be of type double array and define the position of each bit of the incoming value (data typed input port) in the outgoing double value (data frame). From a data type perspective (input ports), the block behaves like a Simulink Sink block. The data types of the input ports are inherited from the driving blocks.

**Programmatic Use**  
**Block Parameter:** BitPatterns

**Output port (packed) data type** — Packed data type  
uint32 (default) | double | single | int8 | uint8 | int16 | uint16 | int32 | boolean

From the list, select an output port (packed) data type.

**Programmatic Use**  
**Block Parameter:** PackDataType

**Output port (packed) dimensions** — Packed data dimensions  
[1] (default)

Specify the dimensions the output port (packed). Enter this value as a vector. Specify the size of the port by using a format compatible with the MATLAB `size` command.

**Programmatic Use**  
**Block Parameter:** PackDataSize

## Version History

Introduced in R2006a

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

### **See Also**

Bit Unpacking

### **Topics**

“Configure Input and Output Ports for Bit Packing and Unpacking”

## Bit Unpacking

Deconstruct data frames



**Libraries:**  
Simulink Real-Time / Utilities

### Description


The Bit Unpacking block extracts data frames. Its input port is typically connected to an output port of a Receive block or Digital Input block.

The block has one input port, which represents the data frame entity from which the signals are extracted and leaving the block at its output ports. The number of output ports and the data type of each output port depend on the settings in the block dialog box.

#### Bit Unpack Four Bytes

This example shows how to configure a Bit Unpacking block to:

- Receive a 32-bit word as input by using input port data type `uint32`.
- Unpack four 8-bit words (bytes) from the input data by using a bit pattern.
- Send four 8-bit words as output by using the output data type `uint8`.



After configuring the block parameters, the Bit Unpacking block appears as shown.



## Parameters

**Bit Patterns** — Select bit pattern  
 {[0:31]} (default)

Specify bit patterns. The data type must be a MATLAB cell array vector. The number of elements in the cell array define the number of input ports shown by this block instance. The cell array elements must be of type double array and define the position of each bit of the incoming value (data typed input port) in the outgoing double value (data frame). From a data type perspective, the block behaves like a Sink block. The **Input port (packed) data types** specify the data type of the input port.

### Programmatic Use

**Block Parameter:** BitPatterns

**Input port (packed) data types** — Packed data type

uint32 (default) | double | single | int8 | uint8 | int16 | uint16 | int32 | boolean

From the list, select an input port (packed) data type.

**Programmatic Use**

**Block Parameter:** PackDataType

**Input port (packed) dimension** — Packed data dimension  
[1] (default)

Specify the dimensions of the input port (packed). Enter this value as a vector. Specify the size of the port by using a format compatible with the MATLAB `size` command.

**Programmatic Use**

**Block Parameter:** PackDataSize

**Output port (unpacked) data types (cell array)** — Unpacked data type  
{'uint32'} (default)

The output ports (packed) can be of an arbitrary data type. The number of elements in the cell array define the number of output ports shown by this block instance. The data types are:

- double
- single
- int8
- uint8
- int16
- uint16
- int32
- uint32
- boolean

**Programmatic Use**

**Block Parameter:** UnpackDataTypes

**Output port (unpacked) dimension (cell array)** — Unpacked data dimension  
{[1]} (default)

Specify the dimensions of each output port (unpacked). Enter this value as a cell array of vector sizes.

**Programmatic Use**

**Block Parameter:** UnpackDataSizes

**Sign extend** — Enable sign extension  
on (default) | off

Select this check box to enable sign extension. If you select this check box and unpack the data frame into a signed type (`int8`, `int16`, or `int32`), the block performs sign extension. For example, if the bit pattern is `[0:4]`, and the data type is `int8`, you are extracting 5 bits into an 8-bit wide signed type. In this case, bits 5, 6, and 7 are the same as bit 4, resulting in sign extension. This functionality enables you to pack and unpack negative numbers without losing precision.

**Programmatic Use**

**Block Parameter:** SignExtend

## **Version History**

Introduced in R2006a

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

## **See Also**

Bit Packing

## **Topics**

“Configure Input and Output Ports for Bit Packing and Unpacking”

## Byte Packing

Construct data frames



**Libraries:**  
Simulink Real-Time / Utilities

### Description

The Byte Packing block converts one or more signals of user-selectable data types to a single vector of varying data types. The output of this block typically connects to an input port of a Send block.

The Byte Packing block and the Byte Unpacking block support the `slrealtime.tlc` code generation target and generate code that runs on Speedgoat target machines. Due to considerations such as endianness and addressable word size, these blocks can generate incorrect results for other code generation targets or target computers.

For example, suppose that you are packing three signals into a vector of `uint8`. The signals have the following attributes:

Dimension	Size	Type
Scalar	1	single
Vector	3	uint8
Vector	3	uint8

- 1 Set the packed output port data type to `uint8`.
- 2 Set the input port data type to a cell array encoding the data types:

```
{'single', ['uint8'], ['uint8']}
```

Use square brackets to represent vectors.

- 3 Set the byte alignment value to 1.
- 4 Connect the signals to the Byte Packing block.

### Input/Output Ports

#### Input

**Port\_1** — First of  $N$  input ports  
scalar | vector

The block has from 1 to  $N$  input ports. Specify the number of input ports and their types by entering them as a cell array in the parameter **Input port (unpacked) data types (cell array)**.

Data Types: single | double | int8 | int16 | int32 | int64 | uint8 | uint16 | uint32 | uint64 | Boolean



## Output

**Port\_1** — Output port containing packed data  
vector

The block displays one output port that transmits a vector of packed data. You determine the data type of the packed data by setting **Output port (packed) data type**.

Data Types: single | double | int8 | int16 | int32 | int64 | uint8 | uint16 | uint32 | uint64 | Boolean

## Parameters

**Output port (packed) data type** — Data type for the packed output signal  
uint8 (default) | double | single | int8 | int16 | uint16 | int32 | uint32 | boolean

From the list, select a data type for the output port.

### Programmatic Use

**Block Parameter:** MaskPackedDataType

**Input port (unpacked) data types (cell array)** — Data types for the unpacked input signals  
{'uint8'} (default) | double | single | int8 | int16 | uint16 | int32 | uint32 | boolean

Specify as a cell array the data types of the input ports (unpacked) for the different input signals. The number of elements in the cell array determines the number of input ports shown by this block instance. To represent vector elements, use square brackets in the cell array.

### Programmatic Use

**Block Parameter:** MaskUnpackedDataTypes

**Byte Alignment** — Alignment of the input signal data types after packing  
1 (default) | 2 | 4 | 8

Each element in the input signals list starts at a multiple of the alignment value, specified from the start of the vector. If the alignment value is larger than the size of the data type in bytes, the block fills the space with pad bytes of value 0.

For example, if the alignment value is 4:

- uint32 receives no padding
- uint16 receives 2 bytes of padding
- uint8 receives 3 bytes of padding

If the model accesses the data items frequently, consider selecting an alignment value equal to the largest data type that you want to access. If the model transfers data items frequently as a group, consider an alignment value of 1, which packs the data into as small a space as possible.

### Programmatic Use

**Block Parameter:** MaskAlignment

## Version History

Introduced in R2006a

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

The Byte Packing block supports C++ code generation only.

### **See Also**

Byte Unpacking

# Byte Reversal/Change Endianess

Reverse little-endian data for big-endian processor



**Libraries:**  
Simulink Real-Time / Utilities

## Description

You use the Byte Reversal/Change Endianess block for communication between a Simulink Real-Time system and a system running with a processor that is *big-endian*. Processors compatible with the Intel 80x86 family are *little-endian*. For this situation, insert a Byte Reversal/Change Endianess block before the Pack block and another just after the Unpack block. The following is the Change Endianess block.

## Parameters

### Block Parameters for Change Endianess

**Number of input ports** — Number of ports  
1 (default)

The number of input ports adjusts to follow this parameter and the number of outputs is equal to the number of inputs.

#### Programmatic Use

**Block Parameter:** numInp

**Machine word length** — Word length for conversion  
Byte (default) | Word | Double Word

Select a machine word length from the list to which to convert the data.

#### Programmatic Use

**Block Parameter:** />

### Byte Reversal Block Parameters

**Number of inputs** — Number of ports  
1 (default)

The number of input ports adjusts to follow this parameter and the number of outputs is equal to the number of inputs.

#### Programmatic Use

**Block Parameter:** numInp

## Version History

Introduced in R2006a

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

# Byte Unpacking

Deconstruct data frames



**Libraries:**  
Simulink Real-Time / Utilities

## Description

The Byte Unpacking block converts a vector of varying data types into one or more signals of user-selectable data types. The input of this block typically connects to an output port of a Receive block.

The Byte Packing block and the Byte Unpacking block support the `slrealtime.tlc` code generation target and generate code that runs on Speedgoat target machines. Due to considerations such as endianness and addressable word size, these blocks can generate incorrect results for other code generation targets or target computers.

For example, suppose that you are unpacking a `uint8` vector signal into three signals. The signals have these attributes:

Dimension	Size	Type
Scalar	1	single
Vector	3	uint8
Vector	3	uint8

- 1 Set the output port data type to:

```
{'single', ['uint8'], ['uint8']}
```

Use square brackets to represent vectors.

- 2 Set the output port dimension to:

```
{[1], [3], [3]}
```

- 3 Set the alignment value to 1.

- 4 Connect the output signals to the Byte Unpacking block.

## Input/Output Ports

### Input

**Port\_1** — Input port containing packed data  
vector

The block displays one input port that receives a vector of packed data. The source of the packed data determines by inheritance the data type of the packed data.

Data Types: `single` | `double` | `int8` | `int16` | `int32` | `int64` | `uint8` | `uint16` | `uint32` | `uint64` | `Boolean`

## Output

**Port\_1** — First of  $N$  output ports  
scalar | vector

The block displays from 1 to  $N$  output ports, as specified by elements of the cell array in the parameter **Output port (unpacked) data types (cell array)**.

Data Types: single | double | int8 | int16 | int32 | int64 | uint8 | uint16 | uint32 | uint64 | Boolean

## Parameters

**Output port (unpacked) data types (cell array)** — Data types for the unpacked output signals  
uint8 (default) | double | single | int8 | int16 | uint16 | int32 | uint32 | boolean

Specify as a cell array the data types of the output ports (unpacked) for the different output signals. The number of elements in the cell array determines the number of output ports shown by this block instance. To represent vector elements, use square brackets in the cell array.

### Programmatic Use

**Block Parameter:** MaskUnpackedDataTypes

**Output port (unpacked) dimensions (cell array)** — Dimensions of each output port (unpacked)  
{[1]} (default) | {[ $N$ ], [ $M$ ], ...}

Specify the dimensions of the output ports as a cell array of vectors.

### Programmatic Use

**Block Parameter:** MaskUnpackedDataSizes

**Byte Alignment** — Alignment of the output signal data types before unpacking  
1 (default) | 2 | 4 | 8

Each element in the output signals list starts at a multiple of the alignment value, specified from the start of the input vector. If the alignment value is larger than the size of the data type in bytes, the vector contains pad bytes of value 0.

For example, if the alignment value is 4:

- uint32 receives no padding
- uint16 receives 2 bytes of padding
- uint8 receives 3 bytes of padding

### Programmatic Use

**Block Parameter:** MaskAlignment

## Version History

Introduced in R2006a

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.


The Byte Unpacking block supports C++ code generation only.

### **See Also**

Byte Packing

## Shared Memory Pack

Shared memory pack



### Libraries:

Simulink Real-Time / Shared Memory

## Description

This block packs the specified partition structure into an unstructured double word array vector. It converts one or more Simulink signals of varying data types into the vector. Typically, the input to a pack block is the output from a write block. The Simulink interface is not aware of structures; pass the output of each structure segment as input to the Shared Memory Pack block.

Memory partitions consist of groups of Simulink signals, which are combined into blocks (packets) of 32-bit words. Before you begin to configure this block, be sure that you have a predefined shared memory partition structure as required by the shared memory manufacturer.

This block ignores the **Address** field of the partition structure.

## Parameters

**Partition struct** — Name of structure

[ ] (default)

Enter the name of the predefined shared memory partition structure.

### Programmatic Use

**Block Parameter:** partition

## Version History

Introduced in R2006a

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.


## See Also

Shared Memory Unpack



# Shared Memory Unpack

Shared memory unpacking



## Libraries:

Simulink Real-Time / Shared Memory

## Description

This block unpacks an unstructured double word array vector (from the Shared Memory Pack block) into the specified partition structure.

Before you begin to configure this block, be sure that you have a predefined shared memory partition structure as required by the shared memory manufacturer.

This block ignores the **Address** field of the partition structure.

## Parameters

**Partition struct** — Name of structure

[ ] (default)

Enter the name of the predefined shared memory partition structure. The block unpacks the double word array vector into this structure.

### Programmatic Use

**Block Parameter:** partition

## Version History

Introduced in R2006a

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

## See Also

Shared Memory Pack



# **XCP Universal Measurement and Calibration Protocol**



# XCP Communications

---

- “XCP Client Mode” on page 27-2
- “XCP Page Switching for Tunable Parameters” on page 27-3

## XCP Client Mode

The Universal Measurement and Calibration Protocol (XCP) is a network protocol that you can use to connect calibration systems to electronic control units (ECUs).

A node in the network can run in either client mode or server mode. Simulink Real-Time supports XCP in client mode to replace (bypass) a subsystem of the ECU controller. The bypass model acquires input signals from the ECU system, computes the output, and stimulates the result.

To support XCP client mode, the Simulink Real-Time software provides the XCP sublibrary. You can:

- Acquire real-time measurement data by using the XCP CAN Data Acquisition block or XCP UDP Data Acquisition block.
- Attach incoming data to software interrupts by using the XCP UDP Bypass block.
- Stimulate real-time measurement data by using the XCP CAN Data Stimulation or XCP UDP Data Stimulation block.

To create an XCP client model:

- Provide an A2L (ASAP2) format file that contains signal, parameter, and XCP-specific network elements for the server ECU.
- Provide an XCP Configuration block to load the A2L data into the XCP database.
- Provide one XCP CAN Transport Layer for each XCP CAN Configuration block.

Simulink Real-Time supports XCP implemented by using FIFO mode CAN or real-time UDP as transport protocols.

- Apply stimulus data to the server device by using the XCP Data Stimulation block.
- Acquire measurement data from the server device by using the XCP Data Acquisition block.

If an error occurs during XCP communications, the XCP client attempts to resolve the issue and continue communications. For example, when a `ERR_RESOURCE_TEMPORARY_NOT_ACCESSIBLE` error is detected for the setup command, the XCP client retries the command. If unsuccessful, the client attempts a restart of XCP communications. The real-time application keeps running while the XCP client tries to reestablish communications. You can monitor communication status by using the `Output Connection Status` port of the XCP UDP Configuration block, the XCP CAN Configuration block, or the XCP CAN FD Configuration block.

### See Also

XCP CAN Configuration | XCP CAN Data Acquisition | XCP CAN Data Stimulation | XCP CAN Transport Layer | XCP UDP Data Acquisition | XCP UDP Data Stimulation | XCP UDP Configuration


### More About

- “CAN”
- “Real-Time UDP”
- “Third-Party Calibration Support”
- “XCP Page Switching for Tunable Parameters” on page 27-3

## XCP Page Switching for Tunable Parameters

The Universal Measurement and Calibration Protocol (XCP) is a network protocol that you can use to connect calibration systems to electronic control units (ECUs).

Simulink Real-Time supports XCP and ECU page switching operation that is described in section 4.4 Online Calibration in the ASAM MCD-1 XCP v 1.5.0 specification. A real-time application has an XCP page that communicates with MATLAB, an ECU page that communicates with the target computer, and two memory pages (0,1) that you can connect with the XCP and ECU pages. Memory page 0 and 1 mapping to the XCP page or ECU page is independent of each other.



When running the real-time application, memory pages 0 and 1 each represents a set of tunable parameters. The pages start with identical content, and the initial mapped memory page for both XCP and ECU is page 0. The real-time application uses the parameters on the memory page (0 or 1) that is mapped to the ECU page. MATLAB communicates with parameter values on the memory page (0 or 1) that is mapped to the XCP page.

You use the page-related functions to copy pages, get the active ECU or XCP page, get the number of pages, or map the ECU or XCP page to memory page 0 or 1.

If working with Simulink Real-Time Explorer, the ECU and XCP page selection for page 0 or 1 need to match. For example, set both ECU and XCP pages to page 0. A page mismatch causes an error for the explorer, and a prompt appears in the app to let you synchronize the page selection.

For examples that demonstrate how to work with ECU and XCP pages, see `functionscopyPage`, `getECUPage`, `getNumPages`, `getXCPPage`, `setECUPage`, `setXCPPage`, and `setECUAndXCPPage`.

## Use XCP and ECU Pages for Parameters

This example shows a possible workflow for applying different parameter values on multiple XCP and ECU pages.

- 1 Open the model, build the real-time application, and load the real-time application.

```
open_system('slrt_ex_param_tuning');
slbuild('slrt_ex_param_tuning');
tg = slrealtime;
load(tg, 'slrt_ex_param_tuning');
```

- 2 Get memory page mapping of ECU page.

```
mappingOfECUpage = getECUPage(tg)
```

```
ans =
```

```
uint8
```

```
0
```

- 3 Get memory page mapping of XCP page.

```
mappingOfXCPpage = getXCPPage(tg)
```

```
ans =
```

```
uint8
```

```
0
```

- 4 Map XCP page to memory page 1.

```
setXCPPage(tg,1);
```

- 5 Start real-time application.

```
start(tg);
```

- 6 Use the `setparam` function to change a parameter value and notice that the parameter change is not reflected in the running application. This behavior occurs because `setparam` affects the parameters in the XCP page. This page is currently mapped to memory page 1, but the ECU page is mapped to memory page 0. So, the parameter value change is not reflected in the application.

```
setparam(tg, 'slrt_ex_param_tuning/Gain2', 'Gain', 1200000);
```

- 7 Use `getsignal` function to show that the parameter values on memory page 1 have not taken effect on the running application. Because the output of the Gain block is a square wave, the value is either 4000000 or -4000000.

```
getsignal(tg, 'slrt_ex_param_tuning/Gain2', 1)
```



```
ans =
```

```
4000000
```

- 8 Map the ECU page to memory page 1 and notice that the parameter value changes take effect in the real-time application. This behavior occurs because memory page 1 is mapped to both the ECU page and XCP page.

```
setECUPage(tg,1);
```

- 9 Use `getsignal` function to show that the parameter values on memory page 1 (now mapped to ECU page) have applied on the running application. Because the output of the Gain block is a square wave, the updated value is either 4800000 or -4800000.

```
getsignal(tg,'slrt_ex_param_tuning/Gain2',1)
```

```
ans =
```

```
4800000
```

## See Also

Target | copyPage | getNumPages | getXCPPage | setECUAndXCPPage | setECUPage | setXCPPage

## More About

- “XCP Client Mode” on page 27-2



# Stimulation Support

---

## Control and Update Stimulation of Inports to Real-Time Application

You can stream data to the inports of a real-time application on a target computer by using the `Target.Stimulation` object and functions. The functions enables you to control inport stimulation for individual or all inports and monitor stimulation status.

To load data to the inports, create a time series object by using, for example the `timeseries` function. Load the object into the inport. Do not pause or stop the stimulation of inports before or during the stimulation. A pause or stop generates a stimulation error.

To control or monitor stimulation of inports in a real-time application:

- Start the stimulation of a specific inport or all inports by using the `start` function.
- Pause the stimulation of a specific inport or all inports by using the `pause` function.
- Stop the stimulation of a specific inport or all inports by using the `stop` function.
- Get the status of stimulation of inports by using the `getStatus` function.
- Load data to specific inports by using the `reloadData` function.

### Stimulate Root Inport by Using MATLAB Language


This example shows how to stimulate root inports in a model by using the `Stimulation` object and related functions:

- `start`
- `stop`
- `getStatus`
- `reloadData`
- `pause`

#### Open Model and Map Inport to Wave Data

Open model `slrt_ex_osc_inport`. Save the model to a working folder. Map the inport to use square wave data. For inport `In1`, `interpolated` is off.

```
model = ('slrt_ex_osc_inport');
open_system(model);
load(fullfile(matlabroot, 'toolbox', 'slrealtime', 'examples', 'slrt_ex_inport_square.mat'));
waveform = square;
set_param(model, 'ExternalInput', 'waveform');
set_param(model, 'LoadExternalInput', 'on');
set_param(model, 'StopTime', 'Inf');
```



Model slrt\_ex\_osc\_inport  
 Simulink Real-Time example model  
 Copyright 2020 The MathWorks, Inc.

### Build Model and Download Real-Time Application

Build, download, and execute the real-time application.

```
evalc('slbuild(model)');
tg = slrealtime('TargetPC1');
load(tg,model);
```

### Stimulate Root Inport Data

Start root inport stimulation of inports 1. Open Scope block and observe results.

```
start(tg.Stimulation,[1]);
start(tg);
```

Pause root inport stimulation of inport 1.

```
pause(tg.Stimulation,[1]);
```

Stop and start the stimulation of inport 1.

```
stop(tg.Stimulation,[1]);
start(tg.Stimulation,[1]);
```

Check the status of stimulation of the inports.

```
getStatus(tg.Stimulation,'all');
```

Create a time-series object to load data to an inport.

```
sampleTime = 0.1;
endTime = 10;
numberOfSamples = endTime * 1/sampleTime + 1;
timeVector = (0:numberOfSamples) * sampleTime;
u = timeseries(timeVector*10,timeVector);
```

Object u is created for 10 seconds. Load it to the inport 1. Stimulation of an inport should be stopped before loading data.

```
stop(tg.Stimulation,[1]);  
reloadData(tg.Stimulation,[1],u);
```

Stop real-time application and close all.

```
stop(tg);  
bdclose('all');
```

**See Also**

timeseries | Target.Stimulation

# XCP Blocks

---

## XCP CAN Transport Layer

Generate and consume XCP messages that are transported by CAN hardware



### Libraries:

Simulink Real-Time / XCP / CAN FD

## Description

The XCP CAN Transport Layer block handles CAN messages that your model transmits or receives by using Simulink Real-Time CAN library blocks.

Connect the input side of the block to a block that receives CAN messages. Connect the output side of the block to a block that transmits the XCP messages over CAN. Set up the transmitting block so that a CAN message is sent only when an XCP message is available. Otherwise, the block sends 0 byte data when XCP messages are not available, causing undefined behavior.

## Ports

### Input

**CAN Msg** — CAN MESSAGE structures being consumed  
vector

Vector of CAN MESSAGE structures being consumed.

**N** — Number of messages  
integer

Number of messages in the vector.

### Output

**CAN Msg** — CAN MESSAGE structures being generated  
vector

Vector of CAN MESSAGE structures being generated.

**N** — Number of messages  
integer

Number of messages in the vector.

## Version History

**Introduced in R2020b**



## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

### **See Also**


[XCP CAN Configuration](#) | [XCP CAN Data Acquisition](#) | [XCP CAN Data Stimulation](#)

### **External Websites**

[www.asam.net](http://www.asam.net)

## XCP CAN Configuration

Configure XCP server connection



### Libraries:

Vehicle Network Toolbox / XCP Communication / CAN  
 Simulink Real-Time / XCP / CAN

### Description

The XCP CAN Configuration block uses the parameters specified in the A2L file and the ASAP2 database to establish an XCP server connection.

Before you acquire or stimulate data, specify the A2L file to use in your XCP CAN Configuration. Use one XCP CAN Configuration to configure one server connection for data acquisition or stimulation. If you add XCP CAN Data Acquisition and XCP CAN Data Stimulation blocks, your model checks to see if there is a corresponding XCP CAN Configuration block. If there is no corresponding XCP CAN Configuration block, the model prompts you to add one.

The XCP CAN communication blocks support Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information about these simulation modes, see “Design Your Model for Effective Acceleration”.

### Parameters

**Config name** — Specify XCP CAN session name  
 'CAN\_Config1' (default)

Specify a unique name for your XCP CAN session.

**A2L File** — Select an A2L file  
 file name

Click **Browse** to select an A2L file for your XCP CAN session.

**Enable seed/key security** — Select that key required to establish connection  
 'off'

Select this option if your server requires a secure key to establish connection. Use the **File (\*.DLL)** parameter to specify the DLL file that contains the seed/key definition.

**File (\*.DLL)** — Select file for seed and key security  
 file name

If you select **Enable seed/key security** (EnableSecurity), this field is enabled. Click **Browse** to select the file that contains the seed and key security algorithm that unlocks an XCP server module. This parameter is available in Windows Desktop Simulation for Vehicle Network Toolbox.

The **File (\*.DLL)** parameter specifies the name of the DLL-file that contains the seed and key security algorithm used to unlock an XCP server module. The file defines the algorithm for generating the

access key from a given seed according to ASAM standard definitions. For information on the file format and API, see the Vector web page [Steps to Use Seed&Key Option in CANape](#) or "Seed and Key Algorithm" in National Instruments™ CAN ECU Measurement and Calibration Toolkit User Manual.

**Note:** The DLL must be the same bitness as MATLAB (64-bit).

**Output connection status** — Display connection status

'off'

Select this option to display the status of the connection to the server module. Selecting this option adds a new output port.

## Version History

Introduced in R2013a

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see [Supported and Compatible Compilers](#).

## See Also

### Blocks

[XCP CAN Data Acquisition](#) | [XCP CAN Data Stimulation](#) | [XCP CAN Transport Layer](#)

## XCP CAN Data Acquisition

Acquire selected measurements from configured server connection



### Libraries:

Vehicle Network Toolbox / XCP Communication / CAN  
 Simulink Real-Time / XCP / CAN

### Description

The XCP CAN Data Acquisition block acquires data from the configured server connection based on measurements that you select. The block uses the XCP CAN transport layer to obtain raw data for the selected measurements at the specified simulation time step. Configure your XCP connection and use the XCP CAN Data Acquisition block to select your event and measurements for the configured server connection. The block displays the selected measurements as output ports.

The XCP communication blocks support the use of Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information on these simulation modes, see “Design Your Model for Effective Acceleration”.

### Ports

#### Output

**Data** — Output measurement samples  
 defined by A2L file

Output measurement samples, with names and types defined by the A2L file. Each entry in the Selected Measurements parameter defines an output port. A sample is available at every port for every step of the simulation.

### Parameters

**Config name** — Specify XCP CAN session name  
 select from list

Select the name of the XCP configuration that you want to use. This list displays all available names specified in the XCP CAN Configuration blocks in the model. Selecting a configuration displays events and measurements available in the A2L file of this configuration.

---


**Note** You can acquire measurements for only one event by using an XCP CAN Data Acquisition block. Use one block for each event whose measurements you want to acquire.

---

**Event name** — Select an event  
 select from list


Select an event from the available list of events. The XCP CAN Configuration block uses the specified A2L file to populate the events list.

**All Measurements** — List all measurements available for event measurements list

This list displays all measurements available for the selected event. Select the measurement that you want to use and click the add button,  to add it to the selected measurements. On your keyboard, press the **Ctrl** key to select multiple measurements.

In the Block Parameters dialog box, type the name of the measurement you want to use in the **Search** box. The **All Measurements** list displays a list of all matching names. Click the x to clear your search.

**Selected Measurements** — List selected measurements measurement names

This list displays selected measurements. Each selected measurement adds an output port to the block with the measurement name. To remove a measurement from this list, select the measurement and click the remove button, .

In the Block Parameters dialog box, use the shift buttons   to reorder the selected measurements.

**Block Output Settings** — Set the port output as Compu method conversion values or raw values  
Raw values as double (no Compu method conversion) (default) | Raw values (no Compu method conversion) | Physical values (apply Compu method conversion)

This parameter enables support for XCP data types and dimensions as defined in the ASAP2 standard. The Block Output Settings parameter selects whether the port outputs Compu method conversion values or raw values. The options provide:

- **Physical values (apply Compu method conversion)** enables the raw-to-physical conversion of ECU measurement values. For this option, the block port settings are set either to 'double' or 'string', based on the underlying Compu method conversion. For example, Compu method IDENTICAL, LINEAR, RAT\_FUNC, TAB\_INTP, and TAB\_NOINTP port settings is 'double' while Compu method TAB\_VERB port settings is 'string'. The maximum string length supported for Compu method conversion is 1024 as specified in the ASAM XIL specification.

The FORM Compu method conversion is not supported. Simulink throws a warning for such a conversion and IDENTICAL conversion is applied to the underlying measurement. Also, only scalar measurement signals are supported for TAB\_VERB conversion as Simulink only supports scalar strings.

Selecting this option shows the physical units (if any) in front of the measurement name on the block mask. This physical unit is acquired from the A2L description of the measurement and Compu method. If the physical unit is not specified, only the measurement name is displayed.

- **Raw values (no Compu method conversion)** sets the port data type according to the type definition in the A2L file and supports up to three-dimensional XCP measurements in Simulink.
- **Raw values as double (no Compu method conversion)** sets the port data type as double, converting all internal measurement values. This selection supports up to three-dimensional XCP measurements in Simulink.

These ASAP2 data types are supported by corresponding Simulink port data types:

- SBYTE
- UWORD
- SWORD
- ULONG
- SLONG
- A\_UINT64
- A\_INT64
- FLOAT32\_IEEE
- FLOAT64\_IEEE

The dimension support in the block accommodates the different treatment of matrices by MATLAB and the ECU. The MATLAB default operation treats matrices as row-major matrices. An XCP measurement can have a LAYOUT as COLUMN\_DIR or ROW\_DIR . If a matrix measurement is COLUMN\_DIR, the blocks rearrange the measurement in memory and ensure that the matrix (row X, col Y) in MATLAB refers to the same entry as (row X, col Y) on the ECU. The rearrangement causes matrix entries that are contiguous on the ECU to be noncontiguous in MATLAB and Simulink.

**DAQ List Priority** — Specify a priority value for server device driver  
priority value

Specify a priority value as an integer from 0 to 255 for the server device driver to prioritize transmission of data packets. The server can accumulate XCP packets for lower priority DAQ lists before transmission to the client. A value of 255 has the highest priority. The SET\_DAQ\_LIST\_MODE command communicates the **DAQ List Priority** value from client to server. This communication method differs from the specification of the Event Channel Priority property, which comes from the A2L file.

**Sample time** — Specify sampling time of block  
-1 (default)

Specify the sampling time of the block during simulation, which is the simulation time. This value defines the frequency at which the XCP CAN Data Acquisition block runs during simulation. If the block is inside a triggered subsystem or is to inherit sample time, you can specify -1 as your sample time, which is the default. You can also specify a MATLAB variable for sample time. For more information, see “What Is Sample Time?”.

**Enable Timestamp** — Enable reading timestamp from incoming DTO packets  
off (default) | on

When the Timestamp is enabled, the block reads the timestamp from incoming DTO packets and outputs the timestamp to Simulink. The **Enable Timestamp** check box appears in the block parameters dialog box when the parameter is supported in the A2L file.

## Version History

Introduced in R2013a

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see Supported and Compatible Compilers.


## See Also

### Blocks

[XCP CAN Configuration](#) | [XCP CAN Data Stimulation](#) | [XCP CAN Transport Layer](#)

## XCP CAN Data Stimulation

Perform data stimulation on selected measurements



### Libraries:

Vehicle Network Toolbox / XCP Communication / CAN  
 Simulink Real-Time / XCP / CAN

### Description

The XCP CAN Data Stimulation block sends data to the selected server connection for the selected event measurements. The block uses the XCP CAN transport layer to output raw data for the selected measurements at the specified stimulation time step. Configure your XCP session and use the XCP CAN Data Stimulation block to select your event and measurements on the configured server connection. The block displays the selected measurements as input ports.

The XCP communication blocks support Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information about these simulation modes, see “Design Your Model for Effective Acceleration”.

### Ports

#### Input

**Data** — Input samples for data stimulation  
 defined by A2L file

Input data stimulation samples, with names and types defined by the A2L file. Each entry in the Selected Measurements parameter defines an input port. A sample is written at every port for every step of the simulation.

### Parameters

**Config name** — Specify XCP CAN session name  
 select from list

Select the name of XCP configuration that you want to use. This list displays all available names specified in the available XCP CAN Configuration blocks in the model. Selecting a configuration displays events and measurements available in the A2L file of this configuration. You can stimulate measurements for only one event by using an XCP CAN Data Stimulation block. Use one block for each event whose measurements you want to stimulate.


**Event name** — Select an event  
 select from list

Select an event from the event list. The XCP CAN Configuration block uses the specified A2L file to populate the events list. The block is configured with the corresponding event number from the A2L.




The event time cycle does not control transmission of stimulation packets. The block stimulates each time it executes. For use in Simulink simulation, consider enabling simulation pacing to avoid free-running stimulation.



**All Measurements** — List all measurements available for event measurements list

This list displays all measurements available for the selected event. Select the measurement that you want to use and click the add button,  to move it to the selected measurements. Hold the Ctrl key on your keyboard to select multiple measurements.

In the block parameters dialog box, type the name of the measurement you want to use in the **Search** box. The **All Measurements** lists displays a list of all matching names. Click the x to clear your search.

**Selected Measurements** — List selected measurements measurement names

This list displays your selected measurements. Each selected measurement adds an input port to the block with the measurement name. To remove a measurement from this list, select the measurement and click the remove button, .

In the **Block Parameters** dialog box, use the shift buttons   to reorder the selected measurements.

**Block Input Settings** — Set the port input as Compu method conversion values or raw values  
Raw values as double (no Compu method conversion) (default) | Raw values (no Compu method conversion) | Physical values (apply Compu method conversion)

This parameter enables support for XCP data types and dimensions as defined in the ASAP2 standard. The Block Input Settings parameter selects whether the port outputs Compu method conversion values or raw values. The options provide:

- **Physical values (apply Compu method conversion)** enables the physical-to-raw conversion of ECU measurement values. For this option, the block port settings are set either to 'double' or 'string', based on the underlying Compu method conversion. For example, Compu method IDENTICAL, LINEAR, RAT\_FUNC, TAB\_INTP, and TAB\_NOINTP port settings is 'double' while Compu method TAB\_VERB port settings is 'string'. The maximum string length supported for Compu method conversion is 1024 as specified in the ASAM XIL specification.

The FORM Compu method conversion is not supported. Simulink throws a warning for such a conversion and IDENTICAL conversion is applied to the underlying measurement. Also, only scalar measurement signals are supported for TAB\_VERB conversion as Simulink only supports scalar strings.

Selecting this option shows the physical units (if any) in front of the measurement name on the block mask. This physical unit is acquired from the A2L description of the measurement and Compu method. If the physical unit is not specified, only the measurement name is displayed.

- **Raw values (no Compu method conversion)** sets the port data type according to the type definition in the A2L file and supports up to three-dimensional XCP measurements in Simulink.

- **Raw values as double (no Compu method conversion)** sets the port data type as `double`, converting all internal measurement values. This selection supports up to three-dimensional XCP measurements in Simulink.

These ASAP2 data types are supported by corresponding Simulink port data types:

- `SBYTE`
- `UWORD`
- `SWORD`
- `ULONG`
- `SLONG`
- `A_UINT64`
- `A_INT64`
- `FLOAT32_IEEE`
- `FLOAT64_IEEE`

The dimension support in the block accommodates the different treatment of matrices by MATLAB and the ECU. The MATLAB default operation treats matrices as row-major matrices. An XCP measurement can have a `LAYOUT` as `COLUMN_DIR` or `ROW_DIR`. If a matrix measurement is `COLUMN_DIR`, the blocks rearrange the measurement in memory and ensure that the matrix (row X, col Y) in MATLAB refers to the same entry as (row X, col Y) on the ECU. The rearrangement causes matrix entries that are contiguous on the ECU to be noncontiguous in MATLAB and Simulink.

**Enable Timestamp** — Enable sending Simulink timestamp in STIM DTO packets  
`off` (default) | `on`

When the Timestamp is enabled, the block inputs a timestamp from Simulink and sends the timestamp in the STIM DTO packets. The **Enable Timestamp** check box appears in the block parameters dialog box when the parameter is supported in the A2L file.

## Version History

Introduced in R2013a

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see Supported and Compatible Compilers.


## See Also

### Blocks

XCP CAN Configuration | XCP CAN Data Acquisition | XCP CAN Transport Layer

# XCP CAN FD Transport Layer

Generate and consume XCP messages that are transported by CAN FD hardware



## Libraries:

Simulink Real-Time / XCP / CAN FD

## Description

The XCP CAN FD Transport Layer block handles CAN FD messages that your model transmits or receives by using Simulink Real-Time CAN FD library blocks.

Connect the input side of the block to a block that receives CAN FD messages. Connect the output side of the block to a block that transmits the XCP messages over CAN FD. Set up the transmitting block so that a CAN FD message is sent only when an XCP message is available. Otherwise, the block sends 0 byte data when XCP messages are not available, causing undefined behavior.

## Ports

### Input

**CAN FD Msg** — CAN FD MESSAGE structures being consumed  
vector

The block input is a Simulink CAN\_FD\_MESSAGE\_BUS signal. For more information on Simulink bus objects, see “Composite Interfaces”.

**N** — Number of messages  
integer

Number of messages in the vector.

### Output

**CAN FD Msg** — CAN FD message output  
CAN\_FD\_MESSAGE\_BUS

The block output is a Simulink CAN\_FD\_MESSAGE\_BUS signal. For more information on Simulink bus objects, see “Composite Interfaces”.

**N** — Number of messages  
integer

Number of messages in the vector.

## Version History

Introduced in R2022b

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

### **See Also**


XCP CAN FD Configuration | XCP CAN FD Data Acquisition | XCP CAN FD Data Stimulation

### **External Websites**

[www.asam.net](http://www.asam.net)

# XCP CAN FD Configuration

Configure XCP server connection



## Libraries:

Vehicle Network Toolbox / XCP Communication / CAN FD  
 Simulink Real-Time / XCP / CAN FD

## Description

The XCP CAN FD Configuration block uses the parameters specified in the A2L file and the ASAP2 database to establish an XCP server connection.

Before you acquire or stimulate data, specify the A2L file to use in your XCP CAN FD Configuration. Use one XCP CAN FD Configuration to configure one server connection for data acquisition or stimulation. If you add XCP CAN FD Data Acquisition and XCP CAN FD Data Stimulation blocks, your model checks to see if there is a corresponding XCP CAN FD Configuration block. If there is no corresponding XCP CAN FD Configuration block, the model editor prompts you to add one.

The XCP CAN FD communication blocks support Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information about these simulation modes, see “Design Your Model for Effective Acceleration”.

## Parameters

**Config name** — Specify XCP CAN FD session name  
 'CAN\_FD\_Config1' (default)

Specify a unique name for your XCP CAN FD session.

**A2L File** — Select an A2L file  
 file name

Click **Browse** to select an A2L file for your XCP CAN FD session.

**Enable seed/key security** — Select that key required to establish connection  
 'off'

Select this option if your server requires a secure key to establish connection. Use the **File (\*.DLL)** parameter to specify the DLL file that contains the seed/key definition.

**File (\*.DLL)** — Select file for seed and key security  
 file name

If you select **Enable seed/key security** (EnableSecurity), this field is enabled. Click **Browse** to select the file that contains the seed and key security algorithm that unlocks an XCP server module. This parameter is available in Windows Desktop Simulation for Vehicle Network Toolbox.

The **File (\*.DLL)** parameter specifies the name of the DLL-file that contains the seed and key security algorithm used to unlock an XCP server module. The file defines the algorithm for generating the

access key from a given seed according to ASAM standard definitions. For information on the file format and API, see the Vector web page [Steps to Use Seed&Key Option in CANape](#) or "Seed and Key Algorithm" in National Instruments CAN ECU Measurement and Calibration Toolkit User Manual.

**Note:** The DLL must be the same bitness as MATLAB (64-bit).

**Output connection status** — Display connection status

'off'

Select this option to display the status of the connection to the server module. Selecting this option adds a new output port.

## Version History

Introduced in R2022b

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see [Supported and Compatible Compilers](#).

## See Also

### Blocks

[XCP CAN FD Data Acquisition](#) | [XCP CAN FD Data Stimulation](#) | [XCP CAN FD Transport Layer](#)

# XCP CAN FD Data Acquisition

Acquire selected measurements from configured server connection



## Libraries:

Vehicle Network Toolbox / XCP Communication / CAN FD  
Simulink Real-Time / XCP / CAN FD

## Description

The XCP CAN FD Data Acquisition block acquires data from the configured server connection based on measurements that you select. The block uses the XCP CAN FD transport layer to obtain raw data for the selected measurements at the specified simulation time step. Configure your XCP connection and use the XCP CAN FD Data Acquisition block to select your event and measurements for the configured server connection. The block displays the selected measurements as output ports.

The XCP communication blocks support the use of Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information on these simulation modes, see “Design Your Model for Effective Acceleration”.

## Ports

### Output

**Data** — Output measurement samples  
defined by A2L file

Output measurement samples, with names and types defined by the A2L file. Each entry in the Selected Measurements parameter defines an output port. A sample is available at every port for every step of the simulation.

## Parameters

**Config name** — Specify XCP CAN FD session name  
select from list

Select the name of the XCP configuration that you want to use. This list displays all available names specified in the XCP CAN FD Configuration blocks in the model. Selecting a configuration displays events and measurements available in the A2L file of this configuration.

---


**Note** You can acquire measurements for only one event by using an XCP CAN FD Data Acquisition block. Use one block for each event whose measurements you want to acquire.

---

**Event name** — Select an event  
select from list


Select an event from the available list of events. The XCP CAN FD Configuration block uses the specified A2L file to populate the events list.

**All Measurements** — List all measurements available for event measurements list

This list displays all measurements available for the selected event. Select the measurement that you want to use and click the add button,  to add it to the selected measurements. On your keyboard, press the **Ctrl** key to select multiple measurements.

In the Block Parameters dialog box, type the name of the measurement you want to use in the **Search** box. The **All Measurements** list displays a list of all matching names. Click the x to clear your search.

**Selected Measurements** — List selected measurements measurement names

This list displays selected measurements. Each selected measurement adds an output port to the block with the measurement name. To remove a measurement from this list, select the measurement and click the remove button, .

In the Block Parameters dialog box, use the shift buttons   to reorder the selected measurements.

**Block Output Settings** — Set the port output as Compu method conversion values or raw values  
Raw values as double (no Compu method conversion) (default) | Raw values (no Compu method conversion) | Physical values (apply Compu method conversion)

This parameter enables support for XCP data types and dimensions as defined in the ASAP2 standard. The Block Output Settings parameter selects whether the port outputs Compu method conversion values or raw values. The options provide:

- **Physical values (apply Compu method conversion)** enables the raw-to-physical conversion of ECU measurement values. For this option, the block port settings are set either to 'double' or 'string', based on the underlying Compu method conversion. For example, Compu method IDENTICAL, LINEAR, RAT\_FUNC, TAB\_INTP, and TAB\_NOINTP port settings is 'double' while Compu method TAB\_VERB port settings is 'string'. The maximum string length supported for Compu method conversion is 1024 as specified in the ASAM XIL specification.

The FORM Compu method conversion is not supported. Simulink throws a warning for such a conversion and IDENTICAL conversion is applied to the underlying measurement. Also, only scalar measurement signals are supported for TAB\_VERB conversion as Simulink only supports scalar strings.

Selecting this option shows the physical units (if any) in front of the measurement name on the block mask. This physical unit is acquired from the A2L description of the measurement and Compu method. If the physical unit is not specified, only the measurement name is displayed.

- **Raw values (no Compu method conversion)** sets the port data type according to the type definition in the A2L file and supports up to three-dimensional XCP measurements in Simulink.
- **Raw values as double (no Compu method conversion)** sets the port data type as double, converting all internal measurement values. This selection supports up to three-dimensional XCP measurements in Simulink.

These ASAP2 data types are supported by corresponding Simulink port data types:



- SBYTE
- UWORD
- SWORD
- ULONG
- SLONG
- A\_UINT64
- A\_INT64
- FLOAT32\_IEEE
- FLOAT64\_IEEE

The dimension support in the block accommodates the different treatment of matrices by MATLAB and the ECU. The MATLAB default operation treats matrices as row-major matrices. An XCP measurement can have a LAYOUT as COLUMN\_DIR or ROW\_DIR . If a matrix measurement is COLUMN\_DIR, the blocks rearrange the measurement in memory and ensure that the matrix (row X, col Y) in MATLAB refers to the same entry as (row X, col Y) on the ECU. The rearrangement causes matrix entries that are contiguous on the ECU to be noncontiguous in MATLAB and Simulink.

**DAQ List Priority** — Specify a priority value for server device driver  
priority value

Specify a priority value as an integer from 0 to 255 for the server device driver to prioritize transmission of data packets. The server can accumulate XCP packets for lower priority DAQ lists before transmission to the client. A value of 255 has the highest priority. The SET\_DAQ\_LIST\_MODE command communicates the **DAQ List Priority** value from client to server. This communication method differs from the specification of the Event Channel Priority property, which comes from the A2L file.

**Sample time** — Specify sampling time of block  
-1 (default)

Specify the sampling time of the block during simulation, which is the simulation time. This value defines the frequency at which the XCP CAN FD Data Acquisition block runs during simulation. If the block is inside a triggered subsystem or is to inherit sample time, you can specify -1 as your sample time, which is the default. You can also specify a MATLAB variable for sample time. For more information, see “What Is Sample Time?”.

**Enable Timestamp** — Enable reading timestamp from incoming DTO packets  
off (default) | on

When the Timestamp is enabled, the block reads the timestamp from incoming DTO packets and outputs the timestamp to Simulink. The **Enable Timestamp** check box appears in the block parameters dialog box when the parameter is supported in the A2L file.

## Version History

Introduced in R2022b

## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see Supported and Compatible Compilers.


## **See Also**

### **Blocks**

XCP CAN FD Configuration | XCP CAN FD Data Stimulation | XCP CAN FD Transport Layer

# XCP CAN FD Data Stimulation

Perform data stimulation on selected measurements



## Libraries:

Vehicle Network Toolbox / XCP Communication / CAN FD  
 Simulink Real-Time / XCP / CAN FD

## Description

The XCP CAN FD Data Stimulation block sends data to the selected server connection for the selected event measurements. The block uses the XCP CAN FD transport layer to output raw data for the selected measurements at the specified stimulation time step. Configure your XCP session and use the XCP CAN FD Data Stimulation block to select your event and measurements on the configured server connection. The block displays the selected measurements as input ports.

The XCP communication blocks support Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information about these simulation modes, see “Design Your Model for Effective Acceleration”.

## Ports

### Input

**Data** — Input samples for data stimulation  
 defined by A2L file

Input data stimulation samples, with names and types defined by the A2L file. Each entry in the Selected Measurements parameter defines an input port. A sample is written at every port for every step of the simulation.

## Parameters

**Config name** — Specify XCP CAN FD session name  
 select from list


Select the name of XCP configuration that you want to use. This list displays all available names specified in the available XCP CAN FD Configuration blocks in the model. Selecting a configuration displays events and measurements available in the A2L file of this configuration. You can stimulate measurements for only one event by using an XCP CAN FD Data Stimulation block. Use one block for each event whose measurements you want to stimulate.

**Event name** — Select an event  
 select from list

Select an event from the event list. The XCP CAN FD Configuration block uses the specified A2L file to populate the events list. The block is configured with the corresponding event number from the A2L.


The event time cycle does not control transmission of stimulation packets. The block stimulates each time it executes. For use in Simulink simulation, consider enabling simulation pacing to avoid free-running stimulation.



**All Measurements** — List all measurements available for event measurements list

This list displays all measurements available for the selected event. Select the measurement that you want to use and click the add button,  to move it to the selected measurements. Hold the Ctrl key on your keyboard to select multiple measurements.

In the block parameters dialog box, type the name of the measurement you want to use in the **Search** box. The **All Measurements** lists displays a list of all matching names. Click the x to clear your search.

**Selected Measurements** — List selected measurements measurement names

This list displays your selected measurements. Each selected measurement adds an input port to the block with the measurement name. To remove a measurement from this list, select the measurement and click the remove button, .

In the **Block Parameters** dialog box, use the shift buttons   to reorder the selected measurements.

**Block Input Settings** — Set the port input as Compu method conversion values or raw values  
Raw values as double (no Compu method conversion) (default) | Raw values (no Compu method conversion) | Physical values (apply Compu method conversion)

This parameter enables support for XCP data types and dimensions as defined in the ASAP2 standard. The Block Input Settings parameter selects whether the port outputs Compu method conversion values or raw values. The options provide:

- **Physical values (apply Compu method conversion)** enables the physical-to-raw conversion of ECU measurement values. For this option, the block port settings are set either to 'double' or 'string', based on the underlying Compu method conversion. For example, Compu method IDENTICAL, LINEAR, RAT\_FUNC, TAB\_INTP, and TAB\_NOINTP port settings is 'double' while Compu method TAB\_VERB port settings is 'string'. The maximum string length supported for Compu method conversion is 1024 as specified in the ASAM XIL specification.

The FORM Compu method conversion is not supported. Simulink throws a warning for such a conversion and IDENTICAL conversion is applied to the underlying measurement. Also, only scalar measurement signals are supported for TAB\_VERB conversion as Simulink only supports scalar strings.

Selecting this option shows the physical units (if any) in front of the measurement name on the block mask. This physical unit is acquired from the A2L description of the measurement and Compu method. If the physical unit is not specified, only the measurement name is displayed.

- **Raw values (no Compu method conversion)** sets the port data type according to the type definition in the A2L file and supports up to three-dimensional XCP measurements in Simulink.

- **Raw values as double (no Compu method conversion)** sets the port data type as `double`, converting all internal measurement values. This selection supports up to three-dimensional XCP measurements in Simulink.

These ASAP2 data types are supported by corresponding Simulink port data types:

- `SBYTE`
- `UWORD`
- `SWORD`
- `ULONG`
- `SLONG`
- `A_UINT64`
- `A_INT64`
- `FLOAT32_IEEE`
- `FLOAT64_IEEE`

The dimension support in the block accommodates the different treatment of matrices by MATLAB and the ECU. The MATLAB default operation treats matrices as row-major matrices. An XCP measurement can have a `LAYOUT` as `COLUMN_DIR` or `ROW_DIR`. If a matrix measurement is `COLUMN_DIR`, the blocks rearrange the measurement in memory and ensure that the matrix (row X, col Y) in MATLAB refers to the same entry as (row X, col Y) on the ECU. The rearrangement causes matrix entries that are contiguous on the ECU to be noncontiguous in MATLAB and Simulink.

**Enable Timestamp** — Enable sending Simulink timestamp in STIM DTO packets  
`off` (default) | `on`

When the Timestamp is enabled, the block inputs a timestamp from Simulink and sends the timestamp in the STIM DTO packets. The **Enable Timestamp** check box appears in the block parameters dialog box when the parameter is supported in the A2L file.

## Version History

Introduced in R2022b

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see Supported and Compatible Compilers.


## See Also

### Blocks

XCP CAN FD Configuration | XCP CAN FD Data Acquisition | XCP CAN FD Transport Layer

## XCP UDP Configuration

Configure XCP UDP server connection



### Libraries:

Vehicle Network Toolbox / XCP Communication / UDP  
 Simulink Real-Time / XCP / UDP

### Description

The XCP UDP Configuration block uses the parameters specified in the A2L file and the ASAP2 database to establish an XCP server connection.

Before you acquire or stimulate data, specify the A2L file to use in your XCP UDP Configuration. Use one XCP UDP Configuration to configure one server connection for data acquisition or stimulation. If you add XCP UDP Data Acquisition and XCP UDP Data Stimulation blocks, your model checks to see if there is a corresponding XCP UDP Configuration block. If there is no corresponding XCP UDP Configuration block, the model prompts you to add one.

The XCP UDP communication blocks support Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information about these simulation modes, see “Design Your Model for Effective Acceleration”.

### Parameters

**Config name** — Specify XCP UDP session name  
 'UDP\_Config1' (default)

Specify a unique name for your XCP session.

**A2L File** — Select an A2L file  
 file name

Click **Browse** to select an A2L file for your XCP session.

**Enable seed/key security** — Select that key required to establish connection  
 'off'

Select this option if your server requires a secure key to establish connection. Select a file that contains the seed/key definition to enable security.

**File (\*.DLL)** — Select file for seed and key security  
 file name

If you select **Enable seed/key security**, this field is enabled. Click **Browse** to select the file that contains the seed and key security algorithm that unlocks an XCP server module. This parameter is available in Windows Desktop Simulation for Vehicle Network Toolbox.

**Output connection status** — Display connection status  
 'off'

Select this option to display the status of the connection to the server module. Selecting this option adds a new output port.

**Disable CTR error detection** — Disable CTR error detection scheme

'on' (default) | 'off'

To detect missing packets, the block can check the counter value in each XCP packet header. When 'on', counter error detection for packet headers is disabled. When 'off', the counter **Error detection scheme** is enabled.

**Error detection scheme** — Select CTR error detection scheme

One counter for all CT0s and DT0s (default) | Separate counters for (RES,ERR,EV,SERV) and (DAQ) | Separate counters for (RES,ERR), (EV,SERV) and (DAQ)

To detect missing packets, the block can check the counter value in each XCP packet header and apply an error-detection scheme.

**Sample time** — Sample time of block

-1 (default) | numeric

Enter the base sample time or a multiple of the base sample time. -1 means that sample time is inherited. For information about simulation sample timing, see “What Is Sample Time?”.

**Local IP Address** — Client IP address

x.x.x.x

Enter the IP address to which you want to connect.

**Local Port** — Client IP port

1–65535

The combination of **Local IP address** and **Local port** must be unique.

Ports in the range 5500 through 5560 are reserved for Simulink Real-Time communications.

## Version History

Introduced in R2019a

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see Supported and Compatible Compilers.

## **See Also**

### **Blocks**

XCP UDP Data Acquisition | XCP UDP Data Stimulation | XCP UDP Bypass



# XCP UDP Data Acquisition

Acquire selected measurements from configured server connection



## Libraries:

Vehicle Network Toolbox / XCP Communication / UDP  
 Simulink Real-Time / XCP / UDP

## Description

The XCP UDP Data Acquisition block acquires data from the configured server connection based on the measurements that you select. The block uses the XCP UDP transport layer to obtain raw data for the selected measurements at the specified simulation time step. Configure your XCP connection and use the XCP UDP Data Acquisition block to select your event and measurements for the configured server connection. The block displays the selected measurements as output ports.

The XCP communication blocks support the use of Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information on these simulation modes, see “Design Your Model for Effective Acceleration”.

## Parameters


**Config name** — Specify XCP UDP session name  
 select from list

Select the name of XCP configuration that you want to use. This list displays all available names specified in the XCP UDP Configuration blocks in the model. Selecting a configuration displays events and measurements available in the A2L file of this configuration. You can acquire measurements for only one event by using an XCP UDP Data Acquisition block. Use one block for each event whose measurements you want to acquire.

**Event name** — Select an event  
 select from list

Select an event from the available list of events. The XCP UDP Configuration block uses the specified A2L file to populate the events list.

**All Measurements** — List all measurements available for event  
 measurements list



This list displays all measurements available for the selected event. Select the measurement that you want to use and click the add button,  to add it to the selected measurements. Hold the Ctrl key on your keyboard to select multiple measurements.

In the **Block Parameters** dialog box, type the name of the measurement you want to use in the **Search** box. The **All Measurements** lists displays a list of all matching names. Click the x to clear your search.

**Selected Measurements** — List selected measurements

measurement names

This list displays selected measurements. To remove a measurement from this list, select the measurement and click the remove button, .

In the **Block Parameters** dialog box, use the toggle buttons   to reorder the selected measurements.

**Block Output Settings** — Set the port output as Compu method conversion values or raw values  
Raw values as double (no Compu method conversion) (default) | Raw values (no Compu method conversion) | Physical values (apply Compu method conversion)

This parameter enables support for XCP data types and dimensions as defined in the ASAP2 standard. The Block Output Settings parameter selects whether the port outputs Compu method conversion values or raw values. The options provide:

- **Physical values (apply Compu method conversion)** enables the raw-to-physical conversion of ECU measurement values. For this option, the block port settings are set either to 'double' or 'string', based on the underlying Compu method conversion. For example, Compu method IDENTICAL, LINEAR, RAT\_FUNC, TAB\_INTP, and TAB\_NOINTP port settings is 'double' while Compu method TAB\_VERB port settings is 'string'. The maximum string length supported for Compu method conversion is 1024 as specified in the ASAM XIL specification.

The FORM Compu method conversion is not supported. Simulink throws a warning for such a conversion and IDENTICAL conversion is applied to the underlying measurement. Also, only scalar measurement signals are supported for TAB\_VERB conversion as Simulink only supports scalar strings.

Selecting this option shows the physical units (if any) in front of the measurement name on the block mask. This physical unit is acquired from the A2L description of the measurement and Compu method. If the physical unit is not specified, only the measurement name is displayed.

- **Raw values (no Compu method conversion)** sets the port data type according to the type definition in the A2L file and supports up to three-dimensional XCP measurements in Simulink.
- **Raw values as double (no Compu method conversion)** sets the port data type as double, converting all internal measurement values. This selection supports up to three-dimensional XCP measurements in Simulink.

These ASAP2 data types are supported by corresponding Simulink port data types:

- SBYTE
- UWORD
- SWORD
- ULONG
- SLONG
- A\_UINT64
- A\_INT64

- FLOAT32\_IEEE
- FLOAT64\_IEEE

The dimension support in the block accommodates the different treatment of matrices by MATLAB and the ECU. The MATLAB default operation treats matrices as row-major matrices. An XCP measurement can have a LAYOUT as COLUMN\_DIR or ROW\_DIR . If a matrix measurement is COLUMN\_DIR, the blocks rearrange the measurement in memory and ensure that the matrix (row X, col Y) in MATLAB refers to the same entry as (row X, col Y) on the ECU. The rearrangement causes matrix entries that are contiguous on the ECU to be noncontiguous in MATLAB and Simulink.

**DAQ List Priority** — Specify a priority value for server device driver  
priority value

Specify a priority value as an integer from 0 to 255 for the server device driver to prioritize transmission of data packets. The server can accumulate XCP packets for lower priority DAQ lists before transmission to the client. A value of 255 has the highest priority. The SET\_DAQ\_LIST\_MODE command communicates the **DAQ List Priority** value from client to server. This communication method differs from the specification of the Event Channel Priority property, which comes from the A2L file.

**Sample time** — Specify sampling time of block  
-1 (default)

Specify the sampling time of the block during simulation, which is the simulation time. This value defines the frequency at which the XCP UDP Data Acquisition block runs during simulation. If the block is inside a triggered subsystem or is to inherit sample time, you can specify -1 as your sample time, which is the default. You can also specify a MATLAB variable for sample time. For information about simulation sample timing, see “What Is Sample Time?”.

**Enable Timestamp** — Enable reading timestamp from incoming DTO packets  
off (default) | on

When the Timestamp is enabled, the block reads the timestamp from incoming DTO packets and outputs the timestamp to Simulink. The **Enable Timestamp** check box appears in the block parameters dialog box when the parameter is supported in the A2L file.

## Version History

Introduced in R2019a

### R2021b: Compu Method Conversion Support

To add Compu method conversion support, the **Force Datatypes and Allow Non-Scalar** parameter for the XCP CAN Data Acquisition block, XCP CAN Data Stimulation block, XCP UDP Data Acquisition block, and XCP UDP Data Stimulation block has been replaced with the **Block Input/ Output Settings** parameter. Using this parameter, you can select whether to apply Compu method conversion to block input or output.

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see Supported and Compatible Compilers.


## **See Also**

### **Blocks**

XCP UDP Configuration | XCP UDP Data Stimulation | XCP UDP Bypass

# XCP UDP Data Stimulation

Perform data stimulation on selected measurements



## Libraries:

Vehicle Network Toolbox / XCP Communication / UDP  
 Simulink Real-Time / XCP / UDP

## Description

The XCP UDP Data Stimulation block sends data to the selected server connection for the event measurements that you select. The block uses the XCP UDP transport layer to output raw data for the selected measurements at the specified stimulation time step. Configure your XCP session and use the XCP UDP Data Stimulation block to select your event and measurements on the configured server connection. The block displays the selected measurements as input ports.

The XCP communication blocks support Simulink accelerator mode and rapid accelerator mode. You can speed up the execution of Simulink models by using these modes. For more information about these simulation modes, see “Design Your Model for Effective Acceleration”.

## Parameters

**Config name** — Specify XCP UDP session name  
 select from list


Select the name of XCP configuration that you want to use. This list displays all available names specified in the available XCP UDP Configuration blocks in the model. Selecting a configuration displays events and measurements available in the A2L file of this configuration. You can stimulate measurements for only one event by using an XCP UDP Data Stimulation block. Use one block for each event whose measurements you want to stimulate.

**Event name** — Select an event  
 select from list

Select an event from the event list. The XCP UDP Configuration block uses the specified A2L file to populate the events list. The block is configured with the corresponding event number from the A2L.

The event time cycle does not control transmission of stimulation packets. The block stimulates each time it executes. For use in Simulink simulation, consider enabling simulation pacing to avoid free-running stimulation.


**All Measurements** — List all measurements available for event  
 measurements list



This list displays all measurements available for the selected event. Select the measurement that you want to use and click the add button,  to move it to the selected measurements. Hold the Ctrl key on your keyboard to select multiple measurements.

In the block parameters dialog box, type the name of the measurement you want to use. The **All Measurements** lists displays a list of all matching names. Click the x to clear your search.

### Selected Measurements — List selected measurements

measurement names

This list displays your selected measurements. To remove a measurement from this list, select the measurement and click the remove button, .

In the **Block Parameters** dialog box, use the toggle buttons   to reorder the selected measurements.

### Block Input Settings — Set the port input as Compu method conversion values or raw values

Raw values as double (no Compu method conversion) (default) | Raw values (no Compu method conversion) | Physical values (apply Compu method conversion)

This parameter enables support for XCP data types and dimensions as defined in the ASAP2 standard. The Block Input Settings parameter selects whether the port outputs Compu method conversion values or raw values. The options provide:

- **Physical values (apply Compu method conversion)** enables the physical-to-raw conversion of ECU measurement values. For this option, the block port settings are set either to 'double' or 'string', based on the underlying Compu method conversion. For example, Compu method IDENTICAL, LINEAR, RAT\_FUNC, TAB\_INTP, and TAB\_NOINTP port settings is 'double' while Compu method TAB\_VERB port settings is 'string'. The maximum string length supported for Compu method conversion is 1024 as specified in the ASAM XIL specification.

The FORM Compu method conversion is not supported. Simulink throws a warning for such a conversion and IDENTICAL conversion is applied to the underlying measurement. Also, only scalar measurement signals are supported for TAB\_VERB conversion as Simulink only supports scalar strings.

Selecting this option shows the physical units (if any) in front of the measurement name on the block mask. This physical unit is acquired from the A2L description of the measurement and Compu method. If the physical unit is not specified, only the measurement name is displayed.

- **Raw values (no Compu method conversion)** sets the port data type according to the type definition in the A2L file and supports up to three-dimensional XCP measurements in Simulink.
- **Raw values as double (no Compu method conversion)** sets the port data type as double, converting all internal measurement values. This selection supports up to three-dimensional XCP measurements in Simulink.

These ASAP2 data types are supported by corresponding Simulink port data types:

- SBYTE
- UWORD
- SWORD
- ULONG
- SLONG

- A\_UINT64
- A\_INT64
- FLOAT32\_IEEE
- FLOAT64\_IEEE

The dimension support in the block accommodates the different treatment of matrices by MATLAB and the ECU. The MATLAB default operation treats matrices as row-major matrices. An XCP measurement can have a LAYOUT as COLUMN\_DIR or ROW\_DIR . If a matrix measurement is COLUMN\_DIR, the blocks rearrange the measurement in memory and ensure that the matrix (row X, col Y) in MATLAB refers to the same entry as (row X, col Y) on the ECU. The rearrangement causes matrix entries that are contiguous on the ECU to be noncontiguous in MATLAB and Simulink.

**Enable Timestamp** — Enable sending Simulink timestamp in STIM DTO packets  
off (default) | on

When the Timestamp is enabled, the block inputs a timestamp from Simulink and sends the timestamp in the STIM DTO packets. The **Enable Timestamp** check box appears in the block parameters dialog box when the parameter is supported in the A2L file.

## Version History

Introduced in R2019a

### R2021b: Compu Method Conversion Support

To add Compu method conversion support, the **Force Datatypes and Allow Non-Scalar** parameter for the XCP CAN Data Acquisition block, XCP CAN Data Stimulation block, XCP UDP Data Acquisition block, and XCP UDP Data Stimulation block has been replaced with the **Block Input/ Output Settings** parameter. Using this parameter, you can select whether to apply Compu method conversion to block input or output.

## Extended Capabilities

### C/C++ Code Generation

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see Supported and Compatible Compilers.


## See Also

### Blocks

XCP UDP Configuration | XCP UDP Data Acquisition | XCP UDP Bypass

## XCP UDP Bypass

Connect the function-call output to a function-call subsystem



### Libraries:

Vehicle Network Toolbox / XCP Communication / UDP  
 Simulink Real-Time / XCP / UDP

### Description

The XCP UDP Bypass block connects the function-call output to a function-call subsystem containing one data acquisition list. The block issues a function-call when the downstream data acquisition list has new data available.

Consider the downstream function-call subsystem as a bypass task:

In Simulink Real-Time, the bypass task is executed asynchronously with the assigned task priority.

In Simulink, the block checks for data acquisition data periodically at the assigned sample rate and executes the bypass task accordingly.

### Ports

#### Output

**Function-call** — Function call for bypass  
 function call

Connects the function-call output to a function-call subsystem containing one data acquisition list.

### Parameters

**Task Priority** — Task priority in QNX Neutrino scheduler  
 191 (default) | integer

Select the task priority for the QNX Neutrino scheduler.

**Sample Time** — Sample time  
 -1 (default) | double

Select the sample time. For more information, see “Sample Times in Subsystems”.

## Version History

Introduced in R2020b



## **Extended Capabilities**

### **C/C++ Code Generation**

Generate C and C++ code using Simulink® Coder™.

The XCP communication blocks support code generation with limited deployment portability that runs only on the host computer or Simulink Real-Time targets.

Code generation requires a C++ compiler that is compatible with the code generation target. For more information, see Supported and Compatible Compilers.

### **See Also**

[XCP UDP Data Acquisition](#) | [XCP UDP Data Stimulation](#) | [XCP UDP Configuration](#)



# Speedgoat Blocks Library



# Speedgoat Support

---

## Speedgoat Target Computers and Speedgoat Support

Speedgoat target computers are real-time computers fitted with a set of I/O hardware, Simulink programmable and configurable FPGAs, and communication protocol support. Speedgoat target computers are optimized for use with Simulink Real-Time and fully support the HDL Coder™ workflow.

Speedgoat real-time target machines include:

- Performance — Highest performance, cost-effective real-time system for office or lab. Supports up to 50 I/O modules.
- Mobile — Compact, rugged, fanless, and expandable real-time system. For mobile and in-vehicle use and use in confined areas. Provides an extended operating temperature range. Supports up to 14 I/O modules.
- Baseline — Small, rugged, and fanless real-time system. For mobile, in-vehicle, and classroom use and use in confined areas. Provides an extended operating temperature range. Supports up to 7 I/O modules
- Audio — Real-time system optimized for audio applications, such as hearing aids and car acoustics.
- Unit — Small, rugged real-time system for mobile, field, in-vehicle and classroom use and use in confined areas. Provides an extended operating temperature range. Supports 1 I/O module

When you install the Speedgoat I/O Blockset, the installer sets up help for the blocks in the MATLAB Help browser. To view the Speedgoat I/O Blockset documentation, open the Help browser and navigate to the home page. At the bottom right of the home page, under **Supplemental Software**, click Speedgoat I/O Blockset.

To install your Speedgoat I/O Blockset, go to [www.speedgoat.com/extranet](http://www.speedgoat.com/extranet), the Speedgoat Customer Portal. Follow the instructions to download and install the Speedgoat I/O Blockset.

You can find Speedgoat real-time target machine configuration documentation online at [www.speedgoat.com/help](http://www.speedgoat.com/help).

You can find Speedgoat real-time target machine product information online at [www.speedgoat.com/products-services](http://www.speedgoat.com/products-services).

### Speedgoat I/O Hardware

Speedgoat provides a wide range of I/O hardware with ready-to-use configurations for rapid control prototyping (RCP) and hardware-in-the-loop (HIL) simulations. Speedgoat I/O connectivity includes support for:

- Analog I/O: single-ended or differential inputs or outputs, with or without isolation, 16-24 bit, voltage and current controlled
- Digital I/O: LVCMOS, TTL, RS-422, RS-485, LVDS
- FPGA code modules for:
  - Interrupts
  - PWM generation and capture, pulse patterns
  - Quadrature decoding and encoding (measurement and simulation)

- SSI protocol
- SSI2 protocol
- EnDat 2.2 decoder, encoder, and sniffer (measurement and simulation)
- BiSS decoder, encoder, and sniffer (measurement and simulation)
- SPI protocol
- I<sup>2</sup>C controller and peripheral
- Cam and crank decoder and simulator (measurement and simulation)
- UART (RS-485/RS-422)
- Aurora 64B/66B protocol
- And more
- LVDT/RVDT and synchro/resolver (measurement and simulation)
- Serial:
  - RS-232, RS-422, RS-485
  - SDLC, HDLC
- Shared memory
- Thermocouple, RTD, and strain gauge (measurement and simulation)
- Vibration measurements (IEPE/ICP transducers)
- Programmable resistors and potentiometers
- SPDT, SPST, and DPST reed relays
- Fault insertion
- Battery management systems

## Speedgoat Communication Protocols

Speedgoat provides communication protocol support for I/O hardware with ready-to-use configurations. Speedgoat communication protocols include:

- CAN, CAN FD, LIN, SAE J1939, and FlexRay<sup>®</sup>
- XCP over Ethernet, XCP over CAN
- MIL-STD-1553, ARINC-429, ARINC-629, AFDX (ARINC 664 Pt7)
- EtherCAT protocol
- Real-time UDP, Real-time raw Ethernet, TCP/IP
- EtherNet/IP<sup>™</sup> Scanner and EtherNet/IP Adapter
- PROFINET controller and PROFINET device
- PROFIBUS protocol
- Modbus TCP Client, Modbus TCP Server, Modbus RTU
- POWERLINK Controlled Node
- Timing and synchronization: PTP (Precision Time Protocol, IEEE 1588), GPS, IRIG
- UART (RS-232, RS-422, RS-485)
- I2C, SPI, SSI, SSI2, EnDAT 2.2, BiSS

- Camera Link®
- Aurora 8B/10B and 64B/66B multigigabit links for FPGA

## **See Also**

### **More About**

- “Set Up and Configure Simulink Real-Time”

### **External Websites**

- [www.speedgoat.com/help](http://www.speedgoat.com/help)
- [www.speedgoat.com/products-services](http://www.speedgoat.com/products-services)
- [www.speedgoat.com](http://www.speedgoat.com)