



Field Feature Bill of Material (FFBM)

PN 89H4327

INSTALLATION of a LIC Type 16 (FC 5216) in IBM 3746 Model 900.

Written by: J. Michaut
Illustration by: S. Vaccaro
Checked by: S. Vaniet / J. Thabourin
Approved by: A. Badino
Reviewed by: B. Kelly



PN 89H4328 2 of 10	EC E59246B 08NOV96				
-----------------------	-----------------------	--	--	--	--



Before Installation (Steps 1-8)

1.0 Machines Affected

3746 Model 900.

2.0 Related BMs and ECs

2.1 Prerequisites

(Must be installed prior to this installation)

- Microcode level: D46120 or higher.

Checkpoint: Check that the EC Level of the Basic Level Packaging Unit CCS is D46120.000 or higher.

Note: Refer to *SPIM*, Chapter 3. 'Displaying the EC Level of Code'.

2.2 Concurrent

(Must be installed together)

None.

2.3 Companion

(Must be installed separately)

None.

3.0 BMs to be Installed

FFBM **Title.**

89H4327 Installation of a LIC type 16 (FC 5216).

4.0 Preparation

1. See the *HONE configuration sheet/ plugging sheet* and the following figures to determine the cassette positions.




Figure 1. Basic Enclosure




Figure 2. 1st or 2nd Expansion Enclosure

3746	PN 89H4328	EC E59246B				
FFBM	3 of 10	08NOV96				



- ___ 2. Familiarize yourself with the purpose and details of these installation instructions before negotiating machine time with the customer.
- ___ 3. Check all the items and count the parts listed on the BM to be installed to determine whether all the parts were received.

5.0 Programming

5.1 Diagnostic Programs

None.

6.0 Purpose and Description

6.1 Purpose

To support the ISDN operation on 3746-9x0

6.2 Description

- Enabling ISDN operation (If not already done).
- Installation of a LIC 16 cassette and reconfiguration of the machine.

7.0 Installation Time

FFBM Installed	Machine Hours	System Hours	Nbr CE
89H4328	0.5	0.0	1

8.0 Tools/Materials Required

ESD kit (PN 6428316).

Installation (Steps 9-11)

9.0 Safety

Review the **Safety Notices** and the **Service Inspection Procedures** located at the beginning of the:

- *3746 Model 900 Service Guide* manual, SY33-2116, or
- *3746 Model 950 Service Guide* manual, SY33-2106.

Review the **Safety Notices** and the **Safety Inspection Procedures** located at the beginning of the *3745 Maintenance Information Procedure (MIP)* manual, SY33-2054.

10.0 Details of Installation

Before the installation, ask the customer:

- ___ • For the maintenance password.
- ___ • To logoff the Service Processor (SP), if not already done.

10.1 3746-900 Power Mode

- ___ • If the 3746-900 is in Power Mode 1 (remote), set the **Power Control** indicator of the 3746-900 control panel to 3 (local). Press the **Validate** key.

10.2 Log the SP ON

- ___ 1. On **MOSS-E View** window, click on **Program**.
- ___ 2. Click on **LOG ON MOSS-E**.
- ___ 3. Enter the maintenance password, press **Enter**.



10.3 Enabling ISDN Feature on the 3746-9x0

1. Double click on the **Service Processor** object icon.
2. Click on "**Configuration Management**".
3. Double click on "**Manage 3745/3746-9x0 installation/Removal**".
4. On the **Controller Installation** menu: Click on the 3746-950 or the 3746-900NN, on which the feature should be installed, then Click on **Select Feature** button.

Controller	Type	Model	S/N	Last changes saved
BS8-810L	<3745 not installed>	3746	950 [APPN]	12-34567 <Not saved>
BS FVT	3745	900	BS-24681	<Not saved>
	3746	900	BS-24681	<Not saved>
<New>	<3745 not installed>			
	<3746 not installed>			
<New>	<3745 not installed>			
	<3746 not installed>			
<New>	<3745 not installed>			
	<3746 not installed>			


5. The **Features Selection** window is displayed. Is ISDN feature already selected?
 - YES, Click on **Cancel**, then go to 10.6, "3746-9x0 Power Mode" on page 8.
 - NO, Click on the "**ISDN**" selection box, then click on **OK**.

If both **APPN** and **IP** were not selectable on the **Feature Selection** window, the process will directly go to 7 on page 6.


Features	Password
<input checked="" type="checkbox"/> APPN/HPR	no password
<input checked="" type="checkbox"/> IP	
<input checked="" type="checkbox"/> X.25	
<input type="checkbox"/> CCM C/S	
<input checked="" type="checkbox"/> ISDN	no password



- ___ 6. On the **Network Routing Protocol Selection Per Processor Type** display:
Click on **OK**.



- ___ 7. On the **Features selection successful message** display: Click on **OK**.



- ___ 8. On the **Controller Installation** menu, click on **CANCEL**.

___ Is there any error? ___

- **YES**, note message and code, then contact your support.
- **NO**, Go to 9.

- ___ 9. From the **MOSS-E View** screen, double click on the **Controller 3746-900** object icon, on which the feature has been installed.
- ___ 10. Click on **Operation Management**
- ___ 11. Double click on **Perform General IML**

10.4 LIC16 Coupler Cassette Installation

- ___ 1. Double click on the **3746-9x0** icon.
- ___ 2. On **3746-900 Menu** window, click on **Configuration Management**.
- ___ 3. Click on **Display/Update Active Configuration (CDF-E)**.
- ___ 4. Is the CLP available for the position of the LIC16 coupler you are installing?
 - **NO**, do not continue the installation of the feature. Inform your Sales Representative.
Click on **Cancel**, then go to 10.6, "3746-9x0 Power Mode" on page 8.
 - **YES**, Click on **Cancel**, then continue with next step.
- ___ 5. Double click on **Add/Retrieve Resources in Concurrent Mode**.

When **Confirmation** screen is displayed, follow this procedure:
 - ___ 6. Remove the dummy cassette.
 - ___ 7. Plug LIC16 coupler following the instructions on the label fitted to the frame.
 - ___ 8. **Wait** for alarm 0052: **FRU plugged OK**,
Verify the displayed positions of the coupler cassette, then Click on **OK**.
 - ___ 9. On confirmation screen, click on **OK**.
 - ___ 10. On **Resource Selector** window, click on the resource you want to add, then Click on **OK**.
 - ___ 11. On **Add/Retrieve Resource Options** window, click on **OK**.
 - ___ 12. On **Test and Running Option Selection** window, click on **LIC16 MAT**, then click on **OK**

The **Information Required** window is displayed.
 - ___ 13. When prompted install the wrap plug PN 57G8097 on the LIC16 coupler, Enter **Yes**, then click on **OK**

The **Diagnostic Active Status** window is displayed.
 - ___ 14. When the test is completed an **Information Message** gives the test results. Click on **OK**

The **Diagnostic Warning** window is displayed:
 - ___ 15. When prompted remove the wrap plug PN 57G8097 on the LIC16 coupler, then click on **OK**

The **Diagnostic Active Status** window is displayed with the number of errors:
 - ___ 16. **If an alarm is displayed**, see the *MIP*, Chapter 1, and follow the appropriate procedure.



- ___ 17. **If there is no error**, click on **Cancel**.
- ___ 18. Plug the cable into the LIC16 coupler cassette.
- ___ 19. Click on **Remove the resource from the concurrent mode**, click on **OK**.
- ___ 20. On the Warning window, click on **OK**.
- ___ 21. **Wait** for alarm 0657 concurrent mode, click on **OK**.
- ___ 22. If a confirmation window is displayed, click on **Cancel**.
If the **Resource Selector** is displayed, click on **Cancel**.

10.5 Save CDF-E on Diskette

- ___ 1. Double click on the SP icon.
- ___ 2. On **Service Processor Menu** window, click on **Configuration Management**.
- ___ 3. Double click on **Manage 3745-3746-9X0 Installation**.
- ___ 4. On **Controller Installation** window, select the machine you are installing/removing the cassette, then Click on **Save**.
- ___ 5. When requested, insert the *Installation Parameters Diskette* in the diskette drive of the SP.
- ___ 6. When the **Warning** window is displayed, remove the diskette and click on **OK**.
- ___ 7. On **Controller Installation** window, click on **Cancel**.

10.6 3746-9x0 Power Mode

- ___ • On the 3746-9x0 control panel, set the **Power Control** indicator to its original value. Press the **Validate** key.

10.7 Log the SP OFF

- ___ 1. On the **3746-9x0 Menu** window, click on **Function**, then, click on **Exit**.
- ___ 2. On the **MOSS-E View** window, click on **Program**.
- ___ 3. Click on **LOG OFF MOSS-E**.

11.0 Test Procedures

None.

After Installation (steps 12-15)

12.0 Field Updating

None.

13.0 Publications Update

None.

14.0 Parts Disposition

14.1 Purchased Machines

Refer to the parts ownership matrix to determine the correct owner of removed/unused parts.

- For EMEA/APG/AG Areas, refer to *Hardware and General Service Code Description*.
- For Domestic Areas, return parts to the customer.

15.0 Machine Records

- Install the new **MACHINE HISTORY** supplied.
- Report installation and quality to existing procedures.

End of instructions.

