



6-2-2 7-digit pager mode




D appears to indicate the 7-digit pager mode. The 7-digit mode is used to call specific stations on an individual basis. In particular, where permissible the Dealer can set group calls.

(1) Transmit

Transmit code configuration

The 7-digit code to call a station consists of the following.



Answering station's code 3-digit numeral

Transmit method

A. Enter keys according to table 1 "key input code." Pushing the * key transmits the entered code.




B. While pushing the PTT, push keys to transmit codes on a real-time basis.
Refer to table 1 "transmit codes" for details.

Calling a group

Where permissible by the dealer, "A" can be used to substitute other numbers (0 to 9) of a specific station's code. For example, entering "12A" will call all stations with codes "120" to "129." The "A" may be used for more than one digit.

4. BASIC OPERATION



4-1 RECEIVING



1. Power ON and audio adjustment
Rotate the volume control clockwise to turn the power ON. Continue rotating clockwise to increase the audio output to a suitable level.
2. Squench adjustment
To adjust the squench to the threshold level, rotate the squench control completely counterclockwise, then slowly rotate it clockwise until the audio noise is just muted when receiving no signal.
3. Setting the memory channel number
Rotate the dial control clockwise to increase the memory channel number and counterclockwise to decrease the memory channel number.

Only memory channels with frequencies, etc. programmed into them will be indicated.

4-2 TRANSMITTING



1. Setting a memory channel number
Set a memory channel number the same as for receiving.
2. Push the PTT key to begin transmitting.
ON AIR appears in the LCD. Continue pushing the PTT key and speak normally into the microphone on the front panel to communicate.
3. Release the PTT key to return to receiving.
To communicate with specific stations only, see p. 12 for details.

Transmit time limits (Time-out-timer)

After pushing the PTT for a specified time, the transceiver will automatically return to receive. (This time is set by your dealer in 30 secs. steps from 30 secs. to 450 secs.)

To continue transmitting after the transceiver returns to receive, release the PTT, then push and hold it to transmit again.