


FLUKE®

FlukeView Forms

Documenting Software

1653 Tester Connection Page



apx031f.eps

Note

Before the USB-IR cable can be used, software drivers must be installed on your Windows PC. See the USB-IR Cable Installation Instructions for more information.

To connect the 1653 electrical installation tester to the PC for use with *FlukeView Forms Documenting Software*:

1. Remove all leads from the 1653; otherwise serial communications will be disabled.
2. Connect the USB-IR cable to an available USB port on the PC.
3. Attach the IR adapter and the device to the tester as shown in the figure above. Be sure to align the IR adapter to the IR port on the tester, or communications with the PC may not function, or will be intermittent.
4. Open *FlukeView Forms Documenting Software*.
5. The current COM serial port setting is displayed at the bottom right of the *FlukeView Forms* window. Double-click on it to change the COM port setting to the virtual COM port used by the USB-IR cable.
6. Press **ⓘ** to turn the tester on.
7. Follow the instructions for transferring data from the tester to the PC found in the online *Users Manual*.