


FlukeView Forms

Documenting Software

1550B MegOhmMeter Connection Page



ASW04F.eps

Note

Before the USB-IR cable can be used, software drivers must be installed on your Windows PC. See the USB-IR Cable Installation Instructions for more information.

To connect the 1550B MegOhmMeter to the PC for use with *FlukeView Forms Documenting Software*:

1. The 1550B should not be running a test; otherwise, serial communications will be disabled.
2. Connect the USB-IR cable to an available USB port on the PC.
3. Attach the IR device to the IR port on the 1550B MegOhmMeter as shown in the figure above.
4. Open *FlukeView Forms Documenting Software*.
5. The current COM serial port setting is displayed at the bottom right of the *FlukeView Forms* window. Double-click on it to change the COM port setting to the virtual COM port used by the USB-IR cable.
6. Turn the 1550B MegOhmMeter on.
7. Follow the instructions for transferring data from the MegOhmMeter to the PC found in the online *Users Manual*.