



EAGLE
PAN TILT SYSTEMS
Helping to bring your world
into focus

5880 N. Sheridan Blvd.
Arvada, CO, USA 80003
(V) 303-412-0399 x22
(F) 303-412-9346
Toll Free: 877-862-6865
<http://www.eaglepan tilt.com>
E-mail: shawn@displaydevices.com

ADDITIONAL NOTES FOR PT-50SDI PAN TILT HEAD




The operations of the PT-50 SDI are exactly the same as the standard PT-50 pan tilt head. The only differences are:

Single integrated 15 pin cable provides camera power, control, and video to internal SDI converter. This cable replaces the standard Y-cable included with the PT-50.

Genlock input BNC on base feeds genlock to the SDI converter. The converter can be configured to accept either wide or narrow pulses; factory standard is narrow. If you have trouble getting the camera to genlock, remove the base cover of the PT-50SDI, and flip switch number 2 on the SDI converter to ON.

Normally, both switches 1 and 3 should be in the ON position.

NOTE: You must set the 15 pin output of your camera to Y/C and not RGB or Component for the SDI converter to work correctly!!



IMPORTANT NOTE:

DO NOT INSERT MOUNTING BOLTS INTO THE PT50 SDI BASE THAT WILL PROTRUDE MORE THAN .25" (6mm) INTO THE BASE. DAMAGE TO THE INTERNAL SDI CONVERTER MAY RESULT IF TOO LONG A MOUNTING BOLT IS USED AS THE BOLT MAY MAKE CONTACT WITH THE ADAPTER!!!