

JVC


SERVICE MANUAL

COLOUR TELEVISION

AV-29BF11ENS

AV-29BF11EPS

AV-29BF11EES



CONTENTS

■ SPECIFICATIONS	2
■ SAFETY PRECAUTIONS	4
■ FEATURES	5
■ MAIN DIFFERENCE LIST	5
■ SPECIFIC SERVICE INSTRUCTIONS	6
■ SERVICE ADJUSTMENTS	11
■ PARTS LIST	23
★ OPERATING INSTRUCTIONS	
★ STANDARD CIRCUIT DIAGRAM	2-1

AV-29BF11ENS
AV-29BF11EPS
AV-29BF11EES

SPECIFICATIONS

ITEM		Content		
		AV-29BF11ENS	AV-29BF11EPS	AV-29BF11EES
Dimensions (WxHxD)		78.4 × 58.2 × 49.3 cm		
Mass		46.2 kg		
TV RF System		B/G	B/G, L	B/G, D/K, K1
Colour System	TV Mode	PAL	PAL / SECAM	←
	Video Mode	PAL / NTSC 3.58 / NTSC 4.43	PAL / SECAM / NTSC 3.58 / NTSC 4.43	←
Teletext System		Fastext / Toptext		
Stereo System		German + NICAM		
Tuning System		Frequency Synthesizer Tuning System		
Number of CH memory position		100 ch		
Receiving Frequency	VHF (VL)	46.25MHZ ~ 168.25MHz		
	VHF (VH)	175.25MHz ~ 463.25MHz		
	UHF	471.25MHz ~ 863.25MHz		
	CATV	B/G :S01-S41, S75-S79	B/G :S01-S41, S75-S79 L : S01-S41, S75-S77	B/G :S01-S41, S75-S79 D/K : S01-S41
Intermediate Frequency	VIF Carrier	38.9MHz		
	SIF Carrier	32.4MHz (6.5MHz : L)		
		32.9MHz (6.0MHz : D/K)		
		33.4MHz (5.5MHz : B/G)		
Colour Sub Carrier Frequency		PAL (4.43MHz), SECAM (4.43MHz), NTSC (3.58MHz/4.43MHz)		
Aerial Input Terminal		75 Ohm Unbalanced		
Power Input		AC 220 ~ 240V, 50Hz		
Power Consumption		135W(Max.) / 120W(Avg.) , <4W(Standby)		
Picture Tube		Visible size : 68cm Measured diagonally		
High Voltage		29.6kV		
Speaker		(77 ×128 mm oval type + Tweeter) ×2		
Audio Output		10W + 10W		
Input	Video	1V(p-p), 75 Ohm		
	Audio (L/R)	500 mV(rms), High Impedance		
Output	Video	1 V(p-p), 75 Ohm		
	Audio (L/R)	500 mV(rms), Low Impedance		
Input Terminal	Rear Side	AV 1 (Video/Audio/RGB)		
		AV 2 (Video/Audio/S-VHS)		
	Front Side	AV 3 (Video/Audio)		
Output Terminal	Front Side	Headphone jack (Stereo mini jack 3.5 ϕ)		
	Rear Side	AV 1 (Video/Audio)		
		AV 2 (Video/Audio) (Selected TV, AV1 or AV3)		
Remote Control Unit		VE-30017763 (RM-C1100) , Battery size:AA/R06 x 2		


Design & specifications are subject to change without notice.

■ 21-pin Euro connector (SCART socket) : AV 1 / AV 2

(P-P= Peak to Peak, S-W= Sync tip to white peak, B-W= Blanking to white peak)

Pin No.	Signal Designation	Matching Value	AV 1	AV 2
1	AUDIO R output	500mV(rms) (Nominal),Low impedance	○ (TV OUT)	○ (TV/LINE OUT)
2	AUDIO R input	500mV(rms) (Nominal),High impedance	○	○
3	AUDIO L output	500mV(rms) (Nominal),Low impedance	○ (TV OUT)	○ (TV/LINE OUT)
4	AUDIO GND		○	○
5	GND (B)		○	○
6	AUDIO L input	500mV(rms) (Nominal), High impedance	○	○
7	B input	700mVB-W, 75 Ω	○	NC
8	FUNCTION SW (SLOW SW)	Low : 0-3V, High : 8-12V, High impedance	○	NC
9	GND (G)		○	○
10	-		NC	-
11	G input	700mVB-W, 75 Ω	○	NC
12	-		NC	-
13	GND (R)		○	○
14	GND (YS)		○	NC
15	R / C input	R : 700mVB-W, 75 Ω C : 300mV(P-P), 75 Ω	○ (R/C)	○ (only C)
16	Ys input	Low : 0 – 0.4, High : 1 - 3V, 75 Ω	○	NC
17	GND(VIDEO output)		○	○
18	GND(VIDEO input)		○	○
19	VIDEO output	1Vs-w(Negative going sync), 75 Ω	○ (TV)	○ (TV/LINE OUT)
20	VIDEO / Y input	1Vs-w(Negative going sync), 75 Ω	○	○
21	COMMON GND		○	○

[Pin assignment]



SAFETY PRECAUTIONS

1. The design of this product contains special hardware, many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Service should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the products should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the parts list of Service manual. **Electrical components having such features are identified by shading on the schematics and by (Δ) on the parts list in Service manual.** The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement part shown in the parts list of Service manual may cause shock, fire, or other hazards.
4. **Don't short between the LIVE side ground and ISOLATED (NEUTRAL) side ground or EARTH side ground when repairing.**
Some model's power circuit is partly different in the GND. The difference of the GND is shown by the LIVE side GND, the ISOLATED(NEUTRAL) side GND and EARTH side GND. Don't short between the LIVE side GND and ISOLATED(NEUTRAL) side GND or EARTH side GND and never measure with a measuring apparatus (oscilloscope etc.) the LIVE side GND and ISOLATED(NEUTRAL) side GND or EARTH side GND at the same time.
If above note will not be kept, a fuse or any parts will be broken.
5. If any repair has been made to the chassis, it is recommended that the B1 setting should be checked or adjusted (See ADJUSTMENT OF B1 POWER SUPPLY).
6. The high voltage applied to the picture tube must conform with that specified in Service manual. Excessive high voltage can cause an increase in X-Ray emission, arcing and possible component damage, therefore operation under excessive high voltage conditions should be kept to a minimum, or should be prevented. If severe arcing occurs, remove the AC power immediately and determine the cause by visual inspection (incorrect installation, cracked or melted high voltage harness, poor soldering, etc.). To maintain the proper minimum level of soft X-Ray emission, components in the high voltage circuitry including the picture tube must be the exact replacements or alternatives approved by the manufacturer of the complete product.
7. Do not check high voltage by drawing an arc. Use a high voltage meter or a high voltage probe with a VTVM. Discharge the picture tube before attempting meter connection, by connecting a clip lead to the ground frame and connecting the other end of the lead through a 10kΩ 2W resistor to the anode button.
8. When service is required, observe the original lead dress. Extra precaution should be given to assure correct lead dress in the high voltage circuit area. Where a short circuit has occurred, those components that indicate evidence of overheating should be replaced. Always use the manufacturer's replacement components.

9. Isolation Check

(Safety for Electrical Shock Hazard)

After re-assembling the product, always perform an isolation check on the exposed metal parts of the cabinet (antenna terminals, video/audio input and output terminals, Control knobs, metal cabinet, screwheads, earphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.

(1) Dielectric Strength Test

The isolation between the AC primary circuit and all metal parts exposed to the user, particularly any exposed metal part having a return path to the chassis should withstand a voltage of 3000V AC (r.m.s.) for a period of one second.

(... Withstand a voltage of 1100V AC (r.m.s.) to an appliance rated up to 120V, and 3000V AC (r.m.s.) to an appliance rated 200V or more, for a period of one second.)

This method of test requires a test equipment not generally found in the service trade.

(2) Leakage Current Check


Plug the AC line cord directly into the AC outlet (do not use a line isolation transformer during this check.). Using a "Leakage Current Tester", measure the leakage current from each exposed metal part of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground (water pipe, etc.). Any leakage current must not exceed 0.5mA AC (r.m.s.).

However, in tropical area, this must not exceed 0.2mA AC (r.m.s.).

● Alternate Check Method

Plug the AC line cord directly into the AC outlet (do not use a line isolation transformer during this check.). Use an AC voltmeter having 1000 ohms per volt or more sensitivity in the following manner. Connect a 1500Ω 10W resistor paralleled by a 0.15μF AC-type capacitor between an exposed metal part and a known good earth ground (water pipe, etc.). Measure the AC voltage across the resistor with the AC voltmeter. Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75V AC (r.m.s.). This corresponds to 0.5mA AC (r.m.s.).

However, in tropical area, this must not exceed 0.3V AC (r.m.s.). This corresponds to 0.2mA AC (r.m.s.).



FEATURES

1. It is a remote controlled colour television.
2. 100 programs from VHF, UHF bands or cable channels can be preset.
3. It can tune cable channels.
4. Controlling the TV is very easy by its menu driven system.
5. It has two Euroconnector sockets for external device (such as video recorder, video games, audio set, etc.)
6. Front AV Input available.
7. Stereo sound systems (German + Nicam) are available.
8. Full function Teletext (Fastext, Toplevel).
9. It is possible to connect headphone.
10. Direct channel access.
11. APS (Automatic Programming System).
12. All programs can be named.
13. Forward or backward automatic tuning.
14. Sleep timer
15. Child LOCK
16. Automatic sound mute when no transmission.
17. 5 minutes after the broadcasting (closedown), the TV switches itself automatically to stand-by mode.

MAIN DIFFERENCE LIST

MODEL No. Parts Name	AV-29BF11ENS	AV-29BF11EPS	AV-29BF11EES
MAIN PWB	VE-20103272	VE-20103267	VE-20103265
LABEL	VE-20103656 VE-20103677(GER) VE-20103679 (ITA)	VE-20103654	VE-20103640 VE-20103638 (POL)
CARTON BOX	VE-50028949 VE-50028950 (GER)	VE-50028947	VE-50028945
INST BOOK	VE-50028493	VE-50028296	VE-50028326

SPECIFIC SERVICE INSTRUCTIONS

DISASSEMBLY PROCEDURE

REMOVING THE REAR COVER

1. Remove the **8** screws marked **A**.
2. Remove the **4** screws marked **B**.
3. Withdraw the rear cover toward you.

REMOVING THE MAIN PWB

- Removing the rear cover.
1. Slightly raise the both sides of the chassis by hand and withdraw MAIN PWB back ward.

[CAUTIONS]

- If necessary, take off the wire clamp, connectors etc.
- Be careful enough when developing a main chassis.

REMOVING THE FRONT AV & HEADPHONE BOARD ASS'Y

- Removing the rear cover.
 - Removing the MAIN PWB.
1. Remove the **2** screws marked **C**, and remove the FRONT AV & HEADPHONE BOARD ASS'Y.

REMOVING THE FRONT CONTROL PWB

- Removing the rear cover.
 - Removing the MAIN PWB.
1. Remove the **3** screws marked **D**, and remove the FRONT CONTROL PWB.

REMOVING THE WOOFER and TWEETER

- Removing the rear cover.
1. Remove the **4** screws marked **E**, and remove the WOOFER.
 2. Remove the **2** screws marked **F**, and remove the TWEETER.
 3. Remove an opposite side similarly.

REMOVING THE MAIN SWITCH

- Removing the rear cover.
 - Removing MAIN PWB.
1. Remove the **2** screws marked **G**, and remove the MAIN SWITCH.

CHECKING THE PW BOARD

To check the back side of the PW Board.


- 1) Pull out the PW Board. (Refer to REMOVING THE MAIN PWB).
- 2) Erect the PW Board vertically so that you can easily check the back side of the PW Board.

[CAUTION]

- When erecting the PW Board, be careful so that there will be no contacting with other PW Board.
- Before turning on power, make sure that the wire connector is properly connected.
- When conducting a check with power supplied, be sure to confirm that the CRT EARTH WIRE (BRAIDED ASS'Y) is connected to the CRT SOCKET PW board.

WIRE CLAMPING AND CABLE TYING

1. Be sure to clamp the wire.
2. Never remove the cable tie used for tying the wires together.
Should it be inadvertently removed, be sure to tie the wires with a new cable tie.



REPLACEMENT OF CHIP COMPONENT

■ CAUTIONS

1. Avoid heating for more than 3 seconds.
2. Do not rub the electrodes and the resist parts of the pattern.
3. When removing a chip part, melt the solder adequately.
4. Do not reuse a chip part after removing it.

■ SOLDERING IRON


1. Use a high insulation soldering iron with a thin pointed end of it.
2. A 30w soldering iron is recommended for easily removing parts.

■ REPLACEMENT STEPS


1. How to remove Chip parts

◆ Resistors, capacitors, etc

- (1) As shown in the figure, push the part with tweezers and alternately melt the solder at each end.




- (2) Shift with tweezers and remove the chip part.




◆ Transistors, diodes, variable resistors, etc

- (1) Apply extra solder to each lead.



- (2) As shown in the figure, push the part with tweezers and alternately melt the solder at each lead. Shift and remove the chip part.




Note : After removing the part, remove remaining solder from the pattern.


2. How to install Chip parts

◆ Resistors, capacitors, etc

- (1) Apply solder to the pattern as indicated in the figure.




- (2) Grasp the chip part with tweezers and place it on the solder. Then heat and melt the solder at both ends of the chip part.




◆ Transistors, diodes, variable resistors, etc

- (1) Apply solder to the pattern as indicated in the figure.
- (2) Grasp the chip part with tweezers and place it on the solder.
- (3) First solder lead **A** as indicated in the figure.



- (4) Then solder leads **B** and **C**.



MEMORY IC REPLACEMENT

1. Memory IC

This model use a memory IC.

This memory IC stores data for proper operation of the video and deflection circuits.

When replacing, be sure to use an IC containing this (initial value) data.

2. Memory IC replacement procedure

(1) Power off

Switch off the power and disconnect the power cord from the wall outlet.

(2) Replace the memory IC

Initial value must be entered into the new IC.

(3) Power on

Connect the power cord to the wall outlet and switch on the power.

(4) SERVICE MENU setting

- 1) Press MENU key and, while the displayed MENU screen, press **4, 7, 2, 5** key on the remote control unit or press MUTING key and INFORMATION key at the simultaneously.
- 2) The SERVICE MENU screen of Fig.1 is displayed.
- 3) Verify what to set in the SERVICE MENU, and set whatever is necessary (Fig.1). Refer to the SERVICE ADJUSTMENT for setting.
- 4) Press the STANDARD key to exit SERVICE MENU.

(5) Receive channel setting

Refer to the OPERATING INSTRUCTIONS (USER'S GUIDE) and set the receive channels (Channels Preset) as described.

(6) User settings

Check the user setting items according to after page. Where these do not agree, refer to the OPERATING INSTRUCTIONS (USER'S GUIDE) and set the items as described.

SERVICE MENU

JVCAK30/37 B04	
OSD	064
IF1	001
IF2	076
IF3	003
IF4	063
AGC	033
VLIN	044
RGBH	037
VSOE	059
VPOF	008
1	1

Fig.1

SERVICE MENU SELECT KEY




Fig.2

SETTING OF THE LAST MEMORY FOR SHIPMENT

■ USER SETTING VALUES

Setting Item	Setting Value	Setting Item	Setting Value
SOUND MENU		FEATURE MENU	
BALANCE	CENTER	SLEEP TIMER	OFF
BASS	↑	CHILD LOCK	OFF
TREBLE	↑	LANGUAGE	ENGLISH
EFFECT	OFF	AV-2 OUTPUT	TV
PICTURE MENU		INSTALL	
BRIGHTNESS	These adjust are automatically restored when APS bit in Service menu is set.	PROGRAMME	Refer to the INSTRUCTION BOOK.
CONTRAST		BAND	
COLOUR		CHANNEL	
SHARPNESS	The procedure for setting APS bit is described below.	SEARCH	
HUE (only NTSC)		FINE TUNING	
PICTURE MODE	AUTO	STORE	

■ SETTING APS BIT IN SERVICE MENU

- 1) Enter service menu in TV mode by pressing "INFORMATION" and "MUTING" keys simultaneously. Service Menu will appear.
- 2) Select TX1(TELETEXT OPTION) by pressing Up/Down keys on remote control unit.
- 3) Press the 7 key on remote control unit to set APS bit. (After this, bit 7 of TX1 will be "1"). (Do not change any other bit.)
- 4) Press STANDARD key on remote control unit to exit service mode.

NOTE : DO NOT TURN OFF THE TV BY USING POWER BUTTON ON THE FRONT PANEL.

SERVICE ADJUSTMENTS

ADJUSTMENT PREPARATION

1. You can make the necessary adjustments for this unit with either the Remote Control Unit or with the adjustment tools and parts as given below.
2. Adjustment with the Remote Control Unit is made on the basis of the initial setting values, however, the new setting values which set the screen to its optimum condition may differ from the initial settings.
3. Make sure that AC power is turned on correctly.
4. Turn on the power for set and test equipment before use, and start the adjustment procedures after waiting at least 30 minutes.
5. Unless otherwise specified, prepare the most suitable reception or input signal for adjustment.

6. Never touch any adjustment parts which are not specified in the list for this adjustment - variable resistors, transformers, condensers, etc.
7. Presetting before adjustment.
Unless otherwise specified in the adjustment instructions, preset the following functions with the remote control unit.

BRIGHTNESS	CENTER
CONTRAST	
COLOUR	
SHARPNESS	


ADJUSTMENT EQUIPMENT

1. DC voltmeter (or digital voltmeter)
2. Signal generator (Pattern generator) [PAL/SECAM/NTSC]
3. Remote control unit

ADJUSTMENT ITEM

- SCREEN ADJUSTMENT
- OSD HORIZONTAL POSITION ADJUSTMENT
- IF ADJUSTMENT
- AGC AUTOMATICALLY ADJUSTMENT
- DEFLECTION CIRCUIT ADJUSTMENT
- GEOMETRY MENU ADJUSTMENT
- WHITE BALANCE ADJUSTMENT
- TXT BRIGHTNESS ADJUSTMENT

MAIN PARTS LOCATIONS



BASIC OPERATION SERVICE MENU

■ HOW TO ENTER THE SERVICE MENU

- 1) Press the **MENU** key.
- 2) MENU screen of fig.1 will be displayed




Fig.1

- 3) While the MENU screen is displayed, press the 4,7,2,5 key or INFORMATION key and MUTING key simultaneously.
- 4) The SERVICE MENU screen (Fig.2) will be displayed.




Fig.2

■ SELECTION OF ADJUSTMENT ITEMS

- 1) Enter the SERVICE MENU
- 2) Press the FUNCTION **▲/▼** key and select the ADJUSTMENT ITEM.
- 3) Press the FUNCTION **◀/▶** key and set the SETTING VALUE.

■ HOW TO EXIT SERVICE MODE

- 1) Press the **STANDARD** Key on REMOTE CONTROL UNIT.

■ HOW TO ENTER THE GEOMETRY MENU

- This model is built-in GEOMETRY MENU for geometry adjustment. For details, refer to the adjustment.
- 1) Enter the SERVICE MENU
 - 2) Press the GREEN key, geometry menu appears (Fig. 3).
 - 3) Press the FUNCTION **▲/▼** key and select the ADJUSTMENT ITEM.
 - 4) Press the FUNCTION **◀/▶** key and set the SETTING VALUE.





Fig.3



● FUNCTION OF COLOUR key

RED key :

It switches the AVL(Automatic volume control) to ON or OFF mode on service menu. AVL word is visible on service menu when AVL is on.

GREEN key :

It switches to GEOMETRY adjust menu. Geometry of the picture is adjusted in this menu.

YELLOW key :

It switches to VERTICAL SCAN DISABLE mode. It is useful to adjust screen voltage.

BLUE key :

It is used to adjust AGC and IF automatically on service menu.

■ ADJUSTMENT ITEM & INITIAL SETTING VALUE in the SERVICE MENU

1/2

ADJUSTMENT ITEM	DESCRIPTION	INITIAL VALUE
OSD	HORIZONTAL POSITION OF OSD	059
IF1	IF COARSE ADJUSTMENT	004
IF2	IF FINE ADJUSTMENT	065
IF3	IF COARSE ADJUSTMENT FOR L-PRIME	004
IF4	IF FINE ADJUSTMENT FOR L-PRIME	065
AGC	AUTOMATIC GAIN CONTROL	Automatically
VLIN	VERTICAL LINEARITY	Not used
RGBH	RGB MODE HORIZONTAL SHIFT OFFSET	005
VSOE	VERTICAL SIZE OFFSET for 60Hz	+05
VPOF	VERTICAL POSITION OFFSET for 60Hz	-01
HSOF	HORIZONTAL SIZE OFFSET for 60Hz	-02
HPOF	HORIZONTAL POSITION OFFSET for 60Hz	-06
HTOF	HORIZONTAL TRAPEZOID OFFSET for 60Hz	-03
WR	WHITE POINT ADJUSTMENT FOR RED	030
WG	WHITE POINT ADJUSTMENT FOR GREEN	030
WB	WHITE POINT ADJUSTMENT FOR BLUE	030
BR	BIAS FOR RED	028
BG	BIAS FOR GREEN	029
APR	AUTOMATIC RGB PEAK REGULATION THRESHOLD	004
BRI	BRIGHTNESS	032
CON	CONTRAST	033
COL	COLOUR	030
SHR	SHARP	006
HUE	HUE	031
VOL	VOLUME	009
WR-R	WHITE POINT ADJUSTMENT for RED (RGBmode)	022
WG-R	WHITE POINT ADJUSTMENT for GREEN (RGBmode)	032
WB-R	WHITE POINT ADJUSTMENT for BLUE (RGBmode)	022
FMP1	FM PRESCALER WHEN AVL IS OFF	Not used
NIP1	NICAM PRESCALER WHEN AVL IS OFF	Not used
SCP1	SCART PRESCALER WHEN AVL IS OFF	Not used
SEC1	SECAM PRESCALER WHEN AVL IS OFF	Not used
FMP2	FM PRESCALER WHEN AVL IS ON	015
NIP2	NICAM PRESCALER WHEN AVL IS ON	045
SCP2	SCART PRESCALER WHEN AVL IS ON	017
SEC2	SECAM PRESCALER WHEN AVL IS ON	Not used
F1H	HIGH BYTE OF VHF1-VHF3 CROSS-OVER FREQUENCY	00001001
F1L	LOW BYTE OF VHF1-VHF3 CROSS-OVER FREQUENCY	10010010
F2H	HIGH BYTE OF VHF3-UHF CROSS-OVER FREQUENCY	00011011
F2L	LOW BYTE OF VHF3-UHF CROSS-OVER FREQUENCY	10000010
BS1	BAND SWITCHING BYTE FOR VHF1	00000011
BS2	BAND SWITCHING BYTE FOR VHF3	00000110
BS3	BAND SWITCHING BYTE FOR UHF	10000101
CB	CONTROL BYTE	10001110



ADJUSTMENT ITEM	DESCRIPTION	INITIAL VALUE
OP1	PERIPHERAL OPTIONS	11110111
OP2	RECEPTION STANDARD OPTIONS	00001001 (EN) 01011001 (EP) 00011001 (EE)
OP3	VIDEO OPTIONS	01101100(EN) 11101100(EP/EE)
OP4	TV FEATURES	10001000
OP5	CHANNEL TABLES	0000000D
TX1	TELETEXT OPTIONS	11010101 (EN) 11000101 (EP) 11001101 (EE)
GEOM	GEOMETRY OPTIONS	00100000
OP8	PIP PRESET CHANGE	00000100

[GEOMETRY MENU]


ADJUSTMENT ITEM	DESCRIPTION	INITIAL VALUE	
		4:3 MODE	16:9 MODE
VSIZ	VERTICAL SIZE for 50Hz	038	009
VPOS	VERTICAL POSITION for 50Hz	022	025
VSCO	VERTICAL S-CORRECTION for 50Hz	005	005
VCCO	VERTICAL CORNER CORRECTION for 50Hz	007	007
HSIZ	HORIZONTAL SIZE for 50Hz	009	013
HPOS	HORIZONTAL POSITION for 50Hz	030	030
HPIN	HORIZONTAL PINCUSHION for 50Hz	014	012
HCCO	HORIZONTAL CORNER CORRECTION for 50Hz	010	010
HTRP	HORIZONTAL TRAPEZOID for 50Hz	013	018
VZSZ	VERTICAL ZOOM SIZE for 50Hz	Not used	Not used

ADJUSTMENTS

■ SCREEN ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description
SCREEN adjustment	Remote control unit		SCREEN VR [On the FBT]	<ol style="list-style-type: none"> 1. Enter SERVICE MENU. 2. Press YELLOW key to disable vertical scan. 3. Adjust SCREEN VR. on the FBT as thin as possible. 4. Press YELLOW key again to enable vertical scan. 5. Press STANDARD key to leave service menu.  

■ OSD HORIZONTAL POSITION ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description
HORIZONTAL POSITION OF OSD adjustment	Remote control unit		OSD	<ol style="list-style-type: none"> 1. Enter SERVICE MENU. 2. Select OSD (On screen display) with FUNCTION (▲/▼) key 3. Adjust the OSD horizontal position with the FUNCTION (◀/▶) key, which shifts the reference bar on the bottom of the SERVICE MENU horizontally, so that the OSD is positioned on the screen center. (X=X') 



■ IF ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description
IF adjustment	Remote control unit		IF 1 IF 2 IF 3 IF 4	<ol style="list-style-type: none"> 1. Receive a PAL colour bar pattern. 2. Enter SERVICE MENU. 3. Select IF 1 with FUNCTION (▲/▼) key 4. Press BLUE key during IF 1 is highlighted, IF 1 and IF 2 values are adjusted automatically by software. 5. If the standard is L-prime, IF 3 and IF 4 values are adjustment automatically when BLUE key is pressed during IF 1 is highlighted.

■ AGC AUTOMATICALLY ADJUSTMENT


Item	Measuring instrument	Test point	Adjustment part	Description																												
AGC AUTOMATIC- ALLY adjustment & check	Remote control unit		AGC	<div>1. Enter SERVICE MENU.</div> <div>2. Receive a 60dB μ V RF signal level.</div> <div>3. Select AGC with the FUNCTION ($\blacktriangle/\blacktriangledown$) key.</div> <div>4. Press BLUE key on the remote control unit.</div> <div>5. Then the adjustment will be done automatically by software.</div> <div>6. See the AGC indicator on SERVICE MENU, it must be "1".</div> <div>7. Check that picture is normal at 90dB μ V signal level.</div>																												
<div>SERVICE MENU SCREEN</div> <div><table><tr><td>JVCAK30/37</td><td>B04</td></tr><tr><td>QSD</td><td>059</td></tr><tr><td>IF1</td><td>004</td></tr><tr><td>IF2</td><td>065</td></tr><tr><td>IF3</td><td>004</td></tr><tr><td>IF4</td><td>065</td></tr><tr><td>AGC</td><td>033</td></tr><tr><td>VLIN</td><td>044</td></tr><tr><td>RGBH</td><td>005</td></tr><tr><td>VSOE</td><td>+05</td></tr><tr><td>VPOE</td><td>-01</td></tr></table><div>: 1 1</div></div> <div><table><tr><td>:</td><td>1</td><td>1</td></tr><tr><td>IF INDICATOR</td><td>AGC INDICATOR</td><td>NONE</td></tr></table></div>					JVCAK30/37	B04	QSD	059	IF1	004	IF2	065	IF3	004	IF4	065	AGC	033	VLIN	044	RGBH	005	VSOE	+05	VPOE	-01	:	1	1	IF INDICATOR	AGC INDICATOR	NONE
JVCAK30/37	B04																															
QSD	059																															
IF1	004																															
IF2	065																															
IF3	004																															
IF4	065																															
AGC	033																															
VLIN	044																															
RGBH	005																															
VSOE	+05																															
VPOE	-01																															
:	1	1																														
IF INDICATOR	AGC INDICATOR	NONE																														

■ DEFLECTION CIRCUIT ADJUSTMENT




Item	Measuring instrument	Test point	Adjustment part	Description
RGB MODE HORIZONTAL SHIFT OFFSET adjustment	Signal generator Remote control unit		RGBH	<ol style="list-style-type: none"> 1. Input R/G/B circle pattern signal via video input terminal. 2. Press AV key on the remote control unit, force the TV to RGB mode. 3. Enter SERVICE MENU. 4. Select RGBH (RGB mode horizontal shift) with the FUNCTION ($\blacktriangle/\blacktriangledown$) key. 5. Adjust RGBH with the FUNCTION ($\blacktriangleleft/\blacktriangleright$) key until the circle pattern is horizontally centered. ($A=B$) 6. Check and readjust RGBH item if the adjustment becomes improper after some other geometric adjustments are done.
				
VERTICAL SIZE OFFSET adjustment (60Hz)	Signal generator Remote control unit		VSOF	<ol style="list-style-type: none"> 1. Receive a NTSC-M cross-hatch pattern of vertical frequency 60Hz. 2. Enter SERVICE MENU. 3. Select VSOF (Vertical size) with the FUNCTION ($\blacktriangle/\blacktriangledown$) key. 4. Adjust VSOF with the FUNCTION ($\blacktriangleleft/\blacktriangleright$) key until the horizontal black lines on both the upper and lower part of the pattern become very close to the upper and lower horizontal sides of picture size and nearly about to disappear. 5. Check and readjust VSOF item if the adjustment becomes improper after some other geometric adjustments are done.
				



Item	Measuring instruments	Test point	Adjustment part	Description
VERTICAL POSITION OFFSET adjustment (60Hz)	Signal generator Remote control unit		VPOF	<ol style="list-style-type: none"> 1. Receive a NTSC-M circle pattern of vertical frequency 60Hz. 2. Enter SERVICE MENU. 3. Select VPOF (Vertical position) with the FUNCTION (▲/▼) key. 4. Adjust VPOF with the FUNCTION (◀/▶) key until the picture is vertically centered.(C=D) 5. Check and readjust vertical position item if the adjustment becomes improper after some other geometric adjustments are done.
HORIZONTAL SIZE OFFSET adjustment (60Hz)	Signal generator Remote control unit		HSOF	<ol style="list-style-type: none"> 1. Receive a NTSC-M cross-hatch pattern of vertical frequency 60Hz. 2. Enter SERVICE MENU. 3. Select HSOF (Horizontal size) with the FUNCTION (▲/▼) key. 4. Adjust HSOF with the FUNCTION (◀/▶) key until the vertical black lines on both the left and right part of the pattern become very close to the left and right vertical sides of picture size and nearly about to disappear. 5. Check and readjust a HSOF item if the adjustment becomes improper after some other geometric adjustments are done.
HORIZONTAL POSITION OFFSET adjustment (60Hz)	Signal generator Remote control unit		HPOF	<ol style="list-style-type: none"> 1. Receive a NTSC-M circle pattern signal of vertical frequency 60Hz. 2. Enter SERVICE MENU. 3. Select HPOF (Horizontal position) with the FUNCTION (▲/▼) key. 4. Adjust HPOF with the FUNCTION (◀/▶) key until the circle pattern is horizontally centered.(E=F) 6. Check and readjust a horizontal position item if the adjustment becomes improper after some other geometric adjustments are done.

AV-29BF11ENS
AV-29BF11EPS
AV-29BF11EES


Item	Measuring instruments	Test point	Adjustment part	Description
HORIZONTAL TRAPEZOID OFFSET adjustment (60Hz)	Signal generator Remote control unit		HTOF	<div>1. Receive a NTSC-M cross-hatch pattern signal of vertical frequency 60Hz.</div> <div>2. Enter SERVICE MENU.</div> <div>3. Select HTOF with the FUNCTION (▲/▼) key.</div> <div>4. Adjust HTOF with the FUNCTION (◀/▶) key until both lengths of the upper side and lower side of the cross-hatch pattern become equal.</div>
<div><div>Pallalel</div></div>				

■ GEOMETRY MENU ADJUSTMENT (Adjust 4:3MODE / 16:9MODE respectively)

Item	Measuring instruments	Test point	Adjustment part	Description
VERTICAL SIZE adjustment (50Hz) 	Signal generator Remote control unit		VSIZ	<ol style="list-style-type: none"> 1. Receive a PAL B/G cross-hatch pattern of vertical frequency 50Hz. 2. Enter SERVICE MENU. 3. Press the GREEN key on the remote control unit then enter the GEOMETRY MENU. 4. Select VSIZ (Vertical size) with the FUNCTION (▲/▼) key. 5. Adjust VSIZ with the FUNCTION (◀/▶) key until the horizontal black lines on both the upper and lower part of the pattern become very close to the upper and lower horizontal sides of picture size and nearly about to disappear. 6. Check and readjust VSIZ item if the adjustment becomes improper after some other geometric adjustments are done.
VERTICAL POSITION adjustment (50Hz) 	Signal generator Remote control unit		VPOS	<ol style="list-style-type: none"> 1. Receive a PAL B/G circle pattern signal of vertical frequency 50Hz. 2. Enter GEOMETRY MENU. 3. Select VPOS (Vertical position) with the FUNCTION (▲/▼) key. 4. Adjust VPOS with the FUNCTION (◀/▶) key until the circle pattern is vertically centered. (A=B) 5. Check and readjust VPOS item if the adjustment becomes improper after some other geometric adjustments are done.
VERTICAL S-CORRECTION adjustment (50Hz) 	Signal generator Remote control unit		VSCO	<ol style="list-style-type: none"> 1. Receive a PAL B/G cross-hatch pattern signal of vertical frequency 50Hz. 2. Enter GEOMETRY MENU. 3. Select VSCO (Vertical s-correction) with the FUNCTION (▲/▼) key. 4. Adjust VSCO with the FUNCTION (◀/▶) key until the vertical length of the center squarer of the cross-hatch pattern becomes equal to upper and lower part squares of the cross-hatch pattern. 5. Check and readjust VSCO item if the adjustment becomes improper after some other geometric adjustments are done.

Item	Measuring instrument	Test point	Adjustment part	Description
VERTICAL CORNER CORRECTION adjustment (50Hz)	Signal generator Remote control unit		VCCO	<ol style="list-style-type: none"> 1. Receive a PAL B/G cross-hatch pattern signal of vertical frequency 50Hz. 2. Enter GEOMETRY MENU. 3. Select VCCO (Vertical corner correction) with the FUNCTION (▲/▼) key. 4. Adjust VCCO with the FUNCTION (◀/▶) key until the vertical length of the upper and lower part squares of the cross-hatch pattern become equal to each other. 5. Check and readjust VCCO item if the adjustment becomes improper after some other geometric adjustments are done.
HORIZONTAL SIZE adjustment (50Hz)	Signal generator Remote control unit		HSIZ	<ol style="list-style-type: none"> 1. Receive a PAL B/G cross-hatch pattern signal of vertical frequency 50Hz. 2. Enter GEOMETRY MENU. 3. Select HSIZ (Horizontal size) with the FUNCTION (▲/▼) key. 4. Adjust HSIZ with the FUNCTION (◀/▶) key until the vertical black lines on both the left and right part of the cross-hatch pattern become very close to the left and right horizontal sides of picture tube and nearly about to disappear.
				
HORIZONTAL POSITION adjustment (50Hz)	Signal generator Remote control unit		HPOS	<ol style="list-style-type: none"> 1. Receive a PAL B/G circle pattern signal of vertical frequency 50Hz. 2. Enter GEOMETRY MENU. 3. Select HPOS (Horizontal position) with the FUNCTION (▲/▼) key. 4. Adjust HPOS with the FUNCTION (◀/▶) key until the circle pattern is horizontally centered.(C=D) 5. Check and readjust HPOS item if the adjustment becomes improper after some other geometric adjustments are done.
				

Item	Measuring instrument	Test point	Adjustment part	Description
HORIZONTAL PINCUSHION adjustment (50Hz)	Signal generator Remote control unit		HPIN	<ol style="list-style-type: none"> 1. Receive a PAL B/G cross-hatch pattern signal of vertical frequency 50Hz. 2. Enter GEOMETRY MENU. 3. Select HPIN (Horizontal pincushion) with the FUNCTION (▲/▼) key. 4. Adjust HPIN with the FUNCTION (◀/▶) key until the bending of the vertical line of the cross-hatch pattern are corrected. 5. Check and readjust HPIN item if the adjustment becomes improper after some other geometric adjustments are done.
HORIZONTAL CORNER CORRECTION adjustment (50Hz)	Signal generator Remote control unit		HCCO	<ol style="list-style-type: none"> 1. Receive a PAL B/G cross-hatch pattern signal of vertical frequency 50Hz. 2. Enter GEOMETRY MENU. 3. Select HCCO (Horizontal corner correction) with the FUNCTION (▲/▼) key. 4. Adjust HCCO with the FUNCTION (◀/▶) key until the bending of the vertical line of the cross-hatch pattern are corrected. 5. Check and readjust HCCO item if the adjustment becomes improper after some other geometric adjustments are done.
HORIZONTAL TRAPEZOID adjustment (50Hz)	Signal generator Remote control unit		HTRP	<ol style="list-style-type: none"> 1. Receive a PAL B/G cross-hatch pattern signal of vertical frequency 50Hz. 2. Enter GEOMETRY MENU. 3. Select HTRP (Horizontal trapezoid) with the FUNCTION (▲/▼) key. 4. Adjust HTRP with the FUNCTION (◀/▶) key until both lengths of the upper side and lower side of the cross-hatch pattern become equal.(A=B)



■ WHITE BALANCE ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description
WHITE BALANCE adjustment (Low light)	Signal generator Remote control unit		WR WG WB	1. Receive a black & white signal (colour off). 2. Enter SERVICE MENU. 3. Select WR / WG / WB with the (▲/▼) key, respectively. 4. Adjust WR / WG / WB with the FUNCTION (◀/▶) key, respectively, until the white part turns to pure white without any other colour.
WHITE BALANCE adjustment (High light)	Signal generator Remote control unit		BR BG	1. Receive a black & white signal (colour off) 2. Enter SERVICE MENU. 3. Select BR / BG with the FUNCTION (▲/▼) key respectively. 4. Adjust BR / BG with the FUNCTION (◀/▶) key respectively, until the white part of screen make white colour.

■ TXT BRIGHTNESS ADJUSTMENT

Item	Measuring instrument	Test point	Adjustment part	Description				
TELETEXT BRIGHTNESS adjustment	Remote control unit			<div>1. Receive a teletext broadcast.</div> <div>2. Enter the SERVICE MENU.</div> <div>3. Press the TELETEXT key on the remote control unit, then change TXT brightness.</div> <div>4. Adjust the TXT brightness with FUNCTION (◀/▶) key.</div> <div>5. Press the TELETEXT key again. You can return to the SERVICE MENU.</div> <div><table><tr><td></td><td>TXT BRIGHTNESS</td></tr><tr><td>Recommended value</td><td>025</td></tr></table></div>		TXT BRIGHTNESS	Recommended value	025
	TXT BRIGHTNESS							
Recommended value	025							