


Confirming the device registration of COOLPIX990/880 - Windows 98 Second Edition (SE)

The following explanation uses COOLPIX990 as an example.


After installing Nikon View 5 (device driver) and restarting the computer, connect your camera to the computer using a USB cable and turn on the camera. The camera is registered automatically.



Follow the instructions below to check that the camera has been correctly registered with the system.

Step 1

Right-click the **My Computer** icon on the desktop. Select **Properties** from the menu which appears. The **System Properties** dialog box opens. Click the **Device Manager** tab.




Before connecting the camera to the computer

Be sure to install Nikon View 5 (device driver) before connecting your camera to the computer.


Click [here](#)  to proceed to the next step.


Step 2

Confirm that **Imaging Device** is listed in the **Device Manager** tab, then click the plus sign (+) next to **Imaging Device**.



If Imaging Device does not appear


If **Nikon Digital Camera E990** is listed under **Other devices**, click [here](#) .



If **Imaging Device** is not listed in the **Device Manager** and **Nikon Digital Camera E990** is not listed under **Other devices**, restart your computer and return to [Step 1](#).


Step 3

After confirming that **Nikon COOLPIX990** is listed under **Imaging Device**, double-click the listing to open the **Properties** window.



Step 4

The **Nikon COOLPIX990 Properties** dialog box will be displayed. Click the **General** tab and confirm that **This device is working properly** appears under **Device status**. Click **OK**.



Device registration is now complete. Click **OK** to close the **System Properties** dialog box.

[Click here](#)  to return to the **Nikon View 5 Reference Manual**.