

Device Registration (if Nikon Transfer does not start)

Registering your camera with Windows

Windows

Instructions for installing or updating device drivers are divided according to camera type and the operating system used.

Camera	Operating system	
COOLPIX series (excluding 990/880) / D100	 <i>Windows XP Home Edition /Professional</i>	 <i>Windows 2000 Professional</i>
	 <i>Windows Millennium Edition (Me)</i>	 <i>Windows 98 Second Edition (SE)</i>
COOLPIX990 COOLPIX880	 <i>Windows XP Home Edition /Professional</i>	 <i>Windows 2000 Professional</i>
	 <i>Windows Millennium Edition (Me)</i>	 <i>Windows 98 Second Edition (SE)</i>
Nikon D1 Nikon D1x Nikon D1H	 <i>Windows XP Home Edition /Professional</i>	 <i>Windows 2000 Professional</i>
	 <i>Windows Millennium Edition (Me)</i>	 <i>Windows 98 Second Edition (SE)</i>
D1 (driver update for those who are using the camera with existing copies of Nikon View DX or Nikon Capture)	 <i>Windows 2000 Professional</i>	 <i>Windows Millennium Edition (Me)</i>
	 <i>Windows 98 Second Edition (SE)</i>	

