

# Registering the DI/DIx/DIH under Windows XP (Home Edition/Professional)

## Installing Windows Hardware Drivers for the DI/DIx/DIH


### Before You Begin

Confirm that your OHCI-compliant IEEE 1394 interface board or card has been correctly registered with the system.

Select **Control Panel** from the **Start** menu to open the Control Panel window. Click the **Performance and Maintenance** icon inside the Control Panel window to open the Performance and Maintenance window.

Click the **System** icon inside the Performance and Maintenance window to open the System Properties window.

Select the **Hardware** tab and click the **Device Manager** button to open Device Manager window shown below.



If the camera has been correctly registered with the system, the controller for your camera should appear under 1394 Bus Controller.

If “IEEE 1394 Bus host controllers” is not listed in the Device Manager, or if your IEEE 1394 interface board or card is listed as an unknown or miscellaneous device or is preceded by a red or yellow warning icon, follow the instructions in the manual provided with the board to ensure that the drivers are properly installed.

After installing Nikon View 5 (device driver) and restarting the computer, connect your camera to the computer using an IEEE 1394 cable and turn on the camera. The camera is registered automatically.

### Log On

You will need to log on as the “Computer Administrator” to register your camera.

### Before connecting the camera to the computer

Be sure to install Nikon View 5 (device driver) before connecting your camera to the computer.




Follow the instructions below to check that the camera has been correctly registered with the system.

## Step 1

Select **Control Panel** from the **Start** menu to open the Control Panel window. Click the **Performance and Maintenance** icon inside the Control Panel window to open the Performance and Maintenance window.

Click the **System** icon inside the Performance and Maintenance window to open the System Properties window.


Select the **Hardware** tab and click the **Device Manager** button to open Device Manager window shown below.



The Device Manager will be displayed. After confirming that “Nikon 1394 Protocol Device” is listed in the Device Manager, click the “+” sign to its left.

## If “Nikon 1394 Protocol Device” does not appear


If “NIKON DIX (DI/DIH)” is listed under “Other devices”, click [here](#) and reinstall the device drivers.



If “Nikon 1394 Protocol Device” is not listed in the Device Manager and “NIKON DIX (DI/DIH)” is not listed under Other Devices, disconnect the camera, and restart the computer. When the computer has restarted, reconnect the camera to the computer.


## Step 2

After confirming that “Nikon Digital Camera D1 Series” is listed under “Nikon 1394 Protocol Device,” double-click the listing to open the Properties window.



## Step 3

The Nikon Digital Camera D1 Series Properties dialog will be displayed. Click the General tab and confirm that “This device is working properly” appears under “Device status”. Click **OK**.



Close the Device Manager, then click **OK** to close the System Properties window. Device registration is now complete.