

Nikon View 5 — Applications

Nikon View 5 version 5.1 contains four separate applications; Nikon Transfer, Nikon Browser, Nikon Viewer and Nikon Editor. Click the illustrations below for detailed instructions on how to use each application.

A - Pictures taken with a Nikon Digital Camera

NikonTransfer starts automatically when camera is connected to the computer




Nikon Transfer

B - Pictures taken with a Nikon Digital Camera

Connect the camera to your computer and transfer your pictures using the TRANSFER button



Transfer Button


Two windows are shown: Nikon Editor on the left and Nikon Viewer on the right. Both display a large image of a sunflower. Yellow arrows point from the Nikon Browser window below towards these two windows. The Nikon Editor window has a small icon in the bottom right corner, and the Nikon Viewer window has a small icon in the bottom right corner.

Nikon Editor

Select the image you want to edit from the Browser thumbnail list and click the  icon

Nikon Viewer

Choose the image you want to view from the Browser thumbnail list and click the  icon

A screenshot of the Nikon Browser software window. It shows a file explorer view of a folder named 'My Pictures\Img001'. The main area displays a grid of image thumbnails. The top of the window shows shooting data for a selected image: Nikon CoolPix2500, 2002/04/15 10:40:23, JPEG (8-bit) Normal, Image Size: 1600 x 1200, Color, Converter/Lens: None, Focal Length: 5.6mm, Exposure Mode: Programmed Auto, Metering Mode: Multi-Pattern, 1/63.9 sec - f/2.7, Exposure Comp.: 0 EV, Sensitivity: Auto, White Balance: Auto, AF Mode: AF-S, Tone Comp.: Normal, Flash Sync Mode: Front Curtain, Digital Zoom Ratio: 1.00, Saturation comp.: 0, Sharpening: Auto, Noise Reduction: OFF.

Nikon Browser



E-mail



Print out



Slideshow

