

Confirming the device registration (COOLPIX series / DI00) - Windows XP Home Edition/Professional -

The following explanation uses COOLPIX2500 as an example.

After installing Nikon View 5 (device driver) and restarting the computer, connect your camera to the computer using a USB cable and turn on the camera. The camera is registered automatically.



If the **Removable disk** dialog box is displayed after registration, click the **Cancel** button and close the dialog box.



Log on

You will need to log on as Computer Administrator to register the camera.



Before connecting the camera to the computer

Be sure to install Nikon View 5 (device driver) before connecting your camera to the computer.


Follow the instructions below to check that the camera has been correctly registered with the system.

Step 1

Select **Control Panel** from the **Start** menu to open the **Control Panel** window.

Click the **Performance and Maintenance** icon inside the **Control Panel** window to open the **Performance and Maintenance** window.

Click the **System** icon inside the **Performance and Maintenance** window to open the **System Properties** window.




Open the **Hardware** tab and click the **Device Manager** button in the **Device Manager** area.



Step 2


The **Device Manager** will be displayed.

Confirm that **Disk drives**, **Storage volumes**, and **Universal Serial Bus controllers** are listed in **Device Manager**. Then, click the plus sign (+) next to each of these device types.



Step 3

Confirm that **Nikon Digital Camera USB Device**, **Generic Volume**, and **USB Mass Storage Device** are listed respectively under **Disk drives**, **Storage volumes**, and **Universal Serial Bus controllers**. Double-click each of these listings to open the associated **Properties** window.






If the **Nikon Digital Camera E2500** is listed under **Other devices**, delete **Nikon Digital Camera E2500**, then turn off the camera and turn it on again.

Step 4

The **Properties** for the selected device are displayed.

Click the **General** tab and confirm that **This device is working properly** appears under **Device status**. Click **OK**.



Click **OK** to close the **System Properties** dialog box.