


Reinstalling the device driver (COOLPIX990/880) - Windows Millennium Edition (Me) -

If **Nikon Digital Camera E990(E880)** is listed under **Other devices**, you need to reinstall the device driver.


Step 1

Double-click the listing for the **Nikon Digital Camera E990** that appears under **Other devices**.




Step 2

The **Nikon Digital Camera E990 Properties** dialog box will be displayed. Open the **General** tab and click **Reinstall Driver**.



Step 3

The Windows **Update Device Driver Wizard** will be displayed. Insert the Nikon View 5 CD into the CD-ROM drive. You can prevent the **Welcome** dialog from opening automatically by holding down the SHIFT key while inserting the CD. Make sure **Automatic search for a better driver** is selected, and click **Next** to update the device driver automatically.



If the **Welcome** dialog box appears when the CD-ROM is inserted, close the dialog box by clicking the **Exit** button.


Step 4

A dialog box will be displayed indicating that the driver was successfully updated. Click **Finish** to close the dialog box.



Step 5

Click the **General** of the **Nikon COOLPIX990 Properties** dialog box, and confirm that **This device is working properly** appears under **Device status**. Click **Close**.



Step 6

Click **OK** to close the **System Properties** dialog box.

