



9 Set the “MINUTE” using [▲] and [▼].

- After setting the minutes, press [▶] to advance to “DST” (Daylight Savings Time).




10 Select “ON” or “OFF” using [▲] and [▼].



11 Select “TIME ZONE” using [▶], and set time zone using [▲] and [▼].

- It is possible to select from the following time zones.
EST, CST, MST, PST, HST



12 Press [SELECT].

- The clock now starts running.


Note:

- Time Zone indicates the time difference with the standard time. If “+9 hr” is indicated, this means the time zone is 9 hours ahead of the standard time.


3. Time Zone Adjust

If the time zone information received via radio transmission differs to the actual time zone when “Auto Clock Setting” has been selected, adjust the time zone using the following procedure.


3 After performing steps 1 and 2 on p. 108, select “6 Clock Settings” using [▲] and [▼], and press [SELECT].



4 Select “Time Zone Adjust” using [▲] and [▼], and press [SELECT].



5 Select “-1”, “0” or “+1” using [◀] and [▶], and press [SELECT].



Notes:

- If “Auto Clock Setting” is not possible, it is also not possible to perform “3 Time Zone Adjust” on the “Clock Settings” screen.
- If the “Time Zone” setting is adjusted with the clock settings and saved, the date information recorded on the disc will also be adjusted accordingly.

7 Channel Settings

1. Antenna System

Refer to p. 18.

2. Auto Channel Setting

Refer to p. 18.

3. Manual Channel Setting

Refer to p. 19.

4. Channel Captions

Refer to p. 19.

5. VCR Plus+CH Setting

Refer to p. 20.