


Digital photo printer connections

You can easily any scene(s) if you connect a digital photo printer (optional accessory) to the VIDEO PRINTER OUT (S-video output) connector.

- Before proceeding with the connections, turn off the power of the components and make sure that your hands are dry.
- Read the operating instructions of the digital photo printer.

Connect the components properly in the numerical order below.



Note:

- Copyright laws prohibit the use of material printed from sources other than what you have produced yourself or pictures you yourself have shot without the permission of the copyright holders except in cases where that material is to be used for your own personal enjoyment or entertainment.