

### ■ To stop the disc formatting

Select “No” in step 3 or 4, and press [SELECT].

- When “Yes” is selected in step 4 and [SELECT] is pressed, formatting can no longer be stopped.

### Note:

- Under no circumstances must the power be turned off or the power cord disconnected while the “Formatting the Disc...” display is on the screen. Failure to heed this warning may render the disc unusable.

### Hints:

- Only DVD-RAM discs can be formatted: no other discs can be formatted.
- A disc cannot be formatted when its write protect tab has been set to PROTECT. Release the tab from this position before proceeding.
- When program protection or disc protection has been set by the direct navigator, the “Contents on the disc have been protected” message appears in step 4. To proceed with formatting, select “Yes.” In this case, all the recordings will be erased despite the protection.
- If the formatting is taking 2 minutes or more, it can be suspended at any time by pressing [RETURN]. However, if formatting has been suspended midway, the disc cannot be used as is: it must be formatted again.
- If the “Unable to Format. Please use 4.7GB DVD-RAM Disc.” message was displayed when “Yes” was selected in step 3, it may mean that the disc in question cannot be used with this unit.


## 6 Clock Settings

Usually, the DVD Video Recorder’s auto setup function automatically adjusts the clock to the correct time. Under some reception conditions, however, the DVD Video Recorder cannot set the clock automatically. In this case, follow the steps below to manually set the clock.



### 1 Auto Clock Setting

If a TV station transmits a signal for time setting, performing the steps below activates the automatic time setting function and the time is corrected automatically.

- 3** After performing steps 1 and 2 on p. 108, select “6 Clock Settings” using [▲] and [▼], and press [SELECT].



- 4** Select “Auto Clock Setting” using [▲] and [▼], and press [SELECT].



- Item “3 Time Zone Adjust” ① is displayed when the settings for “1 Auto Clock Setting” have been completed. (Item ① will not appear if the settings for “1 Auto Clock Setting” have not been completed or if “2 Manual Clock Setting” has been set.)
- If the channel settings have been performed, “1 Auto Clock Setting” will be displayed for title ②; if the channel settings have not been performed, “1 Auto Channel/Clock Setting” will be displayed.
- Under adverse reception conditions, etc., the automatic time setting function may not work. If the reception conditions improve later on, it may be possible to activate this function.

### Notes:

- The built-in clock employs the 12-hour system.
- In case of a power failure, an automatic back-up system maintains the operation of the clock for at least 5 years.
- The automatic time setting function checks and if necessary adjusts the time every day. The automatic time setting function only works when the DVD Video Recorder is switched off.
- The clock setting is performed automatically when the auto channel setting is performed.
- When the power to the unit is off, the clock is adjusted 3 times a day (7:00 a.m., 12:00 p.m. and 7:00 p.m.) based on time information signals sent from TV broadcast stations.