




## 3 Audio Settings (continued)

### 6. MTS/SAP

- 3** After performing steps 1 and 2 on p. 108, select “6 MTS/SAP” using [▲] and [▼], and press [SELECT].



- 4** Select the item to be set using [▲] and [▼], and press [SELECT].



The table below shows the TV broadcast type, MTS settings, and audio recording patterns.

TV Broadcast	MTS Setting	Recording Sound	
		L	R
Mono	Stereo	Mono	Mono
	SAP		
	Mono		
Stereo	Stereo	L	R
	Mono	L+R (Mixed)	L+R (Mixed)
Mono and SAP	Stereo	L+R (Mixed)	L+R (Mixed)
	Mono	L+R (Mixed)	L+R (Mixed)
Stereo and SAP	Stereo	L+R (Mixed)	SAP
	SAP	L+R (Mixed)	SAP
	Mono	L+R (Mixed)	L+R (Mixed)

#### MONO Position

If the sound of a Stereo or SAP broadcast is impaired by noise due to weak reception, set MTS to MONO.

To resume stereophonic recording, set MTS to Stereo or SAP.

## 4 Re-initialize Setting (Restoring the factory setting)

After performing step 1 on p. 108, select “4 Re-initialize Setting” using [▲] and [▼], and press [SELECT].

**3** Select the item to be set using [▲] and [▼], and press [SELECT].



### 1 No

This keeps in place whatever changes have been made to the items in Settings “1 Set Up,” “2 Video Settings” and “3 Audio Settings”.

### 2 Yes

This returns the settings changed in “1 Set Up,” “2 Video Settings” and “3 Audio Settings” to the factory settings.

• However, the settings made for “8 Ratings” of “1 Set Up” in the Initial Settings and the input password will not be restored to their initial settings.