


## Editing play lists (continued)

### 2 Erasing scenes


-Performing these steps will erase the selected scenes and they cannot be restored.

•Proceed after performing steps 1 to 3 on p. 82.

**4** Select “Add/Erase” using [▲] and [▼], and press [SELECT].



**5** Select “Erase” by pressing [▲] and [▶], and then press [SELECT].



**6** Select the scene to be erased using [◀], [▲], [▶] and [▼], and press [SELECT].


•In the example shown, scene 4 is erased.




**7** Select “Yes” using [◀], and press [SELECT].



•The scene is now erased from the play list.





### 3 Erasing all scenes from a play list

-Performing these steps will erase all the scenes and they cannot be restored.

•Proceed after performing steps 1 to 3 on p. 82.

#### 4 Select “Add/Erase” using [▲] and [▼], and press [SELECT].



#### 5 Select “Erase All” by pressing [▲] and [▶], and then press [SELECT].



•All the scenes are now selected.



#### 6 Press [SELECT].

#### 7 Select “Yes” using [◀], and press [SELECT].

•All the scenes are now erased from the play list.



**Note:**

When all the scenes are to be erased, the play list itself will also be erased.