

# Table of Contents

## Dear Customers

Thank you for purchasing this Panasonic DVD Video Recorder. We strongly recommend that you carefully study the Operating Instructions before attempting to operate the recorder and that you note the listed precautions.

The model number and serial number of this recorder can be found on either the back or the bottom of the recorder. Please note them in the space provided below and retain this booklet as a permanent record of your purchase to aid identification in the event of theft.

**MODEL NUMBER:**

**SERIAL NUMBER:**

### General Information

Safety information .....	4
Precautions .....	5
Disc information and care .....	6
Accessories .....	8
Front panel controls and functions .....	9
Rear panel connections .....	10
Display information .....	11
Remote control functions .....	13

### Preparation

Remote control unit preparation .....	14
Basic connections .....	15
Auto Tuning .....	17
Channel Settings .....	18
• Auto Tuning Using the Menu Display .....	18
• Manual Channel Setting .....	19
• Channel Captions .....	19
• VCR Plus+ CH Setting .....	20
Setting the remote control for TV operation .....	20
Inserting discs .....	21

### Playback

Playing discs .....	22
• Listening through headphones .....	23
• When the menu screen has appeared .....	24
• Play without using the menu .....	25
Using the menu .....	26
• Operating the DVD menu .....	26
• Selecting a title .....	27
Playback modes .....	28
• Play pause (still picture), frame advance (reverse), slow playback, fast forward and reverse search playback .....	28
• Using the jog dial and shuttle ring .....	30
• Skipping chapters, tracks, and programs .....	32
• One-minute skip .....	34
• Playing back selected chapters or tracks by designating numbers (direct search) .....	34
Program playback .....	35
Random playback .....	36
Operations using the menu bar (overview) .....	37
• Menu bar basic operations .....	37
• Screen displays .....	38
• Disc information screen .....	40
• Unit information screen .....	42
• Shuttle screen .....	44
Operations using the menu bar (details) .....	45
• Storing favorite positions in the memory (markers) .....	45
• Playback from marker positions .....	47
• Repeat playback between two designated points (A-B repeat) .....	49
• Repeat playback of an entire disc, program, title, chapter or track .....	50
• Repeating programmed tracks .....	51
• Changing the viewing angle .....	51

## Recording and Erasing

<b>Recording TV programs</b> .....	52
• Recording procedure .....	52
• Adjusting the recording level .....	54
• Watching one program while recording another .....	54
<b>End time programmed recording</b> .....	55
<b>Erasing recorded programs</b> .....	56
• Erasing programs one at a time .....	56
• Erasing all the programs at once .....	57
• Erasing programs one at a time with the erase list .....	58
• Erasing all the programs at once with the erase list .....	60
<b>Timer Recordings</b> .....	62
• Programming with the VCR Plus+ Function .....	62
• Programming with the on screen display .....	64
<b>Viewing the last recorded/timer recorded program immediately</b> .....	67

## HANDY FUNCTIONS

<b>Using the direct navigator</b> .....	68
<b>Direct navigator program functions</b> .....	70
<b>Direct navigator disc functions</b> .....	76
<b>Creating and playing play lists</b> .....	80
• Creating play lists .....	80
• Playing back play lists .....	81
<b>Editing play lists</b> .....	82
<b>Entering titles</b> .....	87
<b>Virtual Surround Sound (V.S.S.)</b> .....	88
• Enjoying V.S.S. through the front speakers .....	88
• Enjoying V.S.S. through the headphones .....	89
<b>Cinema picture quality</b> .....	89
<b>Digital noise reduction (DNR)</b> .....	90
<b>Audio mode</b> .....	91
<b>On screen display information</b> .....	92
• Counter display information .....	93
• Switching the displays .....	94
<b>Programming the remote control</b> .....	95

## Advanced Connections

<b>Connecting an external component</b> .....	97
<b>Dubbing / Editing</b> .....	98
<b>Connecting a cable TV box (adaptor)</b> .....	99
<b>Connections to other video components</b> .....	101
<b>Advanced connections guide</b> .....	102
<b>Advanced connections</b> .....	104
• Configuring a Dolby Digital 3/2.1 channel surround system (basic system) .....	104
• Connecting a 3/2.1 channel surround system using an amplifier with a built-in Dolby Digital & dts decoder .....	105
• Connecting to a 2-channel analog amplifier .....	106
• Connecting to a 2-channel digital amplifier .....	106
• Recording on a deck connected to the amplifier .....	106
• Recording directly onto an MD, etc. ....	106
<b>Digital photo printer connections</b> .....	107

## Initial Settings

<b>Changing the initial settings</b> .....	108
<b>1 Set Up</b> .....	110
<b>2 Video Settings</b> .....	116
<b>3 Audio Settings</b> .....	122
<b>4 Re-initialize Setting</b> .....	127
<b>5 Disc Format</b> .....	128
<b>6 Clock Settings</b> .....	129
<b>7 Channel Settings</b> .....	18

## Useful Information

<b>TV screen line-up</b> .....	132
<b>Troubleshooting</b> .....	133
• Self-diagnosis display function .....	133
<b>Error messages</b> .....	136
<b>Q&amp;A</b> .....	137
<b>Glossary</b> .....	138