


3 Audio Settings (continued)

4. Speaker Setting

3 After performing steps 1 and 2 on p. 108, select “4 Speaker Setting” using [▲] and [▼], and press [SELECT].



4 Select the item to be set using [◀], [▲], [▼] and [▶], and press [SELECT]. Then select the detailed setting using [▲] and [▼], and press [SELECT].

■ Speaker modes

Set the speaker sizes and whether the speakers are connected or not.

Front speaker, left (L)

Connected “large” (factory setting) ↔ Connected “small”

Front speaker, right (R)

Connected “large” (factory setting) ↔ Connected “small”

Center speaker

Not connected (factory setting) ↔ Connected “large” ↔ Connected “small”

Sub-woofer

Not connected (factory setting) ↔ Connected

Surround speaker, left (SL)

Not connected (factory setting) ↔ Connected “large” ↔ Connected “small”

Surround speaker, right (SR)

Not connected (factory setting) ↔ Connected “large” ↔ Connected “small”

Display example (for surround, left)

Not connected Connected “large” Connected “small”



- Make the large/small selection using the general principle that “large” can reproduce frequencies of 100 Hz and below whereas “small” cannot.

- When “Not connected” is selected for the sub-woofer, front speakers capable of reproducing frequencies of 100 Hz and below are recommended.

