



7. Disc languages

- 3** After performing steps 1 and 2 on p. 108, select “7 Disc Languages” using [▲] and [▼], and press [SELECT].



- 4** Select the item to be set using [▲] and [▼], and press [SELECT].



■ 1. Audio

1. English (factory setting)

The sound is heard in English during disc play.

2. French

The sound is heard in French during disc play.

3. Spanish

The sound is heard in Spanish during disc play.

4. Original

The sound is heard in the disc's original language during disc play.

5. Other ****

Select this setting to hear the sound in selected language during disc play. Use the numeric buttons to enter the language's 4-digit code from among the language codes listed (see right).

■ 2. Subtitle

1. Automatic (factory setting)

The subtitle language is automatically set to match the language of the sound.

2. English

The disc is played with subtitles in English.

3. French

The disc is played with subtitles in French.

4. Spanish

The disc is played with subtitles in Spanish.

5. Other ****

Select this setting to play the disc with subtitles in any other language. Use the numeric buttons to enter the language's 4-digit code among the language codes listed (see right).

■ 3. Menus (Disc menus)

1. English (factory setting)

The menu screens appear in English.

2. French

The menu screens appear in French.

3. Spanish

The menu screens appear in Spanish.

4. Other ****

Select this setting to display the menu screens in any other language. Use the numeric buttons to enter the language's 4-digit code among the language codes listed (see below).

List of language codes

6565: Afar	6566: Abkhazian	6570: Afrikaans
6577: Ameharic	6582: Arabic	6583: Assamese
6588: Aymara	6590: Azerbaijani	6665: Bashkir
6669: Byelorussian	6671: Bulgarian	6672: Bihari
6678: Bengali; Bangla	6679: Tibetan	6682: Breton
6765: Catalan	6779: Corsican	6783: Czech
6789: Danish	6865: Welsh	6869: German
6890: Bhutani	6976: Greek	6978: Geman
6979: Esperanto	6983: Spanish	6984: Estonian
6985: Basque	7065: Persian	7073: Finnish
7074: Fiji	7079: Faroese	7082: French
7089: Frisian	7165: Irish	7168: Scots Gaelic
7176: Galician	7178: Guarani	7185: Gujarati
7265: Hausa	7273: Hindi	7282: Croatian
7285: Hungarian	7289: Armenian	7365: Interlingua
7378: Indonesian	7383: Icelandic	7384: Italian
7387: Hebrew	7465: Japanese	7473: Yiddish
7487: Javanese	7565: Georgian	7575: Kazakh
7576: Greenlandic	7577: Cambodian	7578: Kannada
7579: Korean	7583: Kashmiri	7585: Kurdish
7589: Kirghiz	7665: Latin	7678: Lingala
7679: Laotian	7684: Lithuanian	7686: Latvian; Lettish
7771: Malagasy	7773: Maori	7775: Macedonian
7776: Malayalam	7778: Mongolian	7779: Moldavian
7782: Marathi	7783: Malay	7784: Maltese
7789: Burmese	7865: Nauru	7869: Nepali
7876: Dutch	7879: Norwegian	7982: Oriya
8065: Punjabi	8076: Polish	8083: Pashto, Pushto
8084: Portuguese	8185: Quechua	8277: Rhaeto-Romance
8279: Romanian	8285: Russian	8365: Sanskrit
8368: Sindhi	8372: Serbo-Croatian	8373: Singhalese
8375: Slovak	8376: Slovenian	8377: Samoan
8378: Shona	8379: Somali	8381: Albanian
8382: Serbian	8385: Sundanese	8386: Swedish
8387: Swahili	8465: Tamil	8469: Telugu
8471: Tajik	8472: Thai	8473: Tigrinya
8475: Turkmen	8476: Tagalog	8479: Tonga
8482: Turkish	8484: Tartar	8487: Twi
8575: Ukrainian	8582: Urdu	8590: Uzbek
8673: Vietnamese	8679: Volapük	8779: Wolof
8872: Xhosa	8979: Yoruba	9072: Chinese
9085: Zulu		

Notes:

- If the desired language or sound is not heard, it means that the sound or subtitles selected has not been recorded on the disc.
- If you want to hear the sound (or read the subtitles) in the language of your choice from the very start and if you preset the language ahead of time, the language setting will take precedence when the power is turned on or the disc is changed. However, if the selected language is not recorded on the disc, the language designated by the disc will be heard (or seen). With some DVD discs, the language designated by the disc takes precedence over the unit's language setting.
- After the setting has been changed, it may take a few seconds for the new language to be displayed.