




## Checking the program contents before proceeding with erasure

- 1 Select the program to be erased using [▲] and [▼], and then press [▶].



- 2 Select "Properties" using [▲] and [▼], and [SELECT].


- The title, if one has been provided, the program number, recording date, channel, start time and recording time will be displayed.



- 3 Press [SELECT]. After returning to the erase list screen, press [SELECT] again.

- 4 Select "Yes" using [◀], and press [SELECT].


- The play list created from this program will also be erased.




## When programs are protected (write-protected)

Programs protected with erasure prevention by the direct navigator cannot be erased. To erase them, release the protection setting.


- 1 Select the protected program to be erased using [▲] and [▼], and press [▶].




- 2 Select "Cancel Protection" using [▼], and press [SELECT].




- 3 Select "Cancel protection" using [◀], and press [SELECT].



- The Padlock icon is cleared.



- 4 Press [SELECT].



- 5 Select "Yes" using [◀] and press [SELECT].

- The play list created from the program is also erased.

### ■ How to protect programs

Refer to p. 73.