

Editing play lists

RAM

The following operations can be performed on play lists that have been created:

1. Adding scenes
2. Erasing scenes
3. Erasing all scenes
4. Copying play lists
5. Giving each play list a title
6. Displaying the play list information

Preparation

- Press [DVD].
- Insert a disc on which play lists have been created.

Initial operation for editing play lists

1 During stop:

Press [PLAY LIST].

- The play list guide screen now appears.






2 Select the play list to be edited using [▲] and [▼].



3 Press [▶].

- The scene editing mode menu appears.





1 Adding scenes

• Proceed after performing steps 1 to 3 described on the left.

4 Select “Add/Erase” using [▲] and [▼], and press [SELECT].




5 Confirm that “Add” has been selected, and then select the position where the scene is to be added using [◀], [▲], [▼] and [▶], and press [SELECT].

• In the example shown, a scene is added to the “Scene 4” position in the play list.



6 When the “Add a scene of Play List?” message is displayed, select “Yes” using [◀], and press [SELECT].



7 Designate the START and END points.

• The procedure for registering these points is the same as for creating a new play list (p. 80).



8 After the scene has been added, select “EXIT” using [▼], and press [SELECT].

• The scene is added to the existing list. (Example where a scene has been added to “Scene 4” in the play list.)

