

Manual Channel Setting

Follow steps 1 to 2 on p. 18.

- 3** Select “3 Manual Channel Setting” using [▲] and [▼], and press [SELECT].
- 4** Select the channel using [▲] and [▼], and press [▶].
 - To select the blanking of a program position, press [▲] and [▼] to “ADD” or “DELETE.”

Channel Plan

TV mode

BAND	CHANNEL RECEIVED OFF THE AIR
VHF	2–13
UHF	14–69

CATV mode


BAND	CHANNEL RECEIVED FROM CABLE
VHF	2–13
CATV LOW BAND	95–99
CATV MID/SUPER BANDS	14–36
CATV HYPER BAND	37–65
ULTRA BAND	66–94
	100–125
SPECIAL CATV CHANNEL	1

Channel Captions


1 Preset Captions

Follow steps 1 to 2 on p. 18.

- 3** Select “4 Channel Captions” using [▲] and [▼], and press [SELECT].



- 4** Select “1 Preset Captions” using [▲] and [▼], and press [SELECT].



- 5** Select the broadcast station using [▲] and [▼], and press [▶].
- 6** Select the desired caption using [▲] and [▼].
 - It is possible to select from the following captions.

ABC, PBS, CBS, CNN, FOX, ESPN, NBC, HBO, A&E, AMC, FAM, MAX, MTV, SHOW, TBS, USA, TNT, CBC, UPN, CTV, WB, TSN, DSC, GLOB

■ To cancel the setting midway
Press [CANCEL].

2 Manual Captions

Follow steps 1 to 2 on p. 18.

- 3** Select “4 Channel Captions” using [▲] and [▼], and press [SELECT].
- 4** Select “2 Manual Captions” using [▲] and [▼], and press [SELECT].
- 5** Select the channel number using [▲] and [▼], and press [▶].
- 6** Input caption using [▲] [▼], and [▶].
 - Using [▲], any of the following characters can be input toward the right in sequence.

A, B, C, D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S, T, U, V, W, X, Y, Z, 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, –, &, !, /, (space)

■ To cancel the setting midway
Press [CANCEL].

Channel settings (continued)

VCR Plus+ CH Setting

Follow steps 1 to 2 on p. 18.

- 3** Select "5 VCR Plus+ CH Setting" using [▲] and [▼], and press [SELECT].
- 4** Select the "Guide Channel" number using [▲] and [▼].
- 5** Select "CATV Channel" or "TV Channel" using [▶] and change the channel number using [▲] and [▼].
- 6** Press [◀] to set and press [SELECT].

Note:

- You may leave lines blank if you don't receive that station, or if the Guide Channel number and Cable (or TV) Channel number are the same.

■ To cancel the setting midway

Press [CANCEL].

Setting the remote control for TV operation

You can operate televisions from the manufacturers listed on the left with the remote control after performing the following settings.


Preparation

- Install the batteries in the remote control.

- 1** Refer to the table on the left to find the manufacturer's number for your TV set.
- 2** While holding down [TV], use the numeric buttons to enter the manufacturer number. This completes the settings.
 - Be sure to enter the number in two digits.
Example: 1 → 01
- 3** To confirm that the correct settings were made, check whether the TV can be operated properly.
 - If there is more than one code listed for the same manufacturer, try them all and select the code that works.

Notes:

- If you are using a Panasonic TV, this setting has already been made, so you do not need to perform the above setting procedure. However, this remote control may not work with some Panasonic TVs.
- Some TV models cannot be operated using this remote control (including all non-remote compatible TVs).



- | | | |
|-----|---|---------|
| 1 | 2 | 3 |
| 4 | 5 | 6 |
| 7 | 8 | 9 |
| 100 | 0 | CM SKIP |
- 01 Panasonic/National QUASAR
 - 02 Panasonic/National QUASAR
 - 03 MAGNAVOX SYLVANIA PHILIPS (RC-5)
 - 04 ZENITH
 - 05 THOMSON RCA GE
 - 06 SHARP
 - 07 SHARP
 - 08 SONY
 - 09 TOSHIBA
 - 10 SANYO FISHER
 - 11 JVC
 - 12 HITACHI PHILCO
 - 13 MITSUBISHI
 - 14 SAMSUNG
 - 15 GOLDSTAR/LG
 - 16 GOLDSTAR/LG
 - 17 GOLDSTAR/LG
 - 18 SAMSUNG


Inserting discs

1 Press [OPEN/CLOSE].

- The power is turned on automatically, and the tray slides out.


■ For **DVD-V** **VCD** **CD** and **RAM** without a cartridge

2 Place the disc on the tray with its label surface facing up.




■ For a type 2 cartridge **RAM** disc

2 After checking the cartridge to see which is its top side and which is its reverse side, insert it in the ▲ direction, and place it in such a way that it fits into the outer frame of the disc tray.



Insert the disc in the [▲] direction with the label surface facing up.



OPEN/CLOSE

1 OPEN/CLOSE

