


Each time [DISPLAY] is pressed, the following screens appear in sequence:



Disc information screen: The user can select tracks and switch between the elapsed track time display, remaining track time display and remaining disc time display.

Unit information screen: The user can perform repeat playback, and adjust the master volume level.

Shuttle screen: The user can perform forward/reverse search, and pause.

Notes:

- The item selected by [◀] or [▶] is indicated with a yellow frame.
- “▲, ▼” on the frame denotes that a change can be made using [▲] and [▼].

Example



- Some menu bar items can be operated by using other buttons provided separately whereas other functions can be operated only using the menu bar.


Dedicated menu bar operations

- Raising the volume level of the dialog only (Dialog Enhancer)
- Adjusting the picture quality (U: user picture quality, etc.)
- Selecting the V.S.S. mode (speaker and headphones)
- Adjusting the master volume (unit's output level)

Operations using menu bar (overview) (continued)

Disc information screen

RAM

Display (operation item)	What is selected or executed	Operation method
	Program number (Does not appear during play list playback.)	 Use [▲] and [▼] to select, and press [SELECT].
	Play time display (elapsed time of program) Play location is designated using time.	 Press the numeric buttons, and press [SELECT]. Example: 1 hour 2 minutes 30 seconds 1 → 0 → 2 → 3 → 0 
(Example 1) 	Audio information (a) Audio number (b) Audio signal type ● □ □ (Dolby Digital) (c) Number of audio signal channels ● □ □ (Dolby Digital) 1ch-3/2.1ch*, 1+1ch (SAP)	 Use [▲] and [▼] to make the selection.
	Audio mode LR (left & right) → L (left) → R (right) MAIN → SAP (for recordings in multi-channel sound)	 Use [▲] and [▼] to make the selection.
	Subtitles Subtitles OFF → ON	 Use [▲] and [▼] to make the selection.

• The selection of numbers in the any of the above items can also be performed using the numeric buttons followed by [SELECT].

※ The display on the On-Screen Menu Icons indicates the number of channels recorded on the disc.

Example:

3 / 2 . 1ch

0: No low frequency effect (for subwoofer)
1: Low frequency effect (for subwoofer)

0: No surround
1: Mono surround
2: Stereo surround (left/right)

1: Center
2: Front left+ Front right
3: Front left+ Front right+ Center