

Channel settings


Auto Tuning Using the Menu Display

Broadcast stations should be tuned automatically by Plug in Auto Tuning. However, if auto tuning fails, follow the procedure below.


Preparation

- Connect the antenna cable.
- Confirm that the TV is on and the DVD Video Recorder viewing channel is selected.
- Press [DVD] .

- 1 Press [ACTION].**
 - The Initial Setting screen now appears.
- 2 Select “7 Channel Settings” using [▲] and [▼], and press [SELECT].**
- 3 Select “1 Antenna System” using [▲] and [▼], and press [SELECT].**




- 4 Select the desired system, and press [SELECT].**



- 5 Select “2 Auto Channel Setting” using [▲] and [▼], and press [SELECT].**

- When auto tuning is completed, the on-screen display disappears and the lowest channel position at which a broadcast can be tuned in is received.



Notes:

- Auto tuning searches for TV stations from VHF minimum to UHF maximum and memorizes every tuned program position. Other program positions are skipped.
- Auto tuning takes three or more minutes to complete its search.
- If the DVD Video Recorder is not correctly tuned by auto tuning, follow the procedure on the next page.

■ Automatic clock adjustment

If the clock adjustment is not set before performing the auto channel setting, it will be set automatically upon completion of auto channel setting.

- The “Auto Clock Setting” screen is displayed.

■ If automatic clock adjustment was not possible

If “Auto Clock Setting is incomplete” appears on the screen, set clock manually (refer to page 130).

■ To cancel auto tuning mid-operation

Auto tuning is cancelled by pressing [RETURN] at any time during auto tuning.

