


Set write Protection


Programs can be write-protected so that they will not be erased by mistake. The write protection function can also be released.

- Proceed after performing steps 1 to 3 on p. 70.


4 Select “Set Protection” using [**▲**] and [**▼**], and press [SELECT].



5 Select “Set” using [**◀**], and press [SELECT].



- The padlock icon is shown.



■ Canceling the program protection

1. Repeat above procedure.
2. Select “Cancel Protection” in step 5.
 - The padlock icon is now cleared.

Note:


- Protected programs will be erased if the disc is formatted.

Direct navigator program functions (continued)


Erasing programs partially

- Proceed after performing steps 1 to 3 on p. 70.

- 4 Select “Erase Partially” using [▲] and [▼], and press [SELECT].




- 5 Perform forward (or reverse) search, slow playback, etc. to locate the START point of the part to be erased.



Once the START point has been located, press [SELECT].

- 6 Perform forward (or reverse) search, slow playback, etc. to locate the END point of the part to be erased.



Once the END point has been located, press [SELECT].

- 7 When there is no other part to be erased in the same program: Select “EXIT” using [▼], and press [SELECT].

