


Erasing recorded programs

(continued)


Erasing all the programs at once with the erase list

RAM


- 1 If [REC] is pressed and the screen shown in the figure below appears, select “Yes” using [◀], and press [SELECT] to display the erase list.



- The erase list screen now appears.




- 2 Press [◀].



- 3 Press [SELECT].

- 4 Select “Yes” using [◀], and press [SELECT].

- The play list created from the programs will also be erased.




Note:

- If you do not want to erase the entire contents of the disc, use another disc to proceed with your recording.

Checking the disc contents before proceeding with erasure


- After performing steps 1 and 2 of the procedure shown on page 60, continue as follows.

3 Press [▶].




4 Select "Properties" using [▲] and [▼], and press [SELECT]. Press [SELECT] again to exit "Properties".

- The disc title, if one has been provided, the number of programs, total recording time, remaining time and number of markers placed will be displayed.




5 Press [SELECT] again to continue erasing.



6 Select "Yes" using [◀], and press [SELECT].

- The play list created from the programs will also be erased.



■ Stopping the erasure midway

Select "No" in step 6.

Note:

- Use another disc if you do not wish to erase the programs.

When the disc is write-protected

A disc that has been write-protected with the direct navigator cannot be erased as is. To erase the contents of a write-protected disc, release the protection setting. (P79)

- After releasing the protection setting, proceed with steps 1 to 4 on page 60.