


1 Enter Title (assigning titles to recorded programs)


• Perform steps 1 to 3 described on the previous page.

4 Select “Enter Title” using [▲] and [▼], and press [SELECT].




• The title input screen (displayed below) now appears.

5 Enter the name of the title using [◀], [▲], [▶] and [▼] to select the characters and press [SELECT].



6 When all characters have been entered: Select the “SET” icon using [◀], [▲], [▶] and [▼], and press [SELECT].




Direct navigator program functions (continued)

RAM


Program Properties

- Proceed after performing steps 1 to 3 on p. 70.

4 Select “Properties” using [▲] and [▼], and press [SELECT].



- The title, if one has been entered, the program number, recording date, channel, start time and recording time will be displayed.



Press [SELECT] to clear the display.

