



5 Format Disc

Some DVD-RAM discs for audio-video applications sold on the market are not formatted. This setting enables these discs to be formatted so that they can be used by this unit for recording.


- This unit automatically detects the disc's logical format and physical format, and formats the disc. For this reason, it takes some time (max. 70 minutes) for a disc to be formatted.

* When a disc is formatted, all its recordings are erased and cannot be restored. Be sure to check the disc contents before formatting the disc.


2 After performing step 1 on p. 108, select “5 Format Disc” using [▲] and [▼], and press [SELECT].




3 Select “Yes” using [◀], and press [SELECT].



4 Select “Yes” using [◀], and press [SELECT].



- Disc formatting now commences.



- When formatting is completed, the “Formatting is completed” message appears on the screen.

