


# 1 Set Up (continued)

## 8. Ratings (viewing and listening restrictions)


By setting the restriction level, disc play can be prohibited unless a password is entered so that violent scenes can be skipped or replaced with other scenes. These restrictions are also known as parental controls. The actual restriction method used differs from one disc to another.

### ■ Setting the parental controls

**3** After performing steps 1 and 2 on p. 108, select “8 Ratings” using [▲] and [▼], and press [SELECT].



**4** Select the level using [◀] and [▶], and press [SELECT].



### Level 8 (factory setting)

All discs can be played.

### Levels 7 to 1

Disc play is prohibited for those discs (with adult themes or violence) on which a restriction level is recorded.


### Level 0

Play is prohibited for all discs.

- Discs with adult themes will be played if they have no restriction levels. Select “0” to restrict playback of these discs.

**5** Enter the 4-digit password using the numeric buttons, and press [SELECT].

- Press [CANCEL] if the wrong number has been entered.
- Do not forget your password.



- Example where password “1234” has been input

